



## SET Commands

---

This chapter provides SET (set) commands for the Cisco ONS 15454 SDH.

### 23.1 SET-ALMTH-<MOD2>

Set Alarm Threshold (10GFC, 10GIGE, 1GFC, 1GFICON, 2GFC, 2GFICON, CLNT, D1VIDEO, DS31, DV6000, E1, E3, E4, ESCON, ETRCLO, FSTE, G1000, GFPOS, GIGE, HDTV, ISC1, STM4, STM64, STM1, STM16, OCH, OMS, OTS, POS, STM1E, VC3, VC44C, VC38C, VC464C, VC48C, STS36C, VC4, VC416C, VC42C, VC43C, VC12, VC3, VC12)

---

**Usage Guidelines**

This command sets the alarm thresholds on the following cards/ports/channels: MXP\_2.5G\_10G/TXP\_MR\_10G, optical service channel, optical amplifier, dispersion compensation units, multiplex/demultiplex and OADM.

The only applicable MOD2 values are CLNT/OCH/OMS/OTS.

---

**Category**

DWDM

---

**Security**

Provisioning

---

**Input Format**

SET-ALMTH-<MOD2>:[<TID>]:<AID>:<CTAG>::<CONDTYPE>,<THLEV>[,,,];

---

**Input Example**

SET-ALMTH-{MOD2}::FAC-1-1:1::OPT-LOW,10;

## Input Parameters

Table 23-1 SET-ALMTH-&lt;MOD2&gt; Input Parameters

| Parameter and Values | Description                                                                                                                                                                                                                        |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AID                  | Access identifier from the “25.1 ALL” section on page 25-1. Must not be null                                                                                                                                                       |
| CONDTYPE             | Condition type for an alarm or a reported event<br>Parameter type is ALM_THR—alarm threshold list for MXP_2.5G_10G, TXP_MR_10G, OSCM, OSC-CSM, OPT-PRE, OPT-BST, MD-4, MUX-32, DMX-32, AD-1C, AD-2C, AD-4C, AD-1B, and AD-4B cards |
| • BATV-EHIGH         | Battery Voltage - Extremely High                                                                                                                                                                                                   |
| • BATV-ELOW          | Battery Voltage - Extremely Low                                                                                                                                                                                                    |
| • BATV-HIGH          | Battery Voltage - High                                                                                                                                                                                                             |
| • BATV-LOW           | Battery Voltage - Low                                                                                                                                                                                                              |
| • GAIN-HDEG          | Gain not reached—High Degrade Threshold                                                                                                                                                                                            |
| • GAIN-HFAIL         | Gain not reached—High Failure Threshold                                                                                                                                                                                            |
| • GAIN-LDEG          | Gain not reached—Low Degrade Threshold                                                                                                                                                                                             |
| • GAIN-LFAIL         | Gain not reached—Low Failure Threshold                                                                                                                                                                                             |
| • LBCL-HIGH          | Laser Bias current in uA as 1/10% High Warning Threshold, Low Warning Threshold Measured value [0.0%, 100.0%]                                                                                                                      |
| • OPR-HIGH           | Receive power in 1/10 uW Measured value [-40.0 dBm,+30.0 dBm]                                                                                                                                                                      |
| • OPR-LOW            | Receive power in 1/10 uW Measured value [-40.0 dBm,+30.0 dBm]                                                                                                                                                                      |
| • OPT-HIGH           | Transmit power in 1/10 uW. Measured value [-40.0 dBm,+30.0 dBm]                                                                                                                                                                    |
| • OPT-LOW            | Transmit power in 1/10 uW. Measured value [-40.0 dBm,+30.0 dBm]                                                                                                                                                                    |
| • OPWR-HDEG          | Optical Power—High Degrade Threshold                                                                                                                                                                                               |
| • OPWR-HFAIL         | Optical Power—High Failure Threshold                                                                                                                                                                                               |
| • OPWR-LDEG          | Optical Power—Low Degrade Threshold                                                                                                                                                                                                |
| • OPWR-LFAIL         | Optical Power—Low Failure Threshold                                                                                                                                                                                                |
| • VOA-HDEG           | VOA Attenuation—High Degrade Threshold                                                                                                                                                                                             |
| • VOA-HFAIL          | VOA Attenuation—High Failure Threshold                                                                                                                                                                                             |
| • VOA-LDEG           | VOA Attenuation—Low Degrade Threshold                                                                                                                                                                                              |
| • VOA-LFAIL          | VOA Attenuation—Low Failure Threshold                                                                                                                                                                                              |
| THLEVEL              | Threshold level. Float                                                                                                                                                                                                             |

## 23.2 SET-ALMTH-EQPT

Set Alarm Equipment

**Usage Guidelines** This command sets the alarm thresholds to manage the power level monitoring on an NE.

**Category** Equipment

**Security** Provisioning

**Input Format** SET-ALMTH-EQPT:[<TID>]:[<AID>]:<CTAG>::<CONDTYPE>,<THLEV>[,,,];

**Input Example** SET-ALMTH-EQPT:::1::BATV-HIGH,-53.5;  
SET-ALMTH-EQPT::SHELF-2:1::BATV-HIGH,-53.5;

### Input Parameters

**Table 23-2 SET-ALMTH-EQPT Input Parameters**

| Parameter and Values | Description                                                                                                                                                                                             |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AID                  | The node or shelf access identifier from the <a href="#">“25.1.22 SHELF”</a> section on page 25-23. If omitted it addresses the node or first shelf of the node. Must not be null                       |
| CONDTYPE             | Alarm threshold type<br>Parameter type is ALM_THR—alarm threshold list for MXP_2.5G_10G, TXP_MR_10G, OSCM, OSC-CSM, OPT-PRE, OPT-BST, MD-4, MUX-32, DMX-32, AD-1C, AD-2C, AD-4C, AD-1B, and AD-4B cards |
| • BATV-EHIGH         | Battery Voltage - Extremely High                                                                                                                                                                        |
| • BATV-ELow          | Battery Voltage - Extremely Low                                                                                                                                                                         |
| • BATV-HIGH          | Battery Voltage - High                                                                                                                                                                                  |
| • BATV-LOW           | Battery Voltage - Low                                                                                                                                                                                   |
| • GAIN-HDEG          | Gain not reached—High Degrade Threshold                                                                                                                                                                 |
| • GAIN-HFAIL         | Gain not reached—High Failure Threshold                                                                                                                                                                 |
| • GAIN-LDEG          | Gain not reached—Low Degrade Threshold                                                                                                                                                                  |
| • GAIN-LFAIL         | Gain not reached—Low Failure Threshold                                                                                                                                                                  |
| • LBCL-HIGH          | Laser Bias current in uA as 1/10% High Warning Threshold, Low Warning Threshold Measured value [0.0%, 100.0%]                                                                                           |
| • OPR-HIGH           | Receive power in 1/10 uW Measured value [-40.0 dBm,+30.0 dBm]                                                                                                                                           |
| • OPR-LOW            | Receive power in 1/10 uW Measured value [-40.0 dBm,+30.0 dBm]                                                                                                                                           |
| • OPT-HIGH           | Transmit power in 1/10 uW. Measured value [-40.0 dBm,+30.0 dBm]                                                                                                                                         |
| • OPT-LOW            | Transmit power in 1/10 uW. Measured value [-40.0 dBm,+30.0 dBm]                                                                                                                                         |

Table 23-2 SET-ALMTH-EQPT Input Parameters (continued)

| Parameter and Values | Description                            |
|----------------------|----------------------------------------|
| • OPWR-HDEG          | Optical Power—High Degrade Threshold   |
| • OPWR-HFAIL         | Optical Power—High Failure Threshold   |
| • OPWR-LDEG          | Optical Power—Low Degrade Threshold    |
| • OPWR-LFAIL         | Optical Power—Low Failure Threshold    |
| • VOA-HDEG           | VOA Attenuation—High Degrade Threshold |
| • VOA-HFAIL          | VOA Attenuation—High Failure Threshold |
| • VOA-LDEG           | VOA Attenuation—Low Degrade Threshold  |
| • VOA-LFAIL          | VOA Attenuation—Low Failure Threshold  |
| THLEVEL              | Threshold level. Float                 |

## 23.3 SET-ATTR-CONT

Set Attribute Control

### Usage Guidelines

This command sets the attributes associated with an external control. The attributes are used when an external control is operated or released. To send the attributes, use the RTRV-ATTR-CONT command.



#### Note

If the <CONTTYPE> parameter is not specified, the control specified by <AID> is unprovisioned.



#### Note

A control should be unprovisioned before it is reprovisioned to another type of control.

### Category

Environment

### Security

Provisioning

### Input Format

SET-ATTR-CONT:[<TID>]:<AID>:<CTAG>[::<CONTTYPE>];

### Input Example

SET-ATTR-CONT:CISCO:ENV-OUT-1:123::AIRCOND;

## Input Parameters

Table 23-3 SET-ATTR-CONT Input Parameters

| Parameter and Values | Description                                                                                                                              |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| <b>AID</b>           | Access identifier from the “25.1.10 ENV” section on page 25-15. Identifies the external control for which attributes are being retrieved |
| <b>CONTTYPE</b>      | Environmental control type. A null value is equivalent to ALL<br>Parameter type is CONTTYPE—Environmental control types                  |
| • AIRCOND            | Air conditioning                                                                                                                         |
| • ENGINE             | Engine                                                                                                                                   |
| • FAN                | Fan                                                                                                                                      |
| • GEN                | Generator                                                                                                                                |
| • HEAT               | Heat                                                                                                                                     |
| • LIGHT              | Light                                                                                                                                    |
| • MISC               | Miscellaneous                                                                                                                            |
| • SPKLR              | Sprinkler                                                                                                                                |

## 23.4 SET-ATTR-ENV

Set Attribute Environment

## Usage Guidelines

This command sets the attributes associated with an external control.



## Note

- If the <NTFCNCDE>, <ALMTYPE>, and <ALMMSG> parameters are omitted, the environmental alarm specified by <AID> is unprovisioned.
- An alarm should be unprovisioned and you should wait for any raised alarm to clear before reprovisioning the alarm to another alarm type.
- In NOTIF\_CODE, CL is not valid for provisioning commands. It is only valid for autonomous messages.

## Category

Environment

## Security

Provisioning

## Input Format

SET-ATTR-ENV:[<TID>]:<AID>:<CTAG>:[:<NTFCNCDE>],[<ALMTYPE>],[<ALMMSG>];

**Input Example**

```
SET-ATTR-ENV:CISCO:ENV-IN-1:123::MJ,OPENDR,\"OPEN DOOR\";
```

**Input Parameters****Table 23-4 SET-ATTR-ENV Input Parameters**

| Parameter and Values | Description                                                                                                                                          |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>AID</b>           | Access identifier from the “25.1.10 ENV” section on page 25-15. Must not be null                                                                     |
| <b>NTFCNCDE</b>      | Two-letter notification code. Must not be null<br>Parameter type is NOTIF_CODE—two-character notification code associated with an autonomous message |
| • CL                 | The condition causing the alarm has cleared                                                                                                          |
| • CR                 | A critical alarm                                                                                                                                     |
| • MJ                 | A major alarm                                                                                                                                        |
| • MN                 | A minor alarm                                                                                                                                        |
| • NA                 | The condition is not alarmed                                                                                                                         |
| • NR                 | The alarm is not reported                                                                                                                            |
| <b>ALMTYPE</b>       | The alarm type for the environmental alarm. Must not be null<br>Parameter type is ENV_ALM—environmental alarm types                                  |
| • AIRCOMPR           | Air compressor failure                                                                                                                               |
| • AIRCOND            | Air conditioning failure                                                                                                                             |
| • AIRDRYR            | Air dryer failure                                                                                                                                    |
| • BATDSCHRG          | Battery discharging                                                                                                                                  |
| • BATTERY            | Battery failure                                                                                                                                      |
| • CLFAN              | Cooling fan failure                                                                                                                                  |
| • CPMAJOR            | Centralized power major failure                                                                                                                      |
| • CPMINOR            | Centralized power minor failure                                                                                                                      |
| • ENGINE             | Engine failure                                                                                                                                       |
| • ENGOPRG            | Engine operating                                                                                                                                     |
| • ENGTRANS           | Standby engine transfer                                                                                                                              |
| • EXPLGS             | Explosive gas                                                                                                                                        |
| • FIRDETR            | Fire detector failure                                                                                                                                |
| • FIRE               | Fire                                                                                                                                                 |
| • FLOOD              | Flood                                                                                                                                                |
| • FUELLEAK           | Fuel leak                                                                                                                                            |
| • FUSE               | Fuse failure                                                                                                                                         |
| • GASALARM           | Explosive gas, toxic gas, ventilation fail, or gas monitor fail                                                                                      |
| • HATCH              | CEV hatch fail                                                                                                                                       |
| • GEN                | Generator failure                                                                                                                                    |

**Table 23-4** SET-ATTR-ENV Input Parameters (continued)

| Parameter and Values | Description                                               |
|----------------------|-----------------------------------------------------------|
| • HIAIR              | High airflow                                              |
| • HIHUM              | High humidity                                             |
| • HITEMP             | High temperature                                          |
| • HIWTR              | High water                                                |
| • INTRUDER           | Intrusion                                                 |
| • LEVELCON           | Level converter                                           |
| • LVDADSL            | Secondary ADSL low voltage disconnect                     |
| • LVDBYPAS           | Low voltage disconnected bypass                           |
| • LWBATVG            | Low battery voltage                                       |
| • LWFUEL             | Low fuel                                                  |
| • LWHUM              | Low humidity                                              |
| • LWPRES             | Low cable pressure                                        |
| • LWTEMP             | Low temperature                                           |
| • LWWTR              | Low water                                                 |
| • MISC               | Miscellaneous                                             |
| • OPENDR             | Open door                                                 |
| • POWER              | Commercial power failure                                  |
| • PUMP               | Pump failure                                              |
| • PWR-48             | 48V power supply failure                                  |
| • PWR-139            | -139V power converter                                     |
| • PWR-190            | -190V power converter                                     |
| • PWRMJ              | Power supply major                                        |
| • PWRMN              | Power supply minor                                        |
| • RECT               | Rectifier failure                                         |
| • RECTHI             | Rectifier high voltage                                    |
| • RECTLO             | Rectifier low voltage                                     |
| • RINGGENMJ          | Ring generator major                                      |
| • RINGGENMN          | Ring generator minor                                      |
| • RTACADSL           | AC or AC/rectifier power fail ADSL equipment              |
| • RTACCRIT           | AC or AC/rectifier power fail DCL equipment critical site |
| • RTACPWR            | AC or AC/rectifier power fail DCL equipment               |
| • RTACPWRENG         | Commercial AC fail, site equipped with standby engine     |
| • RTBAYPWR           | AC power loss distributed power RT bay                    |
| • RTRVENG            | Retrieve standby engine, commercial AC restored           |
| • SMOKE              | Smoke                                                     |
| • TEMP               | High-low temperature                                      |

Table 23-4 SET-ATTR-ENV Input Parameters (continued)

| Parameter and Values | Description                             |
|----------------------|-----------------------------------------|
| • TOXICGAS           | Toxic gas                               |
| • TREPEATER          | T-repeater shelf                        |
| • VENTN              | Ventilation system failure              |
| ALMMSG               | Alarm message. String. Must not be null |

## 23.5 SET-ATTR-SECUDFLT

Set Attribute Security Default

### Usage Guidelines

This command sets the system-wide default values associated with several security parameters.

The following parameters are set on a system-wide basis for all users and all privilege levels: MXINV, DURAL, UOUT, PFRCD, POLD, PINT, and LOGIN. The PRIVLVL keyword cannot be used to set these parameters for a specific privilege level.

The following parameters are set on a privilege-level basis: PAGE, PCND, and TMOUT. If none of these values are specified, the PRIVLVL keyword must also be present. If none of these parameters are specified, the PRIVLVL keyword cannot be used.



#### Note

Password aging can only be enabled/disabled for all privilege levels. The PRIVLVL keyword cannot be used with PAGE=0 to disable a specific user privilege level.

When system-level and privilege-level keywords are combined in the same command, system-level parameters are still set for all privilege levels, regardless of the value specified by PRIVLVL. Privilege-level parameters are only set for the privilege level specified by PRIVLVL.



#### Note

If PAGE and PINT both have values greater than 0, PINT must be less than PAGE.

The order of keywords is not restricted. Commas are only needed to separate keywords. If no keywords are specified, all parameters are left as is.

### Category

Security

### Security

Superuser

### Input Format

```
SET-ATTR-SECUDFLT:[<TID>]::<CTAG>::[PAGE=<PAGE>],[PCND=<PCND>],
[MXINV=<MXINV>],[DURAL=<DURAL>],[TMOUT=<TMOUT>],[UOUT=<UOUT>],
[PFRCD=<PFRCD>],[POLD=<POLD>],[PINT=<PINT>],[LOGIN=<LOGIN>],
[PRIVLVL=<PRIVLVL>],[PDIF=<PDIF>];
```



**Input Example**

```
SET-ATTR-SECUDFLT:CISCO::123::PAGE=45,PCND=5,MXINV=5,DURAL=30,
TMOUT=0,UOUT=20,PFRCD=NO,POLD=5,PINT=20,LOGIN=MULTIPLE,
PRIVLVL=RTRV,PDIF=1;
```

**Input Parameters****Table 23-5 SET-ATTR-SECUDFLT Input Parameters**

| Parameter and Values | Description                                                                                                                                                                                                                                                                                                                                               |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PAGE</b>          | Password aging interval. It is the number of days before a user is prompted to change his/her password. 0 indicates the policy is turned off and is the default. If PAGE is turned on for all privilege levels and is not specified for each privilege level, it defaults to 45 days. PAGE ranges from 20 to 90 days. Integer                             |
| <b>PCND</b>          | Number of days a password can be used before a new one is mandatory (i.e., the warning period). Default is 5 days. PCND ranges from 2 to 20 days. Integer                                                                                                                                                                                                 |
| <b>MXINV</b>         | Maximum number of consecutive and invalid session setup attempts allowed to occur before an intrusion attempt is suspected (i.e., “Failed Logins Before Lockout” from CTC). 0 indicates the policy is turned off. Default is 5. MXINV ranges from 0 to 10. Integer                                                                                        |
| <b>DURAL</b>         | Time interval (in seconds) during which a userid is locked out when an intrusion attempt is suspected (i.e., the “Lockout Duration”). If the user is locked out until unlocked by a superuser, DURAL=INFINITE. Default is 30 seconds. DURAL ranges from 0 to 600 seconds. String                                                                          |
| <b>TMOUT</b>         | Interval (in minutes) after which a session is terminated if no messages are exchanged between the user and the NE. 0 indicates that the session will not timeout. TMOUT ranges from 0 minutes to 999 minutes. Defaults are 0 (no timeout) for RTRV users, 60 minutes for MAINT users, 30 minutes for PROV users, and 15 minutes for SUPER users. Integer |
| <b>UOUT</b>          | UID aging interval, expressed in days. If a userid has not been used in UOUT days, the user will be forced to change his/her password (or logout) at the next login. No other command is allowed until the password has been changed. 0 indicates the policy is turned off and is the default. UOUT ranges from 0 to 99 days. Integer                     |
| <b>PFRCD</b>         | Indicates a password change is required when a new user establishes a session to the NE for the first time (i.e., “Require password change on 1st login”). Default is NO<br><br>Parameter type is YES_NO—indicates whether the user’s password is about to expire, the user is logged into the NE or the user is locked out of the NE                     |
| • NO                 | No                                                                                                                                                                                                                                                                                                                                                        |
| • YES                | Yes                                                                                                                                                                                                                                                                                                                                                       |
| <b>POLD</b>          | Number of prior passwords that cannot be reused (i.e., “Prevent reusing last X passwords”). Default is 1. POLD ranges from 1 to 10. Integer.                                                                                                                                                                                                              |

Table 23-5 SET-ATTR-SECUDFLT Input Parameters (continued)

| Parameter and Values                                       | Description                                                                                                                                                                                                                                                                                                                                                   |
|------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PINT</b>                                                | Number of days that must pass before a password can be changed. If PINT is 0, the policy is turned off. Default is off. PINT ranges from 20 to 95 days. Integer                                                                                                                                                                                               |
| <b>LOGIN</b>                                               | Number of times a user can log into an NE. LOGIN is either SINGLE or MULTIPLE. If LOGIN is SINGLE, a user can only log into an NE one time with any given userid, regardless of the method of login (i.e., CTC, TL1, etc.). Default is MULTIPLE<br><br>Parameter type is USER_LOGINS—the number of times a user can log into the same NE with the same userid |
| <ul style="list-style-type: none"> <li>MULTIPLE</li> </ul> | A user can log into the same NE many times                                                                                                                                                                                                                                                                                                                    |
| <ul style="list-style-type: none"> <li>SINGLE</li> </ul>   | A user can log into the NE only once (includes both CTC and TL1 sessions)                                                                                                                                                                                                                                                                                     |
| <b>PRIVLVL</b>                                             | User's access privilege<br><br>Parameter type is PRIVILEGE—security level                                                                                                                                                                                                                                                                                     |
| <ul style="list-style-type: none"> <li>MAINT</li> </ul>    | Maintenance security level. 60 minutes of idle time                                                                                                                                                                                                                                                                                                           |
| <ul style="list-style-type: none"> <li>PROV</li> </ul>     | Provision security level. 30 minutes of idle time                                                                                                                                                                                                                                                                                                             |
| <ul style="list-style-type: none"> <li>RTRV</li> </ul>     | Retrieve security level. Unlimited idle time                                                                                                                                                                                                                                                                                                                  |
| <ul style="list-style-type: none"> <li>SUPER</li> </ul>    | Superuser security level. 15 minutes of idle time                                                                                                                                                                                                                                                                                                             |
| <b>PDIF</b>                                                | Indicates how many characters must differ between the old and new password. Default minimum character difference is 1. PDIF ranges from 1 to 5 characters. Integer. Rangeable                                                                                                                                                                                 |

## 23.6 SET-PMMODE-<VC\_PATH>

Set Performance Mode of PM Data Collection (VC44C, VC464C, VC48C, VC4, VC416C, VC42C, VC43C)

### Usage Guidelines

This command sets the mode and turns the PM data collection mode on or off. The Cisco ONS 15454 SDH is capable of collecting and storing section, line, and path PM data.

See [Table 27-1 on page 27-1](#) for supported modifiers by platform.



### Note

- The PM mode and state of an entity are retrieved by using the RTRV-PMMODE command.
- The near-end monitoring of the intermediate-path PM (IPPM) only supports STM1, STM4, STM16, STM64 on the VC Path.
- The far-end IPPM data collection is supported by the MRC-12 card only.

- This release of software supports only the Path (P) mode type PM parameters with this command. This command is not applicable for line (L) and section (S) mode types. The PM monitoring for line and section are supported by the Cisco ONS 15454 SDH, and the storing PM data is always performed.

**Category**

Performance

**Security**

Provisioning

**Input Format**

SET-PMMODE-&lt;VC\_PATH&gt;:[&lt;TID&gt;]:&lt;SRC&gt;:&lt;CTAG&gt;::&lt;LOCN&gt;,&lt;MODETYPE&gt;,[&lt;PMSTATE&gt;];

**Input Example**

SET-PMMODE-VC4:CISCO:VC4-4-1-2:123::NEND,P,ON;

**Input Parameters****Table 23-6** SET-PMMODE-<VC\_PATH> Input Parameters

| Parameter and Values | Description                                                                                                                                                                                                                                          |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SRC</b>           | Source access identifier from the <a href="#">“25.1.8 CrossConnectId” section on page 25-12</a>                                                                                                                                                      |
| <b>LOCN</b>          | Location associated with a particular command. Identifies the location from which the PM mode is to be retrieved. Only the near end PM data collection is supported<br><br>Parameter type is LOCATION—the location where the action is to take place |
| • NEND               | Action occurs on the Near End of the facility                                                                                                                                                                                                        |
| <b>MODETYPE</b>      | The type of PM parameters that the entity or the subentity is to store as a result of an attribute change. Only the path (P) PM parameter is supported.<br><br>Parameter type is PM_MODE—the type of PM parameters                                   |
| • P                  | Transport Path PM parameters                                                                                                                                                                                                                         |
| <b>PMSTATE</b>       | Directs the named PM mode type to turn on or off. A null value defaults to on.<br><br>Parameter type is PM_STATE—directs the named PM mode type - path (P) state                                                                                     |
| • OFF                | Disable the mode                                                                                                                                                                                                                                     |
| • ON                 | Enable the mode                                                                                                                                                                                                                                      |

## 23.7 SET-TH-<MOD2>

Set Threshold (10GFC, 10GIGE, 1GFC, 1GFICON, 2GFC, 2GFICON, CLNT, D1VIDEO, DS3I, DV6000, E1, E3, E4, ESCON, ETRCLO, FSTE, G1000, GFPOS, GIGE, HDTV, ISC1, STM4, STM64, STM1, STM16, OCH, OMS, OTS, POS, STM1E, VC3, VC44C, VC38C, VC464C, VC48C, STS36C, VC4, VC416C, VC42C, VC43C, VC12, VC3, VC12)

### Usage Guidelines

This command sets the threshold for PM and sets the alarm thresholds for the MXP\_2.5G\_10G/TXP\_MR\_10G cards. If this command is used to set the alarm thresholds, the time-period is not applicable.

See [Table 27-1 on page 27-1](#) for supported modifiers by platform.

The rules are as follows: The PM Thresholds have a default of NEND for the location. The Alarm Thresholds do not require or interpret the location. The TMPER is not applicable to alarm thresholds. The TMPER default is 15-MIN. The client ports only accept SDH, Laser and alarm MONTYPES. The trunk ports accept SDH, Laser, alarm, FEC, OTN, and 8B10B MONTYPES.

Refer to the [Cisco ONS SONET TL1 Reference Guide](#) for specific card provisioning rules.

### Category

Performance

### Security

Provisioning

### Input Format

SET-TH-<MOD2>:[<TID>]:<AID>:<CTAG>::<MONTYPE>,<THLEV>,[<LOCN>],[<TMPER>];

### Input Example

SET-TH-T3:CISCO:FAC-1-1:123::CVL,12,NEND,,15-MIN;

### Input Parameters

**Table 23-7 SET-TH-<MOD2> Input Parameters**

| Parameter and Values | Description                                                                                                                   |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------|
| AID                  | Access identifier from the <a href="#">“25.1 ALL” section on page 25-1</a> . All the VC, VT1, and Facility AIDs are supported |
| MONTYPE              | Monitored type<br>Parameter type is ALL_MONTYPE—monitoring type list                                                          |
| • AISSP              | Alarm Indication Signal Seconds—Path                                                                                          |
| • ALL                | All possible values                                                                                                           |
| • BBEP               | SDH Background Block Errors Path                                                                                              |
| • BBE-PM             | OTN—Background Block Errors—Path Monitor Point                                                                                |
| • BBER               | SDH Background Block Error Ratio                                                                                              |

**Table 23-7** SET-TH-<MOD2> Input Parameters (continued)

| Parameter and Values        | Description                                                                                                                              |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| • BBER-PM                   | OTN—Background Block Error Ratio—Path Monitor Point expressed as 1/10th of a percentage.                                                 |
| • BBER-SM                   | OTN—Background Block Error Ratio—Section Monitor Point expressed as 1/10th of a percentage.                                              |
| • BBE-SM                    | OTN—Background Block Errors—Section Monitor Point                                                                                        |
| • BIEC                      | FEC—Bit Errors Corrected                                                                                                                 |
| • BIT-EC                    | The number of bit errors corrected by the FEC algorithm                                                                                  |
| • CGV                       | 8B10B—Code Group Violations                                                                                                              |
| • CVCPP                     | Coding Violations—CP-Bit Path                                                                                                            |
| • CVL                       | Coding Violations—Line                                                                                                                   |
| • CVP                       | Coding Violations—Path                                                                                                                   |
| • CVS                       | Coding Violations—Section                                                                                                                |
| • CVV                       | Coding Violations—Section                                                                                                                |
| • DCG                       | 8B10B—Data Code Groups                                                                                                                   |
| • ESCPP                     | Errored Seconds—CP—Bit Path                                                                                                              |
| • ESL                       | Errored Seconds—Line                                                                                                                     |
| • ESP                       | Errored Seconds—Path                                                                                                                     |
| • ES-PM                     | OTN—Errored Seconds—Path Monitor Point                                                                                                   |
| • ESR                       | Errored Second—Ratio                                                                                                                     |
| • ESR-PM                    | Errored Seconds Ratio—Path monitor Point expressed as 1/10th of a percentage                                                             |
| • ESR-SM                    | Errored Seconds Ratio—Section monitor Point expressed as 1/10th of a percentage                                                          |
| • ESS                       | Errored Seconds—Section                                                                                                                  |
| • ES-SM                     | OTN—Errored Seconds—Section Monitor Point                                                                                                |
| • ESV                       | Errored Seconds—VC Path                                                                                                                  |
| • etherStatsBroadcastPkts   | The total number of good packets received that were directed to a multicast address                                                      |
| • etherStatsCollisions      | Number of transmit packets that are collisions                                                                                           |
| • etherStatsCRCAAlignErrors | The total number of packets received that have a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets |
| • etherStatsDropEvents      | Number of received frames dropped at the port level                                                                                      |
| • etherStatsFragments       | The total number of packets received that were less than 64 octets                                                                       |
| • etherStatsJabbers         | The total number of packets received that are longer than 1518 octets                                                                    |
| • etherStatsOctets          | The total number of octets of data                                                                                                       |
| • etherStatsOversizePkts    | The total number of packets received that are longer than 1518 octets                                                                    |

Table 23-7 SET-TH-&lt;MOD2&gt; Input Parameters (continued)

| Parameter and Values      | Description                                                                                            |
|---------------------------|--------------------------------------------------------------------------------------------------------|
| • etherStatsPkts          | The total number of packets (including bad packets, broadcast packets, and multicast packets) received |
| • etherStatsUndersizePkts | The total number of packets received that are less than 64 octets                                      |
| • FCP                     | Failure Count—Line                                                                                     |
| • FC-PM                   | OTN—Failure Count—Path Monitor Point                                                                   |
| • FC-SM                   | OTN—Failure Count—Section Monitor Point                                                                |
| • HP-AR                   | Availability Ratio                                                                                     |
| • HP-BBE                  | High-Order Path Background Block Error                                                                 |
| • HP-BBER                 | High-Order Path Background Block Error Ratio                                                           |
| • HP-EB                   | High-Order Path Errored Block                                                                          |
| • HP-ES                   | High-Order Path Errored Second                                                                         |
| • HP-ESA                  | High-Order Path Errored Seconds - A                                                                    |
| • HP-ESB                  | High-Order Path Errored Seconds - B                                                                    |
| • HP-ESR                  | High-Order Path Errored Second Ratio                                                                   |
| • HP-FC                   | High-Order Path Failure Count                                                                          |
| • HP-NPJC-PDET            | High Order Path Negative Pointer Justification Count                                                   |
| • HP-NPJC-PGEN            | High Order Path Pointer Justification Count Seconds                                                    |
| • HP-OI                   | Outage Intensity                                                                                       |
| • HP-PJCDIFF              | High Order Path Pointer Justification Count Difference                                                 |
| • HP-PJCS-PDET            | High Order Path Pointer Justification Count                                                            |
| • HP-PPJC-PDET            | High Order Path Positive Pointer Justification Count                                                   |
| • HP-PPJC-PGEN            | High Order Path, Positive Pointer Justification Count                                                  |
| • HP-SEPI                 | The number of SEP events in available time                                                             |
| • HP-SES                  | High-Order Path Severely Errored Seconds                                                               |
| • HP-SESR                 | High-Order Path Severely Errored Second Ratio                                                          |
| • HP-UAS                  | High-Order Path Unavailable Seconds                                                                    |
| • ifInBroadcastPkts       | Number of broadcast packets received since the last counter reset                                      |
| • ifInDiscards            | The number of inbound packets                                                                          |
| • ifInErrorBytePktss      | Receive Error Byte                                                                                     |
| • ifInErrors              | The number of inbound packets (or transmission units) that contained errors                            |
| • ifInFramingErrorPkts    | Receive Framing Error                                                                                  |
| • ifInJunkInterPkts       | Receive Interpkt Junk                                                                                  |
| • ifInMulticastPkts       | Number of multicast packets received since the last counter reset                                      |
| • ifInOctets              | Number of bytes transmitted since the last counter reset                                               |
| • ifInUcastPkts           | Number of unicast packets received since the last counter reset                                        |
| • ifOutBroadcastPkts      | Number of broadcast packets transmitted                                                                |

**Table 23-7** SET-TH-<MOD2> Input Parameters (continued)

| Parameter and Values    | Description                                                                                            |
|-------------------------|--------------------------------------------------------------------------------------------------------|
| • ifOutDiscards         | The number of outbound packets                                                                         |
| • ifOutErrors           | The number of outbound packets (or transmission units) that could not be transmitted because of errors |
| • ifOutMulticastPkts    | Number of multicast packets transmitted                                                                |
| • ifOutPayloadCrcErrors | Received payload CRC errors                                                                            |
| • ifOutUcastPkts        | Number of unicast packets transmitted                                                                  |
| • IOS                   | 8B10B- Idle Ordered Sets                                                                               |
| • IPC                   | Invalid Packet Count                                                                                   |
| • LBCL-AVG              | Average Laser Bias current in uA                                                                       |
| • LBCL-MAX              | Maximum Laser Bias current in uA                                                                       |
| • LBCL-MIN              | Minimum Laser Bias current in uA                                                                       |
| • LBCN                  | Normalized Laser Bias current for STM1-8                                                               |
| • LBCN-HWT              | Laser bias current                                                                                     |
| • LBCN-LWT              | Laser bias current                                                                                     |
| • LOSSL                 | Loss of Signal Seconds—Line                                                                            |
| • LP-BBE                | Low-Order Path Background Block Error                                                                  |
| • LP-BBER               | Low-Order Path Background Block Error Ratio                                                            |
| • LP-EB                 | Low-Order Path Errored Block                                                                           |
| • LP-ES                 | Low-Order Path Errored Second                                                                          |
| • LP-ESA                | Low-Order Path Errored Seconds - A                                                                     |
| • LP-ESB                | Low-Order Path Errored Seconds - B                                                                     |
| • LP-ESR                | Low-Order Path Errored Second Ratio                                                                    |
| • LP-FC                 | Low-Order Path Failure Count                                                                           |
| • LP-NPJC-DET           | Low Order Negative Pointer Justification Count, Detected                                               |
| • LP-NPJC-GEN           | Low Order Negative Pointer Justification Count, Generated                                              |
| • LP-PPJC-DET           | Low Order Positive Pointer Justification Count, Detected                                               |
| • LP-PPJC-GEN           | Low Order positive Pointer Justification Count, Generated                                              |
| • LP-SEP                | A sequence of between 3 to 9 consecutive SES                                                           |
| • LP-SEPI               | Low-Order Path Severely Errored Period Intensity                                                       |
| • LP-SES                | Low-Order Path Severely Errored Seconds                                                                |
| • LP-UAS                | Low-Order Path Unavailable Seconds                                                                     |
| • MS-PSC                | Protection Switch Count                                                                                |
| • MS-PSD                | Protection Switch Duration                                                                             |
| • NIOS                  | 8B10B—Non Idle Ordered Sets                                                                            |
| • NPJC-PDET             | PPJC-PDET:Negative Pointer Justification                                                               |
| • NPJC-PGEN             | PPJC-PGEN:Negative Pointer Justification                                                               |

Table 23-7 SET-TH-&lt;MOD2&gt; Input Parameters (continued)

| Parameter and Values | Description                                                                                 |
|----------------------|---------------------------------------------------------------------------------------------|
| • OPR-AVG            | Average Receive Power in 1/10 uW                                                            |
| • OPR-MAX            | Maximum Receive Power in 1/10 uW                                                            |
| • OPR-MIN            | Minimum Receive Power in 1/10 uW                                                            |
| • OPRN               | Normalized Optical Receive Power for STM1-8                                                 |
| • OPRN-MAX           | Maximum value for OPRN                                                                      |
| • OPRN-MIN           | Minimum value for OPRN                                                                      |
| • OPT-AVG            | Average Transmit Power in 1/10 uW                                                           |
| • OPT-MAX            | Maximum Transmit Power in 1/10 uW                                                           |
| • OPT-MIN            | Minimum Transmit Power in 1/10uW                                                            |
| • OPTN               | Normalized value for Optical Power Transmitted for STM1-8 card                              |
| • OPTN-MAX           | Maximum value for OPTN                                                                      |
| • OPTN-MIN           | Minimum value for OPTN                                                                      |
| • OPWR-AVG           | Optical Power—Average Interval Value in 1/10th of dBm                                       |
| • OPWR-MAX           | Optical Power—Maximum Interval Value in 1/10th of dBm                                       |
| • OPWR-MIN           | Optical Power—Minimum Interval Value in 1/10th of dBm                                       |
| • PPJC-PDET          | PPJC-PDET:Positive Pointer Justification                                                    |
| • PPJC-PGEN          | PPJC-PGEN:Positive Pointer Justification                                                    |
| • PSC                | Protection Switching Count                                                                  |
| • PSC-R              | Protection Switching Count—Ring                                                             |
| • PSC-S              | Protection Switching Count—Span                                                             |
| • PSC-W              | Protection Switching Count—Working                                                          |
| • PSD                | Protection Switching Duration                                                               |
| • PSD-R              | Protection Switching Duration—Ring                                                          |
| • PSD-S              | Protection Switching Duration—Span                                                          |
| • PSD-W              | Protection Switching Duration—Working                                                       |
| • SASCPP             | Severely Errored Framing/AIS Second—CP-Bit Path                                             |
| • SASP               | Severely Errored Framing/AIS Seconds Path                                                   |
| • SEFS               | Severely Errored Framing Seconds                                                            |
| • SESCOPP            | Severely Errored Second—CP-Bit Path                                                         |
| • SESL               | Severely Errored Second—Line                                                                |
| • SESP               | Severely Errored Second—Path                                                                |
| • SES-PM             | OTN—Severely Errored Second—Path                                                            |
| • SESR               | Severely Errored Second—Ratio                                                               |
| • SESR-PM            | OTN—Severely Errored Second Ratio—Path Monitor Point expressed as 1/10th of a percentage    |
| • SESR-SM            | OTN—Severely Errored Second Ratio—Section Monitor Point expressed as 1/10th of a percentage |



Table 23-7 SET-TH-&lt;MOD2&gt; Input Parameters (continued)

| Parameter and Values | Description                                                                                                                                                                                      |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| • SESS               | Severely Errored Second—Section                                                                                                                                                                  |
| • SES-SM             | OTN—Severely Errored Second—Section Monitor Point                                                                                                                                                |
| • SESV               | Severely Errored Second—VC Path                                                                                                                                                                  |
| • UASCPP             | Unavailable Second—CP-Bit Path                                                                                                                                                                   |
| • UASL               | Unavailable Second—Line                                                                                                                                                                          |
| • UASP               | Unavailable Second—Path                                                                                                                                                                          |
| • UAS-PM             | OTN—Unavailable Second—Path Monitor Point                                                                                                                                                        |
| • UAS-SM             | OTN—Unavailable Second—Section Monitor Point                                                                                                                                                     |
| • UASV               | Unavailable Second—VC Path                                                                                                                                                                       |
| • UNC-WORDS          | FEC—Uncorrectable Words                                                                                                                                                                          |
| • VPC                | Valid Packet Count                                                                                                                                                                               |
| <b>THELV</b>         | Threshold level. Float                                                                                                                                                                           |
| <b>LOCN</b>          | Location associated with a particular command<br>Parameter type is LOCATION—the location where the action is to take place                                                                       |
| • FEND               | Action occurs on the Far End of the facility                                                                                                                                                     |
| • NEND               | Action occurs on the Near End of the facility                                                                                                                                                    |
| <b>TMPER</b>         | Accumulation time period for performance counters. Optional<br>Parameter type is TMPER—accumulation time period for the performance management center                                            |
| • 1-DAY              | Performance parameter accumulation interval length; every 24-hours. For SDH PM data only one day of history data is available. For RMON managed PM data seven days of history data are available |
| • 1-HR               | Performance parameter accumulation interval length; every 1 hour. This is only applicable to RMON managed PM data. There are 24 hours of history data available                                  |
| • 1-MIN              | Performance parameter accumulation interval length; every 1 minute. This is only applicable to RMON managed PM data. There are 60 minutes of history available                                   |
| • 15-MIN             | Performance parameter accumulation interval length; every 15 minutes. There are 32 15-MIN buckets of history data available for this accumulation interval length                                |
| • RAW-DATA           | Performance parameter accumulation interval length; starting from the last time the counters were cleared. This is only applicable to RMON managed PMs                                           |

## 23.8 SET-TOD

Set Time of Day

**Usage Guidelines** This command sets the system date and time for the NE. The year should be entered using four digits while the hour should be entered using a 24-hour time period (i.e., military time).

**Category** System

**Security** Provisioning

**Input Format** SET-TOD:[<TID>]::<CTAG>::<YEAR>,<MONTH>,<DAY>,<HOUR>,<MINUTE>,<SECOND>,<DIFFERENCE>[:DST=<DST>];

**Input Example** SET-TOD:CAZADERO::240::1998,05,08,13,18,55,480:DST=Y;

**Input Parameters**

**Table 23-8 SET-TOD Input Parameters**

| Parameter and Values | Description                                                                      |
|----------------------|----------------------------------------------------------------------------------|
| <b>YEAR</b>          | The current calendar year. Integer                                               |
| <b>MONTH</b>         | The month of the year. Ranges from 01 to 12. Integer                             |
| <b>DAY</b>           | The day of the month. Ranges from 01 to 31. Integer                              |
| <b>HOUR</b>          | The hour of the day. Ranges from 00 to 23. Integer                               |
| <b>MINUTE</b>        | The minute of the hour. Ranges from 00 to 59. Integer                            |
| <b>SECOND</b>        | The second of the minute. Ranges from 00 to 59. Integer                          |
| <b>DIFFERENCE</b>    | The number of minutes off UTC. Integer                                           |
| <b>DST</b>           | Daylight savings time<br>Parameter type is ON_OFF—disable or enable an attribute |
| • N                  | Disable an attribute                                                             |
| • Y                  | Enable an attribute                                                              |