



# Preface

---



**Note**

The terms "Unidirectional Path Switched Ring" and "UPSR" may appear in Cisco literature. These terms do not refer to using Cisco ONS 15xxx products in a unidirectional path switched ring configuration. Rather, these terms, as well as "Path Protected Mesh Network" and "PPMN," refer generally to Cisco's path protection feature, which may be used in any topological network configuration. Cisco does not recommend using its path protection feature in any particular topological network configuration.

This section explains the objectives, intended audience, and organization of this publication and describes the conventions that convey instructions and other information.

This section provides the following information:

- [Revision History](#)
- [Document Objectives](#)
- [Audience](#)
- [Document Organization](#)
- [Related Documentation](#)
- [Document Conventions](#)
- [Obtaining Optical Networking Information](#)
- [Obtaining Documentation and Submitting a Service Request](#)

# Revision History

Date	Notes
March 2011	<ul style="list-style-type: none"> <li>Removed the table “8G Fibre Channel (FC) Payload PMs for the 40G-MXP-C, 40E-MXP-C, and 40ME-MXP-C Cards” in the chapter, “Performance Monitoring”.</li> </ul>
April 2011	<ul style="list-style-type: none"> <li>Updated the section “Interlink Interfaces” and the table “SFP/XFP Card Compatibility” in the chapter “Transponder and Muxponder Cards”.</li> <li>Updated the table, “XFP Specifications” in the chapter, “Hardware Specifications”.</li> <li>Updated the section “Safety Labels” in the following chapters: <ul style="list-style-type: none"> <li>Common Control Cards</li> <li>Optical Service Channel Cards</li> <li>Optical Amplifier Cards</li> <li>Multiplexer and Demultiplexer Cards</li> <li>Tunable Dispersion Compensating Units</li> <li>Optical Add/Drop Cards</li> <li>Reconfigurable Optical Add/Drop Cards</li> <li>Transponder and Muxponder Cards</li> </ul> </li> <li>Updated the section “Node View (Multishelf Mode), Node View (Single-Shelf Mode), and Shelf View (Multishelf Mode)” in the chapter “Cisco Transport Controller Operation”.</li> <li>Updated the power values in the “Individual Card Power Requirements” table in the appendix, “Hardware Specifications”.</li> </ul>
May 2011	<ul style="list-style-type: none"> <li>Updated the section “SFP and XFP Modules” in the chapter “Transponder and Muxponder Cards”.</li> <li>Removed the sections “SFP Specifications” and “XFP Specifications” and added the section “SFP and XFP Specifications” in the appendix “Hardware Specifications”.</li> <li>Updated the minimum output power value for the MXP_MR_10DMEX_C card in the appendix “Hardware Specifications”.</li> </ul>
June 2011	<ul style="list-style-type: none"> <li>Updated the section “AIC-I Card” in the chapter “Common Control Cards”.</li> <li>Updated the section “Y-Cable Protection” in the chapter “Transponder and Muxponder Cards”.</li> <li>Updated the sections “MXP_2.5G_10EX_C Card Specifications” and “TXP_MR_10EX_C Card Specifications” in the chapter “Hardware Specifications”.</li> <li>Updated the TNC and TSC card power consumption values in the chapter “Hardware Specifications”.</li> <li>Updated the sub-section “Configuration Management” under the section “OTU2_XP Card” in the chapter “Transponder and Muxponder Cards”.</li> </ul>
July 2011	<ul style="list-style-type: none"> <li>Added a note in the “PC and UNIX Workstation Requirements” section of Chapter, “Cisco Transport Controller OperationCard Reference”.</li> </ul>

Date	Notes
August 2011	<ul style="list-style-type: none"> <li>• Updated the table “Ranges, Values, and Edit Options for the ANS Parameters” in the chapter “Node Reference”.</li> <li>• Updated the sections “40E-TXP-C and 40ME-TXP-C Cards” and “40G-MXP-C, 40E-MXP-C, and 40ME-MXP-C Cards” in the chapter “Transponder and Muxponder Cards”.</li> </ul>
September 2011	<ul style="list-style-type: none"> <li>• Updated the key features section of TXP_MR_10G, TXP_MR_10E, TXP_MR_10E_C, TXP_MR_10E_L, TXP_MR_10EX_C, and OTU2_XP cards in the chapter “Transponder and Muxponder Cards”.</li> <li>• Added a note to SONET PM Parameters table in “SONET PM Parameter Definitions” section.</li> <li>• Replaced G.975.1 with G.975.1 I.7 and added a note in the "Enhanced FEC (E-FEC) Feature" section in the chapter, "Transponder and Muxponder Cards".</li> <li>• Created a “Summary Pane” section in the chapter, “Cisco Transport Controller Operation”.</li> </ul>
October 2011	<ul style="list-style-type: none"> <li>• Removed the Temperature table and updated the Temperature section with standard operating temperature values, removed the Environmental section from all the 15454 card specifications, and added "Environmental Exception" to “40G-MXP-C, 40E-MXP-C and 40ME-MXP-C Card Specifications” section in the appendix "Hardware Specifications."</li> <li>• Updated information related to IB_5G in the chapter “Transponder and Muxponder Cards”.</li> <li>• Updated the figure “Scenario 3: Using Proxy ARP with Static Routing (ANSI and ETSI)” in the chapter “Management Network Connectivity”.</li> </ul>
December 2011	<ul style="list-style-type: none"> <li>• Updated the power values in the table “Individual Card Power Requirements” in the appendix “Hardware Specifications”.</li> <li>• Updated the section “Termination Modes” in the chapter “Transponder and Muxponder Cards”.</li> </ul>
January 2012	<ul style="list-style-type: none"> <li>• Updated the section “GE_XP, 10GE_XP, GE_XPE, and 10GE_XPE Cards” with pluggable limitations in the chapter Transponder and Muxponder Cards”.</li> </ul>
February 2012	<ul style="list-style-type: none"> <li>• Removed the autonegotiation support statement for ADM-10G card from the “Key Features” section in the chapter “Transponder and Muxponder Cards”.</li> </ul>
March 2012	<ul style="list-style-type: none"> <li>• Updated the section, “Multishelf Node” in the chapter, “ Node Reference”.</li> </ul>
April 2012	<ul style="list-style-type: none"> <li>• Updated the “Functional View for an Eight-Sided Node” diagram in the chapter “Node Reference”.</li> <li>• Added a note in the “Displaying Optical Power” section of chapter, “Node Reference”.</li> <li>• Updated the "Faceplate and Block Diagram" section of "GE_XP, 10GE_XP, GE_XPE, and 10GE_XPE Cards" in the chapter, “Transponder and Muxponder Cards”.</li> <li>• Upadted the section “SNMP in Multishelf Management” in the chapter “SNMP”.</li> </ul>
May 2012	Updated the section “Optical Channel Circuits” in the chapter “Optical Channel Circuits and Virtual Patchcords Reference”.

Date	Notes
June 2012	<ul style="list-style-type: none"> <li>• Updated the section “Generic Threshold and Performance Monitoring MIBs” in the chapter “SNMP”.</li> <li>• Updated the section “Generic Threshold and Performance Monitoring MIBs” in the chapter “SNMP”.</li> </ul>
July 2012	Document Part Number revised to 78-19685-03 and a full length book-PDF was generated.
August 2012	<ul style="list-style-type: none"> <li>• Updated the table “Platform and Software Release Compatibility for Control Cards” in the chapter “Common Control Cards”.</li> <li>• Updated the section “TCC2P Card” in the chapter “Install the Control cards” and “Supported Node Configurations for OPT-RAMP-C and OPT-RAMP-CE Cards” in the chapter “Node Reference”.</li> <li>• Updated the power values in the table “Individual Card Power Requirements” in the appendix “Hardware Specifications”.</li> </ul>
October 2012	<ul style="list-style-type: none"> <li>• Updated the “Circuit Provisioning” section of ADM-10G card in the chapter “Transponder and Muxponder Cards”.</li> <li>• Updated the section “TCC2P Card” in the chapter “Install the Control cards”.</li> <li>• Added a caution to the section, “IP Addressing with Secure Mode Enabled” in the chapter, “Management Network Connectivity”</li> </ul>
February 2013	<ul style="list-style-type: none"> <li>• In the chapter “Transponder and Muxponder Cards,” added a note after “Table 10-46 Supported SDH Circuit Sizes of ADM-10G card on ONS 15454 SDH”.</li> <li>• In the chapter “Cisco Transport Controller Operation,” added a new column to Table 14-1 JRE Compatibility to reflect the compatibility of releases with JRE 1.7.</li> </ul>
April 2013	Updated the section “External Firewalls” in the chapter “Manage Network Connectivity”.
May 2013	Updated the section, “ REP Limitations and Restrictions” in the chapter, “ Transponder and Muxponder Cards”.
June 2013	Updated the section “Administrative States” in the chapter “Administrative and Service States”.
October 2013	Created a new table "Revision Number Compatibility for Transponder and Muxponder Cards " in the chapter, “Transponder and Muxponder Cards”.
November 2013	Updated the section “Trunk Interface” of OTU2_XP card in the chapter “Transponder and Muxponder Cards”.

# Document Objectives

This document provides background and reference material for Cisco ONS 15454 dense wavelength division (DWDM) systems.

## Audience

To use this publication, you should be familiar with Cisco or equivalent optical transmission hardware and cabling, telecommunications hardware and cabling, electronic circuitry and wiring practices, and preferably have experience as a telecommunications technician.

## Document Organization

**Table 1** *Cisco ONS 15454 Reference Manual Chapters*

Title	Summary
<a href="#">Cisco ONS Documentation Roadmap for Release 9.2.1 and 9.2.2</a>	Provides link to quickly access publications of Cisco ONS Release 9.2.1 and 9.2.2.
<a href="#">Chapter 1, “Cisco ONS 15454 (ANSI and ETSI), ONS 15454 M2, and ONS 15454 M6 Shelf Assembly”</a>	Provides a description of Cisco ONS 15454 (ANSI and ETSI), Cisco ONS 15454 M2, and Cisco ONS 15454 M6 shelf assemblies.
<a href="#">Chapter 2, “Common Control Cards”</a>	Includes descriptions of the TCC2, TCC3, TCC2P, AIC-I, and MS-ISC-100T cards.
<a href="#">Chapter 3, “Optical Service Channel Cards”</a>	Includes descriptions of OSCM and OSC-CSM cards.
<a href="#">Chapter 4, “Optical Amplifier Cards”</a>	Includes descriptions of the OPT-PRE, OPT-BST, OPT-BST-E, OP-BST-L, OPT-AMP-L, OPT-AMP-C, OPT-AMP-17-C, OPT-RAMP-C, and OPT-RAMP-CE, as well as card temperature ranges and card compatibility.
<a href="#">Chapter 5, “Multiplexer and Demultiplexer Cards”</a>	Includes descriptions of the Protection Switching Module (PSM) card used in Cisco ONS 15454 dense wavelength division multiplexing (DWDM) networks.
<a href="#">Chapter 6, “Tunable Dispersion Compensating Units”</a>	Explains the Tunable Dispersion Compensating Units (T-DCU) used in Cisco ONS 15454 dense wavelength division multiplexing (DWDM) networks.
<a href="#">Chapter 7, “Protection Switching Module”</a>	Includes descriptions of the 32-MUX-O, 32DMX-O, and 4MD-xx.x cards.
<a href="#">Chapter 8, “Optical Add/Drop Cards”</a>	Includes descriptions of the AD-1C-xx.x, AD-2C-xx.x, AD-4C-xx.x, AD-1B-xx.x, and AD-4B-xx.x cards, card temperature ranges, compatibility, and applications.

**Table 1** *Cisco ONS 15454 Reference Manual Chapters (continued)*

<b>Title</b>	<b>Summary</b>
Chapter 9, “Reconfigurable Optical Add/Drop Cards”	Includes descriptions of the 32WSS, 32WSS-L, 32DMX, 32DMX-L, 40-DMX-C, 40-DMX-CE, 40-MUX-C, 40-WSS-C, 40-WSS-CE, 40-WXC-C, 80-WXC-C, 40-SMR-1C, 40-SMR-2C, and MMU cards, card temperature ranges, compatibility, and applications.
Chapter 10, “Transponder and Muxponder Cards”	Includes information about transponder (TXP), muxponder (MXP), GE_XP, 10GE_XP, and ADM-10G cards, as well as their associated plug-in modules (Small Form-factor Pluggables [SFPs or XFPs]).
Chapter 11, “Node Reference”	Explains the DWDM node types t available for the ONS 15454. The DWDM node type is determined by the type of amplifier and filter cards that are installed in an ONS 15454. Also explains the DWDM automatic power control (APC), reconfigurable optical add/drop multiplexing (ROADM) power equalization, span loss verification, and automatic node setup (ANS) functions.
Chapter 12, “Network Reference”	Explains the DWDM network applications and topologies. Also provides network-level optical performance references.
Chapter 13, “Optical Channel Circuits and Virtual Patchcords Reference”	Explains the DWDM optical channel (OCH) circuit types and virtual patchcords that can be provisioned. Circuit types include the OCH client connection (OCHCC), the OCH trail, and the OCH network connection (OCHNC).
Chapter 14, “Cisco Transport Controller Operation”	Describes Cisco Transport Controller (CTC), the software interface for the Cisco ONS 15454.
Chapter 15, “Security Reference”	Provides information about Cisco ONS 15454 users and security.
Chapter 16, “Timing Reference”	Provides information about Cisco ONS 15454 users and node timing.
Chapter 17, “Manage Network Connectivity”	Provides an overview of ONS 15454 data communications network (DCN) connectivity. Cisco Optical Networking System (ONS) network communication is based on IP, including communication between Cisco Transport Controller (CTC) computers and ONS 15454 nodes, and communication among networked ONS 15454 nodes. The chapter shows common Cisco ONS 15454 IP network configurations and includes detailed data communications network (DCN) case studies.

**Table 1** Cisco ONS 15454 Reference Manual Chapters (continued)

Title	Summary
Chapter 18, “Alarm and TCA Monitoring and Management”	Describes Cisco Transport Controller (CTC) alarm and threshold crossing alert (TCA) monitoring and management.
Chapter 19, “Performance Monitoring”	Performance monitoring (PM) parameters are used by service providers to gather, store, set thresholds for, and report performance data for early detection of problems. In this chapter, PM parameters and concepts are defined for transponder, muxponder, and dense wavelength division multiplexing (DWDM) cards in the Cisco ONS 15454 including optical amplifier, multiplexer, demultiplexer, optical add/drop multiplexer (OADM), and optical service channel (OSC) cards.
Chapter 20, “SNMP”	Explains Simple Network Management Protocol (SNMP) as implemented by the Cisco ONS 15454.
Appendix A, “Hardware Specifications”	Contains hardware and software specifications for the ONS 15454 ANSI and ETSI shelf assemblies and cards.
Appendix 21, “Administrative and Service States”	Describes the administrative and service states for Cisco ONS 15454 dense wavelength division multiplexing (DWDM) cards, optical payload ports, out-of-band optical service channel (OSC) ports, optical channel network connections (OCHNCs), and transponder/muxponder cards and ports.
Appendix B, “Pseudo Command Line Interface Reference”	Describes Pseudo-IOS command line interface (PCLI) for GE_XP, 10GE_XP, GE_XPE, and 10GE_XPE cards.
Appendix C, “Fiber and Connector Losses in Raman Link Configuration”	Describes guidelines to be followed when configuring a Raman link.

## Related Documentation

Use the *Cisco ONS 15454 DWDM Reference Manual* in conjunction with the following referenced Release 9.2.1 and 9.2.2 publications:

- *Cisco ONS 15454 DWDM Procedure Guide*
- *Cisco ONS 15454 DWDM Troubleshooting Guide*
- *Cisco ONS SONET TL1 Command Guide*
- *Cisco ONS SONET TL1 Reference Guide*
- *Cisco ONS SONET TL1 Command Quick Reference Guide*
- *Cisco ONS 15454 SDH TL1 Command Guide*
- *Cisco ONS 15454 SDH TL1 Reference Guide*

- *Cisco ONS 15454 SDH TL1 Command Quick Reference Guide*
- *Release Notes for Cisco ONS 15454, Release 9.2.1*
- *Release Notes for Cisco ONS 15454 SDH, Release 9.2.1*
- *Release Notes for Cisco ONS 15454, ONS 15454 M2, and ONS 15454 M6 DWDM, Release 9.2.1*
- *Release Notes for Cisco ONS 15454, ONS 15454 M2, and ONS 15454 M6 DWDM, Release 9.2.2*
- *Cisco TransportPlanner DWDM Operations Guide*
- *Cisco ONS 15454 Hardware Installation Guide*

For an update on End-of-Life and End-of-Sale notices, refer to

[http://www.cisco.com/en/US/products/hw/optical/ps2006/prod\\_eol\\_notices\\_list.html](http://www.cisco.com/en/US/products/hw/optical/ps2006/prod_eol_notices_list.html)

## Document Conventions

This publication uses the following conventions:

Convention	Application
<b>boldface</b>	Commands and keywords in body text.
<i>italic</i>	Command input that is supplied by the user.
[ ]	Keywords or arguments that appear within square brackets are optional.
{ x   x   x }	A choice of keywords (represented by x) appears in braces separated by vertical bars. The user must select one.
Ctrl	The control key. For example, where Ctrl + D is written, hold down the Control key while pressing the D key.
screen font	Examples of information displayed on the screen.
<b>boldface screen font</b>	Examples of information that the user must enter.
< >	Command parameters that must be replaced by module-specific codes.



### Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.



### Caution

Means *reader be careful*. In this situation, the user might do something that could result in equipment damage or loss of data.





Warning

**IMPORTANT SAFETY INSTRUCTIONS**

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. Statement 1071

**SAVE THESE INSTRUCTIONS**

Waarschuwing

**BELANGRIJKE VEILIGHEIDSINSTRUCTIES**

Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van de standaard praktijken om ongelukken te voorkomen. Gebruik het nummer van de verklaring onderaan de waarschuwing als u een vertaling van de waarschuwing die bij het apparaat wordt geleverd, wilt raadplegen.

**BEWAAR DEZE INSTRUCTIES**

Varoitus

**TÄRKEITÄ TURVALLISUUSOHJEITA**

Tämä varoitusmerkki merkitsee vaaraa. Tilanne voi aiheuttaa ruumiillisia vammoja. Ennen kuin käsittelet laitteistoa, huomioi sähköpiirien käsittelyyn liittyvät riskit ja tutustu onnettomuuksien yleisiin ehkäisytapoihin. Turvallisuusvaroitusten käännökset löytyvät laitteen mukana toimitettujen käännettyjen turvallisuusvaroitusten joukosta varoitusten lopussa näkyvien lausuntonumeroiden avulla.

**SÄILYTÄ NÄMÄ OHJEET**

Attention

**IMPORTANTES INFORMATIONS DE SÉCURITÉ**

Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant entraîner des blessures ou des dommages corporels. Avant de travailler sur un équipement, soyez conscient des dangers liés aux circuits électriques et familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents. Pour prendre connaissance des traductions des avertissements figurant dans les consignes de sécurité traduites qui accompagnent cet appareil, référez-vous au numéro de l'instruction situé à la fin de chaque avertissement.

**CONSERVEZ CES INFORMATIONS**

Warnung

**WICHTIGE SICHERHEITSHINWEISE**

Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu Verletzungen führen kann. Machen Sie sich vor der Arbeit mit Geräten mit den Gefahren elektrischer Schaltungen und den üblichen Verfahren zur Vorbeugung vor Unfällen vertraut. Suchen Sie mit der am Ende jeder Warnung angegebenen Anweisungsnummer nach der jeweiligen Übersetzung in den übersetzten Sicherheitshinweisen, die zusammen mit diesem Gerät ausgeliefert wurden.

**BEWAHREN SIE DIESE HINWEISE GUT AUF.**

**Avvertenza    IMPORTANTI ISTRUZIONI SULLA SICUREZZA**

Questo simbolo di avvertenza indica un pericolo. La situazione potrebbe causare infortuni alle persone. Prima di intervenire su qualsiasi apparecchiatura, occorre essere al corrente dei pericoli relativi ai circuiti elettrici e conoscere le procedure standard per la prevenzione di incidenti. Utilizzare il numero di istruzione presente alla fine di ciascuna avvertenza per individuare le traduzioni delle avvertenze riportate in questo documento.

**CONSERVARE QUESTE ISTRUZIONI****Advarsel    VIKTIGE SIKKERHETSINSTRUKSJONER**

Dette advarselssymbolet betyr fare. Du er i en situasjon som kan føre til skade på person. Før du begynner å arbeide med noe av utstyret, må du være oppmerksom på farene forbundet med elektriske kretser, og kjenne til standardprosedyrer for å forhindre ulykker. Bruk nummeret i slutten av hver advarsel for å finne oversettelsen i de oversatte sikkerhetsadvarslene som fulgte med denne enheten.

**TA VARE PÅ DISSE INSTRUKSJONENE****Aviso    INSTRUÇÕES IMPORTANTES DE SEGURANÇA**

Este símbolo de aviso significa perigo. Você está em uma situação que poderá ser causadora de lesões corporais. Antes de iniciar a utilização de qualquer equipamento, tenha conhecimento dos perigos envolvidos no manuseio de circuitos elétricos e familiarize-se com as práticas habituais de prevenção de acidentes. Utilize o número da instrução fornecido ao final de cada aviso para localizar sua tradução nos avisos de segurança traduzidos que acompanham este dispositivo.

**GUARDE ESTAS INSTRUÇÕES****¡Advertencia!    INSTRUCCIONES IMPORTANTES DE SEGURIDAD**

Este símbolo de aviso indica peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considere los riesgos de la corriente eléctrica y familiarícese con los procedimientos estándar de prevención de accidentes. Al final de cada advertencia encontrará el número que le ayudará a encontrar el texto traducido en el apartado de traducciones que acompaña a este dispositivo.

**GUARDE ESTAS INSTRUCCIONES****Varning!    VIKTIGA SÄKERHETSANVISNINGAR**

Denna varningssignal signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanliga förfaranden för att förebygga olyckor. Använd det nummer som finns i slutet av varje varning för att hitta dess översättning i de översatta säkerhetsvarningar som medföljer denna anordning.

**SPARA DESSA ANVISNINGAR**

## FONTOS BIZTONSÁGI ELOÍRÁSOK

**Ez a figyelmeztető jel veszélyre utal. Sérülésveszélyt rejtő helyzetben van. Mielott bármely berendezésen munkát végezte, legyen figyelemmel az elektromos áramkörök okozta kockázatokra, és ismerkedjen meg a szokásos balesetvédelmi eljárásokkal. A kiadványban szereplő figyelmeztetések fordítása a készülékhez mellékelt biztonsági figyelmeztetések között található; a fordítás az egyes figyelmeztetések végén látható szám alapján kereshető meg.**

## ORIZZE MEG EZEKET AZ UTASÍTÁSOKAT!

Предупреждение

## ВАЖНЫЕ ИНСТРУКЦИИ ПО СОБЛЮДЕНИЮ ТЕХНИКИ БЕЗОПАСНОСТИ

Этот символ предупреждения обозначает опасность. То есть имеет место ситуация, в которой следует опасаться телесных повреждений. Перед эксплуатацией оборудования выясните, каким опасностям может подвергаться пользователь при использовании электрических цепей, и ознакомьтесь с правилами техники безопасности для предотвращения возможных несчастных случаев. Воспользуйтесь номером заявления, приведенным в конце каждого предупреждения, чтобы найти его переведенный вариант в переводе предупреждений по безопасности, прилагаемом к данному устройству.

## СОХРАНИТЕ ЭТИ ИНСТРУКЦИИ

警告

重要的安全性说明

此警告符号代表危险。您正处于可能受到严重伤害的工作环境中。在您使用设备开始工作之前，必须充分意识到触电的危险，并熟练掌握防止事故发生的标准工作程序。请根据每项警告结尾提供的声明号码来找到此设备的安全性警告说明的翻译文本。

请保存这些安全性说明

警告

安全上の重要な注意事項

「危険」の意味です。人身事故を予防するための注意事項が記述されています。装置の取り扱い作業を行うときは、電気回路の危険性に注意し、一般的な事故防止策に留意してください。警告の各国語版は、各注意事項の番号を基に、装置に付属の「Translated Safety Warnings」を参照してください。

これらの注意事項を保管しておいてください。

주의

중요 안전 지침

이 경고 기호는 위험을 나타냅니다. 작업자가 신체 부상을 일으킬 수 있는 위험한 환경에 있습니다. 장비에 작업을 수행하기 전에 전기 회로와 관련된 위험을 숙지하고 표준 작업 관례를 숙지하여 사고를 방지하십시오. 각 경고의 마지막 부분에 있는 경고문 번호를 참조하여 이 장치와 함께 제공되는 번역된 안전 경고문에서 해당 번역문을 찾으십시오.

이 지시 사항을 보관하십시오.

**Aviso INSTRUÇÕES IMPORTANTES DE SEGURANÇA**

Este símbolo de aviso significa perigo. Você se encontra em uma situação em que há risco de lesões corporais. Antes de trabalhar com qualquer equipamento, esteja ciente dos riscos que envolvem os circuitos elétricos e familiarize-se com as práticas padrão de prevenção de acidentes. Use o número da declaração fornecido ao final de cada aviso para localizar sua tradução nos avisos de segurança traduzidos que acompanham o dispositivo.

**GUARDE ESTAS INSTRUÇÕES****Advarsel VIGTIGE SIKKERHEDSANVISNINGER**

Dette advarselssymbol betyder fare. Du befinder dig i en situation med risiko for legemeskade. Før du begynder arbejde på udstyr, skal du være opmærksom på de involverede risici, der er ved elektriske kredsløb, og du skal sætte dig ind i standardprocedurer til undgåelse af ulykker. Brug erklæringsnummeret efter hver advarsel for at finde oversættelsen i de oversatte advarsler, der fulgte med denne enhed.

**GEM DISSE ANVISNINGER**

تحذير

إرشادات الأمان الهامة

يوضح رمز التحذير هذا وجود خطر. وهذا يعني أنك متواجد في مكان قد ينتج عنه التعرض لإصابات. قبل بدء العمل، احذر مخاطر التعرض للصدمات الكهربائية وكن على علم بالإجراءات القياسية للحيلولة دون وقوع أي حوادث. استخدم رقم البيان الموجود في آخر كل تحذير لتحديد مكان ترجمته داخل تحذيرات الأمان المترجمة التي تأتي مع الجهاز. قم بحفظ هذه الإرشادات

**Upozorenje VAŽNE SIGURNOSNE NAPOMENE**

Ovaj simbol upozorenja predstavlja opasnost. Nalazite se u situaciji koja može prouzročiti tjelesne ozljede. Prije rada s bilo kojim uređajem, morate razumjeti opasnosti vezane uz električne sklopove, te biti upoznati sa standardnim načinima izbjegavanja nesreća. U prevedenim sigurnosnim upozorenjima, priloženima uz uređaj, možete prema broju koji se nalazi uz pojedino upozorenje pronaći i njegov prijevod.

**SAČUVAJTE OVE UPUTE****Upozornění DŮLEŽITÉ BEZPEČNOSTNÍ POKYNY**

Tento upozorňující symbol označuje nebezpečí. Jste v situaci, která by mohla způsobit nebezpečí úrazu. Před prací na jakémkoliv vybavení si uvědomte nebezpečí související s elektrickými obvody a seznamte se se standardními opatřeními pro předcházení úrazům. Podle čísla na konci každého upozornění vyhledejte jeho překlad v přeložených bezpečnostních upozorněních, která jsou přiložena k zařízení.

**USCHOVEJTE TYTO POKYNY**

Προειδοποίηση	<p><b>ΣΗΜΑΝΤΙΚΕΣ ΟΔΗΓΙΕΣ ΑΣΦΑΛΕΙΑΣ</b></p> <p>Αυτό το προειδοποιητικό σύμβολο σημαίνει κίνδυνο. Βρίσκεστε σε κατάσταση που μπορεί να προκαλέσει τραυματισμό. Πριν εργαστείτε σε οποιοδήποτε εξοπλισμό, να έχετε υπόψη σας τους κινδύνους που σχετίζονται με τα ηλεκτρικά κυκλώματα και να έχετε εξοικειωθεί με τις συνήθειες πρακτικές για την αποφυγή ατυχημάτων. Χρησιμοποιήστε τον αριθμό δήλωσης που παρέχεται στο τέλος κάθε προειδοποίησης, για να εντοπίσετε τη μετάφρασή της στις μεταφρασμένες προειδοποιήσεις ασφαλείας που συνοδεύουν τη συσκευή.</p> <p><b>ΦΥΛΑΞΤΕ ΑΥΤΕΣ ΤΙΣ ΟΔΗΓΙΕΣ</b></p>
אזהרה	<p style="text-align: right;"><b>הוראות בטיחות חשובות</b></p> <p>סימן אזהרה זה מסמל סכנה. אתה נמצא במצב העלול לגרום לפציעה. לפני שתעבוד עם ציוד כלשהו, עליך להיות מודע לסכנות הכרוכות במגעלים חשמליים ולהכיר את הנהלים המקובלים למניעת תאונות. השתמש במספר ההוראה המסופק בסופה של כל אזהרה כדי לאתר את התרגום באזהרות הבטיחות המתורגמות שמצורפות להתקן.</p> <p style="text-align: right;"><b>שמור הוראות אלה</b></p>
Opomena	<p><b>ВАЖНИ БЕЗБЕДНОСНИ НАПАТСТВИЈА</b></p> <p>Симболот за предупредување значи опасност. Се наоѓате во ситуација што може да предизвика телесни повреди. Пред да работите со опремата, бидете свесни за ризикот што постои кај електричните кола и треба да ги познавате стандардните постапки за спречување на несреќни случаи. Искористете го бројот на изјавата што се наоѓа на крајот на секое предупредување за да го најдете неговиот период во преведените безбедносни предупредувања што се испорачани со уредот.</p> <p><b>ЧУВАЈТЕ ГИ ОБИЕ НАПАТСТВИЈА</b></p>
Ostrzeżenie	<p><b>WAŻNE INSTRUKCJE DOTYCZĄCE BEZPIECZEŃSTWA</b></p> <p>Ten symbol ostrzeżenia oznacza niebezpieczeństwo. Zachodzi sytuacja, która może powodować obrażenia ciała. Przed przystąpieniem do prac przy urządzeniach należy zapoznać się z zagrożeniami związanymi z układami elektrycznymi oraz ze standardowymi środkami zapobiegania wypadkom. Na końcu każdego ostrzeżenia podano numer, na podstawie którego można odszukać tłumaczenie tego ostrzeżenia w dołączonym do urządzenia dokumencie z tłumaczeniami ostrzeżeń.</p> <p><b>NINIEJSZE INSTRUKCJE NALEŻY ZACHOWAĆ</b></p>
Upozornenie	<p><b>DÔLEŽITÉ BEZPEČNOSTNÉ POKYNY</b></p> <p>Tento varovný symbol označuje nebezpečenstvo. Nachádzate sa v situácii s nebezpečenstvom úrazu. Pred prácou na akomkoľvek vybavení si uvedomte nebezpečenstvo súvisiace s elektrickými obvodmi a oboznámte sa so štandardnými opatreniami na predchádzanie úrazom. Podľa čísla na konci každého upozornenia vyhľadajte jeho preklad v preložených bezpečnostných upozorneniach, ktoré sú priložené k zariadeniu.</p> <p><b>USCHOVAJTE SI TENTO NÁVOD</b></p>

## Obtaining Optical Networking Information

This section contains information that is specific to optical networking products. For information that pertains to all of Cisco, refer to the [Obtaining Documentation and Submitting a Service Request](#) section.

## Where to Find Safety and Warning Information

For safety and warning information, refer to the *Cisco Optical Transport Products Safety and Compliance Information* document that accompanied the product. This publication describes the international agency compliance and safety information for the Cisco ONS 15454 system. It also includes translations of the safety warnings that appear in the ONS 15454 system documentation.

## Cisco Optical Networking Product Documentation CD-ROM

Optical networking-related documentation, including Cisco ONS 15xxx product documentation, is available in a CD-ROM package that ships with your product. The Optical Networking Product Documentation CD-ROM is updated periodically and may be more current than printed documentation.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.