



## Geo-redundant deployment

Geo-redundant deployment is a high-availability deployment model in which Cisco Optical Network Controller is deployed across geographically separate data centers to maintain service continuity during regional outages.

- Uses multiple Kubernetes clusters connected as a single geo supercluster
- Supports asynchronous replication between active and standby regions
- Maintains service availability through automated failover mechanisms

Geo redundancy protects against large-scale failures such as natural disasters, power outages, or data center loss.

### How geo-redundant deployment works

In a geo-redundant deployment, Cisco Optical Network Controller clusters are grouped into a geo supercluster that enables coordinated service operation across regions.

Key architectural components include:

- **Active node:** Hosts operational Cisco Optical Network Controller services
- **Standby node:** Maintains synchronized state and assumes control during failover
- **Arbitrator node:** Participates in active node selection using the RAFT algorithm

The standard geo-redundant configuration is:

1. One active single-node worker
2. One standby single-node worker
3. One arbitrator node

Each region operates as an independent Kubernetes cluster while participating in the supercluster.

Supported Cisco Optical Network Controller releases include:


- 24.3.2
- 25.1.2



**Note** The arbitrator node runs only the operating system and system services. Cisco Optical Network Controller microservices do not run on the arbitrator.

The following figure illustrates a typical geo-redundant deployment:

**Figure 1: Cisco Optical Network Controller geo-redundant deployment**



524720

Use the following information to plan your geo-redundant deployment environment.

**Infrastructure requirements** include:

- **Platform:** VMware ESXi 7.0 and later, and vCenter 7.0 and later.




---

**Attention** Upgrade to VMware vCenter Server 8.0 U2 if you are using VMware vCenter Server 8.0.2 or VMware vCenter Server 8.0.1.

---

- **Virtual machines:** Deploy three VMs (one per cluster) for a 1+1+1 supercluster.
  - One worker VM (active)
  - One worker VM (standby)
  - One arbitrator VM (witness)
- **Geographic separation:** Cisco recommends placing the three VMs in three different zones or regions to avoid a single point of failure. At least two of the three VMs must be reachable for service continuity.

**VM sizing profiles:**

Choose a profile based on your scale requirements.

| Profile          | CPU (cores) |            | Memory (GB) |            | SSD storage (TB) |
|------------------|-------------|------------|-------------|------------|------------------|
|                  | Worker      | Arbitrator | Worker      | Arbitrator |                  |
| Extra Small (XS) | 16          | 8          | 64          | 32         | 2                |
| Small (S)        | 32          | 8          | 128         | 32         | 4                |
| Medium (M)       | 48          | 8          | 256         | 32         | 10               |




---

**Attention** Cisco Optical Network Controller supports only SSDs for storage.

---

**vCPU to physical CPU core ratio:** A ratio of 2:1 is supported when hyperthreading is enabled and supported by the hardware. Otherwise, use 1:1.

**Network requirements:**

A geo-redundant deployment uses three networks.

- **Control plane network:** Internal communication within a cluster. In geo-redundant deployments, the control plane network is used only within a single cluster. You can use a dummy vSwitch for a cluster and apply the same configuration to each cluster.
- **Northbound (VM) network:** Traffic between users and the cluster, including web UI access. Cisco Optical Network Controller uses this network to connect to Cisco Optical Site Manager devices using NETCONF/gRPC.

**Bandwidth and latency requirements for the northbound network:**

- Web UI: 1 Gbps
- Connection to optical nodes: 100 Mbps

- Latency: less than 100 ms

- **Eastbound network:** Internal communication across regions within the supercluster. Active and standby nodes use this network to replicate databases. Postgres is replicated between active and standby nodes. MinIO is replicated on the arbitrator.

**Bandwidth and latency requirements for the eastbound network:** 1 Gbps bandwidth and latency less than 100 ms.

You can configure the eastbound network as a flat Layer 2 network or an L2VPN where eastbound IP addresses are in the same subnet. If eastbound IP addresses are in different subnets, configure static routing between nodes for eastbound connectivity.




---

**Restriction** Do not configure the control plane, northbound, and eastbound networks in the same subnet or VLAN segment. Use separate subnets and VLAN segments.

---

**Virtual IP routing:** BGP is used to route traffic to the virtual IP from multiple locations. Configure the BGP router and add the nodes as neighbors. Coordinate with your network administrator to configure BGP.

**Storage requirements:** Use SSD storage that meets the disk write latency requirement of  $\leq 100$  ms.

**Deployment constraints** include:

- You need three separate VMs with separate eastbound, northbound, and control plane network connectivity.
- You cannot remove nodes from a cluster or change cluster roles after a cluster joins a supercluster.

**Default port assignments:**

This table lists the default port assignments.

**Table 1: Communications matrix**

| Traffic type | Port                       | Description                                   |
|--------------|----------------------------|---|
| Inbound      | TCP 22                     | SSH remote management                         |
|              | TCP 8443                   | HTTPS for UI access                           |
| Outbound     | TCP 830                    | NETCONF to Cisco Optical Site Manager devices |
|              | TCP 389                    | LDAP if using Active Directory                |
|              | TCP 636                    | LDAPS if using Active Directory               |
|              | Customer specific          | HTTP access to an SDN controller              |
|              | User specific              | HTTPS access to an SDN controller             |
|              | TCP 3082, 3083, 2361, 6251 | TL1 to optical devices                        |

| Traffic type                                      | Port          | Description                   |
|---|---------------|-------------------------------|
| Eastbound   | TCP 10443     | Supercluster join requests    |
|   | UDP 8472      | VXLAN                         |
| Syslog  | User specific | TCP/UDP                       |
| Control plane ports<br>(internal, not<br>exposed) | TCP 443       | Kubernetes                    |
|   | TCP 6443      | Kubernetes                    |
|   | TCP 10250     | Kubernetes                    |
|   | TCP 2379      | etcd                          |
|   | TCP 2380      | etcd                          |
|   | UDP 8472      | VXLAN                         |
|   | ICMP          | Ping between nodes (optional) |

**Installation files:**

Cisco Optical Network Controller is released as a single VMware OVA distribution. The OVA includes an OVF descriptor and virtual disk files that contain the operating system and Cisco Optical Network Controller installation files. You can deploy the OVA using vCenter on ESXi hosts for standalone or supercluster deployments.




---

**Note** During OVF deployment, the deployment is aborted if there is an internet disconnection.

---

**Geo-redundant deployment for global operations**

An enterprise with data centers in different geographic regions deploys Cisco Optical Network Controller using a geo-redundant supercluster. If one region becomes unavailable, the standby region automatically assumes control, ensuring uninterrupted network management.

**Single-region deployment without geo redundancy**

A deployment using a single Cisco Optical Network Controller cluster in one data center does not provide protection against regional outages or catastrophic failures.

**Geo redundancy compared to backup control centers**

Geo-redundant deployment is similar to operating a secondary control center that can immediately take over operations if the primary center becomes unavailable.

- [Geo-redundant deployment limitations and behavior, on page 6](#)
- [, on page ?](#)
- [Connect to supercluster VM using SSH keys, on page 16](#)
- [Configure static eastbound routes between supercluster nodes, on page 17](#)

- [Configure BGP for supercluster routing, on page 18](#)
- [Join clusters into a supercluster, on page 19](#)
- [Verify cluster connectivity and start the supercluster, on page 20](#)
- [Validate supercluster service status and installed version, on page 21](#)
- [Set Up Web UI Access to Cisco Optical Network Controller, on page 23](#)
- [Perform a switchover in a geo-redundant Cisco Optical Network Controller deployment, on page 24](#)
- [Upgrade a standalone or high-availability Cisco Optical Network Controller deployment to a geo-redundant deployment , on page 26](#)
- [Update time zone configuration in a geo-redundant deployment, on page 35](#)
- [Revert to a previous version of Cisco Optical Network Controller, on page 40](#)
- [Install Cisco Optical Network Controller using Kernel-based Virtual Machine \(KVM\), on page 41](#)

## Geo-redundant deployment limitations and behavior

Use this reference to understand operational limitations and system behavior during switchover and failover events in geo-redundant deployments.

Geo-redundant deployments have the following limitations and behavioral characteristics:

- **Replication lag:** Geo redundancy uses asynchronous replication. If a switchover or failover occurs during an ongoing operation, there is a small risk of data loss when network latency is high.

The newly active node might not have information about an in-progress operation because the database transaction was not fully replicated.

For example, if a node or circuit delete operation completes on the active node but a switchover occurs before replication finishes, the new active node might still display the deleted object. Retry the operation to resolve the issue.

- **Double failures:** For Cisco Optical Network Controller releases 25.1.2 and earlier, if two out of three nodes are down or unreachable, the remaining node transitions to a standby state.

During recovery, one virtual machine (VM) is designated as active, but no failover alarm is generated. The controller cannot be accessed using the virtual IP address until at least one additional node becomes available.

- **Consistent role state enforcement:** In the GeoHA design, if a role transition request is received while another role transition is still being processed, Cisco Optical Network Controller automatically restarts the network service.

This behavior ensures a clean and accurate view of the active role and prevents inconsistent role status across nodes.

- **Northbound notification loss:** During a switchover or failover, the northbound virtual IP interface is temporarily unreachable.

During this interruption, event notifications sent to hierarchical or external controllers are lost. Cisco Optical Network Controller releases 24.x.x and 25.x.x do not support notification replay.

- **Performance monitoring (PM) data loss:** The 15-minute and 1-day PM buckets collected during a switchover or failover event are lost.

PM data collection resumes normally with the next bucket after the switchover or failover alarm clears.

- **SWIM job failures:** Any SWIMU ad hoc device configuration backup jobs that are running during a switchover or failover transition to the *Failed* state.  
  
Recreate the job to trigger the backup again. Scheduled SWIM jobs that are in progress also fail, but future scheduled executions continue according to the configured schedule.
- **Data corruption during restore operations:** Cisco Optical Network Controller supports database restore operations only on the active node.  
  
If a switchover or failover occurs while a restore operation is in progress, database corruption can occur. In this case, controller services might not return to the ready state.  
  
Perform the restore operation again to recover the cluster.
- **Switchover and failover duration:** Before triggering a manual switchover, verify that all microservices on both active and standby nodes are in the ready state by running the `sedo system status` command.  
  
A switchover or failover requires approximately 4 minutes to complete. Do not initiate another switchover during this period.  
  
After a node failover, the failed node requires approximately 15 to 20 minutes to become ready for a subsequent switchover or failover. Triggering another event before the node is ready can result in a double failure.  
  
When TAPI is enabled, switchover time can exceed 4 minutes depending on the number of devices and circuits.
- **Web UI unavailability during failover:** During a failover event, the Cisco Optical Network Controller web UI is unavailable until the failover process completes.  
  
This unavailability typically lasts approximately 4 minutes. After the failover completes, refresh the browser to regain access. To confirm a failover, review the switchover alarm in the Alarm History.
- **Incomplete circuit configurations:** If a circuit is partially provisioned and a switchover or failover occurs before database replication completes, the system can create incomplete or disconnected configurations.  
  
Manually clean up these configurations using Cisco Optical Site Manager.

Install and deploy geo-redundant Cisco Optical Network Controller Learn how to install and deploy Cisco Optical Network Controller in a geo-redundant environment.

Deploy the Cisco Optical Network Controller OVA for each supercluster node. Deploy a separate OVA for every node in vCenter.

For background and deployment considerations, see Geo-redundant deployment overview. Use the same template values across all nodes and adjust only node-specific settings. Assign consistent names and configure network mappings for every node.

Review prerequisites in Geo-redundant deployment prerequisites. Follow these steps to deploy the OVA for each supercluster node.

1. Right-click the ESXi host in the vSphere client screen and click **Deploy OVF Template**.
2. In the **Select an OVF template** screen, choose the **URL** button to download and install the OVF package from the Internet.

Alternatively, select the **Local file** radio button to upload the OVA files from your local system, then click **Next**. Select an OVF Template

3. In the **Select a name and folder** screen, specify a unique name for the virtual machine instance. Select the VM location and click **Next**.

Choose the data center and location for each virtual machine based on your deployment requirements. Compute resources in the subsequent step will appear according to your selection.

**Figure 2: Select a name and folder**

**Figure 3: Select a name and folder**

The screenshot shows a multi-step wizard titled "Deploy OVF Template". The current step is "2 Select a name and folder". The left sidebar lists the steps: 1 Select an OVF template, 2 Select a name and folder (active), 3 Select a compute resource, 4 Review details, 5 Select storage, and 6 Ready to complete.

The main content area is titled "Select a name and folder" and includes a close button (X). It contains the following text and fields:

- Specify a unique name and target location
- Virtual machine name:
- Select a location for the virtual machine.
- A tree view showing the location hierarchy:
  - svt-vcenter3.cisco.com (expanded)
    - BGL
    - NxF** (selected)
    - SVT-Crosswork
    - SVT-Crosswork2
    - SVT-E2E
- Navigation buttons: CANCEL, BACK, and NEXT.

4. In the **Select a compute resource** screen, select the destination for the VM. In the Review details screen, verify the template details and click **Next**.

Figure 4: Select a Compute Resource

Deploy OVF Template

- Select an OVF template
- Select a name and folder
- Select a compute resource**
- Review details
- Select storage
- Ready to complete

Select a compute resource

Select the destination compute resource for this operation

- NxF
  - 10.58.230.252
  - 10.58.236.12
  - 10.58.236.14
  - 10.58.236.16**
  - onc-cw-13.cisco.com
  - onc-cw-14.cisco.com
  - onc-cw-5.cisco.com
  - onc-cw-6.cisco.com

Compatibility

✓ Compatibility checks succeeded.

CANCEL BACK NEXT

The compatibility check proceeds until it completes successfully.

Figure 5: Review Details

Deploy OVF Template

- Select an OVF template
- Select a name and folder
- Select a compute resource
- Review details**
- Select storage
- Select networks
- Customize template
- Ready to complete

Review details

Verify the template details.

|               |   |
|---------------|---|
| Publisher     | No certificate present                                    |
| Product       | CONC  |
| Version       | 25.1.2  |
| Download size | 4.1 GB  |
| Size on disk  | Unknown (thin provisioned)<br>68.6 GB (thick provisioned) |

CANCEL BACK NEXT

- In the **Select storage** screen, select the virtual disk format according to your requirements. **VM Storage Policy** is set as Datastore Default and click **Next**. Select the **virtual disk format** as Thin Provision.

**Figure 6: Select Storage**

**Deploy OVF Template**

- Select an OVF template
- Select a name and folder
- Select a compute resource
- Review details
- Select storage**
- Select networks
- Customize template
- Ready to complete

**Select storage**

Select the storage for the configuration and disk files

Encrypt this virtual machine (Requires Key Management Server)

Select virtual disk format: Thin Provision

VM Storage Policy: Datastore Default

Disable Storage DRS for this virtual machine

| Name          | Storage Compatibility | Capacity | Provisioned | Free    | Type   | Cluster |
|---------------|-----------------------|----------|-------------|---------|--------|---------|
| 10.58.236.... | --                    | 5.23 TB  | 999.04 GB   | 4.26 TB | VMFS 6 |         |

Compatibility

✓ Compatibility checks succeeded.

CANCEL BACK NEXT

- In the Select networks screen, select the Control Plane, Eastbound, and Northbound networks you created for each VM and click **Next**.

Figure 7: Select Networks

### Deploy OVF Template

- 1 Select an OVF template
- 2 Select a name and folder
- 3 Select a compute resource
- 4 Review details
- 5 Select storage
- 6 Select networks
- 7 Customize template
- 8 Ready to complete

### Select networks

Select a destination network for each source network.

| Source Network | Destination Network  |
|----------------|----------------------|
| Control Plane  | dataplane_gha1-clc ▾ |
| Northbound     | Northbound_gha1 ▾    |
| Eastbound      | Eastbound_gha1_PG ▾  |

3 items

#### IP Allocation Settings

IP allocation: Static - Manual

IP protocol: IPv4

CANCEL BACK NEXT

7. In the **Customize template** screen, set the values using the following table as a guideline.

Figure 8: Customize Template

### Deploy OVF Template

- 1 Select an OVF template
- 2 Select a name and folder
- 3 Select a compute resource
- 4 Review details
- 5 Select storage
- 6 Select networks
- 7 Customize template
- 8 Ready to complete

### Customize template

Customize the deployment properties of this software solution.

General 2 settings

|                   |                      |
|-------------------|----------------------|
| Instance Hostname | CONC-25.12           |
| SSH Public Key    | ssh-ed25519 AAAAC3N: |

Node Config 11 settings

|                               |  |
|-------------------------------|--|
| Node Name                     | Must be a valid DNS name per RFC1123 (will be converted to one if invalid) |
|                               | CONC-25.12   |
| Initiator Node                | <input checked="" type="checkbox"/>  |
| Supercluster Cluster Index    | 1 ▾  |
| Supercluster Cluster Name     | Must be a valid DNS name per RFC1123 (will be converted to one if invalid) |
|                               | cluster1   |
| Data Volume Size (GB)         | 50   |
| NTP Pools (comma separated)   | debian.pool.ntp.org  |
| NTP Servers (comma separated) |  |
| Cluster Join Token            |  |

CANCEL BACK NEXT

### Deploy OVF Template

- 1 Select an OVF template
- 2 Select a name and folder
- 3 Select a compute resource
- 4 Review details
- 5 Select storage
- 6 Select networks
- 7 Customize template
- 8 Ready to complete

### Customize template

|                               |   |
|-------------------------------|---|
| NTP Servers (comma separated) | 1.ntp.esl.cisco.com,10.58                         |
| Cluster Join Token            | 5j72ur.a13dalmh5q07nz                             |
| Control Plane Node Count      | 1   |
| Control Plane IP (ip/subnet)  | 10.1.0.11/24                                      |
| Initiator IP                  | Control plane IP of initiator node<br>10.1.0.11   |
| Northbound Interface          | 4 settings  |
| Protocol                      | Static IP   |
| IP (ip/subnet)                | Used only if DHCP is disabled<br>192.168.10.11/24 |
| Gateway                       | Used only if DHCP is disabled<br>192.168.10.1     |
| DNS                           | Used only if DHCP is disabled<br>10.1.71.184      |
| Eastbound Interface           | 4 settings  |
| Protocol                      | Static IP   |

CANCEL BACK NEXT

### Deploy OVF Template

- 1 Select an OVF template
- 2 Select a name and folder
- 3 Select a compute resource
- 4 Review details
- 5 Select storage
- 6 Select networks
- 7 Customize template
- 8 Ready to complete

### Customize template

|                            |   |
|----------------------------|---|
|                            | 144.254.71.184  |
| Eastbound Interface        | 4 settings  |
| Protocol                   | Static IP   |
| IP (ip/subnet)             | Used only if DHCP is disabled<br>172.20.10.11/24  |
| Gateway                    | Used only if DHCP is disabled<br>172.20.10.2  |
| DNS                        | Used only if DHCP is disabled<br>10.1.71.184  |
| Initiator Config           | 1 settings  |
| Northbound Virtual IP Type | Required if node is initiator<br>L3   |
| Cluster Config             | 3 settings  |
| Northbound Virtual IP      | Required if node is initiator<br>10.58.236.219  |
| Supercluster Cluster Role  | <input checked="" type="checkbox"/> worker<br><input type="checkbox"/> arbitrator<br><input type="checkbox"/> nodes |
| Arbitrator Node Name       |   |

CANCEL BACK NEXT

For the arbitrator node, choose *arbitrator* as the **Supercluster Cluster Role**.

**Table 2: Customize Template**

| Key            | Values |
|----------------|--------|
| <b>General</b> |        |

| Key                                  | Values   |
|--------------------------------------|--|
| Instance Hostname                    | <p>&lt;<i>instance-name</i>&gt;</p> <p>Must be a valid DNS name per RFC1123.1.2.4.</p> <ul style="list-style-type: none"> <li>• Contain at most 63 characters.</li> <li>• Contain only lowercase alphanumeric characters or '-'</li> <li>• Start with an alphanumeric character.</li> <li>• End with an alphanumeric character.</li> </ul> |
| SSH Public Key                       | <p>&lt;<i>ssh-public-key</i>&gt;. Used for SSH access that allows you to connect to the instances securely without the need to manage credentials for multiple instances. SSH public key must be a ed25519 key. See <a href="#">SSH Key Generation</a>.</p>  |
| <b>Node Config</b>                   |  |
| Node Name                            | Use the same name as <i>Instance Hostname</i>  |
| Initiator Node                       | Select the check box   |
| Supercluster Cluster Index           | Set to <b>1</b> (active cluster), <b>2</b> (standby cluster), or <b>3</b> (arbitrator).  |
| Supercluster Cluster Name            | Set to <b>cluster1</b> (active cluster), <b>cluster2</b> (standby cluster), or <b>cluster3</b> (arbitrator).   |
| Data Volume Size (GB)                | Configure data volume according to the VM profile.   |
| NTP Pools (comma separated)          | (Optional) A comma-separated list of the NTP pools. For example, <a href="http://debian.pool.ntp.org">debian.pool.ntp.org</a>  |
| NTP Servers (comma separated)        | A comma-separated list of the NTP servers.   |
| Cluster Join Token                   | Autogenerated value. Leave as is.  |
| Control Plane Node Count             | 1  |
| Control Plane IP (ip[/subnet])       | <Private IP for the Instance> Control Plane Network  |
| Initiator IP                         | <Same IP as Control Plane> Control Plane Network   |
| <b>Northbound Interface</b>          |  |
| Protocol                             | Static IP  |
| IP (ip[/subnet]) - if not using DHCP | <Public IP for the Instance> Northbound Network  |
| Gateway - if not using DHCP          | <Gateway IP for the Instance> Northbound Network   |
| DNS                                  | DNS Server IP  |
| <b>Eastbound Interface</b>           |  |
| Protocol                             | Static IP  |
| IP (ip[/subnet]) - if not using DHCP | < IP for the Instance> Eastbound Network   |

| Key                         | Values   |
|-----------------------------|--|
| Gateway - if not using DHCP | <Gateway IP for the Network> Eastbound Network   |
| DNS                         | DNS Server IP  |
| <b>Initiator Config</b>     |  |
| Northbound Virtual IP Type  | L3   |
| <b>Cluster Config</b>       |  |
| Northbound Virtual IP       | Virtual IP for the SuperCluster  |
| Supercluster Cluster Role   | <i>worker</i> for primary and secondary nodes<br><i>arbiter</i> for arbiter node   |
| Arbiter Node Name           | a unique node name.<br><br><b>Attention</b> <ul style="list-style-type: none"> <li>• The arbiter node name must not be the same as any node in the supercluster. This field must not be the same as the node name of the arbiter node either.</li> <li>• The arbiter node name must be the same across all nodes in the supercluster.</li> </ul> |

Do not configure the Northbound and Eastbound networks in the same subnet or VLAN segment. Use separate subnets and VLAN segments for these networks.

8. In **Review the details** screen, review all your selections and click **Finish**. To check or change any properties from the review screen, before clicking Finish, click **BACK** to return to the **Customize template** screen.

Figure 9: Ready to Complete

**Deploy OVF Template**

- Select an OVF template
- Select a name and folder
- Select a compute resource
- Review details
- Select storage
- Select networks
- Customize template
- Ready to complete**

**Ready to complete**

Review your selections before finishing the wizard

- Select a name and folder**
  - Name: CONC-25.1.2
  - Template name: 25.1.2-9
  - Folder: NxF
- Select a compute resource**
  - Resource: 10.58.230.252
- Review details**
  - Download size: 4.1 GB
- Select storage**
  - Size on disk: 68.6 GB
  - Storage mapping: 1
  - All disks: Datastore: vm-storage; Format: Thick provision lazy zeroed
- Select networks**
  - Network mapping: 3
  - Control Plane: dataplane\_gha1-clc
  - Northbound: Northbound\_gha1
  - Eastbound: Eastbound\_gha1\_PG
  - IP allocation settings

CANCEL BACK FINISH

---

**Deploy OVF Template**

- Select an OVF template
- Select a name and folder
- Select a compute resource
- Review details
- Select storage
- Select networks
- Customize template
- Ready to complete**

**Ready to complete**

- Eastbound: MGMT\_NxF\_PG
- IP allocation settings
- IP protocol: IPV4
- IP allocation: Static - Manual
- Customize template**
  - Properties

```
Instance Hostname = CONC-25.1.2
SSH Public Key = ssh-ed25519
AAAAAC3NzaC1iZDINTES5AAAIKAn33NZjrMWyMjpt7QvrD4vCvEAg4PPdpb3UFxmB6XL
ramve2@RAMVE2-M-D6HZ
Node Name = CONC-25.1.2
Initiator Node = True
Supercluster Cluster Index = 1
Supercluster Cluster Name = cluster1
Data Volume Size (GB) = 50
NTP Pools (comma separated) = debian.pool.ntp.org
NTP Servers (comma separated) = 1.ntp.esl.cisco.com,10.58.228.1
Cluster Join Token = inplhb.vmcrcrw85fkz4ct
Control Plane Node Count = 1
Control Plane IP (ip[/subnet]) = 10.1.0.11
Initiator IP = 10.1.0.11
Protocol = Static IP
IP (ip[/subnet]) = 192.168.10.11
Gateway = 192.168.10.1
DNS = 10.1.71.184
Protocol = Static IP
IP (ip[/subnet]) = 172.20.10.11
Gateway = 172.20.10.1
DNS = 10.1.71.184
Northbound Virtual IP Type = L3
Northbound Virtual IP = 10.64.106.181
Supercluster Cluster Role = worker
Arbitrator Node Name = node3
```

CANCEL BACK FINISH

9. Repeat the step 8 three times to create two worker node VMs (active and standby) and one arbitrator node VM.

- You can create the other nodes at a different data center, host, or vCenter instance as needed. Ensure Eastbound and Northbound network connectivity between the nodes.

- Upon activation of the VM, it does not respond to ping requests. However, you can log in using SSH if the installation is successful.

The OVA deployment is completed for the supercluster nodes.

[Set up the supercluster](#)

## Connect to supercluster VM using SSH keys

Connect to each supercluster VM using SSH keys for secure access.

Use the PEM key generated during SSH key setup to access each node.

### Before you begin

- Confirm that three VMs have been created for geo-redundant deployment of Cisco Optical Network Controller. For more details, see [#unique\\_11, on page ?](#).
- Verify that each VM is powered on. Wait for the IP addresses for the VMs on vSphere to appear.

Follow these steps to connect to the supercluster virtual machines.

### Procedure

**Step 1** Connect to each VM using the PEM key generated during [SSH Key Generation](#).

**Step 2** Log in to each VM using the private key.

```
# ssh -i <private-key_file> nxf@<node_ip>
```

### Note

- If you are prompted for a password, there might be a problem with the key. If your SSH key has a passphrase, the system prompts you for the passphrase. If you are prompted for a password even after entering your SSH key passphrase, your PEM key might be wrong or corrupted.
- If the command times out, check your network settings and make sure the node is reachable.
- After the nodes are deployed, check the OVA deployment progress in the Tasks console of vSphere Client. Upon successful deployment, Cisco Optical Network Controller can take about 20 minutes to boot.
- The default user ID is *admin*. Set the password using the `sedo security user set admin --password` command.

You are connected to each supercluster VM.

### What to do next

[Configure static eastbound routes between supercluster nodes, on page 17](#)

# Configure static eastbound routes between supercluster nodes

Configure static routes to allow eastbound traffic to pass between supercluster nodes. If peer node eastbound IPs are in different subnets, create static routes for eastbound traffic between the nodes.

## Before you begin

[Connect to supercluster VM using SSH keys, on page 16](#)

Follow these steps to configure eastbound routes.

## Procedure

---

**Step 1** Navigate to the configuration directory.

```
cd /etc/systemd/network/
```

**Step 2** Identify the network configuration file for the eastbound interface *ens256*. For example, it may be named *10-cloud-init-ens256.network*.

**Step 3** Open the configuration file with administrative privileges. Update the **[Route]** section by adding the static routes using this template.

### Note

Replace all placeholders with the actual IP addresses and gateway information.

```
[Match]
Name=ens256

[Network]
DHCP=no
DNS=<dns-server-ip>

[Address]
Address=<cluster1-eastbound-ip>/<subnet-mask>

[Route]
Destination=<eastbound-subnet-of-cluster2>/<subnet-mask>
Gateway=<gateway-ip>

[Route]
Destination=<eastbound-subnet-of-cluster3>/<subnet-mask>
Gateway=<gateway-ip>
```

**Step 4** Save the file. Exit the editor.

### Example:

```
# Example
[Match]
Name=ens256

[Network]
DHCP=no
DNS=10.10.128.236

[Address]
Address=172.10.10.11/24
```

```
[Route]
Destination=172.10.20.0/24
Gateway=172.30.10.2
```

```
[Route]
Destination=172.10.30.0/24
Gateway=172.30.10.2
```

**Note**

- Verify that the `Name` in the `[Match]` section matches the correct network interface.
- Verify that the DNS and gateway IPs are correctly assigned for your network.

**Step 5** Use the `ping` command to verify connectivity between the nodes.

**Step 6** Restart the `systemd-networkd` service to apply the changes.

**Example:**

```
sudo systemctl restart systemd-networkd
```

**Step 7** Verify that the routes are created.

```
ip route
```

---

The eastbound routes are configured. Connectivity has been verified.

## Configure BGP for supercluster routing

Configure BGP so the supercluster can advertise the virtual IP route.

**Before you begin**

- Obtain the router IP address, autonomous system number, and password from your network administrator before you begin.
- Confirm that each node can reach the northbound network.

Follow these steps to configure BGP for supercluster routing.

**Procedure**

**Step 1** Initialize BGP on each node.

```
sedo ha bgp init <current_node_name> <current_node_northbound_ip> <current_node_as> --nexthop
<current_node_northbound_ip>
```

**Step 2** Add a BGP router to each node.

```
sedo ha bgp router add <current_node_name> <bgp_router_ip> <bgp_router_as> <bgp_password> --ttl-min 255
```

**Note**

Collect the BGP router IP address, router autonomous system number, and BGP password from your network administrator. The BGP password must match the neighbor configuration on the router.

**Example:**

```
sedo ha bgp router add conc2512-2 192.168.125.1 65534 password --ttl-min 255
```

BGP is initialized, and the router is added to each node.

## Join clusters into a supercluster

Join three clusters into a single supercluster.

**Before you begin**

- Complete the Border Gateway Protocol (BGP) and eastbound routing configuration before you join clusters.
- Ensure you can run commands on each cluster node.

Follow these steps to join clusters into a supercluster.

**Procedure****Step 1**

Use the **sedo supercluster status** command on each node to retrieve the cluster ID.

**Example:**

```
sedo supercluster status
# Sample output
```

| Supercluster Status |   |
|---------------------|---|
| Cluster ID          | vk0uFBSwM1vX4_mC1BAabDxAKXYUTv1KH5dcCDawZw4 |
| Cluster Name        | cluster1                                    |
| Cluster Role        | worker                                      |
| Peers               | <No Peers>                                  |
| Initialized         | No  |

**Note**

You need the cluster ID for each node for the next steps.

**Step 2**

Connect *cluster1* to *cluster2*.

- Initiate the connection on cluster1.

**Example:**

```
# Sample output
sudo sedo supercluster wait-for -b 172.20.2.89:10443 uUD21AaV4cQ8CzZQf0E0YrGmALi0vHASpZI07YzcsQ
Listening for join requests on 172.20.2.89:10443...
Please run the following on peer node:
$ sudo /usr/bin/sedo supercluster join Lh9Gv3FwSUsx7Gu_7EJoIMe4r5YE6ApyHqOEt83fko
https://172.20.2.89:10443/join/g4jKVulJo74ptz821MvngQ
```

- Run the join command generated by cluster1 on cluster2.

**Example:**

```
sudo /usr/bin/sedo supercluster join Lh9Gv3FwsUsx7Gu_7EJoIMe4r5YE6ApyHqOEt83fko
https://172.20.2.89:10443/join/g4jKVulJo74ptz82lMvngQ
```

**Step 3** Connect *cluster1* to *cluster3*.

- a) Initiate the connection on cluster1.

```
sudo sedo supercluster wait-for -b <cluster1_node_eastbound_ip>:10443 <cluster3_node_cluster_id>
```

- b) Run the join command generated by cluster1 on cluster3.

**Step 4** Connect *cluster2* to *cluster3*.

- a) Initiate the connection on cluster2.

```
sudo sedo supercluster wait-for -b <cluster2_node_eastbound_ip>:10443 <cluster3_node_cluster_id>
```

- b) Run the join command generated by cluster2 on cluster3.

---

Clusters are joined and ready for connectivity validation.

## Verify cluster connectivity and start the supercluster

Verify connectivity, start the supercluster, and confirm its operational status.

**Before you begin**

Ensure that clusters are joined and reachable.

Follow these steps to verify connectivity and start the supercluster.

**Procedure**

- Step 1**
- Use the
- sedo supercluster connectivity**
- command to verify connectivity between clusters.

**Note**

Wait until all connections are successful. Clusters typically establish connectivity within 5 minutes.

**Example:**

```
sudo sedo supercluster connectivity
```

| Supercluster Connectivity |                       |      |         |
|---------------------------|-----------------------|------|---------|
| FROM                      | TO                    | RTT  | RESULT  |
| cluster2/controller-0     | cluster1/controller-0 | 14ms | Success |
| cluster2/controller-0     | cluster3/controller-0 | 15ms | Success |
| cluster1/controller-0     | cluster3/controller-0 | 12ms | Success |
| cluster1/controller-0     | cluster2/controller-0 | 12ms | Success |
| cluster3/controller-0     | cluster2/controller-0 | 13ms | Success |
| cluster3/controller-0     | cluster1/controller-0 | 13ms | Success |

- Step 2**
- Use the
- sedo supercluster start**
- command to start the supercluster.

**Note**

The node where you execute this command becomes the active node. The other worker node becomes the standby node.

**Example:**

```
sudo sedo supercluster start
```

```
Checking Supercluster connectivity...Passed
Initiating Supercluster...Done
```

**Step 3**

Use the **sedo supercluster status** to verify the supercluster status.

**Example:**

This sample output shows the result of the status command on the standby node. When **DB replication** is `streaming` and **DB Lag** is `0 bytes`, the geo-redundant deployment is running.

```
sedo supercluster status
```

| Supercluster Status   |  |
|-----------------------|--|
| Cluster ID            | QgQV2uXgPludqshlIssyTwf3LZzEyRh6I3z5MH8almA  |
| Cluster Name          | cluster1   |
| Cluster Role          | worker   |
| Peers                 | cluster2 (worker, jaWeN9BdXUUTxvofwt6Hukt6OQXIUaqo4NxN6zHYDc)<br>cluster3 (arbitrator, SUCrwqQjXToG5GKBwckcg_CtzzgHstQigaEM1X0988E)  |
| Mode                  | Running  |
| Current Active        | cluster1   |
| Previous Active       |  |
| Standby Clusters      | cluster2   |
| Last Switchover       |  |
| Last Failover         |  |
| Last Seen             | controller-0.cluster2: 2025-03-19 11:16:57.051 +0000 UTC<br>controller-0.cluster3: 2025-03-19 11:16:57.047 +0000 UTC<br>controller-0.cluster1: 2025-03-19 11:16:57.051 +0000 UTC |
| Last Peer Error       |  |
| Server Error          |  |
| <b>DB Replication</b> | <b>streaming</b>   |
| <b>DB Lag</b>         | <b>0 bytes</b>   |

The supercluster is running and connectivity is confirmed.

## Validate supercluster service status and installed version

Validate the service status and confirm the installed version.

Run these checks after the supercluster has started.

**Before you begin**

Follow these steps to validate services and version.

## Procedure

### Step 1 Check the status of all pods.

```
sedo system status
```

| System Status (Fri, 20 Sep 2024 08:21:27 UTC) |                              |       |         |          |              |
|---|------------------------------|-------|---------|----------|--------------|
| OWNER   | NAME                         | NODE  | STATUS  | RESTARTS | STARTED      |
| onc   | monitoring                   | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-alarm-service            | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-apps-ui-service          | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-circuit-service          | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-collector-service        | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-config-service           | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-devicemanager-service    | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-inventory-service        | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-nbi-service              | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-netconfcollector-service | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-osapi-gw-service         | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-pce-service              | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-pm-service               | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-pmcollector-service      | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-topology-service         | node1 | Running | 0        | 3 hours ago  |
| onc   | onc-torch-service            | node1 | Running | 0        | 3 hours ago  |
| system  | authenticator                | node1 | Running | 0        | 12 hours ago |
| system  | controller                   | node1 | Running | 0        | 12 hours ago |
| system  | flannel                      | node1 | Running | 0        | 12 hours ago |
| system  | ingress-proxy                | node1 | Running | 0        | 12 hours ago |
| system  | kafka                        | node1 | Running | 0        | 12 hours ago |
| system  | loki                         | node1 | Running | 0        | 12 hours ago |
| system  | metrics                      | node1 | Running | 0        | 12 hours ago |
| system  | minio                        | node1 | Running | 0        | 12 hours ago |
| system  | postgres                     | node1 | Running | 0        | 12 hours ago |
| system  | promtail-cltmk               | node1 | Running | 0        | 12 hours ago |
| system  | vip-add                      | node1 | Running | 0        | 12 hours ago |

#### Note

- The pod statuses appear in separate terminal sessions for each node.
- The status of all services must be *Running*.

### Step 2 Check the current version.

```
sedo version
```

| Installer: 24.3.2 |  |                |
|-------------------|--|----------------|
| NODE NAME         | OS VERSION   | KERNEL VERSION |
| node1-cl-sal      | NxFOS 3.2-555 (93358ad257a6cf1e3da439144e3d2e8343b53008) | 6.1.0-31-amd64 |

| IMAGE NAME | VERSION | NODES |
|------------|---------|-------|
|            |         |       |

...

The service status and version information are confirmed.

## Set Up Web UI Access to Cisco Optical Network Controller

Enable web user interface access to Cisco Optical Network Controller.

### Before you begin

Ensure you have administrator access to the Cisco Optical Network Controller VM.

Follow these steps to set up web user interface access to Cisco Optical Network Controller.

### Procedure

**Step 1** Use the **sedo security user set admin --password** command to set the initial UI password for the admin user.

#### Example:

```
sedo security user set admin --password
```

The password must include at least

- one uppercase letter,
- one lowercase letter,
- one number,
- one special character,
- must have a minimum length of eight characters.

#### Note

The password policy for the system includes both configurable settings and nonconfigurable hard requirements to ensure security.

**Step 2** (Optional) Change the password policy settings using the **sedo security password-policy set** command.

```
sedo security password-policy set --expiration-days <number> --reuse-limit <number>
--min-complexity-score <number>
```

| Parameter       | Description   |
|-----------------|---|
| expiration-days | Default password expiration used when creating new users, in days.<br><b>Default value:</b> 180 |

| Parameter                         | Description   |
|-----------------------------------|---|
| <code>min-complexity-score</code> | The password strength forced for local users can be enabled or disabled and can be set in scores of one to five (weak to strong). The password is checked against several dictionaries and common passwords lists, to ensure its complexity according to the selected score.<br><br><b>Default value:</b> 3 |
| <code>reuse-limit</code>          | This specifies how many historical passwords are retained and blocked from reuse when you change your password.<br><br><b>Default value:</b> 12   |

**Step 3** Use the `sedo security user list` to check the default admin user ID.

**Step 4** Use the `sedo security user admin set --password` to change the default password.

**Step 5** Open this URL to access the Cisco Optical Network Controller Web UI.

```
https://<virtual IP>:8443/
```

**Note**

Access the web UI only after all the `onc` services are running. Use the `sedo system status` command to verify that all services are running.

**Step 6** Log in to Cisco Optical Network Controller with the `admin` user ID and the password set in step 1.

## Perform a switchover in a geo-redundant Cisco Optical Network Controller deployment

Switch active and standby roles in a geo-redundant deployment.

Use this procedure when you need to move the active role to another cluster.

**Before you begin**

- Verify that a geo-redundant Cisco Optical Network Controller deployment is configured.
- Verify that the **DB replication** is *streaming* and **DB Lag** is *0 bytes* using the `sedo supercluster status` command.

```
sedo supercluster status
```

| Supercluster Status |   |
|---------------------|---|
| Cluster ID          | QgQV2uXgPludqshlIssyTwf3LZzEyRh6I3z5MH8aImA                         |
| Cluster Name        | cluster1  |
| Cluster Role        | worker  |
| Peers               | cluster2 (worker, jaWeN9BdXUUTxvofwt6Hukt6OQXIUaqo4NxN6zHYDc)       |
|                     | cluster3 (arbiterator, SUCrwqQjXToG5GKBwckcg_CtzzgHstQigaEM1X0988E) |

|                       |  |
|-----------------------|--|
| Mode                  | Running  |
| Current Active        | cluster1   |
| Previous Active       |  |
| Standby Clusters      | cluster2   |
| Last Switchover       |  |
| Last Failover         |  |
| Last Seen             | controller-0.cluster2: 2025-03-19 11:16:57.051 +0000 UTC |
|                       | controller-0.cluster3: 2025-03-19 11:16:57.047 +0000 UTC |
|                       | controller-0.cluster1: 2025-03-19 11:16:57.051 +0000 UTC |
| Last Peer Error       |  |
| Server Error          |  |
| <b>DB Replication</b> | <b>disconnected</b>                                      |
| <b>DB Lag</b>         | <b>0 bytes</b>   |

Follow these steps to perform a switchover in a geo-redundant deployment.

## Procedure

**Step 1** Run the **sedo supercluster switchover** *<target-active-cluster-name>* command and confirm when prompted.

### Note

When you perform a dynamic switchover of the active cluster using the **sedo supercluster switchover** command, the Cisco Optical Network Controller UI may display an *HTTP 500 Internal Server Error* for up to four minutes while the system stabilizes again.

### Example:

```

nxf@node:~$ sudo sedo supercluster switchover cluster2
Are you sure you want to initiate supercluster switchover to cluster "cluster2"? [y/n]y

```

The switchover takes place and WebUI displays a message that says *Switchover happened. Please refresh the page.*, and the WebUI update takes about 20 seconds.

**Step 2** Use the **sedo supercluster status** command to SSH in to the new active node and view the supercluster status.

```
sedo supercluster status
```

| Supercluster Status   |  |
|-----------------------|--|
| Cluster ID            | jaWeN9BdXUUTxvofwt6Hukt6OQXIUaqo4NxN6zHYDc   |
| Cluster Name          | cluster2   |
| Cluster Role          | worker   |
| Peers                 | cluster1 (worker, QgQV2uXgPludqshlIssyTwf3LZzEyRh6I3z5MH8almA)<br>cluster3 (arbiterator, SUCrwqQjXTToG5GKBwckcg_CtzgHstQigaEM1X0988E)  |
| Mode                  | Running  |
| Current Active        | cluster2   |
| Previous Active       | cluster1   |
| Standby Clusters      | cluster1   |
| Last Switchover       | 2025-03-19 11:20:49.705 +0000 UTC  |
| Last Failover         |  |
| Last Seen             | controller-0.cluster1: 2025-03-19 11:24:07.056 +0000 UTC<br>controller-0.cluster2: 2025-03-19 11:24:07.058 +0000 UTC<br>controller-0.cluster3: 2025-03-19 11:24:07.058 +0000 UTC |
| Last Peer Error       |  |
| Server Error          |  |
| <b>DB Replication</b> | <b>streaming</b>   |

|        |         |
|--------|---------|
| DB Lag | 0 bytes |
|--------|---------|

The DB replication status changes from `disconnected` to `streaming` as the switchover process progresses. Database replication is complete when the **DB Replication** status is streaming and **DB Lag** is 0 bytes.

#### Note

A switchover alarm is raised by Cisco Optical Network Controller during the switchover process. The alarm is cleared after the switchover. You can see the alarm details under Alarm History in the alarms app.

**Step 3** (Optional) Use the raft API to get the supercluster status.

#### Example:

```
nxf@node:~$ kubectl exec -it onc-devicemanager-service-0 -- curl -X GET
http://controller.nxf-system.svc.cluster.local/api/v1/raft/status
```

The API response gives you the information from the **sedo supercluster status** command.

#### Restriction

- Do not perform a switchover until the **DB replication** status is Streaming and **DB Lag** is 0 bytes after the previous switchover. This typically takes five minutes.
- If you perform a switchover while a delete operation was in progress, you must repeat the deleted operation on the new active after the switchover. This restriction applies to node and circuit delete operations.
- If the active cluster goes down for some reason, a failover takes place. During a failover, the web UI becomes unavailable for up to a minute, and the system raises the switchover alarm.

---

The active role switches to the target cluster and status reflects the change.

## Upgrade a standalone or high-availability Cisco Optical Network Controller deployment to a geo-redundant deployment

Upgrade a standalone deployment or a high-availability deployment to a geo-redundant deployment. Cisco Optical Network Controller supports upgrades to version 25.1.2 from previous releases. The required upgrade path depends on your current version.

This table describes the available upgrade path options.

**Table 3: Upgrade paths**

| Current version | Upgrade Path to 25.1.2        |
|-----------------|-------------------------------|
| 24.3.2          | Upgrade from 24.3.2 to 25.1.2 |
| 25.1.1          | Upgrade from 25.1.1 to 25.1.2 |
| 24.3.1          | 24.3.1 → 24.3.2 → 25.1.2      |
|                 | 24.3.1 → 25.1.1 → 25.1.2      |

These instructions explain how to upgrade a standalone deployment from Release 25.1.1 to 25.1.2 as well as configuring necessary networks for geo-redundant supercluster communication.



### Restriction

- Cisco Optical Network Controller does not support direct downgrades to older releases.
- To revert to a previous version, you must first create a database backup using the SWIMU application before upgrading. Then, install the desired older version using its OVA file, and finally, restore the database.
- Refer to the [Backup and Restore Database](#) documentation for detailed instructions.

### Before you begin

- **Backup Creation:** Verify that a full system backup is created. For details about creating a backup, see [Backup and Restore Database](#) or use the `sedo backup create full` command and export the backup for recovery if needed. Use this backup to [revert](#) to the older version if your upgrade fails.

#### Example:

```
root@conc-1:~# sedo backup create full
Creating backup, this may take a while...
Done creating backup
root@conc-1:~# sedo backup list
```

| NAME                          | TIME                                    | SIZE                        | TYPE                       |
|-------------------------------|---|-----------------------------|----------------------------|
| HOSTNAME   POSTGRES VERSION   |   |                             |                            |
| base_0000000E000000010000009E | 2025-03-11 04:11:47.733980894 +0000 UTC | 87 MB (838 MB Uncompressed) | full   postgres-0   150008 |

```
root@conc-1:~# cd /data
root@conc-1:/data# sedo backup download base_0000000E000000010000009E
Downloading Backup ... [.....<#>.....] [63.03MB in 9.200973s]
Finished downloading backup to "/data/nxf-backup-3.2-1741666307.tar.gz"

root@conc-1:/data# scp /data/nxf-backup-3.0-1736872559.tar.gz <remote location>
```

- **Network Configuration:** Before installing Cisco Optical Network Controller, create the required networks.
  - **Control Plane network:** The control plane network helps in the internal communication between the deployed VMs within a cluster.
  - **VM network or Northbound network:** The VM network is used for communication between the user and the cluster. It handles all the traffic to and from the VMs running on your ESXi hosts.

This network is your public network through which the UI is hosted. Cisco Optical Network Controller uses this network to connect to Cisco Optical Site Manager devices using Netconf/gRPC.
  - **Eastbound network:** The Eastbound network helps in the internal communication between the deployed VMs within a supercluster. The active and standby nodes use this network to synchronize their databases. The Postgres database is replicated across both active and standby nodes. MinIO is also replicated on the arbitrator.



**Note** **Bandwidth requirement:** The Eastbound network should provide 1 Gbps (1,000 Mbps) bandwidth and maintain latency below 100 ms (milliseconds).

You can configure the Eastbound network to be a flat Layer 2 network or an L2VPN, where the Eastbound IP addresses of all nodes are in the same subnet. If your Eastbound IPs are in different subnets, you must configure static routing between your nodes for the eastbound network.

- **BGP Router Configuration:** Obtain the BGP router IP, Router autonomous system number, and BGP password from network administrators for configuration.
- **VMware Setup:** Ensure that the vCenter has the required networks configured and attached correctly. Verify that physical adapters are correctly mapped for Northbound and Eastbound networks.
- **Access and Permissions:** Ensure you have the necessary permissions to execute commands and modify network settings on the nodes.

For more details about creating networks, see [Installation Requirements](#).

Follow these steps to upload the system pack for a standalone or high-availability deployment.

## Procedure

- Step 1** Perform any of these tasks based on the standalone or Geo HA setup.
- For standalone deployment, log in to the standalone node using the private key.
  - For Geo-redundant deployment, log in to the active node using the private key.
- Example:**
- ```
ssh -i <private-key_file> nxf@<node_ip>
```
- Step 2** Download or copy the 25.1.2 system pack `system-pack-file.tar.gz` to the NxF SA system running 25.1.1 and place it in the `/tmp` directory using `curl` or `scp`.
- Example:**
- ```
scp user@remote_server:/path/to/system-pack-file.tar.gz /tmp/
curl -o /tmp/system-pack-file.tar.gz http://example.com/path/to/system-pack-file.tar.gz
```
- Step 3** Check the system pack status using the **sedo system upgrade list** command.
- Example:**
- ```
sedo system upgrade list
```
- Step 4** Follow these steps to upload system pack for standalone or HA deployment.

| For standalone                                                                                                                                        | For HA                                                                                                                                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Upload the system pack using the <b>sedo system upgrade upload</b> command.</p> <pre>sedo system upgrade upload /tmp/system-pack-file.tar.gz</pre> | <p><b>a.</b> Upload the system pack using the <b>sedo system upgrade upload</b> command.</p> <pre>sedo system upgrade upload /tmp/system-pack-file.tar.gz</pre> <p><b>b.</b> Check the system pack status using the <b>sedo system upgrade pull</b> command.</p> <pre>sedo system upgrade pull /tmp/system-pack-file.tar.gz</pre> |

**Step 5** Apply the system pack using the **sedo system upgrade apply** command.

**Example:**

```
sedo system upgrade apply /tmp/system-pack-file.tar.gz
```

The upgrade process takes approximately 30 minutes to complete.

**Step 6** Reboot the system using the **reboot** command.

**Example:**

```
reboot
```

**Step 7** After the system reboots, verify the NxF version and system status by using the `sedo version` and `sedo system status` commands.

**Example:**

```
sedo version
```

| Installer: 24.3.2 |                                                                           |
|-------------------|---------------------------------------------------------------------------|
| NODE NAME         | OS VERSION   KERNEL VERSION                                               |
| node1-c1-sc2      | NxFOS 3.2-555 (93358ad257a6cf1e3da439144e3d2e8343b53008)   6.1.0-31-amd64 |

| IMAGE NAME                                                              | VERSION | NODES        |
|-------------------------------------------------------------------------|---------|--------------|
| docker.io/rancher/local-path-provisioner                                | v0.0.30 | node1-c1-sc2 |
| dockerhub.cisco.com/cisco-onc-docker/dev/monitoring                     |         | dev_latest   |
| quay.io/coreos/etcd                                                     | v3.5.15 | node1-c1-sc2 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/alarmservice          |         | 24.3.2-5     |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/circuit-service       |         | 24.3.2-5     |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/collector-service     |         | 24.3.2-5     |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/config-service        |         | 24.3.2-5     |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/devicemanager-service |         | 24.3.2-5     |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/inventory-service     |         | 24.3.2-5     |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/monitoring            |         | 24.3.2-5     |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/nbi-service           |         | 24.3.2-5     |

## Upgrade a standalone or high-availability Cisco Optical Network Controller deployment to a geo-redundant deployment

|                                                                            |              |          |
|----------------------------------------------------------------------------|--------------|----------|
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/netconfcollector-service | node1-cl-sc2 | 24.3.2-5 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/onc-apps-ui-service      | node1-cl-sc2 | 24.3.2-5 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/onc-kafkarecap-service   | node1-cl-sc2 | 24.3.2-5 |
| 0.1.PR93-26c53efb0cf6ebc1f0c4a2aa226a0ab3751b9101                          | node1-cl-sc2 | 24.3.2-5 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/osapi-gw-service         | node1-cl-sc2 | 24.3.2-5 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/pce_service              | node1-cl-sc2 | 24.3.2-5 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/pm-service               | node1-cl-sc2 | 24.3.2-5 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/pmcollector-service      | node1-cl-sc2 | 24.3.2-5 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/topology-service         | node1-cl-sc2 | 24.3.2-5 |
| registry.nxf-system.svc:8443/cisco-onc-docker/dev/torch                    | node1-cl-sc2 | 24.3.2-5 |
| registry.sedona.ciscolabs.com/nxf/authenticator                            | node1-cl-sc2 | 3.2-508  |
| registry.sedona.ciscolabs.com/nxf/bgp                                      | node1-cl-sc2 | 3.2-505  |
| registry.sedona.ciscolabs.com/nxf/controller                               | node1-cl-sc2 | 3.2-533  |
| registry.sedona.ciscolabs.com/nxf/firewalld                                | node1-cl-sc2 | 3.2-505  |
| registry.sedona.ciscolabs.com/nxf/flannel                                  | node1-cl-sc2 | 3.2-505  |
| registry.sedona.ciscolabs.com/nxf/ingress-proxy                            | node1-cl-sc2 | 3.2-508  |
| registry.sedona.ciscolabs.com/nxf/kafka                                    | node1-cl-sc2 | 3.2-505  |
| registry.sedona.ciscolabs.com/nxf/kubernetes                               | node1-cl-sc2 | 3.2-505  |
| registry.sedona.ciscolabs.com/nxf/loki                                     | node1-cl-sc2 | 3.2-505  |
| registry.sedona.ciscolabs.com/nxf/metrics-exporter                         | node1-cl-sc2 | 3.2-505  |
| registry.sedona.ciscolabs.com/nxf/minio                                    | node1-cl-sc2 | 3.2-505  |
| registry.sedona.ciscolabs.com/nxf/service-proxy                            | node1-cl-sc2 | 3.2-508  |
| registry.sedona.ciscolabs.com/nxf/timescale                                | node1-cl-sc2 | 3.2-515  |
| registry.sedona.ciscolabs.com/nxf/timescale                                | node1-cl-sc2 | 3.2-514  |

## sedo system status

| System Status (Fri, 20 Sep 2024 08:21:27 UTC) |                              |       |         |          |              |
|-----------------------------------------------|------------------------------|-------|---------|----------|--------------|
| OWNER                                         | NAME                         | NODE  | STATUS  | RESTARTS | STARTED      |
| onc                                           | monitoring                   | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-alarm-service            | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-apps-ui-service          | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-circuit-service          | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-collector-service        | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-config-service           | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-devicemanager-service    | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-inventory-service        | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-nbi-service              | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-netconfcollector-service | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-osapi-gw-service         | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-pce-service              | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-pm-service               | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-pmcollector-service      | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-topology-service         | node1 | Running | 0        | 3 hours ago  |
| onc                                           | onc-torch-service            | node1 | Running | 0        | 3 hours ago  |
| system                                        | authenticator                | node1 | Running | 0        | 12 hours ago |
| system                                        | controller                   | node1 | Running | 0        | 12 hours ago |
| system                                        | flannel                      | node1 | Running | 0        | 12 hours ago |
| system                                        | ingress-proxy                | node1 | Running | 0        | 12 hours ago |
| system                                        | kafka                        | node1 | Running | 0        | 12 hours ago |
| system                                        | loki                         | node1 | Running | 0        | 12 hours ago |
| system                                        | metrics                      | node1 | Running | 0        | 12 hours ago |

|        |                |       |         |   |              |
|--------|----------------|-------|---------|---|--------------|
| system | minio          | node1 | Running | 0 | 12 hours ago |
| system | postgres       | node1 | Running | 0 | 12 hours ago |
| system | promtail-cltmk | node1 | Running | 0 | 12 hours ago |
| system | vip-add        | node1 | Running | 0 | 12 hours ago |

**Step 8** Verify onboarded sites and services by accessing the Cisco Optical Network Controller UI.

**Example:**

Use a web browser to open `https://<virtual ip>:8443/` and access the Cisco Optical Network Controller Web UI.

**What to do next**

[Configure eastbound and northbound networks, on page 31](#)

## Configure eastbound and northbound networks

Update the interface configuration files. Restart the network services. Verify the network settings in vCenter. Set the eastbound interface to ensure correct connectivity.

Prepare the standalone node so it can communicate over the designated eastbound and northbound interfaces.

**Before you begin**

Ensure you know the required IP addresses and DNS values for eastbound and northbound interfaces.

Follow these steps to set up eastbound and northbound networks.

**Procedure**

**Step 1** Verify the Eastbound (ens256) and Northbound (ens224) interfaces using the `ip address` command.

**Example:**

```
ip address
3: ens224: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc mq state UP group default qlen 1000
   link/ether 00:50:56:9c:16:fb brd ff:ff:ff:ff:ff:ff
   altname enp19s0
   inet 192.168.10.11/24 brd 192.168.10.255 scope global ens224
       valid_lft forever preferred_lft forever
   inet 10.64.103.73/32 scope global ens224
       valid_lft forever preferred_lft forever
   inet6 fe80::250:56ff:fe9c:16fb/64 scope link
       valid_lft forever preferred_lft forever
4: ens256: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc mq state UP group default qlen 1000
   link/ether 00:50:56:9c:e1:fc brd ff:ff:ff:ff:ff:ff
   altname enp27s0
   inet 172.10.10.11/24 brd 172.10.10.255 scope global ens256
       valid_lft forever preferred_lft forever
   inet6 fe80::250:56ff:fe9c:e1fc/64 scope link
       valid_lft forever preferred_lft forever
```

**Note**

This sample output shows only the relevant part of the command output.

**Step 2** Update the IP address for the northbound interface (ens224) by modifying the configuration file located at `/etc/systemd/network/10-cloud-init-ens224.network`.

**Example:**

```
[Address]
Address=<northbound-node1-ip-address>/<subnet>

[Match]
Name=ens224

[Network]
DHCP=no
DNS=<northbound-node1-dns>

[Route]
Destination=0.0.0.0/0
Gateway=<northbound-node1-gateway>
```

**Step 3** Update the IP address of the Eastbound interface (ens256) by editing the interface file located at `/etc/systemd/network/10-cloud-init-ens256.network`.

**Example:**

```
[Address]
Address=<eastbound-node1-ip-address>/<subnet>

[Match]
Name=ens256

[Network]
DHCP=no
DNS=<eastbound-node1-dns>

# Optional - when static route is needed for eastbound network
[Route]
Destination=<network address need to be routed>/<subnet>
Gateway=<eastbound network gateway>
```

**Step 4** Restart the network service to apply the changes.

**Example:**

```
sudo systemctl restart systemd-networkd
```

**Step 5** Use **vCenter** to verify and update the northbound and eastbound network settings for the node.

a) In vCenter, click **ACTIONS** in the node screen.

The screenshot displays the vSphere interface for a VM named 'BGP'. The 'ACTIONS' menu is open, showing various management options. The background shows the VM's configuration page, including sections for Guest OS, VM Hardware, and Related Objects.

**Guest OS**

- LAUNCH REMOTE CONSOLE
- LAUNCH WEB CONSOLE

**VM Hardware**

|                          |                          |
|--------------------------|--------------------------|
| CPU                      | 6 CPU(s), 88 M           |
| Memory                   | 12 GB, 0 GB m            |
| Hard disk 1              | 80 GB   Thick<br>data-20 |
| Network adapter 1 (of 8) | VM Network (             |
| CD/DVD drive 1           | Disconnected             |

**Related Objects**

- Host
- 10.64.103.20
- Networks
- Control Plane
- Eastbound1
- Eastbound2
- Eastbound3

**ACTIONS - BGP**

- Power >
- Guest OS >
- Snapshots >
- Open Remote Console
- Migrate...
- Clone >
- Fault Tolerance >
- VM Policies >
- Template >
- Compatibility >
- Export System Logs...
- Edit Settings...
- Move to folder...
- Rename...
- Edit Notes...
- Tags & Custom Attributes >
- Add Permission...
- Alarms >
- Remove from Inventory
- Delete from Disk
- vSAN >

- Click **Edit Settings** in the drop-down list.
- Update the northbound and eastbound networks that you created for the supercluster.

## Edit Settings ×

Virtual Hardware
VM Options
Advanced Parameters

[ADD NEW DEVICE](#) ▾

|                     |                                                                    |                                           |
|---------------------|--------------------------------------------------------------------|-------------------------------------------|
| > CPU               | 32 ▾ <span style="font-size: 0.8em;">i</span>                      |                                           |
| > Memory            | 128                                                                | ▾ GB ▾                                    |
| > Hard disk 1       | 15,598                                                             | GB ▾ <span style="float: right;">⋮</span> |
| > Hard disk 2       | 500                                                                | GB ▾ <span style="float: right;">⋮</span> |
| > SCSI controller 0 | VMware Paravirtual <span style="float: right;">⋮</span>            |                                           |
| > Network adapter 1 | control plane ▾ <input checked="" type="checkbox"/> Connected      | ⋮                                         |
| > Network adapter 2 | VM Network ▾ <input checked="" type="checkbox"/> Connected         | ⋮                                         |
| > Network adapter 3 | Eastbound Network ▾ <input checked="" type="checkbox"/> Connected  | ⋮                                         |
| > CD/DVD drive 1    | Datastore ISO File ▾ <input checked="" type="checkbox"/> Connected | ⋮                                         |
| > Video card        | Specify custom settings ▾                                          |                                           |
| > SATA controller 0 | AHCI <span style="float: right;">⋮</span>                          |                                           |
| > Serial port 1     | Use physical serial port ▾ <input type="checkbox"/> Connected      | ⋮                                         |
| > Other             | Additional Hardware                                                |                                           |

CANCEL
OK

**Step 6** Use SSH to access the upgraded node with the new northbound IP address. Set the eastbound interface.

```
sedo system set-eastbound eastbound-interface
```

**Example:**

```
sedo system set-eastbound ens256
```

---

You have configured the eastbound and northbound networks for the standalone node.

**What to do next**

[Bring up a Worker Node and an Arbitrator Node.](#)

## Create worker and arbitrator nodes

This task is necessary when setting up georedundancy. It also prepares the nodes for supercluster configuration. Use this task to create worker and arbitrator nodes as part of a georedundant Cisco Optical Network Controller deployment.

### Before you begin

[Configure eastbound and northbound networks, on page 31](#)

Follow these steps to bring up a worker node and an arbitrator node. Create two more Cisco Optical Network Controller nodes for georedundancy.

### Procedure

---

- Step 1** Create two more Cisco Optical Network Controller nodes for Georedundancy. For more details about the instructions, see [Install and Deploy Geo Redundant Cisco Optical Network Controller](#).
- Step 2** (Optional) Edit the interface file located `/etc/systemd/network/10-cloud-init-ens256.network` to create static routes between the nodes for the eastbound network if the eastbound interfaces for the nodes are in different subnets.

#### Example:

```
# Optional - when static route is needed for eastbound network
[Route]
Destination=<network address need to be routed>/<subnet>
Gateway=<eastbound network gateway>
```

Add the configuration section with the required IP addresses to set up static routes.

- Step 3** (Optional) Restart the network service to apply the changes using:

#### Example:

```
sudo systemctl restart systemd-networkd
```

---

The worker and arbitrator nodes are created and prepared for supercluster setup.

### What to do next

[Set up the supercluster](#)

## Update time zone configuration in a geo-redundant deployment

From R25.1.2, you can update the timezone configuration. Previously, only the UTC time zone was supported. You can now configure Cisco Optical Network Controller in your preferred time zone.

For geo-redundant deployments, use the CLI command to update the timezone on each VM. Restart each VM using the steps described in this procedure to ensure a seamless change to the new timezone configuration. If the time zone configuration differs between VMs, a discrepancy can occur during failover or switchover.



**Note** Do not make frequent timezone changes, as it requires a reboot of VMs and services, which might cause inconsistencies.

Apply the same time zone on all three VMs. Be sure to review these limitations before making changes.

### Before you begin

- Verify status of every pod is `Running` by using the `kubectl get pods -A | grep onc` command. This example shows a sample output where all pods are running.

```
root@vml-cluster1-node1:~# kubectl get pods -A | grep onc
onc          monitoring-0          2/2      Running    0          21m
onc          onc-alarm-service-0  2/2      Running    3 (51m ago) 3h6m
onc          onc-apps-ui-service-6f95dfbc7c-60w87ne 2/2      Running
3 (51m ago) 3h6m
onc          onc-circuit-service-0          2/2      Running
3 (51m ago) 3h6m
onc          onc-collector-service-0          2/2      Running
3 (51m ago) 3h6m
onc          onc-config-service-02/2      Running    3 (51m ago) 3h6m
onc          onc-devicemanager-service-0    2/2      Running
3 (51m ago) 3h6m
onc          onc-inventory-service-0          2/2      Running
3 (51m ago) 3h6m
onc          onc-nbi-service-0    2/2      Running    3 (51m ago) 3h6m
onc          onc-netconfcollector-service-85bd7c89bf-qc8pf 2/2      Running
0          21m
```

- Verify that any previous switchover or failover has finished. Confirm that data replication across the active and standby nodes is complete. Use the `sedo supercluster status` to see the supercluster status and confirm that the **DB replication** status is `streaming` and **DB Lag** is `0`.

```
sedo supercluster status
```

| Supercluster Status |                                                                    |
|---------------------|--------------------------------------------------------------------|
| Cluster ID          | QCTdDdt_rlRd9lgzRM15vSeb0r1tkLMkfCK4DoAylaw                        |
| Cluster Name        | cluster1                                                           |
| Cluster Role        | worker                                                             |
| Peers               | cluster2 (worker, rabSbdhIWtq1qzhW1lZTm0Hu5_tIxOFZgDyWr5pac90)     |
|                     | cluster3 (arbitrator, XxHjr5wMmDyiYW6jbvaCcGZW8VIasb4sBv8x0B15DYk) |
| Mode                | Running                                                            |
| Current Active      | cluster1                                                           |
| Previous Active     | cluster2                                                           |
| Standby Clusters    | cluster2                                                           |
| Last Switchover     | 2025-06-09 00:34:46.826 -0500 CDT                                  |
| Last Failover       |                                                                    |
| Last Seen           | controller-0.cluster3: 2025-06-09 00:58:23.636 -0500 CDT           |
|                     | controller-0.cluster2: 2025-06-09 00:58:23.641 -0500 CDT           |
|                     | controller-0.cluster1: 2025-06-09 00:58:23.641 -0500 CDT           |
| Last Peer Error     |                                                                    |

|                |           |
|----------------|-----------|
| Server Error   |           |
| DB Replication | streaming |
| DB Lag         | 0 bytes   |

Follow these steps to configure time zone configuration in a geo-redundant deployment.

## Procedure

**Step 1** Use SSH to access the three VMs and run this command.

```
sudo timedatectl set-timezone timezone-name
```

### Example:

In this example, the time zone is set to JST.

```
root@vml-cluster1-node1:~# sudo timedatectl set-timezone Asia/Tokyo
root@vml-cluster1-node1:~# timedatectl

    Local time: Mon 2025-06-09 15:01:26 JST
    Universal time: Mon 2025-06-09 06:01:26 UTC
    RTC time: Mon 2025-06-09 06:01:26
    Time zone: Japan (JST, +0900)

System clock synchronized: yes
    NTP service: active

    RTC in local TZ: no
```

A few valid time zones are:

```
Asia/Kolkata
Asia/Dubai
Europe/Amsterdam
Africa/Bujumbura
```

**Step 2** Reboot the standby cluster using the **sudo reboot** command.

**Step 3** Verify the standby is up and running using these commands.

- **kubectrl get pods -A | grep onc**
- **sedo supercluster status**

Verify the time zone in one of the pods using these commands. See the offset after the time.

```
root@vml-cluster1-node1:~# kubectrl exec -ti onc-torch-service-0 -n onc -- bash
onc-torch-service-0:/$ date -R
Mon, 09 Jun 2025 15:22:42 +0900
```

**Step 4** Perform a manual switchover using the **sedo supercluster switchover** *cluster* command. Wait for the switchover and data replication to complete.

**Note**

When you perform a dynamic switchover of the active cluster using the **sedo supercluster switchover** command, the Cisco Optical Network Controller UI may display an *HTTP 500 Internal Server Error* for up to four minutes while the system stabilizes again.

```
root@vm1-cluster1-nodel:~# sedo supercluster switchover cluster2
```

```
Are you sure you want to initiate supercluster switchover to cluster "cluster2"? [y/n] y
```

Make sure DB replication status is streaming and DB Lag is 0.

```
root@vm1-cluster1-nodel:~# sedo supercluster status
```

| Supercluster Status |                                                                                                                                                                                  |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cluster ID          | QCTdDdt_rlRd9lgzRM15vSeb0r1tkLMkfCK4DoAylaw                                                                                                                                      |
| Cluster Name        | cluster1                                                                                                                                                                         |
| Cluster Role        | worker                                                                                                                                                                           |
| Peers               | cluster2 (worker, rabSbdhIWtq1qzhW1lZTm0Hu5_tIxOFZgDyWr5pac90)<br>cluster3 (arbitrator, XxHjr5wMmDyiYW6jbvaCcGZW8VIasb4sBv8x0B15DYk)                                             |
| Mode                | Running                                                                                                                                                                          |
| Current Active      | cluster2                                                                                                                                                                         |
| Previous Active     | cluster1                                                                                                                                                                         |
| Standby Clusters    | cluster1                                                                                                                                                                         |
| Last Switchover     | 2025-06-09 15:23:29.686 +0900 JST                                                                                                                                                |
| Last Failover       |                                                                                                                                                                                  |
| Last Seen           | controller-0.cluster3: 2025-06-09 15:23:34.277 +0900 JST<br>controller-0.cluster2: 2025-06-09 15:23:34.418 +0900 JST<br>controller-0.cluster1: 2025-06-09 15:23:34.418 +0900 JST |
| Last Peer Error     |                                                                                                                                                                                  |
| Server Error        |                                                                                                                                                                                  |
| DB Replication      | streaming                                                                                                                                                                        |
| DB Lag              | 0 bytes                                                                                                                                                                          |

```
root@vm109-cluster2-nodel:~# kubectl get pods -A | grep onc
```







```
onc          monitoring-0          2/2      Running   0          50m
onc          onc-alarm-service-0  2/2      Running   16 (65m ago)  4h23m
onc          onc-apps-ui-service-6c474df87d-6aq3bqd  2/2      Running   15 (65m ago)  4h23m
onc          onc-circuit-service-0          2/2      Running   15 (65m ago)  4h23m
onc          onc-collector-service-0        2/2      Running   15 (65m ago)  4h23m
onc          onc-config-service-02/2      Running   15 (65m ago)  4h23m
onc          onc-devicemanager-service-0    2/2      Running   17 (65m ago)  4h23m
onc          onc-inventory-service-0        2/2      Running   15 (65m ago)  4h23m
onc          onc-nbi-service-0  2/2      Running   15 (65m ago)  4h23m
onc          onc-netconfcollector-service-59b855956b-hrbbb  2/2      Running   0          3m18s
onc          onc-osapi-gw-service-0        2/2      Running   15 (65m ago)  4h23m
onc          onc-pce-service-0  2/2      Running   15 (65m ago)  4h23m
onc          onc-pm-service-0  2/2      Running   13 (65m ago)  3h34m
onc          onc-pmcollector-service-785669f8b7-7ndn4  2/2      Running   0          50m
onc          onc-topology-service-0        2/2      Running   15 (65m ago)  4h23m
```

onc                                      onc-torch-service-0 2/2                      Running                      16 (65m ago)                      4h23m

- Step 5**                      Repeat steps 2 and 3 for the new standby VM and the arbitrator VM.
- Step 6**                      If you want to make the original VM active, repeat Step 4.

Time zone configuration has been updated and Cisco Optical Network Controller web UI now displays time in the newly configured time zone.

This table shows screenshots highlighting the behavioral differences between Releases 25.1.1 and 25.1.2. In Release 25.1.2, the timestamp includes the time zone name and offset.

| Release 25.1.2                                                                                                         | Release 25.1.1                                                                                                          |
|------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| <p><b>Figure 10: Alarms</b></p>       | <p><b>Figure 11: Alarms</b></p>       |
| <p><b>Figure 12: PM History</b></p>  | <p><b>Figure 13: PM History</b></p>  |
| <p><b>Figure 14: Nodes</b></p>      | <p><b>Figure 15: Nodes</b></p>      |

This table summarizes how different system components handle time zones and describes related limitations.

| Component                | Time Zone Behavior | Notes                                                                                                                                                    |
|--------------------------|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Database (Alarms & Logs) | Stored in UTC      | During time zone transitions (for example, switchover), the UI might temporarily show alarms with different time zone stamps until the system converges. |

| Component                                          | Time Zone Behavior                        | Notes                                                                                                            |
|----------------------------------------------------|-------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| Cross-launch from Cisco Optical Network Controller | Offset preserved and IANA name may differ | Multiple IANA names can map to the same offset (for example, Asia/Colombo and Asia/Kolkata are both UTC +05:30). |
| TAPI Data and Notifications                        | UTC (+00:00)                              | Always uses UTC regardless of system time zone.                                                                  |
| SNMP Traps                                         | Epoch time                                | Time zone offset is not applied to epoch timestamps.                                                             |
| Developer Logs and Techdump                        | UTC                                       | No time zone conversion applied.                                                                                 |

## Revert to a previous version of Cisco Optical Network Controller

This is a manual process. Automatic rollback is not supported. You cannot perform a revert from within Cisco Optical Network Controller.



### Restriction

- Cisco Optical Network Controller does not support direct downgrades to older releases.
- To revert to a previous version, you must first create a database backup using the SWIMU application before upgrading. Then, install the desired older version using its OVA file, and finally, restore the database.
- Refer to the [Backup and Restore Database](#) documentation for detailed instructions.

You can revert Cisco Optical Network Controller to a previous version by reinstalling the software and restoring the database from a backup.

### Before you begin

Create a backup of the Cisco Optical Network Controller database. For details on creating a database backup, see [Backup and Restore Database](#).

Follow these steps to revert to a previous version of Cisco Optical Network Controller.

### Procedure

#### Step 1

For stand-alone deployments:

- Reinstall the previous version of Cisco Optical Network Controller, which is the version used for the backup. See [Install Cisco Optical Network Controller Using VMware vSphere](#).
- Follow the procedure to perform database restore from a backup. See [Backup and Restore Database](#).

#### Step 2

For georedundant deployments:

- Reinstall the previous version of Cisco Optical Network Controller, which is the version used for the backup. See [Install and Deploy Geo Redundant Cisco Optical Network Controller](#).
- Follow the procedure to perform database restore from a backup. See [Backup and Restore Database](#).

# Install Cisco Optical Network Controller using Kernel-based Virtual Machine (KVM)

Install Cisco Optical Network Controller on Kernel-based Virtual Machine (KVM) in a geo-redundant supercluster environment.

KVM (Kernel-based Virtual Machine) is a virtualization technology that allows you to run multiple virtual machines (VMs) on a single physical host.

## Before you begin

[Prepare virtual machine \(VM\) configuration files and generate the ISO, on page 41](#)

Follow these steps to install Cisco Optical Network Controller on a KVM.

## Procedure

- 
- Step 1** [Create KVM virtual machines](#): Provision new KVM virtual machines using `virt-install`, allocating resources and attaching the generated `cidata.iso` for initial setup.
- Step 2** [Configure BGP on VMs](#): Connect to the newly created VMs via SSH and initialize BGP (`sedo ha bgp init`) to enable inter-region routing for the supercluster.
- Step 3** [Join supercluster nodes](#): Retrieve `CLUSTER_ID` for each node and use `sedo supercluster wait-for` commands to join multiple nodes from different regions into a supercluster.
- Step 4** [Activate and verify Supercluster](#): Start the supercluster (`sedo supercluster start`), verify its operational status, and confirm connectivity among all nodes using `sedo supercluster status` and `sedo supercluster connectivity`. Update security settings and add users as needed.
- 

## What to do next

Use a web browser to access `https://<virtual ip>:8443/` to access the Cisco Optical Network Controller Web UI.

## Prepare virtual machine (VM) configuration files and generate the ISO

Prepare and package the necessary configuration data into an ISO image for deploying a geo-redundancy supercluster in a 1+1+1 scenario using KVM.

You will reuse the generated ISO when you create each KVM VM.

## Before you begin

- Follow this procedure for three VMs (two workers and one arbitrator).
- Ensure that you have the required configuration files.
  - network-config
  - user-data

- meta-data

Follow these steps to copy the configuration files and generate an ISO.

### Procedure

---

**Step 1** Copy the three configuration files to a designated folder on the server.

**Example:**

```
cp network-config user-data meta-data <PATH_TO_DEPLOY_DIR>/vmConfig/cloud-config/
```

**Step 2** Generate the ISO file using the three configuration files *network-config*, *user-data*, and *meta-data*.

**Example:**

```
mkisofs -o "<PATH_TO_DEPLOY_DIR>/vmConfig/cidata.iso" -r -J -V cidata
"<PATH_TO_DEPLOY_DIR>/vmConfig/cloud-config/"
```

---

The *cidata.iso* file is created containing packaged configuration data for the installation of Cisco Optical Network Controller using KVM.

### What to do next

[Create a new virtual machine on Kernel-based Virtual Machine \(KVM\), on page 42](#)

## Create a new virtual machine on Kernel-based Virtual Machine (KVM)

Provision a new KVM virtual machine to serve as a node for the Cisco Optical Network Controller. Define its initial hardware resources, storage, and network connectivity.

This task is executed on a KVM host machine immediately after you generate the *cidata.iso* file. This file contains the initial configuration for the VM.

### Before you begin

[Prepare VM configuration files and generate ISO](#)

Follow these steps for creating a new KVM:

### Procedure

---

Install the KVM using the **virt-install** command.

```
virt-install \
--name <HOST_NAME> \
--vcpus \
--memory \
--disk path=<PATH_TO_DEPLOY_DIR>/<QCOW2_FILE_NAME>.qcow2, format=qcow2 \
```

```

--disk
path=<PATH_TO_DEPLOY_DIR>/<QCOW2_FILE_NAME>-data.qcow2,size=,device=disk,bus=virtio,format=qcow2
\
--disk path=<PATH_TO_DEPLOY_DIR>/vmConfig/cidata.iso,device=cdrom \
--osinfo debian12 \
--network bridge= <Control_Plane_VLAN_ID>,model=virtio \
--network bridge=<Northbound_VLAN_ID>,model=virtio \
--network bridge=<Eastbound_VLAN_ID>,model=virtio \
--boot loader=/usr/share/edk2/ovmf/OVMF_CODE.fd,loader.readonly=yes,
loader_secure=no,nvram.template=/usr/share/edk2/ovmf/OVMF_VARS.fd,hd,uefi \
--serial pty \
--console pty,target_type=serial \
--noautoconsole

```

For detailed parameter descriptions, see the parameter table [Table 4: Parameters required for KVM deployment, on page 43](#).

SSH access may take a few minutes to become available.

---

The KVM virtual machine is created. The VM has its specified CPU, memory, and disk resources allocated. The *cidata.iso* is attached for initial configuration.

**Table 4: Parameters required for KVM deployment**

| Parameter               | Description                                                      |
|-------------------------|------------------------------------------------------------------|
| <HOST_NAME>             | The virtual machine name.                                        |
| <CPUs>                  | The number of VM CPUs.                                           |
| <MEMORY>                | The amount of VM memory.                                         |
| <PATH_TO_DEPLOY_DIR>    | The deployment directory.                                        |
| <QCOW2_FILE_NAME>       | The VM-specific disk install file (must be unique per VM).       |
| <SIZE>                  | The size of the VM disk in gigabytes (GB).                       |
| <Control_Plane_VLAN_ID> | Control plane network for communication between cluster nodes.   |
| <Northbound_VLAN_ID>    | Network used for VIP access (RESTCONF/UI), differs across nodes. |
| <Eastbound_VLAN_ID>     | Network for supercluster communication, differs across nodes.    |

### Example command to install KVM

This example describes the command and its parameters to install KVM.

```

virt-install
--name conc-sa-kvm-1
--VARUS 12
--memory 65536
--disk path=/root/CONC/VMs/kvm-sa-45/CONC-4.1-746-25.4.1-701.qcow2, format=qcow2
--disk
path=/root/CONC/VMs/kvm-sa-45/data.qcow2,size=200device=disk.bus=virtio.format=acow2--disk
path=/root/CONC/VMs/kvm-sa-45/cidata.iso.device=cdrom
--asinto debian12
--network bridge=virbr-control,model=virtio
--network bridge=brø, model=virtio
--network bridge=virbr-east110, model=yirtio
--boot
loader=/usr/share/edk2/ovmf/QMFI.fd.loader.readonly=yes..loader_secure=no.nvram.template=/usr/share/edk2/ovmf/QMFI_VARS.fd.hd.uefi
--serial pty
--console pty.target_type=serial
--autostart \
--noautoconsole

```

**What to do next**

[Configure BGP on the VM for supercluster routing](#)

## Configure Border Gateway Protocol (BGP) on the virtual machine for supercluster routing

Connect to the VM using SSH and configure BGP to enable supercluster routing. This configuration ensures that the supercluster can properly exchange routing information and maintain network connectivity across different regions.

The task involves configuring BGP on nodes within two distinct regions Region 1 and Region 2 to facilitate inter-region routing for a supercluster environment.

**Before you begin**

- [Create a new KVM virtual machine.](#)
- Public or private key pairs have been generated and associated with the VM for secure access.

Follow these steps to configure BGP on newly created VM.

**Procedure**

**Step 1** Connecting to the VM using the `ssh -i <private-key_file> nxf@<hco_management_ip>` command. Use the private key associated with the public key used earlier during customizing public key options to login to the VM.

**Example:**

```
ssh -i pemfile nxf@10.0.1.12 "cat /etc/netplan/50-cloud-init.yaml"
```

**Step 2** Follow these steps to initialize the super-cluster on Region 1 and Region 2 nodes:

a) Initialize BGP on each node using this command:

```
sedo ha bgp init <region1_node_name> <region1_northbound_ip> <BGP_AS_I>
```

- b) Add BGP router to both nodes using this command:

```
sedo ha bgp init <region1_node_name> <region1_northbound_ip> <BGP_AS_1>
```

---

Secure SSH access to the Virtual Machines is established. BGP is initialized and BGP routers are added on the Region 1 and Region 2 nodes.

#### What to do next

[Join the supercluster node](#)

## Join the supercluster node

Join multiple nodes across different regions into a supercluster and configure BGP on these nodes to enable efficient inter-region routing and network connectivity.

You will run join commands on Region 1, Region 2, and Region 3 nodes in sequence.

#### Before you begin

Verify that BGP on the VM for supercluster routing is configured. For details, see [Configure BGP on the VM for supercluster routing](#).

Follow these steps to join multiple nodes across different regions into a supercluster.

### Procedure

---

- Step 1** Retrieve and record the CLUSTER\_ID on each node.

#### Example:

```
sudo sedo supercluster status
```

The output of this command provide the unique CLUSTER\_ID for each node, which is needed for subsequent steps.

- Step 2** On the Region 1 node, generate a **sudo** command to run on the Region 2 node for joining the supercluster.

#### Example:

```
sudo sedo supercluster wait-for -b region1_node_eastboundIP:10443 region2_node_CLUSTER_ID
```

This command prepares the join instruction for Region 2 from Region 1.

- Step 3** On the Region 2 node, execute the command generated in the previous step.

This action initiates the joining process for Region 2 to the supercluster.

- Step 4** On the Region 1 node, generate a **sudo** command to run on the Region 3 node for joining the supercluster.

#### Example:

```
sudo sedo supercluster wait-for -b region1_node_eastboundIP:10443 region3_node_CLUSTER_ID
```

This command prepares the join instruction for Region 3 from Region 1.

- Step 5** On the Region 3 node, execute the command generated in the previous step.

This action initiates the joining process for Region 3 to the supercluster.

**Step 6** On the Region 2 node, generate a **sudo** command to run on the Region 3 node for joining the supercluster.

**Example:**

```
sudo sedo supercluster wait-for -b region2_node_eastboundIP:10443 region3_node_CLUSTER_ID
```

This command prepares the join instruction for Region 3 from Region 2.

**Step 7** On the Region 3 node, execute the command generated in the previous step.

This action initiates the joining process for Region 3 to the supercluster.

**Step 8** Run the **sudo sedo supercluster status** on each node to view the supercluster peers and confirm successful joining.

**Example:**

```
sudo sedo supercluster status
```

The output displays the connected peers within the supercluster.

**Step 9** Run the **sedo supercluster connectivity** command to verify the supercluster connectivity.

This command verifies that all nodes in the supercluster can communicate correctly.

---

Nodes in Region 2 and Region 3 join the supercluster initiated from Region 1 and Region 2 nodes.

**What to do next**

[Activate supercluster for multi-region network](#)

## Activate the supercluster for a multi-region network

Configure and activate a supercluster environment across multiple regions to enable efficient inter-region routing and network connectivity.

Start the supercluster on the Region 1 node, verify its operational status, update security settings by changing the default admin password, and configure user access for effective management.

**Before you begin**

Verify that multiple nodes from different regions successfully join to form a supercluster. For details, see [Join the supercluster node](#).

Follow these steps to configure and activate supercluster for multi-region network.

**Procedure**

---

**Step 1** Run the **sedo supercluster start** to start the supercluster.

This may take a few minutes to complete.

**Step 2** Run the **sudo sedo supercluster status** verify the supercluster status once the connectivity check succeeds.

The status indicates that the supercluster has successfully started.

- Step 3** Run the `sedo ha bgp show` command to display the current BGP configuration.
- Step 4** Run the `sedo security user set` command to change the default password and access string of the admin user.
- Example:**
- ```
sedo security user set --access role/admin --password admin
```
- You will be prompted to provide a new, secure password for the admin user.
- Step 5** Add local users.
- For more details about adding local users, see [Add local users to Cisco Optical Network Controller](#).
- Step 6** Access the Cisco Optical Network Controller application via a web browser.

---

Cisco Optical Network Controller is installed using KVM.

Use a web browser to access `https://<virtual ip>:8443/` to access the Cisco Optical Network Controller Web UI.

