



# Cisco Optical Site Manager Topology

This chapter describes the different Cisco Optical Site Manager views. In this chapter, you will also learn to add new racks.

- [Topology, on page 1](#)
- [Create a rack, on page 1](#)
- [Open the card view, on page 2](#)
- [Identify a passive device associated with a USB, on page 2](#)
- [View voltage, temperature and current details, on page 3](#)
- [View power monitoring parameters, on page 4](#)

## Topology

The **Topology** page provides a visual and tabular representation that allows users to manage optical site configurations effectively. The page offers two distinct views for managing site configurations:

- Rack View
- Table View

### Rack View

Provides a graphical representation of a rack, including nodes and cards. Users can hover over a device or node to display its name in a tooltip, aiding in quick identification.

### Table View

Displays a detailed list of chassis with information such as node UIDs, rack numbers, chassis types, and descriptions. This view also allows users to add new racks, simplifying updates and management.

## Create a rack

A rack serves as a container for other devices that are managed by Cisco Optical Site Manager. Use this task to add a rack to Cisco Optical Site Manager.

**Before you begin**

- [Log into Cisco Optical Site Manager](#)

**Procedure**

- 
- Step 1** Click **Topology** in the left panel.  
The COSM Topology page appears.
- Step 2** Click **Add Rack**.  
The Add rack dialog box appears.
- Step 3** Enter a rack ID in the **Rack ID** field.  
You can enter any value from 1 through 32767.
- Step 4** Click **Apply**.  
The rack is added to the rack and table views.
- 

## Open the card view

Follow these steps to open the card in a card view.

**Before you begin**

- [Log into Cisco Optical Site Manager](#)

**Procedure**

- 
- Step 1** Click **Topology** in the left panel.  
The rack and **Topology** view appear.
- Step 2** To open the card view, perform any of these steps:
- Right-click the outer edge of the chassis or line card from the rack view and select **Open**.
  - Double-click the line card in the rack view.
- The card view appears.
- 

## Identify a passive device associated with a USB

Identify a specific passive device associated with a USB port using the LED blink function.

Follow these steps to identify a passive device associated with a USB:

#### Before you begin

- [Log into Cisco Optical Site Manager](#)

#### Procedure

- Step 1** Click **Topology** in the left panel.
- Step 2** Click the rack name in the rack view.
- Step 3** Click the **Provisioning** tab.
- Step 4** Click **Passives** to expand the section.
- The table displays a list of passive devices.
- Step 5** Select the check box corresponding to a device and click **Edit**.  
After selecting a device, the **USB Port** field becomes editable.
- Step 6** Select the USB port from the drop-down list.
- Step 7** Click **Apply**.
- Step 8** Perform one of these steps:

To	Click
start blinking the LED of the passive device	<b>LED Blink</b>
know the LED status of the associated device	<b>LED Status</b>
stop the LED blinking	<b>LED Blink</b>

## View voltage, temperature and current details

Table 1: Feature History

Feature Name	Release Information	Description
<b>Environmental Monitoring in the Maintenance Tab</b>	Cisco IOS XR release 25.1.1	The <b>Maintenance</b> tab now features an <b>Environmental Monitoring</b> section, providing real-time voltage, current, and temperature data for line cards and chassis. This addition simplifies device monitoring and management.

View the voltage, temperature, and current information of a device using the Cisco Optical Site Manager.

Cisco Optical Site Manager facilitates the monitoring of device voltage, temperature, and current to ensure stable operation, prevent overheating, and maintain safe and efficient device performance.

Follow these steps to view the voltage, temperature, and current information:

### Before you begin

[Log into Cisco Optical Site Manager](#)

### Procedure

- 
- Step 1** Click **Topology** in the left panel.
- Step 2** Click the rack name from the rack view.
- Step 3** To open the chassis or line card view, perform any of these steps:
- Right-click the outer edge of the chassis or line card from the Rack view and select **Open** to open the chassis view.
  - Double-click the chassis or line card to open the chassis or line card view.
- Step 4** Click the **Maintenance** tab.
- Step 5** Click the **Environmental Monitoring** section to expand it.
- Step 6** From the **Type** drop-down list, select any of these options to view the related information:
- Voltage
  - Temperature
  - Current
  - Fan (Only available for Chassis)
- 

## View power monitoring parameters

You can view different power metrics of a chassis, such as total power consumption and maximum power, using Cisco Optical Site Manager.

Follow these steps to view the power monitoring parameters of a chassis:

### Before you begin

[Log into Cisco Optical Site Manager](#)

### Procedure

- 
- Step 1** Click **Topology** in the left panel.
- The **Topology** page appears.

- Step 2** Click the rack name from the rack view.
- Step 3** To open the chassis view, perform any of these steps:
- Right-click the outer edge of the chassis from the rack view and select **Open**.
  - Double-click the chassis.
- Step 4** Click the **Maintenance** tab.
- Step 5** Click the **Power Monitoring** section to expand it.  
The chassis total power consumption and maximum power display.
-

