



# Configure Controllers

---

This chapter describes how to configure OTS and OTS OCH controllers.

- [Controllers, on page 1](#)
- [Configure OTS Controller, on page 1](#)
- [Display Parameters of OTS Controllers, on page 4](#)
- [Span Loss Calculation, on page 6](#)
- [Display Span Loss Calculation, on page 7](#)
- [Dual IP Address, on page 7](#)
- [Configure OTS OCH Controller, on page 8](#)
- [Display Parameters of OTS OCH Controllers, on page 9](#)
- [LLDP over OSC, on page 12](#)

## Controllers

Controllers are represented in the Rack/Slot/Instance/Port format; for example, 0/1/0/1.

Rack	0
Slot	1 to 3. Slots for pluggable optical modules.
Instance	0
Port	Depends on the specific pluggable optical module.

## Configure OTS Controller

The Optical Transport Section (OTS) controller holds all the optical parameters for the OTS optical interfaces. The optical interface has different capabilities depending on its hardware components such as photodiode, VOA, amplifier, and OCM. Hence, the parameters enabled or disabled on the OTS controller depend on the actual hardware capability on the specific optical interface. Each parameter might refer to RX or TX section. For example, if a photodiode is present, the OTS controller can read the total optical power. When the controller is created, each hardware capability is enabled or disabled.

You can configure parameters such as low power threshold, VOA attenuation setpoint, amplifier gain range, amplifier tilt, and amplifier gain set point for the OTS controller. The description on OTS interfaces cannot

be added as they are on the optical amplifier module. To configure the OTS controller, use the following commands.

```
configure
controller controller-type Rack/Slot/Instance/Port
rx enable
rx-low-threshold value
tx enable
tx-low-threshold value
rx-voa-attenuation value
tx-voa-attenuation value
ampli-control-mode {automatic | manual}
ampli-gain-range {normal | extended}
ampli-gain value
ampli-tilt value
ampli-channel-power value
channel-power-max-delta value
osri {on | off}
safety-control-mode {auto | disabled}
commit
end
```

### Example

The following is a sample in which the amplifier gain range is set to extended and amplifier gain set point is set to 29.0 dB.

```
configure
controller ots 0/3/0/0
ampli-gain-range extended
ampli-gain 290
commit
end
```

The following is a sample in which the safety control mode of the pre-amplifier is set to auto.

```
configure
controller ots 0/3/0/0
safety-control-mode auto
commit
end
```

The following is a sample in which the safety control mode of the booster amplifier is set to disabled.

```
configure
controller ots 0/3/0/1
```

```
safety-control-mode disabled
commit
end
```

## OTS Controller Configuration Parameters

*Table 1: OTS Controller Configuration Parameters*

Parameter	Description	Hardware Capability	Range	Default	Notes
rx-low-threshold (0.1 dBm)	Low receive power threshold	Photodiode	-400 to +300	-40.0	
tx-low-threshold (0.1 dBm)	Low transmit power threshold	Photodiode	-400 to +300	-20.0	
rx-voa-attenuation (0.1 dBm)	RX VOA attenuation set point	VOA	0 to 200	0.0	
tx-voa-attenuation (0.1 dBm)	TX VOA attenuation set point	VOA	0 to 200	0.0	
ampli-control-mode	Amplifier control mode	Amplifier	automatic and manual	automatic	The Automatic value is compatible only when the grid is specified through the hw-module configuration.
ampli-gain-range	Amplifier gain range	Amplifier	normal and extended	normal	The amplifier gain range is configurable only when the controller is in shutdown state.
ampli-gain (0.1 dBm)	Amplifier gain set point	Amplifier	0 to 500	0.0	The actual range of amplifier gain set point depends on amplifier gain range.
ampli-tilt (0.1 dBm)	Amplifier tilt	Amplifier	-50 to +50	0.0	
channel-power-max-delta (0.1 dBm)	Maximum difference among all measured channel powers	Amplifier	0 to 200	3.0	

## Display Parameters of OTS Controllers

Parameter	Description	Hardware Capability	Range	Default	Notes
ampli-channel-power (0.1 dBm)	Amplifier per channel power set point	Amplifier	-400 to +300	0.0	
osri	Optical safety remote interlock	Amplifier	on and off	off	When osri is on, the laser is off and vice versa.
safety-control-mode	Safety control mode	Amplifier	auto and disabled	auto	If the safety control mode is disabled, the amplifier optical power is less than 20dB for safety.

# Display Parameters of OTS Controllers

Use this procedure to display the parameters of OTS controllers.

**show controllers controller-type Rack/Slot/Instance/Port [summary]**

- The **show controllers** command displays all the configuration parameters, PM thresholds and alarms when keywords are not provided.
- The **show controllers** command displays the rx/tx power value and minimal information to understand port status when **summary** keyword is provided.
- A \* wild card can be used to display all the controllers associated with a slot. For example, **show controllers ots 0/1/0/\* summary**

### Example

```
RP/0/RP0/CPU0:ios#show controllers ots 0/3/0/1
```

```
Wed Aug 23 09:08:27.962 UTC
```

```
Controller State: Up
```

```
Transport Admin State: In Service
```

```
Port Type: Line
```

```
Laser State: Off
```

```
Optics Status::
```

```
Alarm Status:
```

```
-----
```

```
Detected Alarms:
```

```
RX-LOC
```

```

Alarm Statistics:
-----
LOW-RX-PWR = 0
LOW-TX-PWR = 0
RX-LOS-P = 0
RX-LOC = 1
AMPLI-GAIN-DEG-LOW = 0
AMPLI-GAIN-DEG-HIGH = 0
AUTO-LASER-SHUT = 0
AUTO-POW-RED = 89
AUTO-AMPLI-CTRL-DISABLED = 0
AUTO-AMPLI-CFG-MISMATCH = 0
SWITCH-TO-PROTECT = 0
AUTO-AMPLI-CTRL-RUNNING = 0

Parameter Statistics:
-----
TX Power = -40.00 dBm
RX Power = -40.00 dBm
Ampli Gain = -1.00 dB
Ampli Tilt = 0.00
Total TX Power = -40.00 dBm
Total RX Power = -40.00 dBm

Configured Parameters:
-----
Rx Low Threshold = -25.0 dBm
Tx Low Threshold = -20.0 dBm
Ampli Gain = 1.00 dB
Ampli Tilt = 0.00
Ampli Channel power = 0.00 dBm
Channel Power Max Delta = 3.00 dBm
Ampli Control mode = Manual
Ampli Gain Range = Normal
Ampli Safety Control mode = auto
Osri = OFF

```

### Example

RP/0/RP0/CPU0:ios#show controllers ots 0/1/0/1

```

Controller State: Down
Transport Admin State: In Service
Port Type: Line
Laser State: Apr
Optics Status::
```

```

Alarm Status:
-----
Detected Alarms:
    AUTO-POW-RED

Alarm Statistics:
-----
LOW-RX-PWR = 0
LOW-TX-PWR = 0
RX-LOS-P = 0

```

**Span Loss Calculation**

```

RX-LOC = 1
AMPLI-GAIN-DEG-LOW = 0
AMPLI-GAIN-DEG-HIGH = 0
AUTO-LASER-SHUT = 0
AUTO-POW-RED = 1
AUTO-AMPLI-CTRL-DISABLED = 0
AUTO-AMPLI-CFG-MISMATCH = 0
SWITCH-TO-PROTECT = 0
AUTO-AMPLI-CTRL-RUNNING = 0

Parameter Statistics:
-----
TX Power = -40.00 dBm
RX Power = -11.90 dBm
Ampli Gain = -1.00 dB
Ampli Tilt = -90.00
Total TX Power = 7.99 dBm
Total RX Power = -11.90 dBm
Ampli Gain Range = Normal
Ampli Safety Control mode = disabled
Osri = OFF
TX Enable = Enabled
RX Enable = Enabled
RX Span Loss = N/A
TX Span Loss = N/A
Rx Low Threshold Current = -25.0 dBm
Back Reflection = -6.40 dBm

Configured Parameters:
-----
Rx Low Threshold = -25.0 dBm
Tx Low Threshold = -20.0 dBm
Ampli Gain = 12.00 dB
Ampli Tilt = 0.00
Ampli Channel power = 0.00 dBm
Channel Power Max Delta = 3.00 dBm
Ampli Channel Psd = 31.250 nW/MHz
Rx Low Threshold Psd = 0.099 nW/MHz
Ampli Control mode = Manual
Ampli Safety Control mode = disabled
Osri = OFF
TX Enable = Enabled
RX Enable = Enabled

```

The **Back Reflection** parameter in 0.1 dBm is raised only on port 1. This parameter is raised on the line TX port of the booster amplifier.

## Span Loss Calculation

The Span Loss Calculation is an automatic calculation of span losses between NCS 1001 systems. This feature applies to each topology such as protected or non-protected, linear with or without ILA nodes in the middle.

The Span Loss Calculation is a software functionality available for OTS controller and it can be statically enabled or disabled through `hw-module` configuration. Span Loss calculation is made using the TX and RX total power on EDFA ports.

For this feature 2 new parameters are managed in the show controller ots command for EDFA cards:

- RX Span Loss
- TX Span Loss

The Span Loss Calculation runs automatically every 5 minutes and when there is a configuration change. In the order of priority, the possible configurations are:

- Remote node.
- OSC through OSPF.

#### Limitation

- Span Loss calculation is done by considering the total power of the transmission end and receiver end on the EDFA ports. If the PSM card is connected to the span (for example, in case of Path Protection Topology), the span boundaries are assumed to be the closer EDFA ports.

## Display Span Loss Calculation

Once the feature is enabled and after the first span loss calculation, the loss calculated (for both IPv4 and IPv6) can be retrieved using the `show controller ots` command. In the output RX Span Loss and TX Span Loss are added. RX Span Loss and TX Span Loss are obtained as a result of difference between **TX Total Power** and **RX Total Power** read on the edge of the span.

In case of a TERM node, the command is applied to LINE port. For example, in case of EDFA in slot 1, the span loss calculated are shown in the output of the following command:

```
#show controllers ots 0/1/0/1
...
...
RX Span Loss = 15.20 dB
TX Span Loss = 14.80 dB
...
...
```

In case of an ILA node, the command is applied to LINE port (`controller ots 0/slot/0/1`) to obtain RX Span Loss of related span, and to COM port (`controllers ots 0/slot/0/0`) to obtain TX Span Loss of related span.

For example, in case of an EDFA of ILA site equipped in slot 3:

```
show controllers ots 0/3/0/1
...
RX Span Loss = 12.40 dB
show controllers ots 0/3/0/0
...
TX Span Loss = 11.90 dB
```

## Dual IP Address

Dual independent XR interfaces allows you to connect the two ethernet interfaces to two different switches of different subnet and also of the same subnet. From release 6.5.1, there are different ports from the ethernet switch MGMT RJ45, and Optical SFP MGMT to the CPU.

The two different Management Ethernet interfaces in to XR are:

- MgmtEth 0/RP0/CPU0/0 (already existing) representing the RJ45 port.
- MgmtEth 0/RP0/CPU0/1 (new one) representing the SFP port.

iPXE is not supported at power-on over the new optical interface.

Upgrades from previous releases using only SFP loses MGMT connectivity. In this case, you must configure through Console port.

Before using the two different interfaces, you must upgrade the BIOS and reload the 0/RP0 location.

The following example shows the output of the *show running-config* command:

### Example

```
RP/0/RP0/CPU0:MYST-144#show running-config
...
  interface MgmtEth0/RP0/CPU0/0
    ipv4 address xxx.xxx.xxx.xxx yyyy.yyy.yyy.yyy
  !
  interface MgmtEth0/RP0/CPU0/1
    ipv6 address xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:yy
    ipv6 enable
  !
  interface MgmtEth0/RP0/OSC1/0
    shutdown
  !
  interface MgmtEth0/RP0/OSC2/0
    shutdown
  !
  interface MgmtEth0/RP0/OSC3/0
    shutdown
!
```

## Configure OTS OCH Controller

The Optical Transport Section OCH (OTS OCH) controller represents the OCM device available on the OTS optical interface. This controller is created to have channel granularity over the OTS interface. The OTS OCH controller contains the wavelength information. The controller number starts from 1 and matches with the ITU channel identifier.

Several OTS OCH controllers are created for each OTS Controller depending on the grid configuration (ITU 100GHz or 50GHz Grid). 48 OTS OCH controllers are created for a 100GHz grid and 96 OTS OCH controllers are created for a 50GHz grid.

You can configure the parameters such as RX low power threshold and TX low power threshold for the OTS OCH controller. To configure the OTS OCH controller, use the following commands.

**configure**

**controller controller-type Rack/Slot/Instance/Port**

**rx-low-threshold value**

**tx-low-threshold value**

**commit**

**end**

### Example

```
configure
  controller ots-och 0/1/0/0
```

```

rx-low-threshold -30
tx-low-threshold -35
commit
end

```

### OTS OCH Controller Configuration Parameters

*Table 2: OTS OCH Controller Configuration Parameters*

Parameter	Description	Hardware Capability	Range	Default
rx-low-threshold (0.1 dBm)	Low receive power threshold	OCM	-500 to +300	-25.0
tx-low-threshold (0.1 dBm)	Low transmit power threshold	OCM	-500 to +300	-25.0

## Display Parameters of OTS OCH Controllers

Use this procedure to display the parameters of OTS OCH controllers.

**show controllers controller-type Rack/Slot/Instance/Port/Channel-number [summary]**

- The **show controllers** command displays all the configuration parameters, PM thresholds and alarms when keywords are not provided.
- The **show controllers** command displays the rx/tx power value and wavelength when **summary** keyword is provided.
- A \* wild card can be used to display all the OTS OCH controllers associated with a OTS controller. For example, **show controllers ots-och 0/1/0/\* summary**

### Example

RP/0/RP0/CPU0:ios#**show controllers ots-och 0/3/0/1/1**

Fri Feb 24 13:20:18.456 CET

Controller State: Up

Transport Admin State: Maintenance

Port Type: Line

Laser State: On

Optics Status::

Alarm Status:  
-----  
Detected Alarms:  
LOW-RX-PWR

Alarm Statistics:  
-----

## Display Parameters of OTS OCH Controllers

```

LOW-RX-PWR = 219
LOW-TX-PWR = 5
RX-LOS-P = 0
RX-LOC = 0
AMPLI-GAIN-DEG-LOW = 0
AMPLI-GAIN-DEG-HIGH = 0
AUTO-LASER-SHUT = 0
AUTO-POW-RED = 0
AUTO-AMPLI-CTRL-DISABLED = 0
AUTO-AMPLI-CFG-MISMATCH = 0
SWITCH-TO-PROTECT = 0

```

## Parameter Statistics:

```

-----
TX Power = 4.10 dBm
RX Power = -30.70 dBm

```

## Configured Parameters:

```

-----
Rx Low Threshold = -25.0 dBm
Tx Low Threshold = -25.0 dBm

```

**RP/0/RP0/CPU0:ios#show controllers ots-och 0/2/0/\* summary**

Fri Oct 9 10:37:50.109 CEST

Port Central Frequency	Type	Status	TX Power (dBm)	RX Power (dBm)	TX psd (nW/MHz)	RX psd (nW/MHz)
(GHz)	(GHz)	Channel Width				
Ots-Och0_2_0_0_1 196100.0	Com	N/A	-18.30	-19.30	0.392	0.333
		75.0				
Ots-Och0_2_0_0_2 196025.0	Com	N/A	-19.10	-19.80	0.094	0.068
		75.0				
Ots-Och0_2_0_0_3 195950.0	Com	N/A	-18.00	-18.90	0.450	0.392
		75.0				
Ots-Och0_2_0_0_4 195875.0	Com	N/A	-16.90	-17.60	0.318	0.290
		75.0				
Ots-Och0_2_0_0_5 195800.0	Com	N/A	-18.10	-19.20	0.326	0.290
		75.0				
Ots-Och0_2_0_0_6 195725.0	Com	N/A	-19.50	-19.90	0.059	0.041
		75.0				
Ots-Och0_2_0_0_7 195650.0	Com	N/A	-18.60	-19.00	0.471	0.450
		75.0				
Ots-Och0_2_0_0_8 195575.0	Com	N/A	-17.00	-17.60	0.304	0.318
		75.0				
Ots-Och0_2_0_0_9 195500.0	Com	N/A	-18.50	-19.20	0.318	0.297
		75.0				
Ots-Och0_2_0_0_10 195425.0	Com	N/A	-17.60	-18.00	0.318	0.297
		75.0				
Ots-Och0_2_0_0_11 195350.0	Com	N/A	-18.50	-19.00	0.401	0.374
		75.0				
Ots-Och0_2_0_0_12 195275.0	Com	N/A	-17.70	-18.00	0.188	0.253
		75.0				
Ots-Och0_2_0_0_13 195200.0	Com	N/A	-18.90	-19.70	0.304	0.271
		75.0				
Ots-Och0_2_0_0_14 195125.0	Com	N/A	-20.50	-20.90	0.242	0.236
		75.0				
Ots-Och0_2_0_0_15 195050.0	Com	N/A	-24.00	-27.40	0.031	0.011
		75.0				
Ots-Och0_2_0_0_16	Com	N/A	-17.80	-18.40	0.215	0.242

194975.0	75.0						
Ots-Och0_2_0_0_17	Com	N/A	-18.50	-19.10	0.318	0.290	
194900.0	75.0						
Ots-Och0_2_0_0_18	Com	N/A	-16.90	-17.30	0.333	0.297	
194825.0	75.0						
Ots-Och0_2_0_0_19	Com	N/A	-18.10	-18.90	0.410	0.366	
194750.0	75.0						
Ots-Och0_2_0_0_20	Com	N/A	-17.00	-17.50	0.357	0.366	
194675.0	75.0						
Ots-Och0_2_0_0_21	Com	N/A	-18.50	-19.30	0.326	0.290	
194600.0	75.0						
Ots-Och0_2_0_0_22	Com	N/A	-17.20	-17.70	0.259	0.265	
194525.0	75.0						
Ots-Och0_2_0_0_23	Com	N/A	-18.40	-19.10	0.410	0.392	
194450.0	75.0						
Ots-Och0_2_0_0_24	Com	N/A	-16.50	-16.90	0.450	0.430	
194375.0	75.0						
Ots-Och0_2_0_0_25	Com	N/A	-24.30	-28.90	0.040	0.000	
194300.0	75.0						
Ots-Och0_2_0_0_26	Com	N/A	-16.60	-16.90	0.326	0.297	
194225.0	75.0						
Ots-Och0_2_0_0_27	Com	N/A	-18.10	-18.70	0.420	0.410	
194150.0	75.0						
Ots-Och0_2_0_0_28	Com	N/A	-16.80	-16.90	0.383	0.392	
194075.0	75.0						
Ots-Och0_2_0_0_29	Com	N/A	-19.10	-19.80	0.333	0.311	
194000.0	75.0						
Ots-Och0_2_0_0_30	Com	N/A	-16.90	-17.10	0.284	0.311	
193925.0	75.0						
Ots-Och0_2_0_0_31	Com	N/A	-18.70	-19.20	0.374	0.383	
193850.0	75.0						
Ots-Och0_2_0_0_32	Com	N/A	-17.20	-17.40	0.374	0.392	
193775.0	75.0						
Ots-Och0_2_0_0_33	Com	N/A	-18.60	-19.10	0.410	0.410	
193700.0	75.0						
Ots-Och0_2_0_0_34	Com	N/A	-17.30	-17.60	0.311	0.311	
193625.0	75.0						
Ots-Och0_2_0_0_35	Com	N/A	-18.90	-19.10	0.392	0.401	
193550.0	75.0						
Ots-Och0_2_0_0_36	Com	N/A	-18.00	-18.20	0.265	0.265	
193475.0	75.0						
Ots-Och0_2_0_0_37	Com	N/A	-19.50	-20.00	0.304	0.318	
193400.0	75.0						
Ots-Och0_2_0_0_38	Com	N/A	-17.80	-17.90	0.265	0.311	
193325.0	75.0						
Ots-Och0_2_0_0_39	Com	N/A	-18.60	-19.00	0.383	0.392	
193250.0	75.0						
Ots-Och0_2_0_0_40	Com	N/A	-16.80	-17.00	0.383	0.392	
193175.0	75.0						
Ots-Och0_2_0_0_41	Com	N/A	-18.70	-19.10	0.440	0.450	
193100.0	75.0						
Ots-Och0_2_0_0_42	Com	N/A	-16.80	-17.10	0.374	0.349	
193025.0	75.0						
Ots-Och0_2_0_0_43	Com	N/A	-18.90	-19.40	0.401	0.420	
192950.0	75.0						
Ots-Och0_2_0_0_44	Com	N/A	-17.00	-17.40	0.450	0.440	
192875.0	75.0						
Ots-Och0_2_0_0_45	Com	N/A	-18.50	-18.80	0.392	0.392	
192800.0	75.0						
Ots-Och0_2_0_0_46	Com	N/A	-17.40	-17.60	0.284	0.271	
192725.0	75.0						
Ots-Och0_2_0_0_47	Com	N/A	-24.40	-31.50	0.064	0.000	
192650.0	75.0						
Ots-Och0_2_0_0_48	Com	N/A	-19.20	-19.60	0.410	0.430	

192575.0	75.0							
Ots-Ocho_2_0_0_49	Com	N/A	-18.70	-19.40	0.392	0.383		
192500.0	75.0							
Ots-Ocho_2_0_0_50	Com	N/A	-17.10	-17.60	0.374	0.326		
192425.0	75.0							
Ots-Ocho_2_0_0_51	Com	N/A	-19.10	-19.50	0.401	0.401		
192350.0	75.0							
Ots-Ocho_2_0_0_52	Com	N/A	-20.40	-20.50	0.357	0.311		
192275.0	75.0							
Ots-Ocho_2_0_0_53	Com	N/A	-24.70	-34.20	0.042	0.000		
192200.0	75.0							
Ots-Ocho_2_0_0_54	Com	N/A	-17.60	-18.10	0.201	0.236		
192125.0	75.0							
Ots-Ocho_2_0_0_55	Com	N/A	-18.50	-19.10	0.401	0.392		
192050.0	75.0							
Ots-Ocho_2_0_0_56	Com	N/A	-17.20	-17.80	0.341	0.284		
191975.0	75.0							
Ots-Ocho_2_0_0_57	Com	N/A	-25.60	-30.40	0.050	0.000		
191900.0	75.0							
Ots-Ocho_2_0_0_58	Com	N/A	-17.40	-17.90	0.220	0.188		
191825.0	75.0							
Ots-Ocho_2_0_0_59	Com	N/A	-19.40	-20.40	0.333	0.290		
191750.0	75.0							
Ots-Ocho_2_0_0_60	Com	N/A	-27.10	-38.90	0.023	0.000		
191675.0	75.0							
Ots-Ocho_2_0_0_61	Com	N/A	-26.00	-38.90	0.031	0.000		
191600.0	75.0							
Ots-Ocho_2_0_0_62	Com	N/A	-19.50	-20.10	0.133	0.045		
191525.0	75.0							
Ots-Ocho_2_0_0_63	Com	N/A	-19.20	-19.90	0.401	0.392		
191450.0	75.0							
Ots-Ocho_2_0_0_64	Com	N/A	-17.30	-17.60	0.333	0.333		
191375.0	75.0							

From R7.3.1, a decimal place is introduced for Central Frequency and Channel Width columns.

## LLDP over OSC

**Table 3: Feature History**

Feature Name	Release	Description
LLDP over OSC	Cisco IOS XR Release 7.3.1	LLDP is supported on the OSC management interface for point-to-point local link discovery through OSC channel. This helps you to gather information about the neighboring devices in the network.

The output of **show lldp neighbors** command, when you enable LLDP on a OSC interface is as follows:

```
RP/0/RP0/CPU0:MY5-130#show lldp neighbors
Mon Feb 22 08:29:20.189 UTC
Capability codes:
(R) Router, (B) Bridge, (T) Telephone, (C) DOCSIS Cable Device
(W) WLAN Access Point, (P) Repeater, (S) Station, (O) Other

Device ID Local Intf Hold-time Capability Port ID
```

MY5-131 MgmtEth0/RP0/OSC3/1 120 R MgmtEth0/RP0/OSC1/0

