



Configuring the Card Mode

This chapter lists the supported configurations and the procedures to configure the card mode on the line cards.

- [1.2T and 1.2TL Line Cards, on page 1](#)

1.2T and 1.2TL Line Cards

The following section describes the supported configurations and procedures to configure the card modes on the line cards.

Card Modes

The line cards support module and slice configurations.

The line cards have two trunk ports (0 and 1) and 12 client ports (2 through 13) each. You can configure the line card in two modes:

- Muxponder—In this mode, both trunk ports are configured with the same trunk rate. The client-to-trunk mapping is in a sequence.
- Muxponder slice—In this mode, each trunk port is configured independent of the other with different trunk rates. The client-to-trunk mapping is fixed. For Trunk 0, the client ports are 2 through 7. For Trunk 1, the client ports are 8 through 13.

Supported Data Rates

The following data rates are supported on the line card.

. LLDP drop, L1 encryption, and AINS are not supported on the OTU4 configuration.

The following table displays the client and trunk ports that are enabled for the muxponder configuration.

Trunk Data Rate	Card Support	Client Data Rate (100GE, OTU4)	Trunk Ports	Client Ports
200	1.2T	100GE, OTU4	0, 1	2, 3, 4, 5
300	1.2T	100GE, OTU4	0, 1	2, 3, 4, 5, 6, 7

Trunk Data Rate	Card Support	Client Data Rate (100GE, OTU4)	Trunk Ports	Client Ports
400	1.2T	100GE	0, 1	2, 3, 4, 5, 6, 7, 8, 9
500	1.2T	100GE	0, 1	2, 3, 4, 5, 6, 7, 8, 9, 10, 11
600	1.2T	100GE	0, 1	2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13

The following table displays the client and trunk ports that are enabled for the muxponder slice 0 configuration.

Trunk Data Rate	Card Support	Client Data Rate	Trunk Ports	Client Ports
100	1.2T, 1.2TL		0	2
200	1.2T		0	2, 3
300	1.2T		0	2, 3, 4
400	1.2T		0	2, 3, 4, 5
500	1.2T		0	2, 3, 4, 5, 6
600	1.2T		0	2, 3, 4, 5, 6, 7

The following table displays the client and trunk ports that are enabled for the muxponder slice 1 configuration.

Trunk Data Rate	Card Support	Client Data Rate	Trunk Ports	Client Ports
100	1.2T, 1.2TL		1	8
200	1.2T		1	8, 9
300	1.2T		1	8, 9, 10
400	1.2T		1	8, 9, 10, 11
500	1.2T		1	8, 9, 10, 11, 12
600	1.2T		1	8, 9, 10, 11, 12, 13

All configurations can be accomplished by using appropriate values for client bitrate and trunk bitrate parameters of the **hw-module** command.

The following table displays the trunk parameter ranges for the 1.2T card.

Trunk Payload	FEC	Min BPS	Max BPS	Min GBd	Max GBd
200G	27%	2	4.40625	31.51	69.43
300G	27%	2.8984375	6	34.7175497	71.8681352
400G	27%	3.8671875	6	46.2900663	71.8197392

Trunk Payload	FEC	Min BPS	Max BPS	Min GBd	Max GBd
500G	27%	4.8281250	6	57.8625828	71.9068991
600G	15%	5.2578125	-	-	71.9552971

To configure the BPS, see [Configuring the BPS, on page 6](#).

Configuring the Card Mode

You can configure the line card in the module (muxponder) or slice configuration (muxponder slice).

To configure the card in the muxponder mode, use the following commands.

configure

hw-module location *location* **mxponder client-rate** {100GE | OTU4}

hw-module location *location* **mxponder trunk-rate** {100G200G | 300G | 400G | 500G | 600G }

commit

To configure the card in the muxponder slice mode, use the following commands.

configure

hw-module location *location* **mxponder-slice** *mxponder-slice-number* **client-rate** 100GE

hw-module location *location* **mxponder-slice trunk-rate** { 200G | 300G | 400G | 500G | 600G }

commit

Examples

The following is a sample in which the card is configured in the muxponder mode with a 500G trunk payload.

```
RP/0/RP0/CPU0:ios#config
Sun Feb 24 14:09:33.989 UTC
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2 mxponder client-rate OTU4
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2 mxponder trunk-rate 500G
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the card is configured in the muxponder slice 0 mode with a 500G trunk payload.

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 0 client-rate 100GE
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 0 trunk-rate 500G
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the card is configured in the muxponder slice 1 mode with a 400G trunk payload.

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 1 client-rate 100GE
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 1 trunk-rate 400G
RP/0/RP0/CPU0:ios(config)#commit
```

Verifying the Card Configuration

```
RP/0/RP0/CPU0:ios#show hw-module location 0/2 mxponder
Fri Mar 15 11:48:48.344 IST

Location:          0/2
Client Bitrate:    100GE
Trunk Bitrate:     500G
Status:            Provisioned
LLDP Drop Enabled: FALSE
Client Port
Mapper/Trunk Port  CoherentDSP0/2/0/0  CoherentDSP0/2/0/1
Traffic Split Percentage

HundredGigECtrlr0/2/0/2  ODU40/2/0/0/1          100          0
HundredGigECtrlr0/2/0/3  ODU40/2/0/0/2          100          0
HundredGigECtrlr0/2/0/4  ODU40/2/0/0/3          100          0
HundredGigECtrlr0/2/0/5  ODU40/2/0/0/4          100          0
HundredGigECtrlr0/2/0/6  ODU40/2/0/0/5          100          0
HundredGigECtrlr0/2/0/7  ODU40/2/0/1/1          0           100
HundredGigECtrlr0/2/0/8  ODU40/2/0/1/2          0           100
HundredGigECtrlr0/2/0/9  ODU40/2/0/1/3          0           100
HundredGigECtrlr0/2/0/10 ODU40/2/0/1/4          0           100
HundredGigECtrlr0/2/0/11 ODU40/2/0/1/5          0           100
```

The following is a sample output of all the muxponder slice 0 configurations.

```
RP/0/RP0/CPU0:ios#show hw-module location 0/1 mxponder-slice 0
Fri Mar 15 06:04:18.348 UTC

Location:          0/1
Slice ID:          0
Client Bitrate:    100GE
Trunk Bitrate:     500G
Status:            Provisioned
LLDP Drop Enabled: FALSE
Client Port
Mapper/Trunk Port  CoherentDSP0/1/0/0
Traffic Split Percentage

HundredGigECtrlr0/1/0/2  ODU40/1/0/0/1          100
HundredGigECtrlr0/1/0/3  ODU40/1/0/0/2          100
HundredGigECtrlr0/1/0/4  ODU40/1/0/0/3          100
HundredGigECtrlr0/1/0/5  ODU40/1/0/0/4          100
HundredGigECtrlr0/1/0/6  ODU40/1/0/0/5          100
```

The following is a sample output of all the muxponder slice 1 configurations.

```
RP/0/RP0/CPU0:ios#show hw-module location 0/1 mxponder-slice 1
Fri Mar 15 06:11:50.020 UTC

Location:          0/1
Slice ID:          1
Client Bitrate:    100GE
Trunk Bitrate:     400G
Status:            Provisioned
LLDP Drop Enabled: TRUE
Client Port
Mapper/Trunk Port  CoherentDSP0/1/0/1
Traffic Split Percentage

HundredGigECtrlr0/1/0/8  ODU40/1/0/1/1          100
HundredGigECtrlr0/1/0/9  ODU40/1/0/1/2          100
HundredGigECtrlr0/1/0/10 ODU40/1/0/1/3          100
HundredGigECtrlr0/1/0/11 ODU40/1/0/1/4          100
```

The following is a sample output of the muxponder slice 1 configuration with client configured as OTU4.

```
RP/0/RP0/CPU0:ios#sh hw-module location 0/0 mxponder-slice 1

Wed Mar 11 13:59:11.073 UTC

Location:                0/0
Slice ID:                 1
Client Bitrate:          OTU4
Trunk Bitrate:           200G
Status:                  Provisioned
Client Port              Peer/Trunk Port          CoherentDSP0/0/0/1
                        Traffic Split Percentage
OTU40/0/0/8             ODU40/0/0/1/1          100
OTU40/0/0/9             ODU40/0/0/1/2          100
```

Use the following command to clear alarm statistics on the optics or coherent DSP controller.

clear counters controller *controllertype* R/S/I/P

The following is a sample in which the alarm statistics are cleared on the coherent DSP controller.

```
RP/0/RP0/CPU0:ios#show controller coherentDSP 0/1/0/0
Tue Jun 11 05:15:12.540 UTC

Port                : CoherentDSP 0/1/0/0
Controller State    : Up
Inherited Secondary State : Normal
Configured Secondary State : Normal
Derived State       : In Service
Loopback mode       : None
BER Thresholds      : SF = 1.0E-5  SD = 1.0E-7
Performance Monitoring : Enable

Alarm Information:
LOS = 1 LOF = 1 LOM = 0
OOE = 1 OOM = 1 AIS = 0
IAE = 0 BIAE = 0      SF_BER = 0
SD_BER = 2      BDI = 2 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms      : None

Bit Error Rate Information
PREFEC BER           : 8.8E-03
POSTFEC BER          : 0.0E+00

TTI :
  Remote hostname     : P2B8
  Remote interface    : CoherentDSP 0/1/0/0
  Remote IP addr      : 0.0.0.0

FEC mode              : Soft-Decision 15

AINS Soak             : None
AINS Timer             : 0h, 0m
AINS remaining time   : 0 seconds
RP/0/RP0/CPU0:ios#clear counters controller coherentDSP 0/1/0/0
Tue Jun 11 05:17:07.271 UTC
All counters are cleared
RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/1/0/1
Tue Jun 11 05:20:55.199 UTC

Port                : CoherentDSP 0/1/0/1
Controller State    : Up
Inherited Secondary State : Normal
Configured Secondary State : Normal
```

```

Derived State                : In Service
Loopback mode                : None
BER Thresholds               : SF = 1.0E-5  SD = 1.0E-7
Performance Monitoring      : Enable

Alarm Information:
LOS = 0 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0            SF_BER = 0
SD_BER = 0      BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms              : None

Bit Error Rate Information
PREFEC BER                   : 1.2E-02
POSTFEC BER                  : 0.0E+00

TTI :
    Remote hostname          : P2B8
    Remote interface         : CoherentDSP 0/1/0/1
    Remote IP addr           : 0.0.0.0

FEC mode                      : Soft-Decision 15

AINS Soak                    : None
AINS Timer                   : 0h, 0m
AINS remaining time          : 0 seconds

```

Configuring the BPS

You can configure the Bits per Symbol (BPS) to 3.4375 to support 300G trunk configurations on 75 GHz networks using the following commands:

configure

controller optics R/S/I/P bits-per-symbol 3.4375

commit

The following is a sample in which the BPS is configured to 3.4375.

```

RP/0/RP0/CPU0:ios#configure
Wed Mar 27 14:12:49.932 UTC
RP/0/RP0/CPU0:ios(config)#controller optics 0/3/0/0 bits-per-symbol 3.4375
RP/0/RP0/CPU0:ios(config)#commit

```

Viewing BPS and Baud Rate Ranges

To view the the BPS for a specific range use the following command:

show controller optics R/S/I/P bps-range bps-range | include data-rate | include fec-type

```

RP/0/RP0/CPU0:ios#show controllers optics 0/3/0/0 bps-range 3 3.05 | include 300G | include
SD27
Thu Mar 28 03:01:39.751 UTC
300G          SD27          3.0000000      69.4350994
300G          SD27          3.0078125      69.2547485
300G          SD27          3.0156250      69.0753320
300G          SD27          3.0234375      68.8968428
300G          SD27          3.0312500      68.7192736
300G          SD27          3.0390625      68.5426174
300G          SD27          3.0468750      68.3668671

```

To view the baud for a specific range use the following command:

show controller optics *R/S/I/P* baud-rate-range *baud-range* | include *data-rate* | include *fec-type*

```
RP/0/RP0/CPU0:ios#show controllers optics 0/3/0/0 baud-rate-range 43 43.4 | include 300G |  
include SD27
```

```
Thu Mar 28 03:12:36.521 UTC
```

300G	SD27	4.8046875	43.3545986
300G	SD27	4.8125000	43.2842178
300G	SD27	4.8203125	43.2140651
300G	SD27	4.8281250	43.1441394
300G	SD27	4.8359375	43.0744397
300G	SD27	4.8437500	43.0049648

