



List of Commands

This guide describes the commands supported in NCS 1004.

- [aaa authentication login, on page 4](#)
- [aaa authorization, on page 5](#)
- [aaa authorization \(System Admin-VM\), on page 6](#)
- [active, on page 7](#)
- [address, on page 8](#)
- [ains-soak \(OTN-XP Card\), on page 9](#)
- [automatic-in-service \(OTN-XP Card\), on page 9](#)
- [authentication, on page 10](#)
- [cipher-suite, on page 11](#)
- [controller coherentDSP, on page 12](#)
- [controller HundredGigECtrlr, on page 15](#)
- [controller FourHundredGigECtrlr, on page 17](#)
- [controller TenGigECtrlr \(OTN-XP Card\), on page 18](#)
- [controller odu2e \(OTN-XP Card\), on page 19](#)
- [controller ODU4, on page 20](#)
- [controller ODUC4, on page 21](#)
- [controller odu-group-mp, on page 23](#)
- [controller OTU \(OTN-XP Card\), on page 24](#)
- [controller optics, on page 25](#)
- [crypto ca authenticate, on page 29](#)
- [crypto ca enroll, on page 30](#)
- [crypto ca trustpoint, on page 32](#)
- [crypto key generate dsa, on page 33](#)
- [crypto key generate ecdsa, on page 34](#)
- [crypto key generate ed25519, on page 36](#)
- [crypto key generate rsa, on page 37](#)
- [crypto key import authentication rsa, on page 39](#)
- [crypto key zeroize ed25519, on page 39](#)
- [crypto key zeroize rsa, on page 40](#)
- [destination address, on page 41](#)
- [destination ipv4 unicast, on page 42](#)
- [destination transport-method, on page 42](#)

- [dh](#), on page 43
- [dwdm-carrier](#), on page 44
- [encryption](#), on page 45
- [enrollment retry count](#), on page 46
- [enrollment retry period](#), on page 47
- [enrollment terminal](#), on page 48
- [enrollment url](#), on page 48
- [fault-profile](#), on page 50
- [fault-profile apply](#), on page 51
- [gmpls optical-uni](#), on page 52
- [http client connection](#), on page 52
- [http client response](#), on page 53
- [http client ssl](#), on page 54
- [http client secure-verify-host](#), on page 54
- [http client secure-verify-peer](#), on page 55
- [http client source interface](#), on page 56
- [http client tcp-window-scale](#), on page 57
- [http client version](#), on page 57
- [http client vrf](#), on page 58
- [http-proxy](#), on page 59
- [hw-module](#), on page 59
- [hw-module \(OTN-XP Card\)](#), on page 64
- [ikev2 policy](#), on page 67
- [ikev2 profile](#), on page 68
- [ikev2 proposal](#), on page 69
- [integrity](#), on page 70
- [interface gcc0](#), on page 71
- [interface gcc2](#), on page 71
- [ipcc routed](#), on page 72
- [ipv4 access-group](#), on page 73
- [ipv6 access-group](#), on page 74
- [keyring](#), on page 75
- [lc-module \(OTN-XP Card\)](#), on page 76
- [license smart register](#), on page 78
- [license smart renew](#), on page 78
- [license smart deregister](#), on page 79
- [lifetime](#), on page 80
- [link-id ipv4 unicast](#), on page 80
- [lmp](#), on page 81
- [match address local](#), on page 82
- [match identity remote address](#), on page 83
- [neighbor interface-id unnumbered](#), on page 84
- [neighbor link-id ipv4 unicast](#), on page 84
- [neighbor](#), on page 85
- [otnsec policy](#), on page 86
- [path-option](#), on page 86

- peer, on page 87
- pki trustpoint, on page 88
- pm, on page 89
- prf, on page 94
- protecting-controller, on page 95
- protection-attributes connection-mode, on page 95
- protection-attributes protection-mode, on page 96
- protection-attributes protection-type, on page 97
- protection-attributes timers, on page 98
- protection-switching, on page 98
- query url, on page 99
- router-id ipv4 unicast, on page 100
- rsakeypair, on page 101
- sftp-password (trustpoint), on page 102
- sftp-username (trustpoint), on page 103
- show configuration commit changes, on page 103
- show controllers [odu-group-mp], on page 106
- show crypto ca certificates, on page 108
- show crypto key mypubkey ed25519, on page 110
- show crypto key mypubkey rsa, on page 111
- sak-rekey-interval, on page 112
- security-policy, on page 113
- session-id, on page 114
- show alarms, on page 115
- show controllers, on page 116
- show access-lists ipv4, on page 132
- show access-lists ipv6, on page 133
- show environment, on page 135
- show hw-module, on page 137
- show inventory, on page 140
- show lc-module (OTN-XP Card), on page 147
- show led, on page 148
- show platform, on page 149
- signalling refresh out-of-band interval, on page 151
- signalling refresh out-of-band missed, on page 151
- sks profile, on page 152
- split-client-port-mapping, on page 153
- subject-name (trustpoint), on page 154
- tunnel-id, on page 155
- tunnel-properties, on page 155
- working-controller, on page 156

aaa authentication login

aaa authentication login

To configure authentication, authorization, and accounting (AAA) authentication at login, use the **aaa authentication login** command in global configuration mode.

aaa authentication login { default | list-name } method-list

Syntax Description	<p>login Sets authentication for login.</p> <p>default Uses the listed authentication methods that follow this keyword as the default list of methods for authentication.</p> <p><i>list-name</i> Character string used to name the authentication method list.</p> <p><i>method-list</i> Method used to enable AAA system accounting. Method list types are entered in the preferred sequence. The value is one of the following options:</p> <ul style="list-style-type: none"> • group tacacs+ — Specifies a method list that uses the list of all configured TACACS+ servers for authentication. • group radius — Specifies a method list that uses the list of all configured RADIUS servers for authentication. • group named-group — Specifies a named subset of TACACS+ or RADIUS servers for authentication. • local — Specifies a local username or password database for authentication. • line — Specifies a line password or user group for authentication. 				
Command Default	No authentication is performed.				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>R7.0.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	R7.0.1	This command was introduced.
Release	Modification				
R7.0.1	This command was introduced.				

Example

The following example shows how to specify the default method list for authentication, and also enable authentication.

```
configure
aaa authentication login default group tacacs+
exit
commit
```

aaa authorization

To create a method list for authorization, use the **aaa authorization** command in global configuration mode.

```
aaa authorization {exec | nacm} { default | list-name } {none | local | group tacacs+ | group radius | group group-name }
```

Syntax Description					
exec	Configures authorization for an interactive (EXEC) session.				
nacm	Enables the NACM (NETCONF Access Control Model) functionality.				
default	Uses the listed authorization methods that follow this keyword as the default list of methods for authorization.				
<i>list-name</i>	Character string used to name the list of authorization methods.				
none	Uses no authorization. If you specify none , no subsequent authorization method is attempted.				
local	Uses local authorization. This method of authorization is not available for command authorization.				
group tacacs+	Uses the list of all configured TACACS+ servers for authorization.				
group radius	Uses the list of all configured RADIUS servers for authorization. This method of authorization is not available for command authorization.				
group group-name	Specifies a named subset of TACACS+ or RADIUS servers for authorization.				
Command Default	Authorization is disabled for all actions (equivalent to the method none keyword).				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>R7.0.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	R7.0.1	This command was introduced.
Release	Modification				
R7.0.1	This command was introduced.				

Example

The following example shows how to define the network authorization method list named *listname1*, which specifies that TACACS+ authorization is used.

```
configure
aaa authorization exec listname1 group tacacs+
exit
commit
```

aaa authorization (System Admin-VM)

To create command rules and data rules for user authorization, use the **aaa authorization** command in System Admin Config mode. To delete the command rules and data rules, use the **no** form of this command.

```
aaa authorization { cmdrules cmdrule { integer | range integer } [{ action action-type | command cmd-name | context context-name | group group-name | ops ops-type }] | commands group { none | tacacs } | datarules datarule { integer | range integer } [{ action action-type | context context-name | group group-name | keypath keypath-name | namespace namespace-string | ops ops-type }] }
```

Syntax Description	
cmdrules	Configures command rules.
cmdrule integer	Specifies the command rule number.
range integer	Specifies the range of the command rules or data rules to be configured.
action action-type	<p>Specifies whether users are permitted or not allowed to perform the operation specified for the action-type keyword.</p> <p>The action-type specifies the action type for the command rule or data rule. Available options are: accept, accept_log and reject.</p>
command cmd-name	<p>Specifies the command to which the command rule applies. The command must be entered within double-quotes.</p> <p>Example, get.</p>
context context-name	Specifies to which type of connection the command rule or data rule applies. The connection type can be netconf, cli, or xml.
group group-name	<p>Specifies the group to which the command rule or data rule applies.</p> <p>Example, admin-r.</p>
ops ops-type	<p>Specifies whether the user has read, execute, or read and execute permissions for the command.</p> <p>Available options for command rules are: r, rx, and x.</p> <p>To know the available options for data rules, use a ? after the ops keyword.</p>
commands group	<p>Sets the command authorization lists for server groups.</p> <p>Available options are none that specifies no authorization and tacacs that specifies use of the list of all tacacs+ hosts.</p>
Command Default	None
Command Modes	System Admin Config mode

Command History	Release	Modification
	Release 7.3.2	This command was introduced.
Usage Guidelines		
From Cisco IOS XR Software Release 7.3.2, the system internally maps the users configured on the XR VM to System Admin VM of the router, based on the task table of the user on the XR VM. With this feature, NETCONF and gRPC users can access the admin-related information on the router even if their user profiles do not exist on System Admin VM. For a sample configuration, see the example section.		

This example shows how to create a command rule:

```
Router#admin
sysadmin-vm:0_RP0#configure
sysadmin-vm:0_RP0(config)#aaa authorization cmdrules cmdrule 6
sysadmin-vm:0_RP0(config-cmdrule-6)#context netconf
sysadmin-vm:0_RP0(config-cmdrule-6)#command get
sysadmin-vm:0_RP0(config-cmdrule-6)#group admin-r
sysadmin-vm:0_RP0(config-cmdrule-6)#ops rx
sysadmin-vm:0_RP0(config-cmdrule-6)#action accept
sysadmin-vm:0_RP0(config)#commit
```

active

To enable a Call Home profile, use the **active** command in the call home profile configuration mode.

active

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	Call home profile configuration mode	
Command History	Release	Modification
	Release 7.0.1	This command was introduced.
Usage Guidelines		

You must enable a profile using the **active** command so that call home messages can be triggered.

The following example shows how to activate a profile.

```
domain name-server 192.0.2.6
call-home
service active
contact smart-licensing
profile CiscoTAC-1
active
```

address

To configure the IP address of the peer node during keyring configuration, use the **address** command in keyring configuration mode.

```
address { ipv4-address [ subnet-mask ] }
```

Syntax Description	<i>ipv4-address</i> IP address of the peer node. <i>subnet-mask</i> Subnet mask address.				
Command Default	None				
Command Modes	Keyring configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command was introduced.
Release	Modification				
7.0.1	This command was introduced.				

Example

The following is a sample in which an OTNSec policy is configured.

```
RP/0/RP0/CPU0:ios#conf
Thu Mar 7 19:33:14.594 UTC
RP/0/RP0/CPU0:ios(config)#keyring kyr1
RP/0/RP0/CPU0:ios(config-keyring-kyr1)#peer peer1
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#address 10.0.0.1 255.255.255.0
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#pre-shared-key key1|clear
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#commit
Thu Mar 7 19:54:33.314 UTC
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#exit
RP/0/RP0/CPU0:ios(config-keyring-kyr1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show keyring kyr1
Thu Mar 7 19:58:07.135 UTC

Keyring Name : kyr1
=====
Total Peers : 1
-----
Peer Name : peer1
IP Address : 10.0.0.1
Subnet Mask : 255.255.255.0
Local PSK : Configured
Remote PSK : Configured
```

ains-soak (OTN-XP Card)

To configure the default AINS settings for all controllers on the OTN-XP card, use the **ains-soak** command in the IOS XR configuration mode. The configuration is applied to any OTN-XP line card that is installed in the Cisco NCS 1004.

ains-soak hours hours minutes minutes

Syntax Description	ains-soak hours hours minutes minutes	Specifies the AINS configuration in hours and minutes.				
Command Default	None					
Command Modes	Cisco IOS XR Configuration					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.2.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	7.2.1	This command was introduced.	
Release	Modification					
7.2.1	This command was introduced.					

Example

The following is a sample in which all the controllers on the OTN-XP card are configured with AINS with soak time period specified to be two minutes.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#ains-soak hours 0 minutes 2
RP/0/RP0/CPU0:ios(config)#commit
```

automatic-in-service (OTN-XP Card)

To override the default AINS settings on a specific controller on the OTN-XP card, use the **automatic-in-service** command.



Note This configuration does not persist after a RP reload operation.

automatic-in-service controller optics R/S/I/P hours hours minutes minutes

Syntax Description	R/S/I/P	Rack/Slot/Instance/Port of the optics controller.
	hours minutes minutes	Specifies the AINS configuration in hours and minutes.

authentication

Command Default	None	
Command Modes	None	
Command History	Release	Modification
	Release 7.2.1	This command was introduced.

Example

The following is a sample in which the optics controller on the OTN-XP card is configured with a soak time period of 45 minutes.

```
RP/0/RP0/CPU0:ios#automatic-in-service controller optics 0/1/0/0 hours 0 minutes 45
```

authentication

To configure the local or remote authentication method for the IKEv2 profile, use the **authentication** command in IKEv2 profile configuration mode.



Note You can specify only one local authentication method but multiple remote authentication methods.

authentication {local pre-share | rsa-signature} {remote pre-share | rsa-signature}

Syntax Description	pre-share Specifies the preshared key as the authentication method. rsa-signature Specifies RSA signature as the authentication method.
Command Default	None
Command Modes	IKEv2 profile configuration
Command History	Release Modification R7.2.1 This command was introduced.

Example

The following example shows how to specify the authentication mode in the IKEv2 profile.

```
RP/0/RP0/CPU0:ios#configure
Thu May 7 16:22:33.804 IST
RP/0/RP0/CPU0:ios(config)#ikev2 profile IP1
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#match identity remote address 10.1.1.2
255.255.255.255
```

```

RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#pki trustpoint myca
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#lifetime 120
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#authentication local rsa-signature
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#authentication remote rsa-signature
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#commit

```

cipher-suite

To specify the encryption algorithm for an OTNSec policy, use the **cipher-suite** command in the OTNSec policy configuration mode.

cipher-suite *encryption-algorithm-type*

Syntax Description	<i>encryption-algorithm-type</i> Encryption algorithm type. AES-GCM-256 is used.				
Command Default	None				
Command Modes	OTNSec policy configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	7.0.1	This command was introduced.
Release	Modification				
7.0.1	This command was introduced.				

Example

The following is a sample in which an OTNSec policy is configured.

```

RP/0/RP0/CPU0:ios#configure
Mon Mar 11 15:16:58.417 UTC
RP/0/RP0/CPU0:ios(config)#otnsec policy otnsec-policy1
RP/0/RP0/CPU0:ios(config-otnsec-policy)#cipher-suite AES-GCM-256
RP/0/RP0/CPU0:ios(config-otnsec-policy)#security-policy must-secure
RP/0/RP0/CPU0:ios(config-otnsec-policy)#sak-rekey-interval 120
RP/0/RP0/CPU0:ios(config-otnsec-policy)#commit

```

The following is a sample of an OTNSec policy.

```

RP/0/RP0/CPU0:ios#show run otnsec policy otnsec-policy1
Tue Mar 12 11:14:03.591 UTC
otnsec policy otnsec-policy1
  cipher-suite AES-GCM-256
  security-policy must-secure
  sak-rekey-interval 120
!

```

controller coherentDSP

To configure the coherent DSP controller, use the **controller coherentDSP** command in the Coherent DSP controller configuration mode.

```
controller coherentDSP R/S/I/P [ description ] | [ fec fec-value ] | [ pm { 30-sec
|15-min |24-hour } { fec | otn } { report | threshold } value ] | [ perf-mon { enable | disable
} ] | [ loopback internal ] | [ secondary-admin-state { maintenance | normal } ] | [
shutdown ] | [ tti { sent | expected } { ascii | hex } tti-string ] [ gcc0 ] [ flexo { gid gid-no
| iid iid-no } ]
```

Syntax Description	
R/S/I/P	Rack/Slot/Instance/Port of the coherent DSP controller.
description description	Description of the coherent DSP controller.
fec fec-value	<p>Configures the FEC on the controller. The supported options on the 1.2T line card are StandardSD15 and StandardSD27.</p> <p>From Release 7.2.1 onwards, the supported options on the OTN XP card are EnhancedSD15 and EnhancedSD27.</p> <p>From Release 7.3.1 onwards, OFEC is supported on the OTN XP card.</p>
pm {30-sec 15-min 24-hour } {fec otn } {report threshold } value	<p>Configures performance monitoring parameters for 30 second, 15 minute, or 24-hour intervals.</p> <p>The fec keyword configures FEC PM data in 30 second, 15 minute, or 24-hour intervals.</p> <p>The otn keyword configures OTN PM data in 30 second, 15 minute, or 24-hour intervals.</p> <p>The report keyword configures TCA reporting status.</p> <p>The threshold keyword configures threshold values on PM parameters.</p>
perf-mon { enable disable }	Enables or disables performance monitoring.
loopback internal	<p>Configures the internal loopback mode on the controller.</p> <p>For the 1.2T line card, internal and line loopbacks are supported on the Ethernet controllers whereas only internal loopback is supported on the CoherentDSP controllers.</p>
secondary-admin-state	Configures the administrative state of the controller. The values are maintenance or normal.
shutdown	Disables the configuration of the controller.
tti sent {ascii hex} tti-string	Configures the Trail Trace Identifier (TTI) ASCII or hex string to be sent. From Release 7.3.2 onwards, TTI strings such as SAPI, DAPI, and operator inputs are supported.

tti expected {ascii hex}	Configures the expected TTI ASCII or hex string. The OTUK-TIM alarm is raised if the received TTI string does not match the expected TTI string. From Release 7.3.2 onwards, TTI strings such as SAPI, DAPI, and operator inputs are supported.														
gcc0	Enables the GCC0 interface.														
flexo {gidgid-no iidiid-no}]	Configures FlexO group identification (GID) and FlexO instance identification (IID) on the controller. The range of the gid <i>gid-no</i> is 1–1,048,576. The range of the iid <i>iid-no</i> is 1–254.														
Command Default	None														
Command Modes	Coherent DSP controller configuration														
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.1</td><td>This command was introduced.</td></tr> <tr> <td>Release 7.1.1</td><td>gcc0 keyword was added.</td></tr> <tr> <td>Release 7.2.1</td><td>The following FEC options for the OTN-XP card were added. <ul style="list-style-type: none"> • EnhancedSD15 • EnhancedSD27 </td></tr> <tr> <td>Release 7.3.1</td><td>The following FEC options for the OTN-XP card were added. <ul style="list-style-type: none"> • OFEC </td></tr> <tr> <td>Release 7.3.1</td><td>The flexo {gidgid-no iidiid-no}] keyword and options were added.</td></tr> <tr> <td>Release 7.3.2</td><td>TTI strings such as SAPI, DAPI, and operator inputs were supported.</td></tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command was introduced.	Release 7.1.1	gcc0 keyword was added.	Release 7.2.1	The following FEC options for the OTN-XP card were added. <ul style="list-style-type: none"> • EnhancedSD15 • EnhancedSD27 	Release 7.3.1	The following FEC options for the OTN-XP card were added. <ul style="list-style-type: none"> • OFEC 	Release 7.3.1	The flexo {gidgid-no iidiid-no}] keyword and options were added.	Release 7.3.2	TTI strings such as SAPI, DAPI, and operator inputs were supported.
Release	Modification														
Release 7.0.1	This command was introduced.														
Release 7.1.1	gcc0 keyword was added.														
Release 7.2.1	The following FEC options for the OTN-XP card were added. <ul style="list-style-type: none"> • EnhancedSD15 • EnhancedSD27 														
Release 7.3.1	The following FEC options for the OTN-XP card were added. <ul style="list-style-type: none"> • OFEC 														
Release 7.3.1	The flexo {gidgid-no iidiid-no}] keyword and options were added.														
Release 7.3.2	TTI strings such as SAPI, DAPI, and operator inputs were supported.														

Example

The following is a sample in which performance monitoring parameters of Coherent DSP controller is configured in 30-second intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/0/1/1 pm 30-sec fec threshold post-fec-ber
max OE-15
RP/0/RP0/CPU0:ios(config)#commit
```

The following example shows how to configure TTI on a coherentDSP controller with the sent and expected strings set to the same ASCII string. The state of the controller is up.

```
RP/0/RP0/CPU0:ios#configure
```

controller coherentDSP

```
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/1/0/1 tti sent ascii 1234
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/1/0/1 tti expected ascii 1234
RP/0/RP0/CPU0:ios(config)#commit
```

The following example shows how to configure TTI on a coherentDSP controller with the sent and expected strings set to different ASCII strings. The state of the controller goes down and the OTUK-TIM alarm is raised.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/1/0/1 tti sent ascii 1234
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/1/0/1 tti expected ascii 5678
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample to enable the GCC0 interface.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller CoherentDSP0/0/0/0
RP/0/RP0/CPU0:ios(config-CoDSP) #gcc0
RP/0/RP0/CPU0:ios(config-CoDSP) #commit
RP/0/RP0/CPU0:ios(config-CoDSP) #exit
```

The following is a sample to configure FEC with the EnhancedSD15 option on the CoherentDSP controller of the OTN-XP card:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/0/0/0
RP/0/RP0/CPU0:ios(config-CoDSP) #fec EnhancedSD15
Tue Feb 25 11:25:52.670 UTC
WARNING! Changing FEC mode can impact traffic
RP/0/RP0/CPU0:ios(config-CoDSP) #commit
```

The following is a sample to configure with the O-FEC option on the CoherentDSP controller of the OTN-XP card:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/0/0/0
RP/0/RP0/CPU0:ios(config-CoDSP) #fec OFEC
Tue Feb 25 11:25:52.670 UTC
WARNING! Changing FEC mode can impact traffic
RP/0/RP0/CPU0:ios(config-CoDSP) #commit
```

The following is a sample to configure flexO GID and IID on the CoherentDSP controller of the OTN-XP card:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP0/2/0/12
RP/0/RP0/CPU0:ios(config-CoDSP) #flexo
RP/0/RP0/CPU0:ios(config-CoDSP) #gid 2 iid 5,6,7,8
RP/0/RP0/CPU0:ios(config-CoDSP) #commit
```

The following sample displays how to configure loopback on a coherent DSP controller ports on the OTN-XP in inverse muxponder configuration mode.

```
Thu Sep 30 14:16:04.678 UTC
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/2/0/12
RP/0/RP0/CPU0:ios(config-CoDSP) #secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP) #loopback internal
RP/0/RP0/CPU0:ios(config-CoDSP) #commit
Thu Sep 30 14:16:19.594 UTC
```

```
RP/0/RP0/CPU0:ios(config-CoDSP) #controller coherentDSP 0/2/0/13
RP/0/RP0/CPU0:ios(config-CoDSP) #secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP) #loopback internal
RP/0/RP0/CPU0:ios(config-CoDSP) #commit
```

The following sample displays how to configure TTI on a coherent DSP controller port 12 on the OTN-XP in inverse muxponder configuration mode.

```
RP/0/RP0/CPU0:ios#configure
Thu Sep 30 14:18:13.288 UTC
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/2/0/12
RP/0/RP0/CPU0:ios(config-CoDSP)#tti sent sapi ascii cisco
RP/0/RP0/CPU0:ios(config-CoDSP) #commit
```

controller HundredGigECtrlr

To configure the Ethernet controller, use the **controller HundredGigECtrlr** command in the Ethernet controller configuration mode.

```
controller HundredGigECtrlr R/S/I/P [ pm { 30-sec | 15-min | 24-hour } { ether } { report | threshold } value ] | [ perf-mon disable ] | [ loopback { internal | line } ] | [ sec-admin-state maintenance ] | [ shutdown ] | [ laser-squelch ] | [ fec { none | standard } ] | [ holdoff-time trunk-fault timevalue ] insert-idle ingress insert-idle egress
```

Syntax Description	
<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the Ethernet controller.
pm { 30-sec 15-min 24-hour }	Configures performance monitoring parameters for 30 second, 15 minutes, or 24 hour intervals.
ether	Configures Ethernet PM data in 30 second, 15 minute or 24 hour intervals.
report	Configures TCA reporting status.
threshold	Configures threshold on Ethernet controller parameters.
perf-mon disable	Disables performance monitoring.
loopback [internal line]	Configures the internal or line loopback mode on the Ethernet controller. For the 1.2T line card, internal and line loopbacks are supported on the ethernet controllers whereas only internal loopbacks are supported on the CoherentDSP controllers.
sec-admin-state maintenance	Configures the administrative state of the controller indicating that the controller is under maintenance.
shutdown	Disables the configuration of the controller.
laser-squelch	Enables laser squelching so that laser is brought down in the event of trunk faults (LOF, LOS) and a SQUELCHED alarm is raised.
fec { none standard }	Disables FEC or enables standard (Reed-Solomon) FEC.

holdoff-time trunk-fault	When a fault occurs on the trunk port, the user can hold the propagation of Local Fault using this parameter. The range of <i>timevalue</i> is 0 to 3000 ms.						
insert-idle ingress	Enables idle frames insertion in the ingress direction.						
insert-idle egress	Enables idle frames insertion in the egress direction.						
Command Default	None						
Command Modes	Ethernet controller configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.1</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 7.5.2</td> <td>insert-idle ingress and insert-idle egress keywords were added.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command was introduced.	Release 7.5.2	insert-idle ingress and insert-idle egress keywords were added.
Release	Modification						
Release 7.0.1	This command was introduced.						
Release 7.5.2	insert-idle ingress and insert-idle egress keywords were added.						

Example

The following example shows how to configure the performance monitoring parameters of the Ethernet controller in 15 minute intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 pm 15-min pcs report bip
enable
```

The following example shows how to configure the internal loopback.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 secondary-admin-state
maintenance
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 loopback internal
RP/0/RP0/CPU0:ios(config)#commit
```

The following example enables IDLE hold off timer in Ethernet controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 holdoff-time trunk-fault
3000
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample where laser quenching is enabled on the Ethernet controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 laser-squelch
RP/0/RP0/CPU0:ios(config)#commit
```

controller FourHundredGigECtrlr

To configure the Ethernet controller, use the **controller FourHundredGigECtrlr** command in the Ethernet controller configuration mode.

```
controller FourHundredGigECtrlr R/S/I/P [ pm { 30-sec | 15-min | 24-hour } { ether } { report threshold } value ] | [ perf-mon disable ] | [ loopback { internal | line } ] | [ sec-admin-state maintenance ] | [ shutdown ] | [ laser-squelch ] | [ fec { none | standard } ] | [ holdoff-time trunk-fault timevalue ] insert-idle ingress insert-idle egress
```

Syntax Description	
R/S/I/P	Rack/Slot/Instance/Port of the Ethernet controller.
pm {30-sec 15-min 24-hour}	Configures performance monitoring parameters for 30 second, 15 minutes, or 24 hour intervals.
ether	Configures Ethernet PM data in 30 second, 15 minute or 24 hour intervals.
report	Configures TCA reporting status.
threshold	Configures threshold on Ethernet controller parameters.
perf-mon disable	Disables performance monitoring.
loopback [internal line]	Configures the internal or line loopback mode on the Ethernet controller. For the 1.2T line card, internal and line loopbacks are supported on the ethernet controllers whereas only internal loopbacks are supported on the CoherentDSP controllers.
sec-admin-state maintenance	Configures the administrative state of the controller indicating that the controller is under maintenance.
shutdown	Disables the configuration of the controller.
laser-squelch	Enables laser squelching so that laser is brought down in the event of trunk faults (LOF, LOS) and a SQUELCHED alarm is raised.
fec { none standard }	Disables FEC or enables standard (Reed-Solomon) FEC.
holdoff-time trunk-fault timevalue	When a fault occurs on the trunk port, the user can hold the propagation of Local Fault using this parameter. The range of <i>timevalue</i> is 0 to 3000 ms.
insert-idle ingress	Enables idle frames insertion in the ingress direction.
insert-idle egress	Enables idle frames insertion in the egress direction.
Command Default	None
Command Modes	Ethernet controller configuration

controller TenGigECtrlr (OTN-XP Card)

Command History	Release	Modification
	Release 7.3.1	This command was introduced.
	Release 7.5.2	insert-idle ingress and insert-idle egress keywords were added.

Example

The following example shows how to configure the performance monitoring parameters of the Ethernet controller in 15 minute intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 pm 15-min pcs report bip
enable
```

The following example shows how to configure the internal loopback.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 secondary-admin-state
maintenance
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 loopback internal
RP/0/RP0/CPU0:ios(config)#commit
```

The following example enables IDLE hold off timer in Ethernet controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 holdoff-time trunk-fault
3000
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample where laser quenching is enabled on the Ethernet controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 laser-squelch
RP/0/RP0/CPU0:ios(config)#commit
```

controller TenGigECtrlr (OTN-XP Card)

To configure the Ethernet controller, use the **controller TenGigECtrlr** command in the Ethernet controller configuration mode.

From R7.2.1 onwards, the TenGig Ethernet controller configuration is supported on the OTN-XP card.

```
controller TenGigECtrlr R/S/I/P/L [ pm { 30-sec |15-min | 24-hour } perf-mon disable ] |
[ loopback { internal | line } ] | [ sec-admin-state maintenance ] | [ shutdown ] | [
laser-squelch ] | [ holdoff-time trunk-fault timevalue ]
```

Syntax Description	R/S/I/P/L	Rack/Slot/Instance/Port/Lane of the Ethernet controller.
	pm {30-sec 15-min 24-hour }	Configures performance monitoring parameters for 30 second, 15 minutes, or 24 hour intervals.

perf-mon disable	Disables performance monitoring.				
loopback [internal line]	Configures the internal or line loopback mode on the Ethernet controller.				
sec-admin-state maintenance	Configures the administrative state of the controller indicating that the controller is under maintenance.				
shutdown	Disables the configuration of the controller.				
laser-squelch	Enables laser squelching so that laser is brought down in the event of trunk faults and a SQUELCHED alarm is raised.				
holdoff-time trunk-fault timevalue	When a fault occurs on the trunk port, the user can hold the propagation of Local Fault using this parameter. The range of <i>timevalue</i> is 0 to 3000 ms.				
Command Default	None				
Command Modes	Ethernet controller configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.2.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.2.1	This command was introduced.
Release	Modification				
Release 7.2.1	This command was introduced.				

Examples

The following example shows how to configure the internal loopback.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller TenGigECtrlr 0/0/0/4/1 secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config)#controller TenGigECtrlr 0/0/0/4/1 loopback internal
RP/0/RP0/CPU0:ios(config)#commit
```

The following example enables IDLE hold off timer in Ethernet controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller TenGigECtrlr 0/0/0/4/1 holdoff-time trunk-fault 3000
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample where laser quenching is enabled on the Ethernet controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller TenGigECtrlr 0/0/0/4/1 laser-squelch
RP/0/RP0/CPU0:ios(config)#commit
```

controller odu2e (OTN-XP Card)

To configure the ODU2e controller, use the **controller odu2e** command in the configuration mode.

From R7.2.1 onwards, the PBRS mode configuration is supported on the ODU2e controller on OTN-XP card.

controller ODU4

controller Odu2e R/S/I/P/C/L opu prbs mode { source | sink | source-sink } pattern invertedpn31

Syntax Description	<i>R/S/I/P/C/L</i>	Rack/Slot/Instance/Port/Client-port/Lane-number of the ODU2e controller.				
	opu	Configures Optical Channel Payload Unit (OPU) on the ODU2e controller.				
	prbs mode { source sink source-sink }	Configures Pseudo Random Binary Sequence (PRBS) mode as source, sink, or source sink.				
	patterninvertedpn31	Configures PRBS pattern as inverted pattern. Sequence length is from 2^31 -1 bits.				
Command Default	None					
Command Modes	Configuration					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.2.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>		Release	Modification	Release 7.2.1	This command was introduced.
Release	Modification					
Release 7.2.1	This command was introduced.					

Example

The following is a sample in which PRBS mode is configured as source with pattern as invertedpn31.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller odu2e 0/0/0/0/4/1
RP/0/RP0/CPU0:ios(config-odu2e)#opu
RP/0/RP0/CPU0:ios(config-OpuK)#prbs mode source pattern invertedpn31
RP/0/RP0/CPU0:ios(config-OpuK)#commit
```

controller ODU4

To configure the ODU4 controller, use the **controller ODU4** command in the configuration mode.

controller ODU4 R/S/I/P gcc2

Syntax Description	<i>R/S/I/P/L</i> Rack/Slot/Instance/Port/Lane of the ODU4 controller.
	gcc2 Enables the GCC2 interface.
Command Default	None
Command Modes	Configuration

Command History	Release	Modification
	Release 7.0.1	This command is introduced.
	Release 7.1.1	gcc2 keyword was added.

Example

The following is a sample in which OTNSec is configured on ODU4 controllers.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 12 12:10:21.374 UTC
RP/0/RP0/CPU0:ios(config)#controller ODU4 0/1/0/0/1
RP/0/RP0/CPU0:ios(config-odu4)#otnsec
RP/0/RP0/CPU0:ios(config-otnsec)#source ipv4 10.0.0.1
RP/0/RP0/CPU0:ios(config-otnsec)#destination ipv4 10.0.0.2
RP/0/RP0/CPU0:ios(config-otnsec)#session-id 9000
RP/0/RP0/CPU0:ios(config-otnsec)#policy otnsec-policy1
RP/0/RP0/CPU0:ios(config-otnsec)#ikev2 profile1
RP/0/RP0/CPU0:ios(config-otnsec)#commit
Mon Mar 12 12:14:17.609 UTC
RP/0/RP0/CPU0:ios(config-otnsec)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

The following is a running configuration on an ODU4 controller.

```
RP/0/RP0/CPU0:ios#show run controller ODU4 0/1/0/0/1
Tue Mar 12 12:20:49.153 UTC
controller ODU4 0/1/0/0/1
  gcc2
  otnsec
    policy otnsec-policy1
    source ipv4 10.0.0.1
    destination ipv4 10.0.0.2
    session-id 9000
!
!
```

The following is a sample to enable the GCC2 interface.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller odu4 0/1/0/0/1
RP/0/RP0/CPU0:ios(config-odu4)#gcc2
RP/0/RP0/CPU0:ios(config-odu4)#commit
RP/0/RP0/CPU0:ios(config-odu4)#exit
```

controller ODU4

To configure the ODU4 controller, use the **controller ODU4** command in the configuration mode.

controller ODU4 R/S/I/P

controller ODUC4

Syntax Description	<i>R/S/I/P/L</i> Rack/Slot/Instance/Port/Lane of the ODUC4 controller.				
Command Default	None				
Command Modes	Configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.8.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.8.1	This command is introduced.
Release	Modification				
7.8.1	This command is introduced.				

Example

The following is a sample in which OTNSec is configured on ODUC4 controllers.

```
RP/0/RP0/CPU0:ios#configure
Wed Sep 28 23:10:48.429 UTC
RP/0/RP0/CPU0:ios(config)#controller odusc4 0/0/0/12
RP/0/RP0/CPU0:ios(config-odusc4)#otnsec
RP/0/RP0/CPU0:ios(config-otnsec)#source ipv4 10.1.1.1
RP/0/RP0/CPU0:ios(config-otnsec)#destination ipv4 10.1.1.2
RP/0/RP0/CPU0:ios(config-otnsec)#session-id 99
RP/0/RP0/CPU0:ios(config-otnsec)#policy otnsec-policy1
RP/0/RP0/CPU0:ios(config-otnsec)#ikev2 profile1
RP/0/RP0/CPU0:ios(config-otnsec)#commit
Wed Sep 28 23:10:48.973 UTC
RP/0/RP0/CPU0:ios(config-otnsec)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

The following is a running configuration on an ODUC4 controller.

```
RP/0/RP0/CPU0:ios#show run controller ODUC4 0/0/0/12
Wed Sep 28 23:11:418.123 UTC
controller ODUC4 0/0/0/12
  gcc2
  otnsec
    policy otnsec-policy1
    source ipv4 10.0.0.1
    destination ipv4 10.0.0.2
    session-id 99
!
!
```

The following is a sample to enable the GCC2 interface.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller ODUC4 0/0/0/12
RP/0/RP0/CPU0:ios(config-oduc4)#gcc2
RP/0/RP0/CPU0:ios(config-oduc4)#commit
RP/0/RP0/CPU0:ios(config-oduc4)#exit
```

controller odu-group-mp

To create an ODU group controller, use the **controller odu-group-mp** command in the configuration mode. To delete an ODU group controller, use the **no** form of this command.

```
controller odu-group-mp Group-ID { signal } [ otn | sonet | ethernet ] { odu-type }  

type-of-the-odu [ protecting-controller | protection-attributes | protection-switching |  

working-controller ] [ connection-mode | protection-mode | protection-type | timers ]  

mode-of-the-connection
```

```
no controller odu-group-mp Group-ID { signal type } type-of-the-odu
```

Syntax Description	Group ID	Identifier of the ODU group controller. The valid range is from 1 to 65535.
	signal	Configures the type of the client signal to be added in the ODU group controller.
	odu-type	Configures the odu-type of the signal selected for the ODU group controller.
	<i>Type of the ODU</i>	The odu-type of the signal selected for the ODU group controller.
Command Default	None	
Command Modes	Configuration	
Command History	Release	Modification
	Release 7.8.1	This command was introduced.
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. ODU group is always created on the head node.	
Task ID	Task ID	Operation
	otn	write

Example

This example shows how to create an ODU group controller:

```
RP/0/RP0:hostname(config)# controller odu-group-mp 2 signal Otn odu-type ODUC4
RP/0/RP0:hostname(config-odu-group-mp4)# protecting-controller ODUC4 0/0/0/13
RP/0/RP0:hostname(config-odu-group-mp4)# working-controller ODUC4 0/0/0/12
```

controller OTU (OTN-XP Card)

To configure the OTU controller, use the **controller OTU** command in the configuration mode.

From R7.2.1 onwards, you can configure loopback on the OTU2, OTU2e, and OTU4 controllers on OTN-XP card.

```
controller { otu2 | otu2e | otu4 } R/S/I/P/L sec-admin-state loopback [ internal | line ]
```

Syntax Description	R/S/I/P/L	Rack/Slot/Instance/Port/Lanenumber of the OTU2, OTU2e, and OTU4 controller. The range of <i>Lanenumber</i> is from 1 to 4.
	sec-admin-state	Configures the administrative state of the controller .
	loopback [internal line]	Configures the internal or line loopback mode on the OTU2, OTU2e, and OTU4 controller.
Command Default	None	
Command Modes	Configuration	
Command History	Release	Modification
	Release 7.2.1	This command was introduced.

Examples

The following is a sample in which the line loopback is configured on the OTU2e controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller otu2e 0/0/0/11/3
RP/0/RP0/CPU0:ios(config-otu2e)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-otu2e)#loopback line
RP/0/RP0/CPU0:ios(config-otu2e)#commit
Thu Apr 23 10:55:19.319 UTC
RP/0/RP0/CPU0:ios(config-otu2e)#end
```

The following is a sample in which the internal loopback is configured on the OTU2 controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller otu2 0/0/0/5/1
RP/0/RP0/CPU0:ios(config-otu2)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-otu2)#loopback internal
RP/0/RP0/CPU0:ios(config-otu2)#commit
Thu Apr 23 11:01:00.562 UTC
RP/0/RP0/CPU0:ios(config-otu2)#end
```

The following is a sample in which the internal loopback is configured on the OTU4 controller.

```
RP/0/RP0/CPU0:ios#configure
```

```

RP/0/RP0/CPU0:ios(config)#controller otu4 0/0/0/0
RP/0/RP0/CPU0:ios(config-otu4)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-otu4)#loopback internal
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Apr 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end

```

controller optics

To configure the optics controller, use the **controller optics** command in the optics controller configuration mode.

```

controller optics R/S/I/P [ baud-rate rate ] [ bits-per-symbol value ] [ cd-max cd-max
| cd-min cd-min | cd-low-threshold cd-low | cd-high-threshold cd-high |
dgd-high-threshold dgd-value | lbc-high-threshold lbc-value | osnr-low-threshold osnr-value
description description | rx-high-threshold rx-high | rx-low-threshold rx-low |
tx-high-threshold tx-high | tx-low-threshold tx-low | sec-admin-state {maintenance | normal}
| shutdown | transmit-power transmit-power | transmit-shutdown | perf-mon { enable
| disable } | pm { 30-sec |15-min |24-hour } | optics { report | threshold { cd |
dgd | lbc | lbc-pc | opr | opr-dbm | opt | opt-dbm | osnr | pcr | pdl |
pn | sopmd | rx-sig-pow | rx-sig-pow-dbm } } ] [ fastpoll { enable | disable } ]

```

To configure the sub-sea parameters for the optics controller, use the following command:

```

controller optics R/S/I/P [ filter-roll-off-factor value | filter-roll-off-factor value | rx-voa
target-power value | rx-voa fixed-ratio value | enh-colorless-mode value | enh-sop-tol-mode
value | nleq-comp-mode value | cross-pol-gain-mode value | cross-pol-weight-mode value |
cpr-win-mode value | cpr-ext-win-mode value | submarine-params type value ]

```

Syntax Description	
R/S/I/P	Rack/Slot/Instance/Port of the optics controller.
baud-rate <i>rate</i>	Sets baud-rate for this controller in GBd.
bits-per-symbol <i>value</i>	Sets bits-per-symbol for this controller.
cd-max <i>cd-max</i>	(Only for trunk optics controllers) Maximum chromatic dispersion. The range is –350000 to +350000 ps/nm.
cd-min <i>cd-min</i>	(Only for trunk optics controllers) Minimum chromatic dispersion. The range is –350000 to +350000 ps/nm.
cd-low-threshold <i>cd-low</i>	(Only for trunk optics controllers) Minimum acceptable chromatic dispersion. The CD alarm is raised if the chromatic dispersion goes below this value. The range is –350000 to +350000 ps/nm.
cd-high-threshold <i>cd-high</i>	(Only for trunk optics controllers) Maximum acceptable chromatic dispersion. The CD alarm is raised if the chromatic dispersion exceeds this value. The range is –350000 to +350000 ps/nm.

dgd-high-threshold <i>dgd-value</i>	(Only for trunk optics controllers) Configures the maximum acceptable Differential Group Delay (DGD) value. The DGD alarm is raised if DGD exceeds this value. The range is 0–18000 (in the units of 0.01 ps).
lbc-high-threshold <i>lbc-value</i>	Configures the high laser bias current threshold. The range is 0 to 100%.
osnr-low-threshold <i>osnr-value</i>	(Only for trunk optics controllers) Configures the minimum acceptable Optical Signal to Noise ratio (OSNR) value. The OSNR alarm is raised if OSNR goes below this value. The range is 0–4000 (in units of 0.01db).
description <i>description</i>	Description of the optics controller.
rx-high-threshold <i>rx-high</i>	Configures high receive power threshold. The range is –400 to 300 (in the units of 0.1 dBm).
rx-low-threshold <i>rx-low</i>	Configures low receive power threshold. The range is –400 to 300 (in the units of 0.1 dBm).
tx-high-threshold <i>tx-high</i>	Configures high transmit power threshold. The range is –400 to 300 dBm (in the units of 0.1 dBm).
tx-low-threshold <i>tx-low</i>	Configures low transmit power threshold. The range is –400 to 300 dBm (in the units of 0.1 dBm).
sec-admin-state	Configures the administrative state of the controller. The values are maintenance or normal.
shutdown	Disables the configuration of the controller.
pm	Configures performance monitoring parameters for 30 second, 15 minute, and 24-hour intervals.
transmit-power <i>transmit-power</i>	(Only for trunk optics controllers) Configures the transmit power. The range is –190 to 30 dBm (in the units of 0.1 dBm). From Release 7.3.1 onwards, transmit power is supported on the CFP2 DCO optics for the OTN-XP card. The transmit power value is –10 to +1 dBm.
transmit-shutdown	Shuts down the transmit laser.
perf-mon { enable disable }	Enables or disables performance monitoring.
cd	Configures the chromatic dispersion threshold.
dgd	Configures the differential group delay threshold.
lbc	Configures the laser bias current threshold.

lbc-pc	Configures the laser bias current threshold in percentage.
opr	Configures the optical Rx power threshold in uW.
opr-dbm	Configures the optical Rx power threshold in dBm. The unit is 0.01 dBm. For example, if you want to configure 30.00 dBm, enter 3000.
opt	Configures the optical Tx power threshold in uW.
opt-dbm	Configures the optical Tx power threshold in dBm. The unit is 0.01 dBm.
osnr	Configures the OSNR threshold.
pcr	Configures the Polarization Change Rate (PCR) threshold.
pdl	Configures the Polarization-Dependent Loss (PDL) threshold.
pn	Configures the Phase Noise (PN) threshold.
sopmd	Configures the Second Order Polarization Mode Dispersion (SOPMD) threshold.
rx-sig-pow	Configures the Rx signal power threshold in uW.
rx-sig-pow-dbm	Configures the Rx signal power threshold in dBm. The unit is 0.01 dBm.
filter-roll-off-factor <i>value</i>	Configures the RRC filter roll-off factor. The range is 0 to 1.
rx-voa target-power <i>value</i>	Configures the receive target power. The range is -190 to +30.
rx-voa fixed-ratio <i>value</i>	Configures the receive ratio of optical attenuation. The range is +100 to +1700.
enh-colorless-mode <i>value</i>	Configures the enhanced colorless mode. The range is 1-3.
enh-sop-tol-mode <i>value</i>	Configures the enhanced SOP tolerance mode. The range is 1-3.
nleq-comp-mode <i>value</i>	Configures the non-linear compensation. The range is 1-4.
cross-pol-gain-mode <i>value</i>	Configures the carrier phase recovery cross polarization gain mode. The range is 0-15.
cross-pol-weight-mode <i>value</i>	Configures the carrier phase recovery cross polarization weight mode. The range is 0-15.
cpr-win-mode <i>value</i>	Configures the carrier phase recovery window mode. The range is 1-4.
cpr-ext-win-mode <i>value</i>	Configures the carrier phase recovery extended window mode. The range is 1-9.
submarine-params <i>type value</i>	Configures the proprietary submarine parameters. The range for the type is 1-10 and the range for the value is 1-1000.
Note	This parameter is for future use.
fastpoll { enable disable }	Enables or disables fast polling of SOP data.

controller optics

Command Default	None	
Command History	Release	Modification
	Release 7.0.1	This command was introduced.
	Release 7.3.1	The keyword fastpoll was added.
Command Modes	Optics controller configuration	
Usage Guidelines	The configurations for chromatic dispersion (cd-max, cd-min, cd-low-threshold, and cd-high-threshold) must be performed only after the hw-module configuration. These configurations must be removed before the no hw-module configuration.	

Example

The following example shows how to configure the optics controller and set the high-power threshold at the transmit and receive side.

```
RP/0/RP0/CPU0:ios# configure
RP/0/RP0/CPU0:ios(config)#controller optics 0/0/1/1
RP/0/RP0/CPU0:ios(config-optics)#rx-high-threshold 200
RP/0/RP0/CPU0:ios(config-optics)#tx-high-threshold 300
```

The following example shows how to configure the optics controller and set the ranges for chromatic dispersion.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller optics 0/0/1/1
RP/0/RP0/CPU0:ios(config-optics)#cd-max 10000
RP/0/RP0/CPU0:ios(config-optics)#cd-min 2000
```

The following is a sample in which the performance monitoring parameters of optics controller are configured in 24-hour intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller optics 0/0/1/1 pm 24-hour optics threshold osnr max
345
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the fastpoll data is enabled on the optics controller:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)# [no] controller optics <r/s/i/p> fastpoll enable
```

The following is a sample to configure transmit power on the CFP2 DCO optics for the OTN-XP card:

```
RP/0/RP0/CPU0:ios#configure
Mon Aug 19 19:31:42.115 UTC
RP/0/RP0/CPU0:ios(config)#controller optics 0/1/0/12
RP/0/RP0/CPU0:ios(config-Optics)#transmit-power -1.50
RP/0/RP0/CPU0:ios(config-Optics)#commit
Mon Aug 19 19:35:24.697 UTC
```

```
RP/0/RP0/CPU0:ios(config-Optics)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

The following is a sample to configure 8QAM modulation on the 200G muxponder mode for the OTN-XP card:

```
RP/0/RP0/CPU0:ios#configure
Wed Jun 2 17:21:42.115 UTC
RP/0/RP0/CPU0:ios(config)#controller optics 0/1/0/12
RP/0/RP0/CPU0:ios(config-Optics)#bits-per-symbol 3
RP/0/RP0/CPU0:ios(config-Optics)#commit
```

crypto ca authenticate

To authenticate the certification authority (CA) by getting the certificate for the CA, use the **crypto ca authenticate** command in EXEC mode.

```
crypto ca authenticate { ca-name | system-trustpoint }
```

Syntax Description	<i>ca-name</i> Name of the CA Server. system-trustpoint Generates self-signed root certificate.				
Command Default	None				
Command Modes	EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.10.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.10.1	This command was introduced.
Release	Modification				
Release 7.10.1	This command was introduced.				
Usage Guidelines	<p>The crypto ca authenticate command is required when you initially configure CA support at your NCS 1004. This command authenticates the CA to your NCS 1004 by obtaining the CA certificate, which contains the public key for the CA. For self-signed root CA, because the CA signs its own certificate, you should manually authenticate the CA public key by contacting the CA administrator when you use this command. The certificate fingerprint matching is done out-of-band (for example, phone call, and so forth).</p> <p>Authenticating a second-level CA requires prior authentication of the root CA.</p> <p>After the crypto ca authenticate command is issued and the CA does not respond by the specified timeout period, you must obtain terminal control again to re-enter the command.</p>				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operations</th></tr> </thead> <tbody> <tr> <td></td><td>crypto execute</td></tr> </tbody> </table>	Task ID	Operations		crypto execute
Task ID	Operations				
	crypto execute				
Examples	The CA sends the certificate, and the NCS 1004 prompts the administrator to verify the certificate by checking the certificate fingerprint (a unique identifier). The CA administrator can also display				

crypto ca enroll

the CA certificate fingerprint, so you should compare what the CA administrator sees to what the NCS 1004 displays on the screen. If the fingerprint on the display matches the fingerprint displayed by the CA administrator, you should accept the certificate as valid.

The following example shows that the NCS 1004 requests the CA certificate:

```
RP/0/0RPO/SP0/CPU0:ios# crypto ca authenticate msiox
Retrieve Certificate from SFTP server? [yes/no]: yes
Read 860 bytes as CA certificate
  Serial Number : 06:A5:1B:E6:4F:5D:F7:83:41:11:D5:F9:22:7F:95:23
  Subject:
    Name: CA2
    CN= CA2
  Issued By :
    cn=CA2
  Validity Start : 07:51:51 UTC Wed Jul 06 2005
  Validity End   : 08:00:43 UTC Tue Jul 06 2010
  CRL Distribution Point
    http://10.56.8.236/CertEnroll/CA2.crl
Certificate has the following attributes:
  Fingerprint: D0 44 36 48 CE 08 9D 29 04 C4 2D 69 80 55 53 A3

Do you accept this certificate? [yes/no]: yes

RP/0/0RPO/SP0/CPU0:ios: cepki[335]: %SECURITY-CEPKI-6-INFO : certificate database updated
Do you accept this certificate? [yes/no] yes
```

This example shows how to generate a self-signed root certificate:

```
RP/0/0RPO/SP0/CPU0:ios#crypto ca authenticate system-trustpoint
```

crypto ca enroll

To obtain a NCS 1004 certificate from the certification authority (CA), use the **crypto ca enroll** command in EXEC mode.

crypto ca enroll { ca-name | system-trustpoint }

Syntax Description

ca-name	Name of the CA Server.
system-trustpoint	Generates the leaf certificate.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
----------------	---------------------

Release 7.10.1

This command was introduced.

Usage Guidelines

Use the **crypto ca enroll** command to request certificates from the CA for the Rivest, Shamir, and Adelman (RSA) key pairs for NCS 1004 defined by the [rsakeypair](#), on page 101 command in trustpoint configuration mode. If no **rsakeypair** command is configured for the current trustpoint, the default RSA key pair is used for enrollment. This task is also known as enrolling with the CA. (Enrolling and obtaining certificates are two separate events, but they both occur when the **crypto ca enroll** command is issued.) When using manual enrollment, these two operations occur separately.

NCS 1004 needs a signed certificate from the CA for each of the RSA key pairs on NCS 1004; if you previously generated general-purpose keys, this command obtains the one certificate corresponding to the one general-purpose RSA key pair. If you previously generated special-usage keys, this command obtains two certificates corresponding to each of the special-usage RSA key pairs.

If you already have a certificate for your keys, you are unable to configure this command; instead, you are prompted to remove the existing certificate first. (You can remove existing certificates by removing the trustpoint configuration with the **no crypto ca trustpoint** command.)

The **crypto ca enroll** command is not saved in NCS 1004 configuration.



Note The root certificate signs the leaf certificate.

Task ID**Task ID**

crypto execute

Examples

The following sample output is from the **crypto ca enroll** command:

```
RP/0/0RPO0SP0/CPU0:ios# crypto ca enroll msiox
% Start certificate enrollment...
% Create a challenge password. You will need to verbally provide this password to the
  CA Administrator in order to revoke your certificate.
% For security reasons you password will not be saved in the configuration.
% Please make a note of it.
%Password
re-enter Password:
  Fingerprint: 4F35ADC9 2791997A CE211437 AFC66CF7

RP/0/0RPO0SP0/CPU0:May 29 18:49:15.572 : pki_cmd: %PKI-6-LOG_INFO : certificate request
pending

RP/0/0RPO0SP0/CPU0:May 29 18:52:17.705 : pki_get_cert: %PKI-6-LOG_INFO : certificate is
granted
```

This example shows how to generate a leaf certificate:

```
RP/0/0RPO0SP0/CPU0:ios#crypto ca enroll system-trustpoint
```

crypto ca trustpoint

crypto ca trustpoint

To configure a trusted point with a selected name, use the **crypto ca trustpoint** command. To unconfigure a trusted point, use the **no** form of this command in Config mode.

crypto ca trustpoint { ca-name | system-trustpoint }

Syntax Description	<p><i>ca-name</i> Name of the CA.</p> <p>system-trustpoint Specifies the default system trustpoint.</p>				
Command Default	None				
Command Modes	Config mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>7.10.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	7.10.1	This command was introduced.
Release	Modification				
7.10.1	This command was introduced.				

Usage Guidelines	<p>Use the crypto ca trustpoint command to declare a CA.</p> <p>This command allows you to configure a trusted point with a selected name so that NCS 1004 can verify certificates issued to peers. NCS 1004 need not enroll with the CA that issued the certificates to the peers.</p> <p>The crypto ca trustpoint command enters trustpoint configuration mode, in which you can specify characteristics for the CA with a set of commands. See the Related Commands section for details.</p>
-------------------------	---

Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operations</th></tr> </thead> <tbody> <tr> <td>crypto execute</td><td></td></tr> </tbody> </table>	Task ID	Operations	crypto execute	
Task ID	Operations				
crypto execute					

Examples	The following example shows how to use the crypto ca trustpoint command to create a trustpoint:
-----------------	--

```
RP/0/0R0RSP0/CPU0:ios# configure
RP/0/0R0RSP0/CPU0:ios(config)# crypto ca trustpoint msiox
RP/0/0R0RSP0/CPU0:ios(config-trustp)# sftp-password xxxxxxx
RP/0/0R0RSP0/CPU0:ios(config-trustp)# sftp-username tmordeko
RP/0/0R0RSP0/CPU0:ios(config-trustp)# enrollment url
sftp://192.168..254.254/tftpboot/tmordeko/CAcert
RP/0/0R0RSP0/CPU0:ios(config-trustp)# rsakeypair label-2
```

This example shows how to create a default system trustpoint:

```
RP/0/0R0RSP0/CPU0:ios#configure
RP/0/0R0RSP0/CPU0:ios(config)#crypto ca trustpoint system-trustpoint
RP/0/0R0RSP0/CPU0:ios(config-trustp)#commit
```

Command	Description
enrollment retry count, on page 46	Specifies how many times NCS 1004 resends a certificate request.
enrollment retry period, on page 47	Specifies the wait period between certificate request retries.
enrollment terminal, on page 48	Specifies manual cut-and-paste certificate enrollment.
enrollment url, on page 48	Specifies the URL of the CA.
query url, on page 99	Specifies the LDAP URL of the CRL distribution point. Required only if your CA supports Lightweight Directory Access Protocol (LDAP).
rsakeypair, on page 101	Specifies a named RSA key pair for this trustpoint.
sftp-password (trustpoint), on page 102	Secures the FTP password.
sftp-username (trustpoint), on page 103	Secures the FTP username.
subject-name (trustpoint), on page 154	Specifies a subject name in the certificate request.

crypto key generate dsa

To generate Digital Signature Algorithm (DSA) key pairs, use the **crypto key generate dsa** command in EXEC mode.

crypto key generate dsa [{system-enroll-key | system-root-key}]

Syntax Description	system-enroll-key Specifies key pair generation for the leaf certificate. Note: Crypto key generation in Config Mode does not support this option.
system-root-key	Specifies key pair generation for the root certificate. Note: Crypto key generation in Config Mode does not support this option.
Command Default	None
Command Modes	EXEC mode
Command History	Release Modification Release 7.10.1 This command was introduced.
Usage Guidelines	Use the crypto key generate dsa command to generate DSA key pairs for your NCS 1004. DSA keys are generated in pairs—one public DSA key and one private DSA key. If NCS 1004 already has DSA keys when you issue this command, you are warned and prompted to replace the existing keys with new keys.

crypto key generate ecdsa

To remove the DSA key generated in Config mode, use **no** form of this command in Config mode.

To remove the DSA key generated in EXEC mode, use the **crypto key zeroize dsa** command.

Task ID	Task Operations ID
	crypto execute

Examples

The following example shows how to generate a 512-bit DSA key:

```
RP/0/RP0/CPU0:ios# crypto key generate dsa
The name for the keys will be: the_default
      Choose the size of your DSA key modulus. Modulus size can be 512, 768, or 1024 bits.
      Choosing a key modulus
      How many bits in the modulus [1024]: 512
      Generating DSA keys...
      Done w/ crypto generate keypair
      [OK]
```

This example shows how to generate a DSA key pair for the root certificate:

```
RP/0/RP0/CPU0:ios#crypto key generate dsa system-root-key
```

This example shows how to generate a DSA key pair for the leaf certificate:

```
RP/0/RP0/CPU0:ios#crypto key generate dsa system-enroll-key
```

The following example shows how to generate a 512-bit DSA key-pair in Config mode:

```
RP/0/RP0/CPU0:ios#conf t
RP/0/RP0/CPU0:ios(config)#crypto key generate dsa 512
RP/0/RP0/CPU0:ios(config)#commit
```

This example shows how to delete a DSA key-pair in Config mode:

```
RP/0/RP0/CPU0:ios# conf t
RP/0/RP0/CPU0:ios(config)#no crypto key generate dsa 512
RP/0/RP0/CPU0:ios(config)#commit
```

crypto key generate ecdsa

To generate an Elliptic Curve Digital Signature Algorithm (ECDSA) key pair, use the **crypto key generate ecdsa** command in EXEC mode.

```
crypto key generate ecdsa [{nistp256|nistp384|nistp521}] [{system-enroll-key|system-root-key}]
```

Syntax Description	
nistp256	Generates an ECDSA key of curve type nistp256, with key size 256 bits.
nistp384	Generates an ECDSA key of curve type nistp384, with key size 384 bits.
nistp521	Generates an ECDSA key of curve type nistp521, with key size 521 bits.

system-enroll-key Specifies key pair generation for the leaf certificate.

Note: Crypto key generation in Config Mode does not support this option.

system-root-key Specifies key pair generation for the root certificate.

Note: Crypto key generation in Config Mode does not support this option.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
------------------------	----------------	---------------------

Release	This command was introduced.
7.10.1	

Usage Guidelines To remove the ECDSA key generated in Config mode, use **no** form of this command in Config mode.

To remove an ECDSA key generated in EXEC mode, use the **crypto key zeroize ecdsa** command.

Task ID	Task ID	Operation
----------------	----------------	------------------

crypto	execute
--------	---------

Examples The following example shows how to generate an ECDSA key pair:

```
RP/0/RP0/CPU0:ios# crypto key generate ecdsa nistp384
Wed Mar 28 12:53:57.355 UTC
% You already have keys defined for the_default
Do you really want to replace them? [yes/no]: yes
Generating ECDSA keys ...
Done w/ crypto generate ECDSA keypair
[OK]
```

This example shows how to generate a ECDSA key pair for the root certificate:

```
RP/0/RP0/CPU0:ios#crypto key generate ecdsa system-root-key
```

This example shows how to generate a ECDSA key pair for the leaf certificate:

```
RP/0/RP0/CPU0:ios#crypto key generate dsa system-enroll-key
```

The following example shows how to generate an ECDSA key-pair in Config mode:

```
RP/0/RP0/CPU0:ios#conf t
RP/0/RP0/CPU0:ios(config)#crypto key generate ecdsa nistp256
RP/0/RP0/CPU0:ios(config)#commit
```

This example shows how to delete en ECDSA key-pair in Config mode:

crypto key generate ed25519

```
RP/0/RP0/CPU0:ios# conf t
RP/0/RP0/CPU0:ios(config)#no crypto key generate ecdsa nistp256
RP/0/RP0/CPU0:ios(config)#commit
```

crypto key generate ed25519

To generate Ed25519 crypto key pairs as part of supporting the Ed25519 public-key signature system, use the **crypto key generate ed25519** command in EXEC mode and Config mode.

```
crypto key generate ed25519 [{ system-enroll-key | system-root-key }]
```

Syntax Description

system-enroll-key Specifies key pair generation for the leaf certificate.

Note: Crypto key generation in Config mode does not support this option.

system-root-key Specifies key pair generation for the root certificate.

Note: Crypto key generation in Config mode does not support this option.

Command Default

None

Command Modes

EXEC mode and Config mode

Command History

Release

Modification

Release 7.10.1

This command was introduced.

Usage Guidelines

This command is applicable only for Cisco IOS XR 64-bit platforms.

To remove the Ed25519 key generated in Config mode, use **no** form of this command in Config mode.

To remove the Ed25519 key generated in EXEC mode, use the **crypto key zeroize ed25519** command.

You can generate the crypto keys either with an empty label or with two predefined labels (**system-root-key** and **system-enroll-key**). In case of empty label, the system generates the key pair against the default label. The key pairs with the predefined labels are used to integrate Cisco IOS XR with Cisco Crosswork Trust Insights.

Task ID

Task Operations ID

crypto execute

Examples

This example shows how to generate a Ed25519 crypto key pair:

```
RP/0/RP0/CPU0:ios# crypto key generate ed25519
Mon Nov 30 07:03:17.058 UTC
The name for the keys will be: the_default
Generating ED25519 keys ...
Done w/ crypto generate keypair
```

[OK]

This example shows how to generate a Ed25519 crypto key pair for the root certificate:

```
RP/0/RP0/CPU0:ios#crypto key generate ed25519 system-root-key
```

This example shows how to generate a Ed25519 crypto key pair for the leaf certificate:

```
RP/0/RP0/CPU0:ios#crypto key generate ed25519 system-enroll-key
```

The following example shows how to generate an Ed25519 key-pair in Config mode:

```
RP/0/RP0/CPU0:ios#conf t
RP/0/RP0/CPU0:ios(config)#crypto key generate ed25519
RP/0/RP0/CPU0:ios(config)#commit
```

This example shows how to delete en Ed25519 key-pair in Config mode:

```
RP/0/RP0/CPU0:ios# conf t
RP/0/RP0/CPU0:ios(config)#no crypto key generate ed25519
RP/0/RP0/CPU0:ios(config)#commit
```

Related Commands

Command	Description
crypto key zeroize ed25519, on page 39	Deletes Ed25519 crypto key pairs from NCS 1004.
show crypto key mypubkey ed25519, on page 110	Displays the Ed25519 public keys of NCS 1004.

crypto key generate rsa

To generate a Rivest, Shamir, and Adelman (RSA) key pair, use the **crypto key generate rsa** command in EXEC mode and Config mode.

```
crypto key generate rsa [{usage-keys | general-keys | system-enroll-key | system-root-key}]
[keypair-label]
```

Syntax Description

usage-keys	(Optional) Generates separate RSA key pairs for signing and encryption.
general-keys	(Optional) Generates a general-purpose RSA key pair for signing and encryption.
keypair-label	(Optional) RSA key pair label that names the RSA key pairs.
system-enroll-key	Specifies key pair generation for the leaf certificate. Note: Crypto key generation in Config mode does not support this option.
system-root-key	Specifies key pair generation for the root certificate. Note: Crypto key generation in Config mode does not support this option.

crypto key generate rsa

Command Default RSA key pairs do not exist.
If the **usage-keys** keyword is not used, general-purpose keys are generated. If no RSA label is specified, the key is generated as the default RSA key.

Command Modes EXEC mode and Config mode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Usage Guidelines Use the **crypto key generate rsa** command to generate RSA key pairs for NCS 1004.

RSA keys are generated in pairs—one public RSA key and one private RSA key.

If NCS 1004 already has RSA keys when you issue this command, you are warned and prompted to replace the existing keys with new keys. The keys generated by this command are saved in the secure NVRAM (which is not displayed to the user or backed up to another device).

To remove an RSA key generated in Config mode, use **no** form of this command in Config mode.

To remove an RSA key generated in EXEC mode, use the **crypto key zeroize rsa** command.

Task ID	Task Operations ID
----------------	---------------------------

crypto execute

Examples

The following example shows how to generate an RSA key pair:

```
RP/0/RP0/CPU0:ios# crypto key generate rsa
The name for the keys will be: the_default
Choose the size of the key modulus in the range of 360 to 2048 for your
General Purpose Keys. Choosing a key modulus greater than 512 may take
a few minutes.
How many bits in the modulus[1024]: <return>
RP/0/RP0/CPU0:ios#
```

This example shows how to generate an RSA key pair for the root certificate:

```
RP/0/RP0/CPU0:ios#crypto key generate rsa system-root-key
```

This example shows how to generate an RSA key pair for the leaf certificate:

```
RP/0/RP0/CPU0:ios#crypto key generate rsa system-enroll-key
```

The following example shows how to generate an RSA key-pair in Config mode:

```
RP/0/RP0/CPU0:ios#conf t
RP/0/RP0/CPU0:ios(config)#crypto key generate rsa user1 general-keys 2048
RP/0/RP0/CPU0:ios(config)#commit
```

This example shows how to delete an RSA key-pair in Config mode:

```
RP/0/RP0/CPU0:ios# conf t
RP/0/RP0/CPU0:ios(config)#no crypto key generate rsa user1 general-keys 2048
RP/0/RP0/CPU0:ios(config)#commit
```

crypto key import authentication rsa

To import a public key using the Rivest, Shamir, and Adelman (RSA) method, use the **crypto key import authentication rsa** command in EXEC mode.

crypto key import authentication rsa path

Syntax Description	<i>path</i> (Optional) This denotes the path to the RSA public key file.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	Release 7.10.1	This command was introduced.
Usage Guidelines	<ol style="list-style-type: none"> 1. Use ssh-keygen generation mechanism to generate keys using either a LINUX or UNIX client. This creates two keys: one public and one private. 2. Remove the comment and other header tag from the keys, except the base64encoded text. 3. Decode the base64encoded text, and use the for authentication. 	
Task ID	Task ID	Operations
		crypto execute

Examples

The following example displays how to import a public key:

```
RP/0/RP0/CPU0:ios:hostname#crypto key import authentication rsa
```

crypto key zeroize ed25519

To delete the Ed25519 crypto key pair from NCS 1004, use the **crypto key zeroize ed25519** command in EXEC mode.

crypto key zeroize ed25519

crypto key zeroize rsa

Syntax Description	This command has no keywords or arguments.							
Command Default	None							
Command Modes	EXEC mode							
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>		Release	Modification	Release 7.10.1	This command was introduced.		
Release	Modification							
Release 7.10.1	This command was introduced.							
Usage Guidelines	No specific guidelines impact the use of this command.							
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>crypto execute</td> <td></td> </tr> </tbody> </table>		Task ID	Operations	crypto execute			
Task ID	Operations							
crypto execute								
Examples	This example shows how to delete Ed25519 crypto key pairs from NCS 1004:							
<pre>RP/0/0RPO/RSP0/CPU0:ios# crypto key zeroize ed25519 % Keys to be removed are named the_default Do you really want to remove these keys? [yes/no]: yes</pre>								
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>crypto key generate ed25519, on page 36</td> <td>Generates Ed25519 crypto key pairs.</td> </tr> <tr> <td>show crypto key mypubkey ed25519, on page 110</td> <td>Displays the Ed25519 public keys of NCS 1004.</td> </tr> </tbody> </table>		Command	Description	crypto key generate ed25519, on page 36	Generates Ed25519 crypto key pairs.	show crypto key mypubkey ed25519, on page 110	Displays the Ed25519 public keys of NCS 1004.
Command	Description							
crypto key generate ed25519, on page 36	Generates Ed25519 crypto key pairs.							
show crypto key mypubkey ed25519, on page 110	Displays the Ed25519 public keys of NCS 1004.							

crypto key zeroize rsa

To delete all Rivest, Shamir, and Adelman (RSA) keys from NCS 1004, use the **crypto key zeroize rsa** command in EXEC mode.

crypto key zeroize rsa [keypair-label]

Syntax Description	<i>keypair-label</i> (Optional) Names the RSA key pair to be removed.					
Command Default	If the key pair label is not specified, the default RSA key pair is removed.					
Command Modes	EXEC mode					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>		Release	Modification	Release 7.10.1	This command was introduced.
Release	Modification					
Release 7.10.1	This command was introduced.					

Usage Guidelines

Use the **crypto key zeroize rsa** command to delete all RSA keys that were previously generated by NCS 1004. After issuing this command, you must perform two additional tasks:

- Ask the certification authority (CA) administrator to revoke the certificates for NCS 1004 at the CA; you must supply the challenge password you created when you originally obtained NCS 1004 certificates with the [crypto ca enroll](#), on page 30 command CA.
- Manually remove the certificates from the configuration using the **clear crypto ca certificates** command.

Task ID	Task Operations ID
	crypto execute

Examples

The following example shows how to delete the general-purpose RSA key pair that was previously generated:

```
RP/0/0RPO/RSP0/CPU0:ios:hostname# crypto key zeroize rsa key1
% Keys to be removed are named key1
Do you really want to remove these keys? [yes/no]: yes
```

destination address

To specify the destination address for Smart Call Home, use the **destination address** command in the call home profile configuration mode.

destination address *address*

Syntax Description

address Specifies the destination address for Smart Call Home.

The format is {http|https}://{FQDN}/its/service/oddce/services/DDCEService

FQDN must be either Cisco Smart Software Manager FQDN (tools.cisco.com) or Smart Licensing satellite server FQDN.

Command Default

None

Command Modes

Call home profile configuration mode

Command History

Release	Modification
---------	--------------

Release This command was introduced.
7.0.1

Usage Guidelines

You must configure the DNS server before setting-up the call-home destination address as FQDN. Use **domain name-server {DNS server IP}** command to configure the DNS server on the device.

The following example shows how to specify the destination address for Smart Call Home.

destination ipv4 unicast

```

domain name-server 192.0.2.6
call-home
service active
contact smart-licensing
profile CiscoTAC-1
active
destination address http https://tools.cisco.com/its/service/oddce/services/DDCEService

```

destination ipv4 unicast

To specify the destination of a GMPLS UNI tunnel, use the **destination ipv4 unicast** command in GMPLS UNI controller tunnel-properties configuration sub-mode.

destination ipv4 unicast *address*

Syntax Description	<i>address</i> Specifies the tunnel destination (IPv4 address).				
Command Default	None				
Command Modes	GMPLS UNI controller tunnel-properties configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following example shows how to specify a tunnel destination (10.10.3.4).

```

RP/0/RP0/CPU0:ios(config)#mpls traffic-eng
RP/0/RP0/CPU0:ios(config-mpls-te)#gmpls optical-uni
RP/0/RP0/CPU0:ios(config-te-gmpls)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:ios(config-te-gmpls-tun)#destination 10.10.3.4
RP/0/RP0/CPU0:ios(config-te-gmpls-tun)#

```

destination transport-method

To specify the destination transport method for Smart Call Home, use the **destination transport-method** command.

destination transport-method {http|email}

Syntax Description	email Enables an e-mail address for the profile.
	http Enables an HTTP URL for the profile.

Command Default	None				
Command Modes	Call home profile configuration mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.0.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command was introduced.
Release	Modification				
Release 7.0.1	This command was introduced.				
Usage Guidelines	For the user profile, both e-mail and http can be enabled. For the Cisco TAC profile, only one transport method can be enabled.				
The following example shows how to specify the destination transport method for Smart Call Home.					
<pre>domain name-server 192.0.2.6 call-home service active contact smart-licensing profile CiscoTAC-1 active destination address http https://tools.cisco.com/its/service/oddce/services/DDCEService destination transport-method http</pre>					

dh

To specify the Diffie-Hellman group for the IKEv2 proposal, use the **dh** command in IKEv2 proposal configuration mode.

dh dh-group

Syntax Description	<i>dh-group</i> DH group identifier. The possible values are 19, 20, and 21.				
Command Default	None				
Command Modes	IKEv2 proposal configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.0.1</td><td>This command is introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command is introduced.
Release	Modification				
Release 7.0.1	This command is introduced.				

Example

The following is a sample in which an IKEv2 proposal is configured.

```
RP/0/RP0/CPU0:ios#configure
Thu Mar  7 19:19:30.259 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 proposal proposal1
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#encryption aes-cbc-256
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#integrity sha-1
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#prf sha-256
```

```

RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#dh 20
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#commit
Thu Mar 7 19:20:30.916 UTC
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 proposal proposal1
Thu Mar 7 19:20:48.929 UTC

Proposal Name : proposal1
=====
Status : Complete
-----
Total Number of Enc. Alg. : 1
    Encr. Alg. : CBC-AES-256
-----
Total Number of Hash. Alg. : 1
    Hash. Alg. : SHA 1
-----
Total Number of PRF. Alg. : 1
    PRF. Alg. : SHA 256
-----
Total Number of DH Group : 1
    DH Group : Group 20

```

dwdm-carrier

To configure the wavelength on the trunk port, use the **dwdm-carrier** command in optics controller configuration mode. To return the wavelength to its default value, use the **no** form of this command.

dwdm-carrier { 100MHz-grid frequency frequency } | { 50GHz-grid frequency frequency }

Syntax Description	50Ghz-grid 100MHz-grid	Configures the wavelength in 50GHz grid and 100MHz (0.1GHz) grid spacing respectively in accordance with ITU definition.
	frequency frequency	Specifies the frequency for the optics controller.
Command Default	None	
Command Modes	Optics controller configuration	
Command History	Release	Modification
	Release 7.0.1	This command was introduced.
Usage Guidelines	The controller must be in the shutdown state before you can use the wavelength command.	

Example

The following example shows how to configure the frequency in 100MHz grid spacing.

```
RP/0/RP0/CPU0:ios# config
```

```
RP/0/RP0/CPU0:ios(config)# controller optics 0/0/0/0
RP/0/RP0/CPU0:ios(config-optics)# dwdm-carrier 100MHz-grid frequency 1865000
```

encryption

To specify the transform types for encryption, use the **encryption** command in the IKEv2 proposal configuration mode.

encryption *encryption-type*

Syntax Description	<i>encryption-type</i> Encryption algorithm. The possible values are aes-gcm-256, aes-gcm-128, aes-cbc-256, aes-cbc-192, and aes-cbc-128.				
Command Default	None				
Command Modes	IKEv2 proposal configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which an IKEv2 proposal is configured.

```
RP/0/RP0/CPU0:ios#configure
Thu Mar  7 19:19:30.259 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 proposal proposal1
RP/0/RP0/CPU0:ios(config-ikev2-proposal=proposal1)#encryption aes-cbc-256
RP/0/RP0/CPU0:ios(config-ikev2-proposal=proposal1)#integrity sha-1
RP/0/RP0/CPU0:ios(config-ikev2-proposal=proposal1)#prf sha-256
RP/0/RP0/CPU0:ios(config-ikev2-proposal=proposal1)#dh 20
RP/0/RP0/CPU0:ios(config-ikev2-proposal=proposal1)#commit
Thu Mar  7 19:20:30.916 UTC
RP/0/RP0/CPU0:ios(config-ikev2-proposal=proposal1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 proposal proposal1
Thu Mar  7 19:20:48.929 UTC

Proposal Name          : proposal1
=====
Status                : Complete
=====

Total Number of Enc. Alg.   : 1
    Encr. Alg.           : CBC-AES-256
=====

Total Number of Hash. Alg. : 1
    Hash. Alg.           : SHA 1
=====

Total Number of PRF. Alg.  : 1
    PRF. Alg.            : SHA 256
```

enrollment retry count

```
-----  
Total Number of DH Group : 1  
DH Group : Group 20
```

enrollment retry count

To specify the number of times a NCS 1004 resends a certificate request to a certification authority (CA), use the **enrollment retry count** command in trustpoint configuration mode. To reset the retry count to the default, use the **no** form of this command.

enrollment retry count *number*
no enrollment retry count *number*

Syntax Description	<i>number</i> Number of times NCS 1004 resends a certificate request when NCS 1004 does not receive a certificate from the previous request. The range is from 1 to 100.	
Command Default	If no retry count is specified, the default value is 10.	
Command Modes	Trustpoint configuration	
Command History	Release	Modification
	Release 7.10.1	This command was introduced.
Usage Guidelines	After requesting a certificate, NCS 1004 waits to receive a certificate from the CA. If NCS 1004 does not receive a certificate within a specified time (the retry period), NCS 1004 sends another certificate request. NCS 1004 continues to send requests until it receives a valid certificate, the CA returns an enrollment error, or the configured number of retries (the retry count) is exceeded. To reset the retry count to the default of 10, use the no form of this command. Setting the retry count to 0 indicates an infinite number of retries. NCS 1004 sends the CA certificate requests until a valid certificate is received (there is no limit to the number of retries).	
Task ID	Task ID	Operations
	crypto	read, write

Examples	The following example shows how to declare a CA, change the retry period to 10 minutes, and change the retry count to 60 retries. NCS 1004 resends the certificate request every 10 minutes until receipt of the certificate or approximately 10 hours pass since the original request was sent, whichever occurs first (10 minutes x 60 tries = 600 minutes = 10 hours).
-----------------	---

```
RP/0/0R0RSP0/CPU0:ios:hostname# configure  
RP/0/0R0RSP0/CPU0:ios:hostname(config)# crypto ca trustpoint myca  
RP/0/0R0RSP0/CPU0:ios:hostname(config-trustp)# enrollment url http://ca_server
```

```
RP/0/0RPO0SP0/CPU0:ios:hostname(config-trustp)# enrollment retry period 10
RP/0/0RPO0SP0/CPU0:ios:hostname(config-trustp)# enrollment retry count 60
```

enrollment retry period

To specify the wait period between certificate request retries, use the **enrollment retry period** command in trustpoint configuration mode. To reset the retry period to the default of 1 minute, use the **no** form of this command.

enrollment retry period *minutes*
no enrollment retry period *minutes*

Syntax Description	<i>minutes</i> Period (in minutes) between certificate requests issued to a certification authority (CA) from NCS 1004. The range is from 1 to 60 minutes.
---------------------------	--

Command Default	<i>minutes: 1</i>
------------------------	-------------------

Command Modes	Trustpoint configuration
----------------------	--------------------------

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Usage Guidelines	After requesting a certificate, NCS 1004 waits to receive a certificate from the CA. If NCS 1004 does not receive a certificate within a specified time (the retry period), NCS 1004 sends another certificate request. NCS 1004 continues to send requests until it receives a valid certificate, the CA returns an enrollment error, or the configured number of retries (the retry count) is exceeded.
-------------------------	---

NCS 1004 sends the CA another certificate request every minute until a valid certificate is received. (By default, NCS 1004 sends ten requests, but you can change the number of permitted retries with the **enrollment retry count** command.)

Task ID	Task ID	Operations
		crypto read, write

Examples	The following example shows how to declare a CA and change the retry period to 5 minutes:
-----------------	---

```
RP/0/0RPO0SP0/CPU0:ios:hostname# configure
RP/0/0RPO0SP0/CPU0:ios:hostname(config)# crypto ca trustpoint myca
RP/0/0RPO0SP0/CPU0:ios:hostname(config-trustp)# enrollment retry period 5
```

enrollment terminal

To specify manual cut-and-paste certificate enrollment, use the **enrollment terminal** command in trustpoint configuration mode. To delete a current enrollment request, use the **no** form of this command.

enrollment terminal
no enrollment terminal

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Trustpoint configuration
----------------------	--------------------------

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Usage Guidelines	You can manually cut and paste certificate requests and certificates when you do not have a network connection between NCS 1004 and certification authority (CA). When the enrollment terminal command is enabled, NCS 1004 displays the certificate request on the console terminal, which allows you to enter the issued certificate on the terminal.
-------------------------	--

Task ID	Task Operations ID
	crypto read, write

Examples	The following example shows how to manually specify certificate enrollment through cut-and-paste. In this example, the CA trustpoint is myca.
-----------------	---

```
RP/0/0RPO/RSP0/CPU0:ios:hostname# configure
RP/0/0RPO/RSP0/CPU0:ios:hostname(config)# crypto ca trustpoint myca
RP/0/0RPO/RSP0/CPU0:ios:hostname(config-trustp)# enrollment terminal
```

enrollment url

To specify the certification authority (CA) location by naming the CA URL, use the **enrollment url** command in trustpoint configuration mode. To remove the CA URL from the configuration, use the **no** form of this command.

enrollment url CA-URL
no enrollment url CA-URL

Syntax Description	<i>CA-URL</i> URL of the CA server. The URL string must start with http://CA_name, where CA_name is the host Domain Name System (DNS) name or IP address of the CA (for example, http://ca-server). If the CA cgi-bin script location is not /cgi-bin/pkiclient.exe at the CA (the default CA cgi-bin script location), you must also include the nonstandard script location in the URL, in the form of http://CA-name/script-location, where script-location is the full path to the CA scripts.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Trustpoint configuration
----------------------	--------------------------

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Usage Guidelines	Use the enrollment url command to specify the CA URL. This command is required when you declare a CA with the crypto ca trustpoint command. The URL must include the CA script location if the CA scripts are not loaded into the default cgi-bin script location. The CA administrator should be able to tell you where the CA scripts are located.
-------------------------	--

This table lists the available enrollment methods.

Table 1: Certificate Enrollment Methods

Enrollment Method	Description
SFTP	Enroll through SFTP: file system
TFTP ¹	Enroll through TFTP: file system

¹ If you are using TFTP for enrollment, the URL must be in the form tftp://certserver/file_specification. (The file specification is optional.)

TFTP enrollment sends the enrollment request and retrieves the certificate of the CA and the certificate of NCS 1004. If the file specification is included in the URL, NCS 1004 appends an extension to the file specification.

To change the CA URL, repeat the **enrollment url** command to overwrite the previous URL

Task ID	Task Operations
	crypto read, write

Examples	The following example shows the absolute minimum configuration required to declare a CA:
-----------------	--

```
RP/0/0RPO/RSP0/CPU0:ios:hostname# configure
RP/0/0RPO/RSP0/CPU0:ios:hostname(config)#crypto ca trustpoint myca
RP/0/0RPO/RSP0/CPU0:ios:hostname(config-trustp)#enrollment url
http://ca.domain.com/certsrv/mscep/mscep.dll
```

fault-profile

Use the **fault-profile** command in the global configuration mode, to create a new fault profile with one or more alarms and user-defined severity.

```
fault-profile name fault-identifier subsystem XR fault-type { ethernet | sdh_controller | sonet | OPTICS | G709 } fault-tag name sas severity nsas severity
```

Syntax Description	fault-profile name Name of the fault profile. fault-identifier subsystem XR Supports the XR sub-system. fault-type The component the fault profile is applicable to. The available options are: <ul style="list-style-type: none"> • ethernet • sdh_controller • sonet • OPTICS • G709
fault-tag name	The faults that are included as part of the newly created fault profile.
sas severity nsas severity	Sets the severity level for: <ul style="list-style-type: none"> • sas (service affecting; impacts traffic) • nsas (non-service affecting; does not impact traffic) The available options are: <ul style="list-style-type: none"> • Critical • Major • Minor • Non-faulted • Non-reported
Command Default	No default behavior or values.
Command Modes	Global Configuration

Command History	Release	Modification
	Release 7.1.1	This command was introduced.
	Release 7.2.1	

Example

The following example shows how to use the **fault profile** command.

```
RP/0/RP0/CPU0: router (config) # fault profile f1 fault-identifier subsystem XR fault-type
HW_OPTICS fault-tag OPTICAL_LO_RXPOWER sas CRITICAL nsas CRITICAL
```

fault-profile apply

Use the **fault-profile apply** command in the global configuration mode, to apply a fault profile at the node level or card levelport level or node level.

fault-profile name apply rack0 slot location

Syntax Description	fault-profile name Name of the fault profile.
	rack 0 slot location Sets the profile at the node level or line card levelport level or node level.

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Global Configuration
----------------------	----------------------

Command History	Release	Modification
	Release 7.1.1	This command was introduced.
	Release 7.2.1	

Example

The following example shows how to use the **fault profile apply** command.

```
RP/0/RP0/CPU0:ios(config) # fault profile f1 apply rack 0 slot ALL
```

The following example shows how to use the **fault profile apply** command at the port level.

```
RP/0/RP0/CPU0:ios(config) # fault profile f1 apply rack 0 slot LC0 port 1
```

The following example shows how to use the **fault profile apply** command at the node level.

```
RP/0/RP0/CPU0:ios(config) # fault profile f1 apply rack 0 slot ALL
```

mpls optical-uni

mpls optical-uni

To enable GMPLS UNI feature, use the **mpls optical-uni** command in LMP configuration mode.

mpls optical-uni

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	LMP configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.
Usage Guidelines	The LMP submode enables GMPLS-UNI LMP functionality and acts as a container for other GMPLS-UNI LMP configuration commands.	

Example

The following example shows how to enable GMPLS UNI and enter LMP configuration mode.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp)#mpls optical-uni
RP/0/RP0/CPU0:ios(config-lmp-gmpls)#

```

http client connection

To configure the connection for http client, use the **http client connection** command in XR Config mode. To restore the default value, use the **no** form of this command.

http client connection { retry count | timeout seconds }

Syntax Description	retry count	Specifies how many times HTTP Client resends a connection request. Range is from 1 to 5. The default value is 0.
	timeout seconds	The time interval (in seconds) that HTTP client waits for a server connection to establish before giving up. Range is from 1 to 60 seconds. The default value is 10 seconds.
Command Default	The connection retry is not configured by default. The default connection timeout is set to 10 seconds.	

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Command Modes	HTTP configuration
---------------	--------------------

Usage Guidelines	Use this command to set the connection timeout or connection retry count.
------------------	---

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to configure the connection request retry to two times:

```
RP/0/RP0/CPU0:router(config)#http client connection retry 2
```

The following example shows how to configure the connection request timeout to 20 seconds:

```
RP/0/RP0/CPU0:router(config)#http client connection timeout 20
```

http client response

To configure the time interval (in seconds) for HTTP Client to wait for a response from the server before giving up, use the **http client response** command in XR Config mode. To restore the default value, use the **no** form of this command.

http client response { timeout seconds }

Syntax Description	timeout <i>seconds</i>	The time interval (in seconds) that HTTP client waits for a response from the server before giving up. Range is from 1 to 300 seconds. The default value is 30 seconds.
Command Default	The response timeout is 30 seconds by default.	
Command History	Release	Modification
	Release	Modification
	Release 7.10.1	This command was introduced.
Command Modes	HTTP configuration	
Usage Guidelines	Use this command to configure the response timeout.	
Task ID	Task ID	Operations
	config-services	read, write

http client ssl

The following example shows how to configure the response timeout to 40 seconds:

```
RP/0/RP0/CPU0:router(config)#http client response timeout 40
```

http client ssl

To configure Secure Socket Layer (SSL) version to be used for HTTPS requests, use the **http client ssl** command in XR Config mode. To restore the default value, use the **no** form of this command.

http client ssl *version*

Syntax Description

ssl *version* Specify the SSL version to be used for HTTPS requests. Select one of the following versions:

- **tls1.0** - Forces TLSv1.0 to be used for HTTPS requests.
- **tls1.1** - Forces TLSv1.1 to be used for HTTPS requests.
- **tls1.2** - Forces TLSv1.2 to be used for HTTPS requests.

By default libcurl does not force the TLS version.

Command History

Release	Modification
Release 7.10.1	This command was introduced.

Command Default

By default, the SSL version is not configured.

Command Modes

HTTP configuration

Usage Guidelines

Use this command to configure the ssl version to be used in HTTPS requests.

Task ID

Task ID	Operations
config-service	read, write

The following example shows how to configure the SSL version to tls1.1:

```
RP/0/RP0/CPU0:router(config)#http client ssl tls1.1
```

http client secure-verify-host

To enable verifying host in peer's certificate, use the **http client secure-verify-host** command in XR Config mode. To restore the default value, use the **no** form of this command.

http client secure-verify-host

Syntax Description	secure-verify-host Verifies the host in peer's certificate. This is enabled by default. To disable, use the command http client secure-verify-host disable	
Command Default	Host verification is enabled by default.	
Command History	Release	Modification
	Release 7.10.1	This command was introduced.
Command Modes	HTTP configuration	
Usage Guidelines	Use the http client secure-verify-host command to disable the host verification.	
Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to disable host verification :

```
RP/0/RP0/CPU0:router(config)#http client secure-verify-host disable
```

http client secure-verify-peer

To enable verifying authenticity of the peer certificate, use the **http client secure-verify-peer** command in XR Config mode. To restore the default value, use the **no** form of this command.

http client secure-verify-peer

Syntax Description	secure-verify-peer Verifies authenticity of the peer certificate. This is enabled by default. To disable, use the command http client secure-verify-peer disable	
Command Default	Peer verification is enabled by default.	
Command History	Release	Modification
	Release 7.10.1	This command was introduced.
Command Modes	HTTP configuration	
Usage Guidelines	Use the http client secure-verify-peer command to disable the peer verification.	

http client source interface

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to disable peer verification :

```
RP/0/RP0/CPU0:router(config)#http client secure-verify-peer disable
```

http client source interface

To specify the interface for source address for Hypertext Transfer Protocol (HTTP) connections, use the **http client source-interface** command in XR Config mode. To remove the **http client source-interface** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

http client source-interface { ipv4 | ipv6 }

Syntax Description	ipv4 <i>ip-address</i>	Enter ipv4 address from interface.
	ipv6 <i>ip-address</i>	Enter ipv6 address from interface.

Command Default No default behavior or values.

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Command Modes HTTP configuration

Usage Guidelines Use the **http client source-interface** command to configure ipv4 and ipv6 source interfaces. If both the source interfaces are configured, then the source interface is selected depending on the host DNS resolution.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to configure ipv4 source interface for HTTP connection:

```
RP/0/RP0/CPU0:router(config)#http client source-interface ipv4 gigabitEthernet 0/0/0/0
```

The following example shows how to configure ipv6 source interface for HTTP connection:

```
RP/0/RP0/CPU0:router(config)#http client source-interface ipv6 gigabitEthernet 0/0/0/0
```

http client tcp-window-scale

To configure the TCP window scale factor for high latency links, use the **http client tcp-window-scale** command in XR Config mode. To restore the default value, use the **no** form of this command.

http client tcp-window-scale *scale*

Syntax Description	<i>scale</i> Specify the TCP window scale for HTTP requests. Range is 1 to 14.
---------------------------	--

Command Default	By default, TCP window scale is disabled.
------------------------	---

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Command Modes	HTTP configuration
----------------------	--------------------

Usage Guidelines	Use this command to configure the TCP window scale for HTTP requests.
-------------------------	---



Note	Currently, this is enabled for copying of files using HTTP.
-------------	---

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to set the TCP window scale to 10:

```
RP/0/RP0/CPU0:router(config)#http client tcp-window-scale 10
```

http client version

To configure the HTTP version to be used for HTTP requests, use the **http client version** command in XR Config mode. To restore the default value, use the **no** form of this command.

http client version *version*

http client vrf

Syntax Description	version <i>version</i> Specify the HTTP version to be used for HTTP requests. Select one of the following versions: <ul style="list-style-type: none"> • 1.0 - Forces HTTP1.0 to be used for all HTTP requests. • 1.1 - Forces HTTP1.1 to be used for all HTTP requests. • default - libcurl picks up HTTP version automatically. 				
Command Default	By default, libcurl does not force the HTTP version.				
Note	 HTTP Client uses libcurl version 7.30				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.10.1	This command was introduced.
Release	Modification				
Release 7.10.1	This command was introduced.				
Command Modes	HTTP configuration				
Usage Guidelines	Use this command to configure the HTTP version to be used in HTTP requests.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	config-services	read, write
Task ID	Operations				
config-services	read, write				

The following example shows how to configure the HTTP version to 1.1:

```
Router(config)#http client version 1.1
```

http client vrf

To configure a new VRF to be used by the HTTP client, use the **http client vrf** command. To remove the specified vrf, use the **no** form of this command.

```
http client vrf vrf-name
```

Syntax Description	<i>vrf-name</i> Specifies the name of the VRF to be used by the HTTP client.				
Command Default	If not configured, the default VRF "default-vrf" will be used.				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.10.1	This command was introduced.
Release	Modification				
Release 7.10.1	This command was introduced.				

Command Modes	HTTP configuration				
Usage Guidelines	A HTTP client can have only one VRF. If a specific VRF is not configured for the HTTP client, the default VRF is assumed.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operations</th></tr> </thead> <tbody> <tr> <td>config-services</td><td>read, write</td></tr> </tbody> </table>	Task ID	Operations	config-services	read, write
Task ID	Operations				
config-services	read, write				
	The following example shows the HTTP client being configured to start with the specified VRF:				

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# http client vrf green
```

http-proxy

To configure the Call Home HTTP proxy server, use the **http-proxy** command in the call home profile configuration mode.

http-proxy proxy-server-name port port-number

Syntax Description	<i>proxy-server-name</i> Specifies the name of the proxy server.
	<i>port-number</i> Specifies the port for the specified HTTP proxy server.

Command Default None

Command Modes Call home profile configuration mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines None

The following example configures the call home HTTP proxy server :

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#call-home
RP/0/RP0/CPU0:ios(config-call-home)#http-proxy aa.bbb.cc.dd port 100
```

hw-module

To configure the card in the module (muxponder), slice configuration (muxponder slice), or regen mode, use the **hw-module** command in Cisco IOS XR configuration mode.

```
hw-module location location { mxponder | mxponder-slice mxponder-slice-number { trunk-mode [ZR | OR] } } client-rate [100GE | OTU4] trunk-rate [50G | 100G | 150G | 200G | 250G | 300G | 350G | 400G | 450G | 500G | 550G | 600G] [drop-lldp] [client-port-ains-soak hours minutes minutes] }
hw-module location location { regen trunk-rate trunk-rate regen-slice slice-number }
hw-module location location mxponder arp-snoop
hw-module location location attention-led all-ports | port-number
hw-module location location { mxponder | mxponder-slice mxponder-slice-number { trunk-rate [100G | 200G | 300G | 400G] { client-type [100G | OTU4] | [client-port-rate [2-5] | [6-9]] | client-type [100GE | OTU4]] } } }
```

Syntax Description		
location <i>location</i>		Specifies the location of the optics controller.
mxponder		Configures the card in muxponder mode.
mxponder-slice <i>mxponder-slice-number</i>		Configures the card in muxponder slice configuration. Slice numbers can be 0 or 1.
trunk-mode [ZR OR]		Specifies the trunk mode when using a Bright ZR+ pluggable module as the trunk pluggable on a QXP card. Use ZR for ethernet and OR for OTN datapath.
client-rate [100GE OTU4]		Specifies the traffic rate on the client ports. The supported client rates are 100GE and OTU4.
trunk-rate [50G 100G 150G 200G 250G 300G 350G 400G 450G 500G 550G 600G]		Specifies the traffic rate on the trunk ports. The supported trunk rates are 150G, 200G, 250G, 300G, 350G, 400G, 450G, 500G, 550G, and 600G. From R7.2.1, you can configure trunk rates of 50G, 100G, and 150G to support Binary Phase-Shift Keying (BPSK) modulation.
Note		The 150G, 250G, 350G, 450G, and 550G data rates can be configured only in the muxponder card mode.
drop-lldp		Enables LLDP drop on a muxponder or muxponder slice.

client-port-ains-soak <i>hours hours minutes minutes</i>	Specifies the AINS configuration in hours and minutes.
regen trunk-rate <i>trunk-rate</i>	Configures the card in Regen mode. The supported trunk rates are 100G to 600G in multiples of 100G.
regen-slice <i>slice-number</i>	Specify the slice number on which you want to enable regen mode. The supported trunk rates are 100G to 400G in multiples of 100G. Valid values: <ul style="list-style-type: none">• QXP Card: 0 to 5 (Only alternate slices can be configured.)
arp-snoop	Configures MAC address or ARP snoop on the client ports.
attention-ledall-ports <i>port-number</i>	Turns on the attention LED on all the ports or on a specific port of the line card.
trunk-rate	Specifies the traffic rate on the trunk ports. The supported trunk rates is 100G, 200G, 300G, and 400G.
client-port-rate <i>client-port-number</i>	Specifies client port number. <ul style="list-style-type: none">• Mxponder-slice 0—Client ports 2, 3, 4, and 5 are mapped to the trunk port 0.• Mxponder-slice 1—Client ports 6, 7, 8, and 9 are mapped to the trunk port 1.
client-type [100GE OTU4]	Specifies the traffic type on the client ports. The supported client types are 100GE and OTU4.

Command Default

No slice is configured.

You must configure the card mode before enabling LLDP drop.

Command Modes

Cisco IOS XR Configuration

Command History**Release Modification**

Release 7.0.1 This command was introduced.

Release	Modification
Release 7.1.1	regen keyword was added.
Release 7.2.1	arp-snoop keyword was added.
Release 7.3.1	trunk-rate 50G 100G keyword options are introduced.
Release 7.7.1	attention-led keyword was introduced.
Release 7.10.1	regen-slice, client-port-rate [2-5] [6-9], client-type <100GE OTU4>, trunk-mode [ZR OR] keywords were introduced.

Example

The following is a sample in which the card is configured in the muxponder mode with 100GE client payload and 500G trunk payload.

```
RP/0/RP0/CPU0:ios#configure
Sun Feb 24 14:09:33.989 UTC
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2 mxponder client-rate 100GE
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2 mxponder trunk-rate 500G
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the card is configured in the muxponder mode with a 550G trunk payload.

```
RP/0/RP0/CPU0:ios#config
Tue Oct 15 01:24:56.355 UTC
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder client-rate 100GE
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder trunk-rate 550G
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the card is configured in the muxponder mode with OTU4 client payload and 500G trunk payload.

```
RP/0/RP0/CPU0:ios#configure
Sun Feb 24 14:09:33.989 UTC
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2 mxponder client-rate OTU4
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2 mxponder trunk-rate 500G
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the card is configured in the muxponder slice 0 mode with a 300G trunk payload.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 0 client-rate 100GE
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 0 trunk-rate 300G
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the card is configured in the muxponder slice 1 mode with a 400G trunk payload.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 1 client-rate 100GE
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 1 trunk-rate 400G
RP/0/RP0/CPU0:ios(config)#commit
```

The following example shows how to configure LLDP drop on a muxponder slice.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config) #hw-module location 0/1 mxponder-slice 0 drop-lldp
```

The following is a sample in which all the client ports are configured with AINS with soak time as 15 minutes.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config) #hw-module location 0/3 mxponder client-rate 100GE trunk-rate 500G
RP/0/RP0/CPU0:ios(config) #hw-module location 0/3 mxponder client-port-ains-soak hours 0
minutes 15
RP/0/RP0/CPU0:ios(config) #commit
```

The following is a sample to configure the card in Regen mode.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config) #hw-module location 0/0
RP/0/RP0/CPU0:ios(config-hwmod) #regen
RP/0/RP0/CPU0:ios(config-regen) #trunk-rate 400
RP/0/RP0/CPU0:ios(config-regen) #commit
RP/0/RP0/CPU0:ios(config-regen) #exit
```

The following is a sample to configure regen mode on slices 0, 2, and 4 with a 400G trunk rate on each slice of the QXP card.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config) #hw-module location 0/3 regen-slice 0
RP/0/RP0/CPU0:ios(config-regen) #trunk-rate 400G
RP/0/RP0/CPU0:ios(config) #hw-module location 0/3 regen-slice 2
RP/0/RP0/CPU0:ios(config-regen) #trunk-rate 400G
RP/0/RP0/CPU0:ios(config) #hw-module location 0/3 regen-slice 4
RP/0/RP0/CPU0:ios(config-regen) #trunk-rate 400G
RP/0/RP0/CPU0:ios(config-regen) #commit
```

The following is a sample in which the 2-QDD-C card is configured with mixed client rates in the muxponder slice 1 and 0 modes.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 23 06:10:22.227 UTC
RP/0/RP0/CPU0:ios(config) #hw-module location 0/1 mxponder-slice 0 client-rate OTU4 trunk-rate
400G
RP/0/RP0/CPU0:ios(config) #hw-module location 0/1 mxponder-slice 1 client-rate 100GE trunk-rate
400G
RP/0/RP0/CPU0:ios(config) #commit
```

The following is a sample in which the 2-QDD-C card is configured with mixed client rates in the same muxponder slice 0 mode.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 23 06:10:22.227 UTC
RP/0/RP0/CPU0:ios(config) #hw-module location 0/1 mxponder-slice 0 client-port-rate 2
client-type OTU4 trunk-rate 400G
RP/0/RP0/CPU0:ios(config) #hw-module location 0/1 mxponder-slice 0 client-port-rate 3
client-type 100GE trunk-rate 400G
RP/0/RP0/CPU0:ios(config) #commit
```

The following is a sample to configure MAC address or ARP snoop on client ports for Mxponder mode configuration.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 16 19:08:17.154 UTC
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder arp-snoop
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample to configure MAC address snoop on client ports for slice mode configuration.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 16 19:30:33.933 UTC
RP/0/RP0/CPU0:ios(config)#hw-module location 0/3 mxponder-slice 0
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-rate 100GE
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-rate 600G
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#arp-snoop
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
Mon Mar 16 19:30:52.636 UTC
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#end
```

The following example shows how to configure trunk rate to 50G:

```
RP/0/RP0/CPU0:(config)#hw-module location 0/0 mxponder
RP/0/RP0/CPU0:(config-hwmod-mxp)#trunk-rate 50G
RP/0/RP0/CPU0:(config-hwmod-mxp)#commit
```

hw-module (OTN-XP Card)

To configure the OTN-XP card in the muxponder mode, use the **hw-module** command in IOS XR configuration mode.

```
hw-module location location mxponder-slice mxponder-slice-number trunk-rate [100G | 200G | 300G | 400G] client-port-rate client-port-number lane lane number client-type [10GE | OTU2 | OTU2e | 400GE | FC16 | FC32 | oc192 | stm64]
hw-module location location attention-led all-ports | port-number
```

Syntax Description	location <i>location</i>	Specifies the location of the optics controller.
	mxponder-slice <i>mxponder-slice-number</i>	Configures the card in muxponder mode. The muxponder configuration supports two slices, 0 and 1.
	protected	Enables the Automatic Protection System on the OTN XP card.
	trunk-rate	Specifies the traffic rate on the trunk ports. The supported trunk rates is 100G, 200G, 300G, and 400G.

client-port-rate <i>client-port-number</i>	Specifies client port number.														
	<ul style="list-style-type: none"> • Mxponder-slice 0—Client ports 4, 5, and 2 are mapped to the trunk port 0. • Mxponder-slice 1—Client ports 7, 6, and 11 are mapped to the trunk port 1. 														
lane <i>lane-number</i>	Specifies client port lane number.														
client-type [10GE OTU2 OTU2e 400GE FC16 FC32 oc192 stm64]	Specifies the traffic type on the client ports. The supported client types are 10GE, OTU2, OTU2e, FC16, FC32, OC192, STM64, and 400GE.														
attention-ledall-ports <i>port-number</i>	Turns on the attention LED on all the ports or on a specific port of the line card.														
Command Default	None														
Command Modes	Cisco IOS XR Configuration														
Command History	<table> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.2.1</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 7.3.2</td> <td>The trunk rates 200G, 300G and 400G were introduced.</td> </tr> <tr> <td>Release 7.3.2</td> <td>The client type 400GE was introduced.</td> </tr> <tr> <td>Release 7.5.2</td> <td>The client types FC16 and FC32 were introduced.</td> </tr> <tr> <td>Release 7.7.1</td> <td>attention-led keyword was introduced.</td> </tr> <tr> <td>Release 7.10.1</td> <td>The client types OC192 and STM64 were introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.2.1	This command was introduced.	Release 7.3.2	The trunk rates 200G, 300G and 400G were introduced.	Release 7.3.2	The client type 400GE was introduced.	Release 7.5.2	The client types FC16 and FC32 were introduced.	Release 7.7.1	attention-led keyword was introduced.	Release 7.10.1	The client types OC192 and STM64 were introduced.
Release	Modification														
Release 7.2.1	This command was introduced.														
Release 7.3.2	The trunk rates 200G, 300G and 400G were introduced.														
Release 7.3.2	The client type 400GE was introduced.														
Release 7.5.2	The client types FC16 and FC32 were introduced.														
Release 7.7.1	attention-led keyword was introduced.														
Release 7.10.1	The client types OC192 and STM64 were introduced.														

The following is a sample in which the OTN-XP card is configured with mixed client rates in the mxponder-slice 0 mode.

```
RP/0/RP0/CPU0:ios#config
Tue Apr 21 09:21:44.460 UTC
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 0
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-rate 100G
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 2 lane 3 client-type OTU2
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 2 lane 4 client-type OTU2
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 4 lane 1 client-type 10GE
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
```

hw-module (OTN-XP Card)

The following sample configures inverse muxponder for 400GE over 2x200G CFP2 trunk ports.

```
RP/0/RP0/CPU0:ios(config)#hw-module location 0/0 mxponder
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-rate 200G
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 client-type 400GE
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
```

The following sample configures 300G trunk rate on the OTN-XP card::

```
RP/0/RP0/CPU0:ios#config
Wed Jun 2 17:17:59.409 UTC
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 0
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-rate 300G
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
```

The following is a sample to configure 16G FC muxponder mode on slice 0 of the OTN-XP card:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2 mxponder-slice 0
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-rate 400G
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 1 lane 1 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 1 lane 2 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 1 lane 3 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 1 lane 4 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 6 lane 1 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 6 lane 2 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 6 lane 3 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 6 lane 4 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 7 lane 1 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 7 lane 2 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 7 lane 3 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 7 lane 4 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 9 lane 1 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 9 lane 2 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 9 lane 3 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 9 lane 4 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 lane 1 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 lane 2 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 lane 3 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 lane 4 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 11 lane 1 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 11 lane 2 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 11 lane 3 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 11 lane 4 client-type fc16
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
Fri Feb 4 16:06:59.967 UTC
RP/0/RP0/CPU0:ios(config-hwmod-mxp) #
```

The following is a sample to configure 32G FC muxponder mode on slice 0 of the OTN-XP card:

```
RP/0/RP0/CPU0:ios#configure
Fri Feb 4 16:24:53.964 UTC
RP/0/RP0/CPU0:ios(config)#
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2 mxponder-slice 0
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-rate 400G
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 6 lane 1 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 6 lane 2 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 6 lane 3 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 6 lane 4 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 7 lane 1 client-type fc32
```

```

RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 7 lane 2 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 7 lane 3 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 7 lane 4 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 lane 1 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 lane 2 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 lane 3 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-port-rate 10 lane 4 client-type fc32
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
Fri Feb 4 16:26:46.550 UTC
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#

```

ikev2 policy

To specify an IKEv2 policy name, use the **ikev2 policy** command in configuration mode.

ikev2 policy *policy-name*

Syntax Description	<i>policy-name</i> IKEv2 policy name upto 32 characters.				
Command Default	None				
Command Modes	Configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which an IKEv2 policy is configured.

```

RP/0/RP0/CPU0:ios#configure
Thu Mar  7 19:26:45.752 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 policy mypolicy
RP/0/RP0/CPU0:ios(config-ikev2-policy-mypolicy)#proposal proposalall
RP/0/RP0/CPU0:ios(config-ikev2-policy-mypolicy)#match address local 10.0.0.1
RP/0/RP0/CPU0:ios(config-ikev2-policy-mypolicy)#commit
Thu Mar  7 19:29:25.043 UTC
RP/0/RP0/CPU0:ios(config-ikev2-policy-mypolicy)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 policy mypolicy
Thu Mar  7 19:30:30.343 UTC

Policy Name : mypolicy
=====
Total number of match local addr : 1
      Match address local       : 10.0.0.1
-----
Total number of proposal attached : 1
      Proposal Name             : proposalall

```

ikev2 profile

To configure an IKEv2 profile, use the **ikev2 profile** command in configuration mode.

ikev2 profile *profile-name keyring ppk name*

Syntax Description

<i>profile-name</i>	Name of the IKEv2 profile.
keyring ppk	It specifies that ppk needs to be used and which keyring has the ppk configuration.
<i>name</i>	name of the keyring configured.

Command Default

None

Command Modes

Configuration

Command History

Release	Modification
Release 7.0.1	This command is introduced.
Release 24.1.1	The key word keyring ppk was introduced.

Example

The following is a sample in which an IKEv2 profile is configured.

```
RP/0/RP0/CPU0:ios#configure
Thu Mar 7 20:00:36.490 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 profile profile1
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#match identity remote address 10.0.0.1
255.255.0
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#keyring kyr1
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#lifetime 120
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#commit
Thu Mar 7 20:15:03.401 UTC
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 profile profile1
Thu Mar 7 20:15:25.776 UTC

Profile Name : profile1
=====
Keyring : kyr1
Lifetime(Sec) : 120
DPD Interval(Sec) : 10
DPD Retry Interval(Sec) : 2
Match ANY : NO
Total Match remote peers : 1
Addr/Prefix : 10.0.0.1/255.255.255.0
```

The following is a sample in which keyring ppk is specified in the IKEv2 profile.

```
RP/0/1/CPU0:ios(config)#ikev2 profile test
RP/0/1/CPU0:ios(config-ikev2-profile-test)#keyring dynamic
```

```
RP/0/1/CPU0:ios(config-ikev2-profile-test)#keyring ppk dynamic
RP/0/1/CPU0:ios(config-ikev2-profile-name)#match address 10.0.0.1 255.255.255.0
```

ikev2 proposal

To specify an IKEv2 proposal name, use the **ikev2 proposal** command in the configuration mode .

ikev2 proposal *proposal-name*

Syntax Description	<i>proposal-name</i> Name of IKEv2 proposal upto 32 characters.				
Command Default	None				
Command Modes	Configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which an IKEv2 proposal is configured.

```
RP/0/RP0/CPU0:ios#configure
Thu Mar  7 19:19:30.259 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 proposal proposal1
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#encryption aes-cbc-256
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#integrity sha-1
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#prf sha-256
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#dh 20
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#commit
Thu Mar  7 19:20:30.916 UTC
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 proposal proposal1
Thu Mar  7 19:20:48.929 UTC

Proposal Name          : proposal1
=====
Status                : Complete
-----
Total Number of Enc. Alg. : 1
      Encr. Alg.       : CBC-AES-256
-----
Total Number of Hash. Alg. : 1
      Hash. Alg.        : SHA 1
-----
Total Number of PRF. Alg. : 1
      PRF. Alg.         : SHA 256
-----
Total Number of DH Group : 1
      DH Group          : Group 20
```

integrity

To specify one or more transforms of the integrity algorithm type, use the **integrity** command in IKEv2 proposal configuration mode.

integrity *algorithm-type*

Syntax Description	<i>algorithm-type</i> Integrity algorithm type. The possible values are: sha-1, sha-256, sha-384, and sha-512.				
Command Default	None				
Command Modes	IKEv2 proposal configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which an IKEv2 proposal is configured.

```

RP/0/RP0/CPU0:ios#configure
Thu Mar  7 19:19:30.259 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 proposal proposal1
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#encryption aes-cbc-256
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#integrity sha-1
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#prf sha-256
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#dh 20
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#commit
Thu Mar  7 19:20:30.916 UTC
RP/0/RP0/CPU0:ios(config-ikev2-proposal-proposal1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 proposal proposal1
Thu Mar  7 19:20:48.929 UTC

Proposal Name          : proposal1
-----
Status                : Complete
-----
Total Number of Enc. Alg.   : 1
    Encr. Alg.        : CBC-AES-256
-----
Total Number of Hash. Alg. : 1
    Hash. Alg.       : SHA 1
-----
Total Number of PRF. Alg.  : 1
    PRF. Alg.        : SHA 256
-----
Total Number of DH Group  : 1
    DH Group         : Group 20

```

interface gcc0

To configure the GCC0 interface, use the **interface gcc0** command in configuration mode.

interface gcc0 R/S/I/P

Syntax Description	<i>R/S/I/P</i> Rack/Slot/Instance/Port of the GCC0 interface.	
Command Default	None	
Command Modes	Configuration	
Command History	Release	Modification
	7.1.1	This command is introduced.

Example

The following is a sample to configure the GCC0 interface using the static IP address.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#interface gcc0 0/1/0/0
RP/0/RP0/CPU0:ios(config-if)#ipv4 address 10.1.1.1 255.255.255.0
RP/0/RP0/CPU0:ios(config-if)#commit
RP/0/RP0/CPU0:ios(config-if)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show run interface gcc0 0/1/0/0
interface GCC0/1/0/0
  ipv4 address 10.1.1.1 255.255.255.0
!
```

The following is a sample to configure the GCC0 interface using the loopback IP address.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:R2(config)#interface gcc0 0/1/0/0
RP/0/RP0/CPU0:R2(config-if)#ipv4 unnumbered loopback 0
RP/0/RP0/CPU0:ios(config-if)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

interface gcc2

To configure the GCC2 interface, use the **interface gcc2** command in configuration mode.

interface gcc2 R/S/I/P/L

Syntax Description	<i>R/S/I/P/L</i> Rack/Slot/Instance/Port/Lane of the GCC2 interface.
---------------------------	--

ipcc routed

Command Default	None	
Command Modes	Configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following is a sample to configure the GCC2 interface using the static IP address.

```
RP/0/RP0/CPU0:ios#config
Tue Mar 12 11:16:04.749 UTC
RP/0/RP0/CPU0:ios(config)#interface gcc2 0/1/0/0/1
RP/0/RP0/CPU0:ios(config-if)#ipv4 address 10.0.0.1 255.255.255.0
RP/0/RP0/CPU0:ios(config-if)#commit
Tue Mar 12 11:18:32.867 UTC
RP/0/RP0/CPU0:ios(config-if)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show run interface gcc2 0/1/0/0/1
Tue Mar 12 11:19:00.475 UTC
interface gcc2 0/1/0/0/1
  ipv4 address 10.0.0.1 255.255.255.0
!
```

The following is a sample to configure the GCC2 interface using the loopback IP address.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:R2(config)#interface gcc2 0/1/0/0/1
RP/0/RP0/CPU0:R2(config-if)#ipv4 unnumbered loopback 0
RP/0/RP0/CPU0:ios(config-if)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

ipcc routed

To specify the LMP neighbor IPCC configuration for GMPLS UNI, use the **ipcc routed** command in the neighbor sub-mode for LMP GMPLS-UNI controller configuration mode.

ipcc routed

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	LMP GMPLS-UNI controller neighbor configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Usage Guidelines

The LMP submode enables GMPLS-UNI LMP functionality and acts as a container for other GMPLS-UNI LMP configuration commands.

Example

The following example shows how to specify the IPCC configuration for the GMPLS UNI controller 0/0/0/0, neighbor UN02.

```
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp)#mpls optical-uni
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)#neighbor UN02
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-nbr-UN02)#ipcc routed
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-nbr-UN02)#

```

ipv4 access-group

To configure the Access List (ACL), use the **ipv4 access-group** command at the IPv4 interface in the interface configuration mode.

ipv4 access-group *access-list-name* { **ingress** | **egress** }

Syntax Description

access-list-name Access list name. Names cannot contain a space or quotation marks.

ingress Specifies an inbound interface.

egress Specifies an outbound interface.

Command Default

No IPv4 access list is defined.

Command Modes

Interface configuration

Command History**Release** **Modification**

Release 7.0.1 This command is introduced.

Usage Guidelines

Use the **ipv4 access-list** command to configure an IPv4 access list. This command places the system in access list configuration mode, in which the denied or permitted access conditions must be defined with the **deny** or **permit** command.

Example

The following examples shows how to configure the Access List at the IPv4 interface in the configuration mode:

```
interface MgmtEth0/RP0/CPU0/0
ipv4 address 10.1.1.1 255.255.255.0
ipv4 access-group IPV4_ICMP_DENY ingress
ipv4 access-group IPV4_ROUTER_FWD_TELNET_TRAFFIC_DENY egress
```

ipv6 access-group**Sample Configuration for IPv4 Access Lists**

```
 ipv4 access-list IPV4_ICMP_DENY
 10 deny icmp any any
 20 permit ipv4 any any
 !
 ipv4 access-list IPV4_ROUTER_FWD_TELNET_TRAFFIC_DENY
 10 deny tcp any any eq telnet
 20 permit ipv4 any any
 !
```

ipv6 access-group

To configure the Access List (ACL), use the **ipv6 access-group** command at the IPv6 interface in the interface configuration mode.

ipv6 access-group *access-list-name* { ingress | egress }

Syntax Description	<i>access-list-name</i> Access list name. Names cannot contain a space or quotation marks.				
ingress	Specifies an inbound interface.				
egress	Specifies an outbound interface.				
Command Default	No IPv6 access list is defined.				
Command Modes	Interface configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.0.1</td><td>This command is introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command is introduced.
Release	Modification				
Release 7.0.1	This command is introduced.				

Usage Guidelines	Use the ipv6 access-list command to configure an IPv6 access list. This command places the system in access list configuration mode, in which the denied or permitted access conditions must be defined with the deny or permit command.
-------------------------	---

Example

The following examples shows how to configure the Access List at the IPv6 interface in the configuration mode

```
interface MgmtEth0/RP0/CPU0/0
ipv6 address 1000::1/64
ipv6 access-group IPV6_SSH_DENY ingress
ipv6 access-group IPV6_ROUTER_FWD_TELNET_TRAFFIC_DENY egress
```

Sample Configuration for IPv6 Access Lists

```
 ipv6 access-list IPV6_SSH_DENY
 10 deny tcp any any eq ssh
 20 permit ipv6 any any
```

```

!
ipv6 access-list IPV6_ROUTER_FWD_TELNET_TRAFFIC_DENY
10 deny tcp any any eq telnet
20 permit ipv6 any any
!

```

keyring

To specify the keyring name, use the **keyring** command in the configuration mode.

keyring peer name ppk { manual | dynamic } { address *ipv4 mask* pre-shared-key { clear *clear-text key* | local *local key* | password *encrypted key* } [required] }

Syntax Description

keyring-name	Name of the keyring upto 32 characters.
peer name	Specifies the name of the peer interface
ppk [dynamic manual]	Specifies whether the Postquantum Preshared Keys (PPK) is dynamic or manual.
address <i>ipv4 mask</i>	Specifies the ip address of the peer interface along with the mask.
pre-shared-key	Configures the pre-shared keys for authentication.
clear <i>clear-text key</i>	Specifies that the preshared key for OTNSec communication is in cleartext format.
local <i>local key</i>	Specifies that the preshared key for OTNSec communication is a local passphrase.
password <i>encrypted key</i>	Specifies that the preshared key for OTNSec communication is an encrypted string in hexadecimal format.
required	Specifies whether dynamic ppk configuration is required or not.

Command Default

None

Command Modes

Configuration

Command History

Release	Modification
Release 7.0.1	This command is introduced.
Release 24.1.1	The keyword ppk [dynamic manual] was introduced.

Example 1

The following is a sample in which a keyring is configured.

```

RP/0/RP0/CPU0:ios#conf
Thu Mar  7 19:33:14.594 UTC
RP/0/RP0/CPU0:ios(config)#keyring kyr1
RP/0/RP0/CPU0:ios(config-keyring-kyr1)#peer peer1
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#address 10.0.0.1 255.255.255.0
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#pre-shared-key password 14341B180F547B7977

```

lc-module (OTN-XP Card)

```
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#commit
Thu Mar 7 19:54:33.314 UTC
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#exit
RP/0/RP0/CPU0:ios(config-keyring-kyr1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show keyring kyr1
Thu Mar 7 19:58:07.135 UTC
```

Keyring Name	: kyr1
Total Peers	: 1
Peer Name	: peer1
IP Address	: 10.0.0.1
Subnet Mask	: 255.255.255.0
Local PSK	: Configured
Remote PSK	: Configured

Example 2

The following is a sample in which the dynamic ppk is configured.

```
RP/0/RP0/CPU0:ios#configure terminal
RP/0/RP0/CPU0:ios(config)#keyring dynamic
RP/0/RP0/CPU0:ios(config-ikev2-keyring)#peer peer1
RP/0/RP0/CPU0:ios(config-ikev2-keyring-peer)#ppk dynamic qkd required
RP/0/RP0/CPU0:ios(config-ikev2-keyring-peer)#pre-shared-key cisco123!cisco123
RP/0/RP0/CPU0:ios(config-ikev2-keyring-peer)#address 10.0.0.1 255.0.0.0

RP/0/1/CPU0:ios(config)#ikev2 profile test
RP/0/1/CPU0:ios(config-ikev2-profile-test)#keyring dynamic
RP/0/1/CPU0:ios(config-ikev2-profile-test)#keyring ppk dynamic
RP/0/1/CPU0:ios(config-ikev2-profile-name)#match address 10.0.0.1 255.255.255.0
```

Example 3

The following is a sample in which the manual ppk is configured.

```
RP/0/RP0/CPU0:ios#configure terminal
RP/0/RP0/CPU0:ios(config)#keyring manual
RP/0/RP0/CPU0:ios(config-ikev2-keyring)#peer peer1
RP/0/RP0/CPU0:ios(config-ikev2-keyring-peer)#ppk manual id cisco123 key password
060506324F41584B56 required
RP/0/RP0/CPU0:ios(config-ikev2-keyring-peer)#pre-shared-key cisco123!cisco123
RP/0/RP0/CPU0:ios(config-ikev2-keyring-peer)#address 10.0.0.1
255.0.0.0RP/0/1/CPU0:ios(config)#ikev2 profile test

RP/0/1/CPU0:ios(config-ikev2-profile-test)#keyring manual
RP/0/1/CPU0:ios(config-ikev2-profile-test)#keyring ppk manual
RP/0/1/CPU0:ios(config-ikev2-profile-name)#match address 10.0.0.1 255.255.255.0
RP/0/RP0/CPU0:ios(config-ikev2-keyring-peer)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

lc-module (OTN-XP Card)

To configure the LC mode on the OTN-XP card, use the **lc-module** command in IOS XR configuration mode.

lc-module location *location* lcmode *mode*

Syntax Description	location <i>location</i>	Specifies the location of the optics controller.
	lcmode <i>mode</i>	Configures the line card mode. The LC modes supported on the OTN-XP card are: <ul style="list-style-type: none">• 10G-GREY-MXP• 40x10G-4x100G-MXP• 4x100G-MXP-400G-TXP• FC-MXP• OTUCn-REGEN
		Note Only 10G-GREY-MXP is supported in Release 7.2.1 even though all the above modes are software configurable.
Command Default	None	
Command Modes	Cisco IOS XR Configuration	
Command History	Release	Modification
	Release 7.2.1	This command was introduced.
	Release 7.5.2	The LC modes FC-MXP and OTUCn-REGEN were introduced.

Example

The following is a sample in which the OTN-XP card is configured in the 10G-GREY-MXP mode.

```
RP/0/RP0/CPU0:ios#configure
Thu Mar 26 21:40:51.495 UTC
RP/0/RP0/CPU0:ios(config)#lc-module location 0/1 lcmode 10G-GREY-MXP
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the OTN-XP card is configured in the FC-MXP mode.

```
RP/0/RP0/CPU0:ios#configure
Fri Feb 4 16:06:59.967 UTC
```

license smart register

```
RP/0/RP0/CPU0:ios(config)#lc-module location 0/1 lcmode FC-MXP
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the OTN-XP card is configured in the OTUCn-REGEN mode.

```
RP/0/RP0/CPU0:ios#configure
Fri Feb 4 16:06:59.967 UTC
RP/0/RP0/CPU0:ios(config)#lc-module location 0/1 lcmode OTUCn-REGEN
RP/0/RP0/CPU0:ios(config)#commit
```

license smart register

To register the device instance with Cisco licensing cloud, use the **license smart register idtoken *token-id*** **force** command.

license smart register idtoken *token-id* [force]

Syntax Description

token_id Specifies the token generated in smart manager.

force If the registration fails due to communication failure between the device and the portal or satellite, the system waits for 24 hours before attempting to register the device again. Use this option to force the registration.

Command Default

None

Command Modes

None

Command History**Release Modification**

Release	This command was introduced.
7.0.1	

Usage Guidelines

Use this command to register the device instance with Cisco licensing cloud.

The following example registers and sets the token ID required for registration of NCS 1004.

```
RP/0/RP0/CPU0:ios#license smart register token-id
```

license smart renew

To manually renew the ID certification or authorization, use the **license smart renew** command.

license smart renew id { ID|auth }

Syntax Description

ID ID certificates are renewed automatically after six months. In case, the renewal fails, the product instance goes into unidentified state. You can manually renew the ID certificate using this option.

auth Authorization periods are renewed by the Smart Licensing system every 30 days. As long as the license is in an 'Authorized' or 'Out-of-compliance' (OOC), the authorization period is renewed. Use this command to make an on-demand manual update of your registration. Thus, instead of waiting 30 days for the next registration renewal cycle, you can use this option to instantly find out the status of your license.

After 90 days, the authorization period expires and the status of the associated licenses display "AUTH EXPIRED". Use this option to retry the authorization period renewal. If the retry is successful, a new authorization period begins.

Command Default	None
------------------------	------

Command Modes	None
----------------------	------

Command History	Release Modification
	R7.0.1 This command was introduced.

Usage Guidelines	None
-------------------------	------

The following example manually renews the ID certificate for NCS 1004.

```
RP/0/RP0/CPU0:ios#license smart renew id
```

The following example manually renews the authorization for NCS 1004.

```
RP/0/RP0/CPU0:ios#license smart renew auth
```

license smart deregister

To cancel the registration of your device, use the **license smart deregister** command.

license smart deregister

Command Default	None
------------------------	------

Command Modes	None
----------------------	------

Command History	Release Modification
	R7.0.1 This command was introduced.

Usage Guidelines	When your device is taken off the inventory, shipped elsewhere for redeployment or returned to Cisco for replacement using the return merchandise authorization (RMA) process, you can use this command to cancel the registration on your device. All smart licensing entitlements and certificates on the platform are removed.
-------------------------	---

The following example deregisters NCS 1004.

```
RP/0/RP0/CPU0:ios#license smart deregister
```

lifetime

To configure the lifetime of IKEv2 security association (SA), use the **lifetime** command in IKEv2 profile configuration mode.

lifetime seconds

Syntax Description	<i>seconds</i> Specifies the lifetime in seconds. The range is from 120 to 86400 seconds.				
Command Default	None				
Command Modes	IKEv2 profile configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which an IKEv2 profile is configured.

```

RP/0/RP0/CPU0:ios#configure
Thu Mar  7 20:00:36.490 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 profile profile1
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#match identity remote address 10.0.0.1
255.255.255.0
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#keyring kyrl
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#lifetime 120
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#commit
Thu Mar  7 20:15:03.401 UTC
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 profile profile1
Thu Mar  7 20:15:25.776 UTC

Profile Name : profile1
=====
Keyring : kyrl
Lifetime (Sec) : 120
DPD Interval(Sec) : 10
DPD Retry Interval(Sec) : 2
Match ANY : NO
Total Match remote peers : 1
Addr/Prefix : 10.0.0.1/255.255.255.0

```

link-id ipv4 unicast

To specify the local optical interface address for an LMP link for a GMPLS UNI controller, use the **link-id ipv4 unicast** command in GMPLS-UNI controller configuration mode.

link-id ipv4 unicast address

Syntax Description	<i>address</i> Specifies the optical unicast IPv4 address.	
Command Default	None	
Command Modes	LMP GMPLS-UNI controller configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following example shows how to specify the local optical interface address for an LMP link.

```
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp)#gmpls optical-uni
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-ctrl)#link-id ipv4 unicast 10.11.1.1
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-ctrl)#+
```

Imp

To enable functionality for GMPLS UNI LMP and enter LMP configuration commands, use the **Imp** command in global configuration mode.

Imp

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following example shows how to enable LMP functionality and enter the sub-mode for LMP configuration commands.

```
RP/0/RP0/CPU0:ios#configure
```

match address local

```
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp) #
```

match address local

To specify the IP address of the local node, use the **match address local** command in the IKEv2 policy configuration mode.

match address local *ipv4-address*

Syntax Description	<i>ipv4-address</i> IP address of the local node.				
Command Default	None				
Command Modes	IKEv2 policy configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which an IKEv2 policy is configured.

```
RP/0/RP0/CPU0:ios#configure
Thu Mar  7 19:26:45.752 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 policy mypolicy
RP/0/RP0/CPU0:ios(config-ikev2-policy-mypolicy)#proposal proposal1
RP/0/RP0/CPU0:ios(config-ikev2-policy-mypolicy)#match address local 10.0.0.1
RP/0/RP0/CPU0:ios(config-ikev2-policy-mypolicy)#commit
Thu Mar  7 19:29:25.043 UTC
RP/0/RP0/CPU0:ios(config-ikev2-policy-mypolicy)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 policy mypolicy
Thu Mar  7 19:30:30.343 UTC

Policy Name : mypolicy
=====
Total number of match local addr : 1
Match address local : 10.0.0.1
-----
Total number of proposal attached : 1
Proposal Name : proposal1
```

match identity remote address

To specify the IP address of the remote node, use the **match identity remote address** command in IKEv2 profile configuration mode.

```
match identity remote address { ipv4-address [ subnet-mask ] }
```

Syntax Description	<i>ipv4-address</i> IP address of the remote node. <i>subnet-mask</i> Subnet mask address.				
Command Default	None				
Command Modes	IKEv2 profile configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which an IKEv2 profile is configured.

```
RP/0/RP0/CPU0:ios#configure
Thu Mar  7 20:00:36.490 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 profile profile1
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#match identity remote address 10.0.0.1
255.255.255.0

RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#keyring kyr1
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#lifetime 120
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#commit
Thu Mar  7 20:15:03.401 UTC
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 profile profile1
Thu Mar  7 20:15:25.776 UTC

Profile Name : profile1
=====
Keyring : kyr1
Lifetime (Sec) : 120
DPD Interval (Sec) : 10
DPD Retry Interval (Sec) : 2
Match ANY : NO
Total Match remote peers : 1
Addr/Prefix : 10.0.0.1/255.255.255.0
```

neighbor interface-id unnumbered

neighbor interface-id unnumbered

To specify the neighbor's optical interface ID of an LMP link for a GMPLS UNI controller, use the **neighbor interface-id unnumbered** command in GMPLS-UNI controller configuration mode.

neighbor interface-id unnumbered *interface-id*

Syntax Description	<i>interface-id</i> Specifies the optical interface ID of the neighbor.	
Command Default	None	
Command Modes	LMP GMPLS-UNI controller configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following example shows how to specify the optical interface ID of an LMP neighbor.

```
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp)#gmpls optical-uni
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-ctrl)#neighbor interface-id unnumbered 2130706976
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-ctrl)#
```

neighbor link-id ipv4 unicast

To specify the neighbor's optical address of an LMP link for a GMPLS UNI controller, use the **neighbor link-id ipv4 unicast** command in GMPLS-UNI controller configuration mode.

neighbor link-id ipv4 unicast *address*

Syntax Description	<i>address</i> Specifies the IPv4 address of the neighbor.	
Command Default	None	
Command Modes	LMP GMPLS-UNI controller configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following example shows how to specify the optical IPv4 address (10.1.1.1) of an LMP neighbor for controller 0/0/0/0:

```
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp)#gmpls optical-uni
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-ctrl)#neighbor link-id ipv4 unicast 10.1.1.1
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-ctrl)#+
```

neighbor

To specify an LMP neighbor for GMPLS and enter commands to configure the neighbor, use the **neighbor** command in the LMP GMPLS-UNI configuration mode.

neighbor *name*

Syntax Description	<i>name</i> Specifies the name of the LMP neighbor.				
Command Default	None				
Command Modes	LMP GMPLS-UNI configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td></tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				
Usage Guidelines	Under the LMP GMPLS UNI submode, this command creates a submode in which other properties of the neighbor can be specified.				

Example

The following example shows how to specify the neighbor UN01 for the GMPLS-UNI controller 0/0/0/0.

```
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp)#gmpls optical-uni
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)#neighbor UN01
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-nbr-UN01)#exit
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-cnt1)#neighbor UN01
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-cnt1)#+
```

otnsec policy

otnsec policy

To configure an OTNSec policy, use the **otnsec policy** command in the configuration mode.

otnsec policy *policy-name*

Syntax Description	<i>policy-name</i>	Policy name
Command Default	None	
Command Modes	Configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following is a sample in which an OTNSec policy is configured.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 11 15:16:58.417 UTC
RP/0/RP0/CPU0:ios(config)#otnsec policy otnsec-policy1
RP/0/RP0/CPU0:ios(config-otnsec-policy)#cipher-suite AES-GCM-256
RP/0/RP0/CPU0:ios(config-otnsec-policy)#security-policy must-secure
RP/0/RP0/CPU0:ios(config-otnsec-policy)#sak-rekey-interval 120
RP/0/RP0/CPU0:ios(config-otnsec-policy)#commit
```

The following is a sample of an OTNSec policy.

```
RP/0/RP0/CPU0:ios#show run otnsec policy otnsec-policy1
Tue Mar 12 11:14:03.591 UTC
otnsec policy otnsec-policy1
  cipher-suite AES-GCM-256
  security-policy must-secure
  sak-rekey-interval 120
!
```

path-option

To specify a path option for a GMPLS UNI tunnel, use the **path-option** command in GMPLS UNI controller tunnel-properties configuration sub-mode.

path-option 10 { no-ero | explicit { name *path-name* | index *index* } } [xro-attribute-set *name*] [lockdown] [verbatim]

Syntax Description	10	Specifies the path option index. 10 is the only supported index
---------------------------	-----------	---

explicit	Specifies that LSP paths are IP explicit paths.
name <i>path-name</i>	Specifies the path name of the IP explicit path.
no-ero	Specifies that no ERO object is included in signalling.
xro-attribute-set (Optional)	Specifies the xro attribute set for the path option.
<i>name</i>	Specifies the name of the xro-attribute-set.
lockdown	(Optional) Indicates that the tunnel does not reoptimize without user intervention.
verbatim	(Optional) Bypasses the topology check for explicit paths.

Command Default	None
------------------------	------

Command Modes	GMPLS UNI controller tunnel-properties configuration
----------------------	--

Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following example shows how to specify the tunnel path option for controller 0/0/0/0, attribute set A01..

```
RP/0/RP0/CPU0:ios(config)#mpls traffic-eng
RP/0/RP0/CPU0:ios(config-mpls-te)#mpls optical-uni
RP/0/RP0/CPU0:ios(config-te-gmpls)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:ios(config-te-gmpls-tun)#path-option 10 no-ero xro-attribute-set A01 lockdown
RP/0/RP0/CPU0:ios(config-te-gmpls-tun)#

```

peer

To specify the peer node during keyring configuration, use the **peer** command in keyring configuration mode.

peer *peer-name*

Syntax Description	<i>peer-name</i> Peer node name.
---------------------------	----------------------------------

Command Default	None
------------------------	------

Command Modes	Keyring configuration
----------------------	-----------------------

pki trustpoint

Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following is a sample in which a keyring is configured.

```
RP/0/RP0/CPU0:ios#conf
Thu Mar  7 19:33:14.594 UTC
RP/0/RP0/CPU0:ios(config)#keyring kyr1
RP/0/RP0/CPU0:ios(config-keyring-kyr1)#peer peer1
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#address 10.0.0.1 255.255.255.0
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#pre-shared-key key1|clear
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#commit
Thu Mar  7 19:54:33.314 UTC
RP/0/RP0/CPU0:ios(config-keyring-kyr1-peer-peer1)#exit
RP/0/RP0/CPU0:ios(config-keyring-kyr1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show keyring kyr1
Thu Mar  7 19:58:07.135 UTC

Keyring Name          : kyr1
=====
Total Peers           : 1
-----
Peer Name             : peer1
IP Address            : 10.0.0.1
Subnet Mask           : 255.255.255.0
Local PSK              : Configured
Remote PSK             : Configured
```

pki trustpoint

To specify the trustpoints for use with the RSA signature authentication method, use the **pki trustpoint** command in IKEv2 profile configuration mode

pki trustpoint *trustpoint-label*

Syntax Description	<i>trustpoint-label</i> Specifies the name of the trustpoint.				
Command Default	None				
Command Modes	IKEv2 profile configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>R7.2.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	R7.2.1	This command was introduced.
Release	Modification				
R7.2.1	This command was introduced.				

Example

The following example shows how to specify the authentication mode in the IKEv2 profile.

```
RP/0/RP0/CPU0:ios#configure
Thu May 7 16:22:33.804 IST
RP/0/RP0/CPU0:ios(config)#ikev2 profile IP1
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#match identity remote address 10.1.1.2
255.255.255.255
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#pki trustpoint myca
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#lifetime 120
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#authentication local rsa-signature
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#authentication remote rsa-signature
RP/0/RP0/CPU0:ios(config-ikev2-profile-IP1)#commit
```

pm

To configure the performance monitoring parameters of the optics, Ethernet, and coherent DSP controllers, use the **pm** command in the controller configuration mode.

pm [15-min | 30-sec | 24-hour] [optics | ether | pcs | fec | otn] [report | threshold] value

Syntax Description	15-min 30-sec 24-hour	Configures performance monitoring parameters for 15 minute or 30 second or 24 hour intervals.
	optics ether pcs fec otn	Specifies whether to configure performance monitoring parameters for the optics, Ethernet, or coherent DSP controllers.
	report	Configures optics TCA reporting status.
	threshold	Configures threshold on optics parameters.
	value	Value of the reporting or threshold parameters.

Command Default	None
------------------------	------

Command Modes	Controller configuration
----------------------	--------------------------

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines	The following table describes the optics PM parameters.
Parameter	
cd	Chromatic dispersion TCA reporting status or threshold
dgd	Differential group delay TCA reporting status or threshold

Parameter	Description
lbc	lbc TCA reporting status or threshold
lbc-pc	lbc percentage TCA reporting status or threshold
low-freq-off	low signal frequency offset TCA reporting status or threshold
opr	opr/opr-dbm TCA reporting status or threshold
opt	opt/opt-dbm TCA reporting status or threshold
osnr	Optical Signal to Noise Ratio TCA reporting status or threshold
pcr	Polarization Change Rate TCA reporting status or threshold
pdl	Polarization Dependent Loss TCA reporting status or threshold
pn	Phase Noise TCA reporting status or threshold
rx-sig-pow	rx signal power TCA reporting status or threshold
sopmd	Second Order Polarization Mode Dispersion TCA reporting status or threshold

The following table describes the OTN PM parameters.

Parameter	Description
ES-NE	Error seconds in the near end
ESR-NE	Error seconds ratio in the near end
SES-NE	Severely error seconds in the near end
SESR-NE	Severely error seconds ratio in the near end
UAS-NE	Unavailable seconds in the near end
BBE-NE	Background block errors in the near end
BBER-NE	Background block errors ratio in the near end
FC-NE	Failure counts in the near end
ES-FE	Error seconds in the far end
ESR-FE	Error seconds ratio in the far end
SES-FE	Severely error seconds in the far end
SESR-FE	Severely error seconds ratio in the far end
UAS-FE	Unavailable seconds in the far end
BBE-FE	Background block errors in the far end
BBER-FE	Background block errors ratio in the far end

Parameter	Description
FC-FE	Failure counts in the far end

The following table describes the Ethernet PM parameters.

Parameter	Description
rx-util	Bandwidth utilization of port at the ingress side in percentage.
tx-util	Bandwidth utilization of port at egress side in percentage.
rx-pkt	Number of received packets
stat-pkt	Status of received packets
octet-stat	Total number of octets of data received in the network
oversize-pkt	Total number of packets received that were longer than 1518 octets and were otherwise well formed
jabber-stats	Total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad FCS with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error)
in-64-octets	Total number of packets received that were 64 octets in length
in-65-127-octets	Total number of packets received that were between 65 and 127 octets in length
in-128-255-octets	Total number of packets received that were between 128 and 255 octets in length
in-256-511-octets	Total number of packets received that were between 256 and 511 octets in length
in-512-1023-octets	Total number of packets received that were between 512 and 1023 octets in length
in-1024-1518-octets	Total number of packets received that were between 1024 and 1518 octets in length
in-mcast	Total number of multicast frames received error-free
in-bcast	Total number of broadcast frames received error-free
out-bcast	Total number of broadcast frames transmitted error-free
out-mcast	Total number of multicast frames transmitted error-free
tx-pkt	Number of transmitted packets
out-octets	Total number of octets transmitted out of the interface, including framing characters
ether-stat-multicast-pkt	Status of multicast packets

Parameter	Description
ether-stat-broadcast-pkt	Status of broadcast packets
ether-stat-undersized-pkt	Number of good packets received that are shorter than 64 bytes.
in-error-frgments	Number of bad packets received that are shorter than 64 bytes.
tx-undersized-pkt	Total number of packets transmitted that are shorter than 64 bytes.
tx-oversized-pkt	Total number of oversized packets transmitted.
tx-frgments	Total number of fragmented packets transmitted.
tx-jabber	Total number of Jabber packets transmitted.
tx-bad-fcs	Total number of bad FCS packets transmitted.
fcs-err	A count of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check.
ifIn-Octets	Total number of octets received on the interface, including framing characters.
ifIn-errors	Number of inbound packets that contained errors preventing them from being delivered to a higher-layer protocol.
in-good-bytes	Total number of good bytes or octets received.
in-good-pkts	Total number of good packets received.
long-frame	A count of frames received on a particular interface that exceed the maximum permitted frame size.
out-good-bytes	Total number of good bytes or octets transmitted
out-good-pkts	Total number of good packets transmitted.
1024-1518-octets	Total number of packets (including error packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).
128-255-octets	Total number of packets (including error packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).
256-511-octets	Total number of packets (including error packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).
512-1023-octets	Total number of packets (including error packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).
64-octets	Total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).

Parameter	Description
65-127-octets	Total number of packets (including error packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

The following table describes the FEC PM parameters.

Parameter	Description
ec-words	Number of bit errors that are corrected by the system
uc-words	Number of words that are not corrected by the system

The following table describes the PCS PM parameters.

Parameter	Description
PCS-ES	Error seconds
PCS-SES	Severly error seconds
PCS-UAS	Unavailable seconds
PCS-ES-FE	Error seconds in far end
PCS-SES-FE	Severly error seconds in far end
PCS-UAS-FE	Unavailable seconds in far end

Example

The following is a sample in which the performance monitoring parameters of optics controller is configured in 24 hour intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller optics 0/0/1/1 pm 24-hour optics threshold osnr max
345
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which the performance monitoring parameters of the ethernet controller is configured in 15 minute intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/3/0/2 pm 15-min pcs report bip
enable
RP/0/RP0/CPU0:ios(config)#commit
```

The following is a sample in which performance monitoring parameters of Coherent DSP controller is configured in 30 second intervals.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/0/1/1 pm 30-sec fec threshold post-fec-ber
max OE-15
RP/0/RP0/CPU0:ios(config)#commit
```

prf

To specify the Pseudo-Random Function (PRF) algorithm type, use the **prf** command in IKEv2 proposal configuration mode.

prf prf-algorithm

Syntax Description	<i>prf-algorithm</i> PRF algorithm type. The possible values are sha-1, sha-256, sha-384, and sha-512.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	IKEv2 proposal configuration
----------------------	------------------------------

Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following is a sample in which an IKEv2 proposal is configured.

```

RP/0/RP0/CPU0:ios#configure
Thu Mar  7 19:19:30.259 UTC
RP/0/RP0/CPU0:ios(config)#ikev2 proposal proposal1
RP/0/RP0/CPU0:ios(config-ikev2=proposal=proposal1)#encryption aes-cbc-256
RP/0/RP0/CPU0:ios(config-ikev2=proposal=proposal1)#integrity sha-1
RP/0/RP0/CPU0:ios(config-ikev2=proposal=proposal1)#prf sha-256
RP/0/RP0/CPU0:ios(config-ikev2=proposal=proposal1)#dh 20
RP/0/RP0/CPU0:ios(config-ikev2=proposal=proposal1)#commit
Thu Mar  7 19:20:30.916 UTC
RP/0/RP0/CPU0:ios(config-ikev2=proposal=proposal1)#exit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show ikev2 proposal proposal1
Thu Mar  7 19:20:48.929 UTC

Proposal Name          : proposal1
=====
Status                : Complete
-----
Total Number of Enc. Alg.   : 1
    Encr. Alg.        : CBC-AES-256
-----
Total Number of Hash. Alg. : 1
    Hash. Alg.       : SHA 1
-----
Total Number of PRF. Alg. : 1
PRF. Alg.           : SHA 256
-----
Total Number of DH Group  : 1
    DH Group          : Group 20

```

protecting-controller

To configure an ODUk controller as the protecting controller in the ODU group controller, use the **protecting-controller** command in the configuration mode. To delete an ODUk controller as the protecting controller in the ODU group controller, use the **no** form of this command.

protecting-controller [*ODUk R/S/I/P*]

no protecting-controller [*ODUk*]

Syntax Description	<i>ODUk</i>	Name of the ODUk controller.
	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the controller.
Command Default	None	
Command Modes	Configuration mode	
Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Example

This example shows how to configure an ODU1 controller as the protecting controller in the ODU group 1 controller:

```
RP/0/RP0:hostname(config)# controller Odu-Group-Mp2 signal Otn odu-type ODUC4
RP/0/RP0:hostname(config-odu-group-mp 1)# protecting-controller ODUC40/0/0/13
```

protection-attributes connection-mode

To configure connection mode of all the protecting controllers in the ODU Group controller, use the **protection-attributes connection mode** command in the configuration mode. To delete a connection mode of all the protecting controllers in the ODU Group controller, use the **no** form of this command.

protection-attributes connection mode [*snc-n*]

no protection-attributes connection mode [*snc-n*]

Syntax Description	<i>snc-n</i>	Configures the SNC-N connection-mode which provides non-intrusive monitoring of the original characteristic information. When this mode is selected, protection is provided at the ODUk path (ODUkP) layer or ODUk TCM (ODUkT) sub-layers.
---------------------------	--------------	--

protection-attributes protection-mode

Command Default	SNC-N	
Command Modes	Configuration	
Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Example

This example shows how to configure the connection mode of an ODU group controller as inherent subnetwork connection:

```
RP/0/RP0:hostname(config)# controller Odu-Group-Mp2 signal Otn odu-type ODUC4
RP/0/RP0:hostname(config-odu-group-mp 1)# protection-attributes connection-mode snc-n
```

protection-attributes protection-mode

To configure protection mode of all the protecting controllers in the ODU Group controller, use the **protection-attributes protection-mode** command in the configuration mode. To delete a protection mode of all the protecting controllers in the ODU Group controller, use the **no** form of this command.

protection-attributes protection-mode [revertive wait-to-restore-time] timer
no protection-attributes protection-mode [revertive wait-to-restore-time] timer

Syntax Description	revertive	Configures the revertive protection mode. The revertive mode allows you to configure APS to switch to the working path after it becomes functional. This mode requires configuring the <i>wait-to-restore</i> option in seconds. This switch occurs after the following conditions are met: <ul style="list-style-type: none">• The condition that caused the traffic switch to the protection path is resolved.• The wait-to-restore time has expired.
	wait-to-restore	Configures the wait-to-restore timer.
	<i>Timer</i>	Specify the time in seconds after which the traffic is automatically switched back to the working controller. Valid range: 300 to 720 seconds. Default value: 300 seconds
Command Default	0	

Command Modes	Configuration	
Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Example

This example shows how to configure the protection mode of an ODU group controller as revertive:

```
RP/0/RP0:hostname(config)# controller Odu-Group-Mp2 signal Otn odu-type ODUC4
RP/0/RP0:hostname(config-odu-group-mp1)# protection-attributes protection-mode revertive
wait-to-restore-time 400
```

protection-attributes protection-type

To configure protection type of all the protecting controllers in the ODU Group controller, use the **protection-attributes protection-type** command in the configuration mode. To delete a protection type of all the protecting controllers in the ODU Group controller, use the **no** form of this command.

protection-attributes protection-type [APSbidi]
no protection-attributes protection-type [APSbidi]

Syntax Description	APSBIDI	Configures the 1+1 bi-directional protection type. This protection type allows the working path to switch to the protection path for both receipt and transmission of traffic. This switch happens regardless of whether the signal fails in the receiving or transmitting direction.
Command Default	OTM_PROT_TYPE_ONE_PLUS_ONE_APS_BIDI	
Command Modes	Configuration	
Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Example

This example shows how to configure the protection type of an ODU group controller as 1+1 bidirectional automatic protection switching:

```
RP/0/RP0:hostname(config)# controller Odu-Group-Mp2 signal Otn odu-type ODUC4
RP/0/RP0:hostname(config-odu-group-mp 1)# protection-attributes protection-type APSbidi
```

protection-attributes timers

To configure hold-off timer for the ODU Group controller, use the **protection-attributes timers** command in the configuration mode. To delete a hold-off timer for the ODU Group controller, use the **no** form of this command.

protection-attributes timers [hold-off-time] *timer*
no protection-attributes timers protection-attributes timers { hold-off-time } *timer*

Syntax Description	hold-off-time	(Optional) Configures the hold-off time. Once a signal failure is detected on the working path, APS waits until this timer expires before switching the traffic to the protecting path.
	<i>timer</i>	Specify the time in milliseconds. You can configure the timer only in multiples of hundred.
		Valid range: 100 to 10000 milliseconds
		Default value: 0
Command Default	0	
Command Modes	Configuration	
Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Example

This example shows how to configure the hold-off timer for the ODU group controller:

```
RP/0/RP0:hostname(config)# controller Odu-Group-Mp2 signal Otn odu-type ODUC4
RP/0/RP0:hostname(config-odu-group-mp 1)# protection-attributes timers hold-off-time 1000
```

protection-switching

To configure a controller as a locked out resource in an ODU Group controller, use the **protection-switching** command in the configuration mode. To delete a controller as a locked out resource in an ODU Group controller, use the **no** form of this command.



Note If the protection controller is active, configuring the protection switching to lockout automatically switches the traffic to the working controller.

```
protection-switching { operate lockout odu-dest } [ ODUk R/S/I/P ]
no protection-switching { operate lockout odu-dest } [ ODUk R/S/I/P ]
```

Syntax Description	operate	Configures the protection switching.
	lockout	Configures the working path as a locked out resource, forcing the use of working controller and preventing the traffic to be automatically switched to the protection controller.
	odu-dest	Configures the controller in which the working path is to be locked out.
	<i>ODUk</i>	Specify the name of the controller.
	<i>R/S/I/P</i>	Specify the Rack/Slot/Instance/Port of the working path.

Command Default None

Command Modes Configuration

Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Example

This example shows how to configure a protecting controller as a locked out resource:

```
RP/0/RP0:hostname(config)# controller Odu-Group-Mp2 signal Otn odu-type ODUC4
RP/0/RP0:hostname(config-odu-group-mp 1)# protection-switching operate lockout odu-dest
ODUC4 0/0/0/2
RP/0/RP0:hostname(config-odu-group-mp 1)# commit
```

query url

To specify Lightweight Directory Access Protocol (LDAP) protocol support, use the **query url** command in trustpoint configuration mode. To remove the query URL from the configuration, use the **no** form of this command.

```
query url LDAP-URL
no query url LDAP-URL
```

Syntax Description *LDAP-URL* URL of the LDAP server (for example, ldap://another-server).

This URL must be in the form of ldap://server-name where server-name is the host Domain Name System (DNS) name or IP address of the LDAP server.

router-id ipv4 unicast

Command Default	The URL provided in NCS 1004 certificate's CRLDistributionPoint extension is used.	
Command Modes	Trustpoint configuration	
Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Usage Guidelines	LDAP is a query protocol used when NCS 1004 retrieves the Certificate Revocation List (CRL). The certification authority (CA) administrator should be able to tell you whether the CA supports LDAP; if the CA supports LDAP, the CA administrator can tell you the LDAP location where certificates and certificate revocation lists should be retrieved.
	To change the query URL, repeat the query url command to overwrite the previous URL.

Task ID	Task ID	Operations
	crypto	read, write

Examples	The following example shows the configuration required to declare a CA when the CA supports LDAP:
-----------------	---

```
RP/0/0R0RSP0/CPU0:ios:hostname# configure
RP/0/0R0RSP0/CPU0:ios:hostname(config)# crypto ca trustpoint myca
RP/0/0R0RSP0/CPU0:ios:hostname(config-trustp)# query url ldap://my-ldap.domain.com
```

router-id ipv4 unicast

To configure the LMP unicast or neighbor router ID for GMPLS, use the **router-id** command in the LMP GMPLS UNI configuration or LMP GMPLS UNI neighbor configuration mode.

router-id ipv4 unicast address

Syntax Description	address Specifies the GMPLS UNI optical router-id (IPv4 address).
---------------------------	---

Command Default	None
------------------------	------

Command Modes	LMP GMPLS UNI configuration LMP GMPLS UNI neighbor configuration
----------------------	---

Release	Modification
7.0.1	This command is introduced.

Example

The following example shows how to specify a router ID (address 10.10.4.4) for GMPLS UNI.

```
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp)#gmpls optical-uni
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)#router-id ipv4 unicast 10.10.4.4
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)
```

The following example shows how to specify the neighbor router ID 10.10.5.5 for GMPLS UNI.

```
RP/0/RP0/CPU0:ios(config)#lmp
RP/0/RP0/CPU0:ios(config-lmp)#gmpls optical-uni
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni)#neighbor UN01
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-nbr-UN01)#router-id ipv4 unicast 10.10.5.5
RP/0/RP0/CPU0:ios(config-lmp-gmpls-uni-nbr-UN01) #
```

rsakeypair

To specify a named Rivest, Shamir, and Adelman (RSA) key pair for this trustpoint, use the **rsakeypair** command in trustpoint configuration mode. To reset the RSA key pair to the default, use the **no** form of this command.

rsakeypair *keypair-label*
no rsakeypair *keypair-label*

Syntax Description

keypair-label RSA key pair label that names the RSA key pairs.

Command Default

If the RSA key pair is not specified, the default RSA key is used for this trustpoint.

Command Modes

Trustpoint configuration

Command History

Release

Modification

Release 7.10.1

This command was introduced.

Usage Guidelines

Use the **rsakeypair** command to specify a named RSA key pair generated using the **crypto key generate rsa** command for this trustpoint.

Task ID

Task ID	Operations
---------	------------

crypto read,
write

Examples

The following example shows how to specify the named RSA key pair key1 for the trustpoint myca:

sftp-password (trustpoint)

```
RP/0/0RPO0SP0/CPU0:ios:hostname# configure
RP/0/0RPO0SP0/CPU0:ios:hostname(config)# crypto ca trustpoint myca
RP/0/0RPO0SP0/CPU0:ios:hostname(config-trustp)# rsakeypair key1
```

sftp-password (trustpoint)

To secure the FTP password, use the **sftp-password** command in trustpoint configuration mode. To disable this feature, use the **no** form of this command.

```
sftp-password {clear text | clear text | password encrypted string}
no sftp-password {clear text | clear text | password encrypted string}
```

Syntax Description	<p>clear text Clear text password and is encrypted only for display purposes.</p> <p>password encrypted string Enters the password in an encrypted form.</p>				
Command Default	The <i>clear text</i> argument is the default behavior.				
Command Modes	Trustpoint configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.10.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.10.1	This command was introduced.
Release	Modification				
Release 7.10.1	This command was introduced.				
Usage Guidelines	<p>Passwords are stored in encrypted form and not as plain text. The command-line interface (CLI) contains the provisioning (for example, clear and encrypted) to specify the password input.</p> <p>The username and password are required as part of the SFTP protocol. If you specify the URL that begins with the prefix (sftp://), you must configure the parameters for the sftp-password command under the trustpoint. Otherwise, the certificate from the SFTP server, which is used for manual certificate enrollment, cannot be retrieved.</p>				
Task ID	<table border="1"> <thead> <tr> <th>Task Operations ID</th></tr> </thead> <tbody> <tr> <td>crypto read, write</td></tr> </tbody> </table>	Task Operations ID	crypto read, write		
Task Operations ID					
crypto read, write					

Examples

The following example shows how to secure the FTP password in an encrypted form:

```
RP/0/0RPO0SP0/CPU0:ios:hostname# configure
RP/0/0RPO0SP0/CPU0:ios:hostname(config)# crypto ca trustpoint msiox
RP/0/0RPO0SP0/CPU0:ios:hostname(config-trustp)# sftp-password password xxxxxxxx
```

sftp-username (trustpoint)

To secure the FTP username, use the **sftp-username** command in trustpoint configuration mode. To disable this feature, use the **no** form of this command.

```
sftp-username username
no sftp-username username
```

Syntax Description	<i>username</i> Name of the user.	
Command Default	None	
Command Modes	Trustpoint configuration	
Command History	Release	Modification
	Release 7.10.1	This command was introduced.
Usage Guidelines	The sftp-username command is used only if the URL has (sftp://) in the prefix. If (sftp://) is not specified in the prefix, the manual certificate enrollment using SFTP fails.	
Task ID	Task ID	Operations
		crypto read, write

Examples The following example shows how to secure the FTP username:

```
RP/0/0RPO0SP0/CPU0:ios:hostname# configure
RP/0/0RPO0SP0/CPU0:ios:hostname(config)# crypto ca trustpoint msiox
RP/0/0RPO0SP0/CPU0:ios:hostname(config-trustp)# sftp-username tmordeko
```

show configuration commit changes

To display the changes made to the running configuration by previous configuration commits, a configuration commit, or for a range of configuration commits, use the **show configuration commit changes** command in EXEC, administration EXEC, administration configuration, or global configuration mode.

```
show configuration commit changes { commit-id | since commit-id | last number-of-commits
| original last-modified | all } [diff]
```

show configuration commit changes

Syntax Description	since	Displays all changes committed to the running configuration since (and including) a specific configuration commit.
	<i>commit-id</i>	Displays configuration changes for a specific configuration commit.
	last <i>number-of-commits</i>	Displays the changes made to the running configuration during the last number of configuration commits specified for the <i>number-of-commits</i> argument.
	original <i>last-modified</i>	Displays the original content of the actual commit operation before policy modifications by commit scripts.
	all	Displays commit ID and configurations completed for last 100 commits.
	diff	(Optional) Displays added lines, changed lines, and deleted lines.
Command Default	None	
Command Modes	EXEC Administration EXEC Administration configuration Global configuration	
Command History	Release	Modification
	Release 7.0.1	This command was introduced.
Usage Guidelines	Each time a configuration is committed with the commit command, the configuration commit operation is assigned a commit ID. The show configuration commit changes command displays the configuration changes made since the specified commit. To display a list of the available commit IDs, enter the show configuration commit list command. You can also display the commit IDs by entering the show configuration commit changes command with the online help function (?). You cannot view commit IDs from a different release if the syntax or semantics of the configuration changed in the current release.	



Note Syntax of a configuration refers to its structure and format, while the semantics of a configuration refers to its backend interpretation.

The following example shows sample output from the **show configuration commit changes** command with the *commit-id* argument. In this example, the output displays the changes made in the configuration commit assigned commit ID 1000035693.

```
RP/0/RP0/CPU0:ios#show configuration commit changes 1000035693
Tue Feb 28 14:28:03.404 UTC
!! Building configuration...
interface GCC20/1/0/12
  ipv4 address 10.1.1.2 255.255.255.0
!
end
```

The following example shows sample output from the **show configuration commit changes** command with the **since commit-id** keyword and argument. In this example, the output displays the configuration changes made since the configuration commit assigned commit ID 1000035693 was committed.

```
RP/0/RP0/CPU0:ios#show configuration commit changes since 1000035693
Tue Feb 28 14:29:42.858 UTC
!! Building configuration...
controller ODUC40/1/0/12
  no gcc2
!
no interface preconfigure GCC20/1/0/12
no keyring keyring_all_in_one
no ikev2 profile profile_all_in_one
end
```

The following example shows sample output from the **show configuration commit changes** command with the **diff** keyword. In the display, the following symbols signify changes:

+ indicates an added line.

- indicates a deleted line.

indicates a modified line.

```
RP/0/RP0/CPU0:ios#show configuration commit changes since 1000035681 diff
Tue Feb 28 14:32:24.349 UTC
!! Building configuration...
- logging console disable
# line default
#   exec-timeout 0 0
#
- controller ODUC40/1/0/12
-   gcc2
-
- interface preconfigure GCC20/1/0/12
-   ipv4 address 10.1.1.2 255.255.255.0
-
- keyring keyring_all_in_one
-   peer link_1
-     pre-shared-key password 11021C1C46
-     address 10.1.1.2 255.255.255.0
```

show controllers [odu-group-mp]

```
- !
- !
end
```

The following example shows sample output from the **show configuration commit changes** command with the **all** keyword. In this example, the output displays the list of configurations that are committed in last 100 commits along with their commit-ID.

```
RP/0/RP0/CPU0:ios#show configuration commit changes all
Tue Feb 28 14:33:33.772 UTC

Commit ID : 1000035611
-----
!! Building configuration...
controller Optics0/3/0/12
 shutdown
!
end

Commit ID : 1000035612
-----
!! Building configuration...
controller Optics0/3/0/12
 no shutdown
!
end

Commit ID : 1000035613
-----
!! Building configuration...
controller Odu-Group-Mpl signal Otn odu-type ODUC4
 no protection-switching operate lockout odu-dest ODUC40/3/0/12
!
end
```

show controllers [odu-group-mp]

To display details of an ODU group controller, use the **show controller [odu-group-mp | odu-group-te]** command in the exec mode.

show controllers [odu-group-mp] *Group ID* [protection-detail]

Syntax Description	odu-group-mp	Displays details of the ODU group controller pertaining to management plane.
	Group ID	Name of the ODU group controller.
	protection-detail	Displays the hardware information of the ODU group controller.
Command Modes	Exec mode	

Command History	Release	Modification
	Release 7.8.1	This command was introduced.

Example 1

This example shows how to display the details of an ODU group controller:

```
RP/0/RP0/CPU0:ios# show controllers odu-group-mp 2
```

```
ODU Group Information
-----
ODU GROUP ID : 2
Controller State : Up

WORKING CONTROLLER

ODU NAME : ODUC4 0/0/0/12
ODU ROLE : WORKING
ODU STATE : Active_tx
Local Failure : Yes
Remote Failure : Yes

PROTECTED CONTROLLER

ODU NAME : ODUC4 0/0/0/13
ODU ROLE : PROTECT
ODU STATE : Active
Local Failure : No
Remote Failure : No

PROTECTION PARAMETERS :
Connection Mode : SNC_N
Protection Type : 1+1 Bidirectional Protection
Tcmid : 0
Protection Mode : Revertive
Hold off timer : 1000
Wait-to-restore timer : 400000 ms

Detected Alarms : Switched To Protection
```

Example 2

This example shows how to display the hardware details of an ODU group controller:

```
RP/0/RP0/CPU0:ios#show controllers odu-group-mp 2 protection-detail
```

```
Tue Sep 13 12:22:41.316 UTC

ODU Group Information
-----
LOCAL

Request State : Signal Failed
Request signal : 0
Bridge signal : 1
Bridge Status : 1+1
```

```
show crypto ca certificates
```

REMOTE	Request State	:	Signal Failed
	Request signal	:	0
	Bridge signal	:	1
	Bridge Status	:	1+1
WORKING	Controller Name	:	ODUC40_0_0_12
	ODU STATE	:	Active_tx
	Local Failure	:	Signal Failure
	Remote Failure	:	Signal Failure
	WTR Left	:	0 ms
PROTECT	Controller Name	:	ODUC40_0_0_13
	ODU STATE	:	Active
	Local Failure	:	State Ok
	Remote Failure	:	State Ok
	WTR Left	:	0 ms
Client	Controller Name	:	ODUC40_0_0_0
	ODU STATE	:	Not Present
	Wait to restore	:	400000 ms
	Hold-off-timer	:	1000 ms
	Current State	:	Signal failed on Working
	Previous State	:	No Request State

show crypto ca certificates

To display information about your certificate and the certification authority (CA) certificate, use the **show crypto ca certificates** command in EXEC mode.

```
show crypto ca certificates
```

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Usage Guidelines Use the **show crypto ca certificates** command to display information about the following certificates:

- Your certificate, if you have requested one from the CA (see the **crypto ca enroll** command).
- CA certificate, if you have received the certificate (see the **crypto ca authenticate** command).

Task ID	Task Operations ID
	crypto read

Examples

The following sample output is from the **show crypto ca certificates** command:

```
RP/0/0RPO/RSP0/CPU0:ios:hostname# show crypto ca certificates
Trustpoint      : msiox
=====
CA certificate
  Serial Number : 06:A5:1B:E6:4F:5D:F7:83:41:11:D5:F9:22:7F:95:23
  Subject:
    Name: CA2
    CN= CA2
  Issued By   :
    cn=CA2
  Validity Start : 07:51:51 UTC Wed Jul  6 2005
  Validity End   : 08:00:43 UTC Tue Jul  6 2010
  CRL Distribution Point
    http://10.56.8.236/CertEnroll/CA2.crl
certificate
  Status       : Available
  Key usage    : Signature
  Serial Number: 38:6B:C6:B8:00:04:00:00:01:45
  Subject:
    Name: tdlr533.cisco.com
    IP Address: 192.0.2.89
    Serial Number: 8cd96b64
  Issued By   :
    cn=CA2
  Validity Start : 08:30:03 UTC Mon Apr 10 2006
  Validity End   : 08:40:03 UTC Tue Apr 10 2007
  CRL Distribution Point
    http://10.56.8.236/CertEnroll/CA2.crl
Associated Trustpoint: MS-IOX
certificate
  Status       : Available
  Key usage    : Encryption
  Serial Number: 38:6D:2B:A7:00:04:00:00:01:46
  Subject:
    Name: tdlr533.cisco.com
    IP Address: 198.51.100.3
    Serial Number: 8cd96b64
  Issued By   :
    cn=CA2
  Validity Start : 08:31:34 UTC Mon Apr 10 2006
  Validity End   : 08:41:34 UTC Tue Apr 10 2007
  CRL Distribution Point
    http://10.56.8.236/CertEnroll/CA2.crl
Associated Trustpoint: msiox
```

The following is a sample output with multi-tier CA. The command output displays the **Trusted Certificate Chain** field if there is one or more subordinate CAs involved in the hierarchy.

```
RP/0/RP0/CPU0:ios#show crypto ca certificates test-ca
Mon Feb  6 09:03:53.019 UTC

Trustpoint      : test-ca
=====
CA certificate
  Serial Number : 10:01
```

```
show crypto key mypubkey ed25519
```

```

Subject: CN=SUB_CA_CERT,OU=SPBU,O=CSCO,L=BGL,ST=KA,C=IN
Issued By : CN=TWO-LEVEL-CA,OU=SPBU,O=CSCO,L=BGL,ST=KA,C=IN
Validity Start : 12:31:40 UTC Sun Jun 14 2020
Validity End : 12:31:40 UTC Wed Jun 12 2030

CRL Distribution Point
    http://10.105.236.78/crl_akshath_two_level_ca/crl.der
SHA1 Fingerprint:
    D8E0C11ECED96F67FDDBC800DB6A126676A76BD62
Trusted Certificate Chain
Serial Number : 0F:A0:06:7A:C9:5E:A9:E7:61:A2:B9:2B:27:D1:D6:8F:3D:51:43:3B
Subject:
    CN=TWO-LEVEL-CA,OU=SPBU,O=CSCO,L=BGL,ST=KA,C=IN
Issued By :
    CN=TWO-LEVEL-CA,OU=SPBU,O=CSCO,L=BGL,ST=KA,C=IN
Validity Start : 13:12:32 UTC Sun Jun 07 2020
Validity End : 13:12:32 UTC Sat Jun 02 2040

CRL Distribution Point
    http://10.105.236.78/crl_akshath_two_level_ca/crl.der
SHA1 Fingerprint:
    08E71248FB7578614442E713AC87C461D173952F
certificate
Key usage : General Purpose
Status : Available
Serial Number : 28:E5
Subject:
    CN=test
Issued By :
    CN=SUB_CA_CERT,OU=SPBU,O=CSCO,L=BGL,ST=KA,C=IN
Validity Start : 08:49:54 UTC Mon Feb 06 2023
Validity End : 08:49:54 UTC Wed Mar 08 2023
SHA1 Fingerprint:
    6C8644FA67D9CEBC7C5665C35838265F578835AB
Associated Trustpoint: test-ca

```

show crypto key mypubkey ed25519

To display the Ed25519 crypto public keys of NCS 1004, use the **show crypto key mypubkey ed25519** command in EXEC mode.

show crypto key mypubkey ed25519

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
------------------------	----------------	---------------------

Release 7.10.1 This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
		crypto read

Examples

This example shows the sample output of the **show crypto key mypubkey ed25519** command:

```
RP/0/0RPO/RSP0/CPU0:ios# show crypto key mypubkey ed25519
Mon Nov 30 07:05:06.532 UTC
Key label: the_default
Type : ED25519
Size : 256
Created : 07:03:17 UTC Mon Nov 30 2020
Data :
FF0ED4E7 71531B3D 9ED72C48 3F79EC59 9EFECCC3 46A129B2 FAAA12DD EE9D0351
```

Related Commands	Command	Description
	crypto key generate ed25519, on page 36	Generates Ed25519 crypto key pairs.
	crypto key zeroize ed25519, on page 39	Deletes all Ed25519 keys from NCS 1004.

show crypto key mypubkey rsa

To display the Rivest, Shamir, and Adelman (RSA) public keys for NCS 1004, use the **show crypto key mypubkey rsa** command in EXEC mode.

show crypto key mypubkey rsa

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.10.1	This command was introduced.

Usage Guidelines None

Task ID	Task ID	Operations
		crypto read

sak-rekey-interval**Examples**

The following is sample output from the **show crypto key mypubkey rsa** command:

```
RP/0/0R0RSP0/CPU0:ios:hostname# show crypto key mypubkey rsa

Key label: mykey
Type : RSA General purpose
Size : 1024
Created : 07:46:15 UTC Fri Mar 17 2006
Data :
30819F30 0D06092A 864886F7 0D010101 05000381 8D003081 89028181 00CF8CDF
5BFCA055 DA4D164D F6EDB78B 926B1DDE 0383027F BA71BCC6 9D5592C4 5BA8670E
35CD19B7 1C973A46 62CC5F8C 82BD596C F292410F 8E83B753 4BA71BAC 41AB6B60
F34A2499 EDE11639 F88B4210 B2A0CF5F DD678C36 0D8B7DE1 A2AB5122 9ED947D5
76CF5BCD D9A2039F D02841B0 7F8BFF97 C080B791 10A9ED41 00FB6F40 95020301
0001

Key label: the_default
Type : RSA General purpose
Size : 512
Created : 07:46:15 UTC Fri Mar 17 2006
Data :
305C300D 06092A86 4886F70D 01010105 00034B00 30480241 00C7DE73 7B3EA447
CCE8F3DF DD1327D8 C1C30C45 2EEB4981 B1B48D2B 1AF14665 178058FB 8F6BB6BB
E08C6163 FA0EE356 395C8E5F 2AC59383 0706BDDF EC8E5822 9B020301 0001
```

sak-rekey-interval

To configure the key lifetime for the child security associations (SA), use the **sak-rekey-interval** command in OTNSec policy configuration mode.

sak-rekey-interval seconds

Syntax Description	<i>seconds</i> SAK rekey timer in seconds. The range is from 30 to 1209600 seconds.				
Command Default	None				
Command Modes	OTNSec policy configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command is introduced.
Release	Modification				
Release 7.0.1	This command is introduced.				

Example

The following is a sample in which an OTNSec policy is configured.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 11 15:16:58.417 UTC
RP/0/RP0/CPU0:ios(config)#otnsec policy otnsec-policy1
RP/0/RP0/CPU0:ios(config-otnsec-policy)#cipher-suite AES-GCM-256
RP/0/RP0/CPU0:ios(config-otnsec-policy)#security-policy must-secure
RP/0/RP0/CPU0:ios(config-otnsec-policy)#sak-rekey-interval 120
RP/0/RP0/CPU0:ios(config-otnsec-policy)#commit
```

The following is a sample of an OTNSec policy.

```
RP/0/RP0/CPU0:ios#show run otnsec policy otnsec-policy1
Tue Mar 12 11:14:03.591 UTC
otnsec policy otnsec-policy1
  cipher-suite AES-GCM-256
  security-policy must-secure
  sak-rekey-interval 120
!
```

security-policy

To specify the security for OTNSec policy, use the **security-policy** command in OTNSec policy configuration mode.

security-policy must-secure

Syntax Description	must-secure Mandatory security for OTNSec.				
Command Default	None				
Command Modes	OTNSec policy configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which an OTNSec policy is configured.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 11 15:16:58.417 UTC
RP/0/RP0/CPU0:ios(config)#otnsec policy otnsec-policy1
RP/0/RP0/CPU0:ios(config-otnsec-policy)#cipher-suite AES-GCM-256
RP/0/RP0/CPU0:ios(config-otnsec-policy)#security-policy must-secure
RP/0/RP0/CPU0:ios(config-otnsec-policy)#sak-rekey-interval 120
RP/0/RP0/CPU0:ios(config-otnsec-policy)#commit
```

The following is a sample of an OTNSec policy.

```
RP/0/RP0/CPU0:ios#show run otnsec policy otnsec-policy1
Tue Mar 12 11:14:03.591 UTC
otnsec policy otnsec-policy1
  cipher-suite AES-GCM-256
  security-policy must-secure
  sak-rekey-interval 120
!
```

session-id

session-id

To configure the session ID for OTNSec on ODU4 controller, use the **session-id** command in OTNSec configuration mode.

session-id *session-id*

Syntax Description	<i>session-id</i> Session ID. The range is from 1 to 65535.				
Command Default	None				
Command Modes	OTNSec configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	7.0.1	This command is introduced.
Release	Modification				
7.0.1	This command is introduced.				

Example

The following is a sample in which OTNSec is configured on ODU4 controllers.

```
RP/0/RP0/CPU0:ios#configure
Mon Mar 12 12:10:21.374 UTC
RP/0/RP0/CPU0:ios(config)#controller ODU4 0/1/0/0/1
RP/0/RP0/CPU0:ios(config-odu4)#otnsec
RP/0/RP0/CPU0:ios(config-otnsec)#source ipv4 10.0.0.1
RP/0/RP0/CPU0:ios(config-otnsec)#destination ipv4 10.0.0.2
RP/0/RP0/CPU0:ios(config-otnsec)#session-id 9000
RP/0/RP0/CPU0:ios(config-otnsec)#policy otnsec-policy1
RP/0/RP0/CPU0:ios(config-otnsec)#ikev2 profile profile1
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#commit
Mon Mar 12 12:14:17.609 UTC
RP/0/RP0/CPU0:ios(config-ikev2-profile-profile1)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

The following is a running configuration on an ODU4 controller.

```
RP/0/RP0/CPU0:ios#show run controller ODU4 0/1/0/0/1
Tue Mar 12 12:20:49.153 UTC
controller ODU4/0/1/0/0/1
  gcc2
  otnsec
    policy otnsec-policy1
    source ipv4 10.0.0.1
    destination ipv4 10.0.0.2
    session-id 9000
!
!
```

show alarms

To display alarms in brief or detail, use the **show alarms** command in XR EXEC mode or Administration EXEC mode.

show alarms brief [card [location *location*] | rack | system] [active | history]]

show alarms detail [card [location *location*]| rack | system] [active | clients | history | stats]]

Syntax Description

brief	Displays alarms in brief.
card	Displays card scope alarms related data.
rack	Displays rack scope alarms related data.
system	Displays system scope alarms related data.
location <i>location</i>	Specifies the target location in the <i>rack/slot</i> notation.
active	Displays active alarms.
history	Displays alarm history.
detail	Displays alarms in detail.
clients	Displays clients associated with the service.
stats	Displays service statistics.

Command Default

None

Command Modes

XR EXEC

Administration EXEC

Command History

Release	Modification
7.0.1	This command was introduced.

Usage Guidelines

This command displays the alarms in brief or detail. The command displays only the administration alarms in admin EXEC mode and all the alarms in XR EXEC mode.

Example

The following example shows the output of the **show alarms** command.

```
sysadmin-vm:0_RP0# show alarms
```

```
Wed Mar 20 05:25:53.146 UTC+00:00
```

```
-----
```

```
Active Alarms
```

show controllers

Location	Severity	Group	Set time	Description
0/PM0	major	environ	03/19/19 21:37:29	Power Module Output
Disabled				
0 lost.	major	environ	03/19/19 21:37:35	Power Module redundancy

RP/0/RP0/CPU0:ios# show alarms brief card location 0/RP0/CPU0 active

Wed Mar 20 05:26:52.116 UTC

Active Alarms

Location	Severity	Group	Set Time	Description
0/PM0 Need Upgrade	Major	FPD_Infra	03/19/2019 21:39:04 UTC	One Or More FPDs Or Not In Current State

show controllers

To display status and configuration information about the interfaces on a specific node, use the **show controllers** command in XR EXEC mode.

```
show controllers controller-type R/S/I/P [ pm { current | history } { 30 sec | 15-min | 24-hour } { optics | ether | pcs | prbs | stm | ocn } linenumber { otn | fec } ] [ fastpoll ]
```

To view the bits-per-symbol or baud rate of the optics controller for a specific range use the following command:

```
show controllers optics R/S/I/P { bps-range bps-range | baud-rate-range baud-range } | include data-rate | include fec-type
```

Syntax Description	controller-type	Type of the controller. The possible values are HundredGigECtrlr, CoherentDSP, ODU4, ODUC4, oc192, stm64, and Optics.
	R/S/I/P	Rack/Slot/Instance/Port of the controller.
	pm	Displays performance monitoring parameters for the controller.
	current	Displays the current performance monitoring data in 30 second, 15 minute, and 24-hour intervals.
	history	Displays the historical performance monitoring data in 30 second, 15 minute, and 24-hour intervals.
	optics ether pcs prbs stm ocn	optics to display the PM data for Optics controller, ether, pcs, and prbs to display the PM data for Ethernet controller. stm and ocn for STM64 and OC192 controllers.

<i>linenumber</i>	Line number to display performance monitoring data. The range is 1–4.
otn fec	Displays OTN PM data or FEC PM data for CoherentDSP controller.
bps-range <i>bps-range</i>	Displays the BPS for the specified range.
baud-rate-range <i>baud-range</i>	Displays the baud rates for the specified range.
 include	Filters the show command output so that it displays only lines that contain a particular regular expression.
<i>data-rates</i>	Data rate for which the BPS or baud rate is displayed.
<i>fec-type</i>	FEC type for which the BPS or baud rate is displayed.
fastpoll	The fastpoll data is displayed.

Usage Guidelines

The following table describes the PRBS parameters.

Parameter	Description
EBC	Cumulative count of PRBS bit errors in the sampling window (15 min or 24 hour). Bit errors are accumulated only if PRBS signal is locked.
FOUND-COUNT	Number of state transitions from signal unlocked state to locked state in the sampling window. If no state change is observed in the interval, the count will be zero.
LOST-COUNT	Number of state transitions from signal locked state to signal unlocked state in the sampling window. If there is no state change observed in the interval, the count is zero.
FOUND-AT-TS	Latest timestamp when the PRBS state switches from unlocked state to locked state in the sampling window. If no state change is observed in the sampling window, this value is null.
LOST-AT-TS	Latest timestamp when the PRBS state switches from locked state to unlocked state in the sampling window. If no state change is observed in the sampling window, this value is null.
CONFIG-PTRN	Configured PRBS pattern on the port.

- Total TX Power and Total RX Power: For multi-lane controller optics, total power is calculated by converting each lane power value from dBm to mW, and adding each lane power. Total power in mW must then be converted to dBm.

Total power in mW = [(Lane 1 power in mW) + (Lane 2 power in mW) + (Lane 3 power in mW) + (Lane 4 power in mW)]

Total power in dBm = Converted value of total power in mW to dBm

Command Default

The status and configuration information of all the interfaces is displayed.

Command Modes

XR EXEC

show controllers

Command History	Release	Modification
	7.0.1	This command was introduced.
	7.1.1	pcs keyword was added.
	7.3.1	The keyword fastpoll was added.
	7.8.1	The ODUC4 controllertype argument was added.
	7.10.1	oc192 and stm64, controllertype arguments were added.

Examples

The following is a sample to view the laser squelch status on the Ethernet controller.

```
RP/0/RP0/CPU0:ios#show controller HundredGigECtrlr 0/1/0/10
```

```
RP/0/RP0/CPU0:ios#show controller HundredGigECtrlr 0/1/0/10
Fri Feb 22 15:18:47.011 UTC
Operational data for interface HundredGigECtrlr0/1/0/10:
```

```
State:
Administrative state: enabled
Operational state: Up
LED state: Green On
Maintenance: Disabled
AINS Soak: None
    Total Duration: 0 hour(s) 0 minute(s)
    Remaining Duration: 0 hour(s) 0 minute(s) 0 second(s)
Laser Squelch: Enabled
```

```
Phy:
Media type: Not known
Statistics:
    FEC:
        Corrected Codeword Count: 0
        Uncorrected Codeword Count: 0
```

Autonegotiation disabled.

```
Operational values:
Speed: 100Gbps
Duplex: Full Duplex
Flowcontrol: None
Loopback: None (or external)
BER monitoring:
    Not supported
Forward error correction: Standard (Reed-Solomon)
Holdoff Time: 0ms
```

The following is a sample to view the hold off timer configured on the ethernet controller.

```
RP/0/RP0/CPU0:ios#show controller HundredGigECtrlr 0/1/0/10
```

```
Fri Feb 22 18:58:06.888 UTC
Operational data for interface HundredGigECtrlr0/1/0/10:
```

```

State:
  Administrative state: enabled
  Operational state: Up
  LED state: Green On
  Maintenance: Disabled
  AINS Soak: None
    Total Duration: 0 hour(s) 0 minute(s)
    Remaining Duration: 0 hour(s) 0 minute(s) 0 second(s)
  Laser Squelch: Enabled

Phy:
  Media type: Not known
  Statistics:
    FEC:
      Corrected Codeword Count: 0
      Uncorrected Codeword Count: 0

Autonegotiation disabled.

Operational values:
  Speed: 100Gbps
  Duplex: Full Duplex
  Flowcontrol: None
  Loopback: None (or external)
  BER monitoring:
    Not supported
  Forward error correction: Standard (Reed-Solomon)
Holdoff Time: 3000ms

```

The following is a sample to view the loopback configured on the ethernet controller.

RP/0/RP0/CPU0:ios#**show controller HundredGigECtrlr 0/1/0/10**

```

Fri Feb 22 20:01:00.521 UTC
Operational data for interface HundredGigECtrlr0/1/0/10:

State:
  Administrative state: enabled
  Operational state: Up
  LED state: Green On
  Maintenance: Enabled
  AINS Soak: Pending
    Total Duration: 0 hour(s) 30 minute(s)
    Remaining Duration: 0 hour(s) 30 minute(s) 0 second(s)
  Laser Squelch: Enabled

Phy:
  Media type: Not known
  Statistics:
    FEC:
      Corrected Codeword Count: 0
      Uncorrected Codeword Count: 6

Autonegotiation disabled.

Operational values:
  Speed: 100Gbps
  Duplex: Full Duplex
  Flowcontrol: None
Loopback: Line
  BER monitoring:
    Not supported

```

show controllers

Forward error correction: Standard (Reed-Solomon)
 Holdoff Time: 0ms

The following example displays the optics controller statistics with AINS Soak in running state.

RP/0/RP0/CPU0:ios#show controller optics 0/1/0/3

Thu Feb 21 19:45:41.088 UTC

Controller State: Up

Transport Admin State: Automatic In Service

Laser State: On

LED State: Green

Optics Status

Optics Type: Grey optics

Alarm Status:

 Detected Alarms: None

LOS/LOL/Fault Status:

Alarm Statistics:

 HIGH-RX-PWR = 0 LOW-RX-PWR = 0
 HIGH-TX-PWR = 0 LOW-TX-PWR = 0
 HIGH-LBC = 0 HIGH-DGD = 0
 OOR-CD = 0 OSNR = 0
 WVL-OOL = 0 MEA = 0
 IMPROPER-REM = 0
 TX-POWER-PROV-MISMATCH = 0

Performance Monitoring: Enable

THRESHOLD VALUES

Parameter	High Alarm	Low Alarm	High Warning	Low Warning
Rx Power Threshold(dBm)	4.9	-12.0	0.0	0.0
Tx Power Threshold(dBm)	3.5	-10.1	0.0	0.0
LBC Threshold(mA)	N/A	N/A	0.00	0.00

LBC High Threshold = 98 %

Polarization parameters not supported by optics

Total TX Power = 6.39 dBm

Total RX Power = 5.85 dBm

Lane	Laser Bias	TX Power	RX Power	Output Frequency
1	75.0 %	0.59 dBm	0.63 dBm	230.43 THz
2	68.6 %	0.06 dBm	-0.68 dBm	230.43 THz
3	69.0 %	0.26 dBm	-0.63 dBm	230.43 THz
4	69.1 %	0.56 dBm	-0.10 dBm	230.43 THz

Transceiver Vendor Details

```

Form Factor      : QSFP28
Name            : CISCO-FINISAR
Part Number     : FTLC1152RGPL-C2
Rev Number      : CISCO-FINISAR
Serial Number   : FNS22150LEC
PID              : QSFP-100G-CWDM4-S
VID              : V02
CISCO-FINISAR
Date Code(yy/mm/dd) : 18/04/11
Fiber Connector Type: LC
Sonet Application Code: Not Set
Ethernet Compliance Code: 100GBASE-CWDM4

```

Transceiver Temperature : 32 Celsius

```

AINS Soak        : Running
AINS Timer       : 0h, 15m
AINS remaining time : 771 seconds

```

The following is a sample to view the current performance monitoring parameters of the optics controller in 15-minute intervals.

RP/0/RP0/CPU0:ios#show controller optics 0/1/0/3 pm current 15-min optics 3

Sat Feb 9 19:33:42.480 UTC

Optics in the current interval [19:30:00 - 19:33:42 Sat Feb 9 2019]

	Optics current bucket type : Valid		Operational	Configured	TCA	Operational
	MIN	Avg				
Configured	TCA		Threshold(min)	Threshold(min)	(min)	Threshold(max)
Threshold(max)	(max)					
LBC[%]	: 0.0	0.0	0.0	0.0	NA	NO 100.0
	NA	NO				
OPT[dBm]	: -40.00	-40.00	-40.00	-30.00	NA	NO 63.32
	NA	NO				
OPR[dBm]	: -40.00	-40.00	-40.00	-30.00	NA	NO 63.32
	NA	NO				
FREQ_OFF[Mhz]	: 0	0	0	0	NA	NO 0
	NA	NO				

The following is a sample to view the current performance monitoring parameters of the Coherent DSP controller in 15-minute intervals.

RP/0/RP0/CPU0:ios#show controller coherentDSP 0/2/0/1 pm current 15-min fec

Sat Feb 9 11:23:42.196 UTC

g709 FEC in the current interval [11:15:00 - 11:23:42 Sat Feb 9 2019]

FEC current bucket type : Valid			
EC-BITS : 291612035786	Threshold : 903330		TCA(enable) :
YES			
UC-WORDS : 0	Threshold : 5		TCA(enable) :

show controllers

YES

	MIN	AVG	MAX	Threshold (min)	TCA (enable)	Threshold (max)	TCA (enable)
PreFEC BER	: 7.1E-03	7.2E-03	8.1E-03	0E-15	NO	0E-15	NO
PostFEC BER	: 0E-15	0E-15	0E-15	0E-15	NO	0E-15	NO

The following is a sample of an encryption configuration on an ODU4 controller.

RP/0/RP0/CPU0:ios#show controllers ODU4 0/1/0/0/1 otnsec

```

Tue Mar 12 17:34:50.660 UTC
Controller Name      : ODU4 0/1/0/0/1
Source ip            : 10.0.0.1
Destination ip       : 10.0.0.2
Session id           : 9000
IKEv2 profile        : Not Configured
Session State        : SECURED

Otnsec policy name   : otnsec-policy1
cipher-suite          : AES-GCM-256
security-policy       : Must Secure
sak-rekey-interval    : 120
Time to rekey         : 0

Programming Status    :
Inbound SA(Rx)       :
  AN[0]               :
    SPI                : None
Outbound SA(Tx)       :
  AN[0]               :
    SPI                : None

```

The following is a sample to view the summary of all the ODU4 controllers.

RP/0/RP0/CPU0:ios#show controller ODU4 * otnsec summary

Controller Name	Source ip	Destination ip	Session id	Session State
ODU4 0/0/0/0/1	10.1.1.1	10.1.1.2	1	SECURED
ODU4 0/0/0/0/2	10.1.1.1	10.1.1.2	2	SECURED
ODU4 0/0/0/0/3	10.1.1.1	10.1.1.2	3	SECURED
ODU4 0/0/0/0/4	10.1.1.1	10.1.1.2	4	SECURED
ODU4 0/0/0/0/5	10.1.1.1	10.1.1.2	5	SECURED
ODU4 0/0/0/1/1	10.1.2.1	10.1.2.2	6	SECURED
ODU4 0/0/0/1/2	10.1.2.1	10.1.2.2	7	SECURED
ODU4 0/0/0/1/3	10.1.2.1	10.1.2.2	8	SECURED
ODU4 0/0/0/1/4	10.1.2.1	10.1.2.2	9	SECURED
ODU4 0/0/0/1/5	10.1.2.1	10.1.2.2	10	SECURED
ODU4 0/1/0/0/1	10.1.3.1	10.1.3.2	11	SECURED
ODU4 0/1/0/0/2	10.1.3.1	10.1.3.2	12	SECURED
ODU4 0/1/0/0/3	10.1.3.1	10.1.3.2	13	SECURED
ODU4 0/1/0/0/4	10.1.3.1	10.1.3.2	14	SECURED
ODU4 0/1/0/0/5	10.1.3.1	10.1.3.2	15	SECURED
ODU4 0/1/0/1/1	10.1.4.1	10.1.4.2	16	SECURED
ODU4 0/1/0/1/2	10.1.4.1	10.1.4.2	17	SECURED
ODU4 0/1/0/1/3	10.1.4.1	10.1.4.2	18	SECURED
ODU4 0/1/0/1/4	10.1.4.1	10.1.4.2	19	SECURED
ODU4 0/1/0/1/5	10.1.4.1	10.1.4.2	20	SECURED
ODU4 0/2/0/0/1	10.1.5.1	10.1.5.2	21	SECURED
ODU4 0/2/0/0/2	10.1.5.1	10.1.5.2	22	SECURED

ODU4 0/2/0/0/3	10.1.5.1	10.1.5.2	23	SECURED
ODU4 0/2/0/0/4	10.1.5.1	10.1.5.2	24	SECURED
ODU4 0/2/0/0/5	10.1.5.1	10.1.5.2	25	SECURED
ODU4 0/2/0/1/1	10.1.6.1	10.1.6.2	26	SECURED
ODU4 0/2/0/1/2	10.1.6.1	10.1.6.2	27	SECURED
ODU4 0/2/0/1/3	10.1.6.1	10.1.6.2	28	SECURED
ODU4 0/2/0/1/4	10.1.6.1	10.1.6.2	29	SECURED
ODU4 0/2/0/1/5	10.1.6.1	10.1.6.2	30	SECURED
ODU4 0/3/0/0/1	10.1.7.1	10.1.7.2	31	SECURED
ODU4 0/3/0/0/2	10.1.7.1	10.1.7.2	32	SECURED
ODU4 0/3/0/0/3	10.1.7.1	10.1.7.2	33	SECURED
ODU4 0/3/0/0/4	10.1.7.1	10.1.7.2	34	SECURED
ODU4 0/3/0/0/5	10.1.7.1	10.1.7.2	35	SECURED
ODU4 0/3/0/1/1	10.1.8.1	10.1.8.2	36	SECURED
ODU4 0/3/0/1/2	10.1.8.1	10.1.8.2	37	SECURED
ODU4 0/3/0/1/3	10.1.8.1	10.1.8.2	38	SECURED
ODU4 0/3/0/1/4	10.1.8.1	10.1.8.2	39	SECURED
ODU4 0/3/0/1/5	10.1.8.1	10.1.8.2	40	SECURED

The following is a sample to view the PM statistics for encryption.

RP/0/RP0/CPU0:ios#show controllers ODU4 0/1/0/0/1 pm current 30-sec otnsec

Tue Mar 12 15:19:33.371 IST

```
OTNSec in the current interval [15:19:30 - 15:19:33 Tue Mar 12 2019]
OTNSEC current bucket type : Valid
InBlocks : 0 Threshold : 0 TCA(enable)
: No
InBlocksEnc : 0 Threshold : 0 TCA(enable)
: No
InBlocksUnEncrypted : 0 Threshold : 0 TCA(enable)
: No
InBlocksProtected : 0 Threshold : 0 TCA(enable)
: No
InBlocksUnProtected : 0 Threshold : 0 TCA(enable)
: No
InBlocksSequenceErrors : 0 Threshold : 0 TCA(enable)
: No
InBlocksReplayErrors : 0 Threshold : 0 TCA(enable)
: No
InBlocksAuthErrors : 0 Threshold : 0 TCA(enable)
: No
InBlocksZeroed : 0 Threshold : 0 TCA(enable)
: No
OutBlocks : 3425548 Threshold : 0 TCA(enable)
: No
OutBlocksEnc : 3425548 Threshold : 0 TCA(enable)
: No
OutBlocksUnEncrypted : 0 Threshold : 0 TCA(enable)
: No
OutBlocksSequenceErrors: 0 Threshold : 0 TCA(enable)
: No
OutBlocksZeroed : 0 Threshold : 0 TCA(enable)
: No
Last clearing of "show controllers ODU" counters never
```

The following is a sample to view the current performance monitoring parameters for the ethernet controller in 30-second intervals.

RP/0/RP0/CPU0:ios#show controllers hundredGigECtrlr 0/0/0/2 pm current 30-sec pcs

Tue Nov 19 09:17:26.684 UTC

show controllers

Ethernet PCS in the current interval [09:17:00 - 09:17:26 Tue Nov 19 2019]

```

Ethernet PCS current bucket type : Valid
BIP[00] : 0 Threshold : 0 TCA(enable) : NO
BIP[01] : 0 Threshold : 0 TCA(enable) : NO
BIP[02] : 0 Threshold : 0 TCA(enable) : NO
BIP[03] : 0 Threshold : 0 TCA(enable) : NO
BIP[04] : 0 Threshold : 0 TCA(enable) : NO
BIP[05] : 0 Threshold : 0 TCA(enable) : NO
BIP[06] : 0 Threshold : 0 TCA(enable) : NO
BIP[07] : 0 Threshold : 0 TCA(enable) : NO
BIP[08] : 0 Threshold : 0 TCA(enable) : NO
BIP[09] : 0 Threshold : 0 TCA(enable) : NO
BIP[10] : 0 Threshold : 0 TCA(enable) : NO
BIP[11] : 0 Threshold : 0 TCA(enable) : NO
BIP[12] : 0 Threshold : 0 TCA(enable) : NO
BIP[13] : 0 Threshold : 0 TCA(enable) : NO
BIP[14] : 0 Threshold : 0 TCA(enable) : NO
BIP[15] : 0 Threshold : 0 TCA(enable) : NO
BIP[16] : 0 Threshold : 0 TCA(enable) : NO
BIP[17] : 0 Threshold : 0 TCA(enable) : NO
BIP[18] : 0 Threshold : 0 TCA(enable) : NO
BIP[19] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[00] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[01] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[02] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[03] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[04] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[05] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[06] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[07] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[08] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[09] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[10] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[11] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[12] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[13] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[14] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[15] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[16] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[17] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[18] : 0 Threshold : 0 TCA(enable) : NO
FRM-ERR[19] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[00] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[01] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[02] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[03] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[04] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[05] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[06] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[07] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[08] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[09] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[10] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[11] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[12] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[13] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[14] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[15] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[16] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[17] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[18] : 0 Threshold : 0 TCA(enable) : NO
BAD-SH[19] : 0 Threshold : 0 TCA(enable) : NO
ES : 0 Threshold : 0 TCA(enable) : NO

```

```

SES : 0 Threshold : 0 TCA(enable) : NO
UAS : 0 Threshold : 0 TCA(enable) : NO
ES-FE : 0 Threshold : 0 TCA(enable) : NO
SES-FE : 0 Threshold : 0 TCA(enable) : NO
UAS-FE : 0 Threshold : 0 TCA(enable) : NO

Last clearing of "show controllers ETHERNET " counters never
RP/0/RP0/CPU0:ios#

```

The following is a sample to view the historical performance monitoring parameters for Ethernet controller in 30-second intervals.

```
RP/0/RP0/CPU0:ios#show controllers hundredGigECtrlr 0/0/0/2 pm history 30-sec pcs 1
```

```
Tue Nov 19 09:27:49.169 UTC
```

```
Ethernet PCS in the current interval [09:27:00 - 09:27:30 Tue Nov 19 2019]
```

```

Ethernet PCS current bucket type : Valid
BIP[00] : 0
BIP[01] : 0
BIP[02] : 0
BIP[03] : 0
BIP[04] : 0
BIP[05] : 0
BIP[06] : 0
BIP[07] : 0
BIP[08] : 0
BIP[09] : 0
BIP[10] : 0
BIP[11] : 0
BIP[12] : 0
BIP[13] : 0
BIP[14] : 0
BIP[15] : 0
BIP[16] : 0
BIP[17] : 0
BIP[18] : 0
BIP[19] : 0
FRM-ERR[00] : 0
FRM-ERR[01] : 0
FRM-ERR[02] : 0
FRM-ERR[03] : 0
FRM-ERR[04] : 0
FRM-ERR[05] : 0
FRM-ERR[06] : 0
FRM-ERR[07] : 0
FRM-ERR[08] : 0
FRM-ERR[09] : 0
FRM-ERR[10] : 0
FRM-ERR[11] : 0
FRM-ERR[12] : 0
FRM-ERR[13] : 0
FRM-ERR[14] : 0
FRM-ERR[15] : 0
FRM-ERR[16] : 0
FRM-ERR[17] : 0
FRM-ERR[18] : 0
FRM-ERR[19] : 0
BAD-SH[00] : 0
BAD-SH[01] : 0
BAD-SH[02] : 0
BAD-SH[03] : 0
BAD-SH[04] : 0
BAD-SH[05] : 0

```

show controllers

```

BAD-SH[06] : 0
BAD-SH[07] : 0
BAD-SH[08] : 0
BAD-SH[09] : 0
BAD-SH[10] : 0
BAD-SH[11] : 0
BAD-SH[12] : 0
BAD-SH[13] : 0
BAD-SH[14] : 0
BAD-SH[15] : 0
BAD-SH[16] : 0
BAD-SH[17] : 0
BAD-SH[18] : 0
BAD-SH[19] : 0
ES : 0
SES : 0
UAS : 0
ES-FE : 0
SES-FE : 0
UAS-FE : 0

Last clearing of "show controllers ETHERNET " counters never
RP0/RP0/CPU0:ios#

```

The following is a sample to view the Pseudo Random Binary Sequence (PRBS) performance monitoring parameters on the coherentDSP controller.

RP0/RP0/CPU0:ios#show controllers coherentDSP 0/0/0/1 pm current 15-min prbs

```

Mon Feb 13 00:58:48.327 UTC
PRBS in the current interval [00:45:00 - 00:58:48 Mon Feb 13 2019]
PRBS current bucket type : Valid
EBC : 40437528165
FOUND-COUNT : 1 FOUND-AT-TS : 00:51:22 Mon Feb 13 2019
LOST-COUNT : 1 LOST-AT-TS : 00:52:52 Mon Feb 13 2019
CONFIG-PTRN : PRBS_PATTERN_PN31
Last clearing of "show controllers OTU" counters never

```

The following is a sample to view the fastpoll data using the show controller optics fastpoll command:

RP0/RP0/CPU0:G_BLR#sh controllers optics 0/0/0/0 fastpoll
Thu Mar 4 07:36:06.479 UTC

Index Param3	Timestamp	Interval (in msec)	SOP Param1	SOP Param2	SOP
323997 0.00256355479359627	1614843319774376	71	0.75634020566940308	0.65416425466537476	
323997 -0.01290932949632406	1614843319842376	68	0.73894464969635010	0.67360454797744751	
323997 0.01333658862859011	1614843319911376	69	0.74565875530242920	0.66615802049636841	
323997 -0.01788384653627872	1614843319979376	68	0.75981932878494263	0.64986115694046021	
323997 -0.00027466658502817	1614843320034376	55	0.75841546058654785	0.65172278881072998	
323997 -0.01101718191057444	1614843320091376	57	0.75084686279296875	0.66032898426055908	
323997 -0.00756859034299850	1614843320146376	55	0.74700152873992920	0.66475415229797363	
323997 0.01202429272234440	1614843320201376	55	0.74233222007751465	0.66988128423690796	
323997 0.00363170262426138	1614843320259376	58	0.75130468606948853	0.65990173816680908	

323997	1614843320316376	57	0.75209814310073853	0.65892511606216431
-0.01126132998615503				
323997	1614843320372376	56	0.74962615966796875	0.66182440519332886
0.00259407330304384				
323997	1614843320427376	55	0.75087738037109375	0.66035950183868408
-0.00869777519255877				
323997	1614843320483376	56	0.75930052995681763	0.65068513154983521
-0.00244148075580597				

The following is a sample to view the 8QAM modulation on the 200G muxponder mode for the OTN-XP card.

```
RP/0/RP0/CPU0:ios#show controllers optics 0/1/0/12
Wed Jun 2 17:17:29.652 UTC
Controller State: Up
Transport Admin State: In Service
Laser State: On
LED State: Green
Optics Status

    Optics Type: <Unknown> DWDM
    DWDM carrier Info: C BAND, MSA ITU Channel=61, Frequency=193.10THz,
    Wavelength=1552.524nm

    Alarm Status:
    -----
    Detected Alarms: None

    LOS/LOL/Fault Status:

    Alarm Statistics:
    -----
    HIGH-RX-PWR = 0          LOW-RX-PWR = 1
    HIGH-TX-PWR = 0          LOW-TX-PWR = 1
    HIGH-LBC = 0             HIGH-DGD = 0
    OOR-CD = 0               OSNR = 1
    WVL-OOL = 0              MEA = 0
    IMPROPER-REM = 0
    TX-POWER-PROV-MISMATCH = 0
    Laser Bias Current = 0.0 %
    Actual TX Power = 0.97 dBm
    RX Power = 1.47 dBm
    RX Signal Power = 17.67 dBm
    Frequency Offset = 82 MHz

    Performance Monitoring: Enable

    THRESHOLD VALUES
    -----
    Parameter      High Alarm  Low Alarm  High Warning  Low Warning
    -----          -----       -----       -----        -----
    Rx Power Threshold(dBm)   3.0        -31.5       0.0         0.0
    Tx Power Threshold(dBm)   3.0        -12.0       0.0         0.0
    LBC Threshold(mA)        N/A        N/A        0.00        0.00

    LBC High Threshold = 90 %
    Configured Tx Power = 1.00 dBm
    Configured CD High Threshold = 96000 ps/nm
    Configured CD lower Threshold = -96000 ps/nm
    Configured OSNR lower Threshold = 13.70 dB
```

show controllers

```
Configured DGD Higher Threshold = 67.00 ps
Baud Rate = 42.2082633972 GBd
Bits per Symbol = 3.0000000000 bits/symbol
Modulation Type: 8QAM
Chromatic Dispersion 2 ps/nm
Configured CD-MIN -48000 ps/nm CD-MAX 48000 ps/nm
Polarization Mode Dispersion = 0.0 ps
Second Order Polarization Mode Dispersion = 72.00 ps^2
Optical Signal to Noise Ratio = 34.10 dB
SNR = 18.40 dB
Polarization Dependent Loss = 1.20 dB
Polarization Change Rate = 0.00 rad/s
Differential Group Delay = 2.00 ps
```

Transceiver Vendor Details

```
Form Factor : Not set
Fiber Connector Type: Not Set
Otn Application Code: Not Set
Sonet Application Code: Not Set
Ethernet Compliance Code: Not set
```

Transceiver Temperature : 46 Celsius

```
AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds
```

The following sample verifies the alarm correlation on the inverse muxponder configuration on the OTN-XP card. When trunk port 12 is shut down, LOS alarm is raised and the trunk port 13 also goes down.

```
RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/2/0/12
Thu Sep 30 14:12:54.604 UTC

Port : CoherentDSP 0/2/0/12
Controller State : Down
Inherited Secondary State : Normal
Configured Secondary State : Normal
Derived State : In Service
Loopback mode : None
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 200.0Gb/s

Alarm Information:
LOS = 2 LOF = 0 LOM = 0
OOF = 1 OOM = 0 AIS = 1
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 1
FLEXO-LOF = 0
Detected Alarms : LOS

Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00
Q-Factor : 0.00 dB

Q-Margin : 0.00dB
```

```

TTI :
    Remote IP addr : 0.0.0.0

FEC mode : O_FEC

Flexo-Mode : Enable
Flexo Details:
    Tx GID : 1
    TX IID : 1, 2,
    Rx GID : 0
    RX IID : 0, 0,

Flexo Peers Information:
    Controller : CoherentDSP0_2_0_13
    OTUCn rate : OTUC2

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/2/0/13
Thu Sep 30 14:12:59.330 UTC

Port : CoherentDSP 0/2/0/13
Controller State : Down
Inherited Secondary State : Normal
Configured Secondary State : Normal
Derived State : In Service
Loopback mode : None
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 200.0Gb/s

Alarm Information:
LOS = 1 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 1
FLEXO-LOF = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00
Q-Factor : 15.80 dB

Q-Margin : 9.50dB

TTI :
    Remote IP addr : 0.0.0.0

FEC mode : O_FEC

Flexo-Mode : Enable
Flexo Details:
    Tx GID : 1
    TX IID : 3, 4,
    Rx GID : 1
    RX IID : 3, 4,

```

show controllers

```

Flexo Peers Information:
    Controller : CoherentDSP0_2_0_12
    OTUCn rate : OTUC2

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

The following sample verifies the loopback on the inverse muxponder configuration on the OTN-XP
card:

RP0/RP0/CPU0:ios#show controllers coherentDSP 0/2/0/12
Thu Sep 30 14:17:04.411 UTC

Port : CoherentDSP 0/2/0/12
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Internal
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 200.0Gb/s

Alarm Information:
LOS = 2 LOF = 0 LOM = 0
OOF = 1 OOM = 0 AIS = 1
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 1
FLEXO-LOF = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 2.46E-08
POSTFEC BER : 0.00E+00
Q-Factor : 14.60 dB

Q-Margin : 8.30dB

TTI :
    Remote hostname : ios
    Remote interface : CoherentDSP 0/2/0/12
    Remote IP addr : 0.0.0.0

FEC mode : O_FEC

Flexo-Mode : Enable
Flexo Details:
    Tx GID : 1
    TX IID : 1, 2,
    Rx GID : 1
    RX IID : 1, 2,

Flexo Peers Information:
    Controller : CoherentDSP0_2_0_13
    OTUCn rate : OTUC2

AINS Soak : None

```

```

AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

RP/0/RP0/CPU0:ios#sh controllers coherentDSP 0/2/0/13
Thu Sep 30 14:17:08.140 UTC

Port : CoherentDSP 0/2/0/13
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Internal
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 200.0Gb/s

Alarm Information:
LOS = 1 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 1
FLEXO-LOF = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00
Q-Factor : 15.70 dB

Q-Margin : 9.50dB

TTI :
      Remote IP addr : 0.0.0.0

FEC mode : O_FEC

Flexo-Mode : Enable
Flexo Details:
      Tx GID : 1
      TX IID : 3, 4,
      Rx GID : 1
      RX IID : 3, 4,

Flexo Peers Information:
      Controller : CoherentDSP0_2_0_12
      OTUCn rate : OTUC2

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

The following is a sample of an encryption configuration on an ODUC4 controller.

```

show controllers odusc4 0/0/0/12 otnsec

Wed Sep 28 23:17:15.395 UTC
Controller Name : ODUC4 0/0/0/12
Source ip : 10.1.1.1
Destination ip : 10 .1.1.2

```

```
show access-lists ipv4
```

```

Session id : 99
IKEv2 profile : profile_all_in_one
Session State : SECURED

Otnsec policy name : otnsecpolicy1
cipher-suite : AES-GCM-256
security-policy : Must Secure
sak-rekey-interval : 120
Time to rekey : 103
Time to Expire : 1284201

Programming Status :
Inbound SA(Rx) :
    AN[1] :
        SPI : 0x6301
Outbound SA(Tx) :
    AN[0] :
        SPI : None
    AN[1] :
        SPI : 0x6301
RP/0/RP0/CPU0:ios#
```

show access-lists ipv4

To display the contents of current IPv4 access lists, use the **show access-lists ipv4** command in EXEC mode.

```
show access-lists ipv4 [interface MgmtEth R/S/I/P | maximum [detail] | summary [access-list-name]
] | usage pfilter location {location node-id | all} | access-list-name [sequence-number | usage
pfilter location {location node-id | all} ] ]
```

Syntax Description	
R/S/I/P	Rack/Slot/Instance/Port/ number of the interface.
access-list-name	(Optional) Name of a particular IPv4 access list. The name cannot contain a space or quotation mark; it may contain numbers.
location number	Location of a particular IPv4 access list.
location/node-id	(Optional) Location of a particular IPv4 access list. The node-id argument is entered in the rack/slot/module notation.
usage	(Optional) Displays the usage of the access list on a given line card.
pfilter	(Optional) Displays the packet filtering usage for the specified line card.
summary	Displays a summary of all current IPv4 access lists.
sequence-number	(Optional) Sequence number of a particular IPv4 access list.
maximum	Displays the current maximum number of configurable IPv4 accesscontrol lists (ACLs) and access control entries (ACEs).
detail	(Optional) Displays complete out-of-resource (OOR) details.
all	(Optional) Displays the location of all the line cards.

Command Default	Displays all IPv4 access lists.	
Command Modes	EXEC	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.
Usage Guidelines	<p>Use the show access-lists ipv4 command to display the contents of all IPv4 access lists. To display the contents of a specific IPv4 access list, use the name argument. Use the <i>sequence-number</i> argument to specify the sequence number of the access list.</p> <p>Use the show access-lists ipv4 summary command to display a summary of all current IPv4 access lists. To display a summary of a specific IPv4 access list, use the name argument.</p> <p>Use the show access-lists ipv4 maximum detail command to display the OOR details for IPv4 access lists. OOR limits the number of ACLs and ACEs that can be configured in the system. When the limit is reached, configuration of new ACLs or ACEs is rejected.</p>	
Example	<p>In the following example, the contents of all IPv4 access lists are displayed:</p> <pre>RP/0/RP0/CPU0:ios# show access-lists ipv4</pre> <pre>RP/0/RP0/CPU0:ios#show access-lists ipv4 Wed Jan 17 09:52:12.448 IST ipv4 access-list IPV4_ICMP_DENY 10 deny icmp any any (8 matches) 20 permit ipv4 any any (106 matches) ipv4 access-list IPV4_ROUTER_FWD_TELNET_TRAFFIC_DENY 10 deny tcp any any eq telnet (3 matches) 20 permit ipv4 any any (6 matches)</pre>	

show access-lists ipv6

To display the contents of current IPv6 access lists, use the **show access-lists ipv6** command in EXEC mode.

```
show access-lists ipv6 [interface MgmtEth R/S/I/P] | maximum [detail] | summary [access-list-name]
| usage pfilter location {location node-id | all} | access-list-name [sequence-number | usage
pfilter location {location node-id | all} ] ]
```

Syntax Description	<i>R/S/I/P</i>	Rack/Slot/Instance/Port/ number of the interface.
	<i>access-list-name</i>	(Optional) Name of a particular IPv4 access list. The name cannot contain a space or quotation mark; it may contain numbers.
	location <i>number</i>	Location of a particular IPv4 access list.
	location <i>node-id</i>	(Optional) Location of a particular IPv4 access list. The node-id argument is entered in the rack/slot/module notation.

show access-lists ipv6

usage	(Optional) Displays the usage of the access list on a given line card.
pfilter	(Optional) Displays the packet filtering usage for the specified line card.
summary	Displays a summary of all current IPv4 access lists.
<i>sequence-number</i>	(Optional) Sequence number of a particular IPv4 access list.
maximum	Displays the current maximum number of configurable IPv4 accesscontrol lists (ACLs) and access control entries (ACEs).
detail	(Optional) Displays complete out-of-resource (OOR) details.
all	(Optional) Displays the location of all the line cards.

Command Default	Displays all IPv6 access lists.				
Command Modes	EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.1</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command is introduced.
Release	Modification				
Release 7.0.1	This command is introduced.				

Usage Guidelines The **show access-lists ipv6** command is similar to the **show access-lists ipv4** command, except that it is IPv6 specific.

Use the **show access-lists ipv6** command to display the contents of all IPv6 access lists. To display the contents of a specific IPv6 access list, use the name argument. Use the *sequence-number* argument to specify the sequence number of the access list.

Use the **show access-lists ipv6 summary** command to display a summary of all current IPv6 access lists. To display a summary of a specific IPv6 access list, use the name argument.

Use the **show access-lists ipv6 maximum detail** command to display the OOR details for IPv6 access lists. OOR limits the number of ACLs and ACEs that can be configured in the system. When the limit is reached, configuration of new ACLs or ACEs is rejected.

Example

In the following example, the contents of all IPv6 access lists are displayed:

RP/0/RP0/CPU0:ios#**show access-lists ipv6**

```

Wed Jan 17 09:52:14.591 IST
ipv6 access-list IPV6_ROUTER_FWD_TELNET_TRAFFIC_DENY
10 deny tcp any any eq telnet (3 matches)
20 permit ipv6 any any (5 matches)
ipv6 access-list IPV6_SSH_DENY
10 deny tcp any any eq ssh (9 matches)
20 permit ipv6 any any (100 matches)

```

show environment

To display environmental monitor parameters for the system, use the **show environment** command in administration EXEC mode.

```
show environment [ all | fan | power | voltages | current | trace | temperatures ] [ location | location ]
```

Syntax Description

all	(Optional) Displays information for all the environmental monitor parameters.
fan	(Optional) Displays information about the fans.
power	(Optional) Displays power supply voltage and current information.
voltages	(Optional) Displays system voltage information.
current	(Optional) Displays current sensor information.
temperatures	(Optional) Displays system temperature information.
trace	(Optional) Displays trace data for environment monitoring.
location <i>location</i>	(Optional) Enter the location for which the environmental information needs to be displayed.

Command Default

All environmental monitor parameters are displayed.

Command Modes

Administration EXEC

Command History

Release	Modification
7.0.1	This command was introduced.

Usage Guidelines

The **show environment** command displays information about the hardware that is installed in the system, including fans, power supply voltage, current information, and temperatures.

Example

The following example shows sample output from the **show environment** command with the **fan** keyword.

```
sysadmin-vm:0_RP0# show environment fan
```

```
Wed Mar 20 04:40:02.510 UTC+00:00
=====
                                         Fan speed (rpm)
Location    FRU Type          FAN_0    FAN_1
-----
0/FT0       NCS1K4-FAN      7020     6960
0/FT1       NCS1K4-FAN      6750     6720
0/FT2       NCS1K4-FAN      6750     6720
```

show environment

```
0/PM0      NCS1K4-AC-PSU      24800  23680
0/PM1      NCS1K4-AC-PSU      14240  14176
```

The following example shows sample output from the **show environment** command with the **temperatures** keyword.

```
sysadmin-vm:0_RP0# show environment temperatures location 0/RP0
```

```
Wed Mar 20 04:40:48.518 UTC+00:00
=====
Location  TEMPERATURE          Value   Crit Major Minor Minor Major Crit
Sensor       (deg C)        (Lo)  (Lo)  (Lo)  (Hi)  (Hi)  (Hi)
-----
0/RP0
    TEMP_LOCAL           29     -10    -5     0    55    65    70
    TEMP_REMOTE1         30     -10    -5     0    55    65    70
    TEMP_CPU_DIE         30     -10    -5     0    75    80    90
```

The following example shows sample output from the **show environment** command with the **power** keyword.

```
sysadmin-vm:0_RP0# show environment power
```

```
Wed Mar 20 04:41:39.990 UTC+00:00
=====
CHASSIS LEVEL POWER INFO: 0
=====
Total output power capacity (N + 1) : 2000W + 0W
Total output power required       : 1430W
Total power input                 : 1075W
Total power output                : 1009W

Power Group 0:
=====
Power      Supply      -----Input---  -----Output--- Status
Module     Type        Volts       Amps      Volts       Amps
-----
0/PM0      2kW-AC     0.0        0.0      0.0        0.0     FAILED or NO PWR

Total of Power Group 0:      0W/ 0.0A      0W/ 0.0A

Power Group 1:
=====
Power      Supply      -----Input---  -----Output--- Status
Module     Type        Volts       Amps      Volts       Amps
-----
0/PM1      2kW-AC     228.8      4.7      12.1      83.4     OK

Total of Power Group 1:      1075W/ 4.7A      1009W/ 83.4A

=====
Location   Card Type      Power      Power      Status
          Allocated   Used
          Watts       Watts
-----
0/0        NCS1K4-1.2T-K9  260        -        ON
0/1        NCS1K4-1.2T-K9  260        -        ON
0/2        NCS1K4-1.2T-K9  260        -        ON
0/3        NCS1K4-1.2T-K9  260        -        ON
0/RP0     NCS1K4-CNTLR-K9  55         -        ON
0/FT0     NCS1K4-FAN       100        -        ON
```

0/FT1	NCS1K4-FAN	100	-	ON
0/FT2	NCS1K4-FAN	100	-	ON
0/SC0	NCS1004	35	-	ON

The following example shows sample output from the **show environment** command with the **voltages** keyword.

```
sysadmin-vm:0_RP0# show environment voltages location 0/RP0
```

```
Wed Mar 20 04:43:04.524 UTC+00:00
=====
Location VOLTAGE           Value   Crit Minor Minor   Crit
          Sensor            (mV)    (Lo)  (Lo)  (Hi)  (Hi)
-----
0/RP0
ADM1266_VH1_12V      11982  10800 11040 12960 13200
ADM1266_VH3_3V3       3303   3036 3135  3465  3564
ADM1266_VH4_2V5       2493   2300 2375  2625  2700
ADM1266_VP1_1V8       1794   1656 1710  1890  1944
ADM1266_VP2_1V2       1189   1104 1140  1260  1296
ADM1266_3V3_STAND_BY 3303   3036 3135  3465  3564
ADM1266_VP4_3V3_CPU   3301   3036 3135  3465  3564
ADM1266_VP5_2V5_CPU   2490   2300 2375  2625  2700
ADM1266_VP6_1V8_CPU   1796   1656 1710  1890  1944
ADM1266_VP7_1V24_VCCREF 1233   1140 1178  1302  1339
ADM1266_VP8_1V05_CPU   1047   966  997  1102  1134
ADM1266_VP9_1V2_DDR_VDDQ 1200   1104 1140  1260  1296
ADM1266_VP10_1V0_VCCRAM 1056   500  650  1300  1400
ADM1266_VP11_VNN       876    400  550  1300  1400
ADM1266_VP12_VCCP      1062   300  450  1300  1400
ADM1266_VP13_0V6_VTT    600    552  570  630  648
ADM1293_DB_5V0         5014   4600 4750  5250  5400
ADM1293_DB_3V3         3317   3036 3135  3465  3564
ADM1293_DB_5V0_USB_0   5018   4000 4500  5500  6000
ADM1293_DB_5V0_USB_1   5036   4000 4500  5500  6000
ADM1293_MB_5V0_PMODO   4932   4600 4750  5250  5400
ADM1293_MB_5V0_PMOD1   5012   4600 4750  5250  5400
ADM1293_MB_2V5_PLL     2485   2300 2375  2625  2700
```

show hw-module

To display the details of the muxponder slice, Field Programmable Devices (FPDs), and the card configuration in regen mode, use the **show hw-module** in XR EXEC or administration EXEC mode.

```
show hw-module { fpd | location location [ mxponder | mxponder-slice | regen | 
xponder capabilities ] }
slicenumber
```

Syntax Description	fpd	Displays the status of FPDs installed.
	location <i>location</i>	Specifies the location.
	mxponder	Displays information for all the slices of the muxponder.
	mxponder-slice <i>slicenumber</i>	Displays information for a specific slice of the muxponder. The valid values of <i>slicenumber</i> are 0 and 1.

show hw-module

regen	Displays information of card configuration in regen mode.
xponder capabilities	Displays the client ports that are mapped to each trunk port along with the corresponding trunk rates and client rates.

Command Default None

Command Modes XR EXEC
Administration EXEC

Command History	Release	Modification
	Release 7.0.1	This command was introduced.
	Release 7.1.1	regen keyword was added.
	Release 7.3.2	xponder capabilities keyword was added.

Usage Guidelines If the ISO image has new version of FPD, the Status column in **show hw-module fpd** command shows NEED UPGD. If the upgrade is required, use the **upgrade hw-module location all fpd fpd_device_name** command to start the upgrade. When the upgrade starts, the Status column in **show hw-module fpd** command sequentially shows UPGD PREP, UPGRADING, and the percentage of upgrade completion. After the upgrade is completed, the Status column shows RLOAD REQ if the ISO image requires reload; otherwise the Status column shows CURRENT.



Note The upgrade of LC_OPT_MOD_FW FPD affects traffic. Hence, the user must perform this upgrade during a maintenance window.

If reload is required:

Reload the line card or use the **admin hw-module location all reload** command to reboot NCS 1004. After the reload is completed, the new FPGA runs the current version.

Example

```
RP/0/RP0/CPU0:ios#show hw-module location 0/2 mxponder
Fri Mar 15 11:48:48.344 IST

Location:          0/2
Client Bitrate:    100GE
Trunk Bitrate:     500G
Status:            Provisioned
LLDP Drop Enabled: FALSE
Client Port        Mapper/Trunk Port      CoherentDSP0/2/0/0
CoherentDSP0/2/0/1                           Traffic Split Percentage

                                         ODU40/2/0/0/1          100
                                         0
                                         ODU40/2/0/0/2          100

HundredGigECtrlr0/2/0/2
HundredGigECtrlr0/2/0/3
```

0		
HundredGigEController0/2/0/4	ODU40/2/0/0/3	100
0		
HundredGigEController0/2/0/5	ODU40/2/0/0/4	100
0		
HundredGigEController0/2/0/6	ODU40/2/0/0/5	100
0		
HundredGigEController0/2/0/7	ODU40/2/0/1/1	0
100		
HundredGigEController0/2/0/8	ODU40/2/0/1/2	0
100		
HundredGigEController0/2/0/9	ODU40/2/0/1/3	0
100		
HundredGigEController0/2/0/10	ODU40/2/0/1/4	0
100		
HundredGigEController0/2/0/11	ODU40/2/0/1/5	0
100		

The following is a sample output of all the muxponder slice 0 configurations.

```
RP/0/RP0/CPU0:ios#show hw-module location 0/1 muxponder-slice 0
Fri Mar 15 06:04:18.348 UTC

Location:          0/1
Slice ID:         0
Client Bitrate:   100GE
Trunk Bitrate:    500G
Status:            Provisioned
LLDP Drop Enabled: FALSE
Client Port        Mapper/Trunk Port      CoherentDSP0/1/0/0
                    Traffic Split Percentage

HundredGigEController0/1/0/2      ODU40/1/0/0/1      100
HundredGigEController0/1/0/3      ODU40/1/0/0/2      100
HundredGigEController0/1/0/4      ODU40/1/0/0/3      100
HundredGigEController0/1/0/5      ODU40/1/0/0/4      100
HundredGigEController0/1/0/6      ODU40/1/0/0/5      100
```

The following is a sample output of all the muxponder slice 1 configurations.

```
RP/0/RP0/CPU0:ios#show hw-module location 0/1 muxponder-slice 1
Fri Mar 15 06:11:50.020 UTC

Location:          0/1
Slice ID:         1
Client Bitrate:   100GE
Trunk Bitrate:    400G
Status:            Provisioned
LLDP Drop Enabled: TRUE
Client Port        Mapper/Trunk Port      CoherentDSP0/1/0/1
                    Traffic Split Percentage

HundredGigEController0/1/0/8      ODU40/1/0/1/1      100
HundredGigEController0/1/0/9      ODU40/1/0/1/2      100
HundredGigEController0/1/0/10     ODU40/1/0/1/3      100
HundredGigEController0/1/0/11     ODU40/1/0/1/4      100
```

The following is a sample output of card configuration in regen mode.

```
RP/0/RP0/CPU0:ios#show hw-module location 0/0 regen
Mon Mar 25 09:50:42.936 UTC

Location:          0/0
Trunk Bitrate:    400G
```

show inventory

```
Status: Provisioned
East Port West Port
CoherentDSP0/0/0/0 CoherentDSP0/0/0/1
```

The following shows the muxponder slice 0 configurations where the client ports that are mapped to each trunk port are displayed along with the corresponding trunk rates and client rates.

```
RP/0/RP0/CPU0:ios#show hw-module location 0/1 xponder-capabilities mxponder-slice 0
Fri Aug 13 18:21:43.931 UTC

Location: 0/1

Trunk-Port(s): 11

Port Group Restrictions:
Shared-Client-Group-Bandwidth Shared-Group-Client-Ports
400G 1, 6, 7, 10

Trunk-bandwidth: 400G
Client-port Supported client rates
1 100GE
6 100GE
7 100GE
10 100GE

Trunk-bandwidth: 300G
Client-port Supported client rates
1 100GE
7 100GE
10 100GE

Trunk-bandwidth: 200G
Client-port Supported client rates
7 100GE
10 100GE
```

show inventory

To retrieve and display the physical inventory information, use the **show inventory** command in XR EXEC or administration EXEC mode.

XR EXEC Mode

```
show inventory [all | oid | raw | location location ]
```

Administration EXEC Mode

```
show inventory [all | chassis | fan | power | raw | location location ]
```

Syntax Description

all	(Optional) Displays inventory information for all the physical entities.
fan	(Optional) Displays inventory information for the fans.
power	(Optional) Displays inventory information for the power supply.
raw	(Optional) Displays raw information about the chassis for diagnostic purposes.

chassis	(Optional) Displays inventory information for the entire chassis.
location <i>location</i>	(Optional) Displays inventory information for a specific node, or for all nodes in the chassis.
oid	(Optional) Displays inventory information along with oid.

Command Default All hardware inventory information is displayed.

Command Modes XR EXEC
Administration EXEC

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines Enter the **show inventory** command with the **raw** keyword to display every RFC 2737 entity installed in NCS 1004, including those without a PID, unique device identifier (UDI), or other physical identification. The **raw** keyword is primarily intended for troubleshooting problems with the **show inventory** command itself.

Example

The following examples show sample output from the **show inventory** command in both EXEC and Administration EXEC modes.

sysadmin-vm:0_RP0# **show inventory**

```
Thu Mar 7 12:49:15.974 UTC+00:00

Name: Rack 0             Descr: Network Convergence System 1004 Chassis
PID: NCS1004              VID: V00                         SN: CAT2217B020

Name: 0/0-Optics0/0/0/2   Descr: Cisco QSFP-100G-LR4-S Pluggable Optics Module
PID: QSFP-100G-LR4-S     VID: V01                         SN: FNS20530F3H

Name: 0/0-Optics0/0/0/3   Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module
PID: QSFP-100G-CWDM4-S   VID: V02                         SN: JFQ22108035

Name: 0/0-Optics0/0/0/4   Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module
PID: QSFP-100G-CWDM4-S   VID: V02                         SN: JFQ22108033

Name: 0/0-Optics0/0/0/5   Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module
PID: QSFP-100G-CWDM4-S   VID: V02                         SN: FNS22150QF8

Name: 0/0-Optics0/0/0/6   Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module
PID: QSFP-100G-CWDM4-S   VID: V02                         SN: FNS22150UJQ

Name: 0/0-Optics0/0/0/7   Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module
PID: QSFP-100G-CWDM4-S   VID: V02                         SN: FNS22150Q9P

Name: 0/0-Optics0/0/0/8   Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module
PID: QSFP-100G-CWDM4-S   VID: V02                         SN: FNS22150TE5

Name: 0/0-Optics0/0/0/9   Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module
PID: QSFP-100G-CWDM4-S   VID: V02                         SN: FNS22150TCP
```

show inventory

Name: 0/0-Optics0/0/0/10 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150LDS
Name: 0/0-Optics0/0/0/11 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150L5H
Name: 0/0-Optics0/0/0/12 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150SED
Name: 0/0-Optics0/0/0/13 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150TUV
Name: 0/0 PID: NCS1K4-1.2T-K9	Descr: NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card VID: V00 SN: CAT2250B0A9
Name: 0/1-Optics0/1/0/2 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ22108003
Name: 0/1-Optics0/1/0/3 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150QD8
Name: 0/1-Optics0/1/0/4 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ22108004
Name: 0/1-Optics0/1/0/5 PID: QSFP-100G-SM-SR	Descr: Cisco 100G QSFP28 SM-SR Pluggable Optics Module VID: V02 SN: FNS22070GFW
Name: 0/1-Optics0/1/0/6 PID: QSFP-100G-SM-SR	Descr: Cisco 100G QSFP28 SM-SR Pluggable Optics Module VID: V01 SN: FNS20510ZFP
Name: 0/1-Optics0/1/0/7 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150QFJ
Name: 0/1-Optics0/1/0/8 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150TZF
Name: 0/1-Optics0/1/0/9 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150UJS
Name: 0/1-Optics0/1/0/10 PID: QSFP-100G-SM-SR	Descr: Cisco 100G QSFP28 SM-SR Pluggable Optics Module VID: V02 SN: FNS22070GCH
Name: 0/1-Optics0/1/0/11 PID: QSFP-100G-SM-SR	Descr: Cisco 100G QSFP28 SM-SR Pluggable Optics Module VID: V02 SN: FNS22070J79
Name: 0/1-Optics0/1/0/12 PID: QSFP-100G-SM-SR	Descr: Cisco 100G QSFP28 SM-SR Pluggable Optics Module VID: V02 SN: FNS22070GD7
Name: 0/1-Optics0/1/0/13 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150LHE
Name: 0/1 PID: NCS1K4-1.2T-K9	Descr: NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card VID: V00 SN: CAT2223B129
Name: 0/2-Optics0/2/0/2 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ22108001
Name: 0/2-Optics0/2/0/3 PID: LQ210CR-CPA1	Descr: Non-Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: 01 SN: FG4657250006
Name: 0/2-Optics0/2/0/4 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ2210802P

Name: 0/2-Optics0/2/0/5 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ2210802Q
Name: 0/2-Optics0/2/0/6 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ2210802R
Name: 0/2-Optics0/2/0/7 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ2210802U
Name: 0/2-Optics0/2/0/8 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ2146802T
Name: 0/2-Optics0/2/0/9 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ2210800G
Name: 0/2-Optics0/2/0/10 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ2210802M
Name: 0/2-Optics0/2/0/11 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: JFQ2210800P
Name: 0/2 PID: NCS1K4-1.2T-L-K9	Descr: NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card - Licensed VID: V00 SN: CAT2250B09F
Name: 0/3-Optics0/3/0/2 PID: ONS-QSFP28-LR4	Descr: Non-Cisco 100G QSFP28 LR4 Pluggable Optics Module VID: V01 SN: FNS20500RVT
Name: 0/3-Optics0/3/0/3 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S1D4
Name: 0/3-Optics0/3/0/4 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S16R
Name: 0/3-Optics0/3/0/5 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S16W
Name: 0/3-Optics0/3/0/6 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S17H
Name: 0/3-Optics0/3/0/7 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S1BA
Name: 0/3-Optics0/3/0/8 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S16G
Name: 0/3-Optics0/3/0/9 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S17N
Name: 0/3-Optics0/3/0/10 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S15W
Name: 0/3-Optics0/3/0/11 PID: QSFP-100G-CWDM4-S	Descr: Cisco 100G QSFP28 CWDM4 Pluggable Optics Module VID: V02 SN: FNS22150TES
Name: 0/3-Optics0/3/0/12 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S16S
Name: 0/3-Optics0/3/0/13 PID: QSFP-100G-SR4-S	Descr: Cisco 100GE QSFP28 SR4 Pluggable Optics Module VID: V03 SN: AVF2219S178
Name: 0/3 PID: NCS1K4-1.2T-K9	Descr: NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card VID: V00 SN: CAT2236B01A
Name: 0/RP0	Descr: Network Convergence System 1004 Controller

show inventory

PID: NCS1K4-CNTLR-K9	VID: V00	SN: CAT2217B09N
Name: 0/FT0	Descr: Network Convergence System 1004 Fan	
PID: NCS1K4-FAN	VID: V00	SN: CAT2218B12J
Name: 0/FT1	Descr: Network Convergence System 1004 Fan	
PID: NCS1K4-FAN	VID: V00	SN: CAT2218B125
Name: 0/FT2	Descr: Network Convergence System 1004 Fan	
PID: NCS1K4-FAN	VID: V00	SN: CAT2218B124
Name: 0/PM0	Descr: Network Convergence System 1004 AC Power Supply Unit	
PID: NCS1K4-AC-PSU	VID: V00	SN: POG2212CL12
Name: 0/PM1	Descr: Network Convergence System 1004 AC Power Supply Unit	
PID: NCS1K4-AC-PSU	VID: V00	SN: POG2212CL2Q
Name: 0/SC0	Descr: Network Convergence System 1004 Chassis	
PID: NCS1004	VID: V00	SN: CAT2217B020

RP/0/RP0/CPU0:ios# show inventory

Thu Mar 7 10:39:50.321 UTC

NAME: "0/0", DESCRIPTOR: "NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card"

PID: NCS1K4-1.2T-K9 , VID: V00, SN: CAT2250B0A9

NAME: "0/0-Optics0/0/0/2", DESCRIPTOR: "Cisco QSFP-100G-LR4-S Pluggable Optics Module"

PID: QSFP-100G-LR4-S , VID: V01 , SN: FNS20530F3H

NAME: "0/0-Optics0/0/0/3", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ22108035

NAME: "0/0-Optics0/0/0/4", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ22108033

NAME: "0/0-Optics0/0/0/5", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150QF8

NAME: "0/0-Optics0/0/0/6", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150UJQ

NAME: "0/0-Optics0/0/0/7", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150Q9P

NAME: "0/0-Optics0/0/0/8", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150TE5

NAME: "0/0-Optics0/0/0/9", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150TCP

NAME: "0/0-Optics0/0/0/10", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150LDS

NAME: "0/0-Optics0/0/0/11", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150L5H

NAME: "0/0-Optics0/0/0/12", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150SED

NAME: "0/0-Optics0/0/0/13", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"

PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150TUV

NAME: "0/1", DESCRIPTOR: "NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card"

PID: NCS1K4-1.2T-K9 , VID: V00, SN: CAT2223B129

NAME: "0/1-Optics0/1/0/2", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ22108003

NAME: "0/1-Optics0/1/0/3", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150QD8

NAME: "0/1-Optics0/1/0/4", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ22108004

NAME: "0/1-Optics0/1/0/5", DESCRIPTOR: "Cisco 100G QSFP28 SM-SR Pluggable Optics Module"
PID: QSFP-100G-SM-SR , VID: V02 , SN: FNS22070GFW

NAME: "0/1-Optics0/1/0/6", DESCRIPTOR: "Cisco 100G QSFP28 SM-SR Pluggable Optics Module"
PID: QSFP-100G-SM-SR , VID: V01 , SN: FNS20510ZFP

NAME: "0/1-Optics0/1/0/7", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150QFJ

NAME: "0/1-Optics0/1/0/8", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150TZF

NAME: "0/1-Optics0/1/0/9", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150UJS

NAME: "0/1-Optics0/1/0/10", DESCRIPTOR: "Cisco 100G QSFP28 SM-SR Pluggable Optics Module"
PID: QSFP-100G-SM-SR , VID: V02 , SN: FNS22070GCH

NAME: "0/1-Optics0/1/0/11", DESCRIPTOR: "Cisco 100G QSFP28 SM-SR Pluggable Optics Module"
PID: QSFP-100G-SM-SR , VID: V02 , SN: FNS22070J79

NAME: "0/1-Optics0/1/0/12", DESCRIPTOR: "Cisco 100G QSFP28 SM-SR Pluggable Optics Module"
PID: QSFP-100G-SM-SR , VID: V02 , SN: FNS22070GD7

NAME: "0/1-Optics0/1/0/13", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150LHE

NAME: "0/2", DESCRIPTOR: "NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card - Licensed"
PID: NCS1K4-1.2T-L-K9 , VID: V00 , SN: CAT2250B09F

NAME: "0/2-Optics0/2/0/2", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ22108001

NAME: "0/2-Optics0/2/0/3", DESCRIPTOR: "Non-Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: LQ210CR-CPA1 , VID: 01 , SN: FG4657250006

NAME: "0/2-Optics0/2/0/4", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ2210802P

NAME: "0/2-Optics0/2/0/5", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ2210802Q

NAME: "0/2-Optics0/2/0/6", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ2210802R

NAME: "0/2-Optics0/2/0/7", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ2210802U

NAME: "0/2-Optics0/2/0/8", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ2146802T

NAME: "0/2-Optics0/2/0/9", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ2210800G

show inventory

```

NAME: "0/2-Optics0/2/0/10", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ2210802M

NAME: "0/2-Optics0/2/0/11", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: JFQ2210800P

NAME: "0/3", DESCRIPTOR: "NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card"
PID: NCS1K4-1.2T-K9 , VID: V00, SN: CAT2236B01A

NAME: "0/3-Optics0/3/0/2", DESCRIPTOR: "Non-Cisco 100G QSFP28 LR4 Pluggable Optics Module"
PID: ONS-QSFP28-LR4 , VID: V01 , SN: FNS20500RVT

NAME: "0/3-Optics0/3/0/3", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S1D4

NAME: "0/3-Optics0/3/0/4", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S16R

NAME: "0/3-Optics0/3/0/5", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S16W

NAME: "0/3-Optics0/3/0/6", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S17H

NAME: "0/3-Optics0/3/0/7", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S1BA

NAME: "0/3-Optics0/3/0/8", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S16G

NAME: "0/3-Optics0/3/0/9", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S17N

NAME: "0/3-Optics0/3/0/10", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S15W

NAME: "0/3-Optics0/3/0/11", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V02 , SN: FNS22150TES

NAME: "0/3-Optics0/3/0/12", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S16S

NAME: "0/3-Optics0/3/0/13", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S , VID: V03 , SN: AVF2219S178

NAME: "0/RP0", DESCRIPTOR: "Network Convergence System 1004 Controller"
PID: NCS1K4-CNTLR-K9 , VID: V00, SN: CAT2217B09N

NAME: "0/SC0", DESCRIPTOR: "Network Convergence System 1004 Chassis"
PID: NCS1004 , VID: V00, SN: CAT2217B020

NAME: "Rack 0", DESCRIPTOR: "Network Convergence System 1004 Chassis"
PID: NCS1004 , VID: V00, SN: CAT2217B020

NAME: "0/FT0", DESCRIPTOR: "Network Convergence System 1004 Fan"
PID: NCS1K4-FAN , VID: V00, SN: CAT2218B12J

NAME: "0/FT1", DESCRIPTOR: "Network Convergence System 1004 Fan"
PID: NCS1K4-FAN , VID: V00, SN: CAT2218B125

NAME: "0/FT2", DESCRIPTOR: "Network Convergence System 1004 Fan"
PID: NCS1K4-FAN , VID: V00, SN: CAT2218B124

NAME: "0/PM0", DESCRIPTOR: "Network Convergence System 1004 AC Power Supply Unit"

```

```
PID: NCS1K4-AC-PSU      , VID: V00, SN: POG2212CL12
NAME: "0/PM1", DESC: "Network Convergence System 1004 AC Power Supply Unit"
PID: NCS1K4-AC-PSU      , VID: V00, SN: POG2212CL2Q
```

show lc-module (OTN-XP Card)

To display the details of the LC mode configured on the OTN-XP card, use the **show lc-module** in XR EXEC or administration EXEC mode.

show lc-module location *location* lcmode [all]

Syntax Description

location *location* Specifies the location.

lcmode Displays the LC mode configured.

all Displays all type of LC modes that are supported on the OTN-XP card.

Command Default

None

Command Modes

XR EXEC

Administration EXEC

Command History

Release

Release 7.2.1

Modification

This command was introduced.

The following sample displays the LC modes that are configured on the OTN-XP card.

```
RP/0/RP0/CPU0:ios#show lc-module location 0/3 lcmode all
Wed Aug 11 17:06:29.538 UTC
States: A-Available R-Running C-Configured
Node    Lcmode_Supported    Owner    Options (State)        HW_Ver
-----
0/3      Yes                CLI      10G-GREY-MXP (A)    3.0
                                         4x100G-MXP-400G-TXP (A) 2.0
                                         40x10G-4x100G-MXP (A) 3.0
                                         4x100GE-MXP-DD (R/C)   7.0
```

The following sample displays the OTUCn-REGEN LC mode that is configured on the OTN-XP card.

```
RP/0/RP0/CPU0:ios#show lc-module location 0/2 lcmode
Fri Feb  4 17:00:09.842 UTC
```

Node	Lcmode_Supported	Owner	Running	Configured
0/2	Yes	CLI	OTUCn-REGEN	OTUCn-REGEN

The following sample displays the FC-MXP LC mode that is configured on the OTN-XP card.

```
RP/0/RP0/CPU0:ios#show lc-module location 0/2 lcmode
Fri Feb  4 17:00:09.842 UTC
```

Node	Lcmode_Supported	Owner	Running	Configured
------	------------------	-------	---------	------------

show led

0/2	Yes	CLI	OTUCn-REGEN	FC-MXP
-----	-----	-----	-------------	--------

show led

To display the status of various LEDs present in NCS 1004, use the **show led** command in administration EXEC mode.

show led [location *location*]

Syntax Description	location <i>location</i> (Optional) Displays LED information for a specific location.					
Command Default	The status of all the LEDs present in NCS 1004 is displayed.					
Command Modes	Administration EXEC					
Command History	<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Release</th> <th style="width: 70%;">Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>		Release	Modification	Release 7.0.1	This command was introduced.
Release	Modification					
Release 7.0.1	This command was introduced.					
Usage Guidelines	Enter the show LED command in administration EXEC mode to display the status of all the LEDs present in NCS 1004.					

Example

The following example shows sample output from the **show led** command.

```
sysadmin-vm:0_RP0# show led
```

```
Wed Mar 20 04:45:25.457 UTC+00:00
=====
Location   LED Name           Mode    Color
=====
0/0        0/0-Status LED     WORKING GREEN
0/1        0/1-Status LED     WORKING GREEN
0/2        0/2-Status LED     WORKING GREEN
0/3        0/3-Status LED     WORKING GREEN
0/RP0      0/RP0-Attention LED WORKING OFF
                  0/RP0-SYS LED    WORKING AMBER
                  0/RP0-PSU LED    WORKING RED
                  0/RP0-FAN LED    WORKING GREEN
0/FT0      0/FT0-Status LED   WORKING GREEN
0/FT1      0/FT1-Status LED   WORKING GREEN
0/FT2      0/FT2-Status LED   WORKING GREEN
```

0/PM0	0/PM0-Status LED	WORKING	AMBER
0/PM1	0/PM1-Status LED	WORKING	GREEN

show platform

To display information and status for each node in the system, use the **show platform** command in XR EXEC or administration EXEC mode.

Administration EXEC Mode

show platform [{detail | location | slices} location]

XR EXEC Mode

show platform [vm | 0/RP0]

Syntax Description

detail (Optional) Displays the details of node type and state.

location (Optional) Displays the location of node.

slices (Optional) Displays the summary information of each slice in the node.

location (Optional) Node location such as 0/FT0, 0/RP0.

vm (Optional) Displays the virtual machine information of node.

Command Default

The status and information are displayed for all the nodes in the system.

Command Modes

XR EXEC

Administration EXEC

Command History

Release Modification

Release This command was introduced.
7.0.1

Usage Guidelines

Enter the **show platform** command in administration EXEC mode to display the output for the entire system.

Example

The following example shows sample output from the **show platform** command.

```
sysadmin-vm:0_RP0# show platform
```

Wed Mar 20 04:27:21.562 UTC+00:00				
Location	Card Type	HW State	SW State	Config State

0/0	NCS1K4-1.2T-K9	OPERATIONAL	N/A	NSHUT
0/1	NCS1K4-1.2T-K9	OPERATIONAL	N/A	NSHUT

show platform

0/2	NCS1K4-1.2T-K9	OPERATIONAL	N/A	NSHUT
0/3	NCS1K4-1.2T-K9	OPERATIONAL	N/A	NSHUT
0/RP0	NCS1K4-CNTL-R-K9	OPERATIONAL	OPERATIONAL	NSHUT
0/FT0	NCS1K4-FAN	OPERATIONAL	N/A	NSHUT
0/FT1	NCS1K4-FAN	OPERATIONAL	N/A	NSHUT
0/FT2	NCS1K4-FAN	OPERATIONAL	N/A	NSHUT
0/PM0	NCS1K4-AC-PSU	OPERATIONAL	N/A	NSHUT
0/PM1	NCS1K4-AC-PSU	OPERATIONAL	N/A	NSHUT
0/SC0	NCS1004	OPERATIONAL	N/A	NSHUT

The following example shows sample output from the **show platform detail** command.

```
sysadmin-vm:0_RP0# show platform detail
```

```
Wed Mar 20 04:31:02.480 UTC+00:00
MODULE
      HW OPER     SW OPER
LOCATION : PID :           DESCRIPTION :
      VID/SN : STATE : STATE :   CONFIGURATION : HW VERSION : LAST EVENT :
LAST EVENT REASON :
-----  

0/0      NCS1K4-1.2T-K9    NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card
      V00      OPERATIONAL N/A          NSHUT RST      0.1          HW_EVENT_OK
HW READY
0/1      NCS1K4-1.2T-K9    NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card
      V00      OPERATIONAL N/A          NSHUT RST      0.1          HW_EVENT_OK
HW READY
0/2      NCS1K4-1.2T-K9    NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card
      V00      OPERATIONAL N/A          NSHUT RST      0.1          HW_EVENT_OK
HW READY
0/3      NCS1K4-1.2T-K9    NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card
      V00      OPERATIONAL N/A          NSHUT RST      0.1          HW_EVENT_OK
HW READY
0/RP0     NCS1K4-CNTL-R-K9 Network Convergence System 1004 Controller
      V00      OPERATIONAL OPERATIONAL NSHUT RST      0.1          HW_EVENT_OK
HW Event OK
0/FT0     NCS1K4-FAN       Network Convergence System 1004 Fan
      V00      OPERATIONAL N/A          NSHUT RST      0.1          HW_EVENT_OK
HW Operational
0/FT1     NCS1K4-FAN       Network Convergence System 1004 Fan
      V00      OPERATIONAL N/A          NSHUT RST      0.1          HW_EVENT_OK
HW Operational
0/FT2     NCS1K4-FAN       Network Convergence System 1004 Fan
      V00      OPERATIONAL N/A          NSHUT RST      0.1          HW_EVENT_OK
HW Operational
0/PM0     NCS1K4-AC-PSU   Network Convergence System 1004 AC Power Supply Unit
      V00      OPERATIONAL N/A          NSHUT RST      0.0          HW_EVENT_OK
HW Operational
0/PM1     NCS1K4-AC-PSU   Network Convergence System 1004 AC Power Supply Unit
      V00      OPERATIONAL N/A          NSHUT RST      0.0          HW_EVENT_OK
HW Operational
0/SC0     NCS1004        Network Convergence System 1004 Chassis
      V00      OPERATIONAL N/A          NSHUT RST      0.1          HW_EVENT_OK
HW Event OK
```

```
RP/0/RP0/CPU0:ios# show platform
```

```
Wed Mar 20 04:23:12.582 UTC
Node      Type           State      Config state
-----  

0/0      NCS1K4-1.2T-K9  OPERATIONAL  NSHUT
0/1      NCS1K4-1.2T-K9  OPERATIONAL  NSHUT
0/2      NCS1K4-1.2T-K9  OPERATIONAL  NSHUT
```

0/3	NCS1K4-1.2T-K9	OPERATIONAL	NSHUT
0/RP0/CPU0	NCS1K4-CNTLR-K9 (Active)	IOS XR RUN	NSHUT
0/FT0	NCS1K4-FAN	OPERATIONAL	NSHUT
0/FT1	NCS1K4-FAN	OPERATIONAL	NSHUT
0/FT2	NCS1K4-FAN	OPERATIONAL	NSHUT
0/PM0	NCS1K4-AC-PSU	OPERATIONAL	NSHUT
0/PM1	NCS1K4-AC-PSU	OPERATIONAL	NSHUT
0/SCO	NCS1004	OPERATIONAL	NSHUT

signalling refresh out-of-band interval

To specify the out-of-band refresh interval for RSVP, use the **signalling refresh out-of-band interval** command in RSVP controller configuration mode.

signalling refresh out-of-band interval *interval*

Syntax Description	<i>interval</i> Specifies the refresh interval (180-86400 seconds).	
Command Default	45 seconds	
Command Modes	RSVP controller configuration	
Command History	Release	Modification
	7.0.1	This command is introduced.

Usage Guidelines This command applies only to the RSVP sessions associated with GMPLS UNI tunnels.

Example

The following example shows how to specify 200 seconds for the out-of-band interface refresh interval.

```
RP/0/RP0/CPU0:ios(config)#rsvp
RP/0/RP0/CPU0:ios(config-rsvp)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-rsvp-ctrl)#signalling refresh out-of-band interval 200
RP/0/RP0/CPU0:ios(config-rsvp-ctrl)#+
```

signalling refresh out-of-band missed

To specify the number of missed refresh messages allowed before states are deleted for optical tunnels, use the **signalling refresh out-of-band missed** command in RSVP controller configuration mode.

signalling refresh out-of-band missed *mis-count*

Syntax Description	<i>mis-count</i> Number of missed refresh messages allowed before states are deleted for optical tunnels (1-48).
---------------------------	--

Command Default	The default value is 12.	
Command Modes	RSVP controller configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Usage Guidelines This command applies only to the RSVP sessions associated with GMPLS UNI tunnels.

Example

The following example shows how to specify a maximum of 10 messages for the number of allowed missed refresh messages.

```
RP/0/RP0/CPU0:ios(config)#rsrv
RP/0/RP0/CPU0:ios(config-rsvp)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-rsvp-ctrl)#signalling refresh out-of-band missed 10
RP/0/RP0/CPU0:ios(config-rsvp-ctrl)#

```

sks profile

To configure the Session Key Service (SKS) profile with the IP address of the Key Management Entity (KME) server that manages cryptographic keys (dynamic Postquantum Preshared Keys (PPK), use the command **sks profile**.

sks profile *profile-name* **type** { **local** | **remote** } **kme server** **ipv4** *ip4 address* **port** *port number*

Syntax Description	profile-name	Name of the sks profile used in the dynamic PPK configuration.
	type	Configures the type of the server.
	local remote	Indicates whether the server is local or remote server.
	kme server ipv4	Configures the kme server IP address.
	<i>ip4 address</i>	IP address of the kme server.
	port	Configures the specific port number of the server, through which packets will be sent.
	<i>port number</i>	Port number of the server.

Command Modes	Configuration	
Command History	Release	Modification
	Release 24.1.1	This command was introduced

Example

The following example shows how to define a sks profile for dynamic ppk based IKEv2 encryption.

```
RP/0/RP0/CPU0:ios#configure terminal
RP/0/1/CPU0:ios(config)#sks profile qkd type remote
RP/0/1/CPU0:ios(config-sks-profile)#kme server ipv4 192.0.2.34 port 10001
RP/0/RP0/CPU0:ios(config-ikev2-keyring-peer)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

split-client-port-mapping

To configure the trunk port to client port mapping for sub 50G configuration in the split client port mapping mode, use the **split-client-port-mapping** command in muxponder hardware module configuration mode.

split-client-port-mapping
no split-client-port-mapping

Syntax Description	This command has no keywords or arguments.				
Command Default	This command is disabled by default.				
Command Modes	Muxponder hardware module configuration mode (config-hwmod-mxp)				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.5.2</td> <td>This command is introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.5.2	This command is introduced.
Release	Modification				
Release 7.5.2	This command is introduced.				

Example

The following is a sample in which split-client-port-mapping is configured with a 450G trunk payload.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-rate 450G
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#client-rate 100GE
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#split-client-port-mapping
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#end
```

The following is a sample in which split client port-mapping configuration is removed.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#no split-client-port-mapping
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#end
```

subject-name (trustpoint)

subject-name (trustpoint)

To specify the subject name in the certificate request, use the **subject-name** command in trustpoint configuration mode. To clear any subject name from the configuration, use the **no** form of this command.

subject-name [ca-certificate] *subject-name*

Syntax Description	ca-certificate (Optional) Specifies the subject name for the CA certificate for self-enrollment. subject-name (Optional) Specifies the subject name used in the certificate request.	
Command Default	If the <i>subject-name</i> argument is not specified, the fully qualified domain name (FQDN), which is the default subject name, is used.	
Command Modes	Trustpoint configuration	
Command History	Release	Modification
	Release 7.10.1	This command was introduced.
Usage Guidelines	Before you can use the subject-name command, you must enable the crypto ca trustpoint command, which declares the certification authority (CA) that NCS 1004 should use and enters trustpoint configuration mode. The subject-name command is an attribute that can be set for automatic enrollment; thus, issuing this command prevents you from being prompted for a subject name during enrollment.	
Task ID	Task Operations ID	
	crypto read, write	

Examples

The following example shows how to specify the subject name for the frog certificate:

```
RP/0/0R0RSPO/CPU0:ios# configure
RP/0/0R0RSPO/CPU0:ios(config)# crypto ca trustpoint frog
RP/0/0R0RSPO/CPU0:ios(config-trustp)# enrollment url http://frog.phoobin.com
RP/0/0R0RSPO/CPU0:ios(config-trustp)# subject-name OU=Spiral Dept., O=tiedye.com
RP/0/0R0RSPO/CPU0:ios(config-trustp)# ip-address 172.19.72.120
```

This example shows how to specify the subject name for the CA certificate for self-enrollment.

```
RP/0/0R0RSPO/CPU0:ios#configure
RP/0/0R0RSPO/CPU0:ios(config)#crypto ca trustpoint system-trustpoint
RP/0/0R0RSPO/CPU0:ios(config-trustp)#subject-name ca-certificate
CN=labuser-ca,C=US,ST=CA,L=San Jose,O=cisco systems,OU=ASR
RP/0/0R0RSPO/CPU0:ios(config-trustp)#commit
```

tunnel-id

To specify the ID of the GMPLS UNI tunnel, use the **tunnel-id** command in GMPLS UNI controller tunnel-properties configuration sub-mode.

tunnel-id *number*

Syntax Description	<i>number</i> Specifies the tunnel ID.	
Command Default	None	
Command Modes	GMPLS UNI controller tunnel-properties configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

Example

The following example shows how to specify a tunnel ID.

```
RP/0/RP0/CPU0:ios(config)#mpls traffic-eng
RP/0/RP0/CPU0:ios(config-mpls-te)#mpls optical-uni
RP/0/RP0/CPU0:ios(config-te-gmpls)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:ios(config-te-gmpls-tun)#tunnel-id 5
RP/0/RP0/CPU0:ios(config-te-gmpls-tun)#+
```

tunnel-properties

To configure tunnel-specific information for a GMPLS UNI controller, use the **tunnel-properties** command in GMPLS-UNI configuration sub-mode.

tunnel-properties

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	GMPLS UNI configuration	
Command History	Release	Modification
	Release 7.0.1	This command is introduced.

working-controller**Example**

The following example shows how to enter the sub-mode to configure tunnel-specific information for a GMPLS UNI controller.

```
RP/0/RP0/CPU0:ios(config)#mpls traffic-eng
RP/0/RP0/CPU0:ios(config-mpls-te)#mpls optical-uni
RP/0/RP0/CPU0:ios(config-te-gmpls)#controller Optics0/0/0/0
RP/0/RP0/CPU0:ios(config-te-gmpls-cntl)#tunnel-properties
RP/0/RP0/CPU0:ios(config-te-gmpls-tun) #
```

working-controller

To configure an ODUk controller as the working controller in the ODU group controller, use the **working-controller** command in the config mode. To delete an ODUk controller as the working controller in the ODU group controller, use the **no** form of this command.

working-controller [*ODUk R/S/I/P*]
no working-controller [*ODUk R/S/I/P*]

Syntax Description	<i>ODUk</i>	Name of the ODUk controller.				
	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the controller.				
Command Default		None				
Command Modes		Configuration				
Command History		<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.8.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.8.1	This command was introduced.
Release	Modification					
Release 7.8.1	This command was introduced.					

Example

This example shows how to configure an ODU4 controller as the working controller in the ODU group 2 controller:

```
RP/0/RP0:hostname(config)# controller Odu-Group-Mp 2 signal Otn odu-type ODUC4
RP/0/RP0:hostname(config-odu-group-mp 1)# working-controller ODUC4 0/0/0/12
```