



Configure Coherent Probe

Table 1: Feature History

Feature Name	Release Information	Description
DP01QSDD-ZT5-A1 support	Cisco IOS XR Release 25.1.1	The DP01QSDD-ZT5-A1 QDD pluggable is a coherent probe supported for the EDFA2 card. This pluggable supports C-band with tunable frequency. You can plug the coherent probe pluggable to establish a link for the first time in DWDM.

- [DP01QSDD-ZT5-A1 pluggable](#) , on page 1
- [Coherent Probe on EDFA2 card](#), on page 2
- [Configure coherent probe on the EDFA2 card](#), on page 2
- [Configure PRBS on EDFA2 card](#), on page 6

DP01QSDD-ZT5-A1 pluggable

The EDFA2 card supports a QSFP-DD pluggable transceiver that generates tunable C-band frequency. You can establish a link for the first time by connecting the pluggable to the coherent probe port.

DP01QSDD-ZT5-A1 pluggable supports these features:

- Tunable C-band frequency
- CoherentDSP controller in optics port 7
- Only ZR trunk mode support
- Only HundredGig trunk rate support
- OFEC is the only supported Forward Error Correction
- PRBS support for CoherentDSP

Coherent Probe on EDFA2 card

The DP01QSDD-ZT5-A1 QDD, a Probe that is QSFP-DD MSA-compliant and supported on the EDFA2 card, can be used as a link probe and supports all C-band channels.

The coherent probe on the NCS1K14-EDFA2 card is provided as optics port 7.

Configure coherent probe on the EDFA2 card

Use this task to configure coherent probe on the EDFA2 card.

Before you begin

Insert the DP01QSDD-ZT5-A1 pluggable in the PROBE port.

Procedure

- Step 1** Use the **hw-module location** `<0/<slot-id>/NXR0> mxponder-slice <slice-number>` command to configure the coherent probe, trunk rate, and trunk mode.

Example:

```
RP/0/RP0/CPU0:ios(config)#hw-module location 0/2/NXR0 mxponder-slice 1
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-rate 100G
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#trunk-mode ZR
```

Use the **no hw-module location** `<0/<slot-id>/NXR0> mxponder-slice <slice-number>` command to remove or disable the slice configuration.

Example:

```
RP/0/RP0/CPU0:CohNode2(config)#no hw-module location 0/2/NXR0 mxponder-slice 1
RP/0/RP0/CPU0:CohNode2(config-hwmod-mxp)#commit
```

- Step 2** Commit the configuration and exit.

```
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#commit
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

- Step 3** Run the command **show hw-module location** `0/<slot-id>/NXR0> mxponder-slice <slice-number>` to verify the configuration.

Example:

```
RP/0/RP0/CPU0:ios#show hw-module location 0/2/NXR0 mxponder-slice 1
Tue Mar 11 01:55:20.764 IST
Location:          0/2/NXR0
Slice ID:
1
Client Bitrate:
NONE
Trunk Bitrate:
100G
Status:
```

Provisioned		
Client Port	Mapper/Trunk Port	CoherentDSP0/2/0/7
		Traffic Split Percentage
NONE	NONE	0

Verify Coherent Probe configurations

Use these steps to verify various coherent probe configurations:

Procedure

Step 1 Run the **show inventory** command to retrieve and display the physical inventory information of the coherent probe port.

Example:

```
RP/0RP0/CPU0:CohNode2#show inventory location 0/2/NXR0
Tue Mar 11 01:41:39.512 IST
NAME: "0/2/NXR0", DESCR: "NCS 1014 EDFA terminal with equalization"
PID: NCS1K14-EDFA2 , VID: V00, SN: FCB2813B3B3
NAME: "Optics0/2/0/6", DESCR: "Cisco QSFP DD Pluggable Optical Time Domain Reflectometer"
PID: ONS-QSFP-OTDR , VID: VES1, SN: IIF2814000Y
NAME: "Optics0/2/0/7", DESCR: "Cisco QSFP DD ZT5 Pluggable Optics Module"
PID: DP01QSDD-ZT5-A1 , VID: V01 , SN: ACA282500L2
```

Step 2 Run the **show hw-module location** command to verify the coherent probe configuration.

Example:

```
RP/0/RP0/CPU0:CohNode2#show hw-module location 0/2/NXR0 mxponder-slice 1
Tue Mar 11 01:55:20.764 IST
Location: 0/2/NXR0
Slice ID: 1
Client Bitrate: NONE
Trunk Bitrate: 100G
Status: Provisioned
Client Port Mapper/Trunk Port CoherentDSP0/2/0/7
Traffic Split Percentage
NONE NONE 0
```

Step 3 Run the **show running-config** command to display provisioned slice and trunk port information. .

Example:

```
RP/0/RP0/CPU0:CohNode2#show running-config hw-module location 0/2/NXR0
Tue Mar 11 01:55:40.705 IST
hw-module location 0/2/NXR0
mxponder-slice 1
trunk-mode ZR
trunk-rate 100G
```

Step 4 Run the **show controllers optics <R/S/I/P> P=7** command to display Optics controller status for coherent probe Optics port (Port 7).

Example:

```

RP/0/RP0/CPU0:CohNode2#show controllers optics 0/2/0/7
Tue Mar 11 02:24:28.965 IST
  Controller State: Up
  Transport Admin State: In Service
Laser State: On
LED State: Green
Last link flapped: 00:29:45
Optics Status
  Optics Type: QSFP-DD DWDM
  DWDM carrier Info: C BAND, MSA ITU Channel=Non-ITU, Frequency=193.4750THz,
  Wavelength=1549.515nm
  Alarm Status:
  -----
  Detected Alarms: None
  LOS/LOL/Fault Status:
  Alarm Statistics:

  -----
  HIGH-RX-PWR = 0          LOW-RX-PWR = 2
  HIGH-TX-PWR = 0          LOW-TX-PWR = 2
  HIGH-LBC = 0             HIGH-DGD = 0
  OOR-CD = 0               OSNR = 2
  WVL-OOL = 0              MEA = 0
  IMPROPER-REM = 0
  TX-POWER-PROV-MISMATCH = 0
  Laser Bias Current = 0.0 %
  Actual TX Power = -2.57 dBm
  RX Power = -4.18 dBm
  RX Signal Power = -5.35 dBm
  Frequency Offset = 25 MHz

  Performance Monitoring: Enable
THRESHOLD VALUES
-----

```

Parameter	High Alarm	Low Alarm	High Warning	Low Warning
Rx Power Threshold(dBm)	3.0	-30.0	0.0	0.0
Tx Power Threshold(dBm)	0.0	-16.0	0.0	0.0
LBC Threshold(mA)	N/A	N/A	0.00	0.00

```

LBC High Threshold = 90 %
Configured Tx Power = -2.50 dBm
Configured CD High Threshold = 8600 ps/nm
Configured CD lower Threshold = -8600 ps/nm
Configured OSNR lower Threshold = 14.00 dB
Configured DGD Higher Threshold = 40.00 ps
Baud Rate = 30.0692733990 GBd
Bits per Symbol = 2.0000000000 bits/symbol
Modulation Type: QPSK
Chromatic Dispersion -7 ps/nm
Configured CD-MIN -2400 ps/nm CD-MAX 2400 ps/nm
Polarization Mode Dispersion = 0.0 ps
Second Order Polarization Mode Dispersion = 176.00 ps^2
Optical Signal to Noise Ratio = 23.50 dB
SNR = 21.40 dB
Polarization Dependent Loss = 0.50 dB
Polarization Change Rate = 0.00 rad/s
Differential Group Delay = 0.00 ps
DAC RATE: 1x1.50
Transceiver Vendor Details

  Form Factor          : QSFP-DD

```

```

Name                : CISCO-ACACIA
Part Number         : 10-3655-01
Rev Number          : A
Serial Number       : ACA282500L2
PID                 : DP01QSDD-ZT5-A1
VID                 : V01
Firmware Version    : Major.Minor.Build
Active              : 70.130.21
Inactive            : 70.130.21
Date Code(yy/mm/dd) : 24/05/05
Fiber Connector Type: LC
Otn Application Code: Not Set
Sonet Application Code: Not Set
Ethernet Compliance Code: Not set

```

```
Transceiver Temperature : 34 Celsius
```

```

AINS Soak           : None
AINS Timer           : 0h, 0m
AINS remaining time  : 0 seconds

```

Step 5 Run the **show controllers coherentDSP <R/S/I/P>** command to display coherentDSP controller status for coherent probe.

Example:

```

RP/0/RP0/CPU0:CohNode2#show controllers coherentDSP 0/2/0/7
Tue Mar 11 02:41:55.191 IST

```

```

Port                               : CoherentDSP 0/2/0/7
Controller State                   : Up
Last link flapped                  : 00:47:11

Inherited Secondary State          : Normal
Configured Secondary State         : Normal
Derived State                      : In Service
Loopback mode                     : None
BER Thresholds                     : SF = 1.0E-5  SD = 1.0E-7
Performance Monitoring             : Enable
Bandwidth                         : 100.0Gb/s
Alarm Information:
LOS = 0 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0          SF_BER = 0
SD_BER = 0          BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0      FLEXO_GIDM = 0
FLEXO-MM = 0      FLEXO-LOM = 0  FLEXO-RDI = 0
FLEXO-LOF = 0
Detected Alarms                    : None

Bit Error Rate Information
PREFEC BER                        : 1.29E-08
POSTFEC BER                       : 0.00E+00
Q-Factor                          : 14.80 dB

Q-Margin                          : 8.50 dB

OTU TTI Received

FEC mode                          : O_FEC

Flexo-Mode                        : Enable
Flexo Details:
Tx GID                            : 0
Rx GID                            : 0

```

```
AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds
```

Configure PRBS on EDFA2 card

The EDFA2 card supports PRBS configuration only on Coherent Probe port.

For EDFA2 card, you can configure PRBS only for coherentDSP without setting the secondary admin state of the controllers to maintenance.

Use this task to configure PRBS without maintenance state.

Procedure

Step 1 Enter the **controller coherentDSP R/S/I/P** command to enter the coherentDSP controller configuration mode.

Example:

```
RP/0/RP0/CPU0:ios(config)#controller CoherentDSP0/0/0/7
```

Step 2 Enter the **prbs mode {source | sink | source-sink} pattern {pn31 | pn23 | pn15 | pn7}** to configure the PRBS mode and pattern.

Example:

```
RP/0/RP0/CPU0:ios(config-CoDSP)#prbs mode source-sink pattern pn15
```

Step 3 Commit the changes.

Example:

```
RP/0/RP0/CPU0:ios(config-CoDSP)#commit
```

Verify PRBS

Use these steps to verify CoherentDSP controller PRBS details and performance monitoring details.

Procedure

Step 1 Run the **Show controllers coherentDSP <R/S/I/P> prbs-details** command to display PRBS details configured on a coherentDSP controller.

Example:

```
RP/0/RP0/CPU0:CohNode2#show controllers coherentDSP 0/2/0/7 prbs-details
Tue Mar 11 03:13:34.425 IST
```

```
-----PRBS details-----
PRBS Test           : Enable
PRBS Mode           : Source-Sink
PRBS Pattern        : PN7
PRBS Status         : Locked
PRBS Lock Time(in seconds) : 1403
PRBS Bit Errors      : 0
PRBS Found Count     : 1
PRBS Lost Count      : 0
PRBS Configured Time : 11 Mar 02:50:08 (1406 seconds elapsed)
PRBS First Lock Established Time: 11 Mar 02:50:11 (1403 seconds elapsed)
Result Summary      : PASS
```

Step 2 Run the **show controllers coherentDSP <R/S/I/P> pm current <30-sec/15-min/24-hours>prbs** to view the PRBS performance monitoring parameters on a coherentDSP controller.

Example:

```
RP/0/RP0/CPU0:CohNode2#show controllers coherentDSP 0/2/0/7 pm current 15-min prbs
Tue Mar 11 03:21:31.173 IST
PRBS in the current interval [03:15:00 - 03:21:31 Tue Mar 11 2025]
PRBS current bucket type : Valid
EBC           : 0           Threshold : 0           TCA(enable) : NO
FOUND-COUNT   : 0           Threshold : 0           TCA(enable) : NO
LOST-COUNT    : 0           Threshold : 0           TCA(enable) : NO
FOUND-AT-TS   : NULL
LOST-AT-TS    : NULL
CONFIG-PTRN   : PRBS_PATTERN_PN7
STATUS        : LOCKED
Last clearing of "show controllers OTU" counters neve
```

