



## **Cisco NCS 1020 Optical Applications Configuration Guide, IOS XR Release 25.x.x**

**First Published:** 2025-12-18

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883





## CONTENTS

<b>CHAPTER 1</b>	<b>NCS 1020 Overview and Optical Applications</b>	<b>1</b>
	Document Objective	1
	Document Organization	1
<b>CHAPTER 2</b>	<b>Internode Topology Discovery and Communication</b>	<b>3</b>
	Internode Topology Discovery and Communication	3
	Configure OSPF	3
	Configure OSPF cost	4
<b>CHAPTER 3</b>	<b>Span Loss</b>	<b>7</b>
	Span loss calculations	7
	View span loss values	8
	Configure Span Loss Thresholds	9
<b>CHAPTER 4</b>	<b>Gain Estimator</b>	<b>11</b>
	Overview of Gain Estimator	11
	View Gain Estimator Status	13
<b>CHAPTER 5</b>	<b>Link Tuner</b>	<b>15</b>
	Overview of Link Tuner	15
	Configure Link Tuner	18
<b>CHAPTER 6</b>	<b>Automatic Link Calibration</b>	<b>21</b>
	Automatic Link Calibration Overview	21
	Configure Automatic Link Calibration	23
	View Automatic Link Calibration Status	26

---

<b>CHAPTER 7</b>	<b>Automatic Power Control</b>	<b>31</b>
	Overview of Automatic Power Control	31
	Configure APC	40

---

<b>CHAPTER 8</b>	<b>Automatic Network Turn Up</b>	<b>47</b>
	Overview of Automatic Link Bring Up	47

---

<b>CHAPTER 9</b>	<b>Configure OTDR</b>	<b>51</b>
	OTDR	51
	OTDR modes	52
	Configure the OTDR scan parameters	52
	OTDR scan parameters	53
	Start the OTDR scan	55
	View the OTDR measurements	56
	Stop the OTDR scan	57
	Automatic OTDR scans	57
	Autoscan behavior	58
	Criteria for span fault and restoration events	58
	Configure automatic OTDR scan	58
	Verify autoscan status	59
	Automatic OTDR scan results	60
	Examples for OTDR scan measurement results	63
	OTDR scan status	64

---

<b>CHAPTER 10</b>	<b>Implementing Host Services and Applications</b>	<b>67</b>
	HTTP Client Application	67
	TCP Overview	68
	TCP Dump File Converter	69
	Limitations and Restrictions for TCP Dump File Converter	69
	View Binary Files in Text Format Manually	69
	Convert Binary Files to Readable Format Using TCP Dump File Converter	70



# CHAPTER 1

## NCS 1020 Overview and Optical Applications

This chapter gives a brief overview of the optical apps on NCS 1020.

NCS 1020 software has multiple optical applications to help bring up the link and maintain traffic on the link.

- [Document Objective, on page 1](#)
- [Document Organization, on page 1](#)

### Document Objective

The Cisco NCS 1020 Configuration Guide describes how to configure various card modes for the line cards that are supported in the Cisco NCS 1020 chassis.

### Document Organization

This document is organized into the following chapters:

Chapter	Description
<a href="#">Internode Topology Discovery and Communication, on page 3</a>	NCS 1020 uses OSPF for topology discovery.
<a href="#">Span Loss, on page 7</a>	Span Loss application measures span loss between two nodes for a given direction and verifies if span loss is within the configured range.
<a href="#">Gain Estimator, on page 11</a>	Gain Estimator computes power that is transmitted from the upstream node, analyzes incoming span loss, sets the gain mode of the EDFA amplifier, and provides the initial target gain for the amplifier.
<a href="#">Link Tuner, on page 15</a>	Link Tuner uses actual optical measurements like span loss to compute and configure the target PSD (power spectral density) for each span.
<a href="#">Automatic Power Control, on page 31</a>	Automatic Power Control configures amplifier and attenuator setpoints to achieve target PSD across the link.

Chapter	Description
<a href="#">Automatic Network Turn Up, on page 47</a>	All the optical applications work together to bring up the DWDM link. This chapter describes the link bring up process and how the applications working together.
<a href="#">Configure OTDR , on page 51</a>	OTDR application scans and determines loss in signal power and location on the fiber path where the loss occurs.



## CHAPTER 2

# Internode Topology Discovery and Communication

---

This chapter describes how internode topology discovery and communication between NCS 1020 nodes takes place using OSPF.

- [Internode Topology Discovery and Communication, on page 3](#)

## Internode Topology Discovery and Communication

Optical applications on the NCS 1020 nodes must discover the OLT-OLT link topology. Span level applications must discover the adjacent nodes. Link level applications must learn the complete OLT-OLT link topology. NCS 1020 uses OSPF to discover the link topology and communicate topology information.

The networking devices running OSPF detect topological changes in the network, flood link-state updates to neighbors, and quickly converge on a new view of the topology. Each OSPF router in the network soon has the same topological view again.

Optical applications on NCS 1020 must discover the link topology, the different nodes and the node types, and the optical spectral band the nodes work on. NCS 1020 uses an enhanced version of OSPF that supports a new link-state advertisement attribute that advertises the node type and band.

## Configure OSPF

The following commands are the necessary configurations for OSPF on an NCS 1020 OLT node.

```
configure  
router ospf process-name  
router-id router-id  
distribute link-state  
network point-to-point  
area area-id  
interface Loopback0  
interface GigabitEthernet0/0/0/0
```

The following commands are the necessary configurations for OSPF on an NCS 1020 ILA node.

```
configure
router ospf process-name
router-id router-id
distribute link-state
network point-to-point
area area-id
interface Loopback0
interface GigabitEthernet0/0/0/0
interface GigabitEthernet0/0/0/2
```




---

**Important** You must configure router ID during OSPF configuration on NCS 1020 nodes.

---

See [Implementing OSPF](#), for a description of the concepts and tasks necessary to implement OSPF on Cisco IOS XR.

## Configure OSPF cost

Cost is the metric, you can use the cost command to explicitly specify the interface (network) for OSPF path calculation.

```
configure
router ospf process-name
router-id router-id
area area-id
interface Loopback0
interface GigabitEthernet0/0/0/0
cost cost
```

See [cost \(OSPF\)](#) for different command modes and usage guidelines to implement **cost** OSPF on Cisco IOS XR.




---

**Note** The cost of the link is inversely proportional to the bandwidth of the link.

---

The following example shows a sample **cost** configuration.

```
P/0/RP0/CPU0:ios(config)#router ospf 1

RP/0/RP0/CPU0:ios(config-ospf)#area 0
RP/0/RP0/CPU0:ios(config-ospf-ar)#interface Loopback0
RP/0/RP0/CPU0:ios(config-ospf-ar-if)#interface GigabitEthernet0/0/0/0
```



```
RP/0/RP0/CPU0:ios(config-ospf-ar-if)#cost 20  
RP/0/RP0/CPU0:ios(config-ospf-ar-if)#commit
```





## CHAPTER 3

# Span Loss

This chapter describes the Span Loss optical application for Cisco NCS 1020.

- [Span loss calculations, on page 7](#)

## Span loss calculations

A span loss calculation is an optical network measurement that

- determines the signal power loss between NCS 1020 and NCS 1010 (amplifier) nodes in an optical transmission network,
- compares the power measurements at transmitter (Tx) and receiver (Rx) ports at the near and far ends of a fiber span, and
- automatically raises the *Span Loss Value Out Of Range* alarm when the calculated loss does not fall within configured thresholds.

On a Raman span with Raman tuning enabled, span loss verification reports the following values:


- **Span loss with pumps off:** This measurement is the difference in power values between the DFB-Tx/Rx of the remote node and the DFB-Rx/Tx of the local node. This measurement also includes a timestamp. When a Raman span is up, the span loss application latches on to the difference in power between DFB-Tx and DFB-Rx before Raman tuning turns the Raman pumps on.
- **Apparent span loss:** This measurement is based on the power values of C band, L band and Optical Service Channel (OSC). For a Raman span, the span loss application uses this span loss value to raise the *Span Loss Value Out Of Range* alarm.
- **Estimated span loss:** This value is based on Raman gain that is achieved by Raman tuning application. Estimated span loss value is based on Raman gain that is achieved when safety loop was closed and tuning was performed. Raman tuning application reports the Raman gain measurement. When you disable Raman tuning, the span loss application does not compute the Estimated span loss.

Estimated span loss = Apparent span loss + Raman gain

- **OSC span loss:** This measurement is the difference in OSC power values between the Tx/Rx of the remote node and the Rx/Tx of the local node.
- **Signal span loss:** This measurement is the difference in the received C band signal power values between the Tx/Rx of the remote node and the Rx/Tx of the local node.

The span loss application reports the span loss value for a span every 90 seconds. If span loss changes, for example when a change in fiber loss occurs, the span loss application typically takes 90 seconds to update the span loss.

**Figure 1: Sample two node topology**



For example, in the previous figure, the **Tx Span Loss** on NCS 1020-1 is the difference in signal power between LINE 0 Tx on NCS 1020-1 and LINE 0 Rx on NCS 1010.

## View span loss values

Use this procedure to display span loss measurements between NCS 1010 nodes. This process helps verify optical signal integrity and diagnose network issues



### Note

Rx span loss values are not available on a network where one NCS 1010 node is upgraded to R25.3.1 while other nodes are on an earlier software version.

### Procedure

Use the **show olc span-loss** command to view the Tx span loss and Rx span loss.

#### Example:

The following sample shows the output of the **show olc span-loss** command on a Raman span with Raman tuning enabled.

```

RP/0/RP0/CPU0:ios#show olc span-loss
Sat Nov  2 00:38:53.498 IST

Controller                               : Ots0/0/0/0
Neighbour RID                             : 25.1.1.4
Apparent Rx Span Loss                     : 6.88 dB
Apparent Rx OSC Span Loss                  : 12.65 dB
Apparent Rx Signal Span Loss               : 6.82 dB
Rx Span Loss (with pumps off)              : 18.80 dB
Rx Span Loss (with pumps off) measured at : 2024-10-29 20:19:28
Estimated Rx Span Loss                     : 20.08 dB
Apparent Tx Span Loss                      : 8.84 dB
Apparent Tx OSC Span Loss                  : 15.20 dB
Apparent Tx Signal Span Loss               : 8.78 dB
Tx Span Loss (with pumps off)              : 23.50 dB
Tx Span Loss (with pumps off) measured at : 2024-10-29 20:19:36
Estimated Tx Span Loss                     : 24.74 dB
  
```

The following sample shows the output of the **show olc span-loss** command on a Raman span with Raman tuning disabled. In this sample output, Raman tuning is disabled on both Ots0/0/0/0 and Ots0/0/0/2 on the near end node. The far end nodes have Raman tuning enabled.

```
RP/0/RP0/CPU0:ios#show olc span-loss
Mon Sep  9 17:14:26.149 IST

Controller                               : Ots0/0/0/0
Neighbour RID                             : 24.1.1.2
Apparent Rx Span Loss                     : 23.9 dB
Apparent Rx OSC Span Loss                 : 26.8 dB
Apparent Rx Signal Span Loss              : 23.9 dB
Rx Span Loss (with pumps off)             : 23.8 dB
Rx Span Loss (with pumps off) measured at : 2024-09-06 19:01:50
Estimated Rx Span Loss                    : NA
Apparent Tx Span Loss                     : 24.7 dB
Apparent Tx OSC Span Loss                 : 27.9 dB
Apparent Tx Signal Span Loss              : 24.7 dB
Tx Span Loss (with pumps off)             : 24.4 dB
Tx Span Loss (with pumps off) measured at : 2024-09-06 15:57:12
Estimated Tx Span Loss                    : NA
```

The following sample shows the output of the **show olc span-loss** command on a non-Raman span.

```
RP/0/RP0/CPU0:ios#show olc span-loss
Tue Nov  5 11:09:06.736 IST

Controller                               : Ots0/0/0/0
Neighbour RID                             : 24.1.1.3
Rx Span Loss                             : 4.56 dB
Rx OSC Span Loss                         : 4.50 dB
Rx Signal Span Loss                      : 4.57 dB
Rx Span Loss (with pumps off)            : NA
Estimated Rx Span Loss                    : NA
Tx Span Loss                             : 6.13 dB
Tx OSC Span Loss                         : 6.54 dB
Tx Signal Span Loss                      : 6.12 dB
Tx Span Loss (with pumps off)            : NA
Estimated Tx Span Loss                    : NA

Controller                               : Ots0/0/0/2
Neighbour RID                             : 24.1.1.5
Rx Span Loss                             : 5.84 dB
Rx OSC Span Loss                         : 6.02 dB
Rx Signal Span Loss                      : 5.84 dB
Rx Span Loss (with pumps off)            : NA
Estimated Rx Span Loss                    : NA
Tx Span Loss                             : 5.65 dB
Tx OSC Span Loss                         : 6.08 dB
Tx Signal Span Loss                      : 5.64 dB
Tx Span Loss (with pumps off)            : NA
Estimated Tx Span Loss                    : NA
```

## Configure Span Loss Thresholds

Use this task to configure span loss thresholds.

## Procedure

---

- Step 1** Select the controller on which the span loss thresholds need to be configured after entering into the optical applications configuration mode.

**Example:**

```
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
```

- Step 2** Configure the minimum and maximum span loss threshold values.

**Example:**

```
RP/0/RP0/CPU0:ios(config)#span-loss min 100
RP/0/RP0/CPU0:ios(config)#span-loss max 200
```

The system raises a SPAN-LOSS-OUT-OF-RANGE alarm if span loss is greater than the maximum threshold or less than the minimum threshold.

- Step 3** Commit the changes and exit all the configuration modes.

**Example:**

```
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc)#exit
RP/0/RP0/CPU0:ios(config)#exit
```

---



## CHAPTER 4

# Gain Estimator

---

This chapter describes the Gain Estimator optical application for Cisco NCS 1020.

- [Overview of Gain Estimator, on page 11](#)

## Overview of Gain Estimator

Gain Estimator analyses the span loss and sets the gain mode of the EDFA amplifier and provides the initial target gain for the amplifier. EDFA amplifiers are present in both OLT and ILA line cards of NCS 1020. These EDFA amplifiers are variable-gain optical amplifiers capable of working at two different gain ranges or modes. The modes are normal mode and extended mode. Extended mode provides higher gain than the normal mode. Running the Gain Estimator is a traffic-impacting operation.

Gain Estimator uses the following parameters to estimate the gain necessary on a span.

- Ingress span loss
- Span length
- Tx connector loss
- Spectrum density
- Fiber type

Gain estimator uses the estimated gain to set the gain range.

NCS 1020 automatically triggers gain estimator:

- During automatic link bring up
- After Line Card cold reload
- After device power cycle

### Start Gain Estimator

Use the **olc start-gain-estimation controller ots** *Rack/Slot/Instance/Port* command to trigger the gain estimation operation.

The following output is a sample of the **olc start-gain-estimation controller ots 0/0/0/0** command.

```
RP/0/RP0/CPU0:ios#olc start-gain-estimation controller ots 0/0/0/0
Thu May 12 09:32:05.414 UTC
```

```
Gain Estimation: is running
```

```
RP/0/RP0/CPU0:ios#olc start-gain-estimation controller ots 0/0/0/0
```

### Start Gain Estimator Manually

Use the **olc start-gain-estimation controller ots** *Rack/Slot/Instance/Port* command to trigger the gain estimation operation.

Use the following commands to sets the Gain Estimator to manual mode:

```
configure
```

```
optical-line-control
```

```
controller ots Rack/Slot/Instance/Port
```

```
gain-estimator manual
```

```
commit
```

```
end
```

The following output is a sample configuration sets the Gain Estimator to manual mode:

```
RP/0/RP0/CPU0:ios#configure terminal
Mon Jun 13 05:35:20.510 UTC
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#gain-estimator manual
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
```

The following sample output displays Gain Estimator Manual status:

```
RP/0/RP0/CPU0:SOLN-ILA-1#show olc gain-estimator controller Ots 0/0/0/0
Tue Jun 11 10:35:38.808 IST
Controller                               : Ots0/0/0/0
Egress Gain Estimator Status           : MANUAL
Egress Estimated Gain                     : 15.8 dB
Egress Estimated Gain Mode                 : Normal
Egress Gain Estimation Timestamp           : 2024-06-03 17:03:38
```

### Disable Gain Estimator

Use the following commands to disable Gain Estimator.

```
configure
```

```
optical-line-control
```

```
controller ots Rack/Slot/Instance/Port
```

```
gain-estimator disable
```

```
commit
```

```
end
```

The following output is a sample configuration that disables Gain Estimator.

```
RP/0/RP0/CPU0:ios#configure terminal
Mon Jun 13 05:35:20.510 UTC
RP/0/RP0/CPU0:ios(config)#optical-line-control
```



```
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#gain-estimator disable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
```

### Enable Gain Estimator

Use the following set of commands to enable Gain Estimator.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
gain-estimator enable
commit
end
```

The following output is a sample configuration that enables Gain Estimator.

```
RP/0/RP0/CPU0:ios#configure terminal
Mon Jun 13 05:35:27.511 UTC
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#gain-estimator enable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
```

## View Gain Estimator Status

Use the **show olc gain-estimator** command to view the gain estimation details.

The following output is a sample of the **show olc gain-estimator** command.

```
RP/0/RP0/CPU0:ios#show olc gain-estimator
Thu May 12 09:30:39.987 UTC
Controller                               : Ots0/0/0/0
Egress Gain Estimator Status             : IDLE
Egress Estimated Gain                    : 25.9 dB
Egress Estimated Gain Mode               : Extended
Egress Gain Estimation Timestamp         : 2022-05-07 09:16:53

Controller                               : Ots0/0/0/2
Egress Gain Estimator Status             : IDLE
Egress Estimated Gain                    : 11.7 dB
Egress Estimated Gain Mode               : Normal
Egress Gain Estimation Timestamp         : 2022-05-07 10:13:53
```

Use the **show olc gain-estimator controller ots Rack/Slot/Instance/Port** command to view the gain estimation details for a specific controller.

The following output is a sample of the **show olc gain-estimator controller ots Rack/Slot/Instance/Port** command.

```
RP/0/RP0/CPU0:SOLN-OLT-1#show olc gain-estimator
Tue Jun 11 10:36:30.944 IST
Controller                               : Ots0/0/0/0
Ingress Gain Estimator Status            : MANUAL
Ingress Estimated Gain                   : 26.1 dB
Ingress Estimated Gain Mode              : Extended
Ingress Gain Estimation Timestamp        : 2024-06-03 17:04:25
```





## CHAPTER 5

# Link Tuner

This chapter describes the Link Tuner optical application for Cisco NCS 1020.

- [Overview of Link Tuner, on page 15](#)

## Overview of Link Tuner

Link tuner computes the target Power Spectral Densities (PSD) for APC by calculating the optimal PSDs for a span. Power Spectral Density represents power per 12.5 GHz of spectrum. Link tuner is enabled if automatic link bring up is enabled. Link tuner is span-specific and computes the target PSDs for channels entering the span. Link tuner uses the following parameters to compute the target PSD:

- Fiber-type
- Span loss measurement
- Spectral density
- Connector losses
- Span length

The link tuner application finds the target PSD for the best performance for channels entering a span. You have to manually configure drop-psd. The drop-psd is the target PSD for OLT drop ports.

Link tuner monitors the span loss and total noise in the link. When link tuner detects changes in the span loss, span length, or connector loss, link tuner recomputes the target PSDs.

Link tuner computes the target PSDs and total noise whenever a link goes down and comes back up. All traffic impacting actions trigger link tuner.

The following table describes the different link tuner status.

Status	Description
Operational	Link tuner is active and operational.
Blocked	Link tuner is active but unable to compute target PSDs and noise.
Disabled	Link tuner is disabled.
Manual	User has to manually run

To view link tuner status and PSD computation information, use **show olc link-tuner** command.

The following sample is an output of **show olc link-tuner** command.

```
RP/0/RP0/CPU0:SOLN-OLT-1#show olc link-tuner
Tue Jun 11 10:40:30.667 IST
Controller      : Ots0/0/0/0
Link Tuner Status : MANUAL
Last PSD computation: 2024-06-03 16:49:34
```

-----

Single Band

-----

Setpoint	: Computed PSD (dBm/12.5 GHz)
----------	----------------------------------

-----

01	-6.1
02	-6.0
03	-6.0
04	-5.9
05	-5.8
06	-5.7
07	-5.7
08	-5.6
09	-5.5
10	-5.4
11	-5.4
12	-5.3
13	-5.2
14	-5.2
15	-5.1
16	-5.0
17	-4.9
18	-4.9
19	-4.8
20	-4.7
21	-4.6
22	-4.6
23	-4.5
24	-4.4
25	-4.3
26	-4.3
27	-4.2
28	-4.1
29	-4.1
30	-4.0
31	-3.9
32	-3.8
33	-3.8

To view link tuner status, PSD computation information, and computed total noise, use **show olc link-tuner detail** command.

The following sample is an output of **show olc link-tuner detail** command.

```
RP/0/RP0/CPU0:SOLN-OLT-1#show olc link-tuner details
Tue Jun 11 10:43:48.998 IST
Controller      : Ots0/0/0/0
Link Tuner Status : MANUAL
Last PSD computation: 2024-06-03 16:49:34
Computed Total Noise: NA
```

-----

Setpoint	: Computed PSD (dBm/12.5 GHz)
----------	----------------------------------

-----

01	-6.1
----	------

02	-6.0
03	-6.0
04	-5.9
05	-5.8
06	-5.7
07	-5.7
08	-5.6
09	-5.5
10	-5.4
11	-5.4
12	-5.3
13	-5.2
14	-5.2
15	-5.1
16	-5.0
17	-4.9
18	-4.9
19	-4.8
20	-4.7
21	-4.6
22	-4.6
23	-4.5
24	-4.4
25	-4.3
26	-4.3
27	-4.2
28	-4.1
29	-4.1
30	-4.0
31	-3.9
32	-3.8
33	-3.8

You can view the target PSDs configured for all [setpoints](#) using the **show olc apc-local target-psd-profile** command. The output shows the source of the PSD configuration also. The target PSD source can be Link Tuner or Configuration.

The following sample is an output of **show olc apc-local target-psd-profile** command.

```
RP/0/RP0/CPU0:ios#show olc apc-local target-psd-profile
Mon Jun 20 06:40:32.779 UTC
Controller      : Ots0/0/0/0
Target PSD source : Link Tuner
```

Setpoint	Frequency (THz)	Target PSD (dBm/12.5 GHz)
01	191.337494	-6.3
02	191.488495	-6.3
03	191.639496	-6.2
04	191.790497	-6.2
05	191.941498	-6.2
06	192.092499	-6.1
07	192.243500	-6.1
08	192.394501	-6.1
09	192.545502	-6.0
10	192.696503	-6.0
11	192.847504	-5.9
12	192.998505	-5.9
13	193.149506	-5.8
14	193.300507	-5.8
15	193.451508	-5.8
16	193.602493	-5.7
17	193.753494	-5.7

18	193.904495	-5.7
19	194.055496	-5.6
20	194.206497	-5.6
21	194.357498	-5.5
22	194.508499	-5.5
23	194.659500	-5.5
24	194.810501	-5.4
25	194.961502	-5.4
26	195.112503	-5.3
27	195.263504	-5.3
28	195.414505	-5.3
29	195.565506	-5.2
30	195.716507	-5.2
31	195.867493	-5.1
32	196.018494	-5.1
33	196.169495	-5.1

## Configure Link Tuner

The following configurations are available for the link tuner:

### Enable Link Tuner

You can enable link tuner for a controller. Use the following commands to enable link tuner.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
link-tuner enable
commit
end
```

The following is a sample configuration that enables link tuner.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#link-tuner enable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Manual Link Tuner

You can enable link tuner for a controller. Use the following commands to set the link tuner to manual mode.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
link-tuner manual
commit
end
```

The following is a sample configuration sets the link tuner to manual mode.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#link-tuner manual
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Disable Link Tuner

You can disable link tuner for a controller. Use the following commands to disable link tuner.

**configure**

**optical-line-control**

**controller ots** *Rack/Slot/Instance/Port*

**link-tuner disable**

**commit**

**end**

The following is a sample configuration that disables link tuner.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#link-tuner disable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Configure Link Parameters

Configure fiber-type, spectrum density, connector losses, and span length for accurate link tuning.

To configure fiber type, use **fiber-type** command. SMF is the default fiber-type.

You can configure the following fiber types using **fiber-type** command:

- E-LEAF
- FREE-LIGHT
- METRO-CORE
- SMF
- SMF-28E
- TERA-LIGHT
- TW-RS
- TW-Reach
- TW-minus
- TW-plus
- ULL-SMF28

To configure spectrum density, use **link-tuner spectrum-density** command. You can configure a spectrum density as a percentage value in the range of 1-100. The default spectrum density is 81.

To configure connector loss, use the **connector-loss** command. You can configure Tx and Rx connector loss in the range 0–20 dB.

To configure span length, use the **span-length** command. You can configure span length in the range of 0.1 to 200 km as multiples of 0.1 km. In the absence of span length configuration, link tuner computes span length using span loss.

The following example is a sample configuration that configures the link tuner parameters.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#fiber-type SMF
RP/0/RP0/CPU0:ios(config-olc-ots)#link-tuner spectrum-density 80
RP/0/RP0/CPU0:ios(config-olc-ots)#connector-loss rx 1
RP/0/RP0/CPU0:ios(config-olc-ots)#connector-loss tx 1
RP/0/RP0/CPU0:ios(config-olc-ots)#span-length 100
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```





## CHAPTER 6

# Automatic Link Calibration

Automatic Link Calibration brings up your NCS 1000 optical line system. By identifying and addressing potential issues during the calibration process, ALC can enhance the overall reliability of the network, reducing downtime and ensuring consistent performance.

**Table 1: Feature History**

Feature Name	Release Information	Description
Automatic Link Calibration (ALC) with span-by-span calibration	Cisco IOS XR Release 24.4.15	From this release, NCS 1010 and 1020 perform Automatic Link Calibration span-by-span, improving reliability. The following show command outputs now provide better visibility aiding quicker troubleshooting. <ul style="list-style-type: none"><li>• <b>show olc alc status</b></li><li>• <b>show olc alc-local status</b></li></ul>

- [Automatic Link Calibration Overview, on page 21](#)

## Automatic Link Calibration Overview

From Cisco IOS XR Release 7.11.1, NCS 1020 supports Automatic Link Calibration (ALC). ALC is an alternate to automatic link bring-up. When using ALC, the optical applications except APC remain idle when operating conditions change. After turning up the network, ALC saves optical parameters on all nodes as a baseline. ALC saves the following parameters as a baseline:

- Span loss data
- APC data
- C-band and OSC power measurements
- Link tuner data
- Gain estimator data

- OCM data

ALC is a link level application. ALC is initiated by the ALC manager which is the source OLT. The manager manages the downstream link. Similarly, the OLT at the other end of the link manages the upstream link.

ALC is a network bring up operation. Link calibration is traffic impacting. When you are turning up a link

### Prerequisites for ALC

- **OLT to OLT Topology:** OLT-OLT topology must be up and running from end to end. You should not have a Loss of Signal-Path (LOS-P) or a Loss of Channel (LOC) alarm on any node.
- **Channel Map Configuration:** You must configure channel maps on all nodes to align all nodes with the correct frequencies. Use **hw-module location 0/0/NXR0 grid-mode flex[inline-ampli | terminal-ampli] channel-id id centre-freq frequency width width** command to configure the channel map for all 32 channels.
- **XC Creation:** You must create Optical Cross-Connects (OXC) on OLT nodes. These OXC should cover the entire spectrum to ensure the correct routing of optical signals.
- **Application Modes:** You must set all applications to either manual mode or disabled mode, except for Automatic Power Control (APC). We recommend, all control loop applications should be in manual mode.
- **Span-mode APC:** You must configure APC in span mode on all nodes.



**Note** If you use Cisco Optical Network Planner to design your network, the prerequisite configurations can be imported to the NCS 1020 nodes as an XML file. See [Design and Analyze Networks](#) for more information.

### ALC Process

The following sequence of events takes place when ALC is initiated.

1. The source Optical Line Terminal (OLT) starts the ALC procedure in the transmitting direction. The source OLT is the ALC manager for this direction. The ALC manager raises the **Automatic-link-calibration procedure is running** to indicate that the process is running.
2. The OLT drops all user channels and forces the ASE channels from the Noise Loader (NL). These ASE channels are used for the ALC calibration.



**Note** The Automatic Link Calibration (ALC) process needs a stable and reliable C-band source which covers entire spectrum. When the ALC process begins, it drops all active user channels and forces ASE noise channels from the noise loader. This is done to ensure that the calibration isn't affected by user traffic, which can fluctuate and cause inconsistencies. This allows the ALC process to accurately calibrate the power levels across the entire C-band spectrum, ensuring optimal performance of the optical network.

3. ALC initiates an OTDR scan on the receive (Rx) and transmit (Tx) interfaces in the downstream direction. After the scan is completed, the location of the .sor file is saved.

4. ALC enables the Automatic Power Control (APC), Link Tuner, and Gain Estimator applications to run in parallel.
5. The Power Spectral Density (PSD) and gain are initially calculated using the Optical Supervisory Channel (OSC) span loss. This step is temporary and is used to bring the C-band up.
6. Once the C-band is up, the C-band based span loss is measured and the PSD and Gain are recalculated.
7. Using the PSD computed by the LinkTuner and the gain-range computed by the Gain Estimator, the APC regulates the channels. Once this is completed, the APC moves to the IDLE state.
8. After APC moves to the IDLE state on all nodes, ALC initiates the baseline.
9. After saving the optical parameters, ALC completes the procedure and the ALC status changes to IDLE.
10. The ALC Manager clears the **Automatic-link-calibration procedure is running** alarm.
11. The ALC manager releases the ASE channels, and user channels become active.
12. ALC changes APC mode from Centralized-mode to Span-mode.

#### Restrictions for ALC

- ALC impacts network traffic, and the time it takes to converge depends on the number of nodes in the network.
- ALC does not support Raman networks.
- ALC saves baseline data only if the procedure completes successfully. If the ALC procedure fails due to network errors, the collected baseline data is not saved.
- Do not enable or disable any optical applications or initiate gain estimator after ALC is complete.
- Do not initiate ALC on a link without cross connect configuration across the entire spectrum.
- Baseline data is preserved across reloads.



**Note** To clear the baseline data, you must either perform a **commit replace** on the respective nodes or configure the **no** option of all the applications, for example, **no apc-span-mode RX** and **no apc-span-mode TX** to clear the APC baseline data on a node.

## Configure Automatic Link Calibration

### Prerequisite configuration

The following commands are mandatory configurations for ALC on an OLT node.

**optical-line-control**

**controller Ots R/S/I/P**

**apc manual**

**gain-estimator manual**

**link-tuner manual**

**apc-span-mode RX**

**apc-span-mode TX**

The following commands are mandatory configurations for ALC on an ILA node.

**optical-line-control**

**controller Ots0/0/0/0**

**gain-estimator manual**

**link-tuner manual**

**apc-span-mode TX**

**controller Ots0/0/0/2**

**gain-estimator manual**

**link-tuner manual**

**apc-span-mode TX**

### **Configure APC in Span-mode**

Use the following commands to configure APC in span-mode on an OLT node.

#### **On an OLT node**

**configure**

**optical-line-control**

**controller ots *Rack/Slot/Instance/Port***

**apc-span-mode RX**

**apc-span-mode TX**

**commit**

**end**

Use the following commands to configure APC in span-mode on an ILA node.

**configure**

**optical-line-control**

**controller ots *Rack/Slot/Instance/Port***

**apc-span-mode TX**

**commit**

**end**



**Note** APC runs in centralized mode during Automatic Link Calibration. At the completion of ALC, ALC saves a baseline of the system. After saving the baseline, if the span-mode configurations are present, ALC changes APC mode to span-mode.

### Pause Span-mode APC

Use the following commands to pause span-mode APC

**configure**

**optical-line-control**

**controller ots** *Rack/Slot/Instance/Port*

**apc-span-mode-pause** [TX | RX]

**commit**

**end**

The following is a sample configuration that pauses span-mode APC.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc-span-mode-pause tx
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
Tue Apr 26 09:50:12.055 UTC
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Turn Up a Link Using ALC

Perform the following steps to turn up a link using ALC.

1. Configure all nodes with base configurations and bring up the topology end to end. This involves setting up the basic configurations on all nodes in the network. These configurations include interface configurations, OSPF configurations, hostname, telemetry, and Cisco Optical Site Manager (COSM).
2. Import the XML file generated by Cisco Optical Network Planner (CONP) comprising required configurations for network turn up on all nodes. The CONP configuration file includes specific settings for the network, such as channel configuration, cross-connect (XC) configuration, optical application configuration in manual mode, and span mode Automatic Power Control (APC) configuration. Importing this file applies these settings to all nodes in the network.
3. Initiate the ALC procedure at the near-end Optical Line Terminal (OLT) using the exec command **olc alc-start controller ots 0/0/0/0**. The ALC status shows "IN-PROGRESS". The following sample shows the alc status after running the exec CLI.

```
RP/0/RP0/CPU0:ios#olc alc-start controller ots 0/0/0/0
RP/0/RP0/CPU0:ios#show olc alc status
Tue Sep 26 16:54:57.934 IST

Controller           : Ots0/0/0/0
ALC Status           : IN-PROGRESS
ALC-Procedure started at : 2023-09-26 16:04:07

Node RID             : 10.3.3.3
```

ALC State : IN-PROGRESS

Node RID : 10.2.2.2  
ALC State : IN-PROGRESS

Node RID : 10.1.1.1  
ALC State : IN-PROGRESS

- After completing the ALC in one direction, initiate the ALC in the other direction. Execute the **olc alc-start controller ots 0/0/0/0** command on the far-end Optical Line Terminal (OLT), which acts as the ALC manager for the upstream direction.



#### Restriction

Do not initiate ALC in a direction while ALC is in progress on the other direction. ALC procedure involves OTDR scans. NCS 1010 nodes perform OTDR scans in one direction at a time.

## View Automatic Link Calibration Status

Use the **show olc alc status** command to see the status of ALC. The following sample shows ALC status when ALC is in progress.

```
RP/0/RP0/CPU0:ios#show olc alc status
Tue Sep 26 16:54:57.934 IST

Controller          : Ots0/0/0/0
ALC Status          : IN-PROGRESS
ALC-Procedure started at : 2023-09-26 16:04:07

Node RID            : 10.3.3.3
ALC State           : IN-PROGRESS

Node RID            : 10.2.2.2
ALC State           : IN-PROGRESS

Node RID            : 10.1.1.1
ALC State           : IN-PROGRESS
```

The following sample shows ALC status when ALC is IDLE after the completion of the ALC process.

```
RP/0/RP0/CPU0:ios#show olc alc status
Tue Sep 26 16:54:57.934 IST

Controller          : Ots0/0/0/0
ALC Status          : IDLE
ALC-Procedure started at : 2023-09-26 16:04:07

Node RID            : 10.3.3.3
ALC State           : COMPLETE

Node RID            : 10.2.2.2
ALC State           : COMPLETE

Node RID            : 10.1.1.1
ALC State           : COMPLETE
```

Use the **show olc alc-local baseline controller ots R/S/I/P** command to view the saved baseline. The output of this command shows the baseline info saved for OTDR, Link Tuner, Gain Estimator, Span Loss, APC Regulation, and Power measurements. The following sample is a truncated output of the **show olc alc-local baseline** command.

```
RP/0/RP0/CPU0:ios#show olc alc-local baseline controller ots 0/0/0/0
```

```
OTDR
=====
```

```
Controller      : Ots0/0/0/0
OTDR RX File    : /harddisk:/otdr/PROD1_NCS1010_OTDR_Ots0_0_0_0_RX_20230926-192505.sor
OTDR TX File    : /harddisk:/otdr/PROD1_NCS1010_OTDR_Ots0_0_0_0_TX_20230926-213923.sor
```

```
Link Tuner
=====
```

```
Controller      : Ots0/0/0/0
Config Mode     : Manual
Last PSD computation: 2023-09-26 16:11:40
Target PSD:
```

```
-----
Setpoint        : Computed PSD
                  (dBm/12.5 GHz)
-----
```

```
01              -8.2
.
33              -7.3
```

```
Gain Estimator
=====
```

```
Controller      : Ots0/0/0/0
Config Mode     : Manual
Ingress Estimated Gain      : 23.0 dB
Ingress Estimated Gain Mode : Extended
Ingress Gain Estimation Timestamp : 2023-09-26 13:59:44
```

```
Span Loss Computation
=====
```

```
Controller      : Ots0/0/0/0
Neighbour RID   : 10.2.2.2
Rx Span Loss    : 16.8 dB
Rx Span Loss (with pumps off) : NA
Estimated Rx Span Loss      : NA
Tx Span Loss    : 10.2 dB
Tx Span Loss (with pumps off) : NA
Estimated Tx Span Loss      : NA
```

```
APC Regulation Info
=====
```

```
Config Mode     : Centralized APC
Controller      : Ots0/0/0/0
Domain Manager  : 10.3.3.3
Status          : IDLE
Direction       : Tx
PSD Minimum     : -24.0 (dBm/12.5 GHz)
Gain Range      : Normal
Last Correction  : 2023-09-26 16:09:52
Residual Discrepancy from Previous Node : NA
Residual Discrepancy Input Timestamp    : NA
```

Device Parameters		Min	Max	Configuration
Operational				
Egress Ampli Gain (dB)	:	16.0	30.0	20.9
20.9				
Egress Ampli Tilt (dB)	:	-5.0	2.5	-0.8
-0.8				
Tx Ampli Power (dBm)	:	-	23.0	-

## View Automatic Link Calibration Status

```

22.8
Tx VOA Attenuation (dB)      :      0.0      15.0      5.3
5.3
Egress WSS/DGE Attenuation (dB) :      0.0      25.0      -
-

```

Channel Center Target Frequency PSD (THz) GHz)	Channel Current Width PSD (GHz) GHz)	Channel Discrepancy ID (dB)	Channel Channel Slice Source Attn Config (dB)	Spectrum Slice Num	Ampli-Input PSD (dBm/12.5 GHz)
---	---	--------------------------------------	---	-----------------------	--------------------------------------

191.412500	150.00	1	ASE	25	-23.4
-8.2	-8.1	-0.0	9.3		
.					
196.062500	150.00	35	ASE	1513	-23.8
-7.4	-7.2	-0.0	9.5		

```

Controller      : Ots0/0/0/0
Target PSD source : Link Tuner

```

Setpoint	Frequency (THz)	Target PSD (dBm/12.5 GHz)
01	191.375000	-8.2
.		
33	196.175000	-7.3

## APC Regulation Info

=====

```

Config Mode      : Centralized APC
Controller       : Ots0/0/0/0
Domain Manager   : 10.1.1.1
Status           : IDLE
Direction        : Rx
PSD Minimum      : -24.0 (dBm/12.5 GHz)
Gain Range       : Extended
Last Correction   : 2023-09-26 14:00:07
Residual Discrepancy from Previous Node : NA
Residual Discrepancy Input Timestamp    : NA

```

Device Parameters Operational	Min	Max	Configuration
Ingress Ampli Gain (dB)	20.0	38.0	22.2
22.2			
Ingress Ampli Tilt (dB)	-5.0	5.0	0.9
0.9			
Rx Ampli Power (dBm)	-	25.0	-
24.7			
Rx VOA Attenuation (dB)	0.0	0.0	0.0
0.0			
Ingress WSS/DGE Attenuation (dB)	0.0	25.0	-
-			



Channel Target	Channel Center Frequency	Channel Current PSD	Channel Width	Channel Discrepancy ID	Channel Source	Spectrum Slice Num	Ampli-Input PSD
(GHz)	(THz)	(dBm/12.5 GHz)	(GHz)	(dB)	Attn Config		(dBm/12.5 GHz)

191.412500	150.00	1	ASE	25	-23.3
-8.0	-8.0	0.0	3.7		
.					
196.062500	150.00	35	ASE	1513	-22.0
-8.0	-8.0	0.0	4.0		

## Power Measurements

=====

Controller : Ots0/0/0/0  
 C-Band Total Tx Power on Ots0/0/0/0 : 17.50 dBm  
 OSC Total Tx Power on Osc0/0/0/0 : 1.00 dBm  
 Measured at : 2023-09-26 16:13:47

Spectrum Slices Spacing : 3.125 Ghz  
 Spectrum Slices Range : 1 - 1548  
 Slice Start Wavelength : 1566.82 nm  
 Slice Start Frequency : 191337.50 GHz

Spectrum power information :  
 Tx power :

spectrum-slice num	Ots0/0/0/0 Tx-power values (dBm)
1 - 12	-12.9 -10.7 -9.3 -8.5 -8.2 -8.2 -8.2 -8.2
-8.2 -8.1 -8.1 -8.1	
.	
1537 - 1548	-28.6 -30.0 -31.0 -31.8 -32.4 -32.8 -33.2 -33.5
-33.7 -33.9 -34.1 -34.3	

Controller : Ots0/0/0/0  
 C-Band Total Rx Power on Ots0/0/0/0 : 2.51 dBm  
 OSC Total Rx Power on Osc0/0/0/0 : -16.10 dBm  
 Measured at : 2023-09-26 14:01:51

Spectrum Slices Spacing : 3.125 Ghz  
 Spectrum Slices Range : 1 - 1548  
 Slice Start Wavelength : 1566.82 nm  
 Slice Start Frequency : 191337.50 GHz

Spectrum power information :  
 Rx power :

spectrum-slice num	Ots0/0/0/0 Rx-power values (dBm)
1 - 12	-29.2 -26.4 -24.7 -23.7 -23.2 -23.2 -23.2 -23.3
-23.3 -23.3 -23.3 -23.3	
.	
1537 - 1548	-42.6 -90.0 -90.0 -90.0 -90.0 -90.0 -90.0 -90.0
-90.0 -90.0 -90.0 -90.0	





## CHAPTER 7

# Automatic Power Control

This chapter describes the Automatic Power Control optical application for Cisco NCS 1020.

- [Overview of Automatic Power Control, on page 31](#)

## Overview of Automatic Power Control

On a fiber, the power level may vary between channels. Over long distances and multiple amplifications, these differences in power levels can result in deterioration of the quality of some channels. Automatic Power Control (APC) corrects the power level differences and ensures that power for different channels is according to the target power profile for the spectrum. APC compensates for the degradation of the network over time. APC is enabled if automatic link bring up is enabled.

APC is a network-level feature that is distributed among different nodes. An APC domain is a set of nodes that is controlled by the same instance of APC at the network level. An APC domain identifies a portion of the network that can be independently regulated. The source OLT node acts as the APC Manager or Domain Manager for all the nodes in the path. The subsequent nodes in the path act as APC agent nodes. The manager node enables APC on agent nodes, monitors DISCREPANCY and initiates regulation if correction is required. To avoid large power fluctuations, APC adjusts power levels incrementally. APC performs power correction in steps of  $\pm 0.8\text{dB}$ . This is applied to each iteration until the optimal power level is reached.

You can use APC as a span level application by using span-mode APC.

APC is direction-specific. You can enable APC for each direction at the transmitting OLT node. The source node enables and controls different parameters in all ILA nodes on the path and the far-end OLT ingress EDFA.

The following table lists the parameters that APC configures and controls in different nodes.

Node	Parameters
Transmitting OLT	EDFA Gain EDFA Tilt VOA Attenuation WSS Attenuation

Node	Parameters
ILA	EDFA Gain EDFA Tilt VOA Attenuation DGE Attenuation
Receiving OLT	EDFA Gain EDFA Tilt WSS Attenuation

When you enable APC, APC controls these parameters. APC overrides any manual configuration. When you disable APC, user configuration is applied.

APC divides the C band spectrum into 32 equal parts. APC uses 33 frequencies across the C band to divide the band. We call these 33 frequencies, **setpoints**. Each setpoint is 150 GHz apart from the adjacent setpoints. You can configure a power profile across the spectrum using these setpoints. You can configure the target PSD for each OLT and ILA node on a link.

APC applies amplification and attenuation as required at channel level and composite signal level to ensure that the channels are at the target power level. You can configure the target power spectral densities for 33 points across the band. If you enable link tuner, link tuner sets the target PSDs for APC on all nodes in the path.

APC performs the following functions:

- APC monitors the current PSD against the target PSD for each channel (ASE and user channel) and changes the amplifier parameters including VOA, WSS, and DGE to achieve the target PSD.
- APC detects optical network changes on the path and alters the amplifier parameters on the nearest nodes to compensate for the changes. APC performs these alterations in multiple steps.
- APC collects measurements from other link nodes at the transmitting OLT to precisely locate optical network changes.

APC regulation begins as soon as it discovers any part of the topology. At a transmitting OLT, it starts power correction at the OLT and subsequent ILA nodes even if the complete OLT-OLT link has not been discovered.



#### Note

- If the input slice power of a channel is below psd-min and APC is unable to bring the channel above psd-min even after setting the WSS attenuation to 0dB, APC declares the channel as failed.
- After APC regulation, all channel powers must be above psd-min (-24-dBm default) and at least one channel should be within 0.5 dB of psd-min.

### View APC Status and Information

Use the **show olc apc** command to view APC status.

The following sample is an output of **show olc apc** command when APC is in Centralized mode.

```
RP/0/RP0/CPU0:OLT1#show olc apc
```

```
Controller      : Ots0/0/0/0
APC Status      : WORKING
```

```
Node RID        : 10.1.1.1
Internal State   : IDLE
```

```
Node RID        : 10.99.1.2
Internal State   : IDLE
```

```
Node RID        : 10.99.2.2
Internal State   : IDLE
```

```
Node RID        : 10.99.4.1
Internal State   : IDLE
```

```
Node RID        : 10.1.1.5
Internal State   : DISCREPANCY
```

The following sample is an output of **show olc apc** command when APC is in span-mode.

```
RP/0/RP0/CPU0:ios#show olc apc
```

```
Controller      : Ots0/0/0/0
APC Status      : MANUAL
```

APC Status is the status of APC in the complete path. The following table lists and describes the APC Statuses.

APC Status	Description
BLOCKED	APC moves to BLOCKED state if: <ul style="list-style-type: none"> <li>• there is an event in the network which resulted in topology failure</li> <li>• an amplifier safety event like APR or OSRI has been triggered in the network</li> <li>• APC is locally disabled on agent node</li> </ul>
PAUSED	APC is paused using the <b>apc-pause</b> command.
IDLE	APC regulation has been completed successfully. All the channels in the network have achieved the target PSD provided by Link-tuner or configured by user
WORKING	APC detected a DISCREPANCY between current and target PSD. APC regulation is in progress to converge the power to target PSD.
DISABLED	APC is disabled.
PARTIAL-TOPOLOGY NODE-BLOCKED	APC has limited visibility. APC manager does not have visibility to the full OLT-OLT topology. APC manager tries to correct the power levels on the agent nodes that are reachable and after the regulation is complete, APC moves to BLOCKED state.
Manual	

Internal State is the state of APC on each individual node. The following table lists and describes the internal states.

APC Internal State	Description
DISCREPANCY	The APC manager flags an agent node which needs correction when there is a discrepancy between target PSD and current PSD. This state is temporary and lasts until APC starts power correction and goes into CORRECTING state.
CORRECTING	APC correction is in progress on the node
OOR	<p>APC-OUT-OF-RANGE condition is raised on an agent node when APC fails to regulate and achieve the target PSD power level because the requested gain or attenuation setpoint cannot be set due to one of the following conditions:</p> <ul style="list-style-type: none"> <li>• Amplifier gain is exhausted in the current gain range.</li> <li>• WSS range (0-25dB) is exhausted for a single or multiple channels.</li> <li>• DGE range (0-3dB) is exhausted for a single or multiple channels.</li> <li>• Spanloss increased and amplifier gain is insufficient to achieve target PSD</li> </ul>
IDLE	APC regulation has been completed successfully. All the channels in the network have achieved the target PSD provided by Link-tuner or configured by user
BLOCKED	<p>APC is unable to perform for the following reasons:</p> <ul style="list-style-type: none"> <li>• OSRI has shut down the amplifier: AMPLI-SHUT</li> <li>• APC is disabled locally on the node: USER-DISABLED</li> <li>• Gain Estimation is in progress: GAIN-ESTIMATION-IN-PROGRESS</li> <li>• Amplifier auto power reduction is enabled: AMPLI-APR-ENABLED</li> <li>• Amplifier is shut because of loss of input power: AMPLI-SHUT</li> <li>• An event in the network resulted in topology failure.</li> </ul>

The following sample is an output of **show olc apc** command when OSRI has shut down an amplifier in the link.

```
RP/0/RP0/CPU0:ios#sh olc apc
Thu Jul 7 13:21:05.807 UTC

Controller      : Ots0/0/0/0
APC Status      : BLOCKED

Node RID        : 10.1.1.1
Internal State  : IDLE

Node RID        : 10.1.1.2
Internal State  : BLOCKED
Blocked Reason  : [ AMPLI-SHUT ]

Node RID        : 10.1.1.3
Internal State  : DISCREPANCY

Node RID        : 10.1.1.4
Internal State  : DISCREPANCY

Node RID        : 10.1.1.5
Internal State  : DISCREPANCY
```

The following sample is an output of **show olc apc** command when APC is disabled locally on a node.

```
RP/0/RP0/CPU0:ios#sh olc apc
Thu Jul 7 13:22:44.145 UTC

Controller      : Ots0/0/0/0
APC Status      : BLOCKED

Node RID        : 10.1.1.1
Internal State  : IDLE

Node RID        : 10.1.1.2
Internal State  : BLOCKED
Blocked Reason  : [ USER-DISABLED ]

Node RID        : 10.1.1.3
Internal State  : DISCREPANCY

Node RID        : 10.1.1.4
Internal State  : DISCREPANCY

Node RID        : 10.1.1.5
Internal State  : DISCREPANCY
```

The following sample is an output of **show olc apc** command when Gain Estimation is in progress on a node.

```
RP/0/RP0/CPU0:ios#sh olc apc
Tue Jun 7 11:43:10.801 UTC

Controller : Ots0/0/0/0
APC Status : BLOCKED

Node RID : 10.1.1.1
Internal State : DISCREPANCY

Node RID : 10.1.1.2
Internal State : DISCREPANCY

Node RID : 10.1.1.3
Internal State : BLOCKED
Blocked Reason : [ GAIN-ESTIMATION-IN-PROGRESS ]
```

The following sample is an output of **show olc apc** command when amplifier auto power reduction is enabled on a node.

```
RP/0/RP0/CPU0:ios#sh olc apc
Thu Jul  7 13:21:49.530 UTC

Controller      : Ots0/0/0/0
APC Status      : BLOCKED

Node RID        : 10.1.1.1
Internal State   : IDLE

Node RID        : 10.1.1.2
Internal State   : BLOCKED
Blocked Reason   : [ AMPLI-APR-ENABLED ]

Node RID        : 10.1.1.3
Internal State   : DISCREPANCY

Node RID        : 10.1.1.4
Internal State   : DISCREPANCY

Node RID        : 10.1.1.5
Internal State   : DISCREPANCY
```

You can view the local status of APC on each node using the **show olc apc-local** command. This command shows if APC is enabled or disabled on the node.

The following sample is an output of **show olc apc-local** command when APC is in centralized mode.

```
RP/0/RP0/CPU0:ios#show olc apc-local
Mon Apr 11 06:59:14.679 UTC

Controller : Ots0/0/0/0

TX Status : ENABLED
RX Status : ENABLED
```

The following sample is an output of **show olc apc-local** command when APC is in spam mode.

```
RP/0/RP0/CPU0:SOLN-OLT-1#show olc apc-local
Tue Jun 11 10:57:00.797 IST

Controller : Ots0/0/0/0

Tx Status : SPAN-MODE
Rx Status : SPAN-MODE
```

You can view the target PSDs configured for all setpoints using the **show olc apc-local target-psd-profile** command. The output shows the source of the PSD configuration also. The target PSD source can be Link Tuner or Configuration.

The following sample is an output of **show olc apc-local target-psd-profile** command.

```
RP/0/RP0/CPU0:ios#show olc apc-local target-psd-profile
Tue Apr 26 10:19:24.910 UTC
Controller      : Ots0/0/0/0
Target PSD source : Configuration
```

Setpoint	Frequency (THz)	Target PSD (dBm/12.5 GHz)
01	191.337494	15.0
02	191.488678	15.0



03	191.639847	-4.1
04	191.791016	-4.1
05	191.942184	-4.1
06	192.093353	-4.1
07	192.244537	-4.1
08	192.395706	-4.1
09	192.546875	-4.1
10	192.698044	-4.1
11	192.849213	-4.1
12	193.000397	-4.1
13	193.151566	-4.1
14	193.302734	-4.1
15	193.453903	-4.1
16	193.605072	-4.1
17	193.756256	-4.1
18	193.907425	-4.1
19	194.058594	-4.1
20	194.209763	-4.1
21	194.360931	-4.1
22	194.512115	-4.1
23	194.663284	-4.1
24	194.814453	-4.1
25	194.965622	-4.1
26	195.116791	-4.1
27	195.267975	-4.1
28	195.419144	-4.1
29	195.570312	-4.1
30	195.721481	-4.1
31	195.872650	-4.1
32	196.023834	-4.1
33	196.175003	-4.1

You can view the detailed information about APC on each node using the **show olc apc-local regulation-info** command. This command provides the following information:

- Controller
- APC Domain Manager
- Internal Status
- Minimum PSD
- Last correction timestamp
- Gain range
- Amplifier and attenuation parameters: Configured and current values and available ranges
- Detailed information on the channels

The following details are available:

- Center frequency of each channel
- Channel width
- Channel ID
- Channel Source (ASE or user channel)
- Slice number of the center frequency of the channel in the WSS
- PSD of the channel at the input of the amplifier

- Target PSD for the channel
- Current PSD of the channel
- Discrepancy between current and target PSD
- The configured attenuation on the WSS (OLT) or DGE (ILA) for the channel

You can view the APC information for only the Tx or Rx direction using the **tx|rx** keyword with the **show olc apc-local regulation-info controller ots R/S/I/P** command.

The following sample is an output of **show olc apc-local regulation-info** command.

```
RP/0/RP0/CPU0:ios#show olc apc-local regulation-info controller ots 0/0/0/0 tx
Wed Jul  6 05:01:45.177 UTC
Controller           : Ots0/0/0/0
Domain Manager       : 10.1.1.1
Internal Status      : OOR
Direction            : TX
PSD Minumum          : -24.0 (dBm/12.5 GHz)
Gain Range           : Normal
Last Correction       : 2022-07-06 05:01:28
```

Device Parameters	Min	Max	Configuration	Operational
Egress Ampli Gain (dB)	:15.4	29.4	19.5	19.5
Egress Ampli Tilt (dB)	:-5.0	3.1	-2.2	-2.2
TX Ampli Power (dBm)	: -	22.4	-	21.4
TX VOA Attenuation (dB)	:0.0	20.0	0.0	0.0
Egress WSS/DGE Attenuation (dB)	:0.0	25.0	-	-

Channel Discrepancy	Channel Frequency	Channel Width	Channel ID	Channel Source	Channel Spectrum Slice Num	Ampli-Input PSD	Target PSD	Current PSD
	(THz)	(GHz)				(dBm/12.5 GHz)	(dBm/12.5 GHz)	(dBm/12.5 GHz)
	(dB)	(dB)						
	191.375000	75.00	1	OCh	13	-23.2	-4.6	-4.9
	0.2	7.1						
	191.449997	75.00	-	ASE	37	-23.0	-4.6	-4.7
	0.1	9.2						
	191.524994	75.00	-	ASE	61	-23.1	-4.6	-4.7
	0.1	9.3						
	191.600006	75.00	4	OCh	85	-23.1	-4.5	-4.7
	0.1	8.0						
	191.675003	75.00	-	ASE	109	-23.0	-4.5	-4.5
	0.0	9.1						
	191.750000	75.00	6	OCh	133	-23.0	-4.4	-4.6
	0.1	8.0						
	191.824997	75.00	-	ASE	157	-23.1	-4.4	-4.6
	0.1	9.3						
	191.899994	75.00	8	OCh	181	-23.0	-4.4	-4.4
	0.0	8.0						
	191.975006	75.00	-	ASE	205	-23.0	-4.3	-4.5
	0.1	9.1						
	192.050003	75.00	10	OCh	229	-23.0	-4.3	-4.5
	0.1	8.2						
	192.125000	75.00	-	ASE	253	-22.9	-4.3	-4.3
	0.0	9.0						
	192.199997	75.00	12	OCh	277	-22.8	-4.2	-4.3

0.0	8.3						
192.274994	75.00	-	ASE	301	-22.9	-4.2	-4.4
0.1	9.0						
192.350006	75.00	14	OCh	325	-22.6	-4.2	-4.2
0.0	8.3						
192.425003	75.00	-	ASE	349	-22.8	-4.2	-4.3
0.1	8.7						
192.500000	75.00	16	OCh	373	-22.4	-4.1	-3.9
-0.2	8.1						
192.574997	75.00	-	ASE	397	-22.7	-4.1	-4.2
0.1	8.6						
192.649994	75.00	18	OCh	421	-22.6	-4.1	-4.2
0.1	8.1						
192.725006	75.00	-	ASE	445	-22.7	-4.0	-4.2
0.1	8.6						
192.800003	75.00	20	OCh	469	-22.7	-4.0	-4.1
0.1	7.9						
192.875000	75.00	-	ASE	493	-22.6	-4.0	-4.0
0.0	8.4						
192.949997	75.00	22	OCh	517	-22.6	-3.9	-4.1
0.1	7.6						
193.024994	75.00	-	ASE	541	-22.5	-3.9	-4.0
0.1	8.2						
193.100006	75.00	24	OCh	565	-22.7	-3.8	-4.0
0.1	7.5						
193.175003	75.00	-	ASE	589	-22.7	-3.8	-4.0
0.1	8.2						
193.250000	75.00	26	OCh	613	-22.5	-3.8	-3.9
0.1	7.2						
193.324997	75.00	-	ASE	637	-22.6	-3.8	-4.0
0.2	8.1						
193.399994	75.00	28	OCh	661	-22.7	-3.7	-3.9
0.1	7.2						
193.475006	75.00	-	ASE	685	-22.5	-3.7	-3.8
0.1	8.0						
193.550003	75.00	30	OCh	709	-22.7	-3.7	-3.8
0.1	7.0						
193.625000	75.00	-	ASE	733	-22.7	-3.6	-3.8
0.1	8.1						
193.699997	75.00	32	OCh	757	-22.7	-3.6	-3.7
0.1	6.7						
193.774994	75.00	-	ASE	781	-22.7	-3.5	-3.7
0.1	8.2						
193.850006	75.00	34	OCh	805	-22.7	-3.5	-3.7
0.1	6.6						
193.925003	75.00	-	ASE	829	-22.7	-3.5	-3.6
0.1	8.1						
194.000000	75.00	36	OCh	853	-22.8	-3.5	-3.7
0.2	6.6						
194.074997	75.00	-	ASE	877	-22.8	-3.4	-3.6
0.1	8.3						
194.149994	75.00	38	OCh	901	-22.7	-3.4	-3.5
0.1	10.9						
194.225006	75.00	-	ASE	925	-22.8	-3.3	-3.5
0.1	8.2						
194.300003	75.00	40	OCh	949	-22.9	-3.3	-3.5
0.1	7.1						
194.375000	75.00	-	ASE	973	-22.8	-3.3	-3.4
0.1	8.4						
194.449997	75.00	42	OCh	997	-22.9	-3.2	-3.5
0.2	7.3						
194.524994	75.00	-	ASE	1021	-22.9	-3.2	-3.4
0.1	8.4						
194.600006	75.00	44	OCh	1045	-22.8	-3.2	-3.3

0.1	7.2						
194.675003	75.00	-	ASE	1069	-22.8	-3.2	-3.3
0.1	8.4						
194.750000	75.00	46	OCh	1093	-22.9	-3.1	-3.4
0.2	7.3						
194.824997	75.00	-	ASE	1117	-22.8	-3.1	-3.2
0.1	8.2						
194.899994	75.00	48	OCh	1141	-22.8	-3.0	-3.3
0.2	6.9						
194.975006	75.00	-	ASE	1165	-22.9	-3.0	-3.2
0.1	8.3						
195.050003	75.00	50	OCh	1189	-22.8	-3.0	-3.1
0.1	6.6						
195.125000	75.00	-	ASE	1213	-22.9	-3.0	-3.1
0.1	8.3						
195.199997	75.00	52	OCh	1237	-22.9	-2.9	-3.1
0.1	6.3						
195.274994	75.00	-	ASE	1261	-23.0	-2.9	-3.0
0.1	8.1						
195.350006	75.00	54	OCh	1285	-23.1	-2.8	-3.0
0.1	6.4						
195.425003	75.00	-	ASE	1309	-23.2	-2.8	-3.0
0.1	8.3						
195.500000	75.00	56	OCh	1333	-23.1	-2.8	-2.9
0.1	6.2						
195.574997	75.00	-	ASE	1357	-23.4	-2.8	-3.0
0.2	8.2						
195.649994	75.00	58	OCh	1381	-23.4	-2.7	-2.9
0.1	6.4						
195.725006	75.00	-	ASE	1405	-23.4	-2.7	-2.8
0.1	8.5						
195.800003	75.00	60	OCh	1429	-23.6	-2.7	-2.8
0.1	6.6						
195.875000	75.00	-	ASE	1453	-23.7	-2.6	-2.9
0.2	8.7						
195.949997	75.00	62	OCh	1477	-23.7	-2.6	-2.8
0.2	6.9						
196.024994	75.00	-	ASE	1501	-23.6	-2.5	-2.7
0.1	9.0						
196.100006	75.00	64	OCh	1525	-23.7	-2.5	-2.7
0.1	7.1						

ASE - Noise Loaded Channel

OCh - Optical Channel

**Note**

- In the previous sample output, the channel source is ASE for channels that are empty and for channels that failed due to power level dropping below psd-min. For dropped channels, channel ID is present and the channel source is ASE. ASE or Noise loader fills noise across the spectrum with a spacing of 75 GHz for wherever optical cross connects are not present.
- When APC is in span-mode, the apc regulation info output does not show the channel source on ILA nodes

## Configure APC

If you enable link tuner, the link tuner sets the target PSDs for APC on all nodes in the path.

You can configure the target power spectral densities for 33 points across the band. The 33 PSD values divide the entire spectrum into 150-GHz steps. APC uses the corresponding PSD value if the channel frequency corresponds to a configured point. If the central frequency is not on a configured position, APC computes the target PSD for a channel by extrapolating from the two adjacent steps.

Use the following commands to set the target PSDs for single-band for each node on a C-band network.

**configure**

**optical-line-control**

**controller ots** *Rack/Slot/Instance/Port*

**psd** *<1-33> value*

**commit**

**end**

The following is a sample configuration that sets the psd to 15 dBm/12.5 GHz for the setpoints 1 and 2.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#psd 1 150
RP/0/RP0/CPU0:ios(config-olc-ots)#psd 2 150
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Disable APC

To disable APC for a link, execute the following commands on the transmitting OLT node.

**configure**

**optical-line-control**

**controller ots** *Rack/Slot/Instance/Port*

**apc disable**

**commit**

**end**

The following is a sample configuration that disables APC.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc disable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```



#### Important

- When you disable APC, NCS 1020 sets all setpoints to values in the configuration. If there is no configuration, NCS 1020 sets all setpoints to default values. Disabling APC is traffic impacting.

### Enable Centralized APC

To enable APC for a link, execute the following commands on the transmitting OLT node.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
apc enable
commit
end
```

The following is a sample configuration that enables APC.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc enable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Pause Centralized APC

If you want to modify the network without APC compensating for the changes, you can pause APC. Use the following commands to pause APC.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
apc-pause
commit
end
```

The following is a sample configuration that pauses APC.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc-pause
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```



---

**Note**

- If you run the **apc-pause** command when APC is in idle state, APC remains in the idle state until APC detects changes in the network that requires power correction. APC changes the status to paused after it detects changes, but does not perform power correction.
  - Running the **apc-pause** command, does not pause channel startup.
-

### Disable Centralized APC on an ILA Node

If you want to manually disable APC on a particular node. For example, consider a scenario where the headend OLT encounters a headless event. For any power correction required at agent nodes, APC manager is unavailable to initiate regulation. Also, you cannot perform any adjustments as APC is enabled and user-configuration of target-psd does not take effect. This command gives you an option to disable APC locally on an agent node to perform the parameter adjustments manually. Use the **apc-local disable** command to disable APC on an agent node.

Use the following commands to disable APC on an ILA node.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
apc-local [ RX | TX ] disable
commit
end
```

The following is a sample configuration that disables APC locally.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc-local RX disable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Configure Target Drop PSD

Link Tuner does not set the target PSD for drop ports. The default target PSD for drop ports is -8.0 dBm/12.5 GHz. The NCS 1020 applies drop PSD configuration for channels with cross connect configurations. Use the **drop-psd** command to set the desired drop-psd.

Use the following commands to set the desired drop-psd.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
drop-psd value
commit
end
```

The following is a sample configuration that sets the target PSD at drop ports to -25 dBm/12.5 GHz.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#drop-psd -250
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
Tue Apr 26 09:50:12.055 UTC
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Configure Minimum PSD

If the PSD of a channel with minimum attenuation at the amplifier input on an OLT is less than the minimum PSD, APC marks the channel as failed and replaces the channel using ASE source. The default minimum PSD is -24 dBm/12.5 GHz. Use the **psd-min** command to set the desired minimum PSD.

Use the following commands to set the desired minimum PSD.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
psd-min value
commit
end
```

The following is a sample configuration that sets the minimum PSD to -25 dBm/12.5 GHz.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#psd-min -250
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
Tue Apr 26 09:50:12.055 UTC
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Configure APC Alarm Hold-off Timer

You can configure an interval before APC-TARGET-PSD-NOT-MET alarm is raised after APC detects a discrepancy. The default value is 90 seconds. Use the following commands to configure the timer.

```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
apc-alarm-hold-off-timer time
commit
end
```

The following is a sample configuration that sets the APC alarm hold-off timer to 45 seconds.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc-alarm-hold-off-timer 45
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
Tue Apr 26 09:50:12.055 UTC
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Configure APC Alarm Discrepancy Threshold

You can configure the discrepancy allowed before APC-TARGET-PSD-NOT-MET alarm is raised. The default value is 1dB. Use the following commands to configure the threshold.



```
configure
optical-line-control
controller ots Rack/Slot/Instance/Port
apc-alarm-discrepancy-threshold discrepancy
commit
end
```

The following is a sample configuration that sets the APC alarm discrepancy threshold to 1.5 dB.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc-alarm-discrepancy-threshold 15
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
Tue Apr 26 09:50:12.055 UTC
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

### Switch Between APC Modes

#### Switch from Centralized APC to Span Mode APC

1. Configure APC in manual mode on OLT nodes.
2. Configure apc-span-mode on all nodes.
3. Initiate ALC and wait for ALC process to complete.  
After ALC baseline is saved, APC switches to span mode.

#### Switch from Span Mode APC to Centralized APC

You can switch from span-mode APC to centralized APC in two different ways.

- Commit replace
  1. Reset all nodes to default configuration using the **commit replace** command.
  2. Reload all nodes.
  3. Configure the nodes with required configuration for link bring up.
  4. Configure automatic link bringup or enable APC.  
APC starts regulation in centralized mode.
- **no** configuration of optical applications
  1. Remove the optical applications configurations using the **no** form of APC, Link Tuner, and Gain estimator.
  2. Configure the nodes with required configuration for link bring up.
  3. Configure automatic link bringup or enable APC.  
APC starts regulation in centralized mode.





## CHAPTER 8

# Automatic Network Turn Up

---

This chapter describes the Automatic Network Turn Up workflow for Cisco NCS 1020.

- [Overview of Automatic Link Bring Up, on page 47](#)

## Overview of Automatic Link Bring Up

You can bring up an NCS 1020 DWDM link without using any external tools. NCS 1020 measures optical parameters for all the spans at power-up. It then computes different setpoints for each of the spans to ensure optimal link performance for end-to-end traffic to pass through. The following optical applications enable Automatic Link Bring Up:

- Span loss measurement
- Gain Estimator
- Link Tuner
- Automatic Power Control
- Raman Tuning

Automatic Link Bring Up uses the following user configurations if they are available:

- Measured span loss
- Fiber type
- Spectral Density
- Span length

Automatic Link Bring Up works under the following assumptions:

- The fiber connections are proper. There are no fiber cuts or faulty connectors blocking link bring up.
- OSC link comes up without need of Raman gain. If span length is high and NCS 1020 is not able to turn up OSC without Raman Gain, you must disable Raman tuning and manually configure Raman amplification.

You need Automatic Link Bring Up after physically installing your device and connecting the fibers as necessary. Automatic Link Bring Up process starts when you turn on a device. The new device that you turn on does not have any configuration on it. First, the device must join the network and get an IP address.

The NCS 1020 device uses DHCP to get an IP address. After receiving an IP address using DHCP, the device gets ZTP configuration file from the DHCP server or a separate ZTP server. [Configure the DHCP server](#) with the desired IP address and configuration file for each NCS1020 device you want to configure. The NCS 1020 uses the configuration file and configures itself.

In optical networks with long spans, it is not always practical for all nodes to have direct connectivity to a DHCP server. In such cases, the OLT node that has server connectivity acts as a DHCP relay and provides the next node with DHCP connectivity. The ILA node that connects to the OLT then acts as a DHCP relay for the next ILA node in the link. Each subsequent node then acts as a DHCP relay and provides DHCP connectivity to the adjacent nodes down the link. As this process completes, all nodes get network connectivity and receive the ZTP configuration files. ZTP allows you to provision the network device with day 0 configurations.

The ZTP configuration file must contain the following configurations:

- Host configuration
- DHCP relay configuration (only if there are nodes further down the link)
- Interface configuration
- OSPF configuration
- SSH configuration

See [Boot Using Zero Touch Provisioning](#) for more information on configuring and using ZTP.

After ZTP configuration is complete, the NCS 1020 device uses OSPF to perform topology discovery. During topology discovery, each node finds out about its adjacent node and the entire topology. After discovering neighbor nodes, the device initiates span loss measurement. If the span is a Raman span, the device initiates Raman tuning. Simultaneously, the OLT begins ASE loading to load all the channels with noise.

After ASE loading, span loss measurement, and Raman tuning are complete, the NCS 1020 device initiates Startup Gain Estimation and Link tuner. Startup Gain Estimation sets the target gain and gain mode for the EDFA amplifier. Link tuner provides the target PSDs for the channels.




---


**Note** **Startup Gain Estimation** analyses the span loss and sets the gain mode of the EDFA amplifier and provides the initial target gain for the amplifier. EDFA amplifiers are present in both OLT and ILA variants of NCS 1020. These EDFA amplifiers are variable-gain optical amplifiers capable of working at two different gain ranges or modes. The modes are normal mode and extended mode. Extended mode provides higher gain than the normal mode. Changing the gain mode of an amplifier is traffic impacting. Therefore, Automatic Power Correction (APC) is unable to change the gain mode of an amplifier.

---

After Startup Gain Estimation and Link tuner operations are complete, the NCS 1020 initiates APC. APC uses the target PSDs that Link tuner sets and regulates the power output for all channels. Automatic Link Bring Up is complete and the optical link is up with all ASE loaded noise channels with the target PSDs set by link tuner. Create and configure optical cross connects to get traffic up and running on the link.

The following flowchart shows the sequence of the optical applications during automaticlink bring up.

Figure 2: Automatic Link Bring-up



522668

The following example shows a sample ZTP configuration file with the minimum required configuration.

```

!! IOS XR Configuration
!
hostname ios
username cisco
group root-lr
group cisco-support
secret 10
$6$7motIAh93vG/I...$iM64ZfsZ5ciicdcsdsewHdEiVLTq0YEclG1NMpauwJUiEnkV8LwMJUDZnnTkVj9RPgf4wffWJYe1PN7jqIN3q/

dhcp ipv4
profile r1 relay
  helper-address vrf default 10.33.0.51 giaddr 10.7.3.2
!
profile r2 relay
  helper-address vrf default 10.33.0.51 giaddr 10.7.2.2
!
interface GigabitEthernet0/0/0/0 relay profile r2
interface GigabitEthernet0/0/0/2 relay profile r1
!
call-home
service active
contact smart-licensing
profile CiscoTAC-1

```

```

    active
    destination transport-method email disable
    destination transport-method http
  !
  !
interface Loopback0
ipv4 address 10.3.3.13 255.255.255.255
!
interface GigabitEthernet0/0/0/0
ipv4 address 10.7.2.2 255.255.255.0
!
interface GigabitEthernet0/0/0/2
ipv4 address 10.7.3.2 255.255.255.0
!
router ospf 1
router-id 10.3.3.13
distribute link-state
nsf
network point-to-point
redistribute connected
area 0
    interface Loopback0
    !
    interface GigabitEthernet0/0/0/0
    !
    interface GigabitEthernet0/0/0/2
    !
!
!
ssh server v2
ssh server vrf default
ssh server netconf vrf default
!
end

```

### Enable Automatic Link Bring Up

Use the following commands to enable automatic link bring up.

```

configure
optical-line-control
automatic-link-bringup
commit
end

```

### Disable Automatic Link Bring Up

Use the following commands to disable automatic link bring up.

```

configure
optical-line-control
no automatic-link-bringup
commit
end

```



## CHAPTER 9

# Configure OTDR

This chapter describes how to configure the Optical Time Domain Reflectometer (OTDR) module in NCS 1020.

- [OTDR, on page 51](#)
- [OTDR modes , on page 52](#)
- [Configure the OTDR scan parameters, on page 52](#)
- [Start the OTDR scan, on page 55](#)
- [View the OTDR measurements, on page 56](#)
- [Stop the OTDR scan, on page 57](#)
- [Automatic OTDR scans, on page 57](#)
- [Examples for OTDR scan measurement results, on page 63](#)
- [OTDR scan status, on page 64](#)

## OTDR

An Optical Time Domain Reflectometer (OTDR) is a fiber optic measurement device that

- captures real-time data on loss and back reflection across fiber links,
- performs bidirectional analysis by connecting to both transmitter (TX) and receiver (RX) ports, and
- enables assessment and ongoing monitoring of fiber quality and performance.

The NCS 1020 nodes feature in-built bidirectional OTDR functionality, allowing them to measure loss and back reflection in real time for fiber pairs linked to the TX and RX ports. For the OLT device, the OTDR port can switch between LINE-TX and LINE-RX ports. For the ILA device, the OTDR port can switch among LINE-1-TX, LINE-1-RX, LINE-2-TX, and LINE-2-RX ports.

### SOR file

You can view OTDR measurement results in a Standard OTDR Record (SOR) file. The SOR file includes fiber trace details such as distance, reflectance, loss, and fiber attenuation measurements.

You can export the SOR file from NCS 1020 using the command: **scp username@device-ip:filename\_with\_source\_location destination-location**.

### Example:

```
scp test@192.168.0.1:/harddisk:/otdr/ios_OTDR_Ots0_0_0_0_RX_20230301-101927.sor /users/test/
```

From Release 25.4.1, SOR files from manual and automatic scans are stored in separate folders within the OTDR directory. Automatically generated SOR files are saved in `/harddisk:/otdr/auto/`, while manually triggered SOR files are stored in the existing `/harddisk:/otdr/` folder.

### Benefits

The OTDR offers several key benefits, including:

- Assess the quality of the fiber during system installation, before any live traffic run.
- Monitor the fiber link during operation, including live traffic. You can also monitor the fiber link during troubleshooting after cable cuts or repairs.
- Measure attenuation over the entire fiber link and across individual fiber sections.
- Determine the distance and magnitude of insertion loss and reflection loss.
- Detect fiber events, including concentrated loss events, reflection events, end-of-fiber events, and discontinuities or defects such as pinches or cuts. The OTDR pluggable can also detect loss events from splicing, patch panel connections, and couplers.

## OTDR modes

OTDR modes are operational configurations that

- determine how scan parameters (like pulse width and scan duration) are selected and applied,
- optimize measurements for different user needs or fiber types, and
- support both automated and manual control for various operational scenarios.

An OTDR can operate in several modes to suit different network testing requirements. Selecting the appropriate mode helps ensure efficient, accurate fiber characterization by adapting OTDR performance to the specific task or fiber segment.

These modes are designed to address different testing needs and operational preferences:

1. **Auto:** The device automatically selects the optimal values for OTDR pulse width, scan duration, capture start time, and capture end time parameters. This is the default mode and does not require explicit configuration. However, you can manually configure the other scan parameters if needed.
2. **Expert:** You must manually configure all OTDR scan parameters with the valid values that are required for the OTDR measurement. Automatic adjustments are not performed in this mode.

## Configure the OTDR scan parameters

Use this procedure to configure the parameters for the OTDR scan. If you do not configure the parameters, the NCS 1020 device uses the default values.



## Procedure

**Step 1** Enter the OTS controller configuration mode for the port where you want to configure the OTDR parameters.

**Example:**

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller ots 0/0/0/0
```

**Step 2** Enter the OTDR mode.

If you want to configure the	then run this command
Expert mode	RP/0/RP0/CPU0:ios(config-Ots)#otdr scan-mode expert
Auto mode	Auto mode is the default and you do not need to configure it

**Step 3** Set the required parameters for the OTDR scan. For a complete list of OTDR parameters, refer to [OTDR scan parameters, on page 53](#).

**Example:**

```
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx auto reflectance-threshold -50
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx auto splice-loss-threshold 200
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx expert pulse-width 6000
RP/0/RP0/CPU0:ios(config-Ots)#commit
```

**Step 4** Commit the changes and exit the configuration mode.

**Example:**

```
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#exit
```

## What to do next

[Start the OTDR scan, on page 55.](#)

## OTDR scan parameters

This table provides an overview of key OTDR parameters, including their definitions, measurement units, range of values and the default values.

**Table 2: OTDR scan parameters in Auto mode**

Parameter	Description	Unit	Range	Default
<b>otdr { rx   tx } auto reflectance-threshold</b> <value>	Threshold beyond which a reflective anomaly is reported as an event in the Rx or Tx direction.	dB	–50 to –10	–40

Parameter	Description	Unit	Range	Default
<b>otdr { rx   tx } auto splice-loss-threshold</b> <i>&lt;value&gt;</i>	Threshold beyond which a loss anomaly is reported as an event in Rx or Tx direction.	dB	0.2 to 5	0.35
<b>otdr { rx   tx } auto excess-reflection-threshold</b> <i>&lt;value&gt;</i>	Threshold beyond which a reflective event is reported as an excessive reflection event in the Rx or Tx direction.	dB	−50 to −10	−20
<b>otdr { rx   tx } auto back-scattering</b> <i>&lt;value&gt;</i>	The back scattering value in the Rx or Tx direction.	dB	−90 to −70	−81.87
<b>otdr { rx   tx } auto refractive-index</b> <i>&lt;value&gt;</i>	The refractive-index value in the Rx or Tx direction.	-	1.000 to 2.000	1.4682
<b>otdr { rx   tx } auto excess-orl-threshold</b> <i>&lt;value&gt;</i>	Threshold below which OTDR-ABS-ORL-EXCEEDED alarm is reported in the Rx or Tx direction.	dB	10–60	60
<b>otdr { rx   tx } auto excess-attenuation-threshold</b> <i>&lt;value&gt;</i>	Threshold beyond which a Non-Reflective event is reported as an excessive attenuation event in the Rx or Tx direction.	dB	0.5 to 5	5
<b>otdr { rx   tx } auto end-of-fiber-loss-threshold</b> <i>&lt;value&gt;</i>	Threshold based on which the OTDR identifies the fiber's end, distinguishing it from other components like splices or connectors.	dB	5–99	5.5

Table 3: OTDR scan parameters in Expert mode

Parameter	Description	Unit	Range	Default
<b>otdr { rx   tx } expert pulse-width</b> <i>&lt;value&gt;</i>	Pulse width to be used during the expert scan in the Rx or Tx direction.	ns	5–20000	20
<b>otdr { rx   tx } expert capture-end</b> <i>&lt;value&gt;</i>	OTDR capture endpoint during the expert scan in the Rx or Tx direction.	cm	0–15000000	15000000
<b>otdr { rx   tx } expert capture-start</b> <i>&lt;value&gt;</i>	OTDR capture start point during expert scan in the Rx or Tx direction	cm	0–10000000	0

Parameter	Description	Unit	Range	Default
<b>otdr {rx   tx} expert scan duration</b> <value>	OTDR scan duration during expert scan in the Rx or Tx direction.	Seconds	0–180	60

## Start the OTDR scan

Manually initiate the OTDR scan to diagnose fiber defects, check fiber quality, or verify proper installation.

From Release 25.4.1, you can use the `label` keyword to append a custom substring as a prefix to the SOR file name. This substring helps you identify and retrieve specific SOR files stored in the directory.

### Procedure

**Step 1** Use the **otdr-start controller ots** *R/S/I/P direction* to start the OTDR scan manually.

**Example:**

```
RP/0/RP0/CPU0:ios#otdr-start controller ots 0/0/0/0 rx
Wed Feb 9 05:49:39.178 UTC
OTS OTDR Scan Started at RX
RP/0/RP0/CPU0:ios#
```

This example illustrates a rejected OTDR start request. Once an OTDR scan request has been rejected, it will not automatically run after the lock is released. You will need to create a new request to start the OTDR scan again. These examples show that OTDR scan is locked by Raman tuning:

```
RP/0/RP0/CPU0:ios#otdr-start controller ots 0/0/0/0 rx
Tue Feb 28 10:25:43.379 UTC
OTDR Scan cannot be started as it is locked by Another Entity/Application.
RP/0/RP0/CPU0:ios#
```

**Step 2** Use the `label string` keyword, to append a custom substring as a prefix to the SOR file name.

**Example:**

```
RP/0/RP0/CPU0:ios#otdr-start controller ots 0/0/0/0 rx label Site1.ABC_xyz-1
Mon Nov 3 09:56:23.278 UTC
OTS OTDR Scan Started at RX
RP/0/RP0/CPU0:ios#
```

This example appends the string *Site1.ABC\_xyz-1* to the SOR file name. For example:

```
/harddisk:/otdr/Site1.ABC_xyz-1_ios_OTDR_Ots0_0_0_0_RX_20250306-110133.sor.
```

The OTDR label must adhere to these limitations: Only the special characters dot, hyphen, and underscore are permitted. The maximum file name length is 255 characters. The maximum label length is 55 characters.

The OTDR scan initiates and begins analyzing the fiber. If the scan cannot start, an error message states the reason.

### What to do next

Review scan results to identify defects and assess fiber quality.

# View the OTDR measurements

Use this procedure to view the OTDR scan measurement results.

From Release 25.4.1, the OTDR scan measurement results show Total Measured Loss and Total Measured Length.

This measurement includes the natural backscattered power of the fiber and the reflected power coming from optical connectors, fiber splicing, or other discontinuities along the link. ORL is expressed with a positive number.



**Note** Higher ORL values are desirable for the fiber because they indicate lower back reflection. For example, an ORL of 40 dB is better than 20 dB.

## Procedure

Use the command **show controllers ots R/S/I/P otdr-info direction** to view the OTDR scan measurements.

### Example:

```
RP/0/RP0/CPU0:ios#show controllers ots 0/0/0/0 otdr-info rx
Wed Feb  9 05:55:19.791 UTC
  Scan Direction: RX
  Scan Status: Data Ready
  SOR file: /harddisk:/otdr/IOS_OTDR_Ots0_0_0_0_RX_20220209-055045.sor
  Total Events detected: 11
  Scan Timestamp: Wed Feb  9 05:50:45 2022 UTC
  Event Type Legend:  NR:Non-Reflective  R:Reflective  FE:Fiber-End  ER:Excess-Reflection
```

Event#	Detected Event(s)	Location(km)	Accuracy(m)	Magnitude(dB)	Attenuation/km(dB)
1	R	50.4709	52.47	-39.87	0.18
2	NR	50.4709	52.47	1.17	0.18
3	R	100.9261	102.92	-37.73	0.21
4	NR	100.9261	102.92	1.01	0.21
5	R	105.9500	107.94	-38.52	0.24
6	NR	105.9500	107.94	0.85	0.24
7	R	112.7458	114.74	-40.56	0.00
8	NR	112.7458	114.74	1.48	0.00
9	NR	117.9873	119.98	0.66	-0.02
10	R FE	120.1206	122.12	-35.55	0.00
11	NR FE	120.1206	122.12	21.65	0.00

### Example:

These are the sample OTDR measurement results displaying Total Measured Loss, Total Measured Length and SOR file with appended OTDR label.

```
RP/0/RP0/CPU0:ios#show controllers ots 0/0/0/2 otdr-info tx
Thu Dec  4 09:28:25.136 IST
  Scan Direction: TX
  Scan Status: Data Ready
  Total Measured Loss: 11.04 dB
  Total Measured Length: 50746.3000 m
  Optical Return Loss: 25.0 dB
  SOR file: /harddisk:/otdr/auto/ios_OTDR_Ots0_0_0_2_TX_20251203-122210.sor
```

```

Total Events detected: 4
Scan Timestamp: Wed Dec 3 12:22:10 2025 UTC
Event Type Legend: NR:Non-Reflective R:Reflective FE:Fiber-End ER:Excess-Reflection
EA:Excess-Attenuation

```

Event#	Detected Event(s)	Location(m)	Accuracy(m)	Magnitude(dB)
Attenuation/km (dB)				
1	NR	0.6800	2.00	0.66
0.00				
2	R	10.4800	2.01	-33.66
0.00				
3	R FE ER	50746.3000	52.74	-15.28
0.20				
4	NR FE	50746.3000	52.74	11.04
0.20				

**Note**

The output shows Total measured loss and Total measured length only if a Fiber-End (FE) event is detected.

After you upgrade the FPD of the line card, you may not be able to view the previous OTDR scan results using the **show controllers ots Rack/Slot/Instance/Port otdr-info direction**. To access results from earlier OTDR scans, locate the .SOR files on the hard disk.

You can dynamically raise or clear Excessive Reflection (ER) and Excess Attenuation (EA) events and alarms by modifying their respective threshold values. In contrast, to raise or clear Fiber End (FE) and Reflectance (R) events, change the relevant thresholds and rerun the OTDR scan.

See [OTDR scan measurement results](#) for various examples.

## Stop the OTDR scan

Use this procedure to stop the OTDR scan manually.

**Procedure**

Enter the command **otdr-stop controller ots R/S/I/P direction** to stop the OTDR scan.

**Example:**

```

RP/0/RP0/CPU0:ios#otdr-stop controller ots 0/0/0/0 rx
Wed Feb 9 06:03:37.406 UTC
OTS OTDR Scan Stopped at RX
RP/0/RP0/CPU0:ios#

```

## Automatic OTDR scans

An automatic OTDR scan is a fiber diagnostics feature that

- automatically triggers OTDR tests in response to specific events such as span fault, span restoration, device power cycling, and line card cold reload that affect the optical span,

- enables RX directionscanning for comprehensive fault detection and prevents scan collisions, and
- provides rapid fault localization by monitoring and raising relevant alarms during scan execution.

### Autoscan direction and duration

Autoscan is performed only in the Rx direction, regardless of whether the span fault is unidirectional or bidirectional.

In both span up and span down events, the bidirectional OTDR scan process terminates after both Rx and Tx scans have been completed successfully. You can stop the scan sequence by disabling the autoscan feature.

The OTDR autoscan takes less than three minutes to complete. During the autoscan, the OTDR-SCAN-IN-PROGRESS-RX alarm is raised and gets cleared once the scan is finished.

## Autoscan behavior

Autoscan manages OTDR scanning by coordinating access to scanning resources and responding to interactions with manual and application-triggered scans:

Autoscan manages OTDR scanning operations in these ways:

- Autoscan locks the OTDR resource to prevent manual scan triggers using the **otdr-start** command. However, if a manual scan is already in progress, autoscan waits for its completion before proceeding.
- Autoscan terminates any ongoing scan that was triggered by other applications, such as Raman turn-up.
- During autoscan, if a change in Span Status is detected, it terminates the ongoing scan and automatically initiates a new autoscan.

## Criteria for span fault and restoration events

This table lists the detection criteria for span fault and restoration events.

**Table 4: Definition of span up and span down events**

Events	Non-Raman span	Raman span	Raman span with dual safety configured
Span Down	Raise of RX-LOS-P alarm at OSC controller	Raise of RX-LOS-P alarm at DFB controller	Raise of RX-LOS-P alarm at both OSC and DFB controllers
Span Up	Clearing of RX-LOS-P alarm at OSC controller	Clearing of RX-LOS-P alarm at DFB controller	Clearing of RX-LOS-P alarm at both OSC and DFB controllers

## Configure automatic OTDR scan

Use this task to enable OTDR scan to run automatically during certain events.

## Procedure

**Step 1** Enter OTS controller configuration mode for the port on which you want to enable automatic OTDR scan.

**Example:**

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control controller Ots 0/0/0/0
```

**Step 2** Enable automatic OTDR scan.

**Example:**

```
RP/0/RP0/CPU0:ios(config-olc-ots)#otdr auto-scan enable
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#exit
```

If you want to disable the automatic OTDR scan, use the **otdr auto-scan disable** command.

Automatic OTDR scans are enabled for the selected port. The system will now run OTDR scans automatically during applicable events, allowing you to proactively monitor fiber links and detect faults without manual intervention.

## Verify autoscan status

Use this procedure to verify the status of the autoscan.

## Procedure

View the automatic OTDR scan results using the command **show olc otdr-status [details]**.

**Example:**

This sample display the status of autoscan triggered due to a span fault. See [Automatic OTDR scan results, on page 60](#) for more examples.

```
RP/0/RP0/CPU0:ios#show olc otdr-status details
Mon Sep 18 13:16:16.461 UTC
Controller                               : Ots0/0/0/0
Auto-scan Start Time                     : NA
OTDR Auto-scan Status                   : RUNNING
Status Detail                           : Starting on Span Down
Optical Span Status                      : Down
Trigger Event                          : Span Fault
Last Trigger Event                      : Span Restore

RP/0/RP0/CPU0:ios#show olc otdr-status details
Mon Sep 18 13:16:33.304 UTC
Controller                               : Ots0/0/0/0
Auto-scan Start Time                     : 2023-09-18 13:16:27
OTDR Auto-scan Status                   : RUNNING
Status Detail                           : Waiting Scan Completion on Span Down
Optical Span Status                      : Down
```

```

Trigger Event                : Span Fault
Last Trigger Event          : Span Restore

RP/0/RP0/CPU0:ios#show olc otdr-status details
Mon Sep 18 13:18:54.154 UTC
Controller                   : Ots0/0/0/0
Auto-scan Start Time         : 2023-09-18 13:16:27
OTDR Auto-scan Status        : COMPLETED
Status Detail                : Completed on Span Down
Optical Span Status          : Down
Trigger Event                : Span Fault
Last Trigger Event          : Span Fault

```

### What to do next

If events indicate potential fiber issues, review the SOR file or perform additional analysis as needed.

## Automatic OTDR scan results

This table presents automatic OTDR scan results observed across different network scenarios.

**Table 5: Automatic scan results**

Network scenarios	Sample OTDR scan results
Non-Raman span	<pre> RP/0/RP0/CPU0:ios#show olc otdr-status Mon Sep 18 13:10:57.733 UTC Controller                   : Ots0/0/0/0 Auto-scan Start Time         : NA OTDR Auto-scan Status        : DISABLED Status Detail                : NA Optical Span Status          : UP Trigger Event                : NA  RP/0/RP0/CPU0:ios#show olc otdr-status details Mon Sep 18 13:11:00.565 UTC Controller                   : Ots0/0/0/0 Auto-scan Start Time         : NA OTDR Auto-scan Status        : DISABLED Status Detail                : NA Optical Span Status          : UP Trigger Event                : NA Last Trigger Event          : NA </pre>



Network scenarios	Sample OTDR scan results
Raman span	<pre> RP/0/RP0/CPU0:ios#show olc otdr-status Mon Sep 18 13:41:05.088 UTC Controller                                     : Ots0/0/0/0 Auto-scan Start Time                           : NA <b>OTDR Auto-scan Status</b>                       : <b>DISABLED</b> <b>Raman Turn Up Fiber Check</b>                 : <b>NA</b> Status Detail                                 : NA Optical Span Status                           : UP Trigger Event                                 : NA  RP/0/RP0/CPU0:ios#show olc otdr-status details Mon Sep 18 13:41:08.825 UTC Controller                                     : Ots0/0/0/0 Auto-scan Start Time                           : 2023-09-20 13:58:17 <b>OTDR Auto-scan Status</b>                       : <b>DISABLED</b> Status Detail                                 : NA <b>Raman Turn Up Fiber Check</b>                 : <b>NA</b> Optical Span Status                           : UP Trigger Event                                 : NA Last Raman Turn Up Scan Time                  : NA Last Raman Turn Up Fiber Check               : NA Last Trigger Event                           : NA </pre>
Span restore	<pre> RP/0/RP0/CPU0:ios#show olc otdr-status details Mon Sep 18 13:12:40.430 UTC Controller                                     : Ots0/0/0/0 Auto-scan Start Time                           : NA <b>OTDR Auto-scan Status</b>                       : <b>RUNNING</b> <b>Status Detail</b>                             : <b>Starting on</b> <b>Span Up</b> Optical Span Status                           : Up <b>Trigger Event</b>                             : <b>Span Restore</b> Last Trigger Event                           : NA  RP/0/RP0/CPU0:ios#show olc otdr-status details Mon Sep 18 13:15:06.153 UTC Controller                                     : Ots0/0/0/0 Auto-scan Start Time                           : 2023-09-18 13:12:42 <b>OTDR Auto-scan Status</b>                       : <b>RUNNING</b> <b>Status Detail</b>                             : <b>Waiting Scan</b> <b>Completion on Span Up</b> Optical Span Status                           : Up <b>Trigger Event</b>                             : <b>Span Restore</b> Last Trigger Event                           : NA  RP/0/RP0/CPU0:ios#show olc otdr-status details Mon Sep 18 13:15:06.153 UTC Controller                                     : Ots0/0/0/0 Auto-scan Start Time                           : 2023-09-18 13:12:42 <b>OTDR Auto-scan Status</b>                       : <b>COMPLETED</b> <b>Status Detail</b>                             : <b>Completed on</b> <b>Span Up</b> Optical Span Status                           : Up Trigger Event                                 : Span Restore Last Trigger Event                           : Span Restore </pre>

Network scenarios	Sample OTDR scan results
Autoscan is unable to lock the OTDR resource	<pre>RP/0/RP0/CPU0:ios# show olc otdr-status details Wed Sep 20 14:09:37.011 UTC Controller                               : Ots0/0/0/0 Auto-scan Start Time                     : 2023-09-20 13:58:17 OTDR Auto-scan Status                     : COMPLETED <b>Status Detail</b>                           : <b>Failed due to</b> <b>Timeout</b> Raman Turn Up Fiber Check                 : NA Optical Span Status                       : UP Trigger Event                             : Span Restore Last Raman Turn Up Scan Time               : NA Last Raman Turn Up Fiber Check             : NA Last Trigger Event                         : NA</pre>
Autoscan on one port is waiting for the OTDR resource, because the autoscan is running on another port.	<pre>RP/0/RP0/CPU0:ios#show olc otdr-status details Mon Sep 18 15:57:43.671 UTC Controller                               : Ots0/0/0/0 Auto-scan Start Time                     : 2023-09-18 15:57:43 OTDR Auto-scan Status                     : COMPLETED <b>Status Detail</b>                           : <b>Waiting for</b> <b>OTDR Resource</b> Raman Turn Up Fiber Check                 : NA Optical Span Status                       : UP Trigger Event                             : Span Restore Last Raman Turn Up Scan Time               : NA Last Raman Turn Up Fiber Check             : NA Last Trigger Event                         : NA</pre>
<p>Autoscan is enabled and Raman turnup is disabled on a Raman span</p> <p>In this case</p> <ul style="list-style-type: none"> <li>• On the span down event, the autoscan is triggered.</li> <li>• On the span up event, autoscan is not triggered and OTDR Autoscan Status will be IDLE, because Raman pumps are turned on before the start of autoscan.</li> <li>• On the span up event, autoscan is triggered and <i>OTDR Autoscan Status</i> is displayed as RUNNING.</li> </ul>	<pre>RP/0/RP0/CPU0:ios#show olc otdr-status details Sat Sep 23 12:42:11.304 UTC Controller                               : Ots0/0/0/0 Auto-scan Start Time                     : NA <b>OTDR Auto-scan Status</b>                   : <b>IDLE</b> Status Detail                             : NA Raman Turn Up Fiber Check                 : NA Optical Span Status                       : UP Trigger Event                             : Span Fault Last Raman Turn Up Scan Time               : NA Last Raman Turn Up Fiber Check             : NA Last Trigger Event                         : Span Restore</pre>

Network scenarios	Sample OTDR scan results
Ongoing autoscan is stopped by the user	<pre>RP/0/RP0/CPU0:ios#show olc otdr-status details Mon Sep 18 15:08:27.370 UTC Controller                               : Ots0/0/0/0 Auto-scan Start Time                     : 2023-09-18 15:08:09 OTDR Auto-scan Status                     : COMPLETED <b>Status Detail</b>                           : <b>Stopped by</b> <b>User</b> Raman Turn Up Fiber Check                : NA Optical Span Status                      : DOWN Trigger Event                            : Span Fault Last Raman Turn Up Scan Time              : 2023-09-18 14:55:40 Last Raman Turn Up Fiber Check            : Success Last Trigger Event                        : Span Restore</pre>

See [OTDR scan status, on page 64](#) for a list of the different OTDR scan statuses and their definitions.

## Examples for OTDR scan measurement results

### Optical return loss in OTDR measurement results

Optical Return Loss (ORL) is measured during the OTDR scan and displayed as part of the OTDR results. The ORL represents the total reflected optical power from a complete fiber link, while considering the attenuation. This includes the natural backscattered power of the fiber and the reflected power coming from optical connectors, fiber splicing, or other discontinuities along the link. ORL is expressed with a positive number. Higher ORL values are desirable for the fiber because they indicate lower back reflection. For example, an ORL of 40 dB is better than 20 dB.

This sample displays the ORL value as part of OTDR status:

```
RP/0/RP0/CPU0:ios#show controllers Ots 0/0/0/2 otdr-info rx
Mon Oct 2 11:55:48.552 UTC
Scan Direction: RX
Scan Status: Data Ready
Optical Return Loss: 39.0 dB
SOR file: /harddisk:/otdr/NCS1020_NCS1020_OTDR_Ots0_0_0_2_RX_20231001-110754.sor
Total Events detected: 8
Scan Timestamp: Sun Oct 1 11:07:54 2023 UTC
Event Type Legend:NR:Non-Reflective R:Reflective FE:Fiber-End ER:Excess-Reflection
EA:Excess-Attenuation
```

Event#	Detected Event(s)	Location(m)	Accuracy(m)	Magnitude(dB)	Attenuation/km(dB)
1	NR EA	4.4100	2.00	0.69	0.00
2	NR	664.3200	2.66	0.21	0.00
3	R ER	18222.3900	20.22	-33.78	0.19
4	NR	18222.3900	20.22	0.35	0.19
5	R ER	68674.4800	70.67	-32.25	0.20
6	NR	68674.4800	70.67	0.36	0.20
7	R FE ER	118765.2600	120.76	-28.55	0.23
8	NR FE	118765.2600	120.76	25.86	0.23

See [OTDR scan status, on page 64](#) for a list of the different OTDR scan statuses and their definitions.

## OTDR scan status

This section describes and explains the various OTDR statuses that appear when using the **show olc controller ots R/S/I/P otdr-status** and **show controller ots R/S/I/P otdr-info** commands.

**Table 6: OTDR scan status**

Scan status	Description
Measuring	OTDR scan is currently in progress.
Data Processing	OTDR scan has completed, and the data is ready for review
Data Ready	OTDR scan is stopped by the user, when it is in progress.
Stopped	OTDR is processing data just before populating the event table.
Error	The OTDR status may occasionally enter an Error state for various unpredictable reasons. One possible cause is a timeout event, which occurs if the scan is not completed within five minutes. In such cases, no SOR files or event table is generated. It is important to note that this is a rare occurrence. You can still initiate the OTDR scan to obtain the scan results.

This table explains the various OTDR scan statuses that are applicable for manual and autoscan.

**Table 7: OTDR scan status applicable for manual and autoscan**

Type of OTDR scan	Scan Status	
	show olc controller ots R/S/I/P otdr-status	show controller ots R/S/I/P otdr-info
Manual	NA	<ul style="list-style-type: none"> <li>• Measuring</li> <li>• Data Processing</li> <li>• Data Ready</li> <li>• Stopped</li> <li>• Error</li> </ul>

Type of OTDR scan	Scan Status	
	show olc controller ots R/S/I/P otdr-status	show controller ots R/S/I/P otdr-info
Autoscan	<ul style="list-style-type: none"><li>• Measuring</li><li>• Data Processing</li><li>• Data Ready</li><li>• Stopped</li><li>• Error</li></ul>	<ul style="list-style-type: none"><li>• Measuring</li><li>• Data Processing</li><li>• Data Ready</li><li>• Stopped</li><li>• Error</li></ul>





## CHAPTER 10

# Implementing Host Services and Applications

Cisco IOS XR software Host Services and Applications features on the router are used primarily for checking network connectivity and the route a packet follows to reach a destination, mapping a hostname to an IP address or an IP address to a hostname, and transferring files between routers and UNIX workstations.

### Prerequisites for implementing Host Services and Applications

Ensure to install the relevant optional RPM package before using the host services or applications.

- [HTTP Client Application, on page 67](#)
- [TCP Overview, on page 68](#)

## HTTP Client Application

HTTP Client allows files to be transferred from http server to another device over a network using HTTP protocol. You can configure http client and various parameters associated with it by using the **http client** command.

### Configure HTTP Client

HTTP Client application is available by default. You can configure http client settings or view and modify the existing settings. To configure the settings, use the **http client** command in XR config mode.

```
Router #configure
Router(config)#http client ?
connection          Configure HTTP Client connection
response            How long HTTP Client waits for a response from the server
                    for a request message before giving up
secure-verify-host  Verify that if server certificate is for the server it is known as
secure-verify-peer  Verify authenticity of the peer's certificate
source-interface    Specify interface for source address
ssl                 SSL configuration to be used for HTTPS requests
tcp-window-scale    Set tcp window-scale factor for High Latency links
version             HTTP Version to be used in HTTP requests
vrf                 Name of vrf
```

**Table 8: Commands used to configure HTTP Client settings**

Features	Description
<b>connection</b>	Configure HTTP Client connection by using either retry or timeout options.

Features	Description
<b>response</b>	How long HTTP Client waits for a response from the server for a request message before giving up.
<b>secure-verify-host</b>	Verify host in peer's certificate. To disable verifying this, you can use the command <b>http client secure-verify-host disable</b>
<b>secure-verify-peer</b>	Verify authenticity of the peer's certificate.
<b>source-interface</b>	Specifies the interface for source address for all outgoing HTTP connections. You can enter either an ipv4 or ipv6 address or both.
<b>ssl version</b>	SSL version (configuration) to be used for HTTPS requests.
<b>tcp-window-scale scale</b>	Set tcp window-scale factor for high latency links.
<b>version version</b>	HTTP version to be used in HTTP requests. <ul style="list-style-type: none"> <li>• 1.0 - HTTP1.0 will be used for all HTTP requests.</li> <li>• 1.1 - HTTP1.1 will be used for all HTTP requests.</li> <li>• default libcurl - will use HTTP version automatically.</li> </ul>
<b>vrf name</b>	Name of vrf.

### Examples

**Example 1:** This example shows how to set the tcp window-scale to 8.

```
Router(config)#http client tcp-window-scale 8
```

**Example 2:** This example shows how to set the HTTP version to 1.0.

```
Router(config)#http client version 1.0
```



**Note** HTTP Client uses libcurl version 7.30

## TCP Overview

TCP is a connection-oriented protocol that specifies the format of data and acknowledgments that two computer systems exchange to transfer data. TCP also specifies the procedures the computers use to ensure that the data arrives correctly. TCP allows multiple applications on a system to communicate concurrently, because it handles all demultiplexing of the incoming traffic among the application programs.



## TCP Dump File Converter

TCP dump file converter is a tool that converts ios-xr dump-files in binary format to user-friendly format such as PCAP or text.

It proves especially useful when you disable Non-Stop Routing (NSR) or experience a session flap on your system. During such incidents, by default, the TCP process running on the NCS system promptly stores the latest 200 packet traces in binary format within a temporary folder.

TCP dump packet traces also includes data about the configured routing protocols and the overall network traffic traversing your system. This data equips you with the necessary insights to identify and resolve issues within your network infrastructure, facilitating proactive network troubleshooting.

You can view the packet traces binary files in the user-readable format using the following methods:

- You can use the **show tcp dump-file <binary filename>** command to view each binary file in text format manually. For more information, refer to [View Binary Files in Text Format Manually, on page 69](#).

This process consumes much time, as you have to view each file manually one after another.

- You can convert all stored packet traces in binary files into PCAP, text, or both using the **tcp dump-file convert** command. For more information, refer to [Convert Binary Files to Readable Format Using TCP Dump File Converter, on page 70](#).

This active approach greatly improves the efficiency and ease of packet analysis during network troubleshooting.

## Limitations and Restrictions for TCP Dump File Converter

- The system only stores the most recent 200 message exchanges that occurred right before the session termination, when NSR is disabled, or during a session flap.
- You can view only one binary file in text format using the **show tcp dump-file <binary filename>** command.
- TCP dump files are generated by default for BGP, MSDP, MPLS LDP and SSH.

## View Binary Files in Text Format Manually

Perform the following steps to view each packet traces binary file in text format without using the TCP dump file converter:

### Procedure

- Step 1** View the list of packet traces in binary files stored in the tcpdump folder using the **show tcp dump-file list all** command.

#### Example:

```
RP/0/RP0/CPU0:ios# show tcp dump-file list all
total 1176
-rw-r--r-- 1 root root 5927 Nov 22 12:42 31_0_0_126.179.20966.cl.1700656933
-rw-r--r-- 1 root root 5892 Nov 22 12:42 31_0_0_127.179.35234.cl.1700656933
-rw-r--r-- 1 root root 6148 Nov 22 12:42 31_0_0_149.179.54939.cl.1700656933
-rw-r--r-- 1 root root 5894 Nov 22 12:42 31_0_0_155.179.18134.cl.1700656933
-rw-r--r-- 1 root root 6063 Nov 22 12:42 31_0_0_156.179.25445.cl.1700656933
-rw-r--r-- 1 root root 5860 Nov 22 12:42 31_0_0_161.179.30859.cl.1700656933
```

```
-rw-r--r-- 1 root root 5832 Nov 22 12:42 31_0_0_173.179.36935.cl.1700656933
-rw-r--r-- 1 root root 5906 Nov 22 12:42 31_0_0_190.179.25642.cl.1700656933
```

**Step 2** View each packet traces binary file in text format using the **show tcp dump-file <binary filename>** command.

**Example:**

```
RP/0/RP0/CPU0:ios# show tcp dump-file 10_106_0_73.179.34849.cl.1707424077 location 0/RP0/CPU0
Filename: 10_106_0_73.179.34849.cl.1707424077
```

```
=====
Connection state is CLOSED, I/O status: 0, socket status: 103
PCB 0x00007f86bc05e3b8, SO 0x7f86bc05e648, TCPCB 0x7f86bc0c3718, vrfid 0x60000000,
Pak Prio: Medium, TOS: 192, TTL: 1, Hash index: 1593
Local host: 10.106.0.72, Local port: 179 (Local App PID: 11354)
Foreign host: 10.106.0.73, Foreign port: 34849
(Local App PID/instance/SPL_APP_ID: 11354/1/0)
```

```
Current send queue size in bytes: 0 (max 0)
Current receive queue size in bytes: 0 (max 0) mis-ordered: 0 bytes
Current receive queue size in packets: 0 (max 0)
```

Timer	Starts	Wakeups	Next (msec)
Retrans	103448	8	0
SendWnd	0	0	0
TimeWait	1	0	0
AckHold	106815	106545	0
KeepAlive	1	0	0
PmtuAger	0	0	0
GiveUp	0	0	0
Throttle	0	0	0
FirstSyn	0	0	0

```
iss: 161240548 snduna: 163206936 sndnxt: 163206936
sndmax: 163206936 sndwnd: 63104 sndcwnd: 18120
irs: 3691232436 rcvnxt: 3693473072 rcvwnd: 26099 rcvadv: 3693499171
```

The above sample displays only a part of the actual output; the actual output displays more details.

## Convert Binary Files to Readable Format Using TCP Dump File Converter

Perform the following steps to convert the dump packet traces in binary files into PCAP and text formats:

### Procedure

**Step 1** Execute the **tcp dump-file convert all-formats all** command to convert the dump packet traces in binary files into PCAP and text formats.

**Example:**

```
RP/0/RP0/CPU0:ios# tcp dump-file convert all-formats all
ascii file is saved at :
/harddisk:/decoded_dumpfiles/text_tcpdump_peer_all_node0_RP0_CPU0_2024_3_19_10_8_53.462070.txt
pcap file is saved at :
/harddisk:/decoded_dumpfiles/pcap_tcpdump_peer_all_node0_RP0_CPU0_2024_3_19_10_8_40.154838.pcap
[OK]
```

By default, the system stored the converted files in the "decoded\_dumpfiles" folder on the "hard disk".

Using the **location node-id** and **file <file path>** keywords, you can save the converted TCP dump file to your desired location.

For example, **tcp dump-file convert all-formats all location 0/RP0/CPU0 file /harddisk:/demo2**.

```
RP/0/RP0/CPU0:ios# tcp dump-file convert all-formats all location 0/RP0/CPU0 file /harddisk:/demo2
ascii file is saved at : /harddisk:/demo2.txt
pcap file is saved at : /harddisk:/demo2.pcap
[OK]
```

**Step 2** To view the converted text file in the CLI, use the **run cat <text file path>** command.

**Example:**

```
RP/0/RP0/CPU0:ios# run cat
/harddisk:/decoded_dumpfiles/text_tcpdump_peer_all_node0_RP0_CPU0_2024_3_19_10_8_53.462070.txt
Filename: 2024_3_19_10_8_53.462070
```

```
=====
Connection state is CLOSED, I/O status: 0, socket status: 103
PCB 0x0000000000f47a80, SO 0xf476d0, TCPCB 0xf6a370, vrfid 0x60000000,
Pak Prio: Medium, TOS: 192, TTL: 255, Hash index: 563
Local host: 14:11:11::1, Local port: 47743 (Local App PID: 19579)
Foreign host: 14:11:11::2, Foreign port: 179
(Local App PID/instance/SPL_APP_ID: 19579/1/0)

Current send queue size in bytes: 0 (max 0)
Current receive queue size in bytes: 0 (max 0)  mis-ordered: 0 bytes
Current receive queue size in packets: 0 (max 0)
```

Timer	Starts	Wakeup	Next (msec)
Retrans	70	2	0
SendWnd	0	0	0
TimeWait	2	0	0
AckHold	66	61	0
KeepAlive	1	0	0
PmtuAger	0	0	0
GiveUp	0	0	0
Throttle	0	0	0
FirstSyn	1	1	0

```
iss: 3113104891  snduna: 3113106213  sndnxt: 3113106213
sndmax: 3113106213  sndwnd: 31523  sndcwnd: 2832
irs: 4250126727  rcvnxt: 4250128049  rcvwnd: 31448  rcvadv: 4250159497
```

The above sample displays only a part of the actual output; the actual output displays more details.

**Step 3** Copy the converted packet traces from the system to your local computer using the **scp** command and view the converted PCAP file.

