



## Sample End-to-end Configuration

---

This appendix describes an end-to-end provisioning example for a Routed Optical Networking topology.

- [Sample Configuration, on page 1](#)

## Sample Configuration

This section details the step-by-step approach to build a new Routed Optical Networking based, 75 km fiber span to replace an existing legacy span in a two-node DCI topology.

- [Network Sizing Requirements, on page 1](#)
- [Planning and Design Phase, on page 1](#)
- [Implement Phase, on page 2](#)
- [Operate Phase, on page 63](#)
- [Optimization Phase, on page 75](#)

## Network Sizing Requirements

For Cisco Crosswork, see [Plan Your Deployment](#).

For Cisco Optical Network Controller, see [Cisco Optical Network Controller 25.1.x Installation Guide](#).

## Planning and Design Phase

The planning and design phase involves:

### 1. Network Planning and Design

**Inputs needed:** Packet layer traffic demands, optical fiber topology, resiliency criteria, and other network constraints.

- WAE can be used to determine a new network build or augmentations to an existing network.
- After the IP network circuits have been determined, Cisco ONP is used to determine the optical layer feasibility and components that are used to support the network.

**Output for a sample configuration:**

This topology uses two Cisco 8201 routers, two NCS 2006 terminal nodes with NCS1K-MD-64 add/drop multiplexers, and EDFA-35 bi-directional amplifiers. The span length is 75 kms. Longer spans may require additional ILA nodes for amplification.

**2. Automation Software Resource Planning****Server requirements for the Routed Optical Networking software elements**

Determine the servers required for the full solution. See [Network Sizing Requirements, on page 1](#) and [Installation Requirements for Routed Optical Networking Components, on page 2](#).

- a. For a lab or EFT setup, it is recommended to use three servers each with 384 G of RAM, 32 cores, and two TB SSD.
- b. The solution requires the use of VMware ESX 6.7 or higher.

## Installation Requirements for Routed Optical Networking Components

The following list points to the installation requirements for different Routed Optical Networking components.

- [Cisco Optical Network Planner 5.2](#)
- [Cisco WAN Automation Engine 7.6.x](#)
- [Cisco Crosswork Cluster, Crosswork Data Gateway, and Crosswork Applications](#)
- [Cisco Optical Network Controller 3.1](#)
- [Cisco Evolved Programmable Network Manager 7.1.2](#)
- [Cisco Network Services Orchestrator 6.1.9](#)
  - [Cisco NSO Routed Optical Networking Core Function Pack 3.0.0](#)
  - [Cisco NSO Transport-SDN Function Pack Bundle 6.0](#)
  - [Cisco Network Services Orchestrator DLM Service Pack 6.0](#)
- [Cisco Crosswork Hierarchical Controller 8.0](#)
- [Cisco Crosswork Network Controller 6.0](#)

## Implement Phase

The implement phase involves:

**1. Installation of hardware components**

- a. Hardware staging or installation and initial base configuration required for management connectivity.
- b. All onboard software updates must be completed to the required revision.
- c. All associated base wiring must be completed to support the network. This includes connections between the optical elements and connections between routers and optical add/drop end-points to support Routed Optical Networking circuits using ZR/ZR+ optics. See [Deployment topologies](#).
- d. Install Cisco Optical Site Manager to support NCS 1010 nodes. See [Install Cisco Optical Site Manager](#)

## 2. Installation of the Automation Software Components

- a. Complete all server hardware installation and base configuration to support the solution, including VMWare ESX if not already installed.
- b. Install the following software components to support the Routed Optical Networking solution.
  - [Cisco Optical Network Planner 5.2](#) (for optical planning)
  - [Cisco Crosswork Planning 7.1](#) (for IP planning)
  - [Cisco Crosswork Cluster, Crosswork Data Gateway, and Crosswork Applications](#) (for supporting Crosswork Network Controller)
  - [Cisco Optical Network Controller 3.1](#) (for supporting optical network)
  - [Cisco Evolved Programmable Network Manager 7.1.4](#) (for managing the physical router and the optical network nodes)
  - [Cisco Network Services Orchestrator 6.1.9](#) (base installation to support RON FP)
    - [Cisco NSO Routed Optical Networking Core Function Pack 3.0](#) (for RON ML provisioning)
    - [Cisco NSO Transport-SDN Function Pack Bundle 6.0](#) (for Crosswork Network Controller SR and xVPN provisioning)
    - [Cisco Network Services Orchestrator DLM Service Pack 6.0](#) (for device synchronization between Crosswork Network Controller and NSO)
  - [Cisco Crosswork Hierarchical Controller 8.0](#) (for provisioning the Routed Optical Networking ML service using the Crosswork Hierarchical Controller)



---

**Note** This is required only if the Routed Optical Networking ML service is provisioned via the Crosswork Hierarchical Controller GUI.

---

## 3. Onboarding of Devices

- a. Add devices to Cisco Optical Network Controller. See [Onboard Devices to Cisco Optical Network Controller](#).
- b. Add NSO, SR-PCE, and devices to Crosswork Network Controller. See [Add SR-PCE, NSO, and Routers to Crosswork Network Controller, on page 4](#).
- c. Add routers to NSO using the IOS-XR CLI NED. See Step 3 in [Provision ML Service Using NSO Routed Optical Networking CFP , on page 23](#).
- d. Add and configure the following Crosswork Hierarchical Controller adapters. See [Configure Adapters for Crosswork Hierarchical Controller, on page 10](#).



---

**Note** This step is required only if the Routed Optical Networking ML service is provisioned via the Crosswork Hierarchical Controller GUI.

---

- Add and configure the Crosswork Network Controller adapter.
- Create or import sites in Crosswork Hierarchical Controller. See the sections, "Add Sites" and "Export and Import Sites" in the [Cisco Crosswork Hierarchical Controller Administration Guide 8.0](#).
- Add and configure the IOS-XR adapter. Create router devices in Crosswork Hierarchical Controller using the IOS-XR adapter type. After the routers are created, add the Crosswork Network Controller adapter to the router device.
- Add and configure the Cisco Optical Network Controller adapter.

#### 4. Provisioning of Services

- Ensure all device interconnections are complete.
- To provision the Routed Optical Networking ML service, use either one of the procedures:
  - Using the NSO GUI:**
    - Utilize the Routed Optical Networking FP ML services to provision and end-to-end service. See [Provision ML Service Using NSO Routed Optical Networking CFP](#), on page 23.
    - Verify that the end-to-end service has been deployed by checking the NSO service deployment status using the check-sync status.
    - Verify the router optics controller state using the CLI or in EPNM. See [Troubleshoot Provisioning Issues](#).
  - Using the Crosswork Hierarchical Controller GUI:**
    - Utilize the Crosswork Hierarchical Controller GUI to provision and end-to-end Routed Optical Networking ML service. See [Provision Routed Optical Networking ML Service Using Crosswork Hierarchical Controller](#), on page 37.
    - Verify the router optics controller state using the Link Assurance tool in Crosswork Hierarchical Controller. See Step 4 in [Provision Routed Optical Networking ML Service Using Crosswork Hierarchical Controller](#), on page 37.

## Add SR-PCE, NSO, and Routers to Crosswork Network Controller

Perform these steps to add SR-PCE providers, NSO providers, and routers to Crosswork Network Controller.



**Note** When you add or import devices, or create providers, you need to specify the credential profile.

- [Log in](#) to the Crosswork user interface.
- To create a credential profile, choose **Device Management > Credential Profiles** from the main menu. See [Manage Credential Profiles](#).
  - For the NSO credential profile, the connectivity type must be set to NETCONF and HTTPS. Optionally, HTTP can also be defined if HTTPS is not used in NSO.



Edit Profile nso ×

Profile Name \* nso

Add Credential Protocols

Connectivity Type	User Name *	Password *	Confirm Password *	
NETCONF	nso	*****	*****	
HTTPS	nso	*****	*****	

[+ Add Another](#)

Save

Cancel

521905

- b. The SR-PCE credential profile requires HTTP credentials to communicate with the SR-PCE Northbound API.

Edit Profile SR-PCE ×

Profile Name \* SR-PCE

Add Credential Protocols

Connectivity Type	User Name *	Password *	Confirm Password *	
HTTP	admin	*****	*****	

[+ Add Another](#)

Save

Cancel

521906

- c. The router credential profile requires at a minimum, the SNMPv2 or SNMPv3 and SSH connectivity types. NETCONF is optional. GNMi is used when utilizing GNMi to configure streaming telemetry sensors on the node.

Edit Profile routers

Profile Name \*

routers

Add Credential Protocols

Connectivity Type	Read Community *	Write Community	
SNMPv2	*****	*****	

Connectivity Type	User Name *	Password *	Confirm Password *
SSH	admin	*****	*****
Enable Password			

Connectivity Type	User Name *	Password *	Confirm Password *
NETCONF	admin	*****	*****

Connectivity Type	User Name *	Password *	Confirm Password *
GNMI	admin	*****	*****

+ Add Another

Save

Cancel

521907

3. Add the providers. See [About Adding Providers](#).

- To add the SR-PCE or NSO provider, choose **Administration > Manage Provider Access** from the main menu. See [Manage Providers](#).
- Add the NSO provider. See [Add Cisco NSO Providers](#).

Select the credential profile created for NSO. Select the family as NSO. The Device Key may be set to either the HOST\_NAME or INVENTORY\_ID depending on the specific deployment.

The following image demonstrates the connectivity to NSO's RESTCONF API over SSL using port 8888 and NETCONF using the default port of 2022. Since the Routed Optical Networking NSO CFP utilizes the XR CLI NED, the Cisco-IOS-XR model is not applicable and may be set to any version.

Edit Provider

Provider Name \*

nso-58

Credential Profile \*

nso

Family \*

NSO

Device Key \*

HOST\_NAME

Connection Type(s)

Protocol *	IP Address / Subnet Mask *	Port *	Timeout
HTTPS	172.29.11.58 / 25	8888	60
NETCONF	172.29.11.58 / 25	2022	60

+ Add Another

Provider Properties

Property Key	Property Value
forward	true

+ Add Another

Model Prefix Info

Model *	Version *
Cisco-IOS-XR	7.3.1

Save

Cancel

- c. Add the SR-PCE provider. See [Add Cisco SR-PCE Providers](#).

Select the credential profile created for SR-PCE. Select the family type as SR\_PCE. The connectivity type for SR-PCE must be the HTTP. In the following image, the default API port of 8080 is specified. When the Property Key, "auto-onboard" is set to a Property value, "off", Crosswork Network Controller does not automatically add nodes that are discovered via the SR-PCE IGP topology to the device inventory. Devices must be added through the Crosswork Network Controller UI or inventory API.

Edit Provider

Provider Name \*

sr-pce-test

Credential Profile \*

SR-PCE

Family \*

SR\_PCE

Connection Type(s)

Protocol *	IP Address / Subnet Mask *	Port *	Timeout
HTTP	172.29.11.54 / 25	8080	60

+ Add Another

Provider Properties

Property Key ?	Property Value ?
auto-onboard	off

+ Add Another

Save

Cancel

521909

4. Validate communications with one or more providers. Check on the provider's reachability using the steps in [Get Provider Details](#).
5. Onboard devices. See [Add Devices Through the UI](#).
  - a. The Administration State, Reachability Check, and Credential Profile are mandatory elements. The Host Name must be used if the NSO provider device key is set to the Host Name value. If the NSO provider device key is set to Inventory ID that field must be populated. The Software Type, Software Version, UUID, Serial Number, MAC address, and Product Type are filled by device discovery. Optionally, tags can be applied to the device. The GNMI encoding type can be set to JSON or PROTO.

Add New Device

General

Administration State\*
UP
Reachability Check\*
ENABLE
Credential Profile\*
routers
Host Name
ron-8201-1
Inventory ID
Software Type
Software Version

UUID
Serial Number
Mac Address
Capability\*
YANG\_MDT, SNMP, GNMI
Tags
Product Type
Syslog Format

Connectivity Details

Protocol *	IP Address / Subnet Mask *	Port *	Timeout	Encoding Type	
SSH	172.29.11.20 / 25	22	60		
SNMP	172.29.11.20 / 25	161	60		
GNMI	172.29.11.20 / 25	57333	60	PROTO	
NETCONF	172.29.11.20 / 25	830	60		

+ Add Another

Routing Info

Save
Cancel

521910

Optionally, location information can be entered. Latitude and Longitude information place the node at a specific location on a geographic map.

Add the previously configured NSO provider as a provider for the device.

Add New Device ×

SNMP	172.29.11.20	/ 25	161	60		
GNMI	172.29.11.20	/ 25	57333	60	PROTO	
NETCONF	172.29.11.20	/ 25	830	60		

[+ Add Another](#)

> Routing Info

> Streaming Telemetry config

✓ Location

Building

Street

City

State

Country

Region

Zip

Latitude

Longitude

Altitude

✓ Providers and Access

Provider Family	Provider Name	Credential	Device Key
NSO	nso-58	nso	ron-8201-1

[+ Add Another](#)


[Save](#) [Cancel](#)

521911

- b. Attach the devices to an active Cisco Crosswork Data Gateway pool to manage them (device discovery).

Review the Data Gateways pane (see [Overview of Cisco Crosswork Data Gateway](#)). The operational state of the Cisco Crosswork Data Gateway pool to which you want to attach devices must be **Up**.

Follow the steps in [Attach Devices to Cisco Crosswork Data Gateway](#).



521912

## Configure Adapters for Crosswork Hierarchical Controller

### Prerequisite

When you work with Crosswork Hierarchical Controller adapters you are required to use credentials. These credentials are used for authentication when a device is assigned to an adapter. The same credentials may be shared by multiple adapters. The credentials are added under the **Services > Device Manager > Credentials**

tab in the Crosswork Hierarchical Controller GUI. The adapters needed for the Routed Optical Networking solution are:

**Table 1: Routed Optical Networking Adapters**

Adapter	Credential Type
Crosswork Network Controller	HTTP (username/password)
Cisco Optical Network Controller	HTTP (username/password)



**Note** If Cisco Optical Network Controller and Crosswork Network Controller are on the same Crosswork cluster, they can use the same credential profile.

To add the adapters, perform the following steps:

1. In the applications bar in Crosswork Hierarchical Controller, select **Services > Device Manager > Adapters**.
2. Click **Add new adapter**.
3. Enter the adapter details:
  - **Adapter Type:** Select an adapter type from the list of available adapter types currently installed in Crosswork Hierarchical Controller.
  - **Adapter Name:** Unique user defined name of this adapter type instance (there can be several instances of the same adapter type).
4. To configure the adapter, select the adapter in the Adapters pane. Configure the parameters as displayed in the following images.
  - **Crosswork Network Controller Adapter:**



**Note** API version for Crosswork Network Controller must be V2.

**Figure 1: Crosswork Network Controller Adapter Configuration - General Tab**

The screenshot displays the 'General' tab of the Crosswork Network Controller Adapter Configuration. The 'Enabled' checkbox is checked, and the 'Logging Level' is set to 'Info'. The 'Full Data Fetch Interval [sec]' is 240, and the 'Max run time for a single discovery cycle [sec]' is 600. The 'Enable provisioning support' checkbox is checked. The 'Should the DM reports be only for IGP discovered devices?' checkbox is also checked. The 'SERVER CONFIGURATION' section shows the 'Host' as 172.29.11.75, 'Port' as 30603, 'Timeout [sec]' as 30, 'Api\_version' as V2, and 'Credentials' as cnc-6-75.



**Note** The Full Data Fetch Interval must be set to 300s or higher in a production network.

The following parameters must be configured for Crosswork Network Controller notifications and collection.

**Figure 2: Crosswork Network Controller Notifications**

NOTIFICATIONS CONFIGURATION

☒ Enabled

Congestion control period [sec]: 25

How long to wait after a notification for more notifications, before triggering discovery

☒ Log\_notifications

Maximum notification flood time [sec]: 30

Maximum time between the first notification and triggering discovery. This limits "Maximum notification flood time"

Log\_level: INFO

☐ Vpn\_service

**Figure 3: Crosswork Network Controller Collection and Provisioning**

COLLECTION PARAMETERS

☒ Enable Inventory and Topology Collection

IGP domain Name: cnc-default-domain

only alphanumeric, dash, and underscore characters allowed

☒ Enable L2 IGP IS-IS Collection

IGP IS-IS Priority: 1

☒ Enable Rsvp-Te Collection

☐ Enable L3VPN Collection

Requires topology to be enabled

☒ Enable L1 IGP IS-IS Collection

☒ Enable Sr-Policy Collection

☐ Enable L2VPN Collection (multipoint and elines)

Requires topology to be enabled

PROVISIONING PARAMETERS

IP-Link create timeout: 300

Cnc\_mso\_conn\_red: CLI\_NED

HYPERLINKER RULES CONFIGURATION

☒ Enabled

HyperLinker Rules Interval Checking [sec]: 120

## • Cisco Optical Network Controller Adapter

**Figure 4: Cisco Optical Network Controller Adapter - General Tab**

The Polling cycle must be set to 300s or higher in a production network. Polling retrieves TAPI SIPs, topology, and connectivity services.

The URL in the following figure is for the Cisco Optical Network Controller 3.1.



The screenshot shows the 'General' configuration tab for the Cisco Optical Network Controller Adapter. The 'Enabled' checkbox is checked, and the 'Logging Level' is set to 'Info'. Under 'ADAPTER PROPERTIES', 'Polling Cycle [sec]' is 240, 'Provisioning' is checked, 'Connection Timeout [sec]' is 600, and 'Minimal interval time between data updates [sec]' is 0. 'Pull every X seconds' is 3, and 'Interval time between provisioning retries [sec]' is 60. 'Save persistor request to disk?' is unchecked. Under 'CONNECTION PROPERTIES', the 'Host' is 'https://172.29.11.81:8443/onc-nbi-service/' and 'Credentials' is 'onc31'. Under 'FILE-BRINGERS CONFIGURATION', 'Enabled' is unchecked. Under 'NOTIFICATIONS CONFIGURATION', 'Enabled' is checked, and 'URL Sub-part' is 'CONC\_NETCONF'. Under 'STATS COLLECTION CONFIGURATION', 'Enabled' is checked, and 'Stats Interval Polling [sec]' is 600. Under 'HYPERLINKER RULES CONFIGURATION', 'Enabled' is checked, and 'HyperLinker Rules Interval Checking [sec]' is 600.

The optical nodes are discovered automatically from Cisco Optical Network Controller. Nodes must be assigned a site for it to be displayed in the Explorer UI.

**Figure 5: Cisco Optical Network Controller Adapter - Devices Tab**

The screenshot shows the 'Adapters' tab in the Device Manager. The 'Adapters' list on the left includes 'cisco-xr', 'onc30', 'onc-76', 'onc-poc30-1', and 'svo'. The 'Devices' tab is selected, showing a table of discovered devices.

Name	Status	Status Changes (Last 24 hr)	Site	Adapter(s)
5 ITEMS				
ron-ols-5-roadm	✓ OK	0	Monterey	onc-76
ron-ols-4-roadm	✓ OK	0	San Luis Obispo	onc-76
ron-ols-2-roadm	✓ OK	0	Las Vegas	onc-76
ron-ols-1-roadm	✓ OK	0	Los Angeles	onc-76
ron-ols-3	✓ OK	0	Barstow	onc-76

### • NSO Adapter In Hierarchical Controller

In Hierarchical Controller 11.0 there is an embedded NSO installed when Hierarchical Controller 11.0 is installed. The NSO adapter can use the internal NSO or point to an external NSO instance. Provisioning using the NSO adapter requires adding the NSO adapter to the devices you want to provision.

Use the NSO adapter when you use the [Automation starter solution](#).



#### Note

- If using the internal NSO, the Routed Optical Networking 4.0 Core Function Pack must be installed on the NSO instance.
- If using the internal NSO, devices must be added to that NSO, adding them to Hierarchical Controller does not automatically onboard them into the internal NSO.

Figure 6: NSO Adapter - General Tab

The screenshot shows the 'device-manager-srv' interface with the 'Adapters' tab selected. On the left, a list of adapters includes 'cnc', 'cdg', 'cisco-xr', 'onc', 'onc-50', and 'nso'. The 'nso' adapter is selected. The main panel shows the 'General' tab for the 'nso' adapter. It includes a 'Logging Level' dropdown set to 'Debug', a 'Use internal nso' checkbox which is checked, and a 'SERVER CONFIGURATION' section with fields for 'Host', 'Port', 'Timeout (sec)', and 'Credentials' (set to 'nso'). There is also a 'PROVISIONING PARAMETERS' section with an 'IP-Link create timeout' field set to '600'.

Start configuration with NSO and XR adapters.

The screenshot shows the 'cloud-ncs540-1' configuration window with the 'Adapters' tab selected. It displays two adapters: 'cisco-xr' and 'nso'. The 'cisco-xr' adapter has fields for 'Host' (172.29.11.120), 'Port' (22), 'Authentication' (cisco-xr), and a checked 'Enabled' checkbox. The 'nso' adapter is under 'DEVICE CONFIGURATION'. Both adapters have a red 'Unassign device from this adapter' button. At the bottom, there is a '+ Assign device to a new adapter' button, a 'Delete device' button, and 'Cancel' and 'Save' buttons.

## Configure SSO in Crosswork Hierarchical Controller

This section describes how to configure SSO in Crosswork Hierarchical Controller with Crosswork Network Controller as Identity Provider. You can use the same SSO configuration to set up SSO for Cisco Optical Network Controller Release 25.1.2.

### 1. Configure Crosswork Hierarchical Controller

a. Click **Settings > Security > SAML Configuration**

Enter the necessary information:

- **Login URL:** `https://<CNC_IP>:<port>/crosswork/sso/idp/profile/SAML2/Redirect/SSO`
- **Entity ID:** `https://<CNC_IP>/idp`
- **Certificate:** Copy from Crosswork Network Controller metadata from `https://<CNC_IP>:<port>/crosswork/sso/idp/metadata`
- Use **Groups Attribute Name** `authenticationMethod`

**Figure 7: Crosswork Hierarchical Controller Provider Configuration Sample**

**SAML SSO**

Enabled ☒

Login URL

Entity ID

Base URL  
 Use Current


Signing Certificate

Groups Attribute Name

Reload Save


b. Click **Settings > Security > Permission Mapping**

Figure 8: Crosswork Hierarchical Controller Permission Mapping Sample



- c. Add a **Match** condition for **SAML Group** of **QueryDatabaseAuthenticationHandler** with a permission of `permission/admin`

Figure 9: Crosswork Hierarchical Controller Permission Mapping Sample



2. Copy Crosswork Hierarchical Controller SAML metadata to a file, metadata is located at `https://<HCO_IP>:<port>/sso/metadata`. The following is a sample.

```
<EntityDescriptor entityID="https://172.29.11.83:8443"
xmlns="urn:oasis:names:tc:SAML:2.0:metadata"
xmlns:assertion="urn:oasis:names:tc:SAML:2.0:assertion"
xmlns:ds="http://www.w3.org/2000/09/xmldsig#">
  <SPSSODescriptor AuthnRequestsSigned="false" WantAssertionsSigned="false"
protocolSupportEnumeration="urn:oasis:names:tc:SAML:2.0:protocol">
    <NameIDFormat>urn:oasis:names:tc:SAML:1.1:nameid-format:emailAddress</NameIDFormat>

    <SingleLogoutService Binding="urn:oasis:names:tc:SAML:2.0:bindings:HTTP-Redirect"
Location="https://172.29.11.83:8443/sso/logout">
</SingleLogoutService>
    <AssertionConsumerService index="0"
```

```


Binding="urn:oasis:names:tc:SAML:2.0:bindings:HTTP-POST"
Location="https://172.29.11.83:8443/sso/acs">
  </AssertionConsumerService>
</SPSSODescriptor>
</EntityDescriptor>

```

### 3. Configure Crosswork Network Controller

- a. Login to Crosswork Network Controller, click **Administration > AAA > SSO**


**Figure 10: Crosswork Network Controller AAA**



- b. Click +

- Add a name
- Add a unique evaluation order number
- Upload HCO's Metadata file in XML format

**Figure 11: Crosswork Network Controller Add new Service Provider**



- c. Click **Save**

**Figure 12: Crosswork Network Controller AAA**

Identity Provider ?

Entity ID \*

+ ✎ 🗑

☐ Service Name

Evaluation Order

**Service Provider**


Name \*

Evaluation Order \*

Metadata  [Browse](#)

[Add](#) [Cancel](#)

#### 4. Login to

**Figure 13: Crosswork Network Controller AAA**

### Troubleshooting Cisco Crosswork Hierarchical Controller SSO

- Use the **sedo logs security audit** in the Crosswork Hierarchical Controller to get the logs.
- Ensure time is synchronised between Cisco Crosswork Hierarchical Controller and Cisco Crosswork Network Controller
- If there is an error related to `QueryDatabaseAuthenticationHandler` add the SAML group mapping in Crosswork Hierarchical Controller configuration, map to group Admin


## Examples of Cross Launch

SSO is supported across Hierarchical Controller 8.0, Crosswork Network Controller 6.0, and Cisco Optical Network Controller/Cisco Optical Site Manager.

- Cross Launch from IGP Link SRC/DST Router in Hierarchical Controller to Crosswork Network Controller


1. Click on **Links > IGP**
2. Hover over either Source Device or Destination Device, click the ellipsis and click **IGP device at Crosswork Network Controller**

**Figure 14: Network Inventory**



This operation launches the router traffic engineering information in Crosswork Network Controller.

**Figure 15: Traffic Engineering**



- Hierarchical Controller SR Policy to Crosswork Network Controller

1. Click on **Connections > SR Policy**
2. Hover over policy and click on ellipses to open cross launch.

Figure 16: Network Inventory

Network Inventory

Filter inventory by: Regions/Sites/Devices

Devices Sites Links Connections Services Cards Ports Transceivers Power Supplies Fans Shelves

NMC OCH ETHERNET SR POLICY MC


Apply Inventory Filter On Connections Export Table

Name	Source Device	Destination Device	Operation State	Protection	IGP Hops Count	Tags	Color	Preference
100.0.0.20 to 100.0.0.3, color 1000	ron-ncs57b1-1	ron-8201-32FH-3	UP	SINGLE...	3		1000	200
100.0.0.50 to 100.0.0.52, color 101			UP	SINGLE...	3		101	100
100.0.0.50 to 100.0.0.52, color 1000			UP	SINGLE...	3		1000	200
100.0.0.50 to 100.0.0.52, color 705			UP	SINGLE...	3		705	200
100.0.0.50 to 100.0.0.52, color 103			UP	SINGLE...	3		103	200
100.0.0.50 to 100.0.0.27, color 705			UP	SINGLE...	3		705	200
100.0.0.52, color 10000			UP	SINGLE...	3		10000	200
100.0.0.50 to 100.0.0.52, color 102			UP	SINGLE...	3		102	100
100.0.1.1 to 100.0.1.3, color 9010			UP	SINGLE...	1		9010	100
100.0.1.1 to 100.0.0.27, color 9009			UP	SINGLE...	3		9009	100
100.0.0.52 to 100.0.1.3, color 1000			UP	SINGLE...	3		1000	100
100.0.0.52 to 100.0.0.27, color 5227			UP	SINGLE...	3		5227	100
100.0.0.52 to 100.0.0.50, color 4000	ron-ncs540-1	cloud-ncs540-1	UP	SINGLE...	3		4000	200

More Information:  
[SR Policy at CNC](#)

This operation launches detailed policy information in Crosswork Network Controller.


Figure 17: Traffic Engineering



- Hierarchical Controller Optical Node to Cisco Optical Site Manager
  1. Click on **Devices** > **ONS**
  2. Hover over a device, click ellipsis and click Optical Node at COSM.




Figure 18: Network Inventory



- Hierarchical Controller Optical Port to Cisco Optical Site Manager

1. Click on **Ports > OTS**
2. Hover over a port, click ellipsis and click Optical Port at COSM.


Figure 19: Network Inventory




- Hierarchical Controller Link Assurance Node to Cisco Optical Site Manager or SVO

1. Click **Link Assurance > Inspect links**
2. Hover over a node, click ellipsis and click Optical Node at COSM.

Figure 20: Link Assurance




This operation launches the node functional view in Cisco Optical Site Manager (for NCS 1000 series devices) or SVO (for NCS 2000 series devices).



- Hierarchical Controller Link Assurance Port to Cisco Optical Site Manager

1. Click **Link Assurance > Inspect links**
2. Hover over a port, click ellipsis and click Optical Port at COSM.


Figure 21: Link Assurance




## Provision ML Service Using NSO Routed Optical Networking CFP

Perform the following steps to provision the Routed Optical Networking ML service using the NSO Web UI.


1. To add a new device, perform these steps:
  - a. In the Device manager, click the + to add a new device. Specify a name for the new device. Click **Confirm**.




- b. After creating the new device, click the device name to fill required and optional parameters. In this screen, the required parameters are the authgroup and IP address of the device.




- c. Scroll down in the device configuration screen. Click the “device-type” to bring up the device type selection screen. The device-type that is supported in the Routed Optical Networking ML FP is IOS-XR CLI NED.



- d. Click the blue NETCONF text to select the proper NED. The Routed Optical Networking ML FP requires the use of the **cisco-iosxr-nc-7.3** NED.




- e. Click the Commit manager to view the NSO CLI configuration being applied. Click **Commit** to save the device configuration to NSO.





**Note** Next we add the multilayer end-to-end service to configure and provision both the optical line system and routers. We recommend you to click **check-sync** in the Device manager to ensure that the device configuration is properly in sync with NSO before provisioning. If the device is out of sync, initial provisioning fails.



2. To create Routed Optical Networking ML service, perform these steps:
  - a. In the Service manager, select the Routed Optical Networking ML service point from the drop-down list. When we create the new Routed Optical Networking ML service, the required components are the service name, mode of the service (transponder or muxponder), and the bandwidth. The bandwidth corresponds to the line rate of the ZR/ZR+ optics. Click **Confirm**.

## Create service

name

mode

bandwidth

- b. In the Configuration editor, click the newly created service name for editing the additional parameters that are required for the service. In this example, we set the circuit-id name in the global parameters. The frequency is set by the optical controller based on the specified optical add/drop port. The dac-rate



is set to the default value.

The screenshot shows the Cisco Configuration Editor interface for a circuit named 'poc\_circuit\_195200'. The configuration is as follows:

Field	Value
name	poc_circuit_195200
circuit-id	This is a demo circuit
dac-rate	
mode*	transponder
grid-type	(100mhz-grid)
clear-rollback	
bandwidth*	400
frequency	
end-point	This list is empty
ols-domain	Expanded
service-state	(UNLOCKED)
custom-template	This list is empty

The bottom navigation bar includes: C\* Control manager, E Configuration editor (active), A Alarm manager, B Dashboard, D Device manager, and S Service manager.



#### Note

- User configuration global options are frequency and dac-rate
- Dac-rate controls the TX shaping parameters: 1x1.25 = enabled, 1x1 = disabled. Leaving it blank uses system default of enabled, and can be used in most circumstances
- Modulation of 16 QAM is available for 2x100G muxponder mode.

- c. After the ols-domain is added, you must add end-points to the circuit. Two end-points are always required. The end-points are the routers with ZR/ZR+ optics.

Configuration editor

See "poc\_circuit\_195200" in Service manager

name: poc\_circuit\_195200

circuit-id: This is a demo circuit

dac-rate:

mode\*: transponder

grid-type: (100mhz-grid)

clear-rollback:

bandwidth\*: 400

frequency:

end-point: This list is empty. Add list item +

ols-domain/

service-state: (UNLOCKED)

custom-template: This list is empty. Add list item +

Navigation: C\* Control manager, E Configuration editor, A Alarm manager, B Dashboard, D Device manager, S Service manager

521927

- d. Add the end-point-device to the service. Click **Confirm**.

Configuration editor

See "poc\_circuit\_195200" in Service manager

name: poc\_circuit\_195200

circuit-id: This is a demo circuit

dac-rate:

mode\*: transponder

grid-type: (100mhz-grid)

clear-rollback:

bandwidth\*: 400

frequency:

end-point: Add list item +

ols-domain/

service-state: (UNLOCKED)

custom-template: This list is empty. Add list item +

Add new list item


end-point-device: ron-poc-8201-1

cancel confirm

Navigation: C\* Control manager, E Configuration editor, A Alarm manager, B Dashboard, D Device manager, S Service manager

521928


After the end-point is created, click the end-point to edit the end-point parameters. The line-port is a required parameter and refers to the optics port on the router. In this example, this is the same as the line-port specified in the inter-layer-link service for the end-point router.




The screenshot shows a modal dialog titled "Add new list item". Inside the dialog, there is a text input field with the value "end-point-device". Below this is a dropdown menu showing "ron-poc-8201-2". At the bottom of the dialog are two buttons: "cancel" and "confirm".

The transmit-power is an optional parameter for end-to-end provisioning. If it is omitted the optical controller (Cisco Optical Network Controller) will provide the transmit power. Transmit power sets the transmit power, the value is in 100\*value in 0.1dBm increments. For example, -100 is -10dBm. If no value is specified the default of -10dBm is used for QDD-400G-ZR-S or QDD-400G-ZRP-S, or 0dBm for DP04QSDD-HE0 (Bright ZR+). The transceiver-capability field specifies the optic type and is only required if no packet layer configuration is being performed. In this example, you are performing packet layer provisioning so specifying the transceiver capability is not required.

Add the line-port of 0/0/0/20 to the Routed Optical Networking ML service.



- e. Click end-point to go back to the top-level endpoint configuration, click **terminal-device-packet** to configure Ethernet/IP parameters



#### Note


- Ethernet/IP configuration is optional.
- Bundle configuration adds an interface to an existing bundle or creates a new bundle and adds the newly created IP interface to it.

Interface configuration is used for configuring IP address parameters on newly created Ethernet interfaces.


In this example we add a new Bundle and assign an IP address to the Bundle.

- f. Click the plus sign next to bundle to add a bundle, in this case with an identifier of 500. This creates a bundle interface Bundle-Ether 500 on the endpoint router


The interface index for a bundle use case is always 0. In case of a non-bundle configuration in muxponder mode, the index can be 0–3 representing the number of interfaces created as part of the muxponder configuration.



- g. Click the bundle number and *ip-address* to configure an IP address on the bundle.



- h. Return to the top-level endpoint configuration, select the index 0 previously created and click **membership** to add the interface to the bundle



Configuration editor  
NSO VERSION: 5.7.6.2

/cisco-ron-cfp:ron/ron-ml{poc\_8201\_1\_to\_poc\_8201\_2\_20}/end-point{ron-poc-8201-1}/terminal-device-packet/interface{0}/membership/

See 'poc\_8201\_1\_to\_poc\_8201\_2\_20' in Service manager

bundle-id\*

500


mode

active

**Note**

- Bundle-id selects the previously created bundle.
- Mode sets the bundle LAG signaling mode. Active=LACP, passive=LACP listener only, on=No active signaling, inherit=Inherit signaling from Bundle interface configuration. Default is active.

- Return to the top level of the service configuration and similarly configure the second endpoint.



Configuration editor  
NSO VERSION: 5.7.6.2

/cisco-ron-cfp:ron/ron-ml{poc\_8201\_1\_to\_poc\_8201\_2\_20}/

See 'poc\_8201\_1\_to\_poc\_8201\_2\_20' in Service manager

name: poc\_8201\_1\_to\_poc\_8201\_2\_20

circuit-id: poc\_circuit

dac-rate:

mode\*: transponder

grid-type: (100mhz-grid)

clear-rollback:

bandwidth\*: 400

frequency: 1952000

end-point

☐ end-point-device

☒ ron-poc-8201-1

☒ ron-poc-8201-2

ols-domain/

srlg/

- Click **SRLG** to perform SRLG configuration

**Note**

- Configuration options are to specify a preconfigured group, a list of numeric SRLG values, or a list of SRLG names associated with preconfigured name:value pairs.
- Each type can be populated in the same configuration.
- In this example we specify a list of explicit numeric values. An index is used along with the numeric value.

3. In the Commit manager, click the config tab. The NSO CLI configuration for the end-to-end service is displayed. If the ols-domain component is not specified in the global configuration, no optical line system provisioning is performed, only router provisioning. You can preview and then commit the configuration.

521934

#### 4. Verify status in NSO UI.

You can verify the status by inspecting the plan associated with the service. You can find the plan under the main ron-ml configuration which you can access by clicking the top portion of the service configuration. An example is highlighted in the following image.

The screenshot shows the NSO Configuration editor interface. The breadcrumb path is `/cisco-ron-cfp/ron/ml(poc_8201_1_to_poc_8201_2_20)/`. A link says "See 'poc\_8201\_1\_to\_poc\_8201\_2\_20' in Service manager". The configuration is organized into a grid of fields:

<b>name</b> poc_8201_1_to_poc_8201_2_20	<b>bandwidth*</b> 400	<b>frequency</b> 1952000
<b>plan-location</b> /cisco-ron-cfp/ron/cisco-ron-cfp:ron-ml-plan[cisco-ron-cfp:name='poc_8201_1_to_poc_8201_2_20']	<b>circuit-id</b> poc_circuit	<b>dac-rate</b> 
<b>mode*</b> transponder	<b>grid-type</b> (100mhz-grid)	<b>clear-rollback</b> 

##### a. Inspect the plan by clicking on the newly created service

The screenshot shows the NSO Configuration editor interface for the plan configuration. The breadcrumb path is `/cisco-ron-cfp/ron/ml-plan(poc_8201_1_to_poc_8201_2_20)/plan/`. The configuration is organized into a grid of fields:

<b>name</b> 682b3df2_30b2_4af2_9438_6dfb7738d0ef 6e2b4907_b08b_4338_8304_a4f2903b3311 f7a00076_d3db_4bd9_9d94_673d4cc462cb poc_8201_1_to_poc_8201_2_20
--

If all steps are green and complete, the service has been properly deployed to the network



##### b. Inspect router configuration.

The **show configuration commit changes last 1** command shows the CLI config applied to the device during the NSO provisioning.

The **show optics controller 0/0/0/20** command verifies the operational status.



```

RP/0/RP0/CPU0:ron-poc-8201-1#show configuration commit changes last 1
Mon Oct 17 09:51:11.625 PDT
Building configuration...
!! IOS XR Configuration 7.7.1
srfg
 interface Bundle-Ether500
  10 value 1000
  20 value 2000
  !
!
 interface Bundle-Ether500
  ipv4 address 102.20.20.20 255.255.255.254
  !
!
 controller Optics0/0/0/20
  description poc_circuit
  transmit-power -100
  fec OFEC
  dwdm-carrier 100MHz-grid frequency 1952000
  DAC-Rate 1x1.25
  !
 interface FourHundredGigE0/0/0/20
  bundle id 500 mode active
  !
End

```

```

RP/0/RP0/CPU0:ron-poc-8201-1#show controllers optics 0/0/0/20
Mon Oct 17 09:57:25.475 PDT

Controller State: Up

Transport Admin State: In Service

Laser State: On

LED State: Green

FEC State: FEC ENABLED

Optics Status

  Optics Type: QSFPDD 400G ZRP
  DWDM carrier Info: C BAND, MSA ITU Channel=19, Frequency=195.20THz,
  Wavelength=1535.822nm

Alarm Status:
-----
Detected Alarms: None

```


## Provision Routed Optical Networking ML Service Using Crosswork Hierarchical Controller

1. If you are performing both router and optical line system provisioning, you must create NMC Cross Links between router optics port and optical line system add/drop port.


Crosswork Hierarchical Controller 8.0 in Routed Optical Networking 3.0 also supports “router only” provisioning which provisions optical parameters on router optics port and IP layer parameters but does not provision OLS.

- a. Select **Link Manager** application.

**Figure 22: Crosswork Hierarchical Controller**




You get the following initial view that shows the list of Cross Links.




- b. Click **Add Cross Link**.


**Figure 23:**




- c. Select the NMC cross link type. Cross Link Manager supports ETH and NMC cross links.




- d. The Link Manager application allows you to select either router DCO port or optical add/drop first. In the following image we filter the ports by the router device that we use for our NMC cross link.




- e. The following image shows the filtered list. Our router, ron-poc-8201-1 has a single ZR+ optics port, select the port and click OK




- f. Like in the previous step, select the second port which is the optical add/drop port. Filter by device as *ron-poc-ols-1* and the Name as *194.000* to filter to the add/drop port



- g. Select the two ports (Ethernet and OCH) in your NMC Cross Link. Click **Add Cross Link**.  
(Optional) Add a description



- h. Click the added cross link to see its attributes.




The screenshot shows the 'Link Manager' application with the 'Cross Links' tab selected. A table lists a single cross-link item. Below the table, there are tabs for 'Summary', 'Evidence', and 'History'. The 'Summary' tab is active, displaying details about the link, including device names, time added, and method.

Link Name	Description	Type	Created By	Device A / Port A	Device B / Port B	Status	Method
ron-poc-ols-1/1/CHAN 46 (192.725) / Optics0/0/0/10	Bright ZR+ poc-82... Frequency: 192.725	NMC	Manual	ron-poc-ols-1-roadm / ron-poc-ols-1/1/CHAN 46 (192.725)	ron-poc-8201-1 / Optics0/0/0/10	Unknown	N/A

Summary		Evidence	History
LINK NAME	ron-poc-ols-1/1/CHAN 46 (192.725) / Optics0/0/0/10	DEVICE A / PORT A ron-poc-ols-1-roadm/ron-poc-ols-1/1/CHAN 46 (192.725)	DEVICE B / PORT B ron-poc-8201-1/Optics0/0/0/10
TIME ADDED	2024-03-27 03:15:26 EDT	SOURCE Manual	STATUS Unknown
METHOD	N/A	LAST CHANGE N/A	DESCRIPTION Bright ZR+ poc-8201-1 to ron-poc-ols-1 Frequency: 192.725

- i. View the added crosslink in the explorer app by clicking on the link.



- j. Similar to the previous steps, create the second NMC cross link.

Link Manager

Cross Links

+ Add Cross Link

Validate All Manual

Link Name	Description	Type	Provider	Device A / Port A	Device B / Port B	Status	Method	Last Change
2 OUT OF 21 ITEMS MATCHING FILTERS								
Manual Cross Link ron-poc-8201-1 Optics0/0/...	ron-poc-8201-1...	NMC	Manual	ron-poc-8201-1 / Optics0/0/0/22	ron-poc-ols-1-roadm / 1/CHAN 29 (194.000)	Unknown	N/A	2023-04-24 10:23:34 EDT
Manual Cross Link ron-poc-57b1-1 Optics0/0/...	NCS-57B1 0/0/0/...	NMC	Manual	ron-poc-57b1-1 / Optics0/0/0/24	ron-poc-ols-2-roadm / 1/CHAN 29 (194.000)	Unknown	N/A	2023-04-24 10:29:55 EDT

Summary

Evidence


History

LINK NAME	DEVICE A / PORT A	DEVICE B / PORT B
Manual Cross Link ron-poc-57b1-1 Optics0/0/0/24 to ron-poc-ols-2-roadm 1/CHAN 29 (194.000)	ron-poc-57b1-1/Optics0/0/0/24	ron-poc-ols-2-roadm/1/CHAN 29 (194.000)

TIME ADDED	SOURCE	STATUS
N/A	Manual	Unknown

METHOD	LAST CHANGE	DESCRIPTION
N/A	N/A	NCS-57B1 0/0/0/24 to NCS 2000 MD-64 channel 29

- k. View the end-to-end network with both crosslinks in the Explorer app.



## 2. (Optional) Cross-Link Connectivity Verification

- Cross-Link Connectivity Verification is supported on all router platforms and NCS 1010 with MD-32 and BRK-24 modules.
- Connectivity Verification uses NSO CLI NED to modify router port state and TX power, is service affecting.

- When validation starts, Hierarchical Controller continuously checks the RX power on the optical add/drop port. Connectivity Verification is performed in the background.
- a. Configure NMC Validation Settings. Settings are used to control validation, **Wait period to receive samples while on** must be set to 180 seconds, **Wait period to receive samples while off** must be set to 50.

The screenshot shows a 'Settings' dialog box with two tabs: 'ETH validation' and 'NMC Validation'. The 'NMC Validation' tab is active. The settings are as follows:

Setting	Value
Power on [dbm]:	-11
Power off [dbm]:	-50
Timestamp precision [sec]:	2
Number of cycles:	3
Wait period to receive samples while on [sec]:	200
Wait period to receive samples while off [sec]:	50
Sample interval [sec]:	2
Buffer for power off/on [dbm]:	10

A 'Confirm' button is located at the bottom right of the dialog box.

- b. Select a link and click **Validate Link**. Alternatively, you can click **Validate All Manual Links** to perform connectivity verification for all links.

Link Manager Cross Links

[+ Add Cross Link](#) ✓ Validate All Manual Links

Link Name	Description	Type	Provider	Device A / Port A	Device B / Port B	Status	Method	Last Change
1 OUT OF 24 ITEMS MATCHING FILTERS								
Manual Cross Link ron-ncs5504-1 Optic...	ron-ncs5504-...	NMC	Manual	ron2_olt2-roadm / 0/3/0/6	ron-ncs5504-1 / Optics0/0/0/0	Validated By Shut No Shut	Shut no shut	2023-03-30 04:39:03 EDT

Summary

Evidence

History

LINK NAME  
Manual Cross Link ron-ncs5504-1 Optics0/0/0/0 to ron2\_olt2-roadm 0/3/0/6

DEVICE A / PORT A  
ron2\_olt2-roadm / 0/3/0/6

DEVICE B / PORT B  
ron-ncs5504-1 / Optics0/0/0/0

TIME ADDED  
2023-03-30 03:16:34 EDT

SOURCE  
Manual

STATUS  
Validated By Shut No Shut


METHOD  
Shut no shut

LAST CHANGE  
2023-03-30 04:39:03 EDT

DESCRIPTION  
ron-ncs5504-1 to ron2\_olt2-roadm


[✓ Validate Link](#) Delete Link

- c. After validation completes, inspect the evidence of either successful or unsuccessful verification. The following image shows a successful verification. Status changes from **Unknown** to **Validated By Shut No Shut**. The time it takes for the ZR/ZR+ to start transmitting after no shut is set is typically 60–80 seconds.




The following image shows a failed verification. There is no change in the optical device port power levels after the **no shut** operation





3. To provision the Routed Optical Networking IP link, perform these steps:
  - a. In the applications bar in the Crosswork Hierarchical Controller, click the **Services Manager** icon.



The Service Manager Application shows you a list of services.

service-manager-app Tunnels **Point to Point** NSO Provisioning Operations Settings

Create New P2P ▶

Name	P2P Type	Configuration State	Creation Date	Endpoint A	Endpoint B	Speed	Operational State	Last 24h Operations	Last Operation
8 OUT OF 25 ITEMS MATCHING FILTERS									
RK_2K_OLS_2x100G_16QAM_1x1.2...	IP Link	INSTALLED	27-03-2024 13:59:44 EDT	ron-ncs57c3-1 - Optics0/0/2...	ron-ncs57c3-2 - Optics0/0/2...	200 GB	Up	1	Create IP Link: ✓ Done
RK_8_2K_Router_Only	IP Link	INSTALLED	27-03-2024 07:02:42 EDT	ron-8201-32FH-3 - Optics0/0/...	ron-asr9903-1 - Optics0/0/1/...	400 GB	Up	1	Create IP Link: ✓ Done
RK_OLS	OCH-NC Link	INSTALLED	27-03-2024 06:45:53 EDT	ron-ols-2-roadm - ron-ols-2/...	ron-ols-4-roadm - ron-ols-4/...	400 GB	Up	1	Create OCH-NC: ✓ Done
RK_Test	OCH-NC Link	INSTALLED	27-03-2024 06:39:30 EDT	OLT1-roadm - ron_ncs1010_...	OLT4-roadm - ron_ncs1010_...	400 GB	Down	1	Create OCH-NC: ✓ Done
RK_12_100G	IP Link	INSTALLED	26-03-2024 04:34:55 EDT	ron-8201-32FH-3 - Optics0/0/...	ron-ncs57b1-1 - Optics0/0/0...	100 GB	Up	1	Create IP Link: ✓ Done
RK_11	IP Link	INSTALLED	26-03-2024 04:05:14 EDT	ron-ncs57c3-1 - Optics0/0/3...	ron-8201-32FH-3 - Optics0/0/...	200 GB	Up	1	Create IP Link: ✓ Done
RK_4x100G	IP Link	INSTALLED	26-03-2024 01:58:26 EDT	ron-asr9903-1 - Optics0/0/1/...	ron-8201-32FH-3 - Optics0/0/...	400 GB	Up	1	Create IP Link: ✓ Done
RK_9_3x100G	IP Link	INSTALLED	26-03-2024 00:59:59 EDT	ron-8201-1 - Optics0/0/0/18 ...	ron-ncs5504-1 - Optics0/0/0...	300 GB	Up	1	Create IP Link: ✓ Done

- b. Select the **Point to Point** tab and click **IP Link** from the **Create New P2P** drop-down list to create end to end service between router DCO ports.

service-manager-app Tunnels **Point to Point** NSO Provisioning Operations Settings

Create New P2P ▼

Name	P2P Type	Configuration State	Creation Date	Endpoint A	Endpoint B	Speed	Operational State	Last 24h Operations	Last Operation
CHANG FILTERS									
OCH Link	IP Link	INSTALLED	27-03-2024 13:59:44 EDT	ron-ncs57c3-1 - Optics0/0/2...	ron-ncs57c3-2 - Optics0/0/2...	200 GB	Up	1	Create IP Link: ✓ Done
OCH-NC Link	IP Link	INSTALLED	27-03-2024 07:02:42 EDT	ron-8201-32FH-3 - Optics0/0/...	ron-asr9903-1 - Optics0/0/1/...	400 GB	Up	1	Create IP Link: ✓ Done
OTN Line	OCH-NC Link	INSTALLED	27-03-2024 06:45:53 EDT	ron-ols-2-roadm - ron-ols-2/...	ron-ols-4-roadm - ron-ols-4/...	400 GB	Up	1	Create OCH-NC: ✓ Done
SDH Line	OCH-NC Link	INSTALLED	27-03-2024 06:39:30 EDT	OLT1-roadm - ron_ncs1010_...	OLT4-roadm - ron_ncs1010_...	400 GB	Down	1	Create OCH-NC: ✓ Done
Circuit E-Line	IP Link	INSTALLED	26-03-2024 04:34:55 EDT	ron-8201-32FH-3 - Optics0/0/...	ron-ncs57b1-1 - Optics0/0/0...	100 GB	Up	1	Create IP Link: ✓ Done
Packet E-Line	IP Link	INSTALLED	26-03-2024 04:05:14 EDT	ron-ncs57c3-1 - Optics0/0/3...	ron-8201-32FH-3 - Optics0/0/...	200 GB	Up	1	Create IP Link: ✓ Done
RK_4x100G	IP Link	INSTALLED	26-03-2024 01:58:26 EDT	ron-asr9903-1 - Optics0/0/1/...	ron-8201-32FH-3 - Optics0/0/...	400 GB	Up	1	Create IP Link: ✓ Done
RK_9_3x100G	IP Link	INSTALLED	26-03-2024 00:59:59 EDT	ron-8201-1 - Optics0/0/0/18 ...	ron-ncs5504-1 - Optics0/0/0...	300 GB	Up	1	Create IP Link: ✓ Done

The **IP Link Creation** wizard appears.

- c. Enter the Cisco Crosswork Hierarchical Controller service name, description of the router optical controller, and the Link Rate Mode in the **General** tab.
- Here, we are creating a 1x400G link. In 2x100G, 3x100G, and 4x100G modes, you can choose to create separate IP links or create a Bundle with each channel link added as a member.

The screenshot shows the 'Services Manager' interface with the 'Point to Point' tab selected. A modal dialog titled 'IP Link Creation' is open, displaying the 'GENERAL' tab. The dialog contains the following fields and options:

- Name:** ron-poc-8201-1\_1940000
- Description:** ron-poc-8201-1 0/0/20 to ron-poc-57b1-1 over NCS2K
- Link Rate Mode:** 400G - 1x400G (selected from a dropdown menu)
- Router Configuration Only:** ☐

At the bottom of the dialog, there are buttons for 'Cancel', 'Back', and 'Next'.

### *Alternatively*

- To create a 200G 16-QAM link, Select the 200G – 2x100G link rate mode.

200G 16-QAM allows the use of 200G signals on 50Ghz optical line systems. Default for 200G is QPSK at 60.1Ghz.

## IP Link Creation

1

2

3

4

GENERAL

ENDPOINTS

ADVANCED

SUMMARY

Name\*

200G legacy mode support

Description

Configure link as 200G 16QAM @ 30.1Ghz

Link Rate Mode\*

200G - 2x100G

☐ Router Configuration Only

✕ Cancel

< Back

> Next

*Alternatively*

- To create a Bundle interface, Select a bundle option from the link rate mode drop down list.

You can create a 400G bundle interface (400G Member). Alternatively, 300G-bundle (3X100G Members) and 200G-Bundle (2x100G Members) can be created

## IP Link Creation

1

2

3

4

GENERAL

ENDPOINTS

ADVANCED

SUMMARY

Name\*

400G-Bundle-Cisco8000-ASR9903

Description

Link Rate Mode\*

400G - Bundle

☐ Router Configuration Only

✕ Cancel

< Back

> Next

(Optional) Check the **Router Configuration Only** check box to configure only the router optical controller and IP information and not the optical line system. This configuration is used when the OCHNC is created outside Cisco Crosswork Hierarchical Controller.

- d. Select the two router ports in the service. This is done by selecting the Site and Port. The transmit power for each endpoint is an optional parameter. The default TX power is used if no value is provided.

- e. Click the magnifying glass icon to select the first router port.

The ports are displayed based on the following criteria:

- Is a ZR/ZR+ interface
- Has no existing optics configuration
- Has a proper NMC cross-connect configured

This page lists all available ZR/ZR+ ports currently unused on all devices. Select the *ron-poc-8201-1 Optics0/0/0/22* port.

★

▼

Advanced

3D Explorer

OCH PORTS

Name	Device	Type	Capacity	Description	Admin Status
17 ITEMS					
Optics0/0/0/24	ron-poc-57b1-1	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	UP
Optics0/0/0/24	ron-ncs57b1-1	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	UP
Optics0/0/0/14	ron-8201-32FH-3	OCH		OCH port of Cisco QDD 400G BRT ZRP Plug...	UP
Optics0/0/0/16	ron-8201-32FH-3	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	UP
Optics0/0/0/0	ron-ncs540-2dd-1	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	UP
Optics0/0/0/18	ron-8201-1	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	UP
Optics0/0/0/8	ron-8201-1	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	DOWN
Optics0/0/0/20	ron-8201-1	OCH		OCH port of Cisco QSPFDD 400G ZR Plug...	UP
Optics0/0/0/22	ron-8201-1	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	UP
Optics0/0/1/4	ron-asr9903-1	OCH		OCH port of 400G ZRP-S QSPFDD Module	UP
Optics0/0/1/8	ron-asr9903-1	OCH		OCH port of 400G ZR-S QSPFDD Module	UP
Optics0/0/0/10	ron-8201-2	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	UP
Optics0/0/0/20	ron-8201-2	OCH		OCH port of Cisco QSPFDD 400G ZR Plug...	UP
Optics0/0/0/22	ron-poc-8201-1	OCH		OCH port of Cisco QSPFDD 400G ZRP Plu...	UP
Optics0/0/0/20	ron-8201-4	OCH		OCH port of Cisco QSPFDD 400G ZR Plug...	UP
Optics0/0/3/0	ron-ncs57c3-1	OCH		OCH port of Cisco QDD 400G BRT ZRP Plug...	UP
Optics0/0/2/2	ron-ncs57c3-1	OCH		OCH port of Cisco QSPFDD 400G ZRP Plug...	UP

Cancel

- f. Similar to the previous step, choose *ron-poc-57b1-1 Optics 0/0/0/24* as the second router port.
- g. (Optional) Set the transmit power in dBm on each port. If OLS provisioning is being performed, the OLS controller returns the optical power. If the OLS controller does not return the optical power or **router only** provisioning is being used, the router default power is used.
- h. (Optional) Enter the IP address information for interfaces. If IP addresses are not entered, ZR/ZR+ router optical configuration happens; however, IP addresses are not configured.
- i. Click **Next** to move to **Advanced** configuration.



## IP Link Creation

1  
GENERAL

2  
ENDPOINTS

3  
ADVANCED

4  
SUMMARY

Transmit Power [dBm]  
-10

ENDPOINT B

Site B

Port B\*  
ron-poc-57b1-1 - Optics0/0/0/24

Transmit Power [dBm]  
-10

LINK #1 IP ADDRESSES

IP Address A (CIDR)  
100.28.30.22/31

IP Address B (CIDR)  
100.28.30.23/31

✕ Cancel

< Back

> Next

Sample End-to-end Configuration

53

- j. (Optional) Set the Frequency. If optical provisioning is being performed, the OLS controller can return the frequency to be used, and it may be omitted. If **router only** provisioning is being performed, the Frequency must be specified.
- k. (Optional) Set the DAC rate. A DAC rate setting can be used to enable OpenZR+ compatibility mode, disabling TX shaping and enhanced modem mode. See [OpenZR+ Compatibility Mode](#) for more information on mode support.

## IP Link Creation

1

2

3

4

GENERAL

ENDPOINTS

ADVANCED

SUMMARY

Add to existing LAG

FREQUENCY

☐ L Band

☒ C Band

Frequency THz

194.00

Digital-to-Analog Converter (DAC) rate

✓

1 X 1

1 X 1.25

Set Path Preferences

Min Path Criteria

Latency

▼ Include Nodes or Links

Select Node or Link

✕ Cancel

< Back

> Next

1. (Optional) Set links or nodes to include/exclude in the optical path. This setting is not available in **router only** provisioning.

- m. (Optional) To add the new link or set of links to an existing Bundle LAG interface configured on the routers, choose the bundle from the **Add to existing LAG** drop-down.

The image shows a configuration window titled "IP Link Creation" with four tabs: GENERAL, ENDPOINTS, ADVANCED (selected), and SUMMARY. The ADVANCED tab contains the following settings:

- Add to existing LAG**: A dropdown menu is open, showing a checkmark and the option "Bundle-Ether1 to Bundle-Ether1".
- Frequency**: Radio buttons for "L Band" and "C Band" (selected). Below is a text field for "Frequency THz\*" with the value "195.200".
- Digital-to-Analog Converter (DAC) rate**: A dropdown menu.
- Modulation**: A dropdown menu.
- Set Path Preferences**: A section with a "Min Path Criteria" dropdown set to "Latency".
- Include Nodes or Links**: A section with a search bar labeled "Select Node or Link" and a magnifying glass icon.

At the bottom of the window are three buttons: "Cancel", "Back", and "Next".

- n. (Optional) If you are configuring a 200G 16-QAM link, set the DAC rate to 1x1.25.

200G link rate mode enables the **Modulation** selection drop-down. Modulation selection is not available in any other mode. Select the 16 QAM (30Ghz) modulation.

## IP Link Creation

1

2

3

4

GENERAL

ENDPOINTS

ADVANCED

SUMMARY

Add to existing LAG

FREQUENCY

☐ L Band

☒ C Band

Frequency THz

195.2

Digital-to-Analog Converter (DAC) rate

1 X 1.25

Modulation

✓

8 QAM

16 QAM

QPSK

▼ Include Nodes or Links

Select Node or Link

✕ Cancel

< Back

> Next

- o. Click **Next** to review the final configuration. Verify the router endpoint and optical line system parameters. Click **Finish** to start provisioning, or click **Save** to save for later provisioning.

## IP Link Creation

1

2

3

4

GENERALENDPOINTSADVANCEDSUMMARY

**Name:** ron-poc-8201-1\_ron-poc-57b1-1\_1940000

**Description:** ron-poc-8201-1 0/0/0/20 to ron-poc-57b1-1 over NCS2K

▼ **Endpoint A**

**Port:** ron-poc-8201-1 - Optics0/0/0/22

**Transmit Power:** -10.0 dBm

▼ **Endpoint B**

**Port:** ron-poc-57b1-1 - Optics0/0/0/24

**Transmit Power:** -10.0 dBm

**Link Rate Mode:** 400G - 1x400G

**Frequency:** 194.0 THz

**DAC rate:** -

**Modulation:** -

**Path Criteria:** Latency

**Optical Excluded List:** -

**Included List:** -

**Disjoint From Links:** -

✕ Cancel

< Back

> Finish

Save

The following image shows a sample summary for a 200G 16-QAM link.

## IP Link Creation

1

2

3

4

GENERAL

ENDPOINTS

ADVANCED

SUMMARY

**Name:** 200G legacy mode support

**Description:** Configure link as 200G 16QAM @ 30.1Ghz

▼ **Endpoint A**

**Port:** ron-ncs540-2dd-1 - Optics0/0/0/0

**Transmit Power:** -

▼ **Endpoint B**

**Port:** ron-ncs57b1-1 - Optics0/0/0/24

**Transmit Power:** -

**Link Rate Mode:** 200G - 2x100G

**Frequency:** 195.2 THz

**DAC rate:** 1 X 1.25

**Modulation:** MT\_16QAM

**Path Criteria:** Latency

**Optical Excluded List:** -

**Included List:** -

**Disjoint From Links:** -

✕ Cancel

< Back

> Finish

Save

- p. Go to Services Manager to view provisioning progress.



Click the **Operations > Logs** tab to view the provisioning API calls used and responses. The logs show API calls and responses for both optical line system provisioning via Cisco Optical Network Controller and router provisioning via Crosswork Network Controller.

Services Manager Tunnels **Point to Point** IP Services Operations Settings

Create New P2P

Name	P2P Type	Configuration State	Creation Date	Endpoint A	Endpoint B	Speed	Operational State	Last 24h Operations	Last Operation
1 OUT OF 3 ITEMS MATCHING FILTERS									
ron-poc-8201-1_ron-poc-57b1-1_1940000	IP Link	IN PROGRESS	24-04-2023 14:44:21 UTC	ron-poc-57b1-1 - Optics0/0/0/2...	ron-poc-8201-1 - Optics0/0/0/2...	400 GB	Up	1	Create IP Link: Discovery

ron-poc-8201-1\_ron-poc-57b1-1\_1940000

Summary Endpoints Underlay Path **Operations** Events Actions

3 ITEM

Action	Lifecycle State	Creation Date	Last Update
Create IP Link	Discovery	24-04-2023 14:44:20 UTC	24-04-2023 14:44:27 UTC

SUMMARY LOGS ERRORS

Normal Flow

- Adapter #1: onc-poc-90 ✓
  - create service
  - create service response

If the provisioning is successful, the **Configuration State** field changes to INSTALLED state and the **Operational State** field changes to UP state.

Services Manager Tunnels **Point to Point** IP Services Operations Settings

Create New P2P

Name	P2P Type	Configuration State	Creation Date	Endpoint A	Endpoint B	Speed	Operational State	Last 24h Operations	Last Operation
1 OUT OF 3 ITEMS MATCHING FILTERS									
ron-poc-8201-1_ron-poc-57b1-1_1940000	IP Link	INSTALLED	24-04-2023 14:44:21 UTC	ron-poc-57b1-1 - Optics0/0/0/2...	ron-poc-8201-1 - Optics0/0/0/2...	400 GB	Up	1	Create IP Link: ✓ Done

ron-poc-8201-1\_ron-poc-57b1-1\_1940000

Summary Endpoints Underlay Path Operations Events Actions

GUID: 517d4cd30b6cc64eb7ad44a41269d2d45b  
 Name: ron-poc-8201-1\_ron-poc-57b1-1\_1940000  
 Creation Time: 24-04-2023 14:44:21 UTC  
 Last Changed: 24-04-2023 14:44:21 UTC  
 Template Name: default-template


Service Links:

- 100.28.30.23 to 100.28.30.22


IP Address Assignment Policy: User Allocated  
 Is Bundle? No  
 Channel Config: 1 X 400G  
 Path Criteria: Latency

The **Summary** tab displays the new service link.

- q. Verify the end to end link across both IP and optical layers in the Explorer view.



4. Use the Link Assurance application to verify the end to end path and relevant PM data. Select a link or port to see data on the ZRM, OCH, and OTS layers.



## Operate Phase

To monitor the ZR/Z+ optics:

1. Use either CLI commands or EPNM to monitor router ZR/ZR+ optics for proper operation. See [Monitor ZR or ZR+ Optics Using EPNM](#), on page 63.
2. (Optional) Setup router ZR/ZR+ optics data collection in CW Health Insights. See [Monitor Performance of ZR/ZR+ Optics Using KPIs](#), on page 72.


To monitor NCS 1010, use Cisco Optical Network Controller and Cisco Optical Site Manager:

- [Monitoring using Cisco Optical Network Controller](#)
- [Network and Circuit Monitoring using Workspaces in Cisco Optical Network Controller](#)
- [Monitoring Alarms in Cisco Optical Network Controller](#)
- [Fault Monitoring using Cisco Optical Site Manager](#)

## Monitor ZR or ZR+ Optics Using EPNM


This section adds the 8201 router to EPNM for monitoring the PM parameters on the ZR or ZR+ optics.

1. To add a new device to EPNM choose **Inventory > Device Management > Network Devices**. Click **Routers** or a subgroup if it is already defined in the left panel.



521942

2. Click the **+** icon above the Network Devices table, then choose **Add Device**.



521943

3. Configure the General, SNMP, and SSH parameters as seen in that following figures. Click **Verify Credentials** to validate that Cisco EPN Manager can reach the device. Click **Add** to add the device to EPNM.

### Add Device

**\* General** ✓

**\* SNMP**  
(Optional if TL1 is configured)

Telnet/SSH

HTTP/HTTPS

TL1

Civic Location

**\* General Parameters**

☒ IP Address 172.29.11.28

☐ DNS Name

License Level Full

Device Role --Select--

Add to Group --Select--

Credential Profile --Select--

Add Verify Credentials Cancel

521945

## Add Device

☒ General ✓  
☒ SNMP (Optional if TL1 is configured) ✓  
☒ Telnet/SSH ✓  
☐ HTTP/HTTPS  
☐ TL1  
☐ Civic Location

### Telnet/SSH Parameters

Protocol SSH2  
 Port 22  
 Timeout 60 (secs)  
 Username admin  
 Password \*\*\*\*\*  
 Confirm Password \*\*\*\*\*  
 Enable Password \*\*\*\*\* ?  
 Confirm Enable Password \*\*\*\*\*

\* Note: Not providing Telnet/SSH credentials may result in partial collection of inventory data.

Add

Verify Credentials

Cancel

521946

## Add Device

☒ General ✓  
☒ SNMP (Optional if TL1 is configured) ✓  
☒ Telnet/SSH ✓  
☐ HTTP/HTTPS  
☐ TL1  
☐ Civic Location

### \* SNMP Parameters

Version v2c  
 \* SNMP Retries 2  
 \* SNMP Timeout 10 (secs)  
 \* SNMP Port 161  
 \* Read Community \*\*\*\*\* ?  
 \* Confirm Read Community \*\*\*\*\*  
 Write Community \*\*\*\*\* ?  
 Confirm Write Community \*\*\*\*\*


Add

Verify Credentials

Cancel


521947

- To open the chassis view from the Network devices table, click the device name link. The following figure displays the chassis view of the 8201 router.




521948

- Click the QSFP-DD ZR+ port to see specific data about that port.




521949

Here you can view the port and specific optical channel and CoherentDSP entities.




521950

6. Clicking the additional information icon for the optical channel and then the **Optical Physical** measurement tab displays the relevant optical PM values such as **RX/TX signal power** and **OSNR** values.



521951


7. Clicking the additional information icon for the coherent DSP and then the **FEC** measurement tab displays the relevant coherent DSP FEC statistics such as **PreFEC Bit Error Rate**, **Bit Error Rate Count (BIEC)**, and **Uncorrected Words (UCW)**. The UCW value must remain 0.



521952

The following figures display the current and historical performance monitoring data in EPNM that is specific to the ZR or ZR+ optics.

Figure 24: Optical Physical Parameters



521883



Figure 25: Historical Optical Physical Parameters




Figure 26: Historical Optical Physical Parameters






Figure 27: Historical Optical Physical Parameters



521888

Figure 28: FEC Parameters



521881

Figure 29: Historical FEC Parameters




Figure 30: Historical FEC Parameters




Figure 31: Historical OTN Parameters





Figure 32: Historical OTN Parameters



## Monitor Performance of ZR/ZR+ Optics Using KPIs

Perform the following steps to create KPI Profiles in Health Insights and enable them on the devices to monitor network health.

**Note**

Plan which Cisco-supplied KPIs you want to begin using, based on each device's function and the device performance characteristics you want to monitor. Review the Cisco-supplied KPIs documented in [List of Health Insights KPIs](#). In the following image, you see the available default L1 optics KPIs.

KPI Name	Category	Description	Linked Playbook
<input type="checkbox"/> Layer 1 optical alarms	Layer1-Optics	Monitors per-port optical alarms	
<input type="checkbox"/> Layer 1 optical errors	Layer1-Optics	Monitors per-port Layer 1 errors; generates ale...	
<input type="checkbox"/> Layer 1 optical FEC errors	Layer1-Optics	Monitors per-port optical FEC errors; generate...	
<input type="checkbox"/> Layer 1 optical power	Layer1-Optics	Monitors per-port optical power; generates ale...	
<input type="checkbox"/> Layer 1 optical temperature	Layer1-Optics	Monitors per-port optical temperature; generat...	
<input type="checkbox"/> Layer 1 optical voltage	Layer1-Optics	Monitors per-port optical voltage; generates al...	

521913

1. Group the relevant KPIs to form a KPI Profile. A KPI profile can have many different KPIs assigned. In this case, the focus is only on some specific optics KPIs to add to the **optics\_profile** KPI profile.


Category	KPI	Summary
<input type="checkbox"/> Layer1-Optics	Layer 1 optical alarms	Monitors per-port optical alarms
<input type="checkbox"/> Layer1-Optics	Layer 1 optical errors	Monitors per-port Layer 1 errors; generates alert when error rates exceeds the configured threshold
<input type="checkbox"/> Layer1-Optics	Layer 1 optical FEC errors	Monitors per-port optical FEC errors; generates an alert when FEC errors exceeds the configured th...
<input checked="" type="checkbox"/> Layer1-Optics	Layer 1 optical power	Monitors per-port optical power; generates alert when power levels exceeds the configured threshold
<input checked="" type="checkbox"/> Layer1-Optics	Layer 1 optical temperature	Monitors per-port optical temperature; generates alert when temperature exceeds the configured th...
<input checked="" type="checkbox"/> Layer1-Optics	Layer 1 optical voltage	Monitors per-port optical voltage; generates alert when voltages exceeds the configured threshold

521914


See [Create a New KPI Profile](#).

2. Enable the appropriate KPI Profiles on the devices you want to monitor. From the main menu, choose **Performance Alerts > Enable/Disable KPI Profiles**. Check the checkboxes of all the nodes to which the profile must be applied to, and click **Enable KPI Profiles**.

Multiple nodes may be selected. In the following figure, we are applying the KPI profile to a single node.



3. Select the optics\_profile KPI profile that was created in the previous step and click next to finalize enabling the KPI for the selected device.



4. The following image displays the final page before enabling the KPI profile for the router. After you click **Enable**, the appropriate configuration is applied to the router to begin streaming the telemetry sensors data for the selected optical KPIs.

Performance Alerts / Enable/Disable KPI Profiles

Select Devices      Select KPI Profiles      Verify Details

Selected Device(s)

Name
ron-8201-1

Selected Profile(s)

Name
optics_profile

**optics\_profile**

Description : Measure optics parameters  
Destination :      Server Type : -      Topic : -

3 #KPIs on Profile      0 Enabled Devices

KPI On Profile

Layer 1 optical power

Alerts OFF  
Cadence(sec) 300  
Alert Frequency 1  
Alert Type alarm\_stat...

[View More Details](#)

Layer 1 optical temperature

Alerts OFF  
Cadence(sec) 300  
Alert Frequency 1  
Alert Type alarm\_stat...

[View More Details](#)

Layer 1 optical voltage

Alerts OFF  
Cadence(sec) 300  
Alert Frequency 1  
Alert Type alarm\_stat...


[View More Details](#)

[Cancel](#)      [Previous](#)      [Enable](#)

See [Enable KPI Profiles on Devices](#).

- To view alerts from network devices, see [View Alerts for Network Devices](#).

The following figure displays the RX and TX power of the QDD-400G-ZR-S transceiver.



## Optimization Phase

The optimization phase involves:

- Return to planning stage.
- Continue to add or change circuits on the network to match packet demands.

