



# Slot and Subslot Configuration

---

This chapter contains the following sections:

- [Configuring the Interfaces, on page 1](#)

## Configuring the Interfaces

The following sections describe how to configure interfaces and also provide examples of configuring the router interfaces:

### Configuring the Interfaces: Example

The following example shows the **interface gigabitEthernet** command being used to add the interface and set the IP address. **0/0/0** is the slot/subslot/port. The ports are numbered 0 to 3.

```
Router# show running-config interface gigabitEthernet 0/0/0
Building configuration...
Current configuration : 71 bytes
!
interface gigabitEthernet0/0/0
no ip address
negotiation auto
end

Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# interface gigabitEthernet 0/0/0
```

### Viewing a List of All Interfaces: Example

In this example, **show interfaces summary** command is used to display all the interfaces:

```
Router# show interfaces summary
*: interface is up
IHQ: pkts in input hold queue          IQD: pkts dropped from input queue
OHQ: pkts in output hold queue         OQD: pkts dropped from output queue
RXBS: rx rate (bits/sec)                RXPS: rx rate (pkts/sec)
TXBS: tx rate (bits/sec)                TXPS: tx rate (pkts/sec)
TRTL: throttle count

      Interface           IHQ      IQD      OHQ      OQD      RXBS      RXPS
      TXBS     TXPS     TRTL
```

## Viewing Information About an Interface: Example

Interface	TXBS	TXPS	TRTL	IHQ	IQD	OHQ	OQD	RXBS	RXPS
* GigabitEthernet0/0/0	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/0/1	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/1/0	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/1/1	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/1/2	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/1/3	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/1/4	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/1/5	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/1/6	0	0	0	0	0	0	0	0	0
* GigabitEthernet0/1/7	0	0	0	0	0	0	0	0	0
* Wl0/1/8	0	0	0	0	0	0	0	0	0
* Cellular0/2/0	0	0	0	0	0	0	0	0	0
Cellular0/2/1	0	0	0	0	0	0	0	0	0
* Loopback3	0	0	0	0	0	0	0	0	0
* Loopback50	0	0	0	0	0	0	0	0	0
* Loopback100	0	0	0	0	0	0	0	0	0
* Loopback544534	0	0	0	0	0	0	0	0	0

## Viewing Information About an Interface: Example

The following example shows how to display a brief summary of an interface's IP information and status, including the virtual interface bundle information, by using the **show ip interface brief** command:

```
Router# show ip interface brief
Interface          IP-Address      OK? Method Status           Protocol
GigabitEthernet0/0/0 192.168.1.46  YES NVRAM  up
GigabitEthernet0/0/1 15.15.15.1   YES NVRAM  up
GigabitEthernet0/1/0 unassigned     YES unset   up
GigabitEthernet0/1/1 unassigned     YES unset   up
GigabitEthernet0/1/2 unassigned     YES unset   up
GigabitEthernet0/1/3 unassigned     YES unset   up
GigabitEthernet0/1/4 unassigned     YES unset   up
GigabitEthernet0/1/5 unassigned     YES unset   up
GigabitEthernet0/1/6 unassigned     YES unset   up
GigabitEthernet0/1/7 unassigned     YES unset   up
Wl0/1/8            unassigned     YES unset   up
Cellular0/2/0       unassigned     YES NVRAM  up
Cellular0/2/1       unassigned     YES NVRAM  administratively down down
Loopback3          unassigned     YES unset   up
Loopback50          5.5.5.5       YES NVRAM  up
Loopback100         unassigned     YES unset   up
```

Loopback544534	unassigned	YES	unset	up	up
Loopback32432532	unassigned	YES	unset	up	up
Port-channel2	unassigned	YES	unset	down	down
Vlan1	10.10.10.1	YES	NVRAM	up	up

## Viewing Information About an Interface: Example