

# **Configuring Network Configuration Protocol**

This module provides details of the Network Configuration Protocol. For relevant commands, see *System Security Command Reference for Cisco ASR 9000 Series Routers*.

Release	Modification
Release 5.3.0	This feature was introduced.
Release 5.3.1	Support extended for more Yang models.
Release 6.0	Support extended for the Netconf subsystem configuration to be vrf aware. The configuration of the netconf port is no longer sufficient to start the Netconf subsystem support. At least one vrf needs to be configured. The configuration of the port is now optional.

- The Network Configuration Protocol, on page 1
- Netconf and Yang, on page 3
- Supported Yang Models, on page 4
- Denial of Services Defence for Netconf-Yang, on page 4
- Dynamic Loading of Operational Yang Models, on page 5
- Enabling NETCONF over SSH, on page 5
- Additional Reference, on page 8

## The Network Configuration Protocol

The Network Configuration Protocol (Netconf) provides mechanisms to install, manipulate, and delete the configuration of network devices. It uses an Extensible Markup Language (XML)-based data encoding for the configuration data as well as the protocol messages. Yang is a data modeling language used with Netconf.

Netconf uses a simple RPC-based (Remote Procedure Call) mechanism to facilitate communication between a client and a server. The client can be a script or application typically running as part of a network manager. The server is typically a network device.

The configuration of features need not be done the traditional way (using CLIs), the client application (controller) reads the Yang model and communicates with the Netconf server (IOS XR) accordingly.



Note

Following are the deviations from IETF-NACM YANG, where the system does not support:

- The ordered-by-user functionality for rule-lists and rules. rule-lists & rules are sorted based on name.
- The enable-nacm leaf.
- The *notification* related leafs (notification-name & denied-notifications.)

### **Netconf Sessions and Operations**

A Netconf session is the logical connection between a network configuration application and a network device. A device should be capable of supporting multiple sessions and atleast one Netconf session.

Characteristics of a netconf session:

- Netconf is connection-oriented SSH is the underlying transport.
- The netconf client establishes session with the server.
- Netconf sessions are established with the hello message. Features and capabilities are announced.
- Sessions can be terminated using the *close* or *kill* messages.

Basic Netconf operations:

- Get configuration <get-config>
- Get all information <get>
- Edit configuration <edit-config>
- Copy configuration <copy-config>



Note

<copy-config> does not support source attribute with "data store" at present.

- <lock>, <unlock>
- <kill-session>
- <close-session>
- Commit configuration <commit>

### The Yang data model

Each feature has a defined Yang Model which is synthesized from the schemas. A model is published in a tree format and includes:

- Top level nodes and their subtrees
- Subtrees that augment nodes in other yang models

```
Example: The aaa Yang model
module: Cisco-IOS-XR-aaa-lib-cfg
   +--rw aaa
      +--rw accountings
      | +--rw accounting* [type listname]
           +--rw type xr:Cisco-ios-xr-string
+--rw listname xr:Cisco-ios-xr-string
           +--rw rp-failover? Aaa-accounting-rp-failover
+--rw broadcast? Aaa-accounting-broadcast
           +--rw type-xr? Aaa-accounting
+--rw method* Aaa-method
           +--rw method* Aaa-method
+--rw server-group-name* string
      +--rw authorizations
      | +--rw authorization* [type listname]
                                     xr:Cisco-ios-xr-string
           +--rw type
                                      xr:Cisco-ios-xr-string
            +--rw listname
            +--rw method*
                                       Aaa-method
            +--rw server-group-name* string
      +--rw accounting-update!
      | +--rw type
                                    Aaa-accounting-update
      | +--rw periodic-interval? uint32
      +--rw authentications
         +--rw authentication* [type listname]
                          xr:Cisco-ios-xr-string
            +--rw type
            +--rw listname
                                       xr:Cisco-ios-xr-string
            +--rw method*
                                       Aaa-method
            +--rw server-group-name* string
```

Advantages of using the Yang model are:

- Yang supports programmatic interfaces.
- Yang supports simplified network management applications.
- Yang supports interoperability that provides a standard way to model management data.

## **Netconf and Yang**

The workflow displayed here, will help the user to understand how Netconf-Yang can configure and control the network with minimal user intervention. The required components:

- Cisco Router (ASR9000 series or CRS) with Netconf capability
- Netconf Client Application with connection to the router

S. No.	Device / component	Action
1	Cisco router (ASR 9000 or CRS router)	Login/ access the router.
2	Cisco router	Prerequisites for enabling Netconf.  • k9sec pie must be installed.  • Crypto keys must be generated.

S. No.	Device / component	Action	
3	Cisco router	Enable Netconf agent. Use the <b>netconf-yang agent ssh</b> and <b>ssh server netconf</b> command. The port can be selected. By default, it is set as 830.	
4	Cisco router	Yang models are a part of the software image. The models can be retrieved from the router, using the <get-schema> operation.</get-schema>	
5	Netconf client (application)	Installs and processes the Yang models.	
	The application can be on any standalone application or a SDN controller supporting Netconf	The client can offer a list of supported yang models; else the user will have to browse and locate the required yang file.	
		There is a yang model file for each configuration module; for instance if the user wants to configure CDP, the relevant yang model is Cisco-IOS-XR-cdp-cfg	
		Note Refer the table which lists all the supported yang models. Supported Yang Models, on page 4	
5	Netconf client	Sends Netconf operation request over SSH to the router. A configuration request could include Yang-based XML data to the router. Currently, SSH is the only supported transport method.	
6	Cisco router	Understands the Yang-based XML data and the network is configured accordingly (in case of configuration request from the client).	
		The interactions between the client and the router happens until the network is configured as desired.	

# **Supported Yang Models**

The Yang models can be downloaded from a prescribed location (ftp server) or can also be retrieved directly from the router using the get-schema operation.

For a feature, separate Yang models are available for configuring the feature and to get operational statistics (show commands). The **-cfg.yang** suffix denotes configuration and **-oper\*.yang** is for operational data statistics. In some cases, **-oper** is followed by **-sub**, indicating that a submodule(s) is available.

For a list of supported Yang models, see https://github.com/YangModels/yang/tree/master/vendor/cisco/xr

# **Denial of Services Defence for Netconf-Yang**

In case of a DoS (Denial of Service) attack on Netconf, wherein, Netconf receives numerous requests in a short span of time, the router may become irresponsive if Netconf consumes most of the bandwidth or CPU

processing time. This can be prevented, by limiting the traffic directed at the Netconf agent. This is achieved using the **netconf-yang agent rate-limit** and **netconf-yang agent session** commands.

If rate-limit is set, the Netconf processor measures the incoming traffic from the SSH server. If the incoming traffic exceeds the set rate-limit, the packets are dropped.

If session-limit is set, the Netconf processor checks for the number of open sessions. If the number of current sessions is greater than or equal to, the set limit, no new sessions are opened.

Session idle- timeout and absolute-timeout also prevent DoS attacks. The Netconf processor closes the sessions, even without user input or intervention, as soon at the time out session is greater than or equal to the set time limit.

The relevant commands are discussed in detail, in the System Security Command Reference for Cisco ASR 9000 Series Routers

## **Dynamic Loading of Operational Yang Models**

Netconf is enhanced to pre-load only the configurational yang models in memory, when it starts. The operational yang models are loaded into memory only when a request is issued. This helps reduce consumption of the RAM memory.

## **Enabling NETCONF over SSH**

This task enables NETCONF over SSH. SSH is currently the only supported transport method.

If the client supports, Netconf over ssh can utilize the multi-channeling capabilities of IOS XR ssh server. For additional details about Multi-channeling in SSH, see *Implementing Secure Shell* in *System Security Configuration Guide*.

#### **Prerequisites:**

- k9sec pie must be installed, otherwise the port configuration for the netconf ssh server cannot be completed. (The Netconf subsystem for SSH, as well as, SSH cannot be configured without the k9sec pie.)
- Crypto keys must be generated prior to this configuration.
- The Netconf-YANG feature is packaged in the mgbl pie, which must be installed before enabling the Netconf-YANG agent.

#### SUMMARY STEPS

- 1. configure
- 2. netconf-yang agent ssh
- **3.** ssh server netconf [vrf vrf-name [ipv4 access-listipv4 access list name] [ipv6 access-list ipv6 access list name] ]
- 4. ssh server netconf port port-number

#### **DETAILED STEPS**

	Command or Action	Purpose
Step 1	configure	Enters global configuration mode.
	Example:	
	RP/0/RSP0/CPU0:router# configure	
Step 2	netconf-yang agent ssh  Example:	Enables NETCONF agent over SSH connection. After NETCONF is enabled, the Yang model in the controllcker, can configure the relevant models.
	RP/0/RSP0/CPU0:router (config) # netconf agent ssh	Note The Yang models can be retrieved from the router via NETCONF <get-schema> operation.</get-schema>
Step 3	ssh server netconf [vrf vrf-name [ipv4 access-listipv4 access list name] [ipv6 access-list ipv6 access list name]]  Example:	Brings up the netconf subsytem support with SSH server using a specified VRF of up to 32 characters. If no VRF is specified, the default VRF is used. To stop the SSH server from receiving any further connections for the specified VRF, use the <b>no</b> form of this command.
	<pre>RP/0/RSP0/CPU0:router (config) # ssh server netconf vrf netconfvrf ipv4 access-list InternetFilter</pre>	Optionally ACLs for IPv4 and IPv6 can be used to restrict access to the netconf subsystem of the ssh server before the port is opened.
		Note The netconf subsystem support with SSH server can be configured for use with multiple VRFs.
Step 4	ssh server netconf port port-number	Configures a port for the netconf ssh server. This command
	Example:	is optional. If no port is specified, port 830 is uses by default.
	<pre>RP/0/RSP0/CPU0:router (config) # ssh server netconf port 830</pre>	Note 830 is the IANA-assigned TCP port for NETCONF over SSH, but it can be changed using this command.

#### What to do next

The **show netconf-yang statistics** command and **show netconf-yang clients** command can be used to verify the configuration details of the netconf agent.

The **clear netconf-yang agent session** command clears the specified Netconf session (on the Netconf server side).

### **Examples: Netconf over SSH**

This section illustrates some examples relevant to Netconf:

Enabling netconf-yang for ssh transport and netconf subsystem for default vrf with default port (830)

```
config
netconf-yang agent ssh
ssh server netconf vrf default
!
```

# Enabling netconf-yang for ssh transport and netconf subsystem for vrf green and vrf red with netconf port (831)

```
config
netconf-yang agent ssh
!
ssh server netconf vrf green
ssh server netconf vrf red
ssh server netconf port 831
!
!
```

#### Show command outputs

```
show netconf-yang statistics
Summary statistics
                           requests|
                                                   total time|
                                                                 min time per request|
time per request| avg time per request|
                                    0 |
                                                 0m 0s
other
                                             0h
                                                           0ms|
                                                                       0h
                                                                           0m
                                                                               0s
                                                                                     0ms|
0h 0m 0s
              0ms|
                          0h
                              0m
                                   0s
                                        0ms|
                                    4 |
                                                 0 m
                                                                       0h
                                                                           0m
                                                                               0s
close-session
                                             0h
                                                     0s
                                                                                     0ms1
                                                           3ms|
 0h 0m 0s
                          0h
                               0m
                                   0s
                                        Oms|
kill-session
                                    0 1
                                             0h
                                                 0m
                                                     0s
                                                           0msl
                                                                       0h
                                                                           0m
                                                                               0s
                                                                                     0msl
0h 0m 0s
              0ms|
                          0h
                              0m
                                   0s
                                        0ms|
get-schema
                                    0 |
                                             0h
                                                 0m
                                                      0s
                                                                       0h
                                                                           0m
                                                                               0s
                                                                                     Oms|
                                                           0ms|
0h 0m 0s
              0ms|
                          0h
                              0m
                                   0s
                                        0ms|
                                    0 |
                                             0h
                                                 0m
                                                      0s
                                                           0ms|
                                                                       0h
                                                                           0m
                                                                               0s
                                                                                     0ms|
aet
 0h 0m 0s
              0ms|
                          0h
                               0m
                                   0s
                                             0h
                                                                       0h
get-config
                                    11
                                                 0m
                                                      0s
                                                           1msl
                                                                           Ωm
                                                                               0s
                                                                                     1msl
0h 0m 0s
                          0h
                               0m
                                   0s
              1ms|
                                        1ms|
edit-config
                                    3 |
                                             0h
                                                 0m
                                                      0s
                                                           2ms|
                                                                       0h
                                                                           0m
                                                                               0s
                                                                                     0ms|
0h 0m 0s
                          0h
                              0m
                                   0s
                                        0ms1
              1msl
commit
                                    0 |
                                             0h
                                                 0m
                                                      0s
                                                           0ms|
                                                                       0h
                                                                           0m
                                                                               0s
                                                                                     0ms|
0h 0m 0s
              0ms1
                          0h
                              0m
                                   0s
                                        0ms|
                                    0 [
                                                 0m
                                                      0s
                                                                       0h
                                                                           0m
                                                                               0s
cancel-commit
                                             0h
                                                           0ms|
                                                                                     0ms|
        0s
                          0h
 Oh Om
                               0m
                                   0s
               0ms|
                                        0ms|
                                             0h
                                                 0m
                                                      0s
                                                                       0h
                                                                           0m
                                                                               0s
lock
                                    0 1
                                                           0msl
                                                                                     0ms I
0h 0m 0s
              0ms|
                          0h
                               0m
                                   0s
                                        0ms|
unlock
                                    0 |
                                             0h
                                                 0 m
                                                     0s
                                                           0ms|
                                                                       0h
                                                                           0m
                                                                               0s
                                                                                     0ms|
0h 0m 0s
              0msl
                          0h
                              0m
                                   0s
                                        0ms|
                                    0 |
discard-changes
                                             0h
                                                 0 m
                                                      0s
                                                                       0h
                                                                           0m
                                                                               0s
                                                                                     Oms|
                                                           0ms|
 0h 0m 0s
              0msl
                          0h
                              0m
                                   0s
                                        0ms|
validate
                                    0 1
                                             0h 0m 0s
                                                                       0h
                                                                           0m 0s
                                                           0ms1
                                                                                     0ms I
0h 0m 0s
                              0m
                                   0s
                                        0ms|
show netconf-yang clients
client session ID|
                      NC version|
                                      client connect time |
                                                                    last OP time|
                                                                                          last
OP type|
            <lock>|
22969|
                        1.1|
                                      0d 0h 0m 2s|
                                                                    11:11:24|
                       Nol
close-session|
15389|
                       1.1|
                                    0d 0h 0m 1s|
                                                                11:11:25|
                                                                                   get-config|
           No|
```

## **Additional Reference**

#### **Table 1: Related Documents**

Related Topic	Document Title
Netconf-Yang	For related commands, see System Security Command Reference for Cisco ASR 9000 Series Routers

#### Table 2: Standards

Component	RFCs
YANG	6020
NETCONF	6241
NETCONF over SSH	6242