



Configuring Cloud Native BNG User Plane and Key Features

This chapter describes the configuration procedures to achieve the cnBNG user plane functionality on Cisco ASR 9000 Series Routers.

For details on cnBNG user plane commands, see the *Cloud Native BNG Command Reference for Cisco ASR 9000 Series Routers*.

- [Configure cnBNG User Plane, on page 1](#)
- [Verify cnBNG User Plane Configuration, on page 9](#)

Configure cnBNG User Plane

Before you begin:

You must follow these guidelines for configuring cnBNG user plane:

- You must perform a complete reimage followed by a reboot of the router if you are switching between physical BNG to cnBNG, or the other way around.
- Ensure that the cnBNG package is installed and activated on the user plane. See the *Installing Cloud Native BNG User Plane Packages* chapter for detailed procedure.
- The system does not support the removal of configurations while active sessions are present. You must delete all active sessions and dissociate the CP-UP connection prior to any configuration change or commit replace procedure.

Configuration Procedure

You must perform the following tasks for the UP to spawn the NAL process, to establish connection with the CP, and to provision the subscriber requests.

Configure Basic User Plane Settings

The basic user plane configuration for cnBNG involves these high-level tasks:

- Configuring the server endpoints of CP to which UP can send PFCP or GTP-U messages to enable cnBNG on the router.
- Configuring a loopback interface for each VRF.
- Configuring a route tag for subscriber summary routes.
- Configuring the access-interface to enable IPoE and PPPoE subscribers.

The cnBNG endpoint configurations on the UP are delivered to the cnBNG SPA component for initiating connection with the CP.

Configuration Procedure

This section describes the steps for the basic user plane configuration, which include certain mandatory and optional configurations.

Mandatory Configurations:

- Specifying a unique name for the UP-server instance.
- Specifying the details of the UP server (such as IP address, GTP port, and PFCP port) to which the CP can send PFCP or GTP-U messages.
- Specifying the details of CP server to which the UP can send PFCP or GTP-U messages.
- Specifying the retry count for CP-UP association.
- Enabling secondary address programming.
- Specifying a name for the auto-loopback VRF.
- Configuring a loopback interface to associate with the above VRF.
- Specifying a primary address for the loopback interface.

Optional Configuration:

- Configuring a route summary tag for the routes to add in the routing table

Configuration Example

```
Router#configure
Router(config)#cnbng-nal location 0/RSP0/CPU0
Router(config-cnbng-nal-local)#hostidentifier asr9k-1
Router(config-cnbng-nal-local)#cp-server primary ipv4 198.51.100.1
Router(config-cnbng-nal-local)#up-server ipv4 192.0.2.1 gtp-port 15002 pfcf-port 15003 vrf
default
Router(config-cnbng-nal-local)#secondary-address-update-enable
Router(config-cnbng-nal-local)#cp-association retry-count 10
Router(config-cnbng-nal-local)#auto-loopback vrf test
Router(config-cnbng-nal-local-auto-loopback-vrf)#interface Loopback2
Router(config-cnbng-nal-local-auto-loopback-vrf-int)#primary-address 127.0.0.1
Router(config-cnbng-nal-local-auto-loopback-vrf-int)#exit
Router(config-cnbng-nal-local-auto-loopback-vrf)#exit
/* Auto-loopback configuration for default VRF */
Router(config-cnbng-nal-local)#auto-loopback vrf default
Router(config-cnbng-nal-local-auto-loopback-vrf)#interface Loopback1
Router(config-cnbng-nal-local-auto-loopback-vrf-int)#primary-address 10.0.0.1
```

```
Router(config-cnbng-nal-local-auto-loopback-vrf-int)#exit
Router(config-cnbng-nal-local-auto-loopback-vrf)#exit
Router(config-cnbng-nal-local)#route-summary tag 4
Router(config-cnbng-nal-local)#commit
```

Running Configuration

```
Router#show running-config cnbng-nal location 0/RSP0/CPU0
cnbng-nal location 0/RSP0/CPU0
  hostidentifier asr9k-1
  up-server ipv4 192.0.2.1 vrf default
    gtp-port 15002
    pfcf-port 15003
  cp-server primary ipv4 198.51.100.1
    secondary-address-update-enable
  cp-association retry-count 10
  auto-loopback vrf test
    interface Loopback2
      primary-address 127.0.0.1
    !
  !
  auto-loopback vrf default
    interface Loopback1
      primary-address 10.0.0.1
    !
  !
  route-summary tag 4
  !
```

Configure Access-Interface

This section describes how to configure the access-interface and to enable PPPoE on the cnBNG user plane.

Configuration Example

```
Router#configure
Router(config)#interface Bundle-Ether1.1
Router(config-subif)#ipv4 point-to-point
Router(config-subif)#ipv4 unnumbered Loopback1
Router(config-subif)#ipv6 enable
Router(config-subif)#encapsulation dot1q 1
Router(config-subif)#ipsubscriber
Router(config-cnbng-nal-ipsub)#ipv4 l2-connected
Router(config-cnbng-nal-ipsub-l2conn)#initiator dhcp
Router(config-cnbng-nal-ipsub-l2conn)#exit
Router(config-cnbng-nal-ipsub)#ipv6 l2-connected
Router(config-cnbng-nal-ipsub-ipv6-l2conn)#initiator dhcp
Router(config-cnbng-nal-ipsub-ipv6-l2conn)#exit
Router(config-cnbng-nal-ipsub)#exit

/* Enable PPPoE */
Router(config-subif)#pppoe enable
Router(config-subif)#commit
```

Running Configuration

```

Router#show running-config interface bel.1
interface Bundle-Ether1.1
  ipv4 point-to-point
  ipv4 unnumbered Loopback1
  ipv6 enable
  encapsulation dot1q 1
  ipsubscriber
  ipv4 l2-connected
    initiator dhcp
  !
  ipv6 l2-connected
    initiator dhcp
  !
  !
  pppoe enable
  !

```

Configure Loopback Interface

This section describes how to configure the loopback interface for cnBNG user plane.



Note You must not configure any IP address under loopback interface.

Configuration Example

```

Router#configure
Router(config)#interface loopback 2
Router(config-if)#ipv6 enable
Router(config-if)#commit

```

Running Configuration

```

Router#show running-config interface loopback 2
interface Loopback2
  ipv6 enable
  !

```

Configure DHCP

This section describes the steps to configure DHCP for cnBNG BNG user plane.

The basic DHCP configurations include these steps:

- Creating a cnBNG profile
- Assigning the cnBNG profile to access-interfaces

Configuration Example

```
Router(config)#dhcp ipv4
/* Create a cnBNG profile */
Router(config-dhcpv4)#profile cnbng_1 cnbng
Router(config-dhcpv4-cnbng-profile)#exit
/* Assign the cnBNG profile to access-interfaces */
Router(config-dhcpv4)#interface bundle-Ether 1.1 cnbng profile cnbng_1
Router(config-dhcpv4)#interface bundle-Ether 2.1 cnbng profile cnbng_1
Router(config-dhcpv4)#commit
```

Similarly, you can configure the DHCP IPv6 profiles.

Running Configuration

```
Router#show run dhcp ipv4
Wed Oct 14 16:48:56.814 UTC
dhcp ipv4
  profile cnbng_1 cnbng
  !
  interface Bundle-Ether1.1 cnbng profile cnbng_1
  interface Bundle-Ether2.1 cnbng profile cnbng_1
  !
```

```
Router#show run dhcp ipv6
Wed Oct 14 16:49:19.095 UTC
dhcp ipv6
  profile cnbng_1 cnbng
  !
  interface Bundle-Ether1.1 cnbng profile cnbng_1
  interface Bundle-Ether2.1 cnbng profile cnbng_1
  !
```

Configure Subscriber Gateway Address and Subnet Route

In cnBNG, the IP address management is more dynamic. Hence, the loopback interface for IPoE or PPPoE subscribers isn't provisioned in the user profile of the subscriber with static configuration. cnBNG user plane selects the loopback based on the subnet allocated to a loopback dynamically at cnBNG user plane.



Note For every VRF, one loopback must be present on the UP.

Consider this example,

```
On RSP0:
Tue Jul 28 05:55:13.015 UTC
cnbng-na1 location 0/RSP0/CPU0
hostidentifier asr9k-1
up-server ipv4 192.0.2.1 vrf default
cp-server primary ipv4 198.51.100.1
auto-loopback vrf default
  interface Loopback1
    primary-address 10.0.0.1
```

```

!
!
On RSP1:
Tue Jul 28 05:56:13.015 UTC
cnbng-nal location 0/RSP1/CPU0
hostidentifier asr9k-1
up-server ipv4 192.0.2.1 vrf default
cp-server primary ipv4 198.51.100.1
auto-loopback vrf default
  interface Loopback1
    primary-address 10.0.0.1
!
!

```

In this example, the CP assigns 10.11.12.0/24 as subnet, and 10.11.12.1/32 as gateway address to subscribers under the default VRF. This gateway address serves as the DHCPv4 server address for DHCPv4 OFFER or ACK messages. The *cnbng-nal* process uses Operations Center (OC) to configure this gateway address as secondary IP address on the loopback and route provision APIs to program the entry in the L3 routing table.



Note The system supports a maximum of 32 secondary IP addresses under an interface.

```

Router#show ipv4 interface loopback 1
Tue Jul 28 05:29:58.741 UTC
Loopback1 is Up, ipv4 protocol is Up
  Vrf is default (vrfid 0x60000000)
  Internet address is 10.0.0.1/32
  Secondary address 10.11.12.1/32

```

```

Router#show route vrf all ipv4 subscriber
A   10.11.12.0/24 [1/0] via 0.0.0.0, 00:10:29

```



Note The dynamic programming of the subnet (secondary gateway) under the loopback causes a major churn on the UP if large scale of active subscribers is present on the node. Hence, the secondary address programming is disabled, by default.

Enable Secondary Address Programming

It's mandatory to enable the secondary address programming on cnBNG user plane. To enable that, use the **secondary-address-update enable** command under the *cnbng-nal* configuration mode.

Configuration Example

```

Router#configure
Router(config)#cnbng-nal location 0/RSP0/CPU0
Router(config-cnbng-nal)#secondary-address-update enable
Router(config-cnbng-nal)#commit

```

Running Configuration

```
Router#show running-config cnbng-nal location 0/RSP0/CPU0
cnbng-nal location 0/RSP0/CPU0
  secondary-address-update enable
!
```

Configure Route Summary

This section describes the steps to configure route summary for the cnBNG user plane.

The NAL handles the following routes:

- Individual subscriber routes
- Summary routes for subscriber pool subnet

The subscriber routes are part of the subscriber provisioning message, which includes:

- WAN IP address (/32 or /128 subnet)
- LAN IP (prefix delegation)

The summary routes are for the subscriber pool subnet which are exported to the core network to download traffic towards the subscriber. On physical BNG, the subscriber pool subnets were configured as static routes and redistributed through BGP or IGP. With cnBNG and auto-loopback selection, these subnets for the subscribers are added dynamically to the loopback. Every time a new subscriber pool subnet is added to the loopback, the same is added to the RIB with the tag that is provided by the CP. If tag is '0', the NAL uses the tag configured under the cnbng-nal. Routes with this tag can be exported to the core using the Routing Protocol for Low-Power and Lossy Networks (RPLs).

To configure route summary, use the **route-summary** command under the cnbng-nal configuration mode.

Configuration Example

```
Router#configure
Router(config)#cnbng-nal location 0/RSP0/CPU0
Router(config-cnbng-nal)#route-summary tag 10
Router(config-cnbng-nal)#commit
```

Running Configuration

```
Router#show running-config cnbng-nal location 0/RSP0/CPU0
cnbng-nal location 0/RSP0/CPU0
  route-summary tag 10
!
```

After the first subnet is installed on NAL, the following routes are added to the system:

```
A 10.11.12.0/24 [1/0] via 0.0.0.0, 0d01h
```

Export Routes to Core Network

This section describes how to export routes to core network as part of enabling cnBNG user plane functionality.

Configuration Example

```
Router#configure
Router(config)#route-policy test-policy-cnbnng
Router(config-rpl)#if tag eq 10 then
Router(config-rpl-if)#set community (123:100)
Router(config-rpl-if)#done
Router(config-rpl-if)#endif
Router(config-rpl)#end-policy
Router(config)#commit

Router(config)#router ospf 10
Router(config-ospf)#vrf test-vrf-cnbnng
Router(config-ospf-vrf)#redistribute subscriber route-policy test-policy-cnbnng
Router(config-ospf-vrf)#commit
```

Running Configuration

```
Router#show running-config route-policy test-policy-cnbnng
route-policy test-policy-cnbnng

    if tag eq 10 then

        set community (123:100)

    done

endif

end-policy
!
```

```
Router#show running-config router ospf
router ospf 10
vrf test-vrf-cnbnng
redistribute subscriber route-policy test-policy-cnbnng
!
```

Configure ARP Scale Mode

This section describes the steps to configure ARP scale mode for the cloud-native BNG user plane.

To disable interface entry creation by ARP for each subscriber interface on the data plane (line cards), you must enable ARP scale mode for the subscriber using the **arp scale-mode-enable** command in subscriber configuration mode.

Configuration Example

```
Router#configure
Router(config)#subscriber
Router(config-subscriber)#arp scale-mode-enable
```



```
Router(config-subscriber)#commit
```

Running Configuration

```
Router#show running-config subscriber
Sat Aug 22 06:36:21.422 UTC
subscriber
arp scale-mode-enable
!
```

Verify cnBNG User Plane Configuration

This section describes the show commands to be executed on the router to verify cloud native BNG user plane configuration.

For details on cnBNG commands, see the *Cloud Native BNG Command Reference for Cisco ASR 9000 Series Routers*.

Verify cnBNG NAL Process Information

You can use the following commands to verify the NAL process information on cnBNG user plane.

- ```
Router#show cnbng-nal process-info location 0/RSP0/CPU0
Mon Aug 3 00:12:42.080 UTC

Location: 0/RSP0/CPU0

HA Pre_Init Role : PRIMARY
HA Role : PRIMARY
Restart-flag : FALSE
card_type : 0
Node-Id : 0
Disc-Hist File-logging : FALSE
Test-server config-enabled: FALSE

Proc-flags : 8000FFBF

OT Connection Status: UP
IM Connection Status: UP
IPv4 RIB Connection Status: UP
IPv6 RIB Connection Status: UP
SUBDB Connection Status: UP
```
- ```
Router#show cnbng-nal process-readiness
Mon Aug 3 00:12:00.778 UTC

Location: 0/RSP1/CPU0

NAL resync pending flags:
  Service Resync Pending
  Interface Resync Pending
  IPv4 Route Resync Pending
  IPv6 Route Resync Pending
```

```

SIR status: not ready

Location: 0/RSP0/CPU0
NAL resync pending flags:
    NONE

SIR status: ready

```

```

Router#show processes cnbng_nal
Fri Sep 11 09:22:45.139 UTC
    Job Id: 456
    PID: 1543

```

```

Router#show processes memory 1543

```

```

Fri Sep 11 09:24:12.398 UTC

```

JID	Text (KB)	Data (KB)	Stack (KB)	Dynamic (KB)	Process
456	992	1700604	200	19999	cnbng_nal

Verify Control Plane Connection Status

You can use the following command to verify the connection status of cnBNG control plane.

```

Router#show cnbng-nal cp connection status
Fri Feb 19 11:27:31.178 UTC

```

```

Location: 0/RSP0/CPU0

```

```

User-Plane configurations:
-----

```

```

IP           : 10.105.227.96
GTP Port     : 2152
PFCP Port    : 8805
VRF          : default

```

```

Control-Plane configurations:
-----

```

```

PRIMARY IP   : 10.84.102.235
GTP Port     : 2152
PFCP Port    : 8805

```

```

Association retry count: 10

```

```

Connection Status: Up
Connection Status time stamp: Thu Feb 11 12:46:19 2021

```

```

Connection Prev Status : Down
Connection Prev Status time stamp: Thu Feb 11 12:44:55 2021

```

```

Association status: Active
Association status time stamp: Thu Feb 11 12:46:18 2021

```

Verify Subscriber Information

You can use the following commands to verify subscriber information on the cnBNG user plane.

```

•
Router#show cnbng-nal subscriber access-interface bundle-Ether 1.1
Mon Aug 3 00:04:42.558 UTC
=====
Location: 0/RSP0/CPU0
=====

                Type                PPPoE                IPoE
                ====                =====                =====

Session Counts by State:
  initializing          0                    0
  connecting            0                    0
  connected             0                    0
  activated             0                    8000
  idle                  0                    0
  disconnecting        0                    0
  Total:                0                    8000

Session Counts by Address-Family:
  none                  0                    0
  ipv4                  0                    0
  ipv6                  0                    8000
  dual                  0                    0
  Total:                0                    8000

=====
Location: 0/RSP1/CPU0
=====

                Type                PPPoE                IPoE
                ====                =====                =====

Session Counts by State:
  initializing          0                    0
  connecting            0                    0
  connected             0                    0
  activated             0                    8000
  idle                  0                    0
  disconnecting        0                    0
  Total:                0                    8000

Session Counts by Address-Family:
  none                  0                    0
  ipv4                  0                    0
  ipv6                  0                    8000
  dual                  0                    0
  Total:                0                    8000

•
Router#show cnbng-nal subscriber all
Fri Sep 11 06:07:52.343 UTC
Codes: CN - Connecting, CD - Connected, AC - Activated,
      ID - Idle, DN - Disconnecting, IN - Initializing
    
```

CPID(hex) Ifhandle	Interface	State	Mac Address	Subscriber IP Addr / Prefix (Vrf)
1005ca0	BE2.500.ip2149474448	AC	0010.942e.3b00	13.0.92.160 (default) 0x225e60 1:4::5c9f (IANA) 2003:db0:0:5c9e::/64 (IAPD)
10053b2	BE2.500.ip2149466000	AC	0010.942e.3689	13.0.83.175 (default) 0xfdfef0 1:4::53b1 (IANA) 2003:db0:0:53b0::/64 (IAPD)
1004c81	BE2.600.ip2149013936	AC	0010.942e.5230	13.0.76.129 (default) 0x4079a0 1:4::4c80 (IANA) 2003:db0:0:4c7f::/64 (IAPD)
1004aaa	BE2.500.ip2149353232	AC	0010.942e.3205	13.0.74.169 (default) 0x5192e0 1:4::4aa9 (IANA) 2003:db0:0:4aa8::/64 (IAPD)
1004927	BE2.600.ip2149518576	AC	0010.942e.50b1	13.0.73.116 (default) 0x219ba0 1:4::4926 (IANA) 2003:db0:0:4925::/64 (IAPD)
10047e4	BE2.800.ip2149422928	AC	0010.9431.a7c7	13.0.71.228 (default) 0x41ff60 1:4::47e4 (IANA) 2003:db0:0:47e2::/64 (IAPD)
1004777	BE2.600.ip2149520224	AC	0010.942e.5021	13.0.71.115 (default) 0x41420 1:4::4776 (IANA) 2003:db0:0:4775::/64 (IAPD)
1003a6d	BE2.800.ip2149369728	AC	0010.9431.a3a1	13.0.58.105 (default) 0x141360 1:4::3a6d (IANA) 2003:db0:0:3a6a::/64 (IAPD)
10038b7	BE2.600.ip2149362240	AC	0010.942e.4bb2	13.0.56.178 (default) 0x259aa0 1:4::38b6 (IANA) 2003:db0:0:38b5::/64 (IAPD)
10028ba	BE2.500.ip2149210768	AC	0010.942e.2873	13.0.40.185 (default) 0x129620

```

100247b BE2.600.ip2149396320 AC 0010.942e.46a3 13.0.36.113 (default) 0x4b8e0
1:4::28b9 (IANA)
2003:db0:0:28b8::/64 (IAPD)

100207a BE2.500.ip2149356496 AC 0010.942e.2663 13.0.32.117 (default) 0x1a9460
1:4::2471 (IANA)
2003:db0:0:2470::/64 (IAPD)

1001d3f BE2.600.ip2149251360 AC 0010.942e.44d4 13.0.29.61 (default) 0xcc760
1:4::2079 (IANA)
2003:db0:0:2078::/64 (IAPD)
    
```

```

Router#show cnbng-nal subscriber all summary
Sun Aug 2 16:26:44.281 UTC
    
```

```

Location: 0/RSP0/CPU0
    
```

```

=====
Type          PPPoE        IPoE
=====
Session Counts by State:
initializing  0            0
connecting   0            0
connected    0            0
activated    0            130
idle         0            0
disconnecting 0            0
Total:       0            130

Session Counts by Address-Family:
none         0            0
ipv4         0            130
ipv6         0            0
dual         0            0
Total:       0            130
    
```

```

Location: 0/RSP0/CPU0
    
```

```

Type          PPPoE        IPoE
=====
    
```

```

Session Counts by State:
initializing  0            0
    
```

Verify Subscriber Information

```

connecting      0      0
connected       226     0
activated       31774    0
idle            0      0
disconnecting   0      0
Total:          32000  0

```

Session Counts by Address-Family:

```

none           226     0
ipv4           7774    0
ipv6           0      0
dual           24000   0
Total:         32000  0

```

```

•
Router#show cnbng-nal subscriber all detail
Mon Aug  3 00:00:14.624 UTC
Location: 0/2/CPU0
=====
Location: 0/RSP1/CPU0
=====
Interface:          Bundle-Ether1.1.ip2148413040
UPID:               0x800e2e70
CPID:               0x0100918f
PPPOE Session Id:  0x0000
Type:               IPoE
IPv4 Address:       0.0.0.0
IPv4 Framed Route:
  Prefix:           0.0.0.0/0
  Next Hop:         0.0.0.0
  Tag:              0
IPv6 IANA Address:  1:5::345c
IPv6 IAPD Prefix:  2004:cd0:0:188d::/64
CPE link local Address:  ::
IPv6 Framed Route:
  Prefix:           ::/0
  Next Hop:         ::
  Tag:              0
IPv6 State:         UP, Sat Jul 25 02:09:55 2020
Mac Address:        5065.aaab.d864
Inner VLAN ID:     Not Set
Outer VLAN ID:     100
Outer VLAN Cos:    0
Outer VLAN DEI:    1
Created:           Sat Jul 25 02:09:54 2020
State:              Activated
Ifhandle:          0x000b75a0
VRF:               default
Access-interface:  Bundle-Ether1.1
Attribute List:    0x5556aed3f878

```

```

1: ipv6-enable      len= 4  value= 1(1)
2: ipv4-unnumbered len= 9  value= Loopback1
3: strict-rpf      len= 4  value= 1(1)
4: ipv6-strict-rpf len= 4  value= 1(1)
5: ipv4-icmp-unreachable len= 4  value= 1(1)
6: ipv6-unreachable len= 4  value= 1(1)
7: ipv4-mtu        len= 4  value= 1500(5dc)
8: ipv6-mtu        len= 4  value= 1500(5dc)
Session Accounting:      enabled
Interim Interval:       1800 secs
Last interim timestamp:  Sun Aug  2 23:39:46 2020
Interim fail count:     None
Last interim failed reason: NA
Last stats:
  BytesIn: 0
  BytesOut: 384570
  BytesInGiga: 0
  BytesOutGiga: 0
Feature IDs activated :
  0x800e2e71
  0x800e2e72
    
```

Router#show cnbng-nal subscriber type ipoe summary

Mon Aug 3 00:06:15.032 UTC

=====
Location: 0/RSP0/CPU0
=====

Type	PPPoE	IPoE
====	=====	=====
Session Counts by State:		
initializing	0	0
connecting	0	0
connected	0	0
activated	0	8000
idle	0	0
disconnecting	0	0
Total:	0	8000

Session Counts by Address-Family:		
none	0	0
ipv4	0	0
ipv6	0	8000
dual	0	0
Total:	0	8000

=====
Location: 0/RSP1/CPU0
=====

Type	PPPoE	IPoE
====	=====	=====
Session Counts by State:		
initializing	0	0
connecting	0	0
connected	0	0
activated	0	8000
idle	0	0
disconnecting	0	0
Total:	0	8000

```

Session Counts by Address-Family:
      none          0          0
      ipv4          0          0
      ipv6          0          8000
      dual          0          0
      Total:       0          8000
    
```

Router#

•

```

Router#show cnbng-nal subscriber type pppoe summary
Mon Aug 3 00:06:15.032 UTC
=====
Location: 0/RSP0/CPU0
=====
    
```

Type	PPPoE	IPoE
====	=====	=====
Session Counts by State:		
initializing	0	0
connecting	0	0
connected	0	0
activated	31031	0
idle	0	0
disconnecting	0	0
Total:	31031	0

```

Session Counts by Address-Family:
      none          0          0
      ipv4          31031       0
      ipv6          0          0
      dual          0          0
      Total:       31031       0
    
```

Router#

•

```

Router#show cnbng-nal subscriber disconnect-history unique
Mon Aug 3 00:07:22.716 UTC
Location: 0/RSP1/CPU0
    
```

Count	Last Interface	Disconnected Reason	Last Time Disconnected
Location: 0/1/CPU0			
Location: 0/RSP0/CPU0			
Count	Last Interface	Disconnected Reason	Last Time Disconnected
35494	Bundle-Ether1.1.ip2148328848	Disconnect by CP	Sat Jul 25 02:04:55 2020
14154	Bundle-Ether1.1.ip2148324096	Disconnect by clear CLI	Sat Jul 25 02:05:48 2020
2777	Bundle-Ether1.1.ip2148194512	Disconnect due to create failure	Sat Jul 25 01:38:29 2020

•

```

Router#show cnbng-nal subscriber disconnect-history last location
Mon Aug 3 00:08:42.655 UTC
    
```



```

Disconnect-reason:          Disconnect by clear CLI
Disconnect-timestamp:       Sat Jul 25 02:05:48 2020
  Message Txn ID: 55663
  Session Txn ID: 1
  Failed at: Sat Jul 25 01:57:03 2020
  Feature Mask: 0x0
  SVM State: 0
  IPSUB flags: 0x600a200
  Pending callback: 0x2
  Data:

Interface:                  Bundle-Ether1.1.ip2148324096
UPID:                       0x800cd300
CPID:                       0x01007bd8
PPPOE Session Id:          0x0000
Type:                       IPoE
IPv4 Address:               0.0.0.0
IPv4 Framed Route:
  Prefix:                   0.0.0.0/0
  Next Hop:                 0.0.0.0
  Tag:                      0
IPv6 IANA Address:         1:5::3de5
IPv6 IAPD Prefix:          2004:cd0:0:616::/64
CPE link local Address:    ::
IPv6 Framed Route:
  Prefix:                   ::/0
  Next Hop:                 ::
  Tag:                      0
IPv6 State:                 UP, Sat Jul 25 01:57:03 2020
Mac Address:                5065.aaab.cfbb
Inner VLAN ID:              Not Set
Outer VLAN ID:              100
Outer VLAN Cos:             0
Outer VLAN DEI:             1
Created:                    Sat Jul 25 02:05:48 2020
State:                      Init
Ifhandle:                   0x000323a0
VRF:                        default
Access-interface:           Bundle-Ether1.1
  Attribute List: 0x559125764408
1:  ipv6-enable      len= 4  value= 1(1)
2:  ipv4-unnumbered len= 9  value= Loopback1
3:  strict-rpf      len= 4  value= 1(1)
4:  ipv6-strict-rpf len= 4  value= 1(1)
5:  ipv4-icmp-unreachable len= 4  value= 1(1)
6:  ipv6-unreachable len= 4  value= 1(1)
7:  ipv4-mtu        len= 4  value= 1500(5dc)
8:  ipv6-mtu        len= 4  value= 1500(5dc)
Session Accounting:         enabled
Interim Interval:           1800 secs
Last interim timestamp:     Sat Jul 25 02:05:47 2020
Interim fail count:         None
Last interim failed reason:  NA
Last stats:
  BytesIn: 0
  BytesOut: 540
  BytesInGiga: 0
  BytesOutGiga: 0
Feature IDs activated :
  0x800cd301
  0x800cd302

[Event History]
UPID: 0x800cd300

```

```

| Event Name           | Time Stamp           | S, M
| Create               | Jul 25 01:57:02.999679 | 0, 0
| New Session Request  | Jul 25 01:57:02.999686 | 0, 0
| Interface create     | Jul 25 01:57:02.999823 | 0, 0
| SVM create           | Jul 25 01:57:03.018268 | 0, 0
| UP Install(req)     | Jul 25 01:57:03.018321 | 0, 0
| UP Install(CB)      | Jul 25 01:57:03.019220 | 0, 0
| Last Assoc(req)     | Jul 25 01:57:03.019232 | 0, 0
| Last Assoc(CB)     | Jul 25 01:57:03.020160 | 0, 1
| Produce done(req)   | Jul 25 01:57:03.020233 | 0, 0
| IPv4 Caps Up        | Jul 25 01:57:03.188034 | 0, 0
| IPv6 Caps Up        | Jul 25 01:57:03.233210 | 0, 0
| Init data req       | Jul 25 01:57:03.254482 | 0, 1
| Init data cb        | Jul 25 01:57:03.369027 | 0, 1
| Client Session up   | Jul 25 01:57:03.379152 | 0, 0
| Produce done        | Jul 25 01:57:03.977629 | 0, 0
| IPv6 Up             | Jul 25 01:57:03.977643 | 0, 0
| Session up notified | Jul 25 01:57:03.977650 | 0, 0
| Stats start         | Jul 25 01:57:03.977841 | 0, 0
| Disconnect notified | Jul 25 02:05:47.548202 | 0, 0
| Disconnect ack      | Jul 25 02:05:47.550293 | 0, 0
| IPv4 Caps Down     | Jul 25 02:05:47.652232 | 0, 0
| IPv6 Caps Down     | Jul 25 02:05:47.652333 | 0, 0
| Final stats         | Jul 25 02:05:47.753805 | 0, 0
| SVM delete          | Jul 25 02:05:47.780713 | 0, 0
| SVM cleanup         | Jul 25 02:05:48.283050 | 0, 0
Help: S - Sticky Event, M - Multiple Occurrence

```

```
Router#show cnbng-nal subscriber fadb
```

```
Mon Aug 3 00:03:12.858 UTC
```

```
Location: 0/RSP1/CPU0
```

```
=====
```

```

UPID:          0x800ec810
Service-ID:    0x04000003  Service-Name: JHV_VOICE
Feature-ID:    0x800ec812
Attribute List: 0x559cba6d0008
1: feature-acct-bitmask len= 4 value= 805306413(3000002d)
Accounting:                    enabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

```

```

UPID:          0x800e9470
Service-ID:    0x04000003  Service-Name: JHV_VOICE
Feature-ID:    0x800e9472
Attribute List: 0x559cba6d0008
1: feature-acct-bitmask len= 4 value= 805306413(3000002d)
Accounting:                    enabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

```

```

UPID:          0x800e7ee0
Service-ID: 0x04000003 Service-Name: JHV_VOICE
Feature-ID: 0x800e7ee2
Attribute List: 0x559cba6d0008
1: feature-acct-bitmask len= 4 value= 805306413(3000002d)
Accounting:          enabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

UPID:          0x800e16e0
Service-ID: 0x04000004 Service-Name: LIVE_TV
Feature-ID: 0x800e16e1
Attribute List: 0x559cba6d0008
1: feature-acct-bitmask len= 4 value= 0(0)
Accounting:          disabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

UPID:          0x800dda90
Service-ID: 0x04000003 Service-Name: JHV_VOICE
Feature-ID: 0x800dda91
Attribute List: 0x559cba6d0008
1: feature-acct-bitmask len= 4 value= 805306413(3000002d)
Accounting:          enabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

UPID:          0x800dd4e0
Service-ID: 0x04000004 Service-Name: LIVE_TV
Feature-ID: 0x800dd4e1
Attribute List: 0x559cba6d0008
1: feature-acct-bitmask len= 4 value= 0(0)
Accounting:          disabled
Interim fail count: None
Last interim failed reason: None
Last stats:
  BytesIn: 0
  BytesOut: 0
  BytesInGiga: 0
  BytesOutGiga: 0

```

Verify cnBNG NAL Counters

You can use the following commands to verify various NAL counters on the cnBNG user plane:

```
Router#show cnbng-nal counters type all
Sun Aug  2 20:42:49.548 UTC
```

```
Location: 0/RSP0/CPU0
```

```
Subscriber Counters
-----
```

Counter name	Value
=====	=====
INTF Delete	500
IPv4 caps down	500
IPv6 caps down	500
IPv4 Rou del	500
IPv6 Rou del	500
Blkdis q empty	1
DB cache hit	17113

```
Error Counters
-----
```

Counter name	Value
=====	=====

```
Accounting Counters
-----
```

Counter name	Value
=====	=====
Sess Stop req	500
Feat Stop req	500
Stop req	3000
Stop cb	3000
Final cb	3000
Feat Final cb	500
Sess Final cb	2500

```
SVM Counters
-----
```

Counter name	Value
=====	=====
Sess deleted	500
Delete CB	500
Feat deleted	1000
Cleanup	500
Sess stats, before svm	500
Feat stats, before svm	500

```
SPA Counters
-----
```

Counter name	Value
=====	=====
SPA Delete Req	500
SPA Update Req	500
Sub Delete Res	500
Sub Update Res	500
Blkdic adm more	39
GTPu pkt sent	1000
PFCP pkt sent	1463
GTPu pkt punt	500
PFCP pkt punt	1463

```
DHCPv4 pkt punt          500
DHCPv6 pkt punt          500
DHCPv6 pkt inj           500
Alloc count              3463
Free count               3463
Mutex lock               6741
Mutex unlock            6741
Timer start              463
Timer expiry            463
Sub Update IPOE OK       500
Sub Delete IPOE OK       500
```

CP Recon Counters

```
Counter name              Value
=====
```

Histogram/API Performance Stats

API name	1ms	10ms	100ms	1s	5s	10s	20s	50s	100s
=====	====	====	====	==	==	====	====	====	====
Per trans	410	90	0	500	0	0	0	0	0
Sub Create	0	0	0	0	0	0	0	0	0
Sub Update	445	55	0	0	0	0	0	0	0
Sub Delete	0	0	0	500	0	0	0	0	0
IPOE Int Crt	0	0	0	0	0	0	0	0	0
IPOE Int Upd	0	0	0	0	0	0	0	0	0
IPOE Int Del	0	0	0	500	0	0	0	0	0
PPPOE Int Crt	0	0	0	0	0	0	0	0	0
PPPOE Int Upd	0	0	0	0	0	0	0	0	0
PPPOE Int Del	0	0	0	0	0	0	0	0	0
Sess Create	0	0	0	0	0	0	0	0	0
Sess Update	0	0	0	0	0	0	0	0	0
Sess Delete	0	0	10	490	0	0	0	0	0
V4 RT Inst	0	0	0	0	0	0	0	0	0
V4 RT Del	0	6	320	174	0	0	0	0	0
V4 FR Inst	0	0	0	0	0	0	0	0	0
V4 FR Del	0	0	0	0	0	0	0	0	0
V6 RT Inst	0	0	0	0	0	0	0	0	0
V6 RT Del	0	6	310	184	0	0	0	0	0
V6 PD RT Inst	0	0	0	0	0	0	0	0	0
V6 PD RT Del	0	0	0	0	0	0	0	0	0
V6 FR Inst	0	0	0	0	0	0	0	0	0
V6 FR Del	0	0	0	0	0	0	0	0	0
CDM Lookup	0	0	0	0	0	0	0	0	0
CDM Insert	0	0	0	0	0	0	0	0	0
CDM Update	1469	31	0	0	0	0	0	0	0
Eval Lookup	0	0	0	0	0	0	0	0	0

```
Router#show cnbng-nal counters type all | beg SPA LIB
Sun Aug  2 20:44:07.902 UTC
```

SPA LIB Counters

```
Counter name              Value
=====
```

pfcp_rx_counter	6899
pfcp_tx_counter	6900
gtpu_tx_counter	9048
gtpu_rx_counter	7510

```

pfcpl_keepalive_tx_counter      891
pfcpl_keepalive_rx_counter      890

```

```

SPA API counters
-----

```

```

Router#show cnbng-nal counters type spa
Sun Aug  2 20:42:13.703 UTC

```

```

Location: 0/RSP0/CPU0

```

```

SPA Counters
-----

```

Counter name	Value
=====	=====
SPA Delete Req	500
SPA Update Req	500
Sub Delete Res	500
Sub Update Res	500
Blkdic adm more	39
GTPu pkt sent	1000
PFCP pkt sent	1461
GTPu pkt punt	500
PFCP pkt punt	1461
DHCPv4 pkt punt	500
DHCPv6 pkt punt	500
DHCPv6 pkt inj	500
Alloc count	3461
Free count	3461
Mutex lock	6727
Mutex unlock	6727
Timer start	461
Timer expiry	461
Sub Update IPOE OK	500
Sub Delete IPOE OK	500