

Implementing Traffic Storm Control under a VPLS Bridge

Traffic storm control provides Layer 2 port security under a Virtual Private LAN Services (VPLS) bridge by preventing excess traffic from disrupting the bridge. This module describes how to implement traffic storm control.

Traffic storm control can be configured at the bridge domain level. Support has been added to allow storm control rate to be configured in kbps. For more information about the Traffic Storm Control feature, see the *Implementing Traffic Storm Control under a VPLS Bridge* module in the *System Security Configuration Guide for Cisco ASR 9000 Series Routers*. For complete command reference of Traffic Storm Control commands, see the *Traffic Storm Control Commands* chapter in the *System Security Command Reference for Cisco ASR 9000 Series Routers*.

- Prerequisites for Implementing Traffic Storm Control, on page 1
- Restrictions for Implementing Traffic Storm Control, on page 1
- Information About Implementing Traffic Storm Control, on page 2
- How to Configure Traffic Storm Control, on page 4
- Configuration Examples for Traffic Storm Control, on page 7
- Additional References, on page 10

Prerequisites for Implementing Traffic Storm Control

The following prerequisites are required before implementing traffic storm control:

- The network must be configured with a VPLS bridge domain in an MPLS Layer 2 VPN.
- You must be in a user group associated with a task group that includes the proper task IDs. The command reference guides include the task IDs required for each command. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Restrictions for Implementing Traffic Storm Control

In Cisco IOS XR software Release 3.7.0 FCI, the following restrictions apply:

- Traffic storm control is not supported directly on the bridge domain. The feature must be configured on Ethernet flow points (EFPs) under the bridge domain, using bridge domain submodes. The supported submodes are those used for configuring ACs and access PWs.
- Traffic storm control is not supported for aggregated EFPs (bundles).
- Traffic storm control is not supported for forwarding pseudowires (VFI PWs).
- Immediately after an route switch processor (RSP) failover, traffic storm control drop counters might not be accurate. This loss of counter information after a failover is expected behavior for Cisco IOS XR software counters.
- No alarms are generated when packets are dropped.

Information About Implementing Traffic Storm Control

To implement traffic storm control, you should understand the following concepts:

Understanding Traffic Storm Control

A traffic storm occurs when packets flood a VPLS bridge, creating excessive traffic and degrading network performance. Traffic storm control prevents VPLS bridge disruption by suppressing traffic when the number of packets reaches configured threshold levels. You can configure separate threshold levels for different types of traffic on each port under a VPLS bridge.

Traffic storm control monitors incoming traffic levels on a port and drops traffic when the number of packets reaches the configured threshold level during any 1-second interval. The 1-second interval is set in the hardware and is not configurable. The number of packets allowed to pass during the 1-second interval is configurable, per port, per traffic type. During this interval, it compares the traffic level with the traffic storm control level that the customer configures.

When the incoming traffic reaches the traffic storm control level configured on the bridge port, traffic storm control drops traffic until the end of storm control interval.

Traffic storm control level can be configured separately for these traffic types:

- Broadcast Traffic
- Multicast Traffic
- Unknown Unicast Traffic

The thresholds are configured using a packet-per-second (pps) rate. When the number of packets of the specified traffic type reaches the threshold level on a port, the port drops any additional packets of that traffic type for the remainder of the 1-second interval. At the beginning of a new 1-second interval, traffic of the specified type is allowed to pass on the port.

Traffic storm control has little impact on router performance. Packets passing through ports are counted regardless of whether the feature is enabled. Additional counting occurs only for the drop counters, which monitor dropped packets.

No alarms are produced when packets are dropped.



• Bridge Protocol Data Unit (BPDU) packets are not filtered through the storm control feature.

- Tunneled BPDU packets are filtered as they are forwarded into bridge.
- Traffic storm control is applied to only forwarded packets in the system.

Traffic Storm Control Defaults

- The traffic storm control feature is disabled by default. It must be explicitly enabled on each port for each traffic type.
- The traffic storm control monitoring interval is set in the hardware and is not configurable. On Cisco ASR 9000 Series Router, the monitoring interval is always 1 second.

Supported Traffic Types for Traffic Storm Control

On each VPLS bridge port, you can configure up to three storm control thresholds—one for each of the supported traffic types. If you do not configure a threshold for a traffic type, then traffic storm control is not enabled on that port or interface for that traffic type.

The supported traffic types are:

- Broadcast traffic—Packets with a packet destination MAC address equal to FFFF.FFFF.FFFF.
- Multicast traffic—Packets with a packet destination MAC address not equal to the broadcast address, but with the multicast bit set to 1. The multicast bit is bit 0 of the most significant byte of the MAC address.
- Unknown unicast traffic—Packets with a packet destination MAC address not yet learned.

Traffic storm control does not apply to bridge protocol data unit (BPDU) packets. All BPDU packets are processed as if traffic storm control is not configured.

Supported Ports for Traffic Storm Control

In Cisco IOS XR software Release 3.7.0 FCI, you can configure traffic storm control on the following components under a VPLS bridge domain:

- VPLS bridge domain ACs
- VPLS bridge domain access PWs

Traffic Storm Control Thresholds

Traffic storm control thresholds are configured at a packet-per-second rate. A threshold is the number of packets of the specified traffic type that can pass on a port during a 1-second interval. Valid values for traffic storm control thresholds are integers from 1 to 160000. The maximum value would permit about 19 percent of bandwidth to pass per second on a 10-Gbps link, assuming a 1500-byte packet size.

Traffic Storm Control Drop Counters

Traffic storm control counts the number of packets dropped per port and traffic type. The drop counters are cumulative until you explicitly clear them. Use the **show l2vpn bridge-domain detail** and **show l2vpn forwarding detail** commands to see drop counts. Use the **clear l2vpn forwarding counters** command to clear drop counters.

How to Configure Traffic Storm Control

This section describes how to configure traffic storm control:

Enabling Traffic Storm Control on an AC under a Bridge

Perform this task to enable traffic storm control on an AC under a VPLS bridge. The following task shows how to enable traffic storm control on an AC that is a VLAN on an Ethernet interface.

Note

To disable traffic storm control, navigate to the submode you were in when you enabled the feature, and issue the **no** form of the command.

SUMMARY STEPS

- 1. configure
- **2.** l2vpn
- **3.** bridge group bridge-group-name
- 4. bridge-domain bridge-domain-name
- **5.** interface interface-name
- 6. storm-control {broadcast | multicast | unknown-unicast} pps packet-threshold
- 7. commit
- 8. show l2vpn bridge-domain bd-name bridge-name detail

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure	
Step 2	l2vpn	Enters L2 VPN configuration mode.
	Example:	
	RP/0/0/CPU0:router(config)# l2vpn RP/0/0/CPU0:router(config-l2vpn)#	
Step 3	bridge group bridge-group-name	Enters L2 VPN bridge group configuration mode.
	Example:	

	Command or Action	Purpose
	RP/0/0/CPU0:router(config-l2vpn)# bridge group cscc RP/0/0/CPU0:router(config-l2vpn-bg)#	
Step 4	bridge-domain bridge-domain-name Example: RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain	Enters L2 VPN bridge domain configuration mode.
	abc RP/0/0/CPU0:router(config-12vpn-bg)# bridge-domain RP/0/0/CPU0:router(config-12vpn-bg-bd)#	
Step 5	interface interface-name Example:	Names an AC under the bridge domain. In this case, the AC is a VLAN on an Ethernet interface.
	<pre>RP/0/0/CPU0:router(config-l2vpn-bg-bd)# interface GigabitEthernet0/1/0/0.100 RP/0/0/CPU0:router(config-l2vpn-bg-bd-ac)#</pre>	
Step 6	<pre>storm-control {broadcast multicast unknown-unicast} pps packet-threshold Example:</pre>	Enables traffic storm control on this interface for the specified traffic type. Repeat this command for each traffic type.
	RP/0/0/CPU0:router(config-l2vpn-bg-bd-ac)# storm-control broadcast pps 4500 RP/0/0/CPU0:router(config-l2vpn-bg-bd-ac)# storm-control multicast pps 500 RP/0/0/CPU0:router(config-l2vpn-bg-bd-ac)#	The <i>packet-threshold</i> is a packet per second rate and must be an integer between 1 and 160000. It specifies the number of packets that will be allowed to pass on the interface for the specified traffic type during a 1-second interval.
Step 7	commit	
Step 8	show l2vpn bridge-domain bd-name <i>bridge-name</i> detail Example:	Displays storm control configuration.
	RP/0/0/CPU0:router# show 12vpn bridge-domain bd-name abc detail	

Enabling Traffic Storm Control on a PW under a Bridge

Perform this task to enable traffic storm control on a pseudowire under a VPLS bridge.

Note

To disable traffic storm control, navigate to the submode you were in when you enabled the feature, and issue the **no** form of the command.

SUMMARY STEPS

- 1. configure
- **2.** l2vpn
- 3. bridge group bridge-group-name

- 4. bridge-domain bridge-domain-name
- 5. neighbor address pw-id id
- 6. storm-control {broadcast | multicast | unknown-unicast} pps packet-threshold
- 7. commit
- 8. show l2vpn bridge-domain bd-name bridge-name detail

DETAILED STEPS

	Command or Action	Purpose	
Step 1	configure		
Step 2	l2vpn	Enters L2 VPN configuration mode.	
	Example:		
	RP/0/0/CPU0:router(config)# 12vpn RP/0/0/CPU0:router(config-12vpn)#		
Step 3	bridge group bridge-group-name	Enters L2 VPN bridge group configuration mode.	
	Example:		
	RP/0/0/CPU0:router(config-l2vpn)# bridge group cscc RP/0/0/CPU0:router(config-l2vpn-bg)#		
Step 4	bridge-domain bridge-domain-name	Enters L2 VPN bridge domain configuration mode.	
	Example:		
	RP/0/0/CPU0:router(config-l2vpn-bg)# bridge-domain abc RP/0/0/CPU0:router(config-l2vpn-bg-bd)#		
Step 5	neighbor address pw-id id	Names an access pseudowire under the bridge domain.	
	Example:	Note You cannot apply storm control on a forwarding PW (a PW under a VFI).	
	<pre>RP/0/0/CPU0:router(config-l2vpn-bg-bd)# neighbor 1.1.1.1 pw-id 100 RP/0/0/CPU0:router(config-l2vpn-bg-bd-pw)#</pre>		
Step 6	storm-control {broadcast multicast unknown-unicast} pps packet-threshold	Enables traffic storm control on this pseudowire for the specified traffic type. Repeat this command for each traffic	
	Example:	type.	
	RP/0/0/CPU0:router(config-l2vpn-bg-bd-pw)# storm-control broadcast pps 4500 RP/0/0/CPU0:router(config-l2vpn-bg-bd-pw)# storm-control multicast pps 500 RP/0/0/CPU0:router(config-l2vpn-bg-bd-pw)#	The <i>packet-threshold</i> is a packet per second rate and must be an integer between 1 and 160000. It specifies the number of packets that will be allowed to pass on the interface for the specified traffic type during a 1-second interval.	
Step 7	commit		

	Command or Action	Purpose
Step 8		Displays storm control configuration settings for the named
	Example:	bridge domain. This command also displays the drop counter values for each configured storm control instance
_	RP/0/0/CPU0:router# show l2vpn bridge-domain bd-name csco detail	

Clearing Traffic Storm Control Drop Counters

Perform this task to reset traffic storm control drop counters to zero.

SUMMARY STEPS

1. clear l2vpn forwarding counters

DETAILED STEPS

	Command or Action	Purpose	
Step 1	clear 12vpn forwarding counters	Clears 12vpn forwarding counters, including storm control	
	Example:	drop counters.	
	RP/0/0/CPU0:router# clear l2vpn forwarding counters		

Configuration Examples for Traffic Storm Control

This section includes the following configuration examples:

Configuring Traffic Storm Control on an AC: Example

The following example shows broadcast and multicast storm control configuration on an AC under a VPLS bridge.

RP/0/RSP0/CPU0:router# show run

```
[lines deleted]
```

```
bridge group 215
bridge-domain 215
mtu 9000
interface GigabitEthernet0/1/0/3.215
storm-control multicast pps 500
storm-control broadcast pps 4500
!
[lines deleted]
```

```
RP/0/RSP0/CPU0:router# show l2vpn bridge-domain bd-name 215 detail
Bridge group: 215, bridge-domain: 215, id: 3, state: up, ShgId: 0, MSTi: 0
```

```
MAC learning: enabled
 MAC withdraw: disabled
 Flooding:
   Broadcast & Multicast: enabled
   Unknown unicast: enabled
 MAC aging time: 300 s, Type: inactivity
 MAC limit: 4000, Action: none, Notification: syslog
 MAC limit reached: no
 Security: disabled
 Split Horizon Group: none
 DHCPv4 snooping: disabled
 IGMP Snooping profile: none
 Bridge MTU: 9000
 Filter MAC addresses:
 ACs: 2 (2 up), VFIs: 1, PWs: 1 (1 up)
 List of ACs:
   AC: GigabitEthernet0/1/0/3.215, state is up
     Type VLAN; Num Ranges: 1
    vlan ranges: [100, 100]
     MTU 9008; XC ID 0x440005; interworking none; MSTi 0 (unprotected)
     MAC learning: enabled
     Flooding:
       Broadcast & Multicast: enabled
       Unknown unicast: enabled
     MAC aging time: 300 s, Type: inactivity
     MAC limit: 4000, Action: none, Notification: syslog
     MAC limit reached: no
     Security: disabled
     Split Horizon Group: none
     DHCPv4 snooping: disabled
     IGMP Snooping profile: none
     Storm Control:
      Broadcast: enabled(4500)
      Multicast: enabled(500)
      Unknown unicast: disabled
     Static MAC addresses:
     Statistics:
       packet totals: receive 36728, send 31
       byte totals: receive 2791284, send 2318
       Storm control drop counters:
         packet totals: broadcast 0, multicast 0, unknown unicast 0
         byte totals: broadcast 0, multicast 0, unknown unicast 0
[lines deleted]
```

Configuring Traffic Storm Control on an Access PW: Example

The following example shows broadcast and multicast storm control configuration on an access PW under a VPLS bridge.

```
RP/0/RSP0/CPU0:router# show run
l2vpn
bridge group bg_storm_pw
bridge-domain bd_storm_pw
interface Bundle-Ether101
!
neighbor 10.10.30.30 pw-id 1
storm-control unknown-unicast pps 120
storm-control multicast pps 110
storm-control broadcast pps 100
!
```

1

```
I.
RP/0/RSP0/CPU0:router# show l2vpn bridge-domain group bg_storm_pw detail
Bridge group: bg storm pw, bridge-domain: bd storm pw, id: 2, state: up, ShgId: 0, MSTi: 0
 MAC learning: enabled
 MAC withdraw: disabled
 Flooding:
   Broadcast & Multicast: enabled
   Unknown unicast: enabled
 MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
 MAC limit reached: no
  Security: disabled
  Split Horizon Group: none
 DHCPv4 snooping: disabled
 IGMP Snooping profile: none
 Bridge MTU: 1500
 Filter MAC addresses:
 ACs: 1 (1 up), VFIs: 0, PWs: 1 (1 up)
 List of ACs:
   AC: Bundle-Ether101, state is up
     Type Ethernet
     MTU 1500; XC ID 0xfffc0003; interworking none
     MAC learning: enabled
     Flooding:
       Broadcast & Multicast: enabled
       Unknown unicast: enabled
     MAC aging time: 300 s, Type: inactivity
     MAC limit: 4000, Action: none, Notification: syslog
     MAC limit reached: no
     Security: disabled
     Split Horizon Group: none
     DHCPv4 snooping: disabled
     IGMP Snooping profile: none
     Storm Control: disabled
     Static MAC addresses:
     Statistics:
       packets: received 0, sent 5205
       bytes: received 0, sent 645420
     Storm control drop counters:
       packets: broadcast 0, multicast 0, unknown unicast 0
       bytes: broadcast 0, multicast 0, unknown unicast 0
  List of Access PWs:
    PW: neighbor 10.10.30.30, PW ID 1, state is up ( established )
      PW class not set, XC ID 0xfffc0006
     Encapsulation MPLS, protocol LDP
     PW type Ethernet, control word disabled, interworking none
     PW backup disable delay 0 sec
     Sequencing not set
    PW Status TLV in use
       MPLS
                   Local
                                                  Remote
                ____ _____
        _____
       Label
                   16001
                                                  16001
       Group ID
                   0x2
                                                  0x2
       Interface
                   Access PW
                                                  Access PW
       MTU
                    1500
                                                  1500
       Control word disabled
                                                  disabled
       PW type Ethernet
                                                  Ethernet
       VCCV CV type 0x2
                                                  0x2
                    (LSP ping verification)
                                                  (LSP ping verification)
       VCCV CC type 0x6
                                                  0x6
                    (router alert label)
                                                  (router alert label)
                    (TTL expiry)
                                                  (TTL expiry)
```

```
_____
Incoming Status (PW Status TLV):
 Status code: 0x0 (Up) in Notification message
Outgoing Status (PW Status TLV):
 Status code: 0x0 (Up) in Notification message
Create time: 16/12/2008 00:06:08 (01:00:22 ago)
Last time status changed: 16/12/2008 00:35:02 (00:31:28 ago)
 MAC withdraw message: send 0 receive 0
Static MAC addresses:
Statistics:
 packets: received 0, sent 0
 bytes: received 0, sent 0
Storm control drop counters:
 packets: broadcast 0, multicast 0, unknown unicast 0
 bytes: broadcast 0, multicast 0, unknown unicast 0
MAC learning: enabled
Flooding:
 Broadcast & Multicast: enabled
 Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
Split Horizon Group: none
DHCPv4 snooping: disabled
IGMP Snooping profile: none
Storm Control:
Broadcast: enabled(100)
Multicast: enabled(110)
Unknown unicast: enabled(120)
```

Additional References

For additional information related to implementing traffic storm control, refer to the following references.

Related Documents

Related Topic	Document Title
MPLS Layer 2 VPNs	<i>Implementing MPLS Layer 2 VPNs on Cisco ASR 9000 Series Router</i> module in the <i>MPLS Configuration Guide for Cisco ASR 9000 Series Routers</i> .
MPLS VPLS bridges	<i>Implementing Virtual Private LAN Services on Cisco ASR 9000 Series Router</i> module in the <i>MPLS Configuration Guide for Cisco ASR 9000 Series Routers</i>
Getting started material	Cisco ASR 9000 Series Aggregation Services Router Getting Started Guide

Standards

Standards	Title
1	
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

¹ Not all supported standards are listed.

MIBs

MBs	MIBs Link
	To locate and download MIBs using Cisco IOS XR software, use the Cisco MIB Locator found at the following URL and choose a platform under the Cisco Access Products menu: http://cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml

RFCs

RFCs	Title
No new or modified RFCs are supported, and support for existing RFCs has not been modified.	<u> </u>

Technical Assistance

Description	Link
The Cisco Technical Support website contains thousands of pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content.	http://www.cisco.com/ techsupport