



Coherent Optics Commands

- [ampli-control-mode](#), on page 2
- [controller coherentDSP](#), on page 3
- [controller optics](#), on page 5
- [controller ots \(QDD OLS\)](#), on page 9
- [egress-ampli-gain](#), on page 10
- [egress-ampli-osri](#), on page 11
- [egress-ampli-power](#), on page 12
- [egress-ampli-safety-control-mode](#), on page 13
- [hw-module location](#), on page 14
- [rx-low-threshold](#), on page 16
- [show controllers coherentDSP](#), on page 17
- [show controllers optics](#), on page 19
- [show controllers ots \(QDD OLS\)](#), on page 22
- [tx-low-threshold](#), on page 24

ampli-control-mode

To configure the mode of operation of the OLS pluggable to either gain control or power control mode, use the **ampli-control-mode** command in the controller ots configuration mode.

ampli-control-mode { powermode | manual }

Syntax Description	powermode Configures the OLS pluggable to power control mode. manual Configures the OLS pluggable to gain control mode.				
Command Default	None.				
Command Modes	controller ots				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 25.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.
Release	Modification				
Release 25.3.1	This command was introduced.				
Usage Guidelines	None.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>dwdm</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	dwdm	read, write
Task ID	Operation				
dwdm	read, write				

Example

The following example shows how to configure the gain control operational mode and the amplifier gain of the OLS pluggable :

```
Router#config
Router(config)#controller ots 0/0/2/1/0
Router(config-Ots)#ampli-control-mode manual
Router(config-Ots)#egress-ampli-gain +30
Router(config-Ots)#commit
Router(config-Ots)#exit
Router(config)#exit
```

controller coherentDSP

To configure the coherent DSP controller, use the **controller coherentDSP** command in the Coherent DSP controller configuration mode.

```
controller coherentDSP R/S/I/P [ description description | perf-mon { enable | disable } | pm { 30-sec |15-min |24-hour } { fec } { report | threshold } value | secondary-admin-state { maintenance | normal } loopback { internal | line } ]
```

Syntax Description	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the coherent DSP controller.
description <i>description</i>		Description of the coherent DSP controller.
perf-mon { enable disable }		Enables or disables performance monitoring.
pm { 30-sec 15-min 24-hour }		Configures performance monitoring parameters for 30-second, 15-minute, or 24-hour intervals.
{fec} { report threshold }		The fec keyword configures FEC PM data in 30-second, 15-minute, or 24-hour intervals.
value		The report keyword configures threshold crossing alerts (TCA) reporting status for the PM parameters.
		The threshold keyword configures threshold values for the PM parameters.
		The PM parameters that can be configured are:
		<ul style="list-style-type: none"> • Inst-Q-margin (Instantaneous Q margin) • Q threshold • Q-margin • ec-bits (error corrected bits) • post-FEC BER • pre-FEC BER • uc-words (uncorrected words)
secondary-admin-state		Configures the administrative state of the controller. The states are maintenance or normal.
loopback { internal line }		Configures the internal or line loopback mode on the controller.
Command Default	None.	
Command Modes	Coherent DSP controller configuration	

Command History	Release	Modification
	Release 7.3.2	This command was introduced.

Example

The following example shows how to enable line loopback configuration on coherent DSP controllers:

```
Router#config
Router(config)#controller coherentDSP 0/0/0/4
Router(config-CoDSP)#secondary-admin-state maintenance
Router(config-CoDSP)#loopback line
Router(config-CoDSP)#commit
```

controller optics

To configure the optics controller, use the **controller optics** command in the optics controller configuration mode.

```
controller optics R/S/I/P [ DAC-Rate rate | cd-max cd-max | cd-min cd-min |
cd-low-threshold cd-low | cd-high-threshold cd-high | dgfd-high-threshold dgfd-value |
dwdm-carrier channel-grid | lbc-high-threshold lbc-value | osnr-low-threshold osnr-value |
description description | fec fec-mode | sec-admin-state {maintenance | normal} | shutdown |
transmit-power transmit-power | perf-mon { enable | disable } | host { auto-squelch |
{ disable } | pm { 30-sec | 15-min | 24-hour } { optics } { report | threshold } |
pm-parameter value ]
```

Syntax Description	
R/S/I/P	Rack/Slot/Instance/Port of the optics controller.
DAC-Rate rate	Sets the DAC (digital to analog conversion) sampling rate for this controller. The sampling rate options available are: <ul style="list-style-type: none"> • 1x1 • 1x1.25
cd-max cd-max	(Only for trunk optics controllers) Maximum chromatic dispersion. For QDD-400G-ZR-S optical module, the range is 0 to +2400. For QDD-400G-ZRP-S optical module, the range is 0 to +80000 ps/nm.
cd-min cd-min	(Only for trunk optics controllers) Minimum chromatic dispersion. For QDD-400G-ZR-S optical module, the range is -2400 to 0. For QDD-400G-ZRP-S optical module, the range is -80000 to 0 ps/nm.
cd-low-threshold cd-low	(Only for trunk optics controllers) Minimum acceptable chromatic dispersion value. The CD alarm is raised if the chromatic dispersion goes below this value. This is an alarm threshold parameter. For QDD-400G-ZR-S optical module, the range is -2400 to 0. For QDD-400G-ZRP-S optical module, the range is -80000 to 0 ps/nm.
cd-high-threshold cd-high	(Only for trunk optics controllers) Maximum acceptable chromatic dispersion value. The CD alarm is raised if the chromatic dispersion exceeds this value. This is an alarm threshold parameter. For QDD-400G-ZR-S optical module, the range is 0 to +2400. For QDD-400G-ZRP-S optical module, the range is 0 to +80000 ps/nm.
dgfd-high-threshold dgfd-value	(Only for trunk optics controllers) Configures the maximum acceptable Differential Group Delay (DGD) value. The DGD alarm is raised if DGD exceeds this value. This is an alarm threshold parameter. The range is 0 to 18000 (in the units of 0.01 ps).
dwdm-carrier channel-grid	Configures the DWDM carrier channel. Options are: <ul style="list-style-type: none"> • 100MHz-grid • 50GHz-grid

lbc-high-threshold <i>lbc-value</i>	Configures the high laser bias current threshold. This is an alarm threshold parameter. The range is 0 to 100%
osnr-low-threshold <i>osnr-value</i>	(Only for trunk optics controllers) Configures the minimum acceptable Optical Signal-to-Noise ratio (OSNR) value. The OSNR alarm is raised if OSNR goes below this value. This is an alarm threshold parameter. The range is 0 to 4000 (in units of 0.01db).
description <i>description</i>	Description of the optics controller.
fec <i>fec-mode</i>	Configures Forward Error Correction (FEC) modes.
sec-admin-state	Configures the administrative state of the controller. The values are maintenance or normal.
shutdown	Disables the configuration of the controller.
pm { 30-sec 15-min 24-hour } { optics } { report threshold } pm-parameter value	Configures performance monitoring parameters for 30-second, 15-minute, and 24-hour intervals. The report keyword configures threshold crossing alerts (TCA) reporting status for the PM parameters. The threshold keyword configures threshold values for the PM parameters. The PM parameters that can be configured are: <ul style="list-style-type: none"> • cd (chromatic dispersion) • dgd (differential group delay) • low-freq-off (low signal frequency offset) • opr (optical power RX) • osnr (optical signal-to-noise ratio) • pcr (polarization change rate) • pdl (polarization dependent loss) • rx-sig (receiving signal power) • snr (signal-to-noise ratio) • sopmd (second order polarization mode dispersion)
transmit-power <i>transmit-power</i>	(Only for trunk optics controllers) Configures the transmit power. The range is -190 to 50 dBm (in the units of 0.1 dBm).
host { auto-squelch } { disable }	Disable squelch for host.
perf-mon { enable disable }	Enables or disables performance monitoring.

Command Default**Table 1: Supported Line Cards and Modes**

Line Card	Default Port Speed	Supported Front Panel Ports	1x400G Transponder Mode	4x100G Muxponder Mode	3x100G Muxponder Mode	2x100G Muxponder Mode	1x100G Transponder Mode
A9K-20HG-FLEX-SE / A9K-20HG-FLEX-TR	1x100G	0, 7, 8, 12, 19	Yes	Yes	No	No	Yes
A9K-8HG-FLEX-SE / A9K-8HG-FLEX-TR	1x100G	0, 7	Yes	Yes	No	No	Yes
A99-10X400GE-X-SE / A99-10X400GE-X-TR	1x400G	3, 5, 6, 7, 9	Yes	Yes	No	Yes	Yes
A9903-20HG-PEC	1x100G	0, 4, 8, 12, 16	Yes	No	No	No	Yes

Command History**Release Modification**

Release 7.3.2 This command was introduced.

Release 7.10.1 The following keyword was introduced:
• host auto-squelch disable**Command Modes**

Optics controller configuration

Usage GuidelinesThe configurations for chromatic dispersion, cd-low-threshold, and cd-high-threshold must be performed only after the **hw-module** configuration. These configurations must be removed before the **no hw-module** configuration. Default values are set to optimize the power consumption by the QDD-400G-ZR-S and QDD-400G-ZRP-S modules.**Example**

The following example shows how to configure the optics controller and set the ranges for chromatic dispersion:

```
Router#configure
Router(config)#controller optics 0/0/1/1
Router(config-optics)#cd-max 2000
Router(config-optics)#cd-min -2000
Router(config)#commit
```

The following is a sample in which the performance monitoring parameters of optics controller are configured in 24-hour intervals:

```
Router#configure
Router(config)#controller optics 0/0/1/1
Router(config-optics)#perf-mon enable
```

controller optics

```
Router(config-optics)#pm 24-hour optics threshold osnr max 345
Router(config)#commit
```

This example shows how to disable laser squelching for host on controller optics:

```
router#config
router(config)#controller 0/0/0/0
router(config-Optics)#host auto-squelch disable
router(config-Optics)#commit
```

controller ots (QDD OLS)

To configure the QDD OLS pluggable (ots controller), use the **controller ots** command in the global configuration mode.

controller ots R/S/I/P/SuP

Syntax Description	<i>R/S/I/P/SuP</i> Rack/Slot/Instance/Port/Sub-Port of the QDD OLS pluggable. <i>SuP</i> is the QDD pluggable subport which can be 0 or 1. Com port is represented as 0 and line port is represented as 1.								
Command Default	None.								
Command Modes	Global Configuration								
Command History	<table> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 25.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.				
Release	Modification								
Release 25.3.1	This command was introduced.								
Usage Guidelines	None.								
Task ID	<table> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>dwdm</td> <td>read, write</td> </tr> <tr> <td>sonet-sdh</td> <td>read, write</td> </tr> <tr> <td>interface</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	dwdm	read, write	sonet-sdh	read, write	interface	read, write
Task ID	Operation								
dwdm	read, write								
sonet-sdh	read, write								
interface	read, write								

Example

This example shows how to configure the ots controller and set the low- power threshold at the transmit and receive side.

```
Router#config
Router(config)#controller ots 0/0/2/1/0
Router(config-Ots)#rx-low-threshold -200
Router(config-Ots)#tx-low-threshold -200
Router(config-Ots)#commit
Router(config-Ots)#exit
Router(config)#exit
```

egress-ampli-gain

To configure the amplifier gain of the OLS pluggable, use the **egress-ampli-gain** command in the controller ots configuration mode.

egress-ampli-gain *gain-value*

Syntax Description	<i>gain-value</i> Sets the amplifier gain value. The range is <+30, +400> in units of 0.1dB.				
	<ul style="list-style-type: none"> • For subport 0, the range is from +30 db to + 250 db • For subport 1, the range is from +70 db to +250 db 				
Command Default	None.				
Command Modes	controller ots				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 25.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.
Release	Modification				
Release 25.3.1	This command was introduced.				
Usage Guidelines	None.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>dwdm</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	dwdm	read, write
Task ID	Operation				
dwdm	read, write				

Example

The following example shows how to configure the gain control operational mode and the amplifier gain of the OLS pluggable :

```
Router#config
Router(config)#controller ots 0/0/2/1/0
Router(config-Ots)#ampli-control-mode manual
Router(config-Ots)#egress-ampli-gain +30
Router(config-Ots)#commit
Router(config-Ots)#exit
Router(config)#exit
```

egress-ampli-osri

To shutdown the amplifier (QDD OLS pluggable), use the **egress-ampli-osri** command in the controller ots configuration mode.

egress-ampli-osri { off | on }

Syntax Description	off Disables the Optical Safety Remote Interlock (OSRI) configuration. on Enables the Optical Safety Remote Interlock (OSRI) configuration.				
Command Default	None				
Command Modes	controller ots				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 25.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.
Release	Modification				
Release 25.3.1	This command was introduced.				
Usage Guidelines	The OSRI configuration is used during the maintenance of the pluggable, debugging scenarios, and when the OLS pluggable is not in use.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>dwdm</td><td>read, write</td></tr> </tbody> </table>	Task ID	Operation	dwdm	read, write
Task ID	Operation				
dwdm	read, write				

Example

The following example shows how to configure the Optical Safety Remote Interlock (OSRI) on the OLS pluggable:

```
Router#config
Router(config)#controller ots 0/0/2/1/0
Router(config-Ots)#egress-ampli-osri on
Router(config-Ots)#commit
Router(config-Ots)#exit
Router(config)#exit
```

egress-ampli-power

To configure the amplifier output power of the OLS pluggable, use the **egress-ampli-power** command in the controller ots configuration mode.

egress-ampli-power power-value

Syntax Description	<i>power-value</i> Sets the amplifier power value. The range is <-30, +250> in units of 0.1dB. <ul style="list-style-type: none"> • For subport 0, the range is from 10 dB to 170 dB • For subport 1, the range is from 0 dB to 170 dB 				
Command Default	None.				
Command Modes	controller ots				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 25.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.
Release	Modification				
Release 25.3.1	This command was introduced.				
Usage Guidelines	None.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>dwdm</td><td>read, write</td></tr> </tbody> </table>	Task ID	Operation	dwdm	read, write
Task ID	Operation				
dwdm	read, write				

Example

The following example shows how to configure the power control operational mode and the amplifier output power of the OLS pluggable :

```
Router#config
Router(config)#controller ots 0/0/2/1/0
Router(config-Ots)#ampli-control-mode powermode
Router(config-Ots)#egress-ampli-power 30
Router(config-Ots)#commit
Router(config-Ots)#exit
Router(config)#exit
```

egress-ampli-safety-control-mode

To enable the safety control mode in the OLS pluggable, use the **egress-ampli-safety-control-mode** command in the controller ots configuration mode.

egress-ampli-safety-control-mode { auto | disabled }

Syntax Description	auto Enables the safety control mode (automatic laser shutdown (ALS)) only on sub-port 1 of the OLS pluggable. disabled Disables the safety control mode (automatic laser shutdown (ALS)) on sub-port 1 of the OLS pluggable.				
Command Default	None				
Command Modes	controller ots				
Command History	<table> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 25.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.
Release	Modification				
Release 25.3.1	This command was introduced.				
Usage Guidelines	You can enable safety control mode only on subport 1. With safety-control-mode set as auto and if LOS is detected on the line RX, the line TX normalizes the signal output power to 8 dBm and the ALS alarm is raised.				
Task ID	<table> <thead> <tr> <th>Task ID</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>dwdm</td><td>read, write</td></tr> </tbody> </table>	Task ID	Operation	dwdm	read, write
Task ID	Operation				
dwdm	read, write				

Example

The following example shows how to enable the safety control mode on the OLS pluggable (on sub-port 1):

```
Router#config
Router(config)#controller ots 0/0/2/1/1
Router(config-Ots)#egress-ampli-safety-control-mode auto
Router(config-Ots)#commit
Router(config-Ots)#exit
Router(config)#exit
```

hw-module location

To configure breakout, use the **hw-module location** command in the global configuration mode.

```
hw-module location node-id [bay bay-number] port port-number breakout muxponder-mode
```

Syntax Description	location node-id Specify the node location. bay bay-number Applicable only for Cisco ASR 9903 router. The <i>bay-number</i> is always 1. port port-number Specify the port number. breakout breakout-mode options Configures the breakout for this controller. The router displays these breakout mode options: <ul style="list-style-type: none"> • 1x400GbE • 1x100GbE • 2x100GbE • 4x100GbE • 2x40GbE • 1x40GbE • 4x25GbE • 4x10GbE • 1x10GbE 						
Command Default	None.						
Command Modes	Global Configuration						
Command History	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left; padding-bottom: 5px;">Release</th><th style="text-align: left; padding-bottom: 5px;">Modification</th></tr> </thead> <tbody> <tr> <td style="padding-bottom: 10px;">Release 7.3.2</td><td>This command was enhanced to support QDD-400G-ZR-S and QDD-400G-ZRP-S optical modules.</td></tr> <tr> <td style="padding-bottom: 10px;">Release 24.3.1</td><td>This command was enhanced to support the 1x10GbE breakout mode on the Cisco ASR 9903 router and Cisco A9K-20HG-FLEX-SE line cards with SFP-10G-ER, SFP-10G-ZR, and SFP-10G-LR hot-pluggable transceiver modules.</td></tr> </tbody> </table>	Release	Modification	Release 7.3.2	This command was enhanced to support QDD-400G-ZR-S and QDD-400G-ZRP-S optical modules.	Release 24.3.1	This command was enhanced to support the 1x10GbE breakout mode on the Cisco ASR 9903 router and Cisco A9K-20HG-FLEX-SE line cards with SFP-10G-ER, SFP-10G-ZR, and SFP-10G-LR hot-pluggable transceiver modules.
Release	Modification						
Release 7.3.2	This command was enhanced to support QDD-400G-ZR-S and QDD-400G-ZRP-S optical modules.						
Release 24.3.1	This command was enhanced to support the 1x10GbE breakout mode on the Cisco ASR 9903 router and Cisco A9K-20HG-FLEX-SE line cards with SFP-10G-ER, SFP-10G-ZR, and SFP-10G-LR hot-pluggable transceiver modules.						
Usage Guidelines	For additional information, see the "Configuring Breakout" section in the "Configuring 400G Digital Coherent Optics" chapter of <i>Interface and Hardware Component Configuration Guide for Cisco ASR 9000 Series Routers</i> .						

Example

This example shows how to configure the 4x100 muxponder mode using the **hw-module location** command:

```
Router#configure
Router(config)#hw-module port 1 location 0/1/0/3 breakout 4xHundredGigE
Router(config)#commit
```

This example shows how to configure the 1x10GbE breakout mode using the **hw-module location** command:

```
Router#configure
Router(config)#hw-module location 0/0/CPU0 bay 1 port 9 breakout 1xTenGbE
Router(config)#commit
```

rx-low-threshold

rx-low-threshold

To configure the low receive (RX) power threshold on the QDD OLS pluggable, use the **rx-low-threshold** command in the controller ots configuration mode.

rx-low-threshold rx-low

Syntax Description	<i>rx-low</i> Configures the low receive power threshold. The range is -400 to 400 (in the units of 0.1 dBm). <ul style="list-style-type: none"> For subport 0, the range is from -300 dBm to 170 dBm For subport 1, the range is from -300 dBm to 170 dBm 				
Command Default	None.				
Command Modes	controller ots				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 25.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.
Release	Modification				
Release 25.3.1	This command was introduced.				
Usage Guidelines	None.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>dwdm</td><td>read, write</td></tr> </tbody> </table>	Task ID	Operation	dwdm	read, write
Task ID	Operation				
dwdm	read, write				

Example

This example shows how to configure the ots controller and set the low power threshold at the receiving side.

```
Router#config
Router(config)#controller ots 0/0/2/1/0
Router(config-Ots)#rx-low-threshold -200
Router(config-Ots)#commit
Router(config-Ots)#exit
Router(config)#exit
```

show controllers coherentDSP

To display the status and configuration information about the interfaces configured as coherent DSP controllers on a specific node, use the **show controllers coherentDSP** command in XR EXEC mode.

show controller coherentDSP R/S/I/P [pm { current | history } { 30-sec | 15-min | 24-hour } { fec }]

Syntax Description	<p>R/S/I/P Rack/Slot/Instance/Port of the coherent DSP controller.</p> <p>pm Displays performance monitoring parameters for the controller.</p> <p>current Displays the current performance monitoring data in 30-second, 15- minute, and 24-hour intervals.</p> <p>history Displays the historical performance monitoring data in 30-second, 15-minute, and 24-hour intervals.</p> <p>fec The fec keyword displays FEC PM data in 30-second, 15-minute, or 24-hour intervals.</p>				
Command Default	No default behavior or values				
Command Modes	XR EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 7.3.2</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 7.3.2	This command was introduced.
Release	Modification				
Release 7.3.2	This command was introduced.				

Example

The following is a sample to view the status and configuration information about the coherent DSP controller.

```
Router#show controllers coherentDSP 0/19/0/3

Port : CoherentDSP 0/19/0/3
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Normal
Derived State : In Service
Loopback mode : None
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 100.0Gb/s

Alarm Information:
LOS = 0 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 0
FLEXO-LOF = 1
Detected Alarms : None

Bit Error Rate Information
```

show controllers coherentDSP

```

PREFEC BER : 0.0E+00
POSTFEC BER : 0.0E+00
Q-Factor : 16.50 dB

Q-Margin : 9.90dB

OTU TTI Received

FEC mode : O_FEC

```

The following is a sample to view the current performance monitoring parameters of the coherent DSP controller in 30 second intervals.

```
Router#show controllers coherentDSP 0/0/0/13 pm current 30-sec fec
g709 FEC in the current interval [07:03:00 - 07:03:29 Thu May 27 2021]
```

FEC current bucket type : Valid							
EC-BITS : 11885430510	Threshold : 83203400000	TCA (enable) :					
YES							
UC-WORDS : 0	Threshold : 5	TCA (enable) :					
YES							
Threshold	TCA	MIN	AVG	MAX	Threshold	TCA	
(max)	(enable)				(min)	(enable)	
PreFEC BER 0E-15	NO	:	8.4E-04	8.6E-04	8.7E-04	0E-15	NO
PostFEC BER 0E-15	NO	:	0E-15	0E-15	0E-15	0E-15	NO
Q[dB] 0.00	NO	:	9.90	9.90	9.90	0.00	NO
Q_Margin[dB] 0.00	NO	:	2.70	2.70	2.70	0.00	NO

```
Last clearing of "show controllers OTU" counters never
```

show controllers optics

To display status and configuration information about the interfaces configured as optics controller on a specific node, use the **show controllers optics** command in XR EXEC mode.

```
show controller optics R/S/I/P [ pm { current | history } { 30-sec | 15-min | 24-hour } { optics } { lane-number } ]
```

Syntax Description	<p>R/S/I/P Rack/Slot/Instance/Port of the optics controller.</p> <p>pm Displays performance monitoring parameters for the controller.</p> <p>current Displays the current performance monitoring data in 30 second, 15 minute, and 24 hour intervals.</p> <p>history Displays the historical performance monitoring data in 30 second, 15 minute, and 24 hour intervals.</p> <p>optics Displays the PM data for optics controller.</p> <p>lane-number Displays the performance monitoring data for the applicable lanes in the optical module. The lane number is always 1.</p>						
Command Default	No default behavior or values						
Command Modes	XR EXEC mode						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.4.1</td><td>This command was introduced.</td></tr> <tr> <td>Release 7.3.2</td><td>This command was updated to reflect the QDD-400G-ZR-S and QDD-400G-ZRP-S changes in the output.</td></tr> </tbody> </table>	Release	Modification	Release 6.4.1	This command was introduced.	Release 7.3.2	This command was updated to reflect the QDD-400G-ZR-S and QDD-400G-ZRP-S changes in the output.
Release	Modification						
Release 6.4.1	This command was introduced.						
Release 7.3.2	This command was updated to reflect the QDD-400G-ZR-S and QDD-400G-ZRP-S changes in the output.						

Usage Guidelines To display the firmware version of the optical module, use the **show controllers optics R/S/I/P | inc Firmware** command.

```
Router#show controllers optics 0/0/0/3 | inc Firmware
Firmware Version : 61.20 (Build : 13)
```

Example

The following example displays the output of the **show controllers optics** command:

```
Router#show controllers optics 0/0/0/3
Controller State: Up
Transport Admin State: In Service
Laser State: On
LED State: Green
FEC State: FEC CFEC
Optics Status
    Optics Type: 400G QSFP-DD ZR
    DWDM carrier Info: C BAND, MSA ITU Channel=61, Frequency=193.10THz,
```

show controllers optics

```

Wavelength=1552.524nm
Alarm Status:
-----
Detected Alarms: None
LOS/LOL/Fault Status:
Laser Bias Current = 52.5 mA
Actual TX Power = -8.51 dBm
RX Power = -8.67 dBm
RX Signal Power = -8.66 dBm
Frequency Offset = 0 MHz
Laser Temperature = 62.21 Celsius
Laser Age = 0 %
DAC Rate = 1x1

Performance Monitoring: Enable

THRESHOLD VALUES
-----
Parameter          High Alarm   Low Alarm   High Warning   Low Warning
-----  -----  -----  -----  -----
Rx Power Threshold(dBm)      1.9       -28.2        0.0       -25.0
Tx Power Threshold(dBm)      0.0       -18.0       -2.0       -16.0
LBC Threshold(mA)           0.00       0.00       0.00       0.00
Temp. Threshold(celsius)    80.00      -5.00      75.00      15.00
Voltage Threshold(volt)     3.46       3.13       3.43       3.16

LBC High Threshold = 98 %
Configured Tx Power = -7.00 dBm
Configured CD High Threshold = 80000 ps/nm
Configured CD lower Threshold = -80000 ps/nm
Configured OSNR lower Threshold = 9.00 dB
Configured DGD Higher Threshold = 180.00 ps
Baud Rate = 59.8437500000 GBd
Modulation Type: 16QAM
Chromatic Dispersion 0 ps/nm
Configured CD-MIN -2400 ps/nm CD-MAX 2400 ps/nm
Second Order Polarization Mode Dispersion = 25.00 ps^2
Optical Signal to Noise Ratio = 36.40 dB
Polarization Dependent Loss = 0.07 dB
Polarization Change Rate = 0.00 rad/s
Differential Group Delay = 1.00 ps

Temperature = 59.00 Celsius
Voltage = 3.31 V

Transceiver Vendor Details
Form Factor : QSFP-DD
Optics type : QSFP-DD 400G-ZR-S
Name : CISCO-ACACIA
OUI Number : 7c.b2.5c
Part Number : DP04QSDD-E20-19E
Rev Number : 01
Serial Number : ACA2504002U
PID : QDD-400G-ZR-S
VID : ES03
Firmware Version : 161.20 (Build : 9)
Date Code(yy/mm/dd) : 21/02/03

```

The following is a sample to view the current performance monitoring parameters of the optics controller in 30 second intervals.

```

Router#show controllers optics 0/0/0/7 pm current 30-sec optics 1
Optics in the current interval [07:11:30 - 07:11:33 Thu May 27 2021]
Optics current bucket type : Valid
      MIN        AVG        MAX     Operational     Configured      TCA   Operational
Configured      TCA
                                         Threshold(min)  Threshold(min) (min) Threshold(max)
Threshold(max) (max)
LBC[%] : 0.0      0.0      0.0      0.0          NA           NO   100.0
          NA          NO
OPT[dBm] : -7.92  -7.92    -7.92    -15.09       NA           NO   0.00
          NA          NO
OPR[dBm] : -8.20  -8.19    -8.18    -30.00       NA           NO   8.00
          NA          NO
CD[ps/nm] : -1     -1       0       -80000       NA           NO   80000
          NA          NO
DGD[ps ] : 4.00   4.00    4.00    0.00          NA           NO   80.00
          NA          NO
SOPMD[ps^2] : 46.00 48.00   50.00   0.00          NA           NO 2000.00
          NA          NO
OSNR[dB] : 36.40  36.40   36.40   9.00          NA           NO 40.00
          NA          NO
PDL[dB] : 0.08   0.09    0.09    0.00          NA           NO   7.00
          NA          NO
PCR[rad/s] : 0.00  0.00    0.00    0.00          NA           NO 2500000.00
          NA          NO
RX_SIG[dBm] : -7.40 -7.40   -7.39   -30.00       NA           NO   1.00
          NA          NO
FREQ_OFF[Mhz] : -99   -93     -87     -3600       NA           NO 3600
          NA          NO
SNR[dB] : 18.40  18.45   18.50   7.00          NA           NO 100.00
          NA          NO

```

Last clearing of "show controllers OPTICS" counters never

show controllers ots (QDD OLS)

show controllers ots (QDD OLS)

To display the configuration details of the OLS pluggable, use the **show controllers ots** command in XR EXEC mode.

show controllers ots R/S/I/P/SuP

Syntax Description	<i>R/S/I/P/SuP</i> Rack/Slot/Instance/Port/Sub-Port of the QDD OLS pluggable. <i>SuP</i> is the QDD pluggable sub-port which can be 0 or 1. Com port is represented as 0 and line port is represented as 1.				
Command Default	None.				
Command Modes	XR EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 25.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.
Release	Modification				
Release 25.3.1	This command was introduced.				
Usage Guidelines	None				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>interface</td><td>read</td></tr> </tbody> </table>	Task ID	Operation	interface	read
Task ID	Operation				
interface	read				

Example

The following example displays the configuration details of the OLS pluggable:

```
Router#show controllers ots 0/0/1/1/1
Wed Mar 29 06:59:00.016 UTC

Controller State: Up
Transport Admin State: In Service
LED State: Yellow

Alarm Status:
-----
Detected Alarms: None

Alarm Statistics:
-----
RX-LOS-P = 1
RX-LOC = 0
TX-POWER-FAIL-LOW = 0
INGRESS-AUTO-LASER-SHUT = 0
INGRESS-AUTO-POW-RED = 0
INGRESS-AMPLI-GAIN-LOW = 0
INGRESS-AMPLI-GAIN-HIGH = 0
```

```
EGRESS-AUTO-LASER-SHUT = 1
EGRESS-AUTO-POW-RED = 1
EGRESS-AMPLI-GAIN-LOW = 0
EGRESS-AMPLI-GAIN-HIGH = 0
HIGH-TX-BR-PWR = 0
HIGH-RX-BR-PWR = 0
SPAN-TOO-SHORT-TX = 0
SPAN-TOO-SHORT-RX = 0

Parameter Statistics:
-----
Total Tx Power = 7.52 dBm
Rx Signal Power = -26.77 dBm
Tx Signal Power = 7.23 dBm
Egress Ampli Gain = 20.8 dB
Egress Ampli Safety Control mode = auto
Egress Ampli OSRI = OFF

Configured Parameters:
-----
Egress Ampli Gain = 15.0 dB
Egress Ampli Power = 8.0 dBm
Egress Ampli Safety Control mode = auto
Egress Ampli OSRI = OFF
Ampli Control mode = Manual
Rx Low Threshold = -30.0 dBm
Tx Low Threshold = -5.0 dBm

Temperature = 35.09 Celsius
Voltage = 3.37 V

Optical Module Details

Optics type : QDD DUAL EDFA
Name : CISCO-ACCELINK
OUI Number : 00.00.00
Part Number : EDFA-211917-QDD
Rev Number : 21
Serial Number : ACW2651Z003
PID : ONS-QDD-OLS
VID : VES1
Firmware Version : 2.01
Date Code(yy/mm/dd) : 22/12/28
Fiber Connector Type : CS
```

tx-low-threshold

tx-low-threshold

To configure the low transmit (TX) power threshold on the QDD OLS pluggable, use the **tx-low-threshold** command in the controller ots configuration mode.

tx-low-threshold tx-low

Syntax Description	<i>tx-low</i> Configures the low transmit power threshold. The range is -400 to 400 (in the units of 0.1 dBm). <ul style="list-style-type: none"> • For subport 0, the range is from -50 dBm to 190 dBm • For subport 1, the range is from -50 dBm to 190 dBm 				
Command Default	None.				
Command Modes	controller ots				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 25.3.1</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 25.3.1	This command was introduced.
Release	Modification				
Release 25.3.1	This command was introduced.				
Usage Guidelines	None.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>dwdm</td><td>read, write</td></tr> </tbody> </table>	Task ID	Operation	dwdm	read, write
Task ID	Operation				
dwdm	read, write				

Example

This example shows how to configure the ots controller and set the low power threshold at the transmit side.

```
Router#config
Router(config)#controller ots 0/0/2/1/0
Router(config-Ots)#tx-low-threshold -200
Router(config-Ots)#commit
Router(config-Ots)#exit
Router(config)#exit
```