



## Multipoint Layer 2 Services Commands

---

- [action \(VPLS\), on page 3](#)
- [aging \(VPLS\), on page 5](#)
- [aps-channel, on page 7](#)
- [autodiscovery bgp, on page 9](#)
- [bridge-domain \(VPLS\), on page 10](#)
- [bridge group \(VPLS\), on page 11](#)
- [clear l2vpn bridge-domain \(VPLS\), on page 12](#)
- [debug l2vpn forwarding platform vpls all location, on page 13](#)
- [description \(G.8032\), on page 14](#)
- [dhcp ipv4 snoop profile \(VPLS\), on page 15](#)
- [ethernet ring g8032, on page 17](#)
- [ethernet ring g8032 profile, on page 18](#)
- [exclusion list, on page 20](#)
- [flooding disable, on page 21](#)
- [flooding unknown-unicast disable \(VPLS\), on page 23](#)
- [igmp snooping disable, on page 25](#)
- [inclusion-list, on page 26](#)
- [instance \(G.8032\), on page 28](#)
- [interface \(VPLS\), on page 29](#)
- [l2vpn resynchronize forwarding mac-address-table location, on page 31](#)
- [learning disable \(VPLS\), on page 32](#)
- [level, on page 34](#)
- [limit \(VPLS\), on page 35](#)
- [mac \(VPLS\), on page 37](#)
- [mac secure, on page 39](#)
- [maximum \(VPLS\), on page 42](#)
- [monitor interface \(port0\), on page 44](#)
- [monitor interface \(port1\), on page 45](#)
- [mpls static label \(VPLS\), on page 46](#)
- [mtu \(VPLS\), on page 48](#)
- [multicast p2mp, on page 50](#)
- [neighbor \(VPLS\), on page 52](#)
- [notification \(VPLS\), on page 54](#)

- open ring, on page 56
- port0 interface, on page 57
- port1, on page 58
- port-down flush disable (VPLS), on page 59
- profile, on page 61
- pw-class , on page 62
- pw-oam, on page 64
- pw-status (L2VPN), on page 65
- route-target, on page 67
- routed, on page 69
- rpl, on page 71
- show ethernet ring g8032, on page 73
- show l2vpn bridge-domain (VPLS), on page 76
- show l2vpn ethernet ring g8032, on page 87
- show l2vpn forwarding bridge-domain (VPLS), on page 89
- show l2vpn forwarding bridge-domain mac-address (VPLS), on page 92
- show l2vpn forwarding ethernet ring g8032, on page 96
- show l2vpn forwarding protection main-interface, on page 98
- show l2vpn protection main-interface, on page 100
- shutdown (Bridge Domain), on page 103
- shutdown (VFI), on page 104
- signaling-protocol, on page 106
- split-horizon group, on page 108
- static-address (VPLS), on page 110
- static-mac-address (VPLS), on page 112
- tcn-propagation, on page 114
- time (VPLS), on page 115
- transport rsvp-te, on page 117
- type (VPLS), on page 119
- vfi (VPLS), on page 121
- withdraw (VPLS), on page 123

## action (VPLS)

To configure the bridge behavior when the number of learned MAC addresses reaches the MAC limit configured, use the **action** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

**action** {**flood** | **no-flood** | **shutdown**}  
**no action** {**flood** | **no-flood** | **shutdown**}

Syntax Description	
<b>flood</b>	Configures the action to flood all unknown unicast packets when the MAC limit is reached. If the action is set to flood, all unknown unicast packets, with unknown destinations addresses, are flooded over the bridge.
<b>no-flood</b>	Configures the action to no-flood so all unknown unicast packets are dropped when the MAC limit is reached. If the action is set to no-flood, all unknown unicast packets, with unknown destination addresses, are dropped.
<b>shutdown</b>	Stops forwarding when the MAC limit is reached. If the action is set to shutdown, all packets are dropped.

**Command Default** No action is taken when the MAC address limit is reached.

**Command Modes** L2VPN bridge group bridge domain MAC limit configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **action** command to specify the type of action to be taken when the action is violated.

The configured action has no impact if the MAC limit has not been reached.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example shows how to configure the bridge bar to flood all unknown unicast packets when the number of MAC addresses learned by the bridge reaches 10:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)#bridge group 1
```

```

RP/0/RSP0/CPU0:router (config-l2vpn-bg) #bridge-domain bar
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd) #mac
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd-mac) #limit
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd-mac-limit) #action flood
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd-mac-limit) #maximum 10

```

**Related Commands**

Command	Description
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">limit (VPLS), on page 35</a>	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">maximum (VPLS), on page 42</a>	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
<a href="#">notification (VPLS), on page 54</a>	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

## aging (VPLS)

To enter the MAC aging configuration submode to set the aging parameters such as time and type, use the **aging** command in L2VPN bridge group bridge domain configuration mode. To return to the default value for all parameters that are attached to this configuration submode, use the **no** form of this command.

**aging**  
**no aging**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No defaults are attached to this parameter since it is used as a configuration submode. See defaults that are assigned to the [time \(VPLS\), on page 115](#) and the [type \(VPLS\), on page 119](#) parameters.

**Command Modes** L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **aging** command to enter L2VPN bridge group bridge domain MAC aging configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example shows how to enter MAC aging configuration submode and to set the MAC aging time to 120 seconds:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# time 120
```

Related Commands	Commands	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.

Commands	Description
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then assigns network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">time (VPLS), on page 115</a>	Configures the maximum aging time.
<a href="#">type (VPLS), on page 119</a>	Configures the type for MAC address aging.

# aps-channel

To configure G.8032 instance APS channel and to enter Ethernet ring G.8032 instance aps-channel configuration submode, use the **aps-channel** command in the Ethernet ring g8032 instance configuration submode. To remove the G.8032 instance APS channel configuration, use the **no** form of this command.

```
aps-channel [{level message-level | port0 interface {Bundle-Ether | FastEthernet | GigabitEthernet | TenGigE} interface-id | port1 {bridge-domain bridge-domain-name | interface {Bundle-Ether | FastEthernet | GigabitEthernet | TenGigE} interface-id | none | xconnect xconnect-name}}]
no aps-channel [{level message-level | port0 interface {Bundle-Ether | FastEthernet | GigabitEthernet | TenGigE} interface-id | port1 {bridge-domain bridge-domain-name | interface {Bundle-Ether | FastEthernet | GigabitEthernet | TenGigE} interface-id | none | xconnect xconnect-name}}]
```

## Syntax Description

<b>level</b>	Specifies the APS message level. The message level ranges from 0 to 7.
<b>port0</b>	Configures G.8032 aps-channel information associated to port0.
<b>port1</b>	Configures G.8032 aps-channel information associated to port1.
<b>interface</b>	Assigns interface associated to port0 or port1. You can assign one of these interfaces: <ul style="list-style-type: none"> <li>• Bundle Ethernet</li> <li>• Fast Ethernet</li> <li>• Gigabit Ethernet</li> <li>• TenGigabit Ethernet</li> </ul>
<b>bridge-domain</b>	Specifies VPLS domain where virtual channel is connected.
<b>none</b>	Specify APS channel port0 or port1 as none.
<b>xconnect</b>	Specifies VPWS xconnect where virtual channel is connected.

## Command Default

None

## Command Modes

L2VPN configuration mode

## Command History

Release	Modification
Release 4.1.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to configure G.8032 instance APS channel:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 r1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# instance 1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# description test
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# profile p1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# rpl port0 neighbor
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# inclusion-list vlan-ids e-g
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# aps-channel
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance-aps)#
```

Related Commands	Command	Description
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.
	<a href="#">inclusion-list, on page 26</a>	Associates a set of VLAN IDs with the current instance.



# autodiscovery bgp

To enable BGP autodiscovery, use the **autodiscovery bgp** command in the VFI configuration mode. To return to the default value, use the **no** form of this command.

```
autodiscovery bgp
no autodiscovery bgp
```

**Syntax Description** This command has no keywords or arguments.

**Command Default** None.

**Command Modes** VFI configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to configure a bridge domain:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group EGroup
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain eastdomain
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi eastvfi
RP/0/RSP0/CPU0:routerr(config-l2vpn-bg-bd-vfi)# autodiscovery bgp
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

## bridge-domain (VPLS)

To establish a bridge domain and to enter L2VPN bridge group bridge domain configuration mode, use the **bridge-domain** command in L2VPN bridge group configuration mode. To return to a single bridge domain, use the **no** form of this command.

**bridge-domain** *bridge-domain-name*  
**no bridge-domain** *bridge-domain-name*

<b>Syntax Description</b>	<i>bridge-domain-name</i> Name of the bridge domain.
	<b>Note</b> The maximum number of characters that can be specified in the bridge domain name is 27.

**Command Default** The default value is a single bridge domain.

**Command Modes** L2VPN bridge group configuration

<b>Command History</b>	<b>Release</b> <b>Modification</b>
	Release 3.7.2 This command was introduced.

**Usage Guidelines** Use the **bridge-domain** command to enter L2VPN bridge group bridge domain configuration mode.

<b>Task ID</b>	<b>Task ID</b> <b>Operations</b>
	l2vpn      read, write

**Examples** The following example shows how to configure a bridge domain:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router (config)# l2vpn
RP/0/RSP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd) #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

## bridge group (VPLS)

To create a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain, use the **bridge group** command in L2VPN configuration mode. To remove all the bridge domains that are created under this bridge group and to remove all network interfaces that are assigned under this bridge group, use the **no** form of this command.

**bridge group** *bridge-group-name*  
**no bridge-group** *bridge-group-name*

<b>Syntax Description</b>	<i>bridge-group-name</i> Number of the bridge group to which the interface belongs.
---------------------------	---

<b>Command Default</b>	No bridge group is created.
------------------------	-----------------------------

<b>Command Modes</b>	L2VPN configuration
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Use the **bridge group** command to enter L2VPN bridge group configuration mode.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows that bridge group 1 is assigned:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# clear l2vpn bridge-domain (VPLS)

To clear the MAC addresses and to restart the bridge domains on the router, use the **clear l2vpn bridge-domain** command in EXEC mode.

```
clear l2vpn bridge-domain {all | bd-name name | group group}
```

Syntax Description	all	Clears and restarts all the bridge domains on the router.
	<b>bd-name</b> <i>name</i>	Clears and restarts the specified bridge domain. The <i>name</i> argument specifies the name of the bridge-domain.
	<b>group</b> <i>group</i>	Clears and restarts all the bridge domains that are part of the bridge group.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This is the method that allows a bridge to forward again after it was put in Shutdown state as a result of exceeding the configured MAC limit.

Task ID	Task ID	Operations
	l2vpn	read, write

## Examples

The following example shows how to clear all the MAC addresses and to restart all the bridge domains on the router:

```
RP/0/RSP0/CPU0:router# clear l2vpn bridge-domain all
```

Related Commands	Command	Description
	<a href="#">show l2vpn bridge-domain (VPLS), on page 76</a>	Display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains.

## debug l2vpn forwarding platform vpls all location

To display debugging information about L2VPN forwarding Virtual Private LAN Service (VPLS) platform of a specified location, use the **debug l2vpn forwarding platform vpls all location** command in EXEC mode. To disable debugging, use the **no** form of this command.

**debug l2vpn forwarding platform vpls all location** *location*  
**no debug l2vpn forwarding platform vpls all location** *location*

<b>Syntax Description</b>	<i>location</i> Location to display debugging information.				
<b>Command Default</b>	None				
<b>Command Modes</b>	EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.1	This command was introduced.
Release	Modification				
Release 5.1	This command was introduced.				
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>root-system</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	root-system	read, write
Task ID	Operation				
root-system	read, write				

## description (G.8032)

To specify a string that serves as a description for a G.8032 Ethernet ring instance, use the **description** command in the Ethernet ring G.8032 instance configuration submode.

**description** *ring-instance-identifier*

<b>Syntax Description</b>	<i>ring-instance-identifier</i> A string that serves as a description for a G.8032 Ethernet ring instance. The string can be a maximum of 32 characters.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Ethernet ring G.8032 instance configuration submode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.
Release	Modification				
Release 4.1.0	This command was introduced.				
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write
Task ID	Operation				
l2vpn	read, write				

This example shows how to specify a description for G.8032 Ethernet ring instance:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 r1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# instance 1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# description test
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)#
```

Related Commands	Command	Description
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.
	<a href="#">instance (G.8032), on page 28</a>	Configures a G.8032 Ethernet ring instance and enters Ethernet ring G.8032 instance configuration submode.

## dhcp ipv4 snoop profile (VPLS)

To enable DHCP snooping on a bridge and to attach a DHCP snooping profile to the bridge, use the **dhcp ipv4 snoop** command in L2VPN bridge group bridge domain configuration mode. To disable DHCP snooping on an interface, use the **no** form of this command.

```
dhcp ipv4 snoop profile profile-name
no dhcp ipv4 snoop
```

<b>Syntax Description</b>	<b>profile</b> <i>profile-name</i>	Attaches a DHCP profile. Profile name for DHCPv4 snooping.
<b>Command Default</b>	None	
<b>Command Modes</b>	L2VPN bridge group bridge domain configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how to enable DHCP snooping on a bridge:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# dhcp ipv4 snoop profile attach
```

This example shows how to enable DHCP snooping over a pseudowire:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)#vfi vf1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)#exit
```

```
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd) #neighbor 10.1.1.1 pw-id 100
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd-pw) #dhcp ipv4 snoop profile A
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.



# ethernet ring g8032

To enable G.8032 ring mode and enter the G.8032 configuration submode, use the **ethernet ring g8032** command in the L2VPN configuration mode. To disable the G.8032 ring mode, use the **no** form of this command.

**ethernet ring g8032** *protocol ring identifier*  
**no ethernet ring g8032** *protocol ring identifier*

<b>Syntax Description</b>	<i>protocol ring identifier</i> Ring profile name. The maximum size of the profile name is 32 characters.				
<b>Command Default</b>	None				
<b>Command Modes</b>	L2VPN configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.
Release	Modification				
Release 4.1.0	This command was introduced.				
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write
Task ID	Operation				
l2vpn	read, write				

## Example

This example shows how to enable the G.8032 ring mode:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)#ethernet ring g8032 p1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)#
```

Related Commands	Command	Description
	<a href="#">exclusion list</a> , on page 20	Defines a set of Virtual LAN (VLAN) IDs that are not protected by the Ethernet ring protection mechanism.
	<a href="#">instance (G.8032)</a> , on page 28	Configures a G.8032 Ethernet ring instance and enters Ethernet ring G.8032 instance configuration submode.
	<a href="#">port0 interface</a> , on page 57	Enables G.8032 for a specified ring port.
	<a href="#">port1</a> , on page 58	Enables G.8032 for a specified ring port.

## ethernet ring g8032 profile

To configure G.8032 ring profile and to enter the G.8032 ring profile configuration mode, use the **ethernet ring g8032 profile** command in the global configuration mode. To disable the G.8032 ring profile, use the **no** form of this command.

**ethernet ring g8032 profile** *profile-name* [{**non-revertive** | **timer** {**guard** *milliseconds* | **hold-off** *seconds* | **wtr** *minutes* } }]

Syntax Description		
	<b>non-revertive</b>	Configures non-revertive ring instance.
	<b>timer</b>	Configures G.8032 timer.
	<b>guard</b>	Configures G.8032 guard timer. The Guard timer can be configured and the default time interval is 500 ms. The time interval ranges from 10 to 2000 ms.
	<b>hold-off</b>	Configures G.8032 hold-off timer. The hold-off timer can be configured and the default time interval is 0 seconds. The time interval ranges from 0 to 10 seconds.
	<b>wtr</b>	Configures G.8032 WTR timer. The WTR timer can be configured by the operator, and the default time interval is 5 minutes. The time interval ranges from 1 to 12 minutes.

**Command Default** None

**Command Modes**

**Command History**

Release	Modification
Release 4.1.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

Task ID	Operation
ethernet-services	read, write

This example shows you how to configure a G.8032 ring profile:

```
RP/0/RSP0/CPU0:router# configure
```

```
RP/0/RSP0/CPU0:router(config)# ethernet ring g8032 profile p1
RP/0/RSP0/CPU0:router(config-g8032-ring-profile)#
```

---

**Related Commands**

Command	Description
<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

---

# exclusion list

To define a set of Virtual LAN (VLAN) IDs that are not protected by the Ethernet ring protection mechanism, use the **exclusion list** command in Ethernet ring g8032 configuration submode. To delete the set of VLAN IDs, use the **no** form of this command.

**exclusion list** **vlan-ids** *vlan range*

**no exclusion list** **vlan-ids** *vlan range*

<b>Syntax Description</b>	<p><b>vlan-ids</b> Specifies a list of VLANs. Ranges in the form a-b,c,d,e-f,g where VLAN value is 1–4094 and/or untagged.</p> <p>By default, all the VLANs configured under ring ports are blocked. VLAN IDs specified here cannot belong to the inclusion-list. VLAN IDs range cannot overlap with the IDs specified under inclusion-list.</p>
---------------------------	--

**Command Default** Configured physical Ethernet or ether bundle interface

**Command Modes** Ethernet ring g8032 configuration submode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.1.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write

This example shows the output from the exclusion list command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 r1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# exclusion-list vlan-ids e-g
RP/0/RSP0/CPU0:router(config-l2vpn-erp)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

# flooding disable

To configure flooding for traffic at the bridge domain level or at the bridge port level, use the **flooding disable** command in L2VPN bridge group bridge domain configuration mode. To return the bridge to normal flooding behavior when all unknown unicast packets, all broadcast packets, and all multicast packets are flooded over all other bridge domain network interfaces, use the **no** form of this command.

**flooding disable**  
**no flooding disable**

This command has no keywords or arguments.

**Command Default** The default behavior is that packets are flooded when their destination MAC address is not found.

**Command Modes** L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **flooding disable** command to override the parent bridge configuration.

By default, bridge ports inherit the flooding behavior of the bridge domain.

When flooding is disabled, all unknown unicast packets, all broadcast packets, and all multicast packets are discarded.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to disable flooding on the bridge domain called bar:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# flooding disable
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mtu (VPLS), on page 48</a>	Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.

# flooding unknown-unicast disable (VPLS)

To disable flooding of unknown unicast traffic at the bridge domain level or at the bridge port level, use the **flooding unknown-unicast disable** command in L2VPN bridge group bridge domain configuration mode. To return the bridge to normal flooding behavior, use the **no** form of this command.

**flooding unknown-unicast disable**  
**no flooding unknown-unicast disable**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	The default behavior is that packets are flooded when their destination MAC address is not found.				
<b>Command Modes</b>	L2VPN bridge group bridge domain configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.9.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.9.0	This command was introduced.
Release	Modification				
Release 3.9.0	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>flooding unknown-unicast disable</b> command to override the parent bridge configuration.</p> <p>By default, bridge ports inherit the flooding behavior of the bridge domain.</p> <p>When flooding is disabled, all unknown unicast packets are discarded.</p> <p>Use this command on Layer 2 interfaces. This command is not applicable on BVI interfaces.</p>				

Task ID	Task ID	Operations
	l2vpn	read, write

## Examples

The following example shows how to disable flooding on the bridge domain called bar:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# flooding unknown-unicast disable
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mtu (VPLS), on page 48</a>	Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.



# igmp snooping disable

To disable IGMP snooping on a bridge domain within the L2VPN, use the **igmp snooping disable** command in the L2VPN bridge group bridge-domain configuration mode. To return to the default, use the **no** form of this command.

**igmp snooping disable**  
**no igmp snooping disable**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	IGMP snooping is active on a bridge domain when an IGMP snooping profile is configured to the bridge domain.				
<b>Command Modes</b>	L2VPN bridge group bridge domain configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.1	This command was introduced.
Release	Modification				
Release 5.1	This command was introduced.				
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				

Task ID	Task ID	Operations
	l2vpn	read, write

## Examples

This example shows how to disable IGMP snooping profile for a bridge domain in the L2VPN:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# igmp snooping disable
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)#
```

Related Commands	Command	Description
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

# inclusion-list

To associate a set of VLAN IDs with the current instance, use the **inclusion-list** command in the Ethernet ring G.8032 instance configuration submenu. To disassociate the VLAN IDs with the current instance, use the **no** form of this command.

**inclusion-list** *vlan-ids* *vlan-id*  
**no inclusion-list** *vlan-ids* *vlan-id*

<b>Syntax Description</b>	<b>vlan-ids</b> Associates a set of VLAN IDs with the current instance.				
	<i>vlan-id</i> List of VLAN IDs in the form <code>vlan-id &lt;vlan range&gt;[,&lt;vlan range&gt;][,&lt;vlan range&gt;][,&lt;vlan range&gt;]</code> .				
<b>Command Default</b>	None				
<b>Command Modes</b>	Ethernet ring G.8032 instance configuration submenu				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.
Release	Modification				
Release 4.1.0	This command was introduced.				
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write
Task ID	Operation				
l2vpn	read, write				

This example shows how to associate VLAN IDs with instance 1:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 r1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# instance 1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# description test
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# profile p1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# rpl port0 neighbor
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# inclusion-list vlan-ids e-g
```

Related Commands	Command	Description
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submenu.

Command	Description
<a href="#">instance (G.8032), on page 28</a>	Configures a G.8032 Ethernet ring instance and enters Ethernet ring G.8032 instance configuration submode.

## instance (G.8032)

To configure a G.8032 Ethernet ring instance and enter Ethernet ring G.8032 instance configuration submode, use the `instance` command in the Ethernet ring G.8032 configuration submode. To disable the G.8032 Ethernet ring instance, use the `no` form of this command.

**instance** *instance-id*  
**no instance** *instance-id*

<b>Syntax Description</b>	<i>instance-id</i> Instance ID; currently, supports up to two instances per Ethernet ring. The instance ID can be 1 or 2.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Ethernet ring G.8032 configuration submode
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.1.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write

This example shows how to configure G.8032 Ethernet ring instance:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 r1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# instance 1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

## interface (VPLS)

To add an interface to a bridge domain that allows packets to be forwarded and received from other interfaces that are part of the same bridge domain, use the **interface** command in L2VPN bridge group bridge domain configuration mode. To remove an interface from a bridge domain, use the **no** form of this command.

```
interface type interface-path-id
no interface type interface-path-id
```

<b>Syntax Description</b>	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.

**Command Default** None

**Command Modes** L2VPN bridge group bridge domain configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface** command to enter L2VPN bridge group bridge domain attachment circuit configuration mode. In addition, the **interface** command enters the interface configuration submode to configure parameters specific to the interface.

By default, an interface is not part of a bridge.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how to configure the bundle Ethernet interface as an attachment circuit:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
```

```

RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# interface gigabitethernet 0/1/0/9
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)#

```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# l2vpn resynchronize forwarding mac-address-table location

To retrieve a MAC address table from network processors and transfer the MAC address tables to the L2FIB manager, use the **l2vpn resynchronize forwarding mac-address-table location** command in EXEC mode.

**l2vpn resynchronize forwarding mac-address-table location** *node-id*

<b>Syntax Description</b>	<i>node-id</i> Location of the mac-address-table. The <i>node-id</i> argument is entered using the <i>rack/slot/module</i> notation.				
<b>Command Default</b>	None				
<b>Command Modes</b>	EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.9.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.9.0	This command was introduced.
Release	Modification				
Release 3.9.0	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>To ensure that correct information is displayed, enter this command before issuing any <b>show</b> commands for the mac address tables.</p> <p>The <b>l2vpn resynchronize forwarding mac-address-table location</b> command initiates the transfer of MAC learn information from the network processors, to the L2FIB manager. This operation is CPU intensive especially when there are 512K MACs. Therefore, the command is throttled, so that you cannot issue this command back to back. The throttle time depends on the number of MAC addresses. If the number of MAC addresses is under 16K MACs, the throttle time is five seconds. If it is between 16K and 128K, the throttle time is one minute, and if it is between 128K and 256K, the throttle time is two minutes. The throttle time is four minutes for MAC addresses above 256K.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write, execute</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write, execute
Task ID	Operations				
l2vpn	read, write, execute				
<b>Examples</b>	<p>The following example shows how to retrieve the MAC address table from the network processors:</p> <pre>RP/0/RSP0/CPU0:router# l2vpn resynchronize forwarding mac-address-table location 0/4/CPU0</pre>				
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">show l2vpn forwarding</a></td> <td>Displays forwarding information from the layer2_fib manager on the line card.</td> </tr> </tbody> </table>	Command	Description	<a href="#">show l2vpn forwarding</a>	Displays forwarding information from the layer2_fib manager on the line card.
Command	Description				
<a href="#">show l2vpn forwarding</a>	Displays forwarding information from the layer2_fib manager on the line card.				

## learning disable (VPLS)

To override the MAC learning configuration of a parent bridge or to set the MAC learning configuration of a bridge, use the **learning disable** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command.

**learning disable**  
**no learning disable**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	By default, learning is enabled on all bridge domains and all interfaces on that bridge inherits this behavior.				
<b>Command Modes</b>	L2VPN bridge group bridge domain MAC configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>When set, the <b>learning disable</b> command stops all MAC learning either on the specified interface or the bridge domain.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write
Task ID	Operations				
l2vpn	read, write				

### Examples

In the following example, MAC learning is disabled on all ports in the bridge domain called bar, which is applied to all interfaces in the bridge unless the interface has its own MAC learning enable command.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# learning disable
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.



Command	Description
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.

# level

To specify the APS message level, use the **level** command in the Ethernet ring G.8032 instance `aps-channel` configuration submode.

**level** *number*

<b>Syntax Description</b>	<i>number</i> The APS message level. The range is from between 0 to 7.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Ethernet ring G.8032 instance <code>aps-channel</code> configuration submode
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.1.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write

This example shows how to enable the G.8032 ring mode:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 r1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# instance 1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# description test
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# profile p1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# rpl port0 neighbor
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# inclusion-list vlan-ids e-g
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# aps-channel
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance-aps)# level 3
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

## limit (VPLS)

To set the MAC address limit for action, maximum, and notification and to enter L2VPN bridge group bridge domain MAC limit configuration mode, use the **limit** command in L2VPN bridge group bridge domain MAC configuration mode. To remove all limits that were previously configured under the MAC configuration submodes, use the **no** form of this command.

**limit**  
**no limit**

<b>Syntax Description</b>	This command has no keywords or arguments.
<b>Command Default</b>	None
<b>Command Modes</b>	L2VPN bridge group bridge domain MAC configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **limit** command to enter L2VPN bridge group bridge domain MAC limit configuration mode. The **limit** command specifies that one syslog message is sent or a corresponding trap is generated with the MAC limit when the action is violated.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how the MAC limit for the bridge bar is set to 100 with an action of shutdown. After the configuration, the bridge stops all forwarding after 100 MAC addresses are learned. When this happens, a syslog message and an SNMP trap are created.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 100
```

```
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action shutdown
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# notification both
```

Related Commands	Command	Description
	<a href="#">action (VPLS), on page 3</a>	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
	<a href="#">maximum (VPLS), on page 42</a>	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
	<a href="#">notification (VPLS), on page 54</a>	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

## mac (VPLS)

To enter L2VPN bridge group bridge domain MAC configuration mode, use the **mac** command in L2VPN bridge group bridge domain configuration mode. To disable all configurations added under the MAC configuration submodes, use the **no** form of this command.

**mac**  
**no mac**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **mac** command to enter L2VPN bridge group bridge domain MAC configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example shows how to enter L2VPN bridge group bridge domain MAC configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)#
```

Related Commands	Command	Description
	<a href="#">aging (VPLS), on page 5</a>	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">learning disable (VPLS), on page 32</a>	Overrides the MAC learning configuration of a parent bridge or sets the MAC learning configuration of a bridge.
<a href="#">limit (VPLS), on page 35</a>	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
<a href="#">static-address (VPLS), on page 110</a>	Adds static entries to the MAC address for filtering.
<a href="#">withdraw (VPLS), on page 123</a>	Disables MAC address withdrawal for a specified bridge domain

## mac secure

To configure MAC security at a port and to set the default action that is to be taken when security is violated, use the **mac secure** command in the L2VPN bridge group bridge domain configuration mode. Starting from Cisco IOS XR Release 7.5.2, you can use the command in the EVPN configuration mode as well.

To disable MAC security, use the **no** form of this command.

To configure MAC security in the L2VPN bridge-group, bridge-domain configuration mode use:

```
mac secure { action [{ none | shutdown | restrict }] | logging | disable |
shutdown-recovery-timeout timer-value }
```

Syntax Description		
<b>action</b>	(Optional) Indicates the action to be taken when security is violated.	
<b>none</b>	Forwards the violating packet and allows the MAC address to be relearned.	
<b>shutdown</b>	Shuts down the violating bridge port.	
<b>restrict</b>	Drops the violating packet and disables the learn attempt.	<b>Note</b> The <b>restrict</b> keyword in applicable to interfaces only.
<b>logging</b>	(Optional) Enables logging.	
<b>disable</b>	(Optional) Disables mac security.	
<b>shutdown-recovery-timeout</b> <i>timer-value</i>	Sets the Recovery timer to revert shutdown action automatically after the timer expires. Recovery timer value can be set in the range of 10 to 3600 seconds.	

To configure MAC security in the EVPN configuration mode use:

```
mac secure [ freeze-time freeze-time | move-count move-count | move-interval move-interval |
retry-count retry-count | | reset-freeze-count-interval interval ] disable
```

Syntax Description		
<b>freeze-time</b> <i>freeze-time</i>	Length of time to lock the MAC address after it has been detected as duplicate. Default is 30 seconds.	
<b>move-count</b> <i>move-count</i>	Number of moves to occur within the specified <b>move-interval</b> before freezing the MAC address. Default is 5.	
<b>move-interval</b> <i>move-interval</i>	Interval to watch for subsequent MAC moves before freezing the MAC address. Default is 180 seconds.	
<b>retry-count</b> <i>retry-count</i>	Number of times to unfreeze a MAC address before freezing it permanently. Default is three times.	
<b>reset-freeze-count-interval</b> <i>interval</i>	Interval after which the count of duplicate detection events is reset. Default is 24 hours. The range is from 1 hour to 48 hours.	
<b>disable</b>	Disable duplicate detection of MAC address.	

**Command Default** When configured in the L2VPN bridge-group, bridge-domain configuration mode, if a MAC address has been learned on a secure port and, a relearn attempt from another port (secure or not) is made, the default action is **restrict**.

**Command Modes** L2VPN bridge group bridge domain configuration  
EVPN configuration

Command History	Release	Modification
	Release 4.0.1	This command was introduced.
	Release 6.6.1	The keyword <b>shutdown-recovery-timeout</b> <i>timer-value</i> was introduced.
	Release 7.5.2	The command was modified to support EVPN configuration mode.

**Usage Guidelines** The MAC security recovery applies only for the Ethernet flow point (EFP) security. The Shutdown recovery timer does not apply to MAC limits configured on a per-EFP level, per-bridge domain level, or both.  
MAC secure is supported on physical and bundle AC, PW, and EVPN.

Task ID	Task ID	Operations
	l2vpn	Read, write

**Examples** This example shows how to enable mac security on bridge bar.

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group b1
Router(config-l2vpn-bg)# bridge-domain bar
Router(config-l2vpn-bg-bd)# mac secure
Router(config-l2vpn-bg-bd-mac-secure)#
```

This example shows how to shut down a violating bridge port on bridge bar:

```
Router# configure
Router(config)# l2vpn
Router(config-l2vpn)# bridge group b1
Router(config-l2vpn-bg)# bridge-domain bar
Router(config-l2vpn-bg-bd)# mac secure
Router(config-l2vpn-bg-bd-mac-secure)# action shutdown
Router(config-l2vpn-bg-bd-mac-secure)#
```

This example shows how to bring up or recover the bridge port that was shut down due to security violation.

```
Router(config-l2vpn-bg-bd-mac-secure)# interface GigabitEthernet0/0/0/5.11
Router(config-l2vpn-bg-bd-ac)# mac
```



```

Router(config-l2vpn-bg-bd-ac-mac) # secure
Router(config-l2vpn-bg-bd-ac-mac-secure) # action shutdown
Router(config-l2vpn-bg-bd-ac-mac-secure) # logging
Router(config-l2vpn-bg-bd-ac-mac-secure) # shutdown-recovery-timeout 600
Router(config-l2vpn-bg-bd-ac-mac-secure) # !

```

## Examples

This example shows how to enable MAC security in the EVPN configuration mode.

```

Router# configure
Router(config)# evpn
Router(config-evpn)# mac secure
Router(config-evpn-mac-secure)# move-count 7
Router(config-evpn-mac-secure)# move-interval 30
Router(config-evpn-mac-secure)# commit

```

## Related Commands

Command	Description
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

## maximum (VPLS)

To configure the specified action when the number of MAC addresses learned on a bridge is reached, use the **maximum** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

**maximum** *value*  
**no maximum** *value*

<b>Syntax Description</b>	<i>value</i> Maximum number of learned MAC addresses. The range is from 5 to 512000.
---------------------------	---

<b>Command Default</b>	The default maximum value is 4000.
------------------------	------------------------------------

<b>Command Modes</b>	L2VPN bridge group bridge domain MAC limit configuration
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

The action can either be flood, no flood, or shutdown. Depending on the configuration, a syslog, an SNMP trap notification, or both are issued.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

<b>Examples</b>	The following example shows when the number of MAC address learned on the bridge reaches 5000 and the bridge stops learning but continues flooding:
-----------------	---

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
```

```
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 5000
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action no-flood
```

Related Commands	Command	Description
	<a href="#">action (VPLS), on page 3</a>	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn	Enters L2VPN configuration mode.
	<a href="#">limit (VPLS), on page 35</a>	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
	<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
	<a href="#">notification (VPLS), on page 54</a>	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

## monitor interface (port0)

To specify a port to detect a ring link failure, use the **monitor interface** command in g8032 port0 submode. To delete the port, use the **no** form of this command.

**monitor interface** *interface-name*  
**no monitor interface** *interface-name*

<b>Syntax Description</b>	<i>interface-name</i> Name of the monitored interface. The monitored interface must be a sub-interface of the main interface.
---------------------------	---

<b>Command Default</b>	Configured physical Ethernet or Ether Bundle interface
------------------------	--

<b>Command Modes</b>	Ethernet ring g8032 port0 submode
----------------------	-----------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.1.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write

This example shows the output from the monitor interface command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 g1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# port0 interface TenGigE 0/4/0/0
RP/0/RSP0/CPU0:router(config-l2vpn-erp-port0)# monitor interface GigabitEthernet 0/0/1/0
RP/0/RSP0/CPU0:router(config-l2vpn-erp-port0)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

# monitor interface (port1)

To specify the port to detect a ring link failure, use the **monitor interface** command in g8032 port1 submode. To delete the port, use the **no** form of this command.

**monitor interface** *interface-name*  
**no monitor interface** *interface-name*

<b>Syntax Description</b>	<i>interface-name</i> Name of the monitored interface. The monitored interface must be a sub-interface of the main interface.						
<b>Command Default</b>	Configured physical Ethernet or ether bundle interface						
<b>Command Modes</b>	Ethernet ring g8032 port1 submode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.		
Release	Modification						
Release 4.1.0	This command was introduced.						
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write		
Task ID	Operation						
l2vpn	read, write						
	This example shows the output from the monitor interface command:						
	<pre>RP/0/RSP0/CPU0:router# <b>configure</b> RP/0/RSP0/CPU0:router(config)# <b>l2vpn</b> RP/0/RSP0/CPU0:router(config-l2vpn)# <b>ethernet ring g8032 g1</b> RP/0/RSP0/CPU0:router(config-l2vpn-erp)# <b>port1 interface TenGigE 0/4/0/0</b> RP/0/RSP0/CPU0:router(config-l2vpn-erp-port1)# <b>monitor interface GigabitEthernet 0/0/1/0</b> RP/0/RSP0/CPU0:router(config-l2vpn-erp-port1)#</pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">l2vpn</a></td> <td>Enters L2VPN configuration mode.</td> </tr> <tr> <td><a href="#">ethernet ring g8032, on page 17</a></td> <td>Enables G.8032 ring mode and enters the G.8032 configuration submode.</td> </tr> </tbody> </table>	Command	Description	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.
Command	Description						
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.						
<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.						

## mpls static label (VPLS)

To configure the MPLS static labels and the static labels for the access pseudowire configuration, use the **mpls static label** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To assign the dynamic MPLS labels to either the virtual forwarding interface (VFI) pseudowire or the access pseudowire, use the **no** form of this command.

**mpls static label local** *value value* **remote** *value*  
**no mpls static label local** *value value* **remote** *value*

### Syntax Description

**local** *value* Configures the local pseudowire label.

**Note** Use the **show mpls label range** command to obtain the range for the local labels.

**remote** Configures the remote pseudowire label.

*value* **Note** The range of values for the remote labels depends on the label allocator of the remote router.

### Command Default

By default, the router attempts to assign dynamic labels to the pseudowire.

### Command Modes

L2VPN bridge group bridge domain Access/VFI pseudowire configuration

### Command History

Release	Modification
Release 3.7.2	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Ensure that both ends of the pseudowire have matching static labels.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure the VFI pseudowire 10.1.1.2 with pseudowire ID of 1000 to use MPLS label 800 and remote MPLS label 500:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
```

```
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# mpls static label local 800 remote 500
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">neighbor (VPLS), on page 52</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
	<a href="#">pw-class , on page 62</a>	Configures the pseudowire class template name to use for the pseudowire.
	<a href="#">vfi (VPLS), on page 121</a>	Configures virtual forwarding interface (VFI) parameters.

## mtu (VPLS)

To adjust the maximum packet size or maximum transmission unit (MTU) size for the bridge domain, use the **mtu** command in L2VPN bridge group bridge domain configuration mode. To disable this feature, use the **no** form of this command.

**mtu** *bytes*  
**no mtu**

<b>Syntax Description</b>	<i>bytes</i> MTU size, in bytes. The range is from 46 to 65535.
---------------------------	---

<b>Command Default</b>	The default MTU value is 1500.
------------------------	--------------------------------

<b>Command Modes</b>	L2VPN bridge group bridge domain configuration
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Each interface has a default maximum packet size or MTU size. This number generally defaults to the largest size possible for that interface type. On serial interfaces, the MTU size varies, but cannot be set smaller than 64 bytes.

The MTU for the bridge domain includes only the payload of the packet. For example, a configured bridge MTU of 1500 allows tagged packets of 1518 bytes (6 bytes DA, 6 bytes SA, 2 bytes ethertype, or 4 bytes qtag).



<b>Note</b>	Bridge wide MTU is not enforced on the data traffic.
-------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

<b>Examples</b>	The following example specifies an MTU of 1000 bytes:
-----------------	---

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
```



```
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mtu 1000
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">flooding disable, on page 21</a>	Configures flooding for traffic at the bridge domain level or at the bridge port level.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# multicast p2mp

To enable point to multi-point pseudowire in a VFI and to enter L2VPN bridge group bridge domain VFI multicast P2MP configuration mode, use the **multicast p2mp** command in L2VPN bridge group bridge domain VFI configuration mode. To return to a VFI mode, use the **no** form of this command.

```
multicast p2mp [{signaling-protocol | transport}]
no multicast p2mp [{signaling-protocol | transport}]
```

Syntax Description	
<b>signaling-protocol</b>	Specifies the signaling protocol selection
<b>transport</b>	Specifies the transport type selection

**Command Default** None

**Command Modes** L2VPN bridge group bridge domain VFI configuration

Command History	Release	Modification
	Release 5.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read, write

## Example

This example shows how to configure a point to multi-point pseudowire in a VFI:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)# multicast p2mp
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-p2mp)#
```

Related Commands	Command	Description
	<a href="#">transport rsvp-te, on page 117</a>	Enables RSVP-TE as transport on a VFI.

Command	Description
<a href="#">vfi (VPLS), on page 121</a>	Configures virtual forwarding interface (VFI) parameters.
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

## neighbor (VPLS)

To add an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI), use the **neighbor** command in the appropriate L2VPN bridge group bridge domain configuration submode. To remove the pseudowire either from the bridge or from the VFI, use the **no** form of this command.

**neighbor** *A.B.C.D* **pw-id** *value*  
**no neighbor** *A.B.C.D* **pw-id** *value*

Syntax Description	
<i>A.B.C.D</i>	IP address of the cross-connect peer.
<b>pw-id</b> <i>value</i>	Configures the pseudowire ID and ID value. Range is 1 to 4294967295.

**Command Default** None

**Command Modes** L2VPN bridge group bridge domain configuration  
 L2VPN bridge group bridge domain VFI configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **neighbor** command to enter L2VPN bridge group bridge domain VFI pseudowire configuration mode. Alternatively, use the **neighbor** command to enter L2VPN bridge group bridge domain access pseudowire configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example shows how to configure an access pseudowire directly under a bridge domain in L2VPN bridge group bridge domain configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router (config)# l2vpn
RP/0/RSP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 1000
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd-pw)#
```

The following example shows how to configure the parameters for any pseudowire in L2VPN bridge group bridge domain VFI configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)#
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">mpls static label (VPLS), on page 46</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
	<a href="#">pw-class , on page 62</a>	Configures the pseudowire class template name to use for the pseudowire.
	<a href="#">static-mac-address (VPLS), on page 112</a>	Configures the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface.
	<a href="#">vfi (VPLS), on page 121</a>	Configures virtual forwarding interface (VFI) parameters.

## notification (VPLS)

To specify the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit, use the **notification** command in L2VPN bridge group bridge domain MAC limit configuration mode. To use the notification as only a syslog entry, use the **no** form of this command.

```
notification {both | none | trap}
no notification {both | none | trap}
```

<b>Syntax Description</b>	<p><b>both</b> Sends syslog and trap notifications when the action is violated.</p> <p><b>none</b> Specifies no notification.</p> <p><b>trap</b> Sends trap notifications when the action is violated.</p>				
<b>Command Default</b>	By default, only a syslog message is sent when the number of learned MAC addresses reaches the maximum configured.				
<b>Command Modes</b>	L2VPN bridge group bridge domain MAC limit configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>A syslog message and an SNMP trap is generated. Alternatively, an SNMP trap is generated. Finally, no notification is generated.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write
Task ID	Operations				
l2vpn	read, write				

### Examples

The following example shows how both a syslog message and an SNMP trap are generated with the bridge bar and learns more MAC addresses than the configured limit:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
```

```
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac) # limit
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-limit) # notification both
```

Related Commands	Command	Description
	<a href="#">action (VPLS), on page 3</a>	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
	<a href="#">maximum (VPLS), on page 42</a>	Configures the specified action when the number of MAC addresses learned on a bridge is reached.

# open ring

To specify Ethernet ring g8032 as an open ring, use the **open-ring** command in Ethernet ring g8032 configuration submode. To delete, use the **no** form of this command.

**open-ring**  
**no open-ring**

This command has no keywords or arguments.

## Command Default

The default value is FALSE.

## Command Modes

Ethernet ring g8032 configuration submode

## Command History

Release	Modification
Release 4.1.0	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
l2vpn	read, write

## Example

This example shows the output from the **open-ring** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 g1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# open-ring
RP/0/RSP0/CPU0:router(config-l2vpn-erp)#
```

## Related Commands

Command	Description
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.



# port0 interface

To enable G.8032 for a specified ring port, use the **port0 interface** command in g8032 configuration port0 submode. To disable, use the **no** form of this command.

**port 0 interface** *interface name*  
**no port 0 interface** *interface name*

<b>Syntax Description</b>	<i>interface name</i> Any physical Ethernet or Bundle Ethernet interface. A physical port of the local node connected to G.8032 ring.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Ethernet ring g8032 configuration port0 submode
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.1.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write

### Example

This example shows the output from the port0 interface command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 g1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# port0 interface Bundle-Ether 555
RP/0/RSP0/CPU0:router(config-l2vpn-erp-port0)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
		<a href="#">l2vpn</a>
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

# port1

To enable G.8032 for a specified ring port, use the **port1** command in g8032 configuration port1 submode. To disable, use the **no** form of this command.

**port1** {**interface** *interface name* | **none**}

<b>Syntax Description</b>	<b>interface</b> <i>interface name</i>	Specifies physical Ethernet or Bundle Ethernet interface. A physical port of the local node connected to G.8032 ring. Enables G.8032 for the specified physical port to form a closed ring.
	<b>none</b>	Specifies local node endpoint of an open-ring.
<b>Command Default</b>	None	
<b>Command Modes</b>	Ethernet ring g8032 configuration port1 submode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.1.0	This command was introduced.
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write

This example shows the output from the port1 command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 g1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# port1 interface TenGigE 0/6/0/3
RP/0/RSP0/CPU0:router(config-l2vpn-erp-port1)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

## port-down flush disable (VPLS)

To disable MAC flush when the bridge port is nonfunctional, use the **port-down flush disable** command in the L2VPN bridge group bridge domain MAC configuration mode. Use the **no** form of this command to enable the MAC flush when the bridge port is nonfunctional.

**port-down flush disable**  
**no port-down flush disable**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	L2VPN bridge group bridge domain MAC configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.9.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **port-down flush disable** command disables the MAC flush when the bridge port is nonfunctional.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how to disable MAC flush when the bridge port is nonfunctional:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# port-down flush disable
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">action (VPLS), on page 3</a>	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">maximum (VPLS), on page 42</a>	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
<a href="#">notification (VPLS), on page 54</a>	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

# profile

To specify an associated Ethernet ring G.8032 profile, use the **profile** command in the Ethernet ring G.8032 instance configuration submode.

**profile** *profile-name*

<b>Syntax Description</b>	<i>profile-name</i> Ethernet ring G.8032 profile name.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Ethernet ring G.8032 instance configuration submode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.1.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.1.0	This command was introduced.
Release	Modification				
Release 4.1.0	This command was introduced.				

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read, write

## Example

This example shows how to specify a G.8032 ring profile name:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 r1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# instance 1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# description test
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# profile p1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)#
```

Related Commands	Command	Description
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

# pw-class

To configure the pseudowire class template name to use for the pseudowire, use the **pw-class** command in L2VPN bridge group bridge domain Access pseudowire configuration mode. To delete the pseudowire class, use the **no** form of this command.

**pw-class** *class-name*  
**no pw-class** *class-name*

<b>Syntax Description</b>	<i>class-name</i> Pseudowire class name.						
<b>Command Default</b>	None						
<b>Command Modes</b>	L2VPN bridge group bridge domain Access pseudowire configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.		
Release	Modification						
Release 3.7.2	This command was introduced.						
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write		
Task ID	Operations						
l2vpn	read, write						
<b>Examples</b>	<p>The following example shows how to attach the pseudowire class to the pseudowire:</p> <pre>RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# l2vpn RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1 RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000 RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# pw-class canada</pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">bridge-domain (VPLS), on page 10</a></td> <td>Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.</td> </tr> <tr> <td><a href="#">bridge group (VPLS), on page 11</a></td> <td>Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.</td> </tr> </tbody> </table>	Command	Description	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
Command	Description						
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.						
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.						

Command	Description
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mpls static label (VPLS), on page 46</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
<a href="#">neighbor (VPLS), on page 52</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
<a href="#">vfi (VPLS), on page 121</a>	Configures virtual forwarding interface (VFI) parameters.

## pw-oam

To enable the Operations, Administration, and Maintenance (OAM) feature on a pseudowire for defect notifications, use the **pw-oam** command in L2VPN configuration submode. To disable the feature, use the **no** form of this command.

**pw-oam refresh transmit** *value*  
**no pw-oam refresh transmit** *value*

<b>Syntax Description</b>	<b>refresh transmit</b>	Refresh interval when outbound pseudowire status messages are transmitted.
	<i>value</i>	Interval value in seconds. The range is from 1 to 4095. The default value is 30.
<b>Command Default</b>	None	
<b>Command Modes</b>	L2VPN configuration submode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.2.0	This command was introduced.
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write
<b>Example</b>		
This example shows how to enable the oam feature on a pseudowire:		
<pre>RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# l2vpn RP/0/RSP0/CPU0:router(config-l2vpn)# pw-oam refresh transmit RP/0/RSP0/CPU0:router(config-l2vpn)# pw-oam refresh transmit 456</pre>		
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">pw-class (L2VPN)</a>	Enters pseudowire class submode to define a pseudowire class template.



# pw-status (L2VPN)

To enable status signaling on a pseudowire, use the **pw-status** command in L2VPN configuration submode. To disable the pseudowire status signaling, use the **no** form of this command.

**pw-status**  
**no pw-status**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN configuration submode

Command History	Release	Modification
	Release 4.0.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Cisco IOS XR software provides two methods for signaling pseudowires (PW) status:

- Using Label Withdraw Message

The provider edge routers (PEs) send Label Mapping Message to their peers as soon as the pseudowire is configured and administratively enabled. The pseudowire label should not be withdrawn unless the pseudowire is administratively disabled or deleted.

- Using PW status TLV

The PEs use LDP pseudowire status TLV to indicate pseudowire status to their peers. The LDP pseudowire status TLV contains additional information compared to the Label Withdraw Message.



**Note** Unless pseudowire status TLV is explicitly enabled under L2VPN configuration, the default signaling method is Label Withdrawal.

Task ID	Task ID	Operations
	l2vpn	read, write

**Examples** The following example shows how to enable pseudowire status signaling on configured pseudowires:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# pw-status
RP/0/RSP0/CPU0:router(config-l2vpn)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# route-target

To specify a route target for the VFI, use the **route-target** command in the BGP autodiscovery mode. To return to the default value, use the **no** form of this command.

**route-target** {*as-number:nn ip-address:nn* }  
**no route-target** {*as-number:nn ip-address:nn* }

**Syntax Description**

*as-number:nn* Autonomous system (AS) number of the route distinguisher.

- *as-number*—16-bit AS number  
 Range for 2-byte numbers is 1 to 65535. Range for 4-byte numbers is 1.0 to 65535.65535.
- *nn*—32-bit number

*ip-address:nn* IP address of the route distinguisher.

- *ip-address*—32-bit IP address
- *nn*—16-bit number

**Command Default**

None.

**Command Modes**

BGP autodiscovery configuration

**Command History**

Release	Modification
Release 4.0.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

Task ID	Operations
l2vpn	read, write

**Examples**

The following example shows how to configure a bridge domain:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group EGroup
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain eastdomain
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi eastvfi
```

```
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd-vfi) # autodiscovery bgp
RP/0/RSP0/CPU0:router (config-l2vpn-bg-bd-vfi-ad) #route-target 100:20
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# routed

To specify the bridge domain L3 interface, use the **routed** command in L2VPN bridge-group bridge-domain configuration submenu. To revert, use the **no** form of the command.

**routed interface BVI BVI interface number**  
**no routed interface BVI BVI interface number**

Syntax Description	interface	Bridge domain L3 interface.
	BVI	Bridge-Group Virtual Interface.
	<i>BVI interface number</i>	BVI interface number. The range is 1-65535.

**Command Default** None

**Command Modes** L2VPN bridge-group bridge-domain configuration submenu

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read, write

The example shows how to specify the L3 bridge domain interface:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group bg1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bd1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# routed interface BVI 100
```

Related Commands	Command	Description
	<a href="#">dynamic-arp-inspection</a>	Validates Address Resolution Protocol (ARP) packets in a network.
	<a href="#">ip-source-guard</a>	Enables source IP address filtering on a layer 2 port.
	<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.

Command	Description
<a href="#">mtu (VPLS), on page 48</a>	Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.
<a href="#">neighbor (VPLS), on page 52</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
<a href="#">pbb</a>	Configures the provider backbone bridge core or edge.
<a href="#">shutdown (Bridge Domain), on page 103</a>	Shuts down a bridge domain to bring the bridge and all attachment circuits and pseudowires under it to admin down state.
<a href="#">vfi (VPLS), on page 121</a>	Configures virtual forwarding interface (VFI) parameters.

# rpl

To specify one ring port on local node being RPL owner, neighbor or next-neighbor, use the **rpl** command in the Ethernet ring G.8032 instance configuration submode. To disable the port as RPL owner, neighbor or next-neighbor, use the **no** form of this command.

**rpl** {port0 | port1} {owner | neighbor | next-neighbor}  
**no rpl** {port0 | port1} {owner | neighbor | next-neighbor}

Syntax Description		
	<b>port0</b>	Assigns port0 as RPL owner, neighbor or next-neighbor.
	<b>port1</b>	Assigns port1 as RPL owner, neighbor or next-neighbor.
	<b>owner</b>	Assigns port0 or port1 as RPL owner.
	<b>neighbor</b>	Assigns port0 or port1 as neighbor.
	<b>next-neighbor</b>	Assigns port0 or port1 as next neighbor.

**Command Default** None

**Command Modes** Ethernet ring G.8032 instance configuration submode

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows how to assign port0 as neighbor:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# ethernet ring g8032 r1
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# instance 1
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# description test
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# profile p1
```

```
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)# rpl port0 neighbor  
RP/0/RSP0/CPU0:router(config-l2vpn-erp-instance)#
```

Related Commands	Command	Description
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.



# show ethernet ring g8032

To display Ethernet ring G.8032 Protection data, use the **show ethernet ring g8032** command in the EXEC mode.

**show ethernet ring g.8032** {**brief** *ring-name* | **profile** *ring-profile-name* | **statistics** | **status** {*ring-name* | **location** *location*} | **summary**}

Syntax Description	
<b>brief</b>	Displays brief information on the G.8032 ethernet ring.
<b>profile</b>	Displays information about the G.8032 ethernet ring profile.
<b>statistics</b>	Displays the statistics of the G.8032 ethernet ring.
<b>status</b>	Displays the status of the G.8032 ethernet ring.
<b>summary</b>	Displays a summary of the G.8032 ethernet ring.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	vlan	read
	interface	read
	ethernet-services	read

This example shows the output of the **show ethernet ring g8032** command:

```
RP/0/RSP0/CPU0:router# show ethernet ring g8032 status
```

```
Ethernet ring Subring instance 1 is RPL Owner node in Protection state
Port0: Bundle-Ether100 (Monitor: Bundle-Ether100)
      APS-Channel: Bundle-Ether100.1
      Status: RPL, faulty, blocked
      Remote R-APS NodeId: 0000.0000.0000, BPR: 0
Port1: GigabitEthernet0/0/0/38 (Monitor: GigabitEthernet0/0/0/38)
      APS-Channel: GigabitEthernet0/0/0/38.1
```

## show ethernet ring g8032

```

        Status: NonRPL
        Remote R-APS NodeId: 0000.0000.0000, BPR: 0
    APS Level: 7
    Open APS ring topology
    Profile: timer-wtr (not defined)
        WTR interval: 5 minutes
        Guard interval: 500 milliseconds
        Hold-off interval: 0 seconds
        Revertive mode

Ethernet ring Subring-2 instance 1 is RPL Owner node in Idle state
    Port0: GigabitEthernet0/0/0/33 (Monitor: GigabitEthernet0/0/0/33)
        APS-Channel: GigabitEthernet0/0/0/33.1
        Status: RPL, blocked
        Remote R-APS NodeId: 0000.0000.0000, BPR: 0
    Port1: GigabitEthernet0/0/0/3 (Monitor: GigabitEthernet0/0/0/3)
        APS-Channel: GigabitEthernet0/0/0/3.1
        Status: NonRPL
        Remote R-APS NodeId: 0000.0000.0000, BPR: 0
    APS Level: 7
    Open APS ring topology
    Profile: timer-wtr (not defined)
        WTR interval: 5 minutes
        Guard interval: 500 milliseconds
        Hold-off interval: 0 seconds
        Revertive mode
RP/0/RSP0/CPU0:router#

```

```

RP/0/RSP0/CPU0:router# show ethernet ring g8032 brief
Wed Mar 16 07:14:28.719 UTC

```

```

R: Interface is the RPL-link
F: Interface is faulty
B: Interface is blocked
FS: Local forced switch
MS: Local manual switch

```

RingName	Inst	NodeType	NodeState	Port0	Port1
Subring	1	Owner	Protection	R, F, B	
Subring-2	1	Owner	Idle	R, B	

```

RP/0/RSP0/CPU0:F4-2-A9K#

```

```

RP/0/RSP0/CPU0:router# show ethernet ring g8032 summary
Wed Mar 16 07:14:52.419 UTC

```

```

Chassis Node Id 0026.982b.c6e7

```

```

States
-----
Init           0
Idle           1
Protection     1
Manual Switch  0
Forced Switch  0
Pending        0
-----
Total          2
RP/0/RSP0/CPU0:router#

```

```

RP/0/RSP0/CPU0:router# show ethernet ring g8032 statistics Subring instance 1

```

```

Statistics for Ethernet ring Subring instance 1
Local SF detected:
  Port0: 1
  Port1: 0

R-APS   Port0 (Tx/Rx)           Port1 (Tx/Rx)
        Last Tx time         Last Tx time
        Last Rx time         Last Rx time
-----
NR      : 3/0
        Tue Mar 15 04:41:00.964 UTC   Never
        Never                       Never
NR,RB   : 0/0
        Never                       Never
        Never                       Never
SF      : 19129/0
        Wed Mar 16 07:15:28.995 UTC   Wed Mar 16 07:15:28.774 UTC
        Never                       Never
MS      : 0/0
        Never                       Never
        Never                       Never
FS      : 0/0
        Never                       Never
        Never                       Never
EVENT   : 0/0
        Never                       Never
        Never                       Never

State           Last entry into state time
-----
Init            : Tue Mar 15 04:41:00.933 UTC
Idle            : Never
Protection     : Tue Mar 15 04:41:00.973 UTC
Manual Switch  : Never
Forced Switch  : Never
Pending        : Tue Mar 15 04:41:00.962 UTC
RP/0/RSP0/CPU0:router#

RP/0/RSP0/CPU0:router# show ethernet ring g8032 profile timer-wtr
Wed Mar 16 07:20:04.996 UTC

Ethernet ring profile name: timer-wtr
  WTR interval: 1 minutes
  Guard interval: 500 milliseconds
  Hold-off interval: 0 seconds
  Revertive mode
RP/0/RSP0/CPU0:router#
    
```

Related Commands	Command	Description
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

## show l2vpn bridge-domain (VPLS)

To display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains, use the **show l2vpn bridge-domain** command in EXEC mode.

```
show l2vpn bridge-domain [{autodiscovery | bd-name bridge-domain-name | brief | detail | group
bridge-domain-group-name | hardware | interface type interface-path-id] neighbor IP-address
[{pw-id value | pbb | summary}]
```

Syntax Description	
<b>autodiscovery</b>	(Optional) Displays BGP autodiscovery information.
<b>bd-name</b> <i>bridge-domain-name</i>	(Optional) Displays filter information on the <i>bridge-domain-name</i> . The <i>bridge-domain-name</i> argument is used to name a bridge domain.
<b>brief</b>	(Optional) Displays brief information about the bridges.
<b>detail</b>	(Optional) Displays detailed information about the bridges. Also, displays the output for the Layer 2 VPN (L2VPN) to indicate whether or not the MAC withdrawal feature is enabled and the number of MAC withdrawal messages that are sent or received from the pseudowire.
<b>group</b> <i>bridge-domain-group-name</i>	(Optional) Displays filter information on the bridge-domain group name. The <i>bridge-domain-group-name</i> argument is used to name the bridge domain group.
<b>hardware</b>	(Optional) Displays hardware information.
<b>interface</b> <i>type interface-path-id</i>	(Optional) Displays the filter information for the interface on the bridge domain. <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>neighbor</b> <i>ip-address</i>	(Optional) Displays the bridge domains that contain the pseudowires to match the filter for the neighbor. The <i>ip-address</i> argument is used to specify IP address of the neighbor.
<b>pw-id</b> <i>value</i>	(Optional) Displays the filter for the pseudowire ID. The range is from 1 to 4294967295.
<b>pbb</b>	(Optional) Displays provider backbone bridge information.
<b>summary</b>	(Optional) Displays the summary information for the bridge domain.
<b>Command Default</b>	None
<b>Command Modes</b>	EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** Use the **interface** keyword to display only the bridge domain that contains the specified interface as an attachment circuit. In the sample output, only the attachment circuit matches the filter that is displayed. No pseudowires are displayed.

Task ID	Task ID	Operations
	l2vpn	read

**Examples**

This is the sample output for **show l2vpn bridge-domain** command with VxLAN parameters configured:

```
RP/0/RSP0/CPU0:router# show l2vpn bridge-domain bd-name bg1_bd1 detail
Legend: pp = Partially Programmed.
Bridge group: bg1, bridge-domain: bg1_bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Coupled state: disabled
  MAC learning: enabled
  MAC withdraw: enabled
    MAC withdraw for Access PW: enabled
    MAC withdraw sent on: bridge port up
    MAC withdraw relaying (access to access): disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
  Storm Control: disabled
  Bridge MTU: 1500
  MIB cvplsConfigIndex: 1
  Filter MAC addresses:
  P2MP PW: disabled
  Create time: 30/03/2015 22:25:38 (00:26:08 ago)
  No status change since creation
  ACs: 2 (2 up), VFIs: 1, PWs: 0 (0 up), PBBs: 0 (0 up)
  List of ACs:
    AC: BV11, state is up
      Type Routed-Interface
      MTU 1514; XC ID 0x80000001; interworking none
      BVI MAC address:
        1000.4444.0001
    AC: GigabitEthernet0/8/0/0.1, state is up
      Type VLAN; Num Ranges: 1
      Outer Tag: 1
      VLAN ranges: [1001, 1001]
```

## show l2vpn bridge-domain (VPLS)

```

MTU 1508; XC ID 0x508000a; interworking none
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
MAC port down flush: enabled
MAC Secure: disabled, Logging: disabled
Split Horizon Group: none
Dynamic ARP Inspection: disabled, Logging: disabled
IP Source Guard: disabled, Logging: disabled
DHCPv4 snooping: disabled
IGMP Snooping: enabled
IGMP Snooping profile: none
MLD Snooping profile: none
Storm Control: bridge-domain policer
Static MAC addresses:

Storm control drop counters:
  packets: broadcast 0, multicast 0, unknown unicast 0
  bytes: broadcast 0, multicast 0, unknown unicast 0
Dynamic ARP inspection drop counters:
  packets: 0, bytes: 0
IP source guard drop counters:
  packets: 0, bytes: 0
List of VNIs:
VNI 1, state is up
XC ID 0x80000014
Encap type VXLAN
Overlay nve100, Source 10.0.0.1, Multicast Group 225.1.1.1, UDP Port 4789
Anycast VTEP 100.1.1.1, Anycast Multicast Group 224.10.10.1
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
MAC port down flush: enabled
MAC Secure: disabled, Logging: disabled
Split Horizon Group: none
Dynamic ARP Inspection: disabled, Logging: disabled
IP Source Guard: disabled, Logging: disabled
DHCPv4 snooping: disabled
IGMP Snooping: enabled
IGMP Snooping profile: none
MLD Snooping profile: none
Storm Control: bridge-domain policer

List of Access PWs:
List of VFIs:
VFI bgl_bdl_vfi (up)
VFI Statistics:
  drops: illegal VLAN 0, illegal length 0

```

The following sample output shows information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains:

```

RP/0/RSP0/CPU0:router# #show l2vpn bridge-domain
Tue Feb 23 20:21:56.758 PST

```

```

Bridge group: 189, bridge-domain: 189, id: 0, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 2 (2 up), VFIs: 0, PWs: 0 (0 up), PBBs: 0 (0 up)
  List of ACs:
    Gi0/1/0/3.189, state: up, Static MAC addresses: 0
    Gi0/1/0/7.189, state: up, Static MAC addresses: 0
  List of Access PWs:
  List of VFIs:
Bridge group: 190, bridge-domain: 190, id: 1, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 0 (0 up), VFIs: 1, PWs: 3 (3 up), PBBs: 0 (0 up)
  List of ACs:
  List of Access PWs:
  List of VFIs:
    VFI 190
      Neighbor 10.19.19.19 pw-id 190, state: up, Static MAC addresses: 0
Bridge group: 210, bridge-domain: 210, id: 2, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up), PBBs: 0 (0 up)
  List of ACs:
    Gi0/1/0/7.210, state: up, Static MAC addresses: 0
  List of Access PWs:
  List of VFIs:
    VFI 210
      Neighbor 10.19.19.19 pw-id 210, state: up, Static MAC addresses: 0
Bridge group: 211, bridge-domain: 211, id: 3, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up), PBBs: 0 (0 up)
  List of ACs:
    Gi0/1/0/7.211, state: up, Static MAC addresses: 0
  List of Access PWs:
  List of VFIs:
    VFI 211
      Neighbor 10.19.19.19 pw-id 211, state: up, Static MAC addresses: 0
Bridge group: 215, bridge-domain: 215, id: 4, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 2 (2 up), VFIs: 1, PWs: 1 (1 up), PBBs: 0 (0 up)
  List of ACs:
    Gi0/1/0/3.215, state: up, Static MAC addresses: 0
    Gi0/1/0/7.215, state: up, Static MAC addresses: 0
  List of Access PWs:
  List of VFIs:
    VFI 215
      Neighbor 10.19.19.19 pw-id 215, state: up, Static MAC addresses: 0
Bridge group: 2130, bridge-domain: 2130, id: 5, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up), PBBs: 0 (0 up)
  List of ACs:
    Gi0/1/0/7.2130, state: up, Static MAC addresses: 0
  List of Access PWs:
  List of VFIs:
    VFI 2130
      Neighbor 10.19.19.19 pw-id 2130, state: up, Static MAC addresses: 0

```

This table describes the significant fields shown in the display.

**Table 1: show l2vpn bridge-domain Command Field Descriptions**

Field	Description
Bridge group	Name of bridge domain group is displayed.
bridge-domain	Name of bridge domain is displayed.
id	ID assigned to this bridge domain is displayed.
state	Current state of the bridge domain is displayed.
ShgId	ID for the default Split Horizon Group assigned to all attachment circuits and access pseudowires that are part of this bridge domain is displayed.  <b>Note</b> Members of the special Split Horizon Group ID 0 forwards to other members of the same SPG.

The following example shows sample output for a bridge named bd1:

```
RP/0/RSP0/CPU0:router# show l2vpn bridge-domain bd-name bd1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0
```

The following sample output shows brief information about the bridges:

```
RP/0/RSP0/CPU0:router# show l2vpn bridge-domain brief
Bridge Group/Bridge-Domain Name  ID    State    Num ACs/up    Num PWs/up
-----
bg1/bd1                          0     up       1/1           0/0
bg1/bd2                          1     up       0/0           0/0
bg1/bd3                          2     up       0/0           0/0
```

This table describes the significant fields shown in the display.

**Table 2: show l2vpn bridge-domain brief Command Field Descriptions**

Field	Description
Bridge Group/Bridge-Domain Name	Bridge domain group name followed by the bridge domain name are displayed.
ID	ID assigned to this bridge domain is displayed.
State	Current state of the bridge domain is displayed.
Num ACs/up	Total number of attachment circuits that are up in this bridge domain is displayed.



Field	Description
Num PWs/up	Total number of pseudowires that are up in this bridge domain is displayed. The count includes both VFI pseudowires and access pseudowires.

The following sample output shows detailed information for IOS-XR releases 5.3.1 and earlier releases.

```
RP/0/RSP0/CPU0:router# show l2vpn bridge-domain detail

Bridge group: 210, bridge-domain: 210, id: 2, state: up, ShgId: 0, MSTi: 0
  MAC learning: enabled
  MAC withdraw: disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  Split Horizon Group: none
  DHCPv4 snooping: disabled
  IGMP Snooping profile: none
  Bridge MTU: 9000
  Filter MAC addresses:
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
  List of ACs:
    AC: GigabitEthernet0/1/0/7.210, state is up
      Type VLAN; Num Ranges: 1
      vlan ranges: [100, 100]
      MTU 9008; XC ID 0x440007; interworking none; MSTi 0 (unprotected)
      MAC learning: enabled
      Flooding:
        Broadcast & Multicast: enabled
        Unknown unicast: enabled
      MAC aging time: 300 s, Type: inactivity
      MAC limit: 4000, Action: none, Notification: syslog
      MAC limit reached: no
      Security: disabled
      Split Horizon Group: enabled
      DHCPv4 snooping: disabled
      IGMP Snooping profile: none
      Storm Control: disabled
      Static MAC addresses:
      Statistics:
        packet totals: receive 31645, send 6
        byte totals: receive 2405020, send 456
      Storm control drop counters:
        packet totals: broadcast 0, multicast 0, unknown unicast 0
        byte totals: broadcast 0, multicast 0, unknown unicast 0
  List of Access PWs:
  List of VFIs:
    VFI 210
      PW neighbor 10.19.19.19, PW ID 210, state is up ( established )
      PW class not set, XC ID 0xffffc0004
      Encapsulation MPLS, protocol LDP
      PW type Ethernet, control word disabled, interworking none
      PW backup disable delay 0 sec
      Sequencing not set
      MPLS          Local          Remote
      -----
      Label          16001          16
```

## show l2vpn bridge-domain (VPLS)

```

Group ID      0x2                      0x0
Interface     210                      unknown
MTU           9000                      9000
Control word   disabled                    disabled
PW type       Ethernet                Ethernet
VCCV CV type  0x2                      0x2
                (LSP ping verification)      (LSP ping verification)
VCCV CC type  0x6                      0x2
                (router alert label)        (router alert label)
                (TTL expiry)
-----
Create time: 13/04/1900 14:36:13 (17:46:22 ago)
Last time status changed: 13/04/1900 15:37:03 (16:45:32 ago)
MAC withdraw message: send 0 receive 0
Static MAC addresses:
Statistics:
  packet totals: receive 6, send 31655
  byte totals: receive 432, send 2279160
IGMP Snooping profile: none
VFI Statistics:
  drops: illegal VLAN 0, illegal length 0

```

The following sample output shows that when a bridge operates in VPLS mode, the irrelevant information for MAC learning is suppressed:

```

RP/0/RSP0/CPU0:router# show l2vpn bridge-domain detail
Bridge group: gl, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
MAC learning: enabled
MAC withdraw: disabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
MTU: 1500
Filter MAC addresses:
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  AC: GigabitEthernet0/1/0/0, state is up
  Type Ethernet
  MTU 1500; XC ID 0x2000001; interworking none; MSTi 0
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Security: disabled
  DHCPv4 snooping: disabled
  Static MAC addresses:
    0000.0000.0000
    0001.0002.0003

List of Access PWs:
List of VFIs:
  VFI 1
    PW: neighbor 10.0.0.1, PW ID 1, state is up ( established )
    PW class mpls, XC ID 0xff000001
    Encapsulation MPLS, protocol LDP

```

```

PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
      MPLS          Local          Remote
-----
Label          16003          16003
Group ID       0x0            0x0
Interface      1              1
MTU            1500          1500
Control word   disabled      disabled
PW type        Ethernet     Ethernet
VCCV CV type   0x2           0x2
                (LSP ping verification)   (LSP ping verification)
VCCV CC type   0x2           0x2
                (router alert label)   (router alert label)
-----
Create time: 12/03/2008 14:03:00 (17:17:30 ago)
Last time status changed: 13/03/2008 05:57:58 (01:22:31 ago)
MAC withdraw message: send 0 receive 0
Static MAC addresses:

```

```

VFI Statistics:
  drops: illegal VLAN 0, illegal length 0

```

```

Bridge group: g2, bridge-domain: pbb-bd1, id: 1, state: up, ShgId: 0, MSTi: 0
Type: pbb-edge, I-SID: 1234
Core-bridge: pbb-bd2
MAC learning: enabled
MAC withdraw: disabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
MTU: 1500
Filter MAC addresses:

```

```

ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)

```

```

List of PBBs:

```

```

PBB Edge, state is up
XC ID 0x2000001
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Split Horizon Group: none
DHCPv4 snooping: disabled
IGMP Snooping profile:
Storm Control: disabled
Unknown-unicast-bmac: 666.777.888
CMAC to BMAC Mapping Table:
  CMAC          |          BMAC
  -----
  222.333.444   |   777.888.999
  333.444.555   |   888.999.111

```

```

Statistics:
  packet totals: receive 3919680,send 9328
  byte totals: receive 305735040,send 15022146

```

## show l2vpn bridge-domain (VPLS)

## List of ACs:

```

AC: GigabitEthernet0/1/0/0, state is up
  Type Ethernet
  MTU 1500; XC ID 0x2000001; interworking none; MSTi 0
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Security: disabled
  DHCPv4 snooping: disabled
  Static MAC addresses:
    0000.0000.0000
    0001.0002.0003

```

```

Bridge group: g2, bridge-domain: pbb-bd2, id: 2, state: up, ShgId: 0, MSTi: 0

```

```

  Type: pbb-core
  Number of associated pbb-edge BDs: 1
  MAC learning: enabled
  MAC withdraw: disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Security: disabled
  DHCPv4 snooping: disabled
  MTU: 1500
  Filter MAC addresses:

```

```

ACs: 1 (1 up), VFIs: 0, PWs: 0 (0 up), PBBs: 1 (1 up)

```

## List of PBBs:

```

PBB Core, state is up
  Vlan-id: 1; XC ID 0x2000001
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 600, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  Split Horizon Group: none
  DHCPv4 snooping: profile foo
  IGMP Snooping profile:
  Storm Control: disabled

```

## List of ACs:

```

AC: GigabitEthernet0/1/0/0, state is up
  Type Ethernet
  MTU 1500; XC ID 0x2000001; interworking none; MSTi 0
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Security: disabled

```

```

DHCPv4 snooping: disabled
Static MAC addresses:
  0000.0000.0000
  0001.0002.0003

```

This table describes the significant fields shown in the display.

**Table 3: show l2vpn bridge-domain detail Command Field Descriptions**

Field	Description
Bridge group	Name of bridge domain group is displayed.
bridge-domain	Name of bridge domain is displayed.
ID	ID assigned to this bridge domain is displayed.
state	Current state of the bridge domain is displayed.
ShgId	Split horizon group ID. This field is not used.
MSTi	ID for the Multiple Spanning Tree.
Split Horizon Group	Shows whether the AC is a member of the split horizon group for ACs. There is only one split horizon group for ACs per bridge domain. <ul style="list-style-type: none"> <li>• Enabled—The port belongs to the split horizon group for ACs.</li> <li>• None—The port does not belong to the split horizon group for ACs.</li> </ul>

The following sample output shows filter information about the bridge-domain group named g1:

```

RP/0/RSP0/CPU0:router# show l2vpn bridge-domain group g1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
  List of ACs:
    Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
  List of Access PWs:
  List of VFIs:
    VFI 1
      Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows display the filter information for the interface on the bridge domain for IOS-XR 5.3.1 and earlier releases:

```

RP/0/RSP0/CPU0:router# show l2vpn bridge-domain interface gigabitEthernet 0/1/0/0

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
  List of ACs:
    Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)

```

**show l2vpn bridge-domain (VPLS)**

The following sample output shows that the bridge domain contains the pseudowires to match the filter for the neighbor for IOS-XR 5.3.1 and earlier releases:

```
RP/0/RSP0/CPU0:router# show l2vpn bridge-domain neighbor 10.1.1.1

Bridge group: g1, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0
```

The following sample output shows the summary information for the bridge domain:

```
RP/0/RSP0/CPU0:router# show l2vpn bridge-domain summary

Number of groups: 1, bridge-domains: 2, Up: 2, Shutdown: 0
Default: 0, pbb-edge: 1, pbb-core: 1
Number of ACs: 1 Up: 1, Down: 0
Number of PWs: 0 Up: 0, Down: 0
```

This table describes the significant fields shown in the display.

**Table 4: show l2vpn bridge-domain summary Command Field Descriptions**

Field	Description
Number of groups	Number of configured bridge domain groups is displayed.
bridge-domains	Number of configured bridge domains is displayed.
Shutdown	Number of bridge domains that are in Shutdown state is displayed.
Number of ACs	Number of attachment circuits that are in Up state and Down state are displayed.
Number of PWs	Number of pseudowires that are in Up state and Down state are displayed. This includes the VFI pseudowire and the access pseudowire.

**Related Commands**

Command	Description
<a href="#">clear l2vpn bridge-domain (VPLS), on page 12</a>	Clears the MAC addresses and restarts the bridge domains on the router.

## show l2vpn ethernet ring g8032

To display an overview of the G.8032 ethernet ring configuration, use the **show l2vpn ethernet ring g8032** command in EXEC mode.

```
show l2vpn ethernet ring g8032 [name] [{brief | detail | instance ID | private}]
```

Syntax Description	
<i>name</i>	Ethernet ring G.8032 name.
<b>brief</b>	Brief information about the G.8032 ethernet ring configuration.
<b>detail</b>	Information in detail about the G.8032 ethernet ring configuration.
<b>instance</b> <i>ID</i>	Instance number about the G.8032 ethernet ring configuration.
<b>private</b>	Private information about the G.8032 ethernet ring configuration.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

### Example

This example shows the output from the **show l2vpn ethernet ring g8032** command:

```
# show l2vpn ethernet ring g8032 foo instance 1
Ethernet ring g8032 foo
  Port0: GigabitEthernet0/1/2/0
  Port1: GigabitEthernet0/1/2/1
  Instance 1
    Inclusion-list vlan ids: 500-1000, 1017
    aps-channel
      port0: GigabitEthernet0/1/2/0.1
      port1: GigabitEthernet0/1/2/1.1

# show l2vpn ethernet ring g8032 foo instance 1 brief
```

## show l2vpn ethernet ring g8032

```

Ring      instance  status
-----  -
Foo       1           resolved

# show l2vpn ethernet ring g8032 foo instance 1 detail
Ethernet ring g8032 foo
  Operating in Provider Bridge mode
  Port0: GigabitEthernet0/1/2/0
    Monitor: none
  Port1: GigabitEthernet0/1/2/1
    Monitor: none
  Exclusion-list vlan ids: 2000-2100, untagged
  Open-ring: no

Instance 1
  Description: This_is_a_sample
  Profile      : none
  RPL         : none
  Inclusion-list vlan ids: 500-1000, 1017
  aps-channel
    level: 7
    port0: GigabitEthernet0/1/2/0.1
    port1: GigabitEthernet0/1/2/1.1

# show l2vpn ethernet ring g8032 foo instance 1 private
Ethernet ring g8032 foo (task-id = cisco-support)
  Operating in Provider Bridge mode
  Port0: GigabitEthernet0/1/2/0
    Monitor: none
  Port1: GigabitEthernet0/1/2/1
    Monitor: none
  Exclusion-list vlan ids: 2000-2100, untagged
  Open-ring: no

Instance 1
  Description: This_is_a_sample
  Profile      : none
  RPL         : none
  Inclusion-list vlan ids: 500-1000, 1017
  aps-channel
    level: 7
    port0: GigabitEthernet0/1/2/0.1
    port1: GigabitEthernet0/1/2/1.1

ethernet ring g8032 trace history [Num events: 6]
-----
Time           Event           Sticky Many
====           =====
05/18/2010 21:45:54 Create          No      No
05/18/2010 21:45:54 Resolved        No      No
05/18/2010 21:45:57 Create          No      No
05/18/2010 21:45:57 Modify          No      No
05/18/2010 21:45:57 Resolved        No      No
05/18/2010 21:45:57 Delete          No      No

```

## Related Commands

Command	Description
<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.



# show l2vpn forwarding bridge-domain (VPLS)

To display information on the bridge that is used by the forwarding layer, use the **show l2vpn forwarding bridge-domain** command in EXEC mode.

```
show l2vpn forwarding bridge-domain [bridge-domain-name] {detail | hardware {egress | ingress}}
location node-id
```

Syntax Description	
<i>bridge-domain-name</i>	(Optional) Name of a bridge domain.
<b>detail</b>	Displays all the detailed information on the attachment circuits and pseudowires.
<b>hardware</b>	Displays the hardware location entry.
<b>egress</b>	Reads information from the egress PSE.
<b>ingress</b>	Reads information from the ingress PSE.
<b>location</b> <i>node-id</i>	Displays the bridge-domain information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For each bridge, you can display summary information about the number of bridge ports, number of MAC addresses, configured VXLANs and so forth.

The **detail** keyword displays detailed information on the attachment circuits and pseudowires, and is meant for field investigation by a specialized Cisco engineer.



**Note** All bridge ports in the bridge domain on that line card are displayed. Therefore, if the bridge domain contains non-local bridge ports, those are displayed as well.

Task ID	Task ID	Operations
	l2vpn	read

## Examples

The following sample output shows bridge-domain information for location 0/1/CPU0 for IOS-XR 5.3.1 and earlier releases:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain location 0/1/CPU0

Bridge-Domain Name          ID      Ports addr  Flooding Learning State
-----
g1:bd1

Bridge-domain name: g1:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/0, state: oper up
Number of MAC: 32770
Sent(Packets/Bytes): 0/21838568
Received(Packets/Bytes): 5704781/444972918

Nbor 10.0.0.1 pw-id 1
Number of MAC: 32766
Sent(Packets/Bytes): 0/0
Received(Packets/Bytes): 5703987/444910986
0      2      65536 Enabled Enabled UP
```

This table describes the significant fields shown in the display:

**Table 5: show l2vpn forwarding bridge-domain Command Field Descriptions**

Field	Description
Bridge-Domain Name	Name of bridge domain is displayed.
Bridge ID	ID assigned to this bridge domain is displayed.
Ports	Number of ports that are part of this bridge domain is displayed.
MAC Addr	Number of MAC addresses that are learned on this bridge domain is displayed.
Flooding	Flooding of packets are displayed if they are enabled on this bridge domain.
Learning	Learning of MAC addresses are displayed if they are enabled on this bridge domain.
State	Current state of the bridge domain is displayed.

**Related Commands**

Command	Description
<a href="#">clear l2vpn bridge-domain (VPLS), on page 12</a>	Clears the MAC addresses and restarts the bridge domains on the router.

# show l2vpn forwarding bridge-domain mac-address (VPLS)

To display the summary information for the MAC address, use the **show l2vpn forwarding bridge-domain mac-address** command in EXEC mode.

```
show l2vpn forwarding bridge-domain [bridge-domain-name] mac-address {MAC-address | detail
| hardware {egress | ingress} | interface type interface-path-id | neighbor address pw-id pw-id}
location node-id
```

## Syntax Description

<i>bridge-domain-name</i>	(Optional) Name of a bridge domain.
<i>MAC-address</i>	MAC address.
<b>detail</b>	Displays detailed information for the MAC address.
<b>hardware</b>	Reads information from the hardware.
<b>egress</b>	Reads information from the egress PSE.
<b>ingress</b>	Reads information from the ingress PSE.
<b>interface</b>	Displays the match for the attachment circuit subinterface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>neighbor <i>address</i></b>	Displays the match for the neighbor IP address.
<b>pw-id <i>pw-id</i></b>	Displays the match for the pseudowire ID.
<b>location <i>node-id</i></b>	Displays the bridge-domain information for the MAC address of the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

## Command Default

None

## Command Modes

EXEC

## Command History

Release	Modification
Release 3.7.0	This command was introduced.
Release 3.7.2	This command was introduced.
Release 3.8.0	This command was introduced.

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

Task ID	Task Operations
l2vpn	read

**Examples**

The following sample output shows the specified location of the bridge-domain name g1:bd1 for the MAC address:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0
Bridge-ID      Ports  MAC addr  Flooding Learning State
-----
g1:bd1         0      2      65536   Enabled  Enabled  UP
```

The following sample output shows the list of MAC addresses that are learned on a specified bridge and summary information for the addresses:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain mac-address location 0/1/CPU0
Mac Address    Type      Learned from/Filtered on  LC learned Age
-----
0000.0000.0000 static   Gi0/1/0/0                 N/A           N/A
0000.0001.0101 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0102 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0103 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0104 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0105 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0106 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0107 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0108 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0109 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.010a dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.010b dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.010c dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.010d dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.010e dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.010f dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0110 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0111 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
0000.0001.0112 dynamic  Gi0/1/0/0                 0/1/CPU0     0d 0h 2m 22s
....
```

The following sample output shows the MAC address on a specified interface on a specified bridge:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address 1.2.3 location 0/1/CPU0
Mac Address    Type      Learned from/Filtered on  LC learned Age
-----
0001.0002.0003 static   Gi0/1/0/0                 N/A           N/A
```

The following sample output shows the hardware information from the egress pse:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address hardware
```

## show l2vpn forwarding bridge-domain mac-address (VPLS)

## egress location 0/1/CPU0

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0113	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0114	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
...				

The following sample output shows the MAC addresses that are learned on a specified pseudowire on a specified bridge:

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain mac-address neighbor 10.1.1.1
pw-id 1 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0003.0101	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0102	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0103	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0104	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0105	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0106	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0107	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0108	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0109	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010a	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010b	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010c	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010d	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010e	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010f	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0110	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0111	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0112	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0113	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0114	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0115	dynamic	10.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
...				

The following sample output shows the detailed information for MAC addresses that are learned on a specified interface and on specified bridge of a specified interface card. The sample output lists all the MAC addresses, the learned location, and the current age.

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain gl:bd1 mac-address interface
gigabitEthernet 0/1/0/0 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0113	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0114	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s

```
RP/0/RSP0/CPU0:router# show l2vpn forwarding bridge-domain mac-address location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
....				

**Related Commands**

Command	Description
<a href="#">show l2vpn forwarding bridge-domain (VPLS), on page 89</a>	Displays information on the bridge that is used by the forwarding layer.

## show l2vpn forwarding ethernet ring g8032

To display an overview of the G.8032 ethernet ring configuration from L2Forwarding Information Base (L2FIB) process, use the **show l2vpn forwarding ethernet ring g8032** command in EXEC mode.

**show l2vpn forwarding ethernet ring g8032** *name* [{**detail** | **instance** *ID* | **location** | **private**}]

Syntax Description	
<i>name</i>	Ethernet ring G.8032 name.
<b>detail</b>	Information in detail about the G.8032 ethernet ring configuration.
<b>instance</b> <i>ID</i>	Instance number about the G.8032 ethernet ring configuration.
<b>location</b>	Location specified in the rack/slot/module notation.
<b>private</b>	Private information about the G.8032 ethernet ring configuration.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

### Example

This example shows the output from the **show l2vpn forwarding ethernet ring g8032** command:

```
# show l2vpn forwarding ethernet ring g8032 private location <r/s/i>
Ethernet ring g8032 foo (task-id = cisco-support)
  Port0: GigabitEthernet0/1/2/0
    Monitor: none
  Port1: GigabitEthernet0/1/2/1
    Monitor: none
  Open-ring: no
  TCN propagation: no
  Instance 1
    Profile      : none
    RPL          : none
    aps-channel
```



```

    port0: GigabitEthernet0/1/2/0.1, status: bound
    port1: GigabitEthernet0/1/2/1.1, status: unbound
Instance 2
  Profile      : none
  RPL         : none
  aps-channel
    level: 7
    port0: GigabitEthernet0/1/2/0.10, status: unbound
  ethernet ring g8032 trace history [Num events: 6]
-----
Time           Event                               Sticky Many
====          =====
05/18/2010 21:45:54 Create                       No      No
05/18/2010 21:45:57 Create                       No      No
05/18/2010 21:45:57 Modify                       No      No
05/18/2010 21:45:57 Delete                       No      No

# show l2vpn forwarding ethernet ring g8032 foo instance 1 detail location <r/s/i>
Ethernet ring g8032 foo
  Port0: GigabitEthernet0/1/2/0
    Monitor: none
  Port1: GigabitEthernet0/1/2/1
    Monitor: none
  Open-ring: no
  TCN propagation: no
Instance 1
  Profile      : none
  RPL         : none
  aps-channel
    level: 7
    port0: GigabitEthernet0/1/2/0.1, status: bound
    port1: GigabitEthernet0/1/2/1.1, status: unbound

# show l2vpn forwarding ethernet ring g8032 foo instance 1 private location <r/s/i>
Ethernet ring g8032 foo (task-id = cisco-support)
  Port0: GigabitEthernet0/1/2/0
    Monitor: none
  Port1: GigabitEthernet0/1/2/1
    Monitor: none
  Open-ring: no
  TCN propagation: no
Instance 1
  Profile      : none
  RPL         : none
  aps-channel
    level: 7
    port0: GigabitEthernet0/1/2/0.1, status: bound
    port1: GigabitEthernet0/1/2/1.1, status: unbound

  ethernet ring g8032 instance trace history [Num events: 6]
-----
Time           Event                               Sticky Many
====          =====
05/18/2010 21:45:54 Create                       No      No
05/18/2010 21:45:57 Create                       No      No
05/18/2010 21:45:57 Modify                       No      No
05/18/2010 21:45:57 Delete                       No      No

```

**Related Commands**

Command	Description
<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

# show l2vpn forwarding protection main-interface

To display an overview of the main interface or instance operational information from L2Forwarding Information Base (L2FIB), use the **show l2vpn forwarding protection main-interface** command in EXEC mode.

**show l2vpn forwarding protection main-interface** [*interface name*] [{**detail** | **location** | **private**}]

Syntax Description		
	<i>interface name</i>	Interface name of the Ethernet ring G.8032 name.
	<b>detail</b>	Information in detail about the G.8032 ethernet ring configuration.
	<b>location</b>	Brief information about the G.8032 ethernet ring configuration.
	<b>private</b>	Private information about the G.8032 ethernet ring configuration.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

## Example

This example shows the output from the **show l2vpn forwarding protection main-interface** command:

```
# show l2vpn forwarding protection main-interface location <r/s/i>
Main Interface ID          Instance  State
-----
GigabitEthernet0/0/0/0    1         forward
GigabitEthernet0/0/0/0    2         forward
GigabitEthernet0/0/0/1    1         forward
```

```
# show l2vpn forwarding protection main-interface detail location <r/s/i>
Main Interface ID          Instance  State    # of subIntf
-----
GigabitEthernet0/0/0/0    1        forward  1
GigabitEthernet0/0/0/0    2        forward  3
GigabitEthernet0/0/0/1    1        forward  1

# show l2vpn forwarding protection main-interface private location <r/s/i>

Main Interface ID          Instance  State    # of subIntf
-----
GigabitEthernet0/0/0/0    1        forward  1

Base info: version=0xaabbcc1c, flags=0x0, type=14, reserved=0
Ifhandle: 0x20000040, cfg_instance: 1, Protected: no
```

**Related Commands**

Command	Description
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# show l2vpn protection main-interface

To display an overview of the main interface or instance operational information, use the **show l2vpn protection main-interface** command in EXEC mode.

**show l2vpn protection main-interface** [*interface name*{*Interface*}] [{**brief** | **detail** | **private**}]

Syntax Description		
	<i>interface name</i>	Interface name of the Ethernet ring G.8032 name.
	<i>interface</i>	The forwarding interface ID in number or in Rack/Slot/Instance/Port format as required.
	<b>brief</b>	Brief information about the G.8032 ethernet ring configuration.
	<b>detail</b>	Information in detail about the G.8032 ethernet ring configuration.
	<b>private</b>	Private information about the G.8032 ethernet ring configuration.

**Command Default** None

**Command Modes** EXEC

Command History	Release	Modification
	Release 4.1.0	This command was introduced.
	Release 7.7.1	The command output was enhanced to include protection access gateway subtype indication MST-AG.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

## Example

This example shows the output from the **show l2vpn protection main-interface** command:

```
RP/0/0/CPU0:router# show l2vpn protection main-interface
Main Interface ID          Subintf Count Protected Blocked
-----
```

```
GigabitEthernet0/0/0/0          1          None      No
  Instance : 0
    State   : FORWARDING
    Sub-Intf # : 1
    Flush   # : 0
    Sub-interfaces : GigabitEthernet0/0/0/0.4
```

Main Interface ID	Subintf Count	Protected	Blocked
GigabitEthernet0/0/0/1	1	None	No

```

  Instance : 0
    State   : FORWARDING
    Sub-Intf # : 1
    Flush   # : 0
    Sub-interfaces : GigabitEthernet0/0/0/0.4
```

```
RP/0/0/CPU0:ios#show l2vpn protection main-interface gigabitEthernet 0/0/0/1
Tue Mar 15 10:54:13.366 EDT
```

Main Interface ID	# of subIntf	Protected	Protect Type
GigabitEthernet0/0/0/1	2	Yes	MST-AG

```

  Instance : 0
    State   : FORWARDING
    Sub-Intf # : 1
    Flush   # : 1

  Instance : 1
    State   : BLOCKED
    Sub-Intf # : 1
    Flush   # : 0
```

```
RP/0/0/CPU0:ios#show l2vpn protection main-interface gigabitEthernet 0/0/0/2
Tue Mar 15 10:54:15.044 EDT
```

Main Interface ID	# of subIntf	Protected	Protect Type
GigabitEthernet0/0/0/2	2	Yes	STP

```

  Instance : 0
    State   : FORWARDING
    Sub-Intf # : 1
    Flush   # : 0

  Instance : 1
    State   : FORWARDING
    Sub-Intf # : 1
    Flush   # : 0
```

```
RP/0/0/CPU0:router# show l2vpn protection main-interface brief
```

Main Interface ID	Ref Count	Instance	Protected	State
GigabitEthernet0/0/0/0	3	2	No	FORWARDING
GigabitEthernet0/0/0/1	1	1	No	FORWARDING

```
RP/0/RSP0/CPU0:router# show l2vpn protection main-interface detail
```

Main Interface ID	# of subIntf	Protected
GigabitEthernet0/1/0/19	4	No

```
Main Interface ID          # of subIntf Protected
```

## show l2vpn protection main-interface

```

-----
GigabitEthernet0/1/0/20      3          No
Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/3      2          No
Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/30     1          No
Main Interface ID           # of subIntf Protected
-----
GigabitEthernet0/1/0/7      4          No

```

RP/0/0/CPU0:router# show l2vpn protection main-interface private

```

Main Interface ID           Ref Count  Protected  Blocked   If Handle  Registered
-----
GigabitEthernet0/0/0/0     3          None       No        0x20000020 No

```

Instance : 0

```

State      : FORWARDING      Config ID : 0
Sub-Intf # : 0              Ack       # : 0
Bridge D # : 0              N-Ack    # : 0
Flush #    : 0              Rcv       # : 0
Sub-interfaces : GigabitEthernet0/0/0/0.4

```

Instance event trace history [Total events: 1, Max listed: 8]

```

-----
Time          Event                      State          Action
=====
01/01/1970 01:00:01 Rcv state IF known      Invalid        134833160
07/02/2010 10:13:03 Update L2FIB             FORWARDING     0
01/01/1970 01:00:25 Rcvd AC MA create + UP I/F ST FORWARDING     0

```

## Related Commands

Command	Description
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# shutdown (Bridge Domain)

To shut down a bridge domain to bring the bridge and all attachment circuits and pseudowires under it to admin down state, use the **shutdown** command in L2VPN bridge group bridge domain configuration mode. To re-enable the bridge domain, use the **no** form of this command.

**shutdown**  
**no shutdown**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	By default, the bridge is not shutdown.				
<b>Command Modes</b>	L2VPN bridge group bridge domain configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When a bridge domain is disabled, all VFs associated with the bridge domain are disabled. You can still attach or detach members to or from the bridge domain as well as the VFs associated with the bridge domain.

Task ID	Task ID	Operations
	l2vpn	read, write

## Examples

The following example shows how to disable the bridge domain named bar:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# shutdown
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

## shutdown (VFI)

To disable virtual forwarding interface (VFI), use the **shutdown** command in L2VPN bridge group bridge domain VFI configuration mode. To re-enable VFI, use the **no** form of this command.

**shutdown**  
**no shutdown**

<b>Syntax Description</b>	This command has no keywords or arguments.
<b>Command Default</b>	By default, the VFI is not shutdown.
<b>Command Modes</b>	L2VPN bridge group bridge domain VFI configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how to disable VFI:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)# shutdown
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">mpls static label (VPLS), on page 46</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.



Command	Description
<a href="#">neighbor (VPLS), on page 52</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).

# signaling-protocol

To enable signaling for the VFI, use the **signaling-protocol** command in the BGP autodiscovery mode . To return to the default value, use the **no** form of this command.

```
signaling-protocol {bgp | ldp}
no signaling-protocol {bgp | ldp}
```

## Syntax Description

**bgp** Enables BGP protocol signaling.

**ldp** Enables LDP protocol signaling.

## Command Default

LDP signaling is enabled.

## Command Modes

BGP autodiscovery configuration

## Command History

Release	Modification
Release 3.9.1	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operations
l2vpn	read, write

## Examples

This example shows how to enable signaling for BGP protocol:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group EGroup
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain eastdomain
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi eastvfi
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)# autodiscovery bgp
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-ad)#route-target 100:20
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-ad)#signaling-protocol bgp
```

## Related Commands

Command	Description
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

# split-horizon group

To add an AC to a split horizon group, use the **split-horizon group** command in L2VPN bridge group bridge domain attachment circuit configuration mode. To remove the AC from the group, use the **no** form of this command.

**split-horizon group**  
**no split-horizon group**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	L2VPN bridge group bridge domain attachment circuit configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Only one split horizon group exists for ACs per bridge domain. By default, the group does not have any ACs. You can configure individual ACs to become members of the group using the **split-horizon group** configuration command.

You can configure an entire physical interface or EFPs within an interface to become members of the split horizon group.

Task ID	Task ID	Operations
	l2vpn	Read, write

## Examples

The following example adds an EFP under a GigabitEthernet interface to the AC split horizon group:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group metroA
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain east
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# interface GigabitEthernet0/1/0/6.15
```

```
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# split-horizon group  
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# commit
```

Related Commands	Command	Description
	<a href="#">show l2vpn bridge-domain (VPLS), on page 76</a>	Display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains.

## static-address (VPLS)

To add static entries to the MAC address for filtering, use the **static-address** command in L2VPN bridge group bridge domain MAC configuration mode. To remove entries profiled by the combination of a specified entry information, use the **no** form of this command.

**static-address** *MAC-address* **drop**  
**no static-address** *MAC-address* **drop**

<b>Syntax Description</b>	<i>MAC-address</i> Static MAC address that is used to filter on the bridge domain.
<b>drop</b>	Drops all traffic that is going to the configured MAC address.

**Command Default** No static MAC address is configured.

**Command Modes** L2VPN bridge group bridge domain MAC configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

**Examples** The following example shows how to add static MAC entries in L2VPN bridge group bridge domain MAC configuration mode. This entry causes all packets with destination MAC address 1.1.1 to be dropped.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# static-address 1.1.1 drop
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.

## static-mac-address (VPLS)

To configure the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface, use the **static-mac-address** command in the appropriate L2VPN bridge group bridge domain configuration submode. To disable this feature, use the **no** form of this command.

**static-mac-address** *MAC-address*  
**no static-mac-address** *MAC-address*

<b>Syntax Description</b>	<i>MAC-address</i> Static address to add to the MAC address.				
<b>Command Default</b>	None				
<b>Command Modes</b>	L2VPN bridge group bridge domain VFI pseudowire configuration L2VPN bridge group bridge domain attachment circuit configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

### Examples

The following example shows how to associate a remote MAC address with a pseudowire:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# static-mac-address 1.1.1
```

The following example shows how to associate a GigabitEthernet interface from a bridge domain to static MAC address 1.1.1:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
```



```
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# interface GigabitEthernet 0/1/0/0
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-ac)# static-mac-address 1.1.1
```

The following example shows how to associate an access pseudowire to static MAC address 2.2.2:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 2000
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-pw)# static-mac-address 2.2.2
```

### Related Commands

Command	Description
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mpls static label (VPLS), on page 46</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
<a href="#">neighbor (VPLS), on page 52</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
<a href="#">vfi (VPLS), on page 121</a>	Configures virtual forwarding interface (VFI) parameters.

# tcn-propagation

To enable topology change notification (TCN) propagation, use the **tcn-propagation** command in the L2VPN configuration submode.

## tcn-propagation

This command has no keywords or arguments.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	L2VPN configuration submode
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 4.1.0	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	l2vpn	read, write

This example shows how to enable the G.8032 ring mode:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn-erp)# tcn-propagation
RP/0/RSP0/CPU0:router(config-l2vpn)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">ethernet ring g8032, on page 17</a>	Enables G.8032 ring mode and enters the G.8032 configuration submode.

## time (VPLS)

To configure the maximum aging time, use the **time** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

**time** *seconds*  
**no time** *seconds*

<b>Syntax Description</b>	<i>seconds</i> MAC address table entry maximum age. The range is from 300 to 30000 seconds. Aging time is counted from the last time that the switch saw the MAC address. The default value is 300 seconds.				
<b>Command Default</b>	<i>seconds</i> : 300				
<b>Command Modes</b>	L2VPN bridge group bridge domain MAC aging configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>If no packets are received from the MAC address for the duration of the maximum aging time, the dynamic MAC entry previously learned is removed from the forwarding table.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write
Task ID	Operations				
l2vpn	read, write				
<b>Examples</b>	<p>The following example shows how to increase the maximum aging time to 600 seconds. After 600 seconds of inactivity from a MAC address, the MAC address is removed from the forwarding table.</p> <pre>RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# l2vpn RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# aging RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# time 600</pre>				
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">aging (VPLS), on page 5</a></td> <td>Enters the MAC aging configuration submode to set the aging parameters such as time and type.</td> </tr> </tbody> </table>	Command	Description	<a href="#">aging (VPLS), on page 5</a>	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
Command	Description				
<a href="#">aging (VPLS), on page 5</a>	Enters the MAC aging configuration submode to set the aging parameters such as time and type.				

Command	Description
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
<a href="#">type (VPLS), on page 119</a>	Configures the type for MAC address aging.

## transport rsvp-te

To enable RSVP-TE as transport on a VFI and to enter L2VPN bridge group bridge domain VFI multicast P2MP RSVP - TE configuration mode, use the **transport rsvp-te** command in L2VPN bridge group bridge domain VFI multicast P2MP configuration mode. To return to P2MP mode, use the **no** form of this command.

```
transport rsvp-te [attribute-set]
no transport rsvp-te [attribute-set]
```

<b>Syntax Description</b>	[attribute-set] Specifies the TE attribute set parameters.				
<b>Command Default</b>					
<b>Command Modes</b>	L2VPN bridge group bridge domain VFI multicast P2MP configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.1	This command was introduced.
Release	Modification				
Release 5.1	This command was introduced.				
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read, write
Task ID	Operation				
l2vpn	read, write				

### Example

This example shows how to enable RSVP-TE as transport on a VFI:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)# multicast p2mp
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-p2mp)# transport rsvp-te
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi-p2mp-te)#
```

Related Commands	Command	Description
	<a href="#">multicast p2mp, on page 50</a>	Configures point to multi-point pseudowire in a VFI.

Command	Description
<a href="#">vfi (VPLS), on page 121</a>	Configures virtual forwarding interface (VFI) parameters.
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.

## type (VPLS)

To configure the type for MAC address aging, use the **type** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

```
type {absolute | inactivity}
no type {absolute | inactivity}
```

### Syntax Description

**absolute** Configures the absolute aging type.

**inactivity** Configures the inactivity aging type.

### Command Default

By default, the inactivity type is configured.

### Command Modes

L2VPN bridge group bridge domain MAC aging configuration

### Command History

Release	Modification
Release 3.7.2	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In general, the type is set to inactivity. With an inactivity type configuration, a MAC address is removed from the forwarding table after the MAC address is inactive for the configured aging time.

With an absolute type configuration, a MAC address is always removed from the forwarding table after the aging time has elapsed once it is initially learned.

### Task ID

Task ID	Operations
l2vpn	read, write

### Examples

The following example shows how to configure the MAC address aging type to absolute for every member of the bridge domain named bar:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
```

```

RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# type absolute

```

Related Commands	Command	Description
	<a href="#">aging (VPLS), on page 5</a>	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.
	<a href="#">time (VPLS), on page 115</a>	Configures the maximum aging time.



## vfi (VPLS)

To configure virtual forwarding interface (VFI) parameters and to enter L2VPN bridge group bridge domain VFI configuration mode, use the **vfi** command in L2VPN bridge group bridge domain configuration mode. To remove all configurations that are made under the specified VFI, use the **no** form of this command.

**vfi** *vfi-name*  
**no vfi** *vfi-name*

<b>Syntax Description</b>	<i>vfi-name</i> Name of the specified virtual forwarding interface.						
<b>Command Default</b>	None						
<b>Command Modes</b>	L2VPN bridge group bridge domain configuration						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.		
Release	Modification						
Release 3.7.2	This command was introduced.						
<b>Usage Guidelines</b>	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>vfi</b> command to enter L2VPN bridge group bridge domain VFI configuration mode.</p>						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write		
Task ID	Operations						
l2vpn	read, write						
<b>Examples</b>	<p>The following example shows how to create a VFI:</p> <pre>RP/0/RSP0/CPU0:router# <b>configure</b> RP/0/RSP0/CPU0:router(config)# <b>l2vpn</b> RP/0/RSP0/CPU0:router(config-l2vpn)# <b>bridge group 1</b> RP/0/RSP0/CPU0:router(config-l2vpn-bg)# <b>bridge-domain bar</b> RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# <b>vfi v1</b> RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-vfi)#</pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">bridge-domain (VPLS), on page 10</a></td> <td>Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.</td> </tr> <tr> <td><a href="#">bridge group (VPLS), on page 11</a></td> <td>Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.</td> </tr> </tbody> </table>	Command	Description	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
Command	Description						
<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.						
<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.						

Command	Description
<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
<a href="#">mpls static label (VPLS), on page 46</a>	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
<a href="#">neighbor (VPLS), on page 52</a>	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).

## withdraw (VPLS)

To disable MAC address withdrawal for a specified bridge domain, use the **withdraw** command in L2VPN bridge group bridge domain MAC configuration mode. To enable this feature, use the **no** form of this command

```
withdraw {access-pw disable | disable}
no withdraw {access-pw disable | disable }
```

<b>Syntax Description</b>	<b>access-pw disable</b>	Disables the sending of MAC withdraw messages to access pseudowires.
	<b>disable</b>	Disables MAC address withdrawal.
<b>Command Default</b>	By default, MAC address withdrawal is enabled.	
<b>Command Modes</b>	L2VPN bridge group bridge domain MAC configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 3.7.2	This command was introduced.
	Release 4.0.0	The <b>access-pw disable</b> keyword was added.
<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	l2vpn	read, write

### Examples

The following example shows how to enable disable MAC withdrawal:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# withdraw disable
```

The following example shows how to disable sending MAC withdrawal messages to access pseudowires:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RSP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
```

**withdraw (VPLS)**

```
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RSP0/CPU0:router(config-l2vpn-bg-bd-mac)# withdraw access-pw disable
```

Related Commands	Command	Description
	<a href="#">bridge-domain (VPLS), on page 10</a>	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	<a href="#">bridge group (VPLS), on page 11</a>	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	<a href="#">l2vpn</a>	Enters L2VPN configuration mode.
	<a href="#">mac (VPLS), on page 37</a>	Enters L2VPN bridge group bridge domain MAC configuration mode.