



IGMP Commands on Cisco ASR 9000 Series Router

This chapter describes the commands used to configure and monitor IPv4 multicast protocol on Cisco ASR 9000 Series Routers .

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

The commands in this chapter apply to the Internet Group Management Protocol (IGMP), versions 1, 2, and 3.

For detailed information about multicast routing concepts, configuration tasks, and examples, refer to the Implementing Multicast Routing on Cisco IOS XR Software configuration module in *Multicast Configuration Guide for Cisco ASR 9000 Series Routers* .

- [access-group \(IGMP\), on page 3](#)
- [clear igmp counters, on page 4](#)
- [clear igmp group, on page 6](#)
- [clear igmp reset, on page 8](#)
- [clear igmp unicast-qos-adjust, on page 9](#)
- [explicit-tracking, on page 11](#)
- [igmp accounting, on page 13](#)
- [igmp explicit-tracking, on page 14](#)
- [igmp query-interval, on page 16](#)
- [igmp query-max-response-time, on page 18](#)
- [join-group, on page 20](#)
- [maximum groups, on page 22](#)
- [maximum groups-per-interface, on page 25](#)
- [nsf lifetime \(IGMP\) , on page 29](#)
- [query-interval, on page 31](#)
- [query-max-response-time, on page 33](#)
- [query-timeout, on page 35](#)
- [robustness-count, on page 37](#)
- [router, on page 38](#)
- [router igmp, on page 40](#)
- [router igmp vrf, on page 41](#)

- [show igmp groups](#), on page 42
- [show igmp interface](#), on page 44
- [show igmp nsf](#), on page 47
- [show igmp nsr](#), on page 49
- [show igmp summary](#), on page 51
- [show igmp ssm map](#), on page 54
- [show igmp traffic](#), on page 55
- [show igmp unicast-qos-adjust statistics](#), on page 58
- [show igmp vrf](#), on page 60
- [show igmp vrf vrf_name groups](#), on page 62
- [ssm map](#), on page 63
- [static-group](#), on page 64
- [unicast-qos-adjust](#), on page 66
- [version](#), on page 67
- [vrf \(igmp\)](#), on page 69

access-group (IGMP)

To set limits on an interface for multicast-group join requests by hosts, use the **access-group** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

access-group *access-list*

Syntax Description	<i>access-list</i> Number or name of a standard IP access list. Range is 1 to 99.	
Command Default	No default behavior or values	
Command Modes	IGMP interface configuration	
Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Usage Guidelines	If this command is not specified in router Internet Group Management Protocol (IGMP) configuration mode, the interface accepts all multicast join requests by hosts.	
Task ID	Task ID	Operations
	multicast	read, write
Examples	In the following example, hosts serviced by GigabitEthernet interface 0/1/0/1 can join only group 225.2.2.2: <pre> RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# ipv4 access-list mygroup permit 225.2.2.2 0.0.0.0 RP/0/RSP0/CPU0:router(config)# router igmp RP/0/RSP0/CPU0:router(config-igmp)# interface GigE 0/1/0/1 RP/0/RSP0/CPU0:router(config-igmp-default-if)# access-group mygroup RP/0/RSP0/CPU0:router# configure RP/0/RSP0/CPU0:router(config)# ipv4 access-list mygroup permit 225.2.2.2 0.0.0.0 RP/0/RSP0/CPU0:router(config)# router igmp RP/0/RSP0/CPU0:router(config-igmp)# interface GigE 0/1/0/1 RP/0/RSP0/CPU0:router(config-igmp-default-if)# access-group mygroup </pre>	
Related Commands	Command	Description
	ipv4 access-list	Defines a standard IP access list. For information, see <i>IP Addresses and Services Command Reference for Cisco ASR 9000 Series Routers</i>

clear igmp counters

To clear IGMP traffic statistics, use the **clear igmp counters** command in EXEC mode.

clear igmp [ipv4 vrf vrf-name | vrf vrf-name] counters

Syntax Description	ipv4	(Optional) Specifies IPv4 addressing. IPv4 is the default for Internet Group Management Protocol (IGMP) groups.
	vrf vrf-name	(Optional) Specifies a VPN routing and forwarding (VRF) instance.
Command Default	No default behavior or values	
Command Modes	EXEC	
Command History	Release	Modification
	Release 3.7.2	This command was introduced.
Usage Guidelines	After IGMP statistics are cleared, statistics begin incrementing again.	
Task ID	Task ID	Operations
	multicast	execute

Examples The following example shows sample output before and after clearing IGMP traffic statistics:

```
RP/0/RSP0/CPU0:router# show igmp traffic

IGMP Traffic Counters
Elapsed time since counters cleared: 00:00:19

Valid IGMP Packets          Received      Sent
Queries                     0             3
Reports                     0             9
Leaves                      0             0
Mtrace packets              0             0
DVMRP packets               0             0
PIM packets                  0             0

Errors:
Malformed Packets           0
Bad Checksums                0
Socket Errors                0
Bad Scope Errors             0
Auxiliary Data Len Errors 0
Subnet Errors                0
Packets dropped due to invalid socket 0
Packets which couldn't be accessed 0
Other packets drops          0
```

```
RP/0/RSP0/CPU0:router# clear igmp counters
```

```
RP/0/RSP0/CPU0:router# show igmp traffic
```

IGMP Traffic Counters

Elapsed time since counters cleared: 00:00:12

	Received	Sent
Valid IGMP Packets	0	1
Queries	0	1
Reports	0	0
Leaves	0	0
Mtrace packets	0	0
DVMRP packets	0	0
PIM packets	0	0

Errors:

Malformed Packets	0
Bad Checksums	0
Socket Errors	0
Bad Scope Errors	0
Auxiliary Data Len Errors	0
Subnet Errors	0
Packets dropped due to invalid socket	0
Packets which couldn't be accessed	0
Other packets drops	0

Related Commands

Command	Description
show igmp traffic, on page 55	Displays all the Internet Group Management Protocol (IGMP) traffic-related counters.

clear igmp group

To clear Internet Group Management Protocol (IGMP) groups on one or all interfaces, use the **clear igmp group** command in EXEC mode.

```
clear igmp [ipv4 vrf vrf-name | vrf vrf-name] group [ip-address | type interface-path-id]
```

Syntax Description	ipv4 (Optional) Specifies IPv4 addressing. IPv4 is the default for IGMP groups. vrf vrf-name (Optional) Specifies a VPN routing and forwarding (VRF) instance. ip-address (Optional) IP hostname or group address. type (Optional) Interface type. For more information, use the question mark (?) online help function. interface-path-id (Optional) Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
Command Default	If no group address is specified, all IGMP groups are cleared.
Command Modes	EXEC
Command History	Release Modification Release 3.7.2 This command was introduced.
Usage Guidelines	To clear all IGMP groups, use the clear igmp group command without using an argument. To clear a particular group, use the <i>ip-address</i> or <i>type interface-path-id</i> arguments. The following groups cannot be cleared: 224.0.0.2 224.0.0.13 224.0.0.22 224.0.0.40
Task ID	Task ID Operations multicast execute

Examples

The following example uses the **show igmp groups** command to display the IGMP Connected Group Membership, the **clear igmp group** command to clear address 239.1.1.1, and the **show igmp groups** command again to display the updated list.

```
RP/0/RSP0/CPU0:router# show igmp groups tenGigE 0/4/0/0
```

```
IGMP Connected Group Membership
Group Address    Interface          Uptime    Expires    Last Reporter
224.0.0.2        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.5        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.6        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.13       TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.22       TenGigE0/4/0/0    3w6d      never      10.114.8.44
```

```
RP/0/RSP0/CPU0:router# clear igmp groups tenGigE 0/4/0/0
```

```
RP/0/RSP0/CPU0:router# show igmp groups tenGigE 0/4/0/0
```

```
IGMP Connected Group Membership
Group Address    Interface          Uptime    Expires    Last Reporter
224.0.0.2        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.5        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.6        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.13       TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.22       TenGigE0/4/0/0    3w6d      never      10.114.8.44
```

Related Commands

Command	Description
show igmp groups, on page 42	Displays the multicast groups that are directly connected to the router and that were learned through Internet Group Management Protocol (IGMP).

clear igmp reset

To clear all Internet Group Management Protocol (IGMP) membership entries and reset connection in the Multicast Routing Information Base (MRIB), use the **clear igmp reset** command in EXEC mode.

clear igmp [**ipv4 vrf** *vrf-name* | **vrf** *vrf-name*] **reset**

Syntax Description	ipv4	(Optional) Specifies IPv4 addressing. IPv4 is the default for IGMP groups.
	vrf <i>vrf-name</i>	(Optional) Specifies a VPN routing and forwarding (VRF) instance.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines Every IGMP group membership that IGMP learns is downloaded to the MRIB database.

The **clear igmp reset** command is used to clear all information from the IGMP topology table and reset the MRIB connection.



Note This command is reserved to force synchronization of IGMP and MRIB entries when communication between the two components is malfunctioning.

Task ID	Task ID	Operations
	multicast	execute

Examples The following example shows how to clear the group memberships in MRIB:

```
RP/0/RSP0/CPU0:router# clear igmp reset
```

Related Commands	Command	Description
	show igmp groups, on page 42	Displays the multicast groups that are directly connected to the router and that were learned through IGMP
	show mrrib route	Displays all route entries in the MRIB table.

clear igmp unicast-qos-adjust

To clear IGMP unicast rate adjustment database, use the **clear igmp unicast-qos-adjust** command in the EXEC mode.

clear igmp unicast-qos-adjust { **rate** | **statistics** } **interface** { *type* | *interface_path_id* }

Syntax Description	rate	Specifies the rate programmed in QoS.
	statistics	Specifies the unicast rate adjustment statistics.
	interface	Specifies the interface specific rate.
	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Either a physical interface instance or a virtual interface instance as follows: - Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <i>rack</i>: Chassis number of the rack. <i>slot</i>: Physical slot number of the modular services card or line card. <i>module</i>: Module number. A physical layer interface module (PLIM) is always 0. <i>port</i>: Physical port number of the interface. Note In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RP0 or RP1) and the module is CPU0. Example: interface MgmtEth0/RP1/CPU0/0. - Virtual interface instance. Number range varies depending on interface type. For more information about the syntax for the router, use the question mark (?) online help function.
Command Default	Clears all unicast qos adjust parameters.	
Command Modes	EXEC mode	
Command History	Release	Modification
	Release 4.2.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	

 **clear igmp unicast-qos-adjust**

Task ID

Task ID Operation

multicast exec

This is an example of using the **clear igmp unicast-qos-adjust** command:

```
RP/0/RSP0/CPU0:router# clear igmp unicast-qos-adjust rate interface Loopback 1
```

explicit-tracking

To configure explicit host tracking under Internet Group Management Protocol (IGMP) Version 3, use the **explicit-tracking** command in the appropriate configuration mode. To disable explicit host tracking, use the **no** form of this command.

explicit-tracking [*access-list* | **disable**]

Syntax Description	<i>access-list</i> (Optional) Access list that specifies the group range for host tracking. disable (Optional) Disables explicit host tracking on a specific interface. This option is available only in interface configuration mode.				
Command Default	If this command is not specified in IGMP configuration mode, then explicit host tracking is disabled.				
Command Modes	IGMP VRF configuration IGMP interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	By default, IGMP supports Version 3, unless a Version 2 or Version 1 IGMP host message is detected in the network. For backward compatibility, IGMP downgrades to run at the IGMP version level that is installed. This feature allows the router to achieve minimal leave latencies when hosts leave a multicast group or channel. To monitor IGMP membership of hosts, use the show igmp groups command in EXEC mode. In router configuration mode, the explicit-tracking command enables explicit host tracking for all interfaces. To disable explicit tracking for all interfaces, use the no form of the command from IGMP configuration mode. To disable the feature on specific interfaces, use the explicit-tracking command in interface configuration mode with the disable keyword, as shown in the following example.				
Note	If you configure this command in IGMP VRF configuration mode, parameters are inherited by all new and existing interfaces. However, you can override these parameters on individual interfaces from IGMP interface configuration mode.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>multicast</td><td>read, write</td></tr> </table>	Task ID	Operations	multicast	read, write
Task ID	Operations				
multicast	read, write				
Examples	The following example shows how to enable explicit host tracking for the access list named router1 on all interfaces and how to disable explicit host tracking for a specific GigabitEthernet interface:				

```
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# explicit-tracking router1
RP/0/RSP0/CPU0:router(config-igmp)# interface GigabitEthernet 0/1/0/0
RP/0/RSP0/CPU0:router(config-igmp-default-if)# explicit-tracking disable
```

Related Commands	Command	Description
	show igmp groups, on page 42	Displays the multicast groups that are directly connected to the router and that were learned through Internet Group Management Protocol (IGMP).

igmp accounting

To enable accounting feature under igmp, use the **igmp accounting** command in the Global Configuration mode. To disable this feature, use the **no** form of this command.

igmp accounting { **max-history** *number_of_days*}

Syntax Description	max-history	Sets the maximum history for the accounting in days.
	<i>number_of_days</i>	Specifies the number of days the history has to be retained. This value ranged from 1 to 365.
Command Default	If max-history is not specified, then the default is 0 days, which indicates that there was no history saved.	
Command Modes	Global Configuration mode	
Command History	Release	Modification
	Release 4.2.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	multicast	read, write

This is an example of configuring the **igmp accounting** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router # configure
RP/0/RSP0/CPU0:router(config)# router igmp accounting max-history 67
```

igmp explicit-tracking

To configure explicit host tracking under Internet Group Management Protocol (IGMP) Version 3, use the **igmp explicit-tracking** command in the dynamic-template configuration mode. To disable explicit host tracking, use the **no** form of this command.

igmp explicit-tracking *access_list_name*

Syntax Description	<i>access_list_name</i> Specifies the access list tracking group range.				
Command Default	None				
Command Modes	Dynamic template configuration mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 4.2.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				
Usage Guidelines	Use the dynamic-template type ppp command to enter dynamic template type ppp configuration mode.				
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>multicast</td><td>read, write</td></tr> </table>	Task ID	Operation	multicast	read, write
Task ID	Operation				
multicast	read, write				

This is an example of configuring the **igmp explicit-tracking** command in the dynamic-template configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# dynamic-template
RP/0/RSP0/CPU0:router(config-dynamic-template)# type ppp foo
RP/0/RSP0/CPU0:router(config-dynamic-template-type)# igmp explicit-tracking igmpl
```

Related Commands	Command	Description
	igmp query-interval, on page 16	Configures the frequency at which the Cisco IOS XR Software sends Internet Group Management Protocol (IGMP) host-query messages.
	unicast-qos-adjust, on page 66	Configures the IGMP QOS Shaper for subscriber unicast traffic.
	show igmp unicast-qos-adjust statistics, on page 58	Displays the internal statistics of the unicast-qos-adjusted feature.

Command	Description
igmp query-max-response-time, on page 18	Configures the maximum response time advertised in Internet Group Management Protocol (IGMP) queries

igmp query-interval

To configure the frequency at which the Cisco IOS XR Software sends Internet Group Management Protocol (IGMP) host-query messages, use the **igmp query-interval** command in the dynamic-template configuration mode. To disable this feature, use the **no** form of this command.

igmp query-interval *seconds*

Syntax Description	<i>seconds</i> Specifies the frequency used to send IGMP host-query messages and ranges between 1 to 3600.				
Command Default	The default query-interval value is 60s.				
Command Modes	Dynamic template configuration mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 4.2.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				
Usage Guidelines	Use the dynamic-template type ppp command to enter dynamic template type ppp configuration mode.				
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>multicast</td><td>read, write</td></tr> </table>	Task ID	Operation	multicast	read, write
Task ID	Operation				
multicast	read, write				

This is the example of configuring the **igmp query-interval** command in the dynamic-template configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# dynamic-template
RP/0/RSP0/CPU0:router(config-dynamic-template)# type ppp foo
RP/0/RSP0/CPU0:router(config-dynamic-template-type)# igmp query-interval 60
```

Related Commands	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td>unicast-qos-adjust, on page 66</td><td>Configures the IGMP QOS Shaper for subscriber unicast traffic.</td></tr> <tr> <td>igmp explicit-tracking, on page 14</td><td>Configures explicit host tracking under Internet Group Management Protocol (IGMP) Version 3</td></tr> <tr> <td>igmp query-max-response-time, on page 18</td><td>Configures the maximum response time advertised in Internet Group Management Protocol (IGMP) queries</td></tr> </table>	Command	Description	unicast-qos-adjust, on page 66	Configures the IGMP QOS Shaper for subscriber unicast traffic.	igmp explicit-tracking, on page 14	Configures explicit host tracking under Internet Group Management Protocol (IGMP) Version 3	igmp query-max-response-time, on page 18	Configures the maximum response time advertised in Internet Group Management Protocol (IGMP) queries
Command	Description								
unicast-qos-adjust, on page 66	Configures the IGMP QOS Shaper for subscriber unicast traffic.								
igmp explicit-tracking, on page 14	Configures explicit host tracking under Internet Group Management Protocol (IGMP) Version 3								
igmp query-max-response-time, on page 18	Configures the maximum response time advertised in Internet Group Management Protocol (IGMP) queries								

Command	Description
show igmp unicast-qos-adjust statistics, on page 58	Displays the internal statistics of the unicast-qos-adjusted feature.

igmp query-max-response-time

To configure the maximum response time advertised in Internet Group Management Protocol (IGMP) queries, use the **igmp query-max-response-time** command in the dynamic-template configuration mode. To disable this feature, use the **no** form of this command.

igmp query-max-response-time *seconds*

Syntax Description	<i>seconds</i> Specifies the maximum response time, in seconds, advertised in IGMP queries, and ranges between 1 to 12.				
Command Default	The default query-max-response-time is 10 seconds.				
Command Modes	Dynamic template configuration mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 4.2.0</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 4.2.0	This command was introduced.
Release	Modification				
Release 4.2.0	This command was introduced.				
Usage Guidelines	Use the dynamic-template type ppp command to enter dynamic template type ppp configuration mode.				
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>multicast</td><td>read, write</td></tr> </table>	Task ID	Operation	multicast	read, write
Task ID	Operation				
multicast	read, write				

This is the example of configuring the **igmp query-max-response-time** command in the dynamic-template configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# dynamic-template
RP/0/RSP0/CPU0:router(config-dynamic-template)# type ppp foo
RP/0/RSP0/CPU0:router(config-dynamic-template-type)# igmp query-max-response-time 12
```

Related Commands	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td>igmp query-interval, on page 16</td><td>Configures the frequency at which the Cisco IOS XR Software sends Internet Group Management Protocol (IGMP) host-query messages.</td></tr> <tr> <td>igmp explicit-tracking, on page 14</td><td>Configures explicit host tracking under Internet Group Management Protocol (IGMP) Version 3</td></tr> </table>	Command	Description	igmp query-interval, on page 16	Configures the frequency at which the Cisco IOS XR Software sends Internet Group Management Protocol (IGMP) host-query messages.	igmp explicit-tracking, on page 14	Configures explicit host tracking under Internet Group Management Protocol (IGMP) Version 3
Command	Description						
igmp query-interval, on page 16	Configures the frequency at which the Cisco IOS XR Software sends Internet Group Management Protocol (IGMP) host-query messages.						
igmp explicit-tracking, on page 14	Configures explicit host tracking under Internet Group Management Protocol (IGMP) Version 3						

Command	Description
show igmp unicast-qos-adjust statistics, on page 58	Displays the internal statistics of the unicast-qos-adjusted feature.
unicast-qos-adjust, on page 66	Configures the IGMP QOS Shaper for subscriber unicast traffic.

join-group

To have the router join a multicast group, use the **join-group** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

join-group *group-address* [*source-address*]

Syntax Description	<i>group-address</i>	Address of the multicast group. This is a multicast IP address group in IPv4 format IP address as defined in the Domain Name System (DNS) hosts table or with the domain IPv4 host in the format <i>A.B.C.D</i> .
	<i>source-address</i>	(Optional) Source address of the multicast group to include in IPv4 prefixing format IP address as defined in the Domain Name System (DNS) hosts table or with the domain IPv4 host in the format <i>A.B.C.D</i> .

Command Default No multicast group memberships are predefined. If not specified, include is the default.

Command Modes IGMP interface configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines

The **join-group** command permits the IP packets that are addressed to the group address to pass to the IP client process in the Cisco IOS XR software.

If all the multicast-capable routers that you administer are members of a multicast group, pinging that group causes all routers to respond. This command can be a useful administrative and debugging tool.

Another reason to have a router join a multicast group is when other hosts on the network are prevented from correctly answering IGMP queries. When the router joins the multicast group, upstream devices learn multicast routing table information for that group and keep the paths for that group active.



Caution Joining a multicast group can result in a significant performance impact, because all subscribed multicast packets are punted to the route processor.

Task ID	Task ID	Operations
	multicast	read, write

Examples

In the following example, the router joins multicast group 225.2.2.2:

```
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# interface GigabitEthernet 0/1/0/0
```

```
RP/0/RSP0/CPU0:router(config-igmp-default-if)# join-group 225.2.2.2
```

The **join-group** command can have an include/exclude mode for IGMPv3 interfaces as shown in the following example:

```
RP/0/RSP0/CPU0:router(config)#router igmp
RP/0/RSP0/CPU0:router(config-igmp)#int gigabitEthernet 0/5/0/1
RP/0/RSP0/CPU0:router(config-igmp-default-if)#join-group ?
A.B.C.D IP group address
RP/0/RSP0/CPU0:router(config-igmp-default-if)#join-group 225.0.0.0 ?
A.B.C.D Source address to include
exclude Exclude the only following source address include Include only the following
source address <cr>
RP/0/RSP0/CPU0:router(config-igmp-default-if)#join-group 225.0.0.0 10.10.10.10 ?
<cr>
RP/0/RSP0/CPU0:router(config-igmp-default-if)#join-group 225.0.0.0 ?
A.B.C.D Source address to include
exclude Exclude the only following source address
include Include only the following source address <cr>
RP/0/RSP0/CPU0:router(config-igmp-default-if)#join-group 225.0.0.0
```

Related Commands

Command	Description
ping	Checks host reachability and network connectivity on IP networks. For information, see <i>IP Addresses and Services Command Reference for Cisco ASR 9000 Series Routers</i> .

maximum groups

To configure the maximum number of groups used by Internet Group Management Protocol (IGMP) and accepted by a router, use the **maximum groups** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

maximum groups *number*

Syntax Description	<i>number</i> Maximum number of groups accepted by a router. Range is 1 to 75000.
---------------------------	---

Command Default	<i>number</i> : 50000
------------------------	-----------------------

Command Modes	IGMP configuration IGMP VRF configuration
----------------------	--

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines	When configuring this command within IGMP VRF configuration mode, you may either use the default (unspecified) VRF or a specific VRF by specifying its name. The maximum combined number of groups on all interfaces can be 75000. After the maximum groups value is met, all additional memberships learned are ignored. The maximum number includes external and local membership. The following groups obtain local membership on each interface when multicast is enabled and are added into the group totals for each interface: 224.0.0.13 (for PIM), 224.0.0.22 and 224.0.0.2 (for IGMP). You cannot use the maximum groups command to configure the maximum number of groups below the number of existing groups. For instance, if the number of groups is 39, and you set the maximum number of groups to 10, the configuration is rejected. Although Cisco IOS XR Software Release 3.9.0 supports 40,000 groups per interface, the ASR9000 router supports a maximum of 16,000 multicast routes per system. Furthermore, you can use the maximum groups per-interface command to configure the maximum number of groups for each interface accepted by a router.
-------------------------	--

Task ID	Task ID	Operations
	multicast	read, write

Examples	The following example shows how to display the number of groups (39) and the maximum number of groups configured (50000) . Through use of the maximum groups command, a configuration is committed to change the maximum number of groups to 40. Before and after configuration, the show igmp summary command is used to confirm the configuration change:
-----------------	--

```
RP/0/RSP0/CPU0:router# show igmp summary
```

```
IGMP summary
```

```
Robustness Value 2
```

```
No. of Group x Interfaces 61
```

```
Maximum number of Group x Interfaces 50000
```

```
Supported Interfaces : 18
```

```
Unsupported Interfaces : 2
```

```
Enabled Interfaces : 18
```

```
Disabled Interfaces : 2
```

Interface	Grp No	Max Grp No
MgmtEth0/RSP0/CPU0/0	0	25000
Loopback0	4	25000
Bundle-Ether24	3	25000
Bundle-Ether28	3	25000
Bundle-Ether28.1	3	25000
Bundle-Ether28.2	3	25000
Bundle-Ether28.3	3	25000
MgmtEth0/RP1/CPU0/0	0	25000
GigabitEthernet0/1/5/0	3	25000
GigabitEthernet0/1/5/1	5	25000
GigabitEthernet0/1/5/2	5	25000
GigabitEthernet0/1/0/1	5	25000
GigabitEthernet0/1/4/2	3	25000
GigabitEthernet0/6/5/1	3	25000
GigabitEthernet0/6/5/2	3	25000
GigabitEthernet0/6/5/7	3	25000
GigabitEthernet0/6/0/1	3	25000
GigabitEthernet0/6/4/4	3	25000
GigabitEthernet0/6/4/5	3	25000
GigabitEthernet0/6/4/6	3	25000

```
RP/0/RSP0/CPU0:router# configure
```

```
RP/0/RSP0/CPU0:router(config)# router igmp
```

```
RP/0/RSP0/CPU0:router(config-igmp)# maximum groups 65
```

```
RP/0/RSP0/CPU0:router(config-igmp)# commit
```

```
RP/0/RSP0/CPU0:router:May 13 12:26:59.108 : config[65704]: %LIBTARCFG-6-COMMIT : Configuration committed
```

```
by user 'cisco'. Use 'show commit changes 1000000025' to view the changes.
```

```
RP/0/RSP0/CPU0:router# show igmp summary
```

```
Robustness Value 2
```

```
No. of Group x Interfaces 61
```

```
Maximum number of Group x Interfaces 65
```

```
Supported Interfaces : 18
```

```
Unsupported Interfaces : 2
```

```
Enabled Interfaces : 18
```

```
Disabled Interfaces : 2
```

Interface	Grp No	Max Grp No
MgmtEth0/RSP0/CPU0/0	0	25000
Loopback0	4	25000
Bundle-Ether28	3	25000
Bundle-Ether28.1	3	25000
Bundle-Ether28.2	3	25000
Bundle-Ether28.3	3	25000
MgmtEth0/RP1/CPU0/0	0	25000

maximum groups

GigabitEthernet0/1/5/0	3	25000
GigabitEthernet0/1/5/1	5	25000
GigabitEthernet0/1/5/2	5	25000
GigabitEthernet0/6/5/1	3	25000
GigabitEthernet0/6/5/2	3	25000
GigabitEthernet0/6/5/7	3	25000

Related Commands	Command	Description
	maximum groups-per-interface, on page 25	Configures the maximum number of groups for each interface accepted by a router.
	show igmp summary, on page 51	Displays group membership information for Internet Group Management Protocol (IGMP).

maximum groups-per-interface

To configure the maximum number of groups for each interface accepted by a router, use the **maximum groups-per-interface** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

maximum groups-per-interface *number*

Syntax Description	<i>number</i> Maximum number of groups accepted by a router for each interface. Range is 1 to 16000.
---------------------------	--

Command Default	<i>number</i> : 20000
------------------------	-----------------------

Command Modes	IGMP configuration IGMP VRF configuration IGMP interface configuration
----------------------	--

Command History	<table border="1"> <tr> <th>Release</th> <th>Modification</th> </tr> <tr> <td>Release 3.7.2</td> <td>This command was introduced.</td> </tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				

Usage Guidelines	The following groups obtain local membership on each interface when multicast is enabled and are added into the group totals for each interface: 224.0.0.13 (for Protocol Independent Multicast [PIM]), 224.0.0.22 and 224.0.0.2 (for Internet Group Management Protocol [IGMP]). The number of groups for each interface reflects both external and local group membership.
-------------------------	--



Note	You cannot use the maximum groups-per-interface command to configure the maximum number of groups for each interface below the number of existing groups on an interface. For example, if the number of groups is 39, and you set the maximum number of groups to 10, the configuration is rejected.
-------------	---

When you use the **maximum groups-per-interface** command for a specific interface, it overrides the inheritance property of this command specified under IGMP configuration mode.

Task ID	<table border="1"> <tr> <th>Task ID</th> <th>Operations</th> </tr> <tr> <td>multicast</td> <td>read, write</td> </tr> </table>	Task ID	Operations	multicast	read, write
Task ID	Operations				
multicast	read, write				

Examples

The following example shows how to display the maximum number of groups for each interface. A configuration is committed to change the maximum number of groups for each interface to 12. Before and after configuration, use the **show igmp summary** command to confirm the configuration change:

```
RP/0/RSP0/CPU0:router# show igmp summary
```

maximum groups-per-interface

IGMP summary

Robustness Value 2
 No. of Group x Interfaces 61
 Maximum number of Group x Interfaces 50000

Supported Interfaces : 18
 Unsupported Interfaces : 2
 Enabled Interfaces : 18
 Disabled Interfaces : 2

Interface	Grp No	Max Grp No
MgmtEth0/RSP0/CPU0/0	0	25000
Loopback0	4	25000
Bundle-Ether28	3	25000
Bundle-Ether28.1	3	25000
Bundle-Ether28.2	3	25000
Bundle-Ether28.3	3	25000
MgmtEth0/RP1/CPU0/0	0	25000
GigabitEthernet0/1/5/0	3	25000
GigabitEthernet0/1/5/1	5	25000
GigabitEthernet0/1/5/2	5	25000
GigabitEthernet0/6/5/1	3	25000
GigabitEthernet0/6/5/2	3	25000
GigabitEthernet0/6/5/7	3	25000

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# maximum groups-per-interface 5
RP/0/RSP0/CPU0:router(config-igmp)# commit
```

```
RP/0/RSP0/CPU0:router# show igmp summary
```

Robustness Value 2
 No. of Group x Interfaces 61
 Maximum number of Group x Interfaces 65

Supported Interfaces : 18
 Unsupported Interfaces : 2
 Enabled Interfaces : 18
 Disabled Interfaces : 2

Interface	Grp No	Max Grp No
MgmtEth0/RSP0/CPU0/0	0	5
Loopback0	4	5
Bundle-Ether28	3	5
Bundle-Ether28.1	3	5
Bundle-Ether28.2	3	5
Bundle-Ether28.3	3	5
MgmtEth0/RP1/CPU0/0	0	5
GigabitEthernet0/1/5/0	3	5
GigabitEthernet0/1/5/1	5	5
GigabitEthernet0/1/5/2	5	5
GigabitEthernet0/6/5/1	3	5
GigabitEthernet0/6/5/2	3	5
GigabitEthernet0/6/5/7	3	5

The following example shows how to configure all interfaces with 3000 maximum groups per interface except GigabitEthernet interface 0/4/0/0, which is set to 4000:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router igmp
```

```
RP/0/RSP0/CPU0:router(config-igmp)# maximum groups-per-interface 3000
RP/0/RSP0/CPU0:router(config-igmp)# interface GigabitEthernet 0/4/0/0
RP/0/RSP0/CPU0:router(config-igmp-default-if)# maximum groups-per-interface 4000
IGMP summary
```

```
Robustness Value 2
No. of Group x Interfaces 61
Maximum number of Group x Interfaces 50000
```

```
Supported Interfaces : 18
Unsupported Interfaces : 2
Enabled Interfaces : 18
Disabled Interfaces : 2
```

Interface	Grp No	Max Grp No
MgmtEth0/RP0/CPU0/0	0	25000
Loopback0	4	25000
Bundle-POS24	3	25000
Bundle-Ether28	3	25000
Bundle-Ether28.1	3	25000
Bundle-Ether28.2	3	25000
Bundle-Ether28.3	3	25000
MgmtEth0/RP1/CPU0/0	0	25000
GigabitEthernet0/1/5/0	3	25000
GigabitEthernet0/1/5/1	5	25000
GigabitEthernet0/1/5/2	5	25000
POS0/1/0/1	5	25000
POS0/1/4/2	3	25000
GigabitEthernet0/6/5/1	3	25000
GigabitEthernet0/6/5/2	3	25000
GigabitEthernet0/6/5/7	3	25000
POS0/6/0/1	3	25000
POS0/6/4/4	3	25000
POS0/6/4/5	3	25000
POS0/6/4/6	3	25000

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# maximum groups-per-interface 5
RP/0/RSP0/CPU0:router(config-igmp)# commit
RP/0/RSP0/CPU0:router# show igmp summary
```

```
Robustness Value 2
No. of Group x Interfaces 61
Maximum number of Group x Interfaces 65
```

```
Supported Interfaces : 18
Unsupported Interfaces : 2
Enabled Interfaces : 18
Disabled Interfaces : 2
```

Interface	Grp No	Max Grp No
MgmtEth0/RP0/CPU0/0	0	5
Loopback0	4	5
Bundle-POS24	3	5
Bundle-Ether28	3	5
Bundle-Ether28.1	3	5
Bundle-Ether28.2	3	5
Bundle-Ether28.3	3	5
MgmtEth0/RP1/CPU0/0	0	5
GigabitEthernet0/1/5/0	3	5
GigabitEthernet0/1/5/1	5	5
GigabitEthernet0/1/5/2	5	5
POS0/1/0/1	5	5

maximum groups-per-interface

POS0/1/4/2	3	5
GigabitEthernet0/6/5/1	3	5
GigabitEthernet0/6/5/2	3	5
GigabitEthernet0/6/5/7	3	5
POS0/6/0/1	3	5
POS0/6/4/4	3	5
POS0/6/4/5	3	5
POS0/6/4/6	3	5

```

RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# maximum groups-per-interface 3000
RP/0/RSP0/CPU0:router(config-igmp)# interface POS 0/4/0/0
RP/0/RSP0/CPU0:router(config-igmp-default-if)# maximum groups-per-interface 4000

```

Related Commands	Command	Description
	maximum groups, on page 22	Configures the maximum number of groups used by Internet Group Management Protocol (IGMP) .
	show igmp summary, on page 51	Displays group membership information for Internet Group Management Protocol (IGMP).

nsf lifetime (IGMP)

To configure the maximum time for the nonstop forwarding (NSF) timeout on the Internet Group Management Protocol (IGMP) process, use the **nsf lifetime** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

nsf lifetime *seconds*

Syntax Description	<i>seconds</i> Maximum time for NSF mode. Range is 10 to 3600 seconds.				
Command Default	<i>seconds</i> : 60				
Command Modes	IGMP configuration IGMP VRF configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	The IGMP NSF process is triggered by the restart of the IGMP process. While in IGMP NSF mode, the Multicast Routing Information Base (MRIB) purges the routes installed by the previous IGMP process when the IGMP NSF process times out. The IGMP NSF lifetime is the period for IGMP to relearn all the host membership of the attached network through membership queries and reports. During this NSF period, PIM continues to maintain forwarding state for the local members while IGMP recovers their membership reports. Additionally, IGMP recovers the internal receiver state from Local Packet Transport Services (LPTS) for IP group member applications (including the Session Announcement Protocol (SAP) Listener) and updates the MRIB.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>multicast</td><td>read, write</td></tr> </table>	Task ID	Operations	multicast	read, write
Task ID	Operations				
multicast	read, write				
Examples	The following example shows how to set the IGMP NSF timeout value to 120 seconds: <pre>RP/0/RSP0/CPU0:router(config)# router igmp RP/0/RSP0/CPU0:router(config-igmp)# nsf lifetime 120</pre>				

Related Commands	Command	Description
	nsf (multicast)	Enables NSF capability for the multicast routing system.
	nsf lifetime (PIM)	Configures the NSF timeout value for the PIM process.

Command	Description
show igmp nsf, on page 47	Displays the state of NSF operation in IGMP.
show mfib nsf	Displays the state of NSF operation for the MFIB line cards.

query-interval

To configure the frequency at which the Cisco IOS XR Software sends Internet Group Management Protocol (IGMP) host-query messages, use the **queryinterval** command in the appropriate configuration mode. To return to the default frequency, use the **no** form of this command.

query-interval *seconds*

Syntax Description	<i>seconds</i> Frequency used to send IGMP host-query messages. Range is 1 to 3600.				
Command Default	If this command is not specified in interface configuration mode, the interface adopts the query interval parameter specified in IGMP configuration mode. If this command is not specified in IGMP configuration mode, the query interval time is 60 seconds.				
Command Modes	IGMP VRF configuration IGMP interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	Multicast routers send host membership query messages (host-query messages) to discover which multicast groups have members on the attached networks of the router. Hosts respond with IGMP report messages indicating that they want to receive multicast packets for specific groups (that is, that the host wants to become a member of the group). Host-query messages are addressed to the all-hosts multicast group, which has the address 224.0.0.1, and has an IP time-to-live (TTL) value of 1. The designated router for a LAN is the only router that sends IGMP host-query messages: - For IGMP Version 1 (only), the designated router is elected according to the multicast routing protocol that runs on the LAN. - For IGMP Versions 2 and 3, , the designated querier is the lowest IP-addressed multicast router on the subnet. If the router hears no queries for the timeout period (controlled by the query-timeout command), it becomes the querier.				
					
Note	Changing the value of the <i>seconds</i> argument may severely impact network performance. A short query interval may increase the amount of traffic on the attached network, and a long query interval may reduce the querier convergence time.				
					
Note	If you configure the query-interval command in IGMP configuration mode, parameters are inherited by all new and existing interfaces. You can override these parameters on individual interfaces from interface configuration mode.				

Task ID	Task ID	Operations
	multicast	read, write

Examples

This example shows how to change the frequency at which the designated router sends IGMP host-query messages to 2 minutes:

```
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# interface gigabitEthernet

0/1/0/0
RP/0/RSP0/CPU0:router(config-igmp-default-if)# query-interval 120
```

Related Commands	Command	Description
	hello-interval (PIM)	Configures the frequency of PIM hello messages.
	query-timeout	Configures the timeout value before the router takes over as the querier for the interface.
	show igmp groups, on page 42	Displays the multicast groups that are directly connected to the router and that were learned through IGMP.

query-max-response-time

To configure the maximum response time advertised in Internet Group Management Protocol (IGMP) queries, use the **query-max-response-time** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

query-max-response-time *seconds*

Syntax Description	<i>seconds</i> Maximum response time, in seconds, advertised in IGMP queries. Range is 1 to 12.				
Command Default	If this command is not specified in interface configuration mode, the interface adopts the maximum response time parameter specified in IGMP configuration mode. If this command is not specified in IGMP configuration mode, the maximum response time is 10 seconds.				
Command Modes	IGMP VRF configuration IGMP interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	The query-max-response-time command is not supported on IGMP Version 1. This command is used to control the maximum response time for hosts to answer an IGMP query message. Configuring a value less than 10 seconds enables the router to prune groups much faster, but this action results in network burstiness because hosts are restricted to a shorter response time period. If you configure this command in IGMP configuration mode, parameters are inherited by all new and existing interfaces. You can override these parameters on individual interfaces in interface configuration mode.				
					
Note	If the hosts do not read the maximum response time in the query message correctly, group membership might be pruned inadvertently. Therefore, the hosts must know to respond faster than 10 seconds (or the value you configure).				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>multicast</td><td>read, write</td></tr> </table>	Task ID	Operations	multicast	read, write
Task ID	Operations				
multicast	read, write				
Examples	The following example shows how to configure a maximum response time of 8 seconds: <pre>RP/0/RSP0/CPU0:router(config)# router igmp RP/0/RSP0/CPU0:router(config-igmp)# interface gigabitEthernet 0/1/0/0 RP/0/RSP0/CPU0:router(config-igmp-default-if)# query-max-response-time 8</pre>				

Related Commands

Command	Description
hello-interval (PIM)	Configures the frequency of PIM hello messages.
show igmp groups, on page 42	Displays the multicast groups that are directly connected to the router and that were learned through IGMP.

query-timeout

To configure the timeout value before the router takes over as the querier for the interface, use the **query-timeout** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

query-timeout *seconds*

Syntax Description	<i>seconds</i> Number of seconds that the router waits after the previous querier has stopped querying before it takes over as the querier. Range is 60 to 300.				
Command Default	If this command is not specified in interface configuration mode, the interface adopts the timeout value parameter specified in IGMP VRF configuration mode. If this command is not specified in IGMP VRF configuration mode, the maximum response time is equal to twice the query interval set by the query-interval command.				
Command Modes	IGMP VRF configuration IGMP interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	The query timeout command is not supported on Internet Group Management Protocol (IGMP) Version 1. By default, the router waits twice the query interval specified by the query-interval command, after which, if the router has heard no queries, it becomes the querier. By default, the query interval is 60 seconds, which means that the query timeout value defaults to 120 seconds. If you configure a query timeout value less than twice the query interval, routers in the network may determine a query timeout and take over the querier without good reason.				



Note If you configure this command in IGMP configuration mode, parameters are inherited by all new and existing interfaces. You can override these parameters on individual interfaces in interface configuration mode.

Task ID	Task ID	Operations
	multicast	read, write

Examples

The following example shows how to configure the router to wait 30 seconds from the time it received the last query before it takes over as the querier for the interface:

```
RP/0/RSP0/CPU0:router(config)# router igmp
```

```
RP/0/RSP0/CPU0:router(config-igmp)# interface gigabitEthernet 0/1/0/0
RP/0/RSP0/CPU0:router(config-igmp-default-if)# query-timeout 30
```

Related Commands	Command	Description
	query-interval, on page 31	Configures the frequency at which the Cisco IOS XR Software sends Internet Group Management Protocol (IGMP) host-query messages.

robustness-count

To set the robustness variable to tune for expected packet loss on a network, use the **robustness-count** command in the appropriate configuration mode. To return to the default setting, use the **no** form of this command.

robustness-count *count*

Syntax Description

count Value of the robustness count variable. Range is 2 to 10 packets.

Command Default

Default is 2 packets.

Command Modes

IGMP VRF configuration

IGMP interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

IGMP is a soft-state protocol. State must be periodically refreshed or it times out. At a **robustness-count** command setting, for example, of 4, a network might lose three IGMP packets related to some specific state yet still maintain the state. If, however, a network lost more than three IGMP packets in the sequence, the state would time out. You might then consider changing the **robustness-count** setting to maintain state.

Task ID

Task ID	Operations
multicast	read, write

Examples

The following example illustrates the use of the **robustness-count** command:

```
RP/0/RSP0/CPU0:router(config)# configure
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# robustness-count 2
```

router

To disable or enable Internet Group Management Protocol (IGMP) membership tracking, use the **router** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

router {**disable** | **enable**}

Syntax Description	disable Turns off IGMP membership tracking. enable Turns on IGMP membership tracking.				
Command Default	If this command is not specified in IGMP VRF configuration mode, router functionality is enabled on all interfaces.				
Command Modes	IGMP interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	The router command is used to enable and disable the IGMP router functionality on a specific interface. For instance, IGMP stops queries from an interface when the router functionality is disabled on that interface. Disabling IGMP router functionality does not prevent local group membership from being announced through the group membership report.				



Note This command is useful if you want to disable or enable IGMP interfaces that have been previously enabled through the **mcast-routing** command.

Task ID	Task ID	Operations
	mcast	read, write

Examples The following example shows how to enable IGMP membership tracking functionality on all multicast enabled interfaces, except Packet-over-SONET/SDH (POS) interface 0/1/0/0:

```
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# interface gigabitEthernet 0/1/0/0
RP/0/RSP0/CPU0:router(config-igmp-default-if)# router enable
```

Related Commands

Command	Description
multicast routing	Enables multicast routing and forwarding on all enabled interfaces of the router and enters multicast routing configuration mode.

router igmp

To enter Internet Group Management Protocol (IGMP) configuration mode, use the **router igmp** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

router igmp

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Default Global configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines From IGMP VRF configuration mode, you can configure the maximum response time advertised in IGMP queries and modify the host query interval.



Note The IGMP process is turned on when the **router igmp** command or the **multicast-routing** command is initiated.

Task ID	Task ID	Operations
	multicast	read, write

Examples The following example shows how to enter IGMP configuration mode:

```
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)#
```

Related Commands	Command	Description
	interface all disable	Disables IGMP membership tracking on all interfaces.
	multicast routing	Enables multicast routing and forwarding on all enabled interfaces of the router and enters multicast routing configuration mode.

router igmp vrf

To configure route-policy to be used to map the bandwidth profile, use the **router igmp vrf** command in the Global Configuration mode. To disable this feature, use the **no** form of this command.

router igmp vrf *vrf_name* {**traffic** | **profile***profile_name*}

Syntax Description	<i>vrf_name</i>	Specifies the VRF name.
	traffic	Configures IGMP traffic variables.
	profile	Configures route-policy to be used to map the bandwidth profile.
	<i>profile_name</i>	Specifies the profile name.
Command Default	None	
Command Modes	Global Configuration mode	
Command History	Release	Modification
	Release 4.2.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	multicast	read, write

This is an example of configuring the **router igmp vrf** command in the Global Configuration mode:

```
RP/0/RSP0/CPU0:router # configure
RP/0/RSP0/CPU0:router(config)# router igmp vrf vrf1
RP/0/RSP0/CPU0:router(config)# router igmp vrf vrf1 traffic profile prof-name
```

show igmp groups

To display the multicast groups that are directly connected to the router and that were learned through Internet Group Management Protocol (IGMP), use the **show igmp groups** command in

EXEC

mode.

show igmp [**vrf** *vrf-name*] **groups** [*group-address* | *type* *interface-path-id* | **not-active** | **summary**] [**detail**] [**explicit**]

Syntax Description	vrf <i>vrf-name</i>	(Optional) Specifies a VPN routing and forwarding (VRF) instance.
	<i>group-address</i>	(Optional) Address or name of the multicast group. An address is a multicast IP address in four-part dotted-decimal notation. A name is as defined in the Domain Name System (DNS) hosts table.
	<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	(Optional) Either a physical interface or a virtual interface.
	Note Use the show interfaces command in EXEC mode to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.	
	not-active	(Optional) Displays group joins that are not processed.
	summary	(Optional) Displays the total number of (*, G) and (S, G) states in IGMP.
	detail	(Optional) Displays detail information such as IGMP Version 3 source list, host, and router mode.
	explicit	(Optional) Displays explicit tracking information.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines If you omit all optional arguments, the **show igmp groups** command displays (by group address and interface name) all the multicast memberships that the directly connected networks have subscribed.

Task ID	Task ID	Operations
	multicast	read

Examples

The following is sample output from the **show igmp groups** command on a specific (tenGigE) interface:

```
RP/0/RSP0/CPU0:router# show igmp groups tenGigE 0/4/0/0
```

```
IGMP Connected Group Membership
Group Address    Interface          Uptime    Expires    Last Reporter
224.0.0.2        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.5        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.6        TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.13       TenGigE0/4/0/0    3w6d      never      10.114.8.44
224.0.0.22       TenGigE0/4/0/0    3w6d      never      10.114.8.44
```

This table describes the significant fields shown in the display.

Table 1: show igmp groups Field Descriptions

Field	Description
Group Address	Address of the multicast group.
Interface	Interface through which the group is reachable.
Uptime	How long (in hours, minutes, and seconds) this multicast group has been known.
Expires	How long (in hours, minutes, and seconds) until the entry is removed from the IGMP groups table.
Last Reporter	Last host to report being a member of the multicast group.

Related Commands	Command	Description
	show igmp interface, on page 44	Displays Internet Group Management Protocol (IGMP) multicast-related information about an interface.

show igmp interface

To display Internet Group Management Protocol (IGMP) multicast-related information about an interface, use the **show igmp interface** command in EXEC mode.

show igmp [**vrf** *vrf-name*] **interface** [*type interface-path-id* | **state-on** | **state-off**]

Syntax Description	vrf <i>vrf-name</i>	(Optional) Specifies a VPN routing and forwarding (VRF) instance.
	<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	(Optional) Either a physical interface or a virtual interface. Note Use the show interfaces command in EXEC mode to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
	state-on	(Optional) Displays all interfaces with IGMP enabled.
	state-off	(Optional) Displays all interfaces with IGMP disabled.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Usage Guidelines If you omit the optional arguments, the **show igmp interface** command displays information about all interfaces.

Task ID	Task ID	Operations
	multicast	read

Examples The following is sample output from the **show igmp interface** command:

```
RP/0/RSP0/CPU0:router# show igmp interface

Loopback0 is up, line protocol is up
Internet address is 10.144.144.144/32
IGMP is enabled on interface
Current IGMP version is 3
```

```
IGMP query interval is 60 seconds
IGMP querier timeout is 125 seconds
IGMP max query response time is 10 seconds
Last member query response interval is 1 seconds
IGMP activity: 3 joins, 0 leaves
IGMP querying router is 10.144.144.144 (this system)
TenGigE0/4/0/0 is up, line protocol is up
  Internet address is 10.114.8.44/24
  IGMP is enabled on interface
  Current IGMP version is 3
  IGMP query interval is 60 seconds
  IGMP querier timeout is 125 seconds
  IGMP max query response time is 10 seconds
  Last member query response interval is 1 seconds
  IGMP activity: 9 joins, 4 leaves
  IGMP querying router is 10.114.8.11
Bundle-Ether16.162 is up, line protocol is up
  Internet address is 10.194.8.44/24
  IGMP is disabled on interface
Bundle-Ether16.163 is up, line protocol is up
  Internet address is 10.194.12.44/24
  IGMP is disabled on interface
GigabitEthernet0/1/0/2 is up, line protocol is up
  Internet address is 10.147.4.44/24
  IGMP is enabled on interface
  Current IGMP version is 3
  IGMP query interval is 60 seconds
  IGMP querier timeout is 125 seconds
  IGMP max query response time is 10 seconds
  Last member query response interval is 1 seconds
  IGMP activity: 6 joins, 0 leaves
  IGMP querying router is 10.147.4.44 (this system)
GigabitEthernet0/1/0/8 is up, line protocol is up
  Internet address is 10.146.4.44/24
  IGMP is enabled on interface
  Current IGMP version is 3
  IGMP query interval is 60 seconds
  IGMP querier timeout is 125 seconds
  IGMP max query response time is 10 seconds
  Last member query response interval is 1 seconds
  IGMP activity: 5 joins, 0 leaves
  IGMP querying router is 10.146.4.44 (this system)
GigabitEthernet0/1/0/18 is up, line protocol is up
  Internet address is 10.194.4.44/24
  IGMP is enabled on interface
  Current IGMP version is 3
  IGMP query interval is 60 seconds
  IGMP querier timeout is 125 seconds
  IGMP max query response time is 10 seconds
  Last member query response interval is 1 seconds
  IGMP activity: 7 joins, 2 leaves
  IGMP querying router is 10.194.4.19
GigabitEthernet0/1/0/23 is up, line protocol is up
  Internet address is 10.114.4.44/24
  IGMP is enabled on interface
  Current IGMP version is 3
  IGMP query interval is 60 seconds
  IGMP querier timeout is 125 seconds
  IGMP max query response time is 10 seconds
  Last member query response interval is 1 seconds
  IGMP activity: 9 joins, 4 leaves
  IGMP querying router is 10.114.4.11
GigabitEthernet0/1/0/27 is up, line protocol is up
  Internet address is 10.145.4.44/24
```

show igmp interface

```

IGMP is enabled on interface
Current IGMP version is 3
IGMP query interval is 60 seconds
IGMP querier timeout is 125 seconds
IGMP max query response time is 10 seconds
Last member query response interval is 1 seconds
IGMP activity: 7 joins, 2 leaves
IGMP querying router is 10.145.4.44 (this system)

```

This table describes the significant fields shown in the display.

Table 2: show igmp interface Field Descriptions

Field	Description
Loopback0 is up, line protocol is up	Interface type, number, and status.
Internet address is	Internet address of the interface and subnet mask being applied to the interface, as specified with the address command.
IGMP is enabled on interface	Indicates whether IGMP router functionality has been enabled on the interface. Note Multicast protocols do not run on Management Ethernet interfaces even if they are enabled with the CLI.
IGMP query interval is 60 seconds	Interval at which the Cisco IOS XR software sends Protocol Independent Multicast (PIM) query messages, as specified with the query-interval command.
IGMP querier timeout is...	Timeout that is set by nonquerier routers. When this timeout expires, the nonquerier routers begin to send queries.
IGMP max query response time is...	Query response time, in seconds, that is used by administrators to tune the burstiness of IGMP messages on the network. This is the maximum time within which a response to the query is received.
Last member query response is...	Query response time in seconds since a host replied to a query that was sent by the querier.
IGMP activity:	Total number of joins and total number of leaves received.
IGMP querying router is 239.122.41.51 (this system)	Indicates the elected querier on the link.

Related Commands

Command	Description
address	Sets a primary or secondary IP address for an interface.
query-interval, on page 31	Configures the frequency at which Cisco IOS XR software sends IGMP host-query messages.
router, on page 38	Disables or enables IGMP membership tracking.

show igmp nsf

To display the state of the nonstop forwarding (NSF) operation in Internet Group Management Protocol (IGMP), use the **show igmp nsf** command in EXEC mode

.

show igmp [**vrf vrf-name**] **nsf**

Syntax Description

old-output (Optional) Displays the old show output—available for backward compatibility.

vrf vrf-name (Optional) Specifies a VPN routing and forwarding (VRF) instance.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

The **show igmp nsf** command displays the current multicast NSF state for IGMP. The NSF state that is displayed may be either normal or activated for NSF. The activated state indicates that recovery is in progress due to an IGMP failure. The total NSF timeout and time remaining are displayed until NSF expiration.

Task ID

Task ID	Operations
multicast	read

Examples

The following is sample output from the **show igmp nsf** command:

```
RP/0/RSP0/CPU0:router# show igmp nsf
```

```
IGMP_AFD
```

```
Non-Stop Forwarding Status: Multicast routing state: Normal
```

```
NSF Lifetime
```

```
:          00:01
```

```
:00
```

This table describes the significant fields shown in the display.

Table 3: show igmp nsf Field Descriptions

Field	Description
Multicast routing state	Multicast NSF status of IGMP (Normal or Non-Stop Forwarding Activated).

Field	Description
NSF Lifetime	Timeout for IGMP NSF. IGMP remains in the NSF state, recovering the IGMP route state through IGMP reports for this period of time, before making the transition back to the normal state and signaling the Multicast Routing Information Base (MRIB).
NSF Time Remaining	If IGMP NSF state is activated, the time remaining until IGMP reverts to Normal mode displays.

Related Commands

Command	Description
nsf (multicast)	Enables NSF capability for the multicast routing system.
nsf lifetime (IGMP) , on page 29	Configures the NSF timeout value for the IGMP or MLD process. Configures the NSF timeout value for the IGMP process.
nsf lifetime (PIM)	Configures the NSF timeout value for the PIM process.
show mfib nsf	Displays the state of NSF operation for the MFIB line cards.
show mrrib nsf	Displays the state of NSF operation in the MRIB.
show pim nsf	Displays the state of NSF operation for PIM.

show igmp nsr

To display the nonstop routing (NSR) information in Internet Group Management Protocol (IGMP), use the **show igmp nsr** command in EXEC mode

show igmp [ipv4| ipv6] ipv4| ipv6 nsr

Syntax Description

ipv4 (Optional) Specifies IPv4 address prefixes.

ipv6 (Optional) Specifies IPv6 address prefixes

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 5.2.2	This command was introduced.

Usage Guidelines

The **show igmp nsr** command displays the current multicast NSR information for IGMP. The NSR state that is displayed may be either normal or activated for NSR. The activated state indicates that recovery is in progress due to an IGMP failure. The total NSR timeout and time remaining are displayed until NSR expiration.

Task ID

Task ID	Operations
multicast	read

Examples

The following is sample output from the **show igmp nsr** command:

```
RP/0/RSP0/CPU0:router# show igmp nsr

IGMP NSR Data :-
NSR State                  : Not Ready (uptime 4w0d)
Converged with collaborators : Y
Partner connection state   : Not-covered/Down
RMF Notif done             : Y
Last RMF ready notified    : Never [0]
Last RMF not ready notifed : 4w0d [1]
Last partner process conn up : Never [0]
Last partner process conn down : Never [0]
```

This table describes the significant fields shown in the display.

Table 4: show igmp nsr Field Descriptions

Field	Description
NSR State	Multicast Non-Stop Routing State: Ready or Not Ready

Field	Description
Converged with collaborators	Yes or No
Partner connection state	Converged/Yes or Non-converged/No
RMF Notif done	RMF notification whether activated: Yes or No
Last RMF ready notified	The Time when the last RMF ready notification was received: Yes, No, or Never. The number in the brackets indicate the number of times the RMF ready notification was received.
Last RMF not ready notified	The Time when the last RMF not ready notification was received: Yes, No, or Never. The number in the brackets indicate the number of times the RMF ready notification was received.

Related Commands

Command	Description
show msdp nsr	Displays the state of NSR operation for MSDP.
show mrrib nsr	Displays the state of NSR operation in MRIB.
show pim nsr	Displays the state of NSR operation for PIM.

show igmp summary

To display group membership information for Internet Group Management Protocol (IGMP), use the **show igmp summary** command in EXEC mode.

show igmp [**vrf vrf-name**] **summary**

Syntax Description	old-output (Optional) Displays the old show output—available for backward compatibility. vrf vrf-name (Optional) Specifies a VPN routing and forwarding (VRF) instance.				
Command Default	No default behavior or values				
Command Modes	EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </tbody> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	The show igmp summary command is used to display the total group membership. The value for number of groups is the total number of group members on all interfaces. The value for maximum number of groups is the total number of external and local members possible for all interfaces. The maximum number of groups and the default value for the maximum number of groups is 50000 members. The maximum number of groups for each interface, and the default value for the maximum number of groups for each interface, is 25000 members.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th><th>Operations</th></tr> </thead> <tbody> <tr> <td>multicast</td><td>read</td></tr> </tbody> </table>	Task ID	Operations	multicast	read
Task ID	Operations				
multicast	read				
Examples	The following example shows the number of groups for each interface that are IGMP members and the maximum number of groups that can become members on each interface:				

```
RP/0/RSP0/CPU0:router# show igmp summary
```

```
IGMP summary
```

```
Robustness Value 2
```

```
No. of Group x Interfaces 61
```

```
Maximum number of Group x Interfaces 65
```

```
Supported Interfaces : 18
```

```
Unsupported Interfaces : 2
```

```
Enabled Interfaces : 18
```

```
Disabled Interfaces : 2
```

```
Interface
```

show igmp summary

```

Grp No

  Max Grp No
Bundle-Ether28.1      3      5
MgmtEth0/RSP0/CPU0/0

0
  5
Loopback0

  4
  5
MgmtEth0/RP1/CPU0/0    0      5
Bundle-Ether28
  3      5
Bundle-Ether28

3
  5
Bundle-Ether28.1

3
  5
Bundle-Ether28.2

3
  5
Bundle-Ether28.3      3      5
MgmtEth0
/RP1
/CPU0
/0

  0
  5
GigabitEthernet0/1
/5/0
  3      5
GigabitEthernet0/1
/5/1

5
  5
GigabitEthernet0
/1
/5
/2

5
  5
GigabitEthernet0
/6/5
/1
  3      5
GigabitEthernet0
/6/5
/2
  3      5
GigabitEthernet0
/6/5
/7
  3      5

```

This table describes the significant fields shown in the display.

Table 5: show igmp summary Field Descriptions

Field	Description
No. of Group x Interfaces	Number of multicast groups that are joined through the interface.
Maximum number of Group x Interfaces	Maximum number of multicast groups that can be joined through the interface.
Supported Interfaces	Interfaces through which the multicast groups are reachable.
Unsupported Interfaces	Number of unsupported interfaces.
Enabled Interfaces	Number of enabled interfaces.
Disabled Interfaces	Number of disabled interfaces.

Related Commands

Command	Description
show igmp groups, on page 42	Displays the multicast groups that are directly connected to the router and that were learned through Internet Group Management Protocol (IGMP).

show igmp ssm map

To query the source-specific mapping (SSM) state, use the **show igmp ssm map** command in EXEC mode

show igmp [**vrf** *vrf-name*] **ssm map** [*group-address*] [**detail**]

Syntax Description	vrf	(Optional) Specifies a VPN routing and forwarding (VRF) instance to be queried.
	<i>vrf-name</i>	(Optional) Specifies the name of the specific VRF instance.
	<i>group-address</i>	(Optional) Specifies the address of the SSM group for which to obtain the mapping state.
	detail	(Optional) Displays detailed source information.

Command Default No default behavior or values

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Task ID	Task ID	Operations
	multicast	read

Examples The following example illustrates the use of the **show igmp ssm map** command:

```
RP/0/RSP0/CPU0:router# show igmp ssm map 232.1.1.1
```

```
232.1.1.1 is static with 1 source
```

show igmp traffic

To display all the Internet Group Management Protocol (IGMP) traffic-related counters, use the **show igmp traffic** command in EXEC mode

show igmp [**vrf vrf-name**] **traffic**

Syntax Description	vrf vrf-name (Optional) Specifies a VPN routing and forwarding (VRF) instance.				
Command Default	No default behavior or values				
Command Modes	EXEC				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	The show igmp traffic command is used to display the state of all counters for IGMP traffic. It gives information about the length of time the counters have been active and the count of different types of IGMP packets received, such as queries, leaves, and reports. Also, this command keeps a count of all the erroneous IGMP packets received.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>multicast</td><td>read</td></tr> </table>	Task ID	Operations	multicast	read
Task ID	Operations				
multicast	read				

Examples

The following is sample output from the **show igmp traffic** command:

```
RP/0/RSP0/CPU0:router# show igmp traffic

IGMP Traffic Counters
Elapsed time since counters cleared: 15:27:38

Valid IGMP Packet          Received      Sent
Queries                    0            2784
Reports                    2784        2792
Leaves                     0            0
Mtrace packets             0            0
DVMRP packets              0            0
PIM packets                0            0

Errors:
Malformed Packets          0
Bad Checksums              0
Socket Errors              0
Bad Scope Errors           0
Auxiliary Data Len Error   0
Subnet Errors              0
```

show igmp traffic

```
Packets dropped due to invalid socket      0
Packets which couldn't be accessed        0
```

This table describes the significant fields shown in the display for the **show igmp traffic** command.

Table 6: show igmp traffic Field Descriptions

Field	Description
Valid IGMP Packet	Total number of valid protocol packets sent and received. Valid packet types include: • Queries • Membership reports • Leaves
Queries	Total number of query packets sent and received. IP Multicast routers send queries to determine the multicast reception state of neighboring interfaces.
Reports	Total number of membership report packets received. Membership reports indicate either the current multicast reception state of a neighboring interface or a change to that state.
Leaves	Total number of leaves received. A leave group packet indicates a neighboring interface no longer has multicast reception state for a particular group.
Mtrace packets	Total number of Mtrace packets sent and received. Mtrace traces the route from a receiver to a source using a particular multicast address.
DVMRP packets	Total number of Distance Vector Multicast Routing Protocol (DVMRP) packets sent and received. DVMRP is an Internet routing protocol that provides a mechanism for connectionless datagram delivery to a group of hosts across an internetwork. This protocol dynamically generates IP multicast delivery trees using Reverse Path Multicasting. Packet type 0x13 indicates a DVMRP packet.
PIM packets	Total number of sent and received Protocol Independent Multicast (PIM) packets.
Malformed Packets	Total number of malformed packets received. A malformed packet is a packet smaller than the smallest valid protocol packet.
Bad Checksums	Total number of packets received with a bad protocol header checksum.
Socket Errors	Total number of read and write failures on the protocol socket.
Bad Scope Errors	Total number of packets received with an invalid multicast scope. Note IGMP has no invalid scopes; this counter, therefore, never increments in IGMP.
Auxiliary Data Len Errors	Total number of packets received with a non-zero auxiliary data length.

Field	Description
Subnet Errors	Total number of packets received that were not sourced on the same subnet as the router. DVMRP and MTRACE packets received are not checked for this error as they may be validly sourced from a different subnet.
Packets dropped due to invalid socket	Total number of packets dropped due to an invalid socket.
Packets which couldn't be accessed	Total number of packets that could not be sent or received. This might occur if: • Packet buffer does not form a valid protocol packet. • IP header is not written to the packet. • Outgoing packet interface handle was not set. • Errors occurred calculating the protocol checksum.
Other Packet Drops	Packets dropped for any other reason.

Related Commands

Command	Description
show pim traffic	Displays PIM traffic counter information.

show igmp unicast-qos-adjust statistics

To show the statistics of the unicast-qos-adjusted feature, use the **show igmp unicast-qos-adjust statistics** command in the EXEC mode.

show igmp unicast-qos-adjust statistics [**interface** *type interface-path-id*]

Syntax Description	interface (Optional). Displays the interface specific information such as name of the interface, number of flows adjusted, total rate adjusted, and uptime after first adjustment, in a tabular format. If the interface is specified, then the interface specific statistics are displayed with table of 5 latest updates. Specifies the output modifiers.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	Release 4.2.0	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	multicast	read

This is the sample output of the **show igmp unicast-qos-adjust statistics** command:

```
RP/0/RSP0/CPU0:router# show igmp unicast-qos-adjust statistics
```

The show igmp unicast-qos-adjust statistics output is as follows:

```
Mon Feb  4 08:47:01.640 GMT

IGMP to QoS Batch stats
Current Queue count           : 0
Last IGMP-to-QOS Batch count  : 0
Last IGMP-to-QOS Batch errors : 0
Interfaces added to queue(all batches) : 0
Interfaces removed from queue(all batches) : 0

IGMP to QoS message send stats
Number of Send Success        : 1
Number of Send Error COMMS    : 0
Number of Send Error Partial  : 0
Time elapsed since last download : 3w0d

Resync stats
Is RESYNC required            : No
```

```

Is RESYNC REQUEST received           : No
Is RESYNC START message sent         : No
Has Mark&Sweep happened anytime      : Yes
Time elapsed since last mark and sweep : 3w0d

```

This table describes the significant fields shown in the display.

Table 7: show igmp unicast-qos-adjust statistics Field Descriptions

Field	Description
IGMP to QoS Batch stats	Specifies the batch statistics details for IGMP to QoS, such as current queue count, batch counter, batch errors, number of interfaces added to the queue, and the number of interfaces removed from the queue.
IGMP to QoS message send stats	Specifies the send statistics details for IGMP to QoS, such as number of send messages that was successful, number of send messages that had errored, number of send messages that had partially errored, and time elapsed since the last download.
Resync stats	Specifies the detailed information on the resynchronization statistics, such as whether resync is required, if the resync request was received, if the resync start message was sent, if mark and sweep for the resync has taken place, and time elapsed since the last mark and sweep.

Related Commands

Command	Description
igmp query-interval, on page 16	Configures the frequency at which the Cisco IOS XR Software sends Internet Group Management Protocol (IGMP) host-query messages.
unicast-qos-adjust, on page 66	Configures the IGMP QOS Shaper for subscriber unicast traffic.
igmp explicit-tracking, on page 14	Configures explicit host tracking under Internet Group Management Protocol (IGMP) Version 3
igmp query-max-response-time, on page 18	Configures the maximum response time advertised in Internet Group Management Protocol (IGMP) queries

show igmp vrf

To show the igmp vrf specific information, use the **show igmp vrf** command in the EXEC mode.

show igmp vrf *vrf_name* {**groups** | **interface** | **nsf** | **ranges** | **ssm** | **summary** | **traffic** | **unicast-qos-adjusted**}

Syntax Description	vrf	Shows the vrf information for igmp unicast qos shaper.
	<i>vrf_name</i>	Specifies the vrf name.
	groups	Shows the igmp group membership information.
	interface	Shows igmp interface information.
	nsf	Shows igmp nsf status.
	ranges	Shows igmp group-map ranges.
	ssm	Shows ssm related information.
	summary	Shows igmp summary information.
	traffic	Show igmp traffic counters.
	unicast-qos-adjusted	Shows igmp unicast qos shaper.

Command Default None

Command Modes EXEC mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	multicast	read

This is the sample output of the **show igmp vrf** command:

```
RP/0/RSP0/CPU0:router#show igmp vrf vrf1 summary
```

The show igmp vrf vrf1 summary output is as follows:

```
Thu Feb  7 10:02:24.457 GMT
Robustness Value 2
No. of Group x Interfaces 10
Maximum number of Group x Interfaces 50000
```

```

Supported Interfaces : 2
Unsupported Interfaces : 0
Enabled Interfaces : 2
Disabled Interfaces : 0

MTE tuple count : 0

Interface                Number  Max #
                        Groups  Groups
BVI1                      3       7      10
Loopback1001              3     25000

RP/0/RSP0/CPU0:router#show igmp vrf vrf1 interface bvi1

Thu Feb  7 10:02:48.231 GMT

BVI1 is up, line protocol is up
Internet address is 172.16.251.1/30
IGMP is enabled on interface
Current IGMP version is 3
IGMP query interval is 60 seconds
IGMP querier timeout is 125 seconds
IGMP max query response time is 10 seconds
Last member query response interval is 1 seconds
IGMP activity: 26 joins, 19 leaves
IGMP querying router is 172.16.251.1 (this system)
Time elapsed since last query sent 00:00:41
Time elapsed since IGMP router enabled 3w3d
Time elapsed since last report received 00:00:32

```

This table describes the significant fields shown in the display.

Table 8: show igmp vrf Field Descriptions

Field	Description
Supported Interfaces	Specifies the number of supported interfaces.
Unsupported Interfaces	Specifies the number of unsupported interfaces.
Enabled Interfaces	Specifies the number of interfaces that are enabled.
Disabled Interfaces	Specifies the number of interfaces that are disabled.

show igmp vrf vrf_name groups

To display the IGMP group membership information, use the **show igmp vrf vrf_name groups** command in the EXEC mode.

show igmp vrf vrf_name groups ip_address

Syntax Description	ip_address Specifies the IP address or group address.
--------------------	---

Command Default	No default behavior or values
-----------------	-------------------------------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
------------------	--

Task ID	Task ID	Operation
	multicast	read

```
RP/0/RSP0/CPU0:router# show igmp vrf vrfl groups 232.1.1.1
IGMP Connected Group Membership
Group Address      Interface          Uptime    Expires    Last Reporter
232.1.1.1          tunnel-mtel        12:39:31  never      110.110.110.110
```

ssm map

To map group memberships from legacy hosts in Source-Specific Multicast (SSM) groups accepted by an access control list (ACL) to a Protocol Independent Multicast (PIM)-SSM source or to configure DNS mapping for PIM-SSM sources to a set of SSM groups, use the **ssm map** command in the appropriate configuration mode. To revert to default behavior, use the **no** form of this command.

```
ssm map { static source-address access-list | query dns }
```

Syntax Description

<i>source-address</i>	PIM-SSM source address to be used to create a static mapping.
<i>access-list</i>	ACL specifying the groups to be used to create a static mapping.
query	Configure a mapping of sources to groups querying external database.
dns	Configure a DNS mapping for sources to a set of SSM groups.

Command Default

Legacy host membership reports in the SSM group range are discarded and DNS-based SSM mapping is not enabled.

Command Modes

IGMP VRF configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 5.3.2	The keywords "query" and "DNS" were introduced to configure DNS-based SSM mapping.

Usage Guidelines

PIM-SSM requires the use of IGMPv3 (IPv4) to determine local memberships. Under normal operating conditions, IGMP discards older version group membership reports for groups in the SSM group range. This means that a host with a legacy group membership protocol is unable to receive data from a PIM-SSM source.

The **ssm map static** command maps an older group membership report to a set of PIM-SSM sources. If the ACL associated with a configured source accepts the SSM group, then that source is included in its set of sources for the SSM group.

Task ID

Task ID	Operations
multicast	read, write

Examples

The following example shows PIM-SSM mapping in IGMP routing configuration mode:

```
RP/0/RSP0/CPU0:router(config)# configuration
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# ssm map static 10.0.0.1 mc2
RP/0/RSP0/CPU0:router(config-igmp)#
```

static-group

To configure the router to be a statically configured member of the specified group on the interface, or to statically forward for a multicast group onto the interface, use the **static-group** command in the appropriate configuration mode. To return to the default behavior, use the **no** form of this command.

static-group *group-address* [**inc-mask** *mask* **count** *cnt*] [*source-address* [**inc-mask** *mask* **count** *cnt*]]

Syntax Description	<i>group-address</i> IP address of the multicast group in IPv4 prefixing format: IP address as defined in the Domain Name System (DNS) hosts table or with the domain IPv4 host in the format <i>A.B.C.D</i> .				
	inc-mask <i>mask</i> (Optional) Specifies a mask for the increment range. This is an IP address expressed range in IPv4 format. This mask is used with the group address to generate subsequent group addresses: IP address as defined in the Domain Name System (DNS) hosts table or with the domain IPv4 host in the format <i>A.B.C.D</i> . Note This mask is used with the group address to generate subsequent group addresses.				
	count <i>cnt</i> (Optional) Specifies a number of group addresses to generate using the increment mask. Range is 1 to 512.				
	<i>source address</i> (Optional) Source address of the multicast group to include in IPv4 prefixing format: IP address as defined in the Domain Name System (DNS) hosts table or with the domain IPv4 host in the format <i>A.B.C.D</i> .				
Command Default	A router is not a statically connected member of an IP multicast group.				
Command Modes	IGMP interface configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				

Usage Guidelines

When you configure the **static-group** command, packets to the group are switched out the interface, provided that packets were received on the correct Reverse Path Forwarding (RPF) interface.

The **static-group** command differs from the **join-group** command. The **join-group** command allows the router to join the multicast group and draw traffic to an IP client process (that is, the route processor). If you configure both the **join-group** and **static-group** command for the same group address, the **join-group** command takes precedence and the group behaves like a locally joined group.



Note The **static-group** command has no impact on system performance. Configuring a static-group on a loopback interface has no effect on the ASR 9000 Series Aggregation Services Router.

Task ID	Task ID	Operations
	multicast	read, write

Examples

In the following example, the router statically joins two multicast groups 225.2.2.2 and 225.2.2.4 for the specific source 1.1.1.1:

```
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# interface GigE 0/1/0/0
RP/0/RSP0/CPU0:router(config-igmp-default-if)# static-group 225.2.2.2 inc-mask 0.0.0.2 count
2 1.1.1.1
```

unicast-qos-adjust

To configure the IGMP QOS Shaper for subscriber unicast traffic, use the **unicast-qos-adjust** command in the IGMP configuration mode. To disable this feature, use the **no** form of this command.

unicast-qos-adjust {**adjustment-delay** | **download-interval** | **holdoff**}

Syntax Description	adjustment-delay	Configures the time to wait before programming rate in QOS.
	download-interval	Configures the time before downloading a batch of interfaces to QOS.
	holdoff	Configures the hold-off time before QOS clears the stale entries.

Command Default None

Command Modes IGMP configuration mode

Command History	Release	Modification
	Release 4.2.0	This command was introduced.

Usage Guidelines Use the **dynamic-template type ppp** command to enter dynamic template type ppp configuration mode.

Task ID	Task ID	Operation
	multicast	read, write

This is an example of configuring the **unicast-qos-adjust** command in the IGMP configuration mode:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router igmp
RP/0/RSP0/CPU0:router(config-igmp)# unicast-qos-adjust
```

version

To configure an Internet Group Management Protocol (IGMP) version for the router, use the **version** command in the appropriate configuration mode. To restore the default value, use the **no** form of this command.

version {1 | 2 | 3}

Syntax Description

- 1 Specifies IGMP Version 1.
- 2 Specifies IGMP Version 2.
- 3 Specifies IGMP Version 3.

Command Default

If this command is not specified in interface configuration mode, the interface adopts the IGMP version parameter specified in IGMP VRF configuration mode.

If this command is not specified in IGMP configuration mode, IGMP uses Version 3 .

Command Modes

IGMP configuration
IGMP VRF configuration
IGMP interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

All routers on the subnet must be configured with the same version of IGMP. For example, a router running Cisco IOS XR software does not automatically detect Version 1 systems and switch to Version 1. Hosts can have any IGMP version and the router will correctly detect their presence and query them appropriately.

The **query-max-response-time** and **query-timeout** commands require IGMP Version 2 or 3.



Note

If you configure this command in IGMP configuration mode, parameters are inherited by all new and existing interfaces. You can override these parameters on individual interfaces from interface configuration mode.

Task ID

Task ID Operations

multicast read,
write

Examples

The following example shows how to configure the router to use IGMP Version 3:

```
RP/0/RSP0/CPU0:router(config)# router igmp  
RP/0/RSP0/CPU0:router(config-igmp)# version 3
```

Related Commands	Command	Description
	query-max-response-time, on page 33	Configures the maximum response time advertised in Internet Group Management Protocol (IGMP) queries.
	query-timeout, on page 35	Configures the timeout value before the router takes over as the querier for the interface.

vrf (igmp)

To configure a virtual private network (VRF) instance, use the **vrf** command in IGMP routing configuration mode. To remove the VRF instance from the configuration file and restore the system to its default condition, use the **no** form of this command.

vrf *vrf-name*

Syntax Description	<i>vrf-name</i> Name of the VRF instance.				
Command Default	No default behavior or values.				
Command Modes	IGMP configuration				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 3.7.2	This command was introduced.
Release	Modification				
Release 3.7.2	This command was introduced.				
Usage Guidelines	When you use the vrf command from the IGMP routing configuration mode to configure a VRF instance, you enter the IGMP VRF configuration submode. A VRF instance is a collection of VPN routing and forwarding tables maintained at the provider edge (PE) router.				
Task ID	<table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>multicast</td><td>read, write</td></tr> </table>	Task ID	Operations	multicast	read, write
Task ID	Operations				
multicast	read, write				
Examples	The following example shows how to configure a VRF instance in IGMP configuration submode and to enter VRF configuration submode: <pre>RP/0/RSP0/CPU0:router(config)# router igmp RP/0/RSP0/CPU0:router(config-igmp)# vrf vrf_1 RP/0/RSP0/CPU0:router(config-igmp-vrf_1)#</pre>				

