



Configuring Call Home

The Call Home feature provides e-mail-based and web-based notification of critical system events. A versatile range of message formats are available for optimal compatibility with pager services, standard e-mail, or XML-based automated parsing applications. Common uses of this feature may include direct paging of a network support engineer, e-mail notification to a Network Operations Center, XML delivery to a support website, and utilization of Cisco Smart Call Home services for direct case generation with the Cisco Systems Technical Assistance Center (TAC).

Finding Feature Information in This Module

Your Cisco IOS software release may not support all of the features documented in this module. To reach links to specific feature documentation in this module and to see a list of the releases in which each feature is supported, see [Feature Information for Call Home](#).

Finding Support Information for Platforms and Cisco IOS and Catalyst OS Software Images

Use Cisco Feature Navigator to find information about platform support and Cisco IOS and Catalyst OS software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

- [Finding Feature Information, on page 1](#)
- [Prerequisites for Call Home, on page 2](#)
- [Restrictions for Call Home, on page 2](#)
- [Information About Call Home, on page 2](#)
- [How to Configure Call Home, on page 4](#)
- [Additional References, on page 45](#)
- [Feature Information for Call Home, on page 46](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <https://cfnng.cisco.com/>. An account on Cisco.com is not required.

Prerequisites for Call Home

How you configure Call Home depends on how you intend to use the feature. Consider the following requirements before you configure Call Home:

- Obtain e-mail, phone, and street address information for the Call Home contact to be configured so that the receiver can determine the origin of messages received.
- Identify the name or IPv4 address of a primary Simple Mail Transfer Protocol (SMTP) server and any backup servers, if using e-mail message delivery.
- Configure a trustpoint certificate authority (CA) if using secure HTTP (HTTPS) message delivery. For example, this procedure is required if you are using the HTTPS server for Cisco Smart Call Home Service in the CiscoTAC-1 profile for Call Home.
- Verify IP connectivity from the router to the e-mail server(s) or the destination HTTP server.
- If Cisco Smart Call Home is used, verify an active service contract exists for the device being configured.

Restrictions for Call Home

The Call Home feature does not work when the router is connected to an On-Prem server with the following default configuration:

```
crypto pki trustpoint SLA-TrustPoint
  enrollment terminal
  revocation-check crl
!
```

Use the following configuration as a workaround for the above instance:

```
crypto pki trustpoint SLA-TrustPoint
  enrollment terminal
  revocation-check none
!
```

Information About Call Home

Call Home provides e-mail-based and web-based notification of critical system events. A versatile range of message formats are available for optimal compatibility with pager services, standard e-mail, or XML-based automated parsing applications. Common uses of this feature may include direct paging of a network support engineer, e-mail notification to a Network Operations Center, XML delivery to a support website, and utilization of Cisco Smart Call Home services for direct case generation with the Cisco Systems Technical Assistance Center (TAC).

The Call Home feature can deliver alert messages containing information on configuration, environmental conditions, inventory, syslog, and crash events.

The Call Home feature can deliver alerts to multiple recipients, referred to as *Call Home destination profiles*, each with configurable message formats and content categories. A predefined destination profile (CiscoTAC-1) is provided, and you also can define your own destination profiles. The CiscoTAC-1 profile is used to send alerts to the backend server of the Smart Call Home service, which can be used to create service requests to Cisco TAC, the service will depend on the Smart Call Home service support in place for your device and the severity of the alert.

Flexible message delivery and format options make it easy to integrate specific support requirements.

Benefits of Using Call Home

The Call Home feature offers the following benefits:

- Multiple message-format options:
 - Short Text—Suitable for pagers or printed reports.
 - Plain Text—Full formatted message information suitable for human reading.
 - XML—Matching readable format using Extensible Markup Language (XML) and Adaptive Markup Language (AML) document type definitions (DTDs). The XML format enables communication with the Cisco Smart Call Home server.
- Multiple concurrent message destinations.
- Multiple message categories, including configuration, environmental conditions, inventory, syslog, and crash events
- Filtering of messages by severity and pattern matching.
- Scheduling of periodic message sending.

Obtaining Smart Call Home Services

If you have a service contract directly with Cisco, you can register for the Smart Call Home service. Smart Call Home analyzes Smart Call Home messages and provides background information and recommendations. For critical issues, Automatic Service Requests are generated with the Cisco TAC.

Smart Call Home offers the following features:

- Continuous device health monitoring and real-time alerts.
- Analysis of Smart Call Home messages and, if needed, Automatic Service Request generation routed to the correct TAC team, including detailed diagnostic information to speed problem resolution.
- Secure message transport directly from your device or through an HTTP proxy server or a downloadable Transport Gateway (TG). You can use a TG aggregation point to support multiple devices or in cases where security dictates that your devices may not be connected directly to the Internet.
- Web-based access to Smart Call Home messages and recommendations, inventory, and configuration information for all Smart Call Home devices provides access to associated field notices, security advisories, and end-of-life information.

You need the following items to register for Smart Call Home:

- SMARTnet contract number for your router.
- Your e-mail address
- Your Cisco.com username

For information on how to configure and register a Cisco ASR 1000 Series Router for Smart Call Home, see the [Smart Call Home Quick Start Configuration Guide](#)

How to Configure Call Home

Configuring the Management Interface VRF

The Call Home feature requires use of the Gigabit Ethernet Management interface virtual routing and forwarding (VRF) instance. The Gigabit Ethernet Management interface is automatically part of its own VRF named “Mgmt-intf.”

To configure the Management interface VRF, complete the following steps:

or

ipv6 address {X:X:X:X::X link-local | X:X:X:X::X/prefix [anycast | eui-64] | autoconfig [default]}

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	interface GigabitEthernet 0 Example: Router(config)# interface GigabitEthernet0	(Required) Specifies the Gigabit Ethernet Management interface on the router.
Step 3	vrf forwarding Mgmt-intf Example: Router(config-if)# vrf forwarding Mgmt-intf	(Required) Associates the Mgmt-intf VRF with the Gigabit Ethernet Management interface. This command is configured by default.
Step 4	Do one of the following: <ul style="list-style-type: none"> • ip address ip-address mask [secondary [vrf vrf-name]] • ipv6 address {X:X:X:X::X link-local X:X:X:X::X/prefix [anycast eui-64] autoconfig [default]} Example: Router(config-if)# ip address 10.10.10.10 0.0.0.0	(Required) Specifies the IPv4 or IPv6 addressing for the interface.

What To Do Next

To find out more about the Gigabit Ethernet Management interface or perform additional related configuration tasks on the management interface, see the [Using the Management Ethernet Interface](#).

Configuring a Destination Profile

A destination profile contains the required delivery information for an alert notification. You can configure multiple destination profiles of one or more type.

You can create and define a new destination profile or copy and use another destination profile. If you define a new destination profile, you must assign a profile name.



Note The Call Home feature provides a predefined profile named CiscoTAC-1 that is inactive by default. The CiscoTAC-1 profile is intended for use with the Smart Call Home service, which requires certain additional configuration steps to enable the service with the Call Home feature. For more information about this profile, see the [Using the Predefined CiscoTAC-1 Destination Profile, on page 14](#).

You can configure the following attributes for a destination profile:

- Profile name—A string that uniquely identifies each user-defined destination profile. The profile name is limited to 31 characters and is not case-sensitive. You cannot use **all** as a profile name.
- Transport method—The transport mechanism, either e-mail or HTTP (including HTTPS), for delivery of alerts.
 - For user-defined destination profiles, e-mail is the default, and you can enable one or both transport mechanisms. If you disable both methods, e-mail is enabled.
 - For the predefined Cisco TAC profile, you can enable either transport mechanism, but not both.
- Destination address—The actual address related to the transport method to which the alert should be sent.
- Message formatting—The message format used for sending the alert. The format options for a user-defined destination profile are long-text, short-text, or XML. The default is XML. For the predefined Cisco TAC profile, only XML is allowed. If you use the Cisco Smart Call Home service, the destination profile must use the XML message format.
- Message size—The maximum destination message size. The valid range is 50 to 3,145,728 bytes and the default is 3,145,728 bytes.

This section includes the following tasks:

Configuring a Destination Profile to Send Email Messages

To configure Call Home to send email messages, complete the following tasks:

Configuring the Mail Server

To use the e-mail message transport, you must configure at least one Simple Mail Transfer Protocol (SMTP) e-mail server address. You can specify up to four backup e-mail servers, for a maximum of five total mail-server definitions.

Consider the following guidelines when configuring the mail server:

- Backup e-mail servers can be defined by repeating the **mail-server** command using different priority numbers.
- The **mail-server priority number** parameter can be configured from 1 to 100. The server with the highest priority (lowest priority number) is tried first.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router(config)# call-home	Enters call home configuration mode.
Step 3	mail-server {ipv4-address name} priority number Example: Router(cfg-call-home)# mail-server smtp.example.com priority 1	Specifies an e-mail server and its relative priority among configured e-mail servers, where: <ul style="list-style-type: none"> • <i>ipv4-address</i> —Specifies the IPv4 address of the mail server. • <i>name</i> —Specifies the mail server’s fully qualified domain name (FQDN) of 64 characters or less. • <i>number</i> —Assigns a number between 1 (highest priority) and 100 (lowest priority).

What to do next

Example:

The following example shows the configuration of a primary mail server (named “smtp.example.com”) and secondary mail server at IP address 192.168.0.1:

```
Router# configure terminal

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)# call-home

Router(cfg-call-home)# mail-server smtp.example.com priority 1

Router(cfg-call-home)# mail-server 192.168.0.1 priority 2

Router(cfg-call-home)# exit
```

```
Router(config)#
```

Associating the Management Interface VRF With Call Home

The Call Home feature requires the management interface VRF (Mgmt-intf) to provide e-mail messaging support. If you have not configured the management interface VRF, see the [Configuring the Management Interface VRF, on page 4](#).

To associate the management interface VRF with Call Home, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router (config) # call-home	Enters call home configuration mode.
Step 3	vrf Mgmt-intf Example: Router (cfg-call-home) # vrf Mgmt-intf	(Required) Associates the Mgmt-intf VRF for the email transport method using Call Home.

Configuring a Destination Profile for E-mail

To configure a destination profile for e-mail transport, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router (config) # call-home	Enters call home configuration mode.
Step 3	profile name Example:	Enters call home destination profile configuration mode for the specified

	Command or Action	Purpose
	Router (config-call-home) # profile profile1	destination profile name. If the specified destination profile does not exist, it is created.
Step 4	destination transport-method email Example: Router (cfg-call-home-profile) # destination transport-method email	(Optional) Configures the message transport method for email. This is the default.
Step 5	destination address email email-address Example: Router (cfg-call-home-profile) # destination address email myaddress@example.com	(Required) Configures the destination e-mail address to which Call Home messages are sent.
Step 6	destination preferred-msg-format {long-text short-text xml} Example: Router (cfg-call-home-profile) # destination preferred-msg-format xml	(Optional) Configures a preferred message format. The default is XML.
Step 7	destination message-size bytes Example: Router (cfg-call-home-profile) # destination message-size 3145728	(Optional) Configures a maximum destination message size (from 50 to 3145728 bytes) for the destination profile. The default is 3145728 bytes.
Step 8	active Example: Router (cfg-call-home-profile) # active	(Optional) Enables the destination profile. By default, a user-defined profile is enabled when it is created.
Step 9	exit Example: Router (cfg-call-home-profile) # exit	Exits call home destination profile configuration mode and returns to call home configuration mode.
Step 10	end Example: Router (cfg-call-home) # end	Returns to privileged EXEC mode.

Configuring Other Email Options

For the e-mail transport method, you can also configure the from and reply-to e-mail addresses by completing the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router(config)# call-home	Enters call home configuration mode.
Step 3	sender from <i>email-address</i> Example: Router(cfg-call-home)# sender from username@example.com	(Optional) Assigns the e-mail address that will appear in the from field in Call Home e-mail messages. If no address is specified, the contact e-mail address is used.
Step 4	sender reply-to <i>email-address</i> Example: Router(cfg-call-home)# sender reply-to username@example.com	(Optional) Assigns the e-mail address that will appear in the reply-to field in Call Home e-mail messages.

Configuring a Destination Profile to Send HTTP Messages

To configure Call Home to send HTTP (or HTTPS) messages, complete the following tasks:

Configuring the HTTP Source Interface

If you are using HTTP or HTTPS to send Call Home messages, then you must configure the VRF management interface as the HTTP client source interface.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
Step 2	ip http client source-interface <i>type number</i> Example: <pre>Router(config)# ip http client source-interface gigabitethernet 0</pre>	Configures the source interface for the HTTP client. Note This interface should be the VRF management interface.
Step 3	end Example: <pre>Router(cfg-call-home)# end</pre>	Returns to privileged EXEC mode.

Configuring a Destination Profile for HTTP

To configure a destination profile for http transport, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: <pre>Router# configure terminal</pre>	Enters global configuration mode.
Step 2	call-home Example: <pre>Router(config)# call-home</pre>	Enters call home configuration mode.
Step 3	profile <i>name</i> Example: <pre>Router(config-call-home)# profile test</pre>	Enters call home destination profile configuration mode for the specified destination profile. If the specified destination profile does not exist, it is created.
Step 4	destination transport-method http Example: <pre>Router(cfg-call-home-profile)# destination transport-method http</pre>	Enables the HTTP message transport method.
Step 5	destination address http <i>url</i> Example:	Configures the destination URL to which Call Home messages are sent. Note

	Command or Action	Purpose
	<pre>Router(cfg-call-home-profile)# destination address http https://example.url.com</pre>	When entering a destination URL, include either http:// or https:// , depending on whether the server is a secure server. If the destination is a secure server, you must also configure a trustpoint CA.
Step 6	<pre>destination preferred-msg-format {long-text short-text xml} Example: Router(cfg-call-home-profile)# destination preferred-msg-format xml</pre>	(Optional) Configures a preferred message format. The default is XML.
Step 7	<pre>destination message-size bytes Example: Router(cfg-call-home-profile)# destination message-size 3,145,728</pre>	(Optional) Configures a maximum destination message size for the destination profile.
Step 8	<pre>active Example: Router(cfg-call-home-profile)# active</pre>	Enables the destination profile. By default, a profile is enabled when it is created.
Step 9	<pre>exit Example: Router(cfg-call-home-profile)# exit</pre>	Exits call home destination profile configuration mode and returns to call home configuration mode.
Step 10	<pre>end Example: Router(cfg-call-home)# end</pre>	Returns to privileged EXEC mode.

Configuring a Trustpoint Certificate Authority

If you are using the HTTP transport method and specifying an HTTPS destination URL, then you will also need to configure a trustpoint certificate authority (CA).

For more information about how to configure a trustpoint CA, see the [Declare and Authenticate a CA Trustpoint](#). That section describes how to configure a CA trustpoint for a secure Cisco server to use with the Smart Call Home service, but can be applied to other secure server configuration as needed by your site using the required certificate for your secure server.

Working With Destination Profiles

This section describes some of the tasks that you can complete with destination profiles:

Activating and Deactivating a Destination Profile

Except for the predefined CiscoTAC-1 profile, all Call Home destination profiles are automatically activated once you create them. If you do not want to use a profile right way, you can deactivate the profile. The CiscoTAC-1 profile is inactive by default and must be activated to be used.

To activate or deactivate a destination profile, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router(config)# call-home	Enters call home configuration mode.
Step 3	profile name Example: Router(config-call-home)# profile test	Enters call home destination profile configuration mode for the specified destination profile. If the specified destination profile does not exist, it is created.
Step 4	active Example: Router(cfg-call-home-profile)# active	Enables the destination profile. By default, a new profile is enabled when it is created.
Step 5	no active Example: Router(cfg-call-home-profile)# no active	Disables the destination profile.
Step 6	end Example: Router(cfg-call-home)# end	Exits call home destination profile configuration mode and returns to privileged EXEC mode.

Copying a Destination Profile

To create a new destination profile by copying an existing profile, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router(config)# call-home	Enters call home configuration mode.
Step 3	copy profile <i>source-profile target-profile</i> Example: Router(cfg-call-home)# copy profile profile1 profile2	Creates a new destination profile with the same configuration settings as the existing destination profile, where: <ul style="list-style-type: none"> • <i>source-profile</i> —Specifies the existing name of the profile. • <i>target-profile</i> —Specifies a name for the new copy of the profile.

Renaming a Destination Profile

To change the name of an existing profile, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router(config)# call-home	Enters call home configuration mode.
Step 3	rename profile <i>source-profile target-profile</i> Example:	Renames an existing source file, where: <ul style="list-style-type: none"> • <i>source-profile</i> —Specifies the existing name of the profile.

	Command or Action	Purpose
	Router (cfg-call-home) # rename profile2 testprofile	<ul style="list-style-type: none"> • <i>target-profile</i> —Specifies a new name for the existing profile.

Using the Predefined CiscoTAC-1 Destination Profile

The CiscoTAC-1 profile is automatically configured in the Call Home feature for your use with the Cisco Smart Call Home service. This profile includes certain information, such as the destination e-mail address and HTTPS URL, and default alert groups for communication with the Smart Call Home service. Some of these attributes, such as the destination e-mail address, HTTPS URL, and message format cannot be modified.

You can use either email or http transport to communicate with the Smart Call Home service backend server. By default, the CiscoTAC-1 profile is inactive and uses email as the default transport method. To use email transport, you only need to enable the profile. However, to use this profile with the Cisco Smart Call Home service secure server (via HTTPS), you not only must enable the profile, but you must also change the transport method to HTTP as shown in the following example:

```
Router# configure terminal
Router (config) # call-home
Router (config-call-home) # profile CiscoTAC-1
Router (cfg-call-home-profile) # destination transport-method http
Router (cfg-call-home-profile) # active
```

For more information about additional requirements for Configuring the Smart Call Home service, see the [How To Configure Call Home to Support the Smart Call Home Service](#) section.

Verifying the Call Home Profile Configuration

To verify the profile configuration for Call Home, use the **show call-home profile** command. See [Displaying Call Home Configuration Information](#) for more information and examples.

Subscribing to Alert Groups

An alert group is a predefined subset of Call Home alerts supported in all routers. Different types of Call Home alerts are grouped into different alert groups depending on their type. The following alert groups are available on the router:

- Configuration
- Diagnostic
- Environment
- Inventory
- Syslog

The triggering events for each alert group are listed in the [Alert Group Trigger Events and Commands, on page 34](#), and the contents of the alert group messages are listed in the [Message Contents, on page 35](#).

You can select one or more alert groups to be received by a destination profile.



Note A Call Home alert is only sent to destination profiles that have subscribed to the alert group containing that Call Home alert. In addition, the alert group must be enabled.

Periodic Notification

When you subscribe a destination profile to either the Configuration or the Inventory alert group, you can choose to receive the alert group messages asynchronously or periodically at a specified time. The sending period can be one of the following:

- **Daily**—Specify the time of day to send, using an hour:minute format hh:mm, with a 24-hour clock (for example, 14:30).
- **Weekly**—Specify the day of the week and time of day in the format day hh:mm, where the day of the week is spelled out (for example, monday).
- **Monthly**—Specify the numeric date, from 1 to 31, and the time of day, in the format date hh:mm.

Message Severity Threshold

When you subscribe a destination profile to the Environment or Syslog alert group, you can set a threshold for the sending of alert group messages based on the message's level of severity. Any message with a severity lower than the specified threshold of the destination profile is not sent to the destination.



Note When syslog level is changed via IOS CLI, the new value is propagated to non-IOS processes as well, with the result that these processes no longer send syslog messages of lower priority to IOS to process, thus "saving" CPU cycles for IOS.

The table below lists the keywords used to configure the severity, which range from catastrophic (level 9, highest level of urgency) to debugging (level 0, lowest level of urgency). If no severity threshold is configured, the default is debugging (level 0). However, the default is not recommended due to the number of messages that will be triggered.



Note Call Home severity levels are not the same as system message logging severity levels.

Table 1: Severity and Syslog Level Mapping

Level	Keyword	Syslog Level	Description
9	catastrophic	N/A	Network-wide catastrophic failure.
8	disaster	N/A	Significant network impact.
7	fatal	Emergency (0)	System is unusable.
6	critical	Alert (1)	Critical conditions, immediate attention needed.
5	major	Critical (2)	Major conditions.
4	minor	Error (3)	Minor conditions.
3	warning	Warning (4)	Warning conditions.
2	notification	Notice (5)	Basic notification and informational messages. Possibly independently insignificant.

Level	Keyword	Syslog Level	Description
1	normal	Information (6)	Normal event signifying return to normal state.
0	debugging	Debug (7)	Debugging messages.

Syslog Pattern Matching

When you subscribe a destination profile to the Syslog alert group, you can optionally specify a text pattern to be matched within each syslog message. If you configure a pattern, a Syslog alert group message is sent only if it contains the specified pattern and meets the severity threshold. If the pattern contains spaces, you must enclose it within double quotation marks(“ ”) when configuring it. You can specify up to five patterns for each destination profile.

To subscribe a destination profile to one or more alert groups, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Device (config)# call-home	Enters call home configuration mode.
Step 3	alert-group {all configuration environment inventory syslog} Example: Device (cfg-call-home)# alert-group all	Enables the specified alert group. Use the all keyword to enable all alert groups. By default, all alert groups are enabled.
Step 4	profile name Example: Device (cfg-call-home)# profile profile1	Enters call home destination profile configuration mode for the specified destination profile.
Step 5	subscribe-to-alert-group all Example: Device (cfg-call-home-profile)# subscribe-to-alert-group all	(Optional) Subscribes this destination profile to all available alert groups. Note Alternatively, you can also subscribe to alert groups individually by specific type as described in steps 6 through 9.

	Command or Action	Purpose
Step 6	<p>subscribe-to-alert-group configuration [periodic {daily <i>hh:mm</i> monthly <i>date hh:mm</i> weekly <i>day hh:mm</i>}]</p> <p>Example:</p> <pre>Device(cfg-call-home-profile)# subscribe-to-alert-group configuration periodic daily 12:00</pre>	Subscribes this destination profile to the Configuration alert group, with an optional periodic value.
Step 7	<p>subscribe-to-alert-group diagnostic [severity {catastrophic critical debugging disaster fatal major minor normal notification warning}]</p> <p>Example:</p> <pre>Device(cfg-call-home-profile)# subscribe-to-alert-group diagnostic severity critical</pre>	Subscribes this destination profile to the Diagnostic alert group, with an optional severity level.
Step 8	<p>subscribe-to-alert-group environment [severity {catastrophic critical debugging disaster fatal major minor normal notification warning}]</p> <p>Example:</p> <pre>Device(cfg-call-home-profile)# subscribe-to-alert-group environment severity major</pre>	Subscribes this destination profile to the Environment alert group, with an optional severity level.
Step 9	<p>subscribe-to-alert-group inventory [periodic {daily <i>hh:mm</i> monthly <i>date hh:mm</i> weekly <i>day hh:mm</i>}]</p> <p>Example:</p> <pre>Device(cfg-call-home-profile)# subscribe-to-alert-group inventory periodic monthly 1 12:00</pre>	Subscribes this destination profile to the Inventory alert group, with an optional periodic value.
Step 10	<p>subscribe-to-alert-group syslog [severity {catastrophic critical debugging disaster fatal major minor normal notification warning;}][<i>pattern string</i>]</p> <p>Example:</p> <pre>Device(cfg-call-home-profile)# subscribe-to-alert-group syslog</pre>	Subscribes this destination profile to the Syslog alert group, with an optional severity level. You can specify a pattern to be matched in the syslog message, up to a maximum of five patterns per profile. If the pattern contains spaces, you must enclose it within double quotation marks (“”).

Configuring Contact Information

Each router must include a contact email address. You can optionally include a phone number, street address, contract ID, customer ID, and site ID.

To assign the contact information, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router> configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router(config)# call-home	Enters call home configuration mode.
Step 3	contact-email-addr <i>email-address</i> Example: Router(cfg-call-home)# contact-email-addr username@example.com	Assigns the customer's email address. Enter up to 200 characters in email address format with no spaces.
Step 4	phone-number <i>+phone-number</i> Example: Router(cfg-call-home)# phone-number +1-222-333-4444	(Optional) Assigns the customer's phone number. Note The number must start with a plus (+) prefix, and may contain only dashes (-) and numbers. Enter up to 16 characters. If you include spaces, you must enclose your entry within double quotation marks ("").
Step 5	street-address <i>street-address</i> Example: Router(cfg-call-home)# street-address "1234 Any Street, Any city, Any state, 12345"	(Optional) Assigns the customer's street address where RMA equipment can be shipped. Enter up to 200 characters. If you include spaces, you must enclose your entry within double quotation marks ("").
Step 6	customer-id <i>text</i> Example: Router(cfg-call-home)# customer-id Customer1234	(Optional) Identifies the customer ID. Enter up to 64 characters. If you include spaces, you must enclose your entry within double quotation marks ("").

	Command or Action	Purpose
Step 7	site-id <i>text</i> Example: Router (cfg-call-home) # site-id Site1ManhattanNY	(Optional) Identifies the customer site ID. Enter up to 200 characters. If you include spaces, you must enclose your entry within double quotation marks (“”).
Step 8	contract-id <i>text</i> Example: Router (cfg-call-home) # contract-id Company1234	(Optional) Identifies the customer’s contract ID for the router. Enter up to 64 characters. If you include spaces, you must enclose your entry within double quotation marks (“”).

Example

The following example shows the configuration of contact information:

```

Device# configure terminal

Enter configuration commands, one per line.  End with CNTL/Z.

Device(config)# call-home

Device(cfg-call-home)# contact-email-addr username@example.com

Device(cfg-call-home)# phone-number +1-222-333-4444

Device(cfg-call-home)# street-address "1234 Any Street, Any city, Any state, 12345"

Device(cfg-call-home)# customer-id Customer1234

Device(cfg-call-home)# site-id Site1ManhattanNY

Device(cfg-call-home)# contract-id Company1234

Device(cfg-call-home)# exit

```

Configuring the Number of Call Home Messages Sent Per Minute

The Call Home feature defaults to a maximum of 20 messages per minute. If you want to change that value, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router(config)# call-home	Enters call home configuration mode.
Step 3	rate-limit number Example: Router(cfg-call-home)# rate-limit 40	Specifies a limit on the number of messages sent per minute. Range 1 to 60. The default is 20.

Sending Call Home Communications Manually

You can manually send several types of Call Home communications. To send Call Home communications, complete the tasks in this section. This section contains the following subsections:

Sending a Call Home Test Message Manually

You can use the **call-home test** command to send a user-defined Call Home test message.

Procedure

	Command or Action	Purpose
Step 1	call-home test [" <i>test-message</i> "] profile name Example: Router# call-home test profile profile1	Sends a test message to the specified destination profile. The user-defined test message text is optional, but must be enclosed in quotes (" ") if it contains spaces. If no user-defined message is configured, a default message is sent.

Sending Call Home Alert Group Messages Manually

You can use the **call-home send** command to manually send a specific alert group message.

Note the following guidelines when manually sending a Call Home alert group message:

- Configuration, , and inventory alert groups can be sent manually.
- When you manually trigger an alert group message and you specify a destination profile name, a message is sent to the destination profile regardless of the active status, subscription status, or severity setting of the profile.

- When you manually trigger a configuration or inventory alert group message and do not specify a destination profile name, a message is sent to all active profiles that have either a normal or periodic subscription to the specified alert group.
- When you manually trigger a diagnostic alert group message and do not specify a destination profile name, a message is sent to all active profiles that have a lower severity subscription than the severity of the diagnostic results of the specified slot.

To manually trigger Call Home alert group messages, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	call-home send alert-group configuration [profile name] Example: Device# call-home send alert-group configuration profile CiscoTAC-1	Sends a configuration alert group message to one destination profile if specified, or to all subscribed destination profiles.
Step 2	call-home send alert-group inventory [profile name] Example: Device# call-home send alert-group inventory	Sends an inventory alert group message to one destination profile if specified, or to all subscribed destination profiles.

Submitting Call Home Analysis and Report Requests

The **call-home request** command allows you to submit the system information to Cisco Systems. The report provides helpful analysis and information specific to your system. You can request various reports, including security alerts, known bugs, recommendations, and the command references.

Note the following guidelines when manually sending Call Home analysis and report requests:

- If a **profile name** is specified, the request is sent to the profile. If no profile is specified, the request is sent to the Cisco TAC profile. The Call-home request can have a recipient profile that is not enabled. The recipient profile specifies the email address where the transport gateway is configured. The recipient profile allows the request message to be forwarded to the Cisco TAC and you can receive the reply from the Smart Call Home service.
- The **ccoid user-id** is the registered identifier of the Smart Call Home user. If the **user-id** is specified, the response is sent to the email address of the registered user. If no **user-id** is specified, the response is sent to the contact email address of the device.
- Based on the keyword specifying the type of report that is requested, the following information is returned:
 - **config-sanity**—Information on the recommendations for the current running configuration.
 - **bugs-list**—Known bugs in the running version and in the currently applied features.
 - **command-reference**—Reference links to all commands in the running configuration.

Example

- **product-advisory**—Product Security Incident Response Team (PSIRT) notices. The PSIRT includes End of Life (EOL) or End of Sales (EOS) notices, or field notices (FN) that may affect devices in your network.

To submit a request for analysis and report information from the Cisco Output Interpreter tool, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	call-home request output-analysis <i>"show-command"</i> Example: <code>[profile name] [ccoid user-id]</code> Example: <pre>Device# call-home request output-analysis "show diag" profile TG</pre>	Sends the output of the specified show command for analysis. The show command must be contained in quotes ("").
Step 2	call-home request {config-sanity bugs-list command-reference product-advisory} Example: <code>[profile name] [ccoid user-id]</code> Example: <pre>Device# call-home request config-sanity profile TG</pre>	Sends the output of a predetermined set of commands, such as the show running-config all and show version commands, for analysis. In addition, the call home request product-advisory subcommand includes all inventory alert group commands. The keyword that is specified after the call-home request command specifies the type of report requested.

Example

The following example shows a request for analysis of a user-specified **show** command:

```
Router# call-home request output-analysis "show diag" profile TG
```

Sending the Output of a Command to Cisco or an E-Mail Address

You can use the **call-home send** command to execute a CLI command and e-mail the command output to Cisco or to an e-mail address that you specify.

Note the following guidelines when sending the output of a command:

- The specified CLI command can be any run command, including commands for all modules. The command must be contained in quotes ("").

- If an e-mail address is specified, the command output is sent to that address. If no e-mail address is specified, the output is sent to the Cisco TAC (attach@cisco.com). The e-mail is sent in long text format with the service number, if specified, in the subject line.
- The service number is required only if no e-mail address is specified, or if a Cisco TAC e-mail address is specified.

To execute a CLI command and e-mail the command output, complete the following step:

Procedure

	Command or Action	Purpose
Step 1	<p>call-home send “<i>command</i>”</p> <p>Example:</p> <pre>{email <i>email-addr</i> [tac-service-request <i>request-number</i>] tac-service-request <i>request-number</i> [email <i>email-addr</i>]}</pre> <p>Example:</p> <pre>Router# call-home send "show call-home" email support@example.com</pre>	<p>Executes the specified CLI command and e-mails the output, where:</p> <ul style="list-style-type: none"> • email <i>email-addr</i> —Specifies the email address to which the command output should be sent. This keyword is optional if used after entering the tac-service-request option. • tac-service-request <i>request-number</i> —Specifies the TAC service request number that will appear in the subject line of the email. This keyword is optional if used after entering the email option.

Example

The following example shows how to send the output of a CLI command to a user-specified e-mail address:

```
Router# call-home send "show diag" email support@example.com
```

How To Configure Call Home to Support the Smart Call Home Service

This section provides an overview of the minimum steps required to configure the Call Home feature on a Cisco device, and other required supporting configuration to communicate securely with the Smart Call Home service using HTTPS:

Prerequisites

Before you configure and use the Smart Call Home Service, be sure that you have completed the following prerequisites:

- Verify that you have an active Cisco Systems service contract for the device being configured.
- Verify that you have IP connectivity to the Cisco HTTPS server.
- Obtain the latest Cisco Systems server security certificate. In Cisco IOS XE Release 2.6.0, the following shows the latest text for the Cisco Systems server security certificate:

```
MIIDAjCCAmSCEH3Z/gfPqB63EHln+6eJNMYwDQYJKoZIhvcNAQEFBQAwwcExCzAJ
BgNVBAYTAlVTMRcwFQYDVQQKEw5WZXJpU2lnbiwgSW5jLjE8MDoGA1UECzMzQ2xh
```

```
c3MgMyBQdWJsaWMgUHJpbWFyeSBDZXJ0aWZpY2F0aW9uIEF1dGhvcml0eSAtIEcy
MTowOAYDVQQLZezEoYykgMTk5OCBwZXJpU2lnbiwgSW5jLiAtIEZvciBhdXRob3Jp
emVkiHVzZSBvbmx5MR8wHQYDVQQLZXJpU2lnbiBucnVzdB0ZXR3b3JrMB4X
DTk4MDUxODAwMDAwMFOxDTI4MDgwMTIzNTk1OVowgcExCzAJBgNVBAYTAlVTMRcw
FQYDVQQKEw5WZXJpU2lnbiwgSW5jLjE8MDoGA1UECXMzQ2xhc3MgMyBQdWJsaWMg
UHJpbWFyeSBDZXJ0aWZpY2F0aW9uIEF1dGhvcml0eSAtIEcyMTowOAYDVQQLZezEo
YykgMTk5OCBwZXJpU2lnbiwgSW5jLiAtIEZvciBhdXRob3JpemVkiHVzZSBvbmx5
MR8wHQYDVQQLZXJpU2lnbiBucnVzdB0ZXR3b3JrMIGfMA0GCSqGSIb3DQEB
AQUAA4GNADCBiQKBgQDMXtERXVxp0KvTuWpMmR9ZmDCOFoUgRm1HP9SFIIThbbP4
p00M8RcPO/mn+SXXwc+EY/J8Y8+iR/LGWzOOZEAEaMGAuWQcRXfH2G711Sk8U0g0
13gflptQ5Gvj0VXXn7F+8qkBOvqlzdUMG+7AUcyM83cV5tkaWH4mx0ciU9cZwID
AQABMA0GCSqGSIb3DQEBBQUAA4GBAFFNzb5cy5gZnBWyAT14Lk0PZ3BwmcYQWpSk
U01UbSuvDV1Ai2TT1+7eVmGSX6bEHRBhNtMsJzZoKQm5EWR0zLVznxxIqbxhAe7i
F6YM40AIOW7n60RzKprxaZLvcRTDOaxxp5EJb+RxBR06WVcmeQD2+A2iMzAo1KpY
oJ2daZH9
```

Configure and Enable Call Home

To establish the Cisco Smart Call Home service, there are certain steps that must be performed to configure and enable the Call Home feature on the router.

The CiscoTAC-1 profile is predefined in the Call Home feature to communicate using email to the back-end server for the Smart Call Home service. The URL to the Cisco HTTPS back-end server is also predefined. This profile is inactive by default.

However, unlike other profiles that you can configure in Call Home to support both transport methods, the CiscoTAC-1 profile can only use one transport method at a time. Therefore, to use this profile with the Cisco Smart Call Home HTTPS server, you must change the transport method from email to HTTP and enable the profile. In addition, you must minimally specify a contact e-mail address and enable the Call Home feature.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	call-home Example: Router (config)# call-home	Enters call home configuration mode.
Step 3	profile CiscoTAC-1 Example: Router (config-call-home)# profile CiscoTAC-1	Enters call home destination profile configuration mode for the CiscoTAC-1 destination profile.
Step 4	destination transport-method http Example:	(Required only if using HTTPS) Configures the message transport method for http.

	Command or Action	Purpose
	Router (cfg-call-home-profile) # destination transport-method http	
Step 5	active Example: Router (cfg-call-home-profile) # active	Enables the destination profile.
Step 6	exit Example: Router (cfg-call-home-profile) # exit	Exits call home destination profile configuration mode and returns to call home configuration mode.
Step 7	contact-email-addr <i>email-address</i> Example: Router (cfg-call-home) # contact-email-addr username@example.com	Assigns the customer's e-mail address. Enter up to 200 characters in e-mail address format with no spaces.
Step 8	exit Example: Router (cfg-call-home) # exit	Exits call home configuration mode and returns to global configuration mode.
Step 9	service call-home Example: Router (config) # service call-home	Enables the Call Home feature.
Step 10	exit Example: Router (config) # exit	Exits global configuration mode and returns to privileged EXEC mode.
Step 11	copy running-config startup-config Example: Router# copy running-config startup-config	Saves the configuration to NVRAM.

Enabling and Disabling Call Home

To enable or disable the Call Home feature, complete the following steps:

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	service call-home Example: Router(config)# service call-home	Enables the Call Home feature.
Step 3	no service call-home Example: Router(config)# no service call-home	Disables the Call Home feature.

Declare and Authenticate a CA Trustpoint

To establish communication with the Cisco HTTPS server for Smart Call Home service, you must declare and authenticate the Cisco server security certificate.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	crypto pki trustpoint <i>name</i> Example: Router(config)# crypto pki trustpoint cisco	Declares a CA trustpoint on your router and enters CA trustpoint configuration mode.
Step 3	enrollment terminal Example: Router(ca-trustpoint)# enrollment terminal	Specifies a manual cut-and-paste method of certificate enrollment.
Step 4	exit Example:	Exits CA trustpoint configuration mode and returns to global configuration mode.

	Command or Action	Purpose
	Router(ca-trustpoint)# exit	
Step 5	crypto pki authenticate <i>name</i> Example: Router(config)# crypto pki authenticate cisco	Authenticates the named CA. Note The CA name should match the <i>name</i> specified in the crypto pki trustpoint command.
Step 6	At the prompt, paste the security certificate text. Example: Enter the base 64 encoded CA certificate. Example: End with a blank line or the word "quit" on a line by itself Example: <Paste certificate text here>	Specifies the security certificate text.
Step 7	quit Example: quit	Specifies the end of the security certificate text.
Step 8	yes Example: % Do you accept this certificate? [yes/no]: yes	Confirms acceptance of the entered security certificate.
Step 9	end Example: Router# end	Exits global configuration mode and returns to privileged EXEC mode.
Step 10	copy running-config startup-config Example: Router# copy running-config startup-config	Saves the configuration to NVRAM.

Example: Declaring and authenticating the Cisco server security certificate

The following example shows the configuration for declaring and authenticating the Cisco server security certificate:

```

Router# configure terminal
Router(config)# crypto pki trustpoint cisco
Router(ca-trustpoint)# enrollment terminal
Router(ca-trustpoint)# exit
Router(config)# crypto pki authenticate cisco
Enter the base 64 encoded CA certificate.
End with a blank line or the word "quit" on a line by itself
MIIDAjCCAmCEH3Z/gfPqB63EHln+6eJNMYwDQYJKoZIhvcNAQEFBQAwwcExCzAJ
BgNVBAYTAlVTMRcwFQYDVQQKEw5WZXXpU2lnbiwgSW5jLjE8MDoGAlUECXMzQ2xh
c3MgMyBQdWJsaWMgUHJpbWVyeSBDZXJ0aWZpY2F0aW9uIEF1dGhvcml0eSAtIEcy
MTowOAYDVQQLEzEoYykgMTk5OCBwZXJpU2lnbiwgSW5jLiAtIEZvciBhdXRob3Jp
emVkiHVzZSBvbmx5MR8wHQYDVQQLZXZlbnBiUcnVzdCB0ZXR3b3JrMB4X
DTk4MDUxODAwMDAwMFOxDTI4MDgwMTIzNTk1OVowcExCzAJBgNVBAYTAlVTMRcw
FQYDVQQKEw5WZXXpU2lnbiwgSW5jLjE8MDoGAlUECXMzQ2xhc3MgMyBQdWJsaWMg
UHJpbWVyeSBDZXJ0aWZpY2F0aW9uIEF1dGhvcml0eSAtIEcyMTowOAYDVQQLEzEo
YykgMTk5OCBwZXJpU2lnbiwgSW5jLiAtIEZvciBhdXRob3JpemVkiHVzZSBvbmx5
MR8wHQYDVQQLZXZlbnBiUcnVzdCB0ZXR3b3JrMIGfMA0GCSqGSIb3DQEB
AQUAA4GNADCBiQKBgQDMXtERXVxp0KvTuWpMmR9ZmDCoFoUgRm1HP9SFIIThbbP4
pO0M8RcPO/mn+SXXwc+EY/J8Y8+iR/LGWzOOZEAEaMGauWQcRXfH2G71lSk8UOg0
13gfgLptQ5GvJ0VXXn7F+8qkBOvqlzdUMG+7AUcyM83cV5tkaWH4mx0ciU9cZwID
AQABMA0GCSqGSIb3DQEBBQUAA4GBAFFNzb5cy5gZnBWyAT14Lk0PZ3BwmcYQWpSk
U01UbSuvDV1Ai2TT1+7eVmGSX6bEHRBhNtMsJzZoKQm5EWR0zLVznxxIqbxhAe7i
F6YM40AIOw7n60RzKprxaZLvcRTDOaxxp5EJb+RxBrO6WVcmeQD2+A2iMzAo1KpY
oJ2daZH9
quit
Certificate has the following attributes:
    Fingerprint MD5: A2339B4C 747873D4 6CE7C1F3 8DCB5CE9
    Fingerprint SHA1: 85371CA6 E550143D CE280347 1BDE3A09 E8F8770F
% Do you accept this certificate? [yes/no]: yes
Trustpoint CA certificate accepted.
% Certificate successfully imported
Router(config)# end
Router# copy running-config startup-config

```

Start Smart Call Home Registration

To start the Smart Call Home registration process, manually send an inventory alert-group message to the CiscoTAC-1 profile.

Procedure

	Command or Action	Purpose
Step 1	call-home send alert-group inventory profile CiscoTAC-1 Example: Device# call-home send alert-group inventory profile CiscoTAC-1	Sends an inventory alert group message to the CiscoTAC-1 destination profile.

What To Do Next

To receive an email from Cisco Systems and follow the instructions to complete the device registration in the Smart Call Home web application:

- Launch the Smart Call Home web application at the following URL:

<https://tools.cisco.com/sch/>

- Accept the Legal Agreement.
- Confirm device registration for Call Home devices with pending registration.

For more information about using the Smart Call Home web application, see *Smart Call Home User Guide*. This user guide also includes configuration examples for sending Smart Call Home messages directly from your device or through a transport gateway (TG) aggregation point. You can use a TG aggregation point in cases requiring support for multiple devices or in cases where security requirements mandate that your devices must not be connected directly to the Internet.

Displaying Call Home Configuration Information

You can use variations of the **show call-home** command to display Call Home configuration information.

To display the configured Call Home information, use one or more of the following commands:

Procedure

	Command or Action	Purpose
Step 1	show call-home Example: Device# show call-home	Displays the Call Home configuration in summary.
Step 2	show call-home detail Example: Device# show call-home detail	Displays the Call Home configuration in detail.
Step 3	show call-home alert-group Example: Device# show call-home alert-group	Displays the available alert groups and their status.
Step 4	show call-home mail-server status Example: Device# show call-home mail-server status	Checks and displays the availability of the configured e-mail server(s).
Step 5	show call-home profile {all name} Example: Device# show call-home profile all	Displays the configuration of the specified destination profile. Use the all keyword to display the configuration of all destination profiles.
Step 6	show call-home statistics Example:	Displays the statistics of Call Home events.

	Command or Action	Purpose
	Device# show call-home statistics	

Configuration Examples for Call Home

The following examples show the sample output when using different options of the **show call-home** command.

Examples

The following examples show the sample output when using different options of the **show call-home** command.

Configured Call Home Information in Summary

```
Router# show call-home
Current call home settings:
  call home feature : disable
  call home message's from address: username@example.com
  call home message's reply-to address: username@example.com
  vrf for call-home messages: Mgmt-intf
  contact person's email address: username@example.com
  contact person's phone number: +14085551234
  street address: 1234 Any Street Any city Any state 12345
  customer ID: customer@example.com
  contract ID: 123456789
  site ID: example.com
  Mail-server[1]: Address: smtp.example.com Priority: 1
  Mail-server[2]: Address: 192.168.0.1 Priority: 2
  Rate-limit: 20 message(s) per minute
Available alert groups:
  Keyword                State  Description
  -----
  configuration           Enable configuration info
  diagnostic              Enable diagnostic info
  environment             Enable environmental info
  inventory               Enable inventory info
  syslog                 Enable  syslog info
Profiles:
  Profile Name: campus-noc
  Profile Name: CiscoTAC-1
```

Configured Call Home Information in Detail

```
Router# show call-home detail
Current call home settings:
  call home feature : disable
  call home message's from address: username@example.com
  call home message's reply-to address: username@example.com
  vrf for call-home messages: Mgmt-intf
  contact person's email address: username@example.com
  contact person's phone number: +14085551234
  street address: 1234 Any Street Any city Any state 12345
  customer ID: customer@example.com
  contract ID: 123456789
  site ID: example.com
  Mail-server[1]: Address: smtp.example.com Priority: 1
  Mail-server[2]: Address: 192.168.0.1 Priority: 2
  Rate-limit: 20 message(s) per minute
Available alert groups:
  Keyword                State  Description
```

```

-----
configuration          Enable  configuration info
diagnostic             Enable  diagnostic info
environment            Enable  environmental info
inventory              Enable  inventory info
syslog                 Enable  syslog info
Profiles:
Profile Name: campus-noc
Profile status: ACTIVE
Preferred Message Format: long-text
Message Size Limit: 3145728 Bytes
Transport Method: email
Email address(es): username@example.com
HTTP address(es): Not yet set up
Alert-group            Severity
-----
inventory              normal
Syslog-Pattern         Severity
-----
N/A                    N/A
Profile Name: CiscoTAC-1
Profile status: INACTIVE
Preferred Message Format: xml
Message Size Limit: 3145728 Bytes
Transport Method: email
Email address(es): callhome@cisco.com
HTTP address(es): https://tools.cisco.com/its/service/oddce/services/DDCEService
Periodic configuration info message is scheduled every 23 day of the month at 10:28
Periodic inventory info message is scheduled every 23 day of the month at 10:13
Alert-group            Severity
-----
diagnostic             minor
environment            minor
inventory              normal
Syslog-Pattern         Severity
-----
.*                     major

```

Available Call Home Alert Groups

```

Router# show call-home alert-group
Available alert groups:
Keyword                State  Description
-----
configuration          Enable  configuration info
crash                  Enable  crash and traceback info
environment            Enable  environmental info
inventory              Enable  inventory info
snapshot              Enable  snapshot info
syslog                 Enable  syslog info

```

E-Mail Server Status Information

```

Router# show call-home mail-server status
Please wait. Checking for mail server status ...
Translating "smtp.example.com"
Mail-server[1]: Address: smtp.example.com Priority: 1 [Not Available]
Mail-server[2]: Address: 192.168.0.1 Priority: 2 [Not Available]

```

Information About All Destination Profiles (Predefined and User-Defined)

```

Router# show call-home profile all
Profile Name: campus-noc

```

```

Profile status: ACTIVE
Preferred Message Format: long-text
Message Size Limit: 3145728 Bytes
Transport Method: email
Email address(es): username@example.com
HTTP address(es): Not yet set up
Alert-group          Severity
-----
inventory            normal
Syslog-Pattern       Severity
-----
N/A                  N/A
Profile Name: CiscoTAC-1
Profile status: INACTIVE
Preferred Message Format: xml
Message Size Limit: 3145728 Bytes
Transport Method: email
Email address(es): callhome@cisco.com
HTTP address(es): https://tools.cisco.com/its/service/oddce/services/DDCEService
Periodic configuration info message is scheduled every 23 day of the month at 12:13
Periodic inventory info message is scheduled every 23 day of the month at 11:58
Alert-group          Severity
-----
diagnostic           minor
environment           minor
inventory            normal
Syslog-Pattern       Severity
-----
.*                   major
Router#

```

Information About a User-Defined Destination Profile

```

Router# show call-home profile campus-noc
Profile Name: campus-noc
Profile status: ACTIVE
Preferred Message Format: long-text
Message Size Limit: 3145728 Bytes
Transport Method: email
Email address(es): username@example.com
HTTP address(es): Not yet set up
Alert-group          Severity
-----
inventory            normal
Syslog-Pattern       Severity
-----
N/A                  N/A

```

Call Home Statistics

```

Router# show call-home statistics
Message Types      Total      Email      HTTP
-----
Total Success     6          6          0
  Config          4          4          0
  Diagnostic       0          0          0
  Environment      0          0          0
  Inventory        2          2          0
  SysLog           0          0          0
  Test             0          0          0
  Request          0          0          0
  Send-CLI         0          0          0
Total In-Queue    0          0          0

```

```

Config      0          0          0
Diagnostic  0          0          0
Environment 0          0          0
Inventory   0          0          0
SysLog      0          0          0
Test        0          0          0
Request     0          0          0
Send-CLI    0          0          0
Total Failed 0          0          0
Config      0          0          0
Diagnostic  0          0          0
Environment 0          0          0
Inventory   0          0          0
SysLog      0          0          0
Test        0          0          0
Request     0          0          0
Send-CLI    0          0          0
Total Ratelimit
-dropped 0          0          0
Config      0          0          0
Diagnostic  0          0          0
Environment 0          0          0
Inventory   0          0          0
SysLog      0          0          0
Test        0          0          0
Request     0          0          0
Send-CLI    0          0          0
Last call-home message sent time: 2010-01-11 18:32:32 GMT+00:00

```

Default Settings

Lists of default Call Home settings.

Parameters	Default
Call Home feature status	Disabled
User-defined profile status	Active
Predefined Cisco TAC profile status	Inactive
Transport method	E-mail
Message format type	XML
Destination message size for a message sent in long text, short text, or XML format	3,145,728
Alert group status	Enabled
Call Home message severity threshold	0 (debugging)
Message rate limit for messages per minute	20
AAA Authorization	Disabled
Call Home syslog message throttling	Enabled
Data privacy level	Normal

Alert Group Trigger Events and Commands

Call Home trigger events are grouped into alert groups, with each alert group assigned CLI commands to execute when an event occurs. The CLI command output is included in the transmitted message. [Table 2: Call Home Alert Groups, Events, and Actions](#), on page 34 lists the trigger events included in each alert group, including the severity level of each event and the executed CLI commands for the alert group.

Table 2: Call Home Alert Groups, Events, and Actions

Alert Group	Call Home Trigger Event	Syslog Event	Severity	Description and CLI Commands Executed
Configuration	—	—	—	User-generated request for configuration. (Sent to TAC.) CLI commands executed: show platform show inventory show running-config all show startup-config show version
Crash	Reload System crash and device reload	—	7	Crash dump reporting allows crash information to be collected and send to Cisco backend when a system is reloaded due to reload. Note Kernal crash can't be processed. CLI commands executed: show version show logging show region show inventory show stack
Environmental	—	—	—	Events related to power, fan, and environment sensing elements, such as temperature alarms. (Sent to TAC.) CLI commands executed: show platform show environment show inventory show logging
—	—	%ENVIRONMENTAL-1-ALERT	1	Any sensor in fp/cc/rp has exceeded a certain threshold and resulted in this environmental alert.
—	ENVM	%ENVIRONMENTAL-1-SENSORFAIL	1	Any sensor in fp/cc/rp has failed and resulted in this environmental alert.
—	—	%ENVIRONMENTAL-1-SENSOROK	1	Any sensor in fp/cc/rp has recovered and resulted in this environmental alert.

Alert Group	Call Home Trigger Event	Syslog Event	Severity	Description and CLI Commands Executed
Inventory	—	—	—	Inventory status should be provided whenever a unit is cold-booted, or when FRUs are inserted or removed. This is considered a noncritical event, and the information is used for status and entitlement. (Sent to TAC.) CLI commands executed: show platform show inventory oid show version show diag all eeprom detail
Syslog	—	—	—	Event logged to syslog. CLI commands executed: show inventory show logging
—	SYSLOG	LOG_EMERG	0	System is unusable.
—	SYSLOG	LOG_ALERT	1	Action must be taken immediately.
—	SYSLOG	LOG_CRIT	2	Critical conditions.
—	SYSLOG	LOG_ERR	3	Error conditions.
—	SYSLOG	LOG_WARNING	4	Warning conditions.
—	SYSLOG	LOG_NOTICE	5	Normal but signification condition.
—	SYSLOG	LOG_INFO	6	Informational.
—	SYSLOG	LOG_DEBUG	7	Debug-level messages.
Test	—	TEST	—	User-generated test message. (Sent to TAC.) CLI commands executed: show platform show inventory show version

Message Contents

The following tables display the content formats of alert group messages:

- The **Format for a Short Text Message** table describes the content fields of a short text message.
- The **Common Fields for All Long Text and XML Messages** table describes the content fields that are common to all long text and XML messages. The fields specific to a particular alert group message are inserted at a point between the common fields. The insertion point is identified in the table.
- The **Inserted Fields for a Reactive or Proactive Event Message** table describes the inserted content fields for reactive messages (system failures that require a TAC case) and proactive messages (issues that might result in degraded system performance).
- The **Inserted Fields for an Inventory Event Message** table describes the inserted content fields for an inventory message.

This section also includes the following subsections that provide sample messages:

Table 3: Format for a Short Text Message

Data Item	Description
Device identification	Configured device name
Date/time stamp	Time stamp of the triggering event
Error isolation message	Plain English description of triggering event
Alarm urgency level	Error level such as that applied to a system message

Table 4: Common Fields for All Long Text and XML Messages

Data Item (Plain Text and XML)	Description (Plain Text and XML)	MML Tag (XML Only)
Time stamp	Date and time stamp of event in ISO time notation: <i>YYYY-MM-DD HH:MM:SS GMT+HH:MM.</i>	CallHome/EventTime
Message name	Name of message. Specific event names are listed in the Alert Group Trigger Events and Commands section.	For short text message only
Message type	Specifically “Call Home”.	CallHome/Event/Type
Message subtype	Specific type of message: full, delta, test	CallHome/Event/SubType
Message group	Specifically “reactive”. Optional, because default is “reactive”.	Not applicable. For long-text message only
Severity level	Severity level of message.	Body/Block/Severity
Source ID	Product type for routing through the workflow engine. This is typically the product family name.	For long-text message only

Data Item (Plain Text and XML)	Description (Plain Text and XML)	MML Tag (XML Only)
Device ID	<p>Unique device identifier (UDI) for end device generating message. This field should be empty if the message is nonspecific to a fabric switch. The format is <i>type@Sid@serial</i>.</p> <ul style="list-style-type: none"> • <i>type</i> is the product model number from backplane IDPROM. • @ is a separator character. • <i>Sid</i> is C, identifying the serial ID as a chassis serial number. • <i>serial</i> is the number identified by the Sid field. <p>Example: ASR1006@C@FOX105101DH</p>	CallHome/CustomerData/ ContractData/DeviceId
Customer ID	Optional user-configurable field used for contract information or other ID by any support service.	CallHome/CustomerData/ ContractData/CustomerId
Contract ID	Optional user-configurable field used for contract information or other ID by any support service.	CallHome/CustomerData/ ContractData/ContractId
Site ID	Optional user-configurable field used for site IDs supplied by Cisco Systems or other data meaningful to alternate support services.	CallHome/CustomerData/ ContractData/SiteId
Server ID	<p>If the message is generated from the fabric switch, this is the unique device identifier (UDI) of the switch.</p> <p>The format is <i>type@Sid@serial</i>.</p> <ul style="list-style-type: none"> • <i>type</i> is the product model number from backplane IDPROM. • @ is a separator character. • <i>Sid</i> is C, identifying the serial ID as a chassis serial number. • <i>serial</i> is the number identified by the Sid field. <p>Example: ASR1006@C@FOX105101DH</p>	For long text message only
Message description	Short text describing the error.	CallHome/MessageDescription

Data Item (Plain Text and XML)	Description (Plain Text and XML)	MML Tag (XML Only)
Device name	Node that experienced the event. This is the host name of the device.	CallHome/CustomerData/SystemInfo/NameName
Contact name	Name of person to contact for issues associated with the node experiencing the event.	CallHome/CustomerData/SystemInfo/Contact
Contact e-mail	E-mail address of person identified as contact for this unit.	CallHome/CustomerData/SystemInfo/ContactEmail
Contact phone number	Phone number of the person identified as the contact for this unit.	CallHome/CustomerData/SystemInfo/ContactHomeNumber
Street address	Optional field containing street address for RMA part shipments associated with this unit.	CallHome/CustomerData/SystemInfo/StreetAddress
Model name	Model name of the router. This is the “specific model as part of a product family name.	CallHome/DeviceCso_Chassis/Model
Serial number	Chassis serial number of the unit.	CallHome/DeviceCso_Chassis/SerialNumber
Chassis part number	Top assembly number of the chassis.	CallHome/DeviceCso_Chassis/AdditionalInfo/AD@name=“PartNumber”
System object ID	System Object ID that uniquely identifies the system.	CallHome/DeviceCso_Chassis/AdditionalInfo/AD@name=“sysObjectID”
System description	System description for the managed element.	CallHome/DeviceCso_Chassis/AdditionalInfo/AD@name=“sysDescr”

Data Item (Plain Text and XML)	Description (Plain Text and XML)	MML Tag (XML Only)	
Fields specific to a particular alert group message are inserted here.	The following fields may be repeated if multiple CLI commands are executed for this alert group.		
	Command output name	The exact name of the issued CLI command.	/aml/Attachments/Attachment/Name
	Attachment type	Attachment type. Usually "inline".	/aml/Attachments/Attachment@type
	MIME type	Normally "text" or "plain" or encoding type.	/aml/Attachments/Attachment/Data@encoding
	Command output text	Output of command automatically executed.	/mml/attachments/attachment/atdata

Table 5: Inserted Fields for a Reactive or Proactive Event Message

Data Item (Plain Text and XML)	Description (Plain Text and XML)	MML Tag (XML Only)
Chassis hardware version	Hardware version of chassis.	CallHome/Device/Cisco_Chassis/ HardwareVersion
Supervisor module software version	Top-level software version.	CallHome/Device/Cisco_Chassis/ AdditionalInformation/AD@name="SoftwareVersion"
Affected FRU name	Name of the affected FRU generating the event message.	CallHome/Device/Cisco_Chassis/ Cisco_Card/Model
Affected FRU serial number	Serial number of affected FRU.	CallHome/Device/Cisco_Chassis/ Cisco_Card/SerialNumber
Affected FRU part number	Part number of affected FRU.	CallHome/Device/Cisco_Chassis/ Cisco_Card/PartNumber
FRU slot	Slot number of FRU generating the event message.	CallHome/Device/Cisco_Chassis/ Cisco_Card/LocationWithinContainer
FRU hardware version	Hardware version of affected FRU.	CallHome/Device/Cisco_Chassis/ Cisco_Card/HardwareVersion
FRU software version	Software version(s) running on affected FRU.	CallHome/Device/Cisco_Chassis/ Cisco_Card/SoftwareIdentity/ VersionString

Table 6: Inserted Fields for an Inventory Event Message

Data Item (Plain Text and XML)	Description (Plain Text and XML)	MML Tag (XML Only)
Chassis hardware version	Hardware version of chassis.	CallHome/Device/Cisco_Chassis/ HardwareVersion
Supervisor module software version	Top-level software version.	CallHome/Device/Cisco_Chassis/ AdditionalInformation/AD@name= "SoftwareVersion"
FRU name	Name of the affected FRU generating the event message.	CallHome/Device/Cisco_Chassis/ Cisco_Card/Model
FRU s/n	Serial number of FRU.	CallHome/Device/Cisco_Chassis/ Cisco_Card/SerialNumber
FRU part number	Part number of FRU.	CallHome/Device/Cisco_Chassis/ Cisco_Card/PartNumber
FRU slot	Slot number of FRU.	CallHome/Device/Cisco_Chassis/ Cisco_Card/LocationWithinContainer
FRU hardware version	Hardware version of FRU.	CallHome/Device/Cisco_Chassis/ CiscoCard/HardwareVersion
FRU software version	Software version(s) running on FRU.	CallHome/Device/Cisco_Chassis/ Cisco_Card/SoftwareIdentity/ VersionString

Sample Syslog Alert Notification in Long Text Format

The following example shows a Syslog alert notification in long text format:

```

TimeStamp : 2014-07-09 09:17 GMT+00:00
Message Name : syslog
Message Type : Call Home
Message Group : reactive
Severity Level : 4
Source ID : ASR920
Device ID : ASR-920@CAT1740U01D
Customer ID :
Contract ID :
Site ID :
Server ID : ASR-920@CAT1740U01D
Event Description : *Jul 9 09:17:03.055: %LINK-3-UPDOWN: Interface GigabitEthernet0/0/11,
  changed state to up System Name : Router Contact Email : vmalshet@cisco.com Contact Phone
  :
Street Address :
Affected Chassis : ASR-920
Affected Chassis Serial Number : CAT1740U01D Affected Chassis Part No : 68-3992-01 Affected
  Chassis Hardware Version : 1.0 Supervisor Software Version : 15.5(20140708:133902) Command
  Output Name : show logging Attachment Type : command output MIME Type : text/plain Command
  Output Text : show logging Syslog logging: enabled (0 messages dropped, 1 messages
  rate-limited, 0 flushes, 0 overruns, xml disabled, filtering disabled)

No Active Message Discriminator.

No Inactive Message Discriminator.

```

```

Console logging: level debugging, 183 messages logged, xml disabled,
                  filtering disabled
Monitor logging: level debugging, 0 messages logged, xml disabled,
                  filtering disabled
Buffer logging:  level debugging, 48 messages logged, xml disabled,
                  filtering disabled
Exception Logging: size (4096 bytes)
Count and timestamp logging messages: disabled
Persistent logging: disabled
Trap logging: level informational, 114 message lines logged
Logging Source-Interface:      VRF Name:

```

Log Buffer (1000000 bytes):

```

*Jul  9 08:25:11.492: %SYS-5-LOG_CONFIG_CHANGE: Buffer logging: level debugging, xml disabled,
                  filtering disabled, size (1000000) *Jul  9 08:25:17.639: %SYS-5-CONFIG_I: Configured from
                  console by console *Jul  9 08:27:13.757: DEBUG - Found job name 9, to be triggered in 1049
                  secs, changing to 1 seconds *Jul  9 08:27:13.757: DEBUG - *Jul  9 08:27:14.758: DEBUG -
                  Invoking callback 0x3B9887B0 for job 9 *Jul  9 08:27:14.758: DEBUG - *Jul  9 08:27:14.957:
                  %SSH-5-DISABLED: SSH 1.99 has been disabled *Jul  9 08:27:21.719: %SSH-5-ENABLED: SSH 1.99
                  has been enabled *Jul  9 08:27:21.910: %PKI-4-NOCONFIGAUTOSAVE: Configuration was modified.
                  Issue "write memory" to save new IOS PKI configuration *Jul  9 08:27:21.910: DEBUG - Found
                  job name 9, to be triggered in 1 secs, changing to 1189 seconds *Jul  9 08:27:21.910: DEBUG
                  - *Jul  9 08:30:36.996: DEBUG - Found job name 9, to be triggered in 1189 secs, changing
                  to 1 seconds *Jul  9 08:30:36.997: DEBUG - *Jul  9 08:30:37.995: DEBUG - Invoking callback
                  0x3B9887B0 for job 9 *Jul  9 08:30:37.996: DEBUG - *Jul  9 08:30:38.198: %SSH-5-DISABLED:
                  SSH 1.99 has been disabled *Jul  9 08:30:41.734: %SSH-5-ENABLED: SSH 1.99 has been enabled
                  *Jul  9 08:30:41.935: %PKI-4-NOCONFIGAUTOSAVE: Configuration was modified. Issue "write
                  memory" to save new IOS PKI configuration *Jul  9 08:30:41.935: DEBUG - Found job name 9,
                  to be triggered in 1 secs, changing to 928 seconds *Jul  9 08:30:41.935: DEBUG - *Jul  9
                  08:46:09.936: DEBUG - Invoking callback 0x3B9887B0 for job 9 *Jul  9 08:46:09.936: DEBUG -
                  *Jul  9 08:46:10.136: %SSH-5-DISABLED: SSH 1.99 has been disabled *Jul  9 08:46:14.301:
                  %SSH-5-ENABLED: SSH 1.99 has been enabled *Jul  9 08:46:14.483: %PKI-4-NOCONFIGAUTOSAVE:
                  Configuration was modified. Issue "write memory" to save new IOS PKI configuration *Jul
                  9 08:46:14.483: DEBUG - Found job name 9, to be triggered in 928 secs, changing to 1033
                  seconds *Jul  9 08:46:14.483: DEBUG - *Jul  9 09:03:27.484: DEBUG - Invoking callback
                  0x3B9887B0 for job 9 *Jul  9 09:03:27.484: DEBUG - *Jul  9 09:03:27.688: %SSH-5-DISABLED:
                  SSH 1.99 has been disabled *Jul  9 09:03:33.000: %SSH-5-ENABLED: SSH 1.99 has been enabled
                  *Jul  9 09:03:33.190: %PKI-4-NOCONFIGAUTOSAVE: Configuration was modified. Issue "write
                  memory" to save new IOS PKI configuration *Jul  9 09:03:33.191: DEBUG - Found job name 9,
                  to be triggered in 1033 secs, changing to 1144 seconds *Jul  9 09:03:33.191: DEBUG - *Jul
                  9 09:07:03.174: DEBUG - Invoking callback 0x3B988508 for job 12 *Jul  9 09:07:03.174: DEBUG
                  - *Jul  9 09:07:03.174: %SMART_LIC-3-EVAL_EXPIRED_WARNING: Evaluation period expired on
                  Jan  1 00:00:00 1970 UTC where Jan  1 00:00:00 1970 UTC is the UTC date that it expired.
                  *Jul  9 09:07:03.174: DEBUG - Found job name 12, to be triggered in 3600 secs, changing to
                  3600 seconds *Jul  9 09:07:03.174: DEBUG - *Jul  9 09:10:32.325: SMART-LICENSE-TRACE:
                  call_home_smart_license_status_get[446], Get smart license status 1 *Jul  9 09:11:14.883:
                  %SYS-5-CONFIG_I: Configured from console by console *Jul  9 09:12:23.087: %SYS-5-CONFIG_I:
                  Configured from console by console *Jul  9 09:12:58.243: %SYS-5-CONFIG_I: Configured from
                  console by console *Jul  9 09:13:29.983: %LINK-5-CHANGED: Interface GigabitEthernet0/0/11,
                  changed state to administratively down *Jul  9 09:13:30.682: %LINEPROTO-5-UPDOWN: Line
                  protocol on Interface GigabitEthernet0/0/11, changed state to down *Jul  9 09:13:43.831:
                  %SYS-5-CONFIG_I: Configured from console by console *Jul  9 09:16:42.319: %SYS-5-CONFIG_I:
                  Configured from console by console *Jul  9 09:16:58.459: %LINK-3-UPDOWN: Interface
                  GigabitEthernet0/0/11, changed state to down Router# Command Output Name : show inventory
                  Attachment Type : command output MIME Type : text/plain Command Output Text : show inventory
                  NAME: "Chassis", DESCR: "Cisco ASR920 Series - 12GE and 2-10GE - AC model"
                  PID: ASR-920                , VID: V01, SN: CAT1740U01D

NAME: "IM subslot 0/0", DESCR: "12-port Gig & 2-port Ten Gig Dual Ethernet Interface Module"
PID: 12xGE-2x10GE-FIXED, VID: V00, SN: N/A

NAME: "subslot 0/0 transceiver 1", DESCR: "GE SX"

```

```

PID: GLC-SX-MMD          , VID: A  , SN: FNS17481N4J

NAME: "subslot 0/0 transceiver 2", DESCR: "GE SX"
PID: FTLF8519P2BCL-CS  , VID: 0000, SN: FNS11270EAW

NAME: "subslot 0/0 transceiver 3", DESCR: "GE ZX"
PID: GLC-ZX-SMD        , VID: M1  , SN: OPL14450280

NAME: "subslot 0/0 transceiver 4", DESCR: "GE SX"
PID: GLC-SX-MMD        , VID: A  , SN: FNS17220A5R

NAME: "subslot 0/0 transceiver 5", DESCR: "GE SX"
PID: QFBR-5766LP       , VID:      , SN: AGS09498EPL

NAME: "subslot 0/0 transceiver 6", DESCR: "GE SX"
PID: GLC-SX-MMD        , VID: A  , SN: FNS17472EX1

NAME: "subslot 0/0 transceiver 7", DESCR: "GE SX"
PID: GLC-SX-MMD        , VID: A  , SN: FNS17372HFX

NAME: "subslot 0/0 transceiver 9", DESCR: "GE SX"
PID: GLC-SX-MMD        , VID: A  , SN: FNS17481M3M

NAME: "subslot 0/0 transceiver 13", DESCR: "SFP+ 10GBASE-SR"
PID: SFP-10G-SR        , VID: G4.1, SN: AVD1744A0UW

NAME: "module R0", DESCR: "ASR 920 Route Switch Processor , Base Scale, 64Gbps "
PID: ASR-920-12CZ-A    , VID: V00, SN: CAT1740U01D

```

Sample Syslog Alert Notification in XML Format

The following example shows a Syslog alert notification in XML format:

```

<?xml version="1.0" encoding="UTF-8"?>
<soap-env:Envelope xmlns:soap-env="http://www.w3.org/2003/05/soap-envelope">
<soap-env:Header>
<aml-session:Session xmlns:aml-session="http://www.cisco.com/2004/01/aml-session"
soap-env:mustUnderstand="true"
soap-env:role="http://www.w3.org/2003/05/soap-envelope/role/next">
<aml-session:To>http://tools.cisco.com/neddce/services/DDCEService</aml-session:To>
<aml-session:Path>
<aml-session:Via>http://www.cisco.com/appliance/uri</aml-session:Via>
</aml-session:Path>
<aml-session:From>http://www.cisco.com/appliance/uri</aml-session:From>
<aml-session:MessageId>M2:CAT1740U01D:53BD07BB</aml-session:MessageId>
</aml-session:Session>
</soap-env:Header>
<soap-env:Body>
<aml-block:Block xmlns:aml-block="http://www.cisco.com/2004/01/aml-block">
<aml-block:Header>
<aml-block:Type>http://www.cisco.com/2005/05/callhome/syslog</aml-block:Type>
<aml-block:CreationDate>2014-07-09 09:13:31 GMT+00:00</aml-block:CreationDate>
<aml-block:Builder>
<aml-block:Name>ASR920</aml-block:Name>
<aml-block:Version>2.0</aml-block:Version>
</aml-block:Builder>
<aml-block:BlockGroup>
<aml-block:GroupId>G3:CAT1740U01D:53BD07BB</aml-block:GroupId>
<aml-block:Number>0</aml-block:Number>
<aml-block:IsLast>true</aml-block:IsLast>
<aml-block:IsPrimary>true</aml-block:IsPrimary>
<aml-block:WaitForPrimary>>false</aml-block:WaitForPrimary>
</aml-block:BlockGroup>

```

```

<aml-block:Severity>2</aml-block:Severity>
</aml-block:Header>
<aml-block:Content>
<ch:CallHome xmlns:ch="http://www.cisco.com/2005/05/callhome" version="1.0">
<ch:EventTime>2014-07-09 09:13:29 GMT+00:00</ch:EventTime> <ch:MessageDescription>*Jul 9
09:13:29.983: %LINK-5-CHANGED: Interface GigabitEthernet0/0/11, changed state to
administratively down</ch:MessageDescription> <ch:Event> <ch>Type>syslog</ch>Type>
<ch:SubType></ch:SubType> <ch:Brand>Cisco Systems</ch:Brand>
<ch:Series>ASR920 Series Router</ch:Series> </ch:Event> <ch:CustomerData> <ch:UserData>
<ch:Email>vmalshet@cisco.com</ch:Email>
</ch:UserData>
<ch:ContractData>
<ch:CustomerId></ch:CustomerId>
<ch:SiteId></ch:SiteId>
<ch:ContractId></ch:ContractId>
<ch:DeviceId>ASR-920@C@CAT1740U01D</ch:DeviceId>
</ch:ContractData>
<ch:SystemInfo>
<ch>Name>Router</ch>Name>
<ch>Contact></ch>Contact>
<ch:ContactEmail>vmalshet@cisco.com</ch:ContactEmail>
<ch:ContactPhoneNumber></ch:ContactPhoneNumber>
<ch:StreetAddress></ch:StreetAddress>
</ch:SystemInfo>
<ch:CCOID></ch:CCOID>
</ch:CustomerData>
<ch:Device>
<rme:Chassis xmlns:rme="http://www.cisco.com/rme/4.0">
<rme:Model>ASR-920</rme:Model>
<rme:HardwareVersion>1.0</rme:HardwareVersion>
<rme:SerialNumber>CAT1740U01D</rme:SerialNumber>
<rme:AdditionalInformation>
<rme:AD name="PartNumber" value="68-3992-01" /> <rme:AD name="SoftwareVersion"
value="15.5(20140708:133902)" /> <rme:AD name="SystemObjectId" value="1.3.6.1.4.1.9.1.2062"
/> <rme:AD name="SystemDescription" value="Cisco IOS Software, ASR920 Software
(PPC_LINUX_IOSD-UNIVERSALK9_NPE-M), Experimental Version 15.5(20140708:133902)
[mcp_dev-mrameshj-july4 114] Copyright (c) 1986-2014 by Cisco Systems, Inc.
Compiled Tue 08-Jul-14 23:52 by mrameshj" /> <rme:AD name="ServiceNumber" value="" /> <rme:AD
name="ForwardAddress" value="" /> </rme:AdditionalInformation> </rme:Chassis> </ch:Device>
</ch:CallHome> </aml-block:Content> <aml-block:Attachments> <aml-block:Attachment
type="inline"> <aml-block:Name>show logging</aml-block:Name> <aml-block:Data encoding="plain">
<![CDATA[show logging Syslog logging: enabled (0 messages dropped, 1 messages rate-limited,
0 flushes, 0 overruns, xml disabled, filtering disabled)

```

No Active Message Discriminator.

No Inactive Message Discriminator.

```

Console logging: level debugging, 178 messages logged, xml disabled,
filtering disabled
Monitor logging: level debugging, 0 messages logged, xml disabled,
filtering disabled
Buffer logging: level debugging, 43 messages logged, xml disabled,
filtering disabled
Exception Logging: size (4096 bytes)
Count and timestamp logging messages: disabled
Persistent logging: disabled
Trap logging: level informational, 109 message lines logged
Logging Source-Interface: VRF Name:

```

Log Buffer (1000000 bytes):

```
*Jul 9 08:25:11.492: %SYS-5-LOG_CONFIG_CHANGE: Buffer logging: level debugging, xml disabled,
```

```

filtering disabled, size (1000000) *Jul  9 08:25:17.639: %SYS-5-CONFIG_I: Configured from
console by console *Jul  9 08:27:13.757: DEBUG - Found job name 9, to be triggered in 1049
secs, changing to 1 seconds *Jul  9 08:27:13.757: DEBUG - *Jul  9 08:27:14.758: DEBUG -
Invoking callback 0x3B9887B0 for job 9 *Jul  9 08:27:14.758: DEBUG - *Jul  9 08:27:14.957:
%SSH-5-DISABLED: SSH 1.99 has been disabled *Jul  9 08:27:21.719: %SSH-5-ENABLED: SSH 1.99
has been enabled *Jul  9 08:27:21.910: %PKI-4-NOCONFIGAUTOSAVE: Configuration was modified.
Issue "write memory" to save new IOS PKI configuration *Jul  9 08:27:21.910: DEBUG - Found
job name 9, to be triggered in 1 secs, changing to 1189 seconds *Jul  9 08:27:21.910: DEBUG
- *Jul  9 08:30:36.996: DEBUG - Found job name 9, to be triggered in 1189 secs, changing
to 1 seconds *Jul  9 08:30:36.997: DEBUG - *Jul  9 08:30:37.995: DEBUG - Invoking callback
0x3B9887B0 for job 9 *Jul  9 08:30:37.996: DEBUG - *Jul  9 08:30:38.198: %SSH-5-DISABLED:
SSH 1.99 has been disabled *Jul  9 08:30:41.734: %SSH-5-ENABLED: SSH 1.99 has been enabled
*Jul  9 08:30:41.935: %PKI-4-NOCONFIGAUTOSAVE: Configuration was modified. Issue "write
memory" to save new IOS PKI configuration *Jul  9 08:30:41.935: DEBUG - Found job name 9,
to be triggered in 1 secs, changing to 928 seconds *Jul  9 08:30:41.935: DEBUG - *Jul  9
08:46:09.936: DEBUG - Invoking callback 0x3B9887B0 for job 9 *Jul  9 08:46:09.936: DEBUG -
*Jul  9 08:46:10.136: %SSH-5-DISABLED: SSH 1.99 has been disabled *Jul  9 08:46:14.301:
%SSH-5-ENABLED: SSH 1.99 has been enabled *Jul  9 08:46:14.483: %PKI-4-NOCONFIGAUTOSAVE:
Configuration was modified. Issue "write memory" to save new IOS PKI configuration *Jul
9 08:46:14.483: DEBUG - Found job name 9, to be triggered in 928 secs, changing to 1033
seconds *Jul  9 08:46:14.483: DEBUG - *Jul  9 09:03:27.484: DEBUG - Invoking callback
0x3B9887B0 for job 9 *Jul  9 09:03:27.484: DEBUG - *Jul  9 09:03:27.688: %SSH-5-DISABLED:
SSH 1.99 has been disabled *Jul  9 09:03:33.000: %SSH-5-ENABLED: SSH 1.99 has been enabled
*Jul  9 09:03:33.190: %PKI-4-NOCONFIGAUTOSAVE: Configuration was modified. Issue "write
memory" to save new IOS PKI configuration *Jul  9 09:03:33.191: DEBUG - Found job name 9,
to be triggered in 1033 secs, changing to 1144 seconds *Jul  9 09:03:33.191: DEBUG - *Jul
9 09:07:03.174: DEBUG - Invoking callback 0x3B988508 for job 12 *Jul  9 09:07:03.174: DEBUG
- *Jul  9 09:07:03.174: %SMART_LIC-3-EVAL_EXPIRED_WARNING: Evaluation period expired on
Jan 1 00:00:00 1970 UTC where Jan 1 00:00:00 1970 UTC is the UTC date that it expired.
*Jul  9 09:07:03.174: DEBUG - Found job name 12, to be triggered in 3600 secs, changing to
3600 seconds *Jul  9 09:07:03.174: DEBUG - *Jul  9 09:10:32.325: SMART-LICENSE-TRACE:
call_home_smart_license_status_get[446], Get smart license status 1 *Jul  9 09:11:14.883:
%SYS-5-CONFIG_I: Configured from console by console *Jul  9 09:12:23.087: %SYS-5-CONFIG_I:
Configured from console by console *Jul  9 09:12:58.243: %SYS-5-CONFIG_I: Configured from
console by console Router#]]</aml-block:Data> </aml-block:Attachment> <aml-block:Attachment
type="inline"> <aml-block:Name>show inventory</aml-block:Name> <aml-block:Data
encoding="plain"> <![CDATA[show inventory
NAME: "Chassis", DESCR: "Cisco ASR920 Series - 12GE and 2-10GE - AC model"
PID: ASR-920          , VID: V01, SN: CAT1740U01D

NAME: "IM subslot 0/0", DESCR: "12-port Gig & 2-port Ten Gig Dual Ethernet Interface Module"
PID: 12xGE-2x10GE-FIXED, VID: V00, SN: N/A

NAME: "subslot 0/0 transceiver 1", DESCR: "GE SX"
PID: GLC-SX-MMD          , VID: A  , SN: FNS17481N4J

NAME: "subslot 0/0 transceiver 2", DESCR: "GE SX"
PID: FTLF8519P2BCL-CS  , VID: 0000, SN: FNS11270EAW

NAME: "subslot 0/0 transceiver 3", DESCR: "GE ZX"
PID: GLC-ZX-SMD          , VID: M1  , SN: OPL14450280

NAME: "subslot 0/0 transceiver 4", DESCR: "GE SX"
PID: GLC-SX-MMD          , VID: A  , SN: FNS17220A5R

NAME: "subslot 0/0 transceiver 5", DESCR: "GE SX"
PID: QFBR-5766LP        , VID:      , SN: AGS09498EPL

NAME: "subslot 0/0 transceiver 6", DESCR: "GE SX"
PID: GLC-SX-MMD          , VID: A  , SN: FNS17472EX1

NAME: "subslot 0/0 transceiver 7", DESCR: "GE SX"
PID: GLC-SX-MMD          , VID: A  , SN: FNS17372HFX

```

```

NAME: "subslot 0/0 transceiver 9", DESCR: "GE SX"
PID: GLC-SX-MMD          , VID: A    , SN: FNS17481M3M

NAME: "subslot 0/0 transceiver 13", DESCR: "SFP+ 10GBASE-SR"
PID: SFP-10G-SR         , VID: G4.1, SN: AVD1744A0UW

NAME: "module R0", DESCR: "ASR 920 Route Switch Processor , Base Scale, 64Gbps "
PID: ASR-920-12CZ-A     , VID: V00, SN: CAT1740U01D

Router#]]></aml-block:Data>
</aml-block:Attachment>
</aml-block:Attachments>
</aml-block:Block>
</soap-env:Body>
</soap-env:Envelope>

```

Additional References

The following sections provide references related to the Call Home feature.

Related Documents

Related Topic	Title
Cisco IOS XE commands	Cisco IOS Master Commands List, All Releases
Explains how the Smart Call Home service offers web-based access to important information on select Cisco devices and offers higher network availability, and increased operational efficiency by providing real-time alerts.	Smart Call Home User Guide
Smart Call Home site page on Cisco.com for access to all related product information.	Cisco Smart Call Home site
Public Key Infrastructure (PKI) and Certificate Authority configuration in Cisco IOS XE software	Cisco IOS XE Security Configuration Guide: Secure Connectivity

Standards

Standard	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

MIBs

MIB	MIBs Link
CISCO-CALLHOME-MIB	To locate and download MIBs for selected platforms, Cisco IOS XE software releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

RFCs

RFC	Title
No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature.	—

Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	http://www.cisco.com/cisco/web/support/index.html

Feature Information for Call Home

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 7: Feature Information for Call Home

Feature Name	Releases	Feature Information
Call Home	Cisco IOS XE Release 3.13.0S	This feature was introduced on the Cisco ASR 920 Series Aggregation Services Router (ASR-920-12CZ-A, ASR-920-12CZ-D, ASR-920-4SZ-A, ASR-920-4SZ-D).