



Virtual Private Network Command Reference for Cisco CRS Series Routers, IOS XR Release 6.4.x

First Published: 2018-03-01

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Full Cisco Trademarks with Software License

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2018 Cisco Systems, Inc. All rights reserved.



CONTENTS

Full Cisco Trademarks with Software License ii

PREFACE

Preface ix

Changes to This Document ix

Communications, Services, and Additional Information ix

CHAPTER 1

Ethernet Interfaces Commands 1

encapsulation dot1ad dot1q 1

encapsulation dot1q 2

encapsulation dot1q second-dot1q 3

l2transport (Ethernet) 4

rewrite ingress tag 5

CHAPTER 2

Virtual Private Network Commands 9

authentication (L2TP) 10

backup disable (L2VPN) 12

clear l2tp counters control session 13

clear l2tp counters control tunnel 14

clear l2tp tunnel 15

clear l2vpn collaborators 16

clear l2vpn counters l2tp 17

clear l2vpn counters bridge mac-withdrawal 18

clear l2vpn forwarding counters 19

clear l2vpn forwarding mac-address-table 19

clear l2vpn forwarding message counters 21

clear l2vpn forwarding table 21

digest (L2TP)	22
hello-interval (L2TP)	24
hidden (L2TP)	25
hostname (L2TP)	26
interface (p2p)	27
l2tp-class	28
l2transport	29
l2transport l2protocol	31
l2transport propagate	32
l2transport service-policy	33
l2vpn	34
load-balancing flow-label	35
logging (l2vpn)	37
logging nsr	38
monitor-session (l2vpn)	39
mpls static label (L2VPN)	40
neighbor (L2VPN)	41
nsr (L2VPN)	42
password (L2TP)	43
pw-class (L2VPN)	44
pw-class encapsulation l2tpv3	45
pw-class encapsulation mpls	47
pw-ether	49
pw-grouping	50
p2p	51
receive-window (L2TP)	52
retransmit (L2TP)	53
rollover (L3VPN)	54
show generic-interface-list	55
show l2tp class	57
show l2tp counters forwarding session	58
show l2tp session	59
show l2tp tunnel	61
show l2vpn	63

show l2vpn atom-db	64
show l2vpn collaborators	66
show l2vpn database	67
show l2vpn forwarding	70
show l2vpn forwarding l2tp	77
show l2vpn generic-interface-list	78
show l2vpn index	79
show l2vpn nsr	81
show l2vpn provision queue	82
show l2vpn pw-class	83
show l2vpn pwhe	85
show l2vpn resource	86
show l2vpn trace	87
show l2vpn xconnect	88
show tunnel-template	98
storm-control	100
tag-impose	102
tag-rewrite	103
timeout setup (L2TP)	104
transport mode (L2VPN)	105
transport mode vlan passthrough	106
tunnel-template	107
xconnect group	108

CHAPTER 3 **Virtual Private LAN Services Commands** **111**

action (VPLS)	112
aging (VPLS)	113
bridge-domain (VPLS)	114
bridge group (VPLS)	115
clear l2vpn bridge-domain (VPLS)	116
flooding disable	117
interface (VPLS)	118
learning disable (VPLS)	120
limit (VPLS)	121

- mac (VPLS) 122
- maximum (VPLS) 123
- mpls static label (VPLS) 125
- mtu (VPLS) 126
- neighbor (VPLS) 127
- notification (VPLS) 129
- port-down flush disable (VPLS) 130
- pw-class (VFI) 132
- show l2vpn bridge-domain (VPLS) 133
- show l2vpn forwarding bridge-domain (VPLS) 141
- show l2vpn forwarding bridge-domain mac-address (VPLS) 156
- shutdown (Bridge Domain) 167
- shutdown (VFI) 168
- static-address (VPLS) 169
- static-mac-address (VPLS) 170
- time (VPLS) 172
- type (VPLS) 173
- vfi (VPLS) 174
- withdraw (VPLS) 175

CHAPTER 4

Generic Routing Encapsulation Commands 177

- interface tunnel-ip 177
- keepalive 178
- tunnel destination 179
- tunnel dfbit 180
- tunnel mode 181
- tunnel source 182
- tunnel tos 183
- tunnel ttl 184



Preface

The preface contains these sections:

- [Changes to This Document, on page ix](#)
- [Communications, Services, and Additional Information, on page ix](#)

Changes to This Document



Note *This software release has reached end-of-life status. For more information, see the [End-of-Life and End-of-Sale Notices](#).*

The following table lists the technical changes made to this document since it was first published.

Date	Change Summary
March 2018	Initial release of this document.

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



CHAPTER 1

Ethernet Interfaces Commands

This module describes the Cisco IOS XR software commands used to configure the Ethernet interfaces on the Cisco CRS Router.



Note This module does not include the commands for Management Ethernet interfaces and Ethernet OAM. To configure a Management Ethernet interface for routing or modify the configuration of a Management Ethernet interface or to configure Ethernet OAM, use the commands described in the *Interface and Hardware Component Configuration Guide for Cisco CRS Routers*

Refer to the *Interface and Hardware Component Command Reference for Cisco CRS Routers* for more information on the Ethernet Interfaces and Ethernet OAM commands.

- [encapsulation dot1ad dot1q](#), on page 1
- [encapsulation dot1q](#), on page 2
- [encapsulation dot1q second-dot1q](#), on page 3
- [l2transport \(Ethernet\)](#), on page 4
- [rewrite ingress tag](#), on page 5

encapsulation dot1ad dot1q

To define the matching criteria to be used in order to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance, use the **encapsulation dot1ad dot1q** command in subinterface configuration mode. To delete the matching criteria to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance, use the **no** form of this command.

```
encapsulation dot1ad vlan-id dot1q {vlan-id | any}
no encapsulation dot1ad vlan-id dot1q {vlan-id | any}
```

Syntax Description

dot1ad Indicates that the IEEE 802.1ad provider bridges encapsulation type is used for the outer tag.

dot1q Indicates that the IEEE 802.1q standard encapsulation type is used for the inner tag.

vlan-id VLAN ID, integer in the range 1 to 4094.

any Matches any VLAN ID.

Command Default No matching criteria are defined.

Command Modes Subinterface configuration

Command History	Release	Modification
	Release 5.1.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The outer VLAN tag is an 802.1ad VLAN tag, instead of an 802.1Q tag. An 802.1ad tag has an ethertype value of 0x88A8, instead of 0x8100 that 802.1Q uses.

Some of the fields in the 802.1ad VLAN header are interpreted differently per 802.1ad standard. A **tunneling ethertype** command applied to the main interface does not apply to an 802.1ad subinterface.

An interface with encapsulation dot1ad causes the router to categorize the interface as an 802.1ad interface. This causes special processing for certain protocols and other features:

- MSTP uses the IEEE 802.1ad MAC STP address instead of the STP MAC address.
- Certain QoS functions may use the Drop Eligibility (DE) bit of the IEEE 802.1ad tag.

Examples

The following example shows how to map single-tagged 802.1ad ingress frames to a service instance:

```
RP/0/RP0/CPU0:router (config-subif) # encapsulation dot1ad 100 dot1q 20
```

Related Commands	Command	Description
	encapsulation dot1q, on page 2	Defines the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance.

encapsulation dot1q

To define the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance, use the **encapsulation dot1q** command in the subinterface configuration mode. To delete the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance, use the **no** form of this command.

```
encapsulation dot1q vlan-id
no encapsulation
```

Syntax Description **vlan-id** VLAN ID, integer in the range 1 to 4094.

Command Default No matching criteria are defined.

Command Modes Subinterface configuration

Command History	Release	Modification
	Release 5.1.1	This command was introduced.

Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Only one encapsulation statement can be applied to a subinterface. Encapsulation statements cannot be applied to main interfaces.</p> <p>A single encapsulation dot1q statement specifies matching for frames with a single VLAN ID.</p>
------------------	--

Examples	<p>The following example shows how to map 802.1Q frames ingress on an l2transport subinterface:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/1/0/3.10 l2transport RP/0/RP0/CPU0:router(config-subif)# encapsulation dot1q 10</pre>
----------	--

Related Commands	Command	Description
	encapsulation dot1ad dot1q, on page 1	Defines the matching criteria to be used in order to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance.
	encapsulation dot1q second-dot1q, on page 3	Defines the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance.

encapsulation dot1q second-dot1q

To define the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance, use the **encapsulation dot1q second-dot1q** command in the subinterface configuration mode. To delete the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance, use the **no** form of this command.

```
encapsulation dot1q {any | vlan-id} second-dot1q {any | vlan-id }
no encapsulation dot1q {any | vlan-id} second-dot1q {any | vlan-id }
```

Syntax Description	<p><i>vlan-id</i></p> <p>VLAN ID, integer in the range 1 to 4094.</p> <p>A maximum of nine ranges or individual values may be specified. The values must not overlap.</p>
	<p>second-dot1q</p> <p>(Optional) Specifies IEEE 802.1Q VLAN tagged packets.</p>
	<p>any</p> <p>Any second tag in the range 1 to 4094.</p>

Command Default	No matching criteria are defined.
-----------------	-----------------------------------

Command Modes Subinterface configuration

Command History	Release	Modification
	Release 5.1.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The criteria for this command are: the outer tag must be unique and the inner tag may be a single VLAN.

QinQ service instance, allows single, multiple or range on second-dot1q.

Only one encapsulation command must be configured per service instance.

Examples

The following example shows how to map ingress frames to a service instance:

```
RP/0/RP0/CPU0:router(config-subif)# encapsulation dot1q second-dot1q 20
```

Related Commands	Command	Description
	encapsulation dot1ad dot1q, on page 1	Defines the matching criteria to be used in order to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance.
	encapsulation dot1q, on page 2	Defines the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance.

I2transport (Ethernet)

To enable Layer 2 transport port mode on an Ethernet interface and enter Layer 2 transport configuration mode, use the **I2transport** command in interface or subinterface configuration mode for an Ethernet interface. To disable Layer 2 transport port mode on an Ethernet interface, use the **no** form of this command.

I2transport
no I2transport

This command has no keywords or arguments.

Command Default None

Command Modes Interface or Subinterface configuration

Command History	Release	Modification
	Release 5.1.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Task Operations
l2vpn	read, write

Examples

The following example shows how to use the l2transport command on an Ethernet subinterface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/1/0/3.10 l2transport
RP/0/RP0/CPU0:router(config-subif)# encapsulation dot1q 10
```

Related Commands

Command	Description
show interfaces	Displays statistics for all interfaces configured on the router or for a specific node.
show l2vpn xconnect	Displays brief information on configured xconnects.

rewrite ingress tag

To specify the encapsulation adjustment that is to be performed on the frame ingress to the service instance, use the **rewrite ingress tag** command in the subinterface configuration mode. To delete the encapsulation adjustment that is to be performed on the frame ingress to the service instance, use the **no** form of this command.

```
rewrite ingress tag {push {dot1q vlan-id | dot1q vlan-id second-dot1q vlan-id | dot1ad vlan-id
dot1q vlan-id} | pop {1 | 2} | translate {1to1 {dot1q vlan-id | dot1ad vlan-id} | 2-to-1 dot1q vlan-id
| dot1ad vlan-id} | 1-to-2 {dot1q vlan-id second-dot1q vlan-id | dot1ad vlan-id dot1q vlan-id} | 2-to-2
{dot1q vlan-id second-dot1q vlan-id | dot1ad vlan-id dot1q vlan-id}} [symmetric]
no rewrite tag [symmetric]
```

Syntax Description

<i>vlan-id</i>	VLAN ID, integer in the range 1 to 4094.
push dot1q <i>vlan-id</i>	Pushes one 802.1Q tag with <i>vlan-id</i> .
push dot1q <i>vlan-id</i> second-dot1q <i>vlan-id</i>	Pushes a pair of 802.1Q tags in the order first, second.
pop {1 2}	One or two tags are removed from the packet. This command can be combined with a push (pop N and subsequent push <i>vlan-id</i>).
translate 1-to-1 dot1q <i>vlan-id</i>	Replaces the incoming tag (defined in the encapsulation command) into a different 802.1Q tag at the ingress service instance.

translate 2-to-1 dot1q <i>vlan-id</i>	Replaces a pair of tags defined in the encapsulation command by <i>vlan-id</i> .
translate 1-to-2 dot1q <i>vlan-id</i> second-dot1q <i>vlan-id</i>	Replaces the incoming tag defined by the encapsulation command by a pair of 802.1Q tags.
translate 2-to-2 dot1q <i>vlan-id</i> second-dot1q <i>vlan-id</i>	Replaces the pair of tags defined by the encapsulation command by a pair of VLANs defined by this rewrite.
symmetric	(Optional) A rewrite operation is applied on both ingress and egress. The operation on egress is the inverse operation as ingress.

Command Default The frame is left intact on ingress.

Command Modes Subinterface configuration

Command History	Release	Modification
	Release 5.1.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **symmetric** keyword is accepted only when a single VLAN is configured in encapsulation. If a list of VLANs or a range VLAN is configured in encapsulation, the **symmetric** keyword is accepted only for push rewrite operations; all other rewrite operations are rejected.

The **pop** command assumes the elements being popped are defined by the encapsulation type. The exception case should be drop the packet.

The **rewrite ingress tag translate** command assume the tags being translated from are defined by the encapsulation type. In the 2-to-1 option, the “2” means “2 tags of a type defined by the **encapsulation** command. The translation operation requires at least “from” tag in the original packet. If the original packet contains more tags than the ones defined in the “from”, then the operation should be done beginning on the outer tag. Exception cases should be dropped.

Examples The following example shows how to specify the encapsulation adjustment that is to be performed on the frame ingress to the service instance:

```
RP/0/RP0/CPU0:router (config-subif) # rewrite ingress push dot1q 200
```

Related Commands	Command	Description
	encapsulation dot1ad dot1q, on page 1	Defines the matching criteria to be used in order to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance.
	encapsulation dot1q, on page 2	Defines the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance.

Command	Description
encapsulation dot1q second-dot1q , on page 3	Defines the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance.

rewrite ingress tag



CHAPTER 2

Virtual Private Network Commands

For detailed information about virtual private network concepts, configuration tasks, and examples, refer to the *Virtual Private Network Configuration Guide for Cisco CRS Routers*

- authentication (L2TP), on page 10
- backup disable (L2VPN), on page 12
- clear l2tp counters control session, on page 13
- clear l2tp counters control tunnel, on page 14
- clear l2tp tunnel, on page 15
- clear l2vpn collaborators, on page 16
- clear l2vpn counters l2tp, on page 17
- clear l2vpn counters bridge mac-withdrawal, on page 18
- clear l2vpn forwarding counters, on page 19
- clear l2vpn forwarding mac-address-table, on page 19
- clear l2vpn forwarding message counters, on page 21
- clear l2vpn forwarding table, on page 21
- digest (L2TP), on page 22
- hello-interval (L2TP), on page 24
- hidden (L2TP), on page 25
- hostname (L2TP), on page 26
- interface (p2p), on page 27
- l2tp-class, on page 28
- l2transport, on page 29
- l2transport l2protocol, on page 31
- l2transport propagate, on page 32
- l2transport service-policy, on page 33
- l2vpn, on page 34
- load-balancing flow-label, on page 35
- logging (l2vpn), on page 37
- logging nsr, on page 38
- monitor-session (l2vpn), on page 39
- mpls static label (L2VPN), on page 40
- neighbor (L2VPN), on page 41
- nsr (L2VPN), on page 42
- password (L2TP), on page 43

- pw-class (L2VPN), on page 44
- pw-class encapsulation l2tpv3, on page 45
- pw-class encapsulation mpls, on page 47
- pw-ether, on page 49
- pw-grouping, on page 50
- p2p, on page 51
- receive-window (L2TP), on page 52
- retransmit (L2TP), on page 53
- rollover (L3VPN), on page 54
- show generic-interface-list , on page 55
- show l2tp class, on page 57
- show l2tp counters forwarding session, on page 58
- show l2tp session, on page 59
- show l2tp tunnel, on page 61
- show l2vpn, on page 63
- show l2vpn atom-db, on page 64
- show l2vpn collaborators, on page 66
- show l2vpn database, on page 67
- show l2vpn forwarding, on page 70
- show l2vpn forwarding l2tp, on page 77
- show l2vpn generic-interface-list, on page 78
- show l2vpn index, on page 79
- show l2vpn nsr , on page 81
- show l2vpn provision queue, on page 82
- show l2vpn pw-class, on page 83
- show l2vpn pwhe, on page 85
- show l2vpn resource, on page 86
- show l2vpn trace, on page 87
- show l2vpn xconnect, on page 88
- show tunnel-template, on page 98
- storm-control , on page 100
- tag-impose, on page 102
- tag-rewrite, on page 103
- timeout setup (L2TP), on page 104
- transport mode (L2VPN), on page 105
- transport mode vlan passthrough, on page 106
- tunnel-template, on page 107
- xconnect group, on page 108

authentication (L2TP)

To enable L2TP authentication for a specified L2TP class name, use the **authentication** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

authentication
no authentication

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes L2TP class configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note You can also enable L2TP authentication for a specified class name from L2TP class configuration submode. To enter this submode, enter the **l2tp-class** command followed by the class name.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure L2TP authentication for the specified L2TP class name “cisco”:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# authentication
```

Related Commands	Command	Description
	hello-interval (L2TP), on page 24	Configures the hello-interval value for L2TP (duration between control channel hello packets).
	hidden (L2TP), on page 25	Enables hidden attribute-value pairs (AVPs).
	hostname (L2TP), on page 26	Defines the name used in the L2TP hostname AVP.
	l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
	password (L2TP), on page 43	Defines the password and password encryption type for control channel authentication.
	receive-window (L2TP), on page 52	Configures the receive window size for the L2TP server.
	retransmit (L2TP), on page 53	Configures retransmit retry and timeout values.

backup disable (L2VPN)

To specify how long a backup pseudowire should wait before resuming primary pseudowire operation after the failure with primary pseudowire has been cleared, use the **backup disable** command in L2VPN pseudowire class configuration mode. To disable this feature, use the **no** form of this command.

```
backup disable {delay value | never}
no backup disable {delay value | never}
```

Syntax Description	<p>delay value Specifies the number of seconds that elapse after the failure with primary pseudowire has been cleared before the Cisco IOS XR software attempts to activate the primary pseudowire.</p> <p>The range, in seconds, is from 0 to 180. The default is 0.</p> <p>never Specifies that the secondary pseudowire does not fall back to the primary pseudowire if the primary pseudowire becomes available again, unless the secondary pseudowire fails.</p>						
Command Default	The default disable delay is the value of 0, which means that the primary pseudowire is activated immediately when it comes back up.						
Command Modes	L2VPN pseudowire class configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.8.0</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 5.2.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.8.0	This command was introduced.	Release 5.2.1	This command was introduced.
Release	Modification						
Release 3.8.0	This command was introduced.						
Release 5.2.1	This command was introduced.						
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write		
Task ID	Operations						
l2vpn	read, write						

Examples

The following example shows how a backup delay is configured for point-to-point pseudowire in which the backup disable delay is set to 50 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class class1
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# backup disable delay 50
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# exit
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group A
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p rtrx
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.1 pw-id 2
```

```
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# pw-class class1
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# backup neighbor 10.2.2.2 pw-id 5
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)#
```

Related Commands	Command	Description
	l2vpn, on page 34	Enters L2VPN configuration mode.
	neighbor (L2VPN), on page 41	Configures a pseudowire for a cross-connect.
	p2p, on page 51	Enters p2p configuration submode to configure point-to-point cross-connects.
	pw-class (L2VPN), on page 44	Enters pseudowire class submode to define a pseudowire class template.
	xconnect group, on page 108	Configures cross-connect groups.

clear l2tp counters control session

To clear L2TP control counters for a session, use the **clear l2tp counters control session** command in EXEC mode.

```
clear l2tp counters control session fsm [{event | state transition}]
```

Syntax Description	Parameter	Description
	fsm	(Optional) Clears finite state machine counters.
	event	(Optional) Clears state machine event counters.
	state	(Optional) Clears state machine state counters.
	transition	(Optional) Clears state machine transition counters.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.0	This command was introduced.
	Release 5.2.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to clear all L2TP state machine transition counters:

```
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)## clear l2tp counters control session fsm state transition
```

Related Commands	Command	Description
	clear l2tp counters control tunnel, on page 14	Clears L2TP control counters for a tunnel.
	clear l2vpn counters l2tp, on page 17	Clears L2VPN statistical information, such as, packets dropped.

clear l2tp counters control tunnel

To clear L2TP control counters for a tunnel, use the **clear l2tp counters control tunnel** command in EXEC mode.

```
clear l2tp counters control tunnel {all | authentication | id tunnel id}
```

Syntax Description		
	all	Clears all L2TP counters, except authentication counters
	authentication	Clears tunnel authentication counters.
	id tunnel id	Clears a specified counter. Range is 1 to 4294967295.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to clear all L2TP control tunnel counters:

```
RP/0/RP0/CPU0:router# clear l2tp counters control tunnel all
```

Related Commands	Command	Description
	clear l2tp counters control session, on page 13	Clears L2TP control counters for a session.
	clear l2vpn counters l2tp, on page 17	Clears L2VPN statistical information, such as, packets dropped.

clear l2tp tunnel

To clear L2TP tunnels, use the **clear l2tp tunnel** command in EXEC mode.

```
clear l2tp tunnel {all | id tunnel id | l2tp-class class name | local ipv4 ipv4 address | remote ipv4 ipv4 address}
```

Syntax Description		
	all	Clears all L2TP tunnels.
	id <i>tunnel id</i>	Clears a specified tunnel.
	l2tp-class <i>class name</i>	Clears all L2TP tunnels based on L2TP class name.
	local ipv4 <i>ipv4 address</i>	Clears all local tunnels based on the specified local IPv4 address.
	remote ipv4 <i>ipv4 address</i>	Clears all remote tunnels based on the specified local IPv4 address.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to clear all L2TP tunnels:

```
RP/0/RP0/CPU0:router# clear l2tp tunnel all
```

Related Commands

Command	Description
clear l2tp counters control session, on page 13	Clears L2TP control counters for a session.
clear l2tp counters control tunnel, on page 14	Clears L2TP control counters for a tunnel.

clear l2vpn collaborators

To clear the state change counters for L2VPN collaborators, use the **clear l2vpn collaborators** command in EXEC mode.

clear l2vpn collaborators

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to clear change counters for L2VPN collaborators:

```
RP/0/RP0/CPU0:router# clear l2vpn collaborators
```

Related Commands	Command	Description
	show l2vpn collaborators, on page 66	Displays information about the state of the interprocess communications connections between l2vpn_mgr and other processes.

clear l2vpn counters l2tp

To clear L2VPN statistical information, such as, packets dropped, use the **clear l2vpn counters l2tp** command in EXEC mode.

```
clear l2vpn counters l2tp [neighbor ip-address [pw-id value]]
```

Syntax Description	l2tp	Clears all L2TP counters.
	neighbor <i>ip-address</i>	(Optional) Clears all L2TP counters for the specified neighbor.
	pw-id <i>value</i>	(Optional) Configures the pseudowire ID. The range is from 1 to 4294967295.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to clear all L2TP counters:

clear l2vpn counters bridge mac-withdrawal

```
RP/0/RP0/CPU0:router# clear l2vpn counters l2tp
```

Related Commands	Command	Description
	show l2vpn collaborators, on page 66	Displays information about the state of the interprocess communications connections between l2vpn_mgr and other processes.

clear l2vpn counters bridge mac-withdrawal

To clear the MAC withdrawal statistics for the counters of the bridge domain, use the **clear l2vpn counters bridge mac-withdrawal** command in EXEC mode.

clear l2vpn counters bridge mac-withdrawal {**all** | **group** *group-name* **bd-name** *bd-name* | **neighbor** *ip-address* **pw-id** *value*}

Syntax Description		
	all	Clears the MAC withdrawal statistics over all the bridges.
	group <i>group-name</i>	Clears the MAC withdrawal statistics over the specified group.
	bd-name <i>bd-name</i>	Clears the MAC withdrawal statistics over the specified bridge.
	neighbor <i>ip-address</i>	Clears the MAC withdrawal statistics over the specified neighbor.
	pw-id <i>value</i>	Clears the MAC withdrawal statistics over the specified pseudowire. The range is from 1 to 4294967295.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to clear the MAC withdrawal statistics over all the bridges:

```
RP/0/RP0/CPU0:router# clear l2vpn counters bridge mac-withdrawal all
```

clear l2vpn forwarding counters

To clear L2VPN forwarding counters, use the **clear l2vpn forwarding counters** command in EXEC mode.

clear l2vpn forwarding counters

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to clear L2VPN forwarding counters:

```
RP/0/RP0/CPU0:router# clear l2vpn forwarding counters
```

Related Commands	Command	Description
	show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.

clear l2vpn forwarding mac-address-table

To clear L2VPN forwarding MAC address tables, use the **clear l2vpn forwarding mac-address-table** command in EXEC mode.

clear l2vpn forwarding mac-address-table

clear l2vpn forwarding mac-address-table {**address** *address* | **bridge-domain** *name* | **interface** *type interface-path-id* | **location** *node-id*}

Syntax Description		
<i>address</i>		Clears a specified MAC address.
bridge-domain <i>name</i>		Clears bridge domains learned from a MAC address table.
<i>type</i>		(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>		Physical interface or a virtual interface.
	Note	Use the show interfaces command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.
location <i>node-id</i>		Clears L2VPN forwarding message counters for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write, execute

Examples The following example shows how to clear L2VPN forwarding MAC address tables on a specified node:

```
RP/0/RP0/CPU0:router# clear l2vpn forwarding mac-address location 1/1/1
```

Related Commands	Command	Description
	show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.

clear l2vpn forwarding message counters

To clear L2VPN forwarding message counters, use the **clear l2vpn forwarding message counters** command in EXEC mode.

```
clear l2vpn forwarding message counters location node-id
```

Syntax Description	location <i>node-id</i>	Clears L2VPN forwarding message counters for the specified location.	
Command Default	None		
Command Modes	EXEC		
Command History	Release	Modification	
	Release 3.5.0	This command was introduced.	
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.		
Task ID	Task ID	Operations	
	l2vpn	read, write	
Examples	The following example shows how to clear L2VPN forwarding message counters on a specified node: RP/0/RP0/CPU0:router# clear l2vpn forwarding message counters location 0/6/CPU0		
Related Commands	Command	Description	
	show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.	

clear l2vpn forwarding table

To clear an L2VPN forwarding table at a specified location, use the **clear l2vpn forwarding table** command in EXEC mode.

```
clear l2vpn forwarding table location node-id
```

digest (L2TP)

Syntax Description	location <i>node-id</i>	Clears L2VPN forwarding tables for the specified location.
---------------------------	-----------------------------------	--

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to clear an L2VPN forwarding table from a specified location:

```
RP/0/RP0/CPU0:router# clear l2vpn forwarding table location 1/2/3/5
```

Related Commands	Command	Description
	show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.

digest (L2TP)

To configure digest options, use the **digest** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

```
digest {check disable | hash {MD5 | SHA1} | secret {0 | 7word}}
no digest {check disable | hash {MD5 | SHA1} | secret {0 | 7word}}
```

Syntax Description		
	check disable	Disables digest checking.
	hash { MD5 SHA1 }	Configures the digest hash method (MD5 or SHA1). Default is MD5.
	secret { 0 7 <i>word</i> }	Configures a shared secret for message digest.

Command Default **check disable**: Digest checking is enabled by default.

hash: Default is MD5 if the **digest** command is issued without the secret keyword option and L2TPv3 integrity checking is enabled.

Command Modes L2TP class configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The digest secret and hash algorithm can be configured in the l2tp-class configuration for authentication of the control channel. For control channel authentication to work correctly, however, both sides of the L2TP control channel connection must share a common secret and hash algorithm.

To update of digest secret without network disruption, Cisco supports a maximum to two digest secrets. You can configure a new secret while keeping the old secret valid. You can safely remove the old secret after you update all affected peer nodes with a new secret,

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to configure digest options for L2TP:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# digest check disable
RP/0/RP0/CPU0:router(config-l2tp-class)# digest secret cisco hash md5
```

Related Commands	Command	Description
	authentication (L2TP), on page 10	Enables L2TP authentication for a specified L2TP class name.
	hello-interval (L2TP), on page 24	Configures the hello-interval value for L2TP (duration between control channel hello packets).
	hidden (L2TP), on page 25	Enables hidden attribute-value pairs (AVPs).
	hostname (L2TP), on page 26	Defines the name used in the L2TP hostname AVP.
	l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
	password (L2TP), on page 43	Defines the password and password encryption type for control channel authentication.
	receive-window (L2TP), on page 52	Configures the receive window size for the L2TP server.

Command	Description
retransmit (L2TP), on page 53	Configures retransmit retry and timeout values.

hello-interval (L2TP)

To configure the hello-interval value for L2TP (duration between control channel hello packets), use the **hello-interval (L2TP)** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

hello-interval *interval*
no hello-interval *interval*

Syntax Description	
	<i>interval</i> Interval (in seconds) between control channel hello packets. The range is from 0 to 1000. Default is 60 seconds.

Command Default	
	<i>interval</i> : 60 seconds

Command Modes	
	L2TP class configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines	
	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure the hello-interval value for L2TP to 22 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# hello-interval 22
```

Related Commands	Command	Description
	authentication (L2TP), on page 10	Enables L2TP authentication for a specified L2TP class name.
	hidden (L2TP), on page 25	Enables hidden attribute-value pairs (AVPs).
	hostname (L2TP), on page 26	Defines the name used in the L2TP hostname AVP.

Command	Description
l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 43	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 52	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 53	Configures retransmit retry and timeout values.

hidden (L2TP)

To enable hidden attribute-value pairs (AVPs), use the **hidden** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

hidden
no hidden

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes L2TP class configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to enable hidden AVPs:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# hidden
```

Related Commands	Command	Description
	authentication (L2TP), on page 10	Enables L2TP authentication for a specified L2TP class name.

Command	Description
hello-interval (L2TP), on page 24	Configures the hello-interval value for L2TP (duration between control channel hello packets).
hostname (L2TP), on page 26	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 43	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 52	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 53	Configures retransmit retry and timeout values.

hostname (L2TP)

To define the name used in the L2TP hostname AVP, use the **hostname** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

hostname *name*
no hostname *name*

Syntax Description	
	<i>name</i> Hostname used to identify the router during L2TP control channel authentication.

Command Default	
	None

Command Modes	
	L2TP class configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines	
	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure a hostname using the word “cisco”:

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# hostname cisco
```

Related Commands	Command	Description
	authentication (L2TP), on page 10	Enables L2TP authentication for a specified L2TP class name.
	hello-interval (L2TP), on page 24	Configures the hello-interval value for L2TP (duration between control channel hello packets).
	hidden (L2TP), on page 25	Enables hidden attribute-value pairs (AVPs).
	l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
	password (L2TP), on page 43	Defines the password and password encryption type for control channel authentication.
	receive-window (L2TP), on page 52	Configures the receive window size for the L2TP server.
	retransmit (L2TP), on page 53	Configures retransmit retry and timeout values.

interface (p2p)

To configure an attachment circuit, use the **interface** command in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

```
interface type interface-path-id [PW-Ether | PW-IW]
no interface type interface-path-id [PW-Ether | PW-IW]
```

Syntax Description	
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface.
Note	Use the show interfaces command to see a list of all possible interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark (?) online help function.
PW-Ether	(Optional) Configures an Ethernet Interface.
PW-IW	(Optional) Configures an IP Interworking Interface.

Command Default None

Command Modes p2p configuration submode

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Release	Modification
Release 4.2.1	The following keywords were added: <ul style="list-style-type: none"> • PW-Ether • PW-IW

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure an attachment circuit on a TenGigE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# xconnect group gr1
RP/0/RP0/CPU0:router (config-l2vpn-xc)# p2p p001
RP/0/RP0/CPU0:router (config-l2vpn-xc-p2p)# interface TenGigE 1/1/1/1
```

Related Commands	Command	Description
	p2p, on page 51	Enters p2p configuration submode to configure point-to-point cross-connects.

l2tp-class

To enter L2TP class configuration mode where you can define an L2TP signaling template, use the **l2tp-class** command in global configuration mode. To delete the L2TP class, use the **no** form of this command.

```
l2tp-class l2tp-class-name
no l2tp-class l2tp-class-name
```

Syntax Description	l2tp-class-name L2TP class name.
--------------------	----------------------------------

Command Default No L2TP classes are defined.

Command Modes Global configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note An L2TP class name must be defined before configuring L2TP control plane configuration settings.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to enter L2TP configuration mode to create a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes (in this case, the word “cisco” is used):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)#
```

l2transport

To configure a physical interface to operate in Layer 2 transport mode, use the **l2transport** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

l2transport
no l2transport

This command has no arguments or keywords.

Command Default None

Command Modes Interface configuration

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The l2transport command and these configuration items are mutually exclusive:

- IPv4 address and feature (for example, ACL) configuration
- IPv4 enable, address and feature (for example, ACL) configuration
- Bundle-enabling configuration
- L3 subinterfaces
- Layer 3 QoS Policy



Note After an interface or connection is set to Layer 2 switched, commands such as **ipv4 address** are not usable. If you configure routing commands on the interface, **l2transport** is rejected.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure an interface or connection as Layer 2 switched under several different modes:

Ethernet Port Mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RP0/CPU0:router(config-if)# l2transport
```

Ethernet VLAN Mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/RP0/CPU0:router(config-if)# encapsulation dot1q 100dot1q vlan 999
```

Ethernet VLAN Mode (QinQ):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/RP0/CPU0:router(config-if)# encapsulation dot1q 20 second-dot1q 10vlan 999 888
```

Ethernet VLAN Mode (QinAny):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/RP0/CPU0:router(config-if)# encapsulation dot1q 30 second-dot1q dot1q vlan 999 any
```

Related Commands

Command	Description
show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.

l2transport l2protocol

To configure Layer 2 protocol handling, use the **l2transport l2protocol** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

```
l2transport l2protocol {cdp | pvst | stp | vtp} {drop | experimental bits | tunnel experimental bits}
no l2transport l2protocol {cdp | pvst | stp | vtp} {drop | experimental bits | tunnel experimental bits}
```

Syntax Description		
	cdp	Configures Cisco Discovery Protocol (CDP).
	pvst	Configures Per VLAN Spanning Tree protocol (PVST).
	stp	Configures Spanning Tree Protocol (STP).
	vtp	Configures VLAN Trunk Protocol (VTP).
	drop	Drops the selected protocol packets.
	experimental bits	Modifies the MPLS experimental bits.
	tunnel experimental bits	Configures tunnel protocol packets.

Command Default None

Command Modes Interface configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

These L2 protocols are available:

- Cisco Discovery Protocol (CDP)—CDP is protocol-independent and is used to obtain protocol addresses, platform information, and other data about neighboring devices.
- PVST maintains a spanning tree instance for each VLAN configured in the network and permits a VLAN trunk to be forwarding for some VLANs and not for others. It can also load balance Layer 2 traffic by forwarding some VLANs on one trunk and other VLANs on others.
- Spanning-Tree Protocol (STP)—STP is a link management protocol that provides path redundancy in the network. For Ethernet networks to function properly, only one active path can exist between two stations.

- VLAN Trunk Protocol (VTP)—VTP is a Cisco-proprietary protocol that reduces administration in a switched network. When you configure a new VLAN on one VTP server, the VLAN is distributed through all switches in the domain.

Task ID	Task ID	Operations
	l2vpn	read, write
	atm	read, write

Examples

The following example shows how to configure Layer 2 protocol handling:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RP0/CPU0:router(config-if)# l2transport l2protocol cpsv reverse-tunnelstp drop
```

Related Commands	Command	Description
	show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.

l2transport propagate

To propagate Layer 2 transport events, use the **l2transport propagate** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

l2transport propagate remote-status
no l2transport propagate remote-status

Syntax Description	remote-status	Propagates remote link status changes.

Command Default	None

Command Modes	Interface configuration

Command History	Release	Modification
	Release 3.6.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **l2transport propagate** command provides a mechanism for the detection and propagation of remote link failure for port mode EoMPLS.

To display the state of l2transport events, use the **show controller internal** command in *Interface and Hardware Component Configuration Guide for Cisco CRS Routers*



Note This command is supported on the following Cisco CRS Router SPA cards:

- Cisco 1-Port 10 Gigabit Ethernet Shared Port Adapter, Version 2
- Cisco 2-port, 5-port, 8-port, and 10-port Gigabit Ethernet Shared Port Adapters
- Cisco 2-, 5-, 8-, and 10-Port Gigabit Ethernet Shared Port Adapters, Version 2
- Cisco 1-Port 10 Gigabit Ethernet LAN/WAN-PHY Shared Port Adapter

Any port on 6-10GE-WLO-FLEX (irrespective of SPA or fixed) does not support the **l2transport propagate** command.

For more information about the Ethernet remote port shutdown feature, see *MPLS Configuration Guide for the Cisco CRS Routers*.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to propagate remote link status changes:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RP0/CPU0:router(config-if)# l2transport propagate remote remote-status
```

Related Commands	Command	Description
	show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.

l2transport service-policy

To configure a Layer 2 transport quality of service (QoS) policy, use the **l2transport service-policy** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

```
l2transport service-policy {input policy-name | output policy-name}
no l2transport service-policy {input policy-name | output policy-name}
```

Syntax Description	input <i>policy-name</i>
	Configures the direction of service policy application: input.

output Configures the direction of service policy application: output.
policy-name

Command Default None

Command Modes Interface configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write
	atm	read, write

Examples The following example shows how configure an L2 transport quality of service (QoS) policy:

```
RP/0/RSP0RP00/CPU0:router# configure
RP/0/RSP0RP00/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RSP0RP00/CPU0:router(config-if)# l2transport service-policy input sp_0001
```

Related Commands	Command	Description
	show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.

l2vpn

To enter L2VPN configuration mode, use the **l2vpn** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

l2vpn
no l2vpn

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---



Note	All L2VPN configuration can be deleted using the no l2vpn command.
-------------	---

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to enter L2VPN configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)#
```

Related Commands	Command	Description
	show l2vpn forwarding, on page 70	Displays forwarding information from the layer2_fib manager on the line card.

load-balancing flow-label

To balance the load based on flow-labels, use the **load-balancing flow label** command in the l2vpn pseudowire class mpls configuration submode or l2vpn bridge group bridge-domain vfi autodiscovery bgp or ldp signaling submodes. To undo flow-label based load-balancing, use the **no** form of this command.

```
load-balancing flow-label {both | code | receive | transmit} [{static}]
no load-balancing flow-label {both | code | receive | transmit} [{static}]
```

Syntax Description	both	Inserts or discards flow labels on transmit or receive.
	code	Specifies the flow label TLV (type-length-value) code. The code value is 17.
	receive	Discards flow label on receive.
	transmit	Inserts flow label on transmit.

static Sets flow label parameters statically.

Command Default None

Command Modes L2vpn pseudowire class mpls configuration submenu
 L2vpn bridge group bridge-domain vfi autodiscovery bgp signaling submenu
 L2vpn bridge group bridge-domain vfi autodiscovery ldp signaling submenu

Command History	Release	Modification
	Release 4.2.0	This command was introduced.
	Release 4.3.2	The code keyword was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In the [draft-ietf-pwe3-fat-pw](#) document, the flow label sub-TLV identifier for the Flow Aware Transport Pseudowire (FAT PW) was 0x11. This value has been changed to 0x17, which is also the sub-TLV identifier assigned by the Internet Assigned Numbers Authority (IANA).

Use the **load-balancing flow label code** command to toggle between the sub-TLV identifiers—0x11 and 0x17. If there is a mismatch between two endpoints in the load-balancing flow label code, then the PWs will have a mismatched TLV value resulting in a load balancing failure.

The **no** form of the **load-balancing flow label code** command uses the flow label sub-TLV identifier 0x11.

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows the output of the **load-balancing flow-label** command of the **both** keyword.

```
RP/0/RP0/CPU0:router#config
RP/0/RP0/CPU0:router (config) #l2vpn
RP/0/RP0/CPU0:router (config-l2vpn) #pw-class p1
RP/0/RP0/CPU0:router (config-l2vpn-pwc) #encapsulation
RP/0/RP0/CPU0:router (config-l2vpn-pwc) #encapsulation mpls
RP/0/RP0/CPU0:router (config-l2vpn-pwc-mpls) #load-balancing
RP/0/RP0/CPU0:router (config-l2vpn-pwc-mpls) #load-balancing flow-label
RP/0/RP0/CPU0:router (config-l2vpn-pwc-mpls) #load-balancing flow-label both
RP/0/RP0/CPU0:router (config-l2vpn-pwc-mpls) #load-balancing flow-label both static
```

Related Commands	Command	Description
	pw-class encapsulation mpls, on page 47	Configures MPLS pseudowire encapsulation.

logging (l2vpn)

To enable cross-connect logging, use the **logging** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

logging pseudowire status
no logging pseudowire status

Syntax Description

pseudowire status Enables pseudowire state change logging.

Command Default

None

Command Modes

L2VPN configuration submode

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note

All L2VPN configuration can be deleted using the **no l2vpn** command.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to enable cross-connect logging:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# logging pseudowire status
```

Related Commands

Command	Description
l2vpn, on page 34	Enters L2VPN configuration mode.

logging nsr

To enable non-stop routing logging, use the **logging nsr** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

logging nsr
no logging nsr

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes L2VPN configuration submode

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note All L2VPN configuration can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to enable non-stop routing logging:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# logging nsr
```

Related Commands	Command	Description
	l2vpn, on page 34	Enters L2VPN configuration mode.

monitor-session (l2vpn)

To attach a traffic monitoring session as one of the segments for a cross connect, use the **monitor-session** command in point-to-point cross connect configuration mode. To remove the association between a traffic mirroring session and a cross connect, use the **no** form of this command.

monitor-session *session-name*
no monitor-session *session-name*

Syntax Description	<i>session-name</i> Name of the monitor session to configure.
---------------------------	---

Command Default	No default behavior or values
------------------------	-------------------------------

Command Modes	Point-to-point cross connect configuration
----------------------	--

Command History	Release	Modification
	Release 4.0.0	This command was introduced.

Usage Guidelines	<p>Before you can attach a traffic mirroring session to a cross connect, you must define it using the monitor-session global configuration command. Once the traffic mirroring session is defined, use the monitor-session point-to-point cross connect configuration command to attach this session as one of the segments for the cross connect. Once attached, all traffic replicated from the monitored interfaces (in other words, interfaces that are associated with the monitor-session) is replicated to the pseudowire that is attached to the other segment of the cross-connect.</p>
-------------------------	--

The *session-name* argument should be different than any interface names currently used in the system.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	This example shows how to attach a traffic mirroring session as segment for the xconnect:
-----------------	---

```
RP/0/RSP0/CPU0:router(config)# l2vpn
RP/0/RSP0/CPU0:router(config-l2vpn)# xconnect group g1
RP/0/RSP0/CPU0:router(config-l2vpn-xc)# p2p xcon1
RP/0/RSP0/CPU0:router(config-l2vpn-xc-p2p)# monitor-session mon1
```

Related Commands	Command	Description
	See the monitor session command in the <i>Interface and Hardware Component Command Reference for Cisco CRS Routers</i> .	

mpls static label (L2VPN)

To configure static labels for MPLS L2VPN, use the **mpls static label** command in L2VPN cross-connect P2P pseudowire configuration mode. To have MPLS assign a label dynamically, use the **no** form of this command.

```
mpls static label local label remote value
no mpls static label local label remote value
```

Syntax Description	
local <i>label</i>	Configures a local pseudowire label. Range is 16 to 15999.
remote <i>value</i>	Configures a remote pseudowire label. Range is 16 to 15999.

Command Default The default behavior is a dynamic label assignment.

Command Modes L2VPN cross-connect P2P pseudowire configuration

Command History	Release	Modification
	Release 3.7.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure static labels for MPLS L2VPN:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn xconnect group l2vpn
RP/0/RP0/CPU0:router (config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/RP0/CPU0:router (config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router (config-l2vpn-xc-p2p-pw)# mpls static label local 800 remote 500
```

Related Commands	Command	Description
	l2vpn, on page 34	Enters L2VPN configuration mode.
	neighbor (L2VPN), on page 41	Configures a pseudowire for a cross-connect.
	p2p, on page 51	Enters p2p configuration submode to configure point-to-point cross-connects.

Command	Description
xconnect group, on page 108	Configures cross-connect groups.

neighbor (L2VPN)

To configure a pseudowire for a cross-connect, use the **neighbor** command in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

```
neighbor A.B.C.D pw-id value [{backup | mpls | pw-class | tag-impose}]
no neighbor A.B.C.D pw-id value [{backup | mpls | pw-class | tag-impose}]
```

Syntax Description	
<i>A.B.C.D</i>	IP address of the cross-connect peer.
pw-id <i>value</i>	Configures the pseudowire ID and ID value. Range is 1 to 4294967295.
tag-impose	Optional Specifies a tag during a VLAN ID configuration.

Command Default None

Command Modes p2p configuration submode

Command History	Release	Modification
	Release 3.4.0	This command was introduced.
	Release 3.4.1	The vccv disable keyword was added.
	Release 3.7.0	These keywords were removed: <ul style="list-style-type: none"> • control-word • pw-static-label local • remote • vccv • transport-mode
	Release 4.2.1	The keyword tag-impose was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A cross-connect may have two segments:

1. An Attachment Circuit (AC)
2. An second AC or a pseudowire



Note The pseudowire is identified by two keys: neighbor and pseudowire ID. There may be multiple pseudowires going to the same neighbor. It is not possible to configure only a neighbor.

All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

This example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000 pw-class class12
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.3 pw-id 1001 pw-class class13
RP/0/RP0/CPU0:router(config-xc)# p2p rtrC_to_rtrD
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.2.2.3 pw-id 200 pw-class class23
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.2.2.4 pw-id 201 pw-class class24
```

This example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000 pw-class foo
RP/0/RP0/CPU0:router(config-xc)# p2p rtrC_to_rtrD
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 20.2.2.3 pw-id 200 pw-class bar1
```

Related Commands

Command	Description
l2vpn, on page 34	Enters L2VPN configuration mode.
p2p, on page 51	Enters p2p configuration submode to configure point-to-point cross-connects.
pw-class (L2VPN), on page 44	Enters pseudowire class submode to define a pseudowire class template.
xconnect group, on page 108	Configures cross-connect groups.

nsr (L2VPN)

To configure non-stop routing, use the **nsr** command in L2VPN configuration submode. To return to the default behavior, use the **no nsr** form of this command.

```
nsr
no nsr
```

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes L2VPN configuration submode

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

Usage Guidelines All L2VPN configuration can be deleted using the **no l2vpn** command.



Note NSR is enabled by default for L2VPN On Cisco IOS XR 64 bit operating system. You cannot configure the **nsr** command under L2VPN configuration submode.

Task ID	Task ID	Operation
	l2vpn	read, write

The following example shows how to configure non-stop routing:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# nsr
```

Related Commands	Command	Description
	l2vpn, on page 34	Enters L2VPN configuration mode.

password (L2TP)

To define the password and password encryption type for control channel authentication, use the **password** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

```
password [{0 | 7}] password
no password
```

Syntax Description	0	(Optional) Specifies that an unencrypted password will follow.
	7	(Optional) Specifies that an encrypted password will follow.
	<i>password</i>	Unencrypted or clear text user password.

pw-class (L2VPN)**Command Default** None**Command Modes** Global configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to define an unencrypted password using the word “cisco” for control channel authentication:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class sanjose
RP/0/RP0/CPU0:router(config-l2tp-class)# password 0 cisco
```

Related Commands	Command	Description
	authentication (L2TP), on page 10	Enables L2TP authentication for a specified L2TP class name.
	hello-interval (L2TP), on page 24	Configures the hello-interval value for L2TP (duration between control channel hello packets).
	hidden (L2TP), on page 25	Enables hidden attribute-value pairs (AVPs).
	hostname (L2TP), on page 26	Defines the name used in the L2TP hostname AVP.
	l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
	receive-window (L2TP), on page 52	Configures the receive window size for the L2TP server.
	retransmit (L2TP), on page 53	Configures retransmit retry and timeout values.

pw-class (L2VPN)

To enter pseudowire class submode to define a pseudowire class template, use the **pw-class** command in L2VPN configuration submode. To delete the pseudowire class, use the **no** form of this command.

```
pw-class class-name
no pw-class class-name
```

Syntax Description	<i>class-name</i> Pseudowire class name.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	L2VPN configuration submode
----------------------	-----------------------------

Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---



Note	All L2VPN configurations can be deleted using the no l2vpn command.
-------------	--

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to define a simple pseudowire class template:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group l1vpn
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# pw-class kanata01
```

Related Commands	Command	Description
	p2p, on page 51	Enters p2p configuration submode to configure point-to-point cross-connects.

pw-class encapsulation l2tpv3

To configure L2TPv3 pseudowire encapsulation, use the **pw-class encapsulation l2tpv3** command in L2VPN pseudowire class configuration mode. To return to the default behavior, use the **no** form of this command.

```
pw-class class name encapsulation l2tpv3 [{cookie size {0|4|8} | ipv4 source address | pmtu
max 68-65535 | protocol l2tpv3 class name | tos {reflect value 0-255 | value 0-255} | ttl value}]
no pw-class class name encapsulation l2tpv3 [{cookie size {0|4|8} | ipv4 source address | pmtu
max 68-65535 | protocol l2tpv3 class name | tos {reflect value 0-255 | value 0-255} | ttl value}]
```

Syntax Description		
class name		Configures an encapsulation class name.
cookie size {0 4 8}		(Optional) Configures the L2TPv3 cookie size setting: <ul style="list-style-type: none"> • 0—Cookie size is 0 bytes. • 4—Cookie size is 4 bytes. • 8—Cookie size is 8 bytes.
ipv4 source address		(Optional) Configures the local source IPv4 address.
pmtu max 68-65535		(Optional) Configures the value of the maximum allowable session MTU.
protocol l2tpv3 class name		(Optional) Configures L2TPv3 as the signaling protocol for the pseudowire class.
tos {reflect value 0-255 value 0-255}		(Optional) Configures TOS and the TOS value. Range is 0 to 255.
ttl value		Configures the Time-to-live (TTL) value. Range is 1 to 255.

Command Default None

Command Modes L2VPN pseudowire class configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to define L2TPV3 pseudowire encapsulation:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# encapsulation l2tpv3
```

The following example shows how to set the encapsulation and protocol to L2TPV3:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# encapsulation l2tpv3
RP/0/RP0/CPU0:router(config-l2vpn-pwc-l2tpv3)# protocol l2tpv3
```

Related Commands	Command	Description
	pw-class (L2VPN), on page 44	Enters pseudowire class submode to define a pseudowire class template.
	pw-class encapsulation mpls, on page 47	Configures MPLS pseudowire encapsulation.

pw-class encapsulation mpls

To configure MPLS pseudowire encapsulation, use the **pw-class encapsulation mpls** command in L2VPN pseudowire class configuration mode. To undo the configuration, use the **no** form of this command.

```
pw-class class-name encapsulation mpls {control word | ipv4 | load-balancing flow-label |
preferred-path | protocol ldp | sequencing | tag-rewrite | transport-mode | vccv verification-type none}
no pw-class class-name encapsulation mpls {control word | ipv4 | load-balancing flow-label |
preferred-path | protocol ldp | sequencing | tag-rewrite | transport-mode | vccv verification-type none}
```

Syntax Description		
	<i>class-name</i>	Encapsulation class name.
	control word	Disables control word for MPLS encapsulation. Disabled by default.
	ipv4	Sets the local source IPv4 address.
	load-balancing flow-label	Sets flow label-based load balancing.
	preferred-path	Configures the preferred path tunnel settings.
	protocol ldp	Configures LDP as the signaling protocol for this pseudowire class.
	sequencing	Configures sequencing on receive or transmit.
	tag-rewrite	Configures VLAN tag rewrite.
	transport-mode	Configures transport mode to be either Ethernet or VLAN.
	vccv none	Enables or disables the VCCV verification type.

Command Default None

Command Modes L2VPN pseudowire class configuration

Command History	Release	Modification
	Release 3.5.0	This command was introduced.
	Release 3.8.0	The keywords control word disable and vccv none were replaced by the keywords control word and vccv verification-type none .
	Release 3.9.0	The following keywords were added: <ul style="list-style-type: none"> • preferred-path • sequencing • tag-rewrite • transport-mode
	Release 4.3.0	The keyword load-balancing flow-label was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples This example shows how to define MPLS pseudowire encapsulation:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls
```

Related Commands	Command	Description
	pw-class (L2VPN), on page 44	Enters pseudowire class submode to define a pseudowire class template.
	pw-class encapsulation l2tpv3, on page 45	Configures L2TPv3 pseudowire encapsulation.

pw-ether

To configure a PWHE Ethernet interface, use the **pw-ether** command in global configuration mode or in p2p configuration submodule. To return to the default behavior, use the **no** form of this command.

pw-ether *value*
no pw-ether *value*

Syntax Description	<i>value</i> Value of the PWHE Ethernet interface. The range is from 1 to 32768.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration p2p configuration
----------------------	---

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operation
	interface (global configuration)	read, write
	l2vpn (p2p configuration)	read, write

This example shows the sample output of a PWHE Ethernet interface configuration in global configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# attach generic-interface-list interfacelist1
```

This example shows the sample output of a PWHE Ethernet interface configuration in p2p configuration submodule:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group xc1
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p grp1
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# interface pw-ether 78
```

This example shows the sample output of L2 overhead configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# l2overhead 32
```

This example shows the sample output of Load-interval configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# load-interval 60
```

This example shows the sample output of how to set logging of interface state change for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# logging events link-status
```

This example shows the sample output of MAC address configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# mac-address 44-37-E6-89-C3-93
```

This example shows the sample output of MTU configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# mtu 128
```

This example shows the sample output of bandwidth configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# bandwidth 256
```

Related Commands

Command	Description
p2p, on page 51	Enters p2p configuration submode to configure point-to-point cross-connects.

pw-grouping

To enable Pseudowire Grouping, use the **pw-grouping** command in L2vpn configuration submode. To return to the default behavior, use the **no** form of this command.

```
pw-grouping
no pw-grouping
```

Syntax Description

```
pw-grouping Enables Pseudowire Grouping.
```

Command Default

PW-grouping is disabled by default.

Command Modes

L2VPN configuration submode

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
------------------	---

Task ID	Task ID	Operation
	l2vpn	read, write

This example shows the sample output of pw-grouping configuration in L2VPN configuration submode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-grouping
```


Related Commands	Command	Description
	l2vpn, on page 34	Enters L2VPN configuration mode.
	show l2vpn, on page 63	Displays L2VPN information

p2p

To enter p2p configuration submode to configure point-to-point cross-connects, use the **p2p** command in L2VPN xconnect mode. To return to the default behavior, use the **no** form of this command.

```
p2p xconnect-name
no p2p xconnect-name
```

Syntax Description	<i>xconnect-name</i> (Optional) Configures the name of the point-to-point cross- connect.	
Command Default	None	
Command Modes	L2VPN xconnect	
Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The name of the point-to-point cross-connect string is a free format description string.

Task ID

Task ID	Task Operations
l2vpn	read, write

Examples

The following example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group group 1
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p xc1
```

Related Commands

Command	Description
interface (p2p), on page 27	Configures an attachment circuit.

receive-window (L2TP)

To configure the receive window size for the L2TP server, use the **receive-window** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

```
receive-window size
no receive-window size
```

Syntax Description

size Maximum number of packets that are received from a peer before back-off is applied. Default is 512.

Command Default

size: 512

Command Modes

L2TP class configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to configure the receive window size for the L2TP server to 10 packets:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# receive-window 10
```

Related Commands	Command	Description
	authentication (L2TP), on page 10	Enables L2TP authentication for a specified L2TP class name.
	hello-interval (L2TP), on page 24	Configures the hello-interval value for L2TP (duration between control channel hello packets).
	hidden (L2TP), on page 25	Enables hidden attribute-value pairs (AVPs).
	hostname (L2TP), on page 26	Defines the name used in the L2TP hostname AVP.
	l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
	password (L2TP), on page 43	Defines the password and password encryption type for control channel authentication.
	retransmit (L2TP), on page 53	Configures retransmit retry and timeout values.

retransmit (L2TP)

To configure retransmit retry and timeout values, use the **retransmit** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

```
retransmit {initial initial-retries | retries retries | timeout {max | min} timeout}
no retransmit {initial initial-retries | retries retries | timeout {max | min} timeout}
```

Syntax Description		
initial <i>initial-retries</i>		Configures the number of SCCRQ messages resent before giving up on a particular control channel. Range is 1 to 1000. Default is 2.
retries <i>retries</i>		Configures the maximum number of retransmissions before determining that peer router does not respond. Range is 5 to 1000. Default is 15.
timeout { max min } <i>timeout</i>		Configures the maximum and minimum retransmission interval in seconds for control packets. Range is 1 to 8. Maximum timeout default is 8 seconds. Minimum timeout default is 1 second.

Command Default *initial retries: 2*

retries: 15

min timeout: 1

max timeout: 8

Command Modes L2TP class configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure a retransmit retry value to 1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# retransmit initial retries 1
```

Related Commands	Command	Description
	authentication (L2TP), on page 10	Enables L2TP authentication for a specified L2TP class name.
	hello-interval (L2TP), on page 24	Configures the hello-interval value for L2TP (duration between control channel hello packets).
	hidden (L2TP), on page 25	Enables hidden attribute-value pairs (AVPs).
	hostname (L2TP), on page 26	Defines the name used in the L2TP hostname AVP.
	l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
	password (L2TP), on page 43	Defines the password and password encryption type for control channel authentication.
	receive-window (L2TP), on page 52	Configures the receive window size for the L2TP server.

rollover (L3VPN)

To configure rollover times for a tunnel-template, use the **rollover** command in tunnel encapsulation l2tp configuration mode. To return to the default behavior, use the **no** form of this command.

rollover periodic *time* **holdown** *time*
no rollover periodic *time* **holdown** *time*

Syntax Description	periodic <i>time</i> Configures the periodic rollover time in seconds. Range is 60 to 31536000.
	holddown <i>time</i> Configures the holddown time for old session cookie values.

Command Default	None
------------------------	------

Command Modes	tunnel encapsulation l2tp configuration
----------------------	---

Command History	Release	Modification
	Release 3.5.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The name of the point-to-point cross-connect string is a free format description string.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to configure rollover times for a tunnel-template:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# tunnel-template kanata_9
RP/0/RP0/CPU0:router(config-tuntem) encapsulation l2tp
RP/0/RP0/CPU0:router(config-tunencap-l2tp)# rollover
```

Related Commands	Command	Description
	interface (p2p), on page 27	Configures an attachment circuit.

show generic-interface-list

To display information about interface-lists, use the **show generic-interface-list** in EXEC mode.

show generic-interface-list [{ **location** | **name** | **retry** | **standby** }]

Syntax Description	location (Optional) Displays information about interface-lists for the specified location.
	name (Optional) Displays information about interface-lists for the specified interface list name.

show generic-interface-list

retry (Optional) Displays retry-list information.

standby (Optional) Displays Standby node specific information.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

The following example displays output for the **show generic-interface-list** command:

```
RP/0/RP0/CPU0:router# show generic-interface-list
Thu Aug  2 13:48:57.462 CDT
generic-interface-list: nsrIL (ID: 1, interfaces: 2)
  Bundle-Ether2 - items pending 0, downloaded to FIB
  GigabitEthernet0/0/0/1 - items pending 0, downloaded to FIB
Number of items: 400
List is downloaded to FIB
```

The following example displays output for the **show generic-interface-list retry private** command:

```
RP/0/RP0/CPU0:router# show generic-interface-list retry private
Thu Aug  2 14:20:42.883 CDT
total: 0 items
```

The following example displays output for the **show generic-interface-list standby** command:

```
RP/0/RP0/CPU0:router# show generic-interface-list standby
Thu Aug  2 14:25:01.749 CDT
generic-interface-list: nsrIL (ID: 0, interfaces: 2)
  Bundle-Ether2 - items pending 0, NOT downloaded to FIB
  GigabitEthernet0/0/0/1 - items pending 0, NOT downloaded to FIB
Number of items: 0
List is not downloaded to FIB
```

Related Commands

Command	Description
l2vpn, on page 34	Enters L2VPN configuration mode.

show l2tp class

To display information about an L2TP class, use the **show l2tp class** command in EXEC mode.

show l2tp class name *name*

Syntax Description	name Configures an L2TP class name. <i>name</i>
---------------------------	---

Command Default	None
------------------------	------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows sample output for the **show l2vtp session class** command:

```
RP/0/RP0/CPU0:router# show l2tp class name kanata_02

l2tp-class kanata_02
  manually configured class
  configuration parameters:
    (not) hidden
    (no) authentication
    (no) digest
    digest check enable
    hello 60
    (no) hostname
    (no) password
    (no) accounting
    (no) security crypto-profile
    (no) ip vrf
    receive-window 888
    retransmit retries 15
    retransmit timeout max 8
    retransmit timeout min 1
    retransmit initial retries 2
    retransmit initial timeout max 8
```

```
retransmit initial timeout min 1
timeout setup 300
```

This table describes the significant fields shown in the display.

Table 1: show l2tp class brief Field Descriptions

Field	Description
l2tp-class	Shows the L2TP class name and the manner of its creation. For example, manually configured class.
configuration parameters	Displays a complete list and state of all configuration parameters.

Related Commands

Command	Description
l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.

show l2tp counters forwarding session

To display L2TP forward session counters, use the **show l2tp counter forwarding session** command in EXEC mode.

show l2tp counters forwarding session [{**id** *identifier* | **name** *local-name remote-name*}]

Syntax Description

id <i>identifier</i>	(Optional) Configures the session counter identifier.
name <i>local-name remote name</i>	(Optional) Configures the local and remote names for a session counter.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows sample output for the **show l2tp counters forwarding session** command:

```
RP/0/RP00/CPU0:router(config-l2vpn)# pw-class kanata01show l2tp counters forwarding session
```

LocID	RemID	TunID	Pkts-In	Pkts-Out	Bytes-In	Bytes-Out
22112	15584	14332	0	0	0	0

This table describes the significant fields shown in the display.

Table 2: show l2tp counters forwarding session Field Descriptions

Field	Description
LocID	Local session ID.
RemID	Remote session ID.
TunID	Local Tunnel ID for this session.
Pkts-In	Number of packets input in the session.
Pkts-Out	Number of packets output in the session.
Bytes-In	Number of bytes input in the session.
Bytes-Out	Number of bytes output in the session.

Related Commands

Command	Description
#unique_59	

show l2tp session

To display information about L2TP sessions, use the **show l2tp session** command in EXEC mode.

```
show l2tp session [{detail | brief | interworking | circuit | sequence | state}] {id id | name name}
```

Syntax Description

brief	(Optional) Displays summary output for a session.
circuit	(Optional) Displays attachment circuit information for a session.
detail	(Optional) Displays detailed output for a session.
interworking	(Optional) Displays interworking information for a session.
sequence	(Optional) Displays data packet sequencing information for a session.
state	(Optional) Displays control plane state information for a session.
id id	Configures the local tunnel ID. Range is 0 to 4294967295.

show l2tp session

name *name* Configures the tunnel name.

Command Default None

Command Modes EXEC

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following sample output is from the **show l2tp session brief** command:

```
RP/0/RP00/CPU0:router(config-l2vpn-pw)# show l2tp session brief
Tue Jun 10 12:51:30.901 UTC
LocID      TunID      Peer-address  State      Username, Intf/sess/cir  Vcid, Circuit
-----
1606803058 1487464659 26.26.26.26   est,UP     101, Gi0/2/0/1.101
3663696887 1487464659 26.26.26.26   est,UP     100, Gi0/2/0/1.100
```

This table describes the significant fields shown in the display.

Table 3: show l2tp session brief Field Descriptions

Field	Description
LocID	Local session ID.
TunID	Local tunnel ID for this session.
Peer-address	The IP address of the other end of the session.
State	The state of the session.
Vcid	The Virtual Circuit ID of the session. This is the same value of the pseudowire ID for l2vpn.

The following sample output is from the **show l2tp session detail** command:

```
RP/0/RP00/CPU0:router(config-l2vpn-pw)# show l2tp session detail
Tue Jun 10 12:53:19.842 UTC
Session id 1606803058 is up, tunnel id 1487464659, logical session id 131097
Remote session id is 2602674409, remote tunnel id 2064960537
```

```

Remotely initiated session
Call serial number is 4117500017
Remote tunnel name is ASR9K-PE2
Internet address is 26.26.26.26:1248
Local tunnel name is PRABHRAM-PE1
Internet address is 25.25.25.25:4272
IP protocol 115
Session is L2TP signaled
Session state is established, time since change 00:07:28
UDP checksums are disabled
Session cookie information:
  local cookie, size 4 bytes, value 6d 3e 03 67
  remote cookie, size 4 bytes, value 0d ac 7a 3b
Tie breaker is 0xfee65781a2fa2cfd, enabled TRUE.
Sequencing is off
Conditional debugging is disabled
Unique ID is 101
Session Layer 2 circuit
Payload type is Ethernet, Name is GigabitEthernet0_2_0_1.101
Session vcid is 101
Circuit state is UP
  Local circuit state is UP
  Remote circuit state is UP

```

Related Commands

Command	Description
#unique_59	

show l2tp tunnel

To display information about L2TP tunnels, use the **show l2tp tunnel** command in EXEC mode.

```
show l2tp tunnel {detail | brief | state | transport} {id identifier | name local-name remote-name}
```

Syntax Description

detail	Displays detailed output for L2TP tunnels.
brief	Displays summary information for the tunnel.
state	Displays control plane state information.
transport	Displays transport information (IP) for each selected control channel.
id <i>identifier</i>	Displays local control channel identifiers.
name <i>local-name remote-name</i>	Displays the local and remote names of a control channel.

Command Default

None

Command Modes

EXEC

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Task Operations
l2vpn	read, write

Examples

The following sample output is from the **show l2tp tunnel brief** command:

```
RP/0/RP0/CPU0:router(config-l2vpn-encap-mpls)# show l2tp tunnel brief
Tue Jun 10 12:46:04.421 UTC
LocTunID  RemTunID  Remote Name  State  Vrf Name  Remote Address  Sessn L2TP Class/Count
VPDN Group
1487464659 2064960537 ASR9K-PE2    est              26.26.26.26    2      L2TPV3_CLASS
```

This table describes the significant fields shown in the display.

Table 4: show l2tp tunnel Field Descriptions

Field	Description
LocTunID	Local session ID.
RemTunID	Remote session ID.
Remote Name	Remote name of the session.
State	State of the session.
Remote Address	Remote address of the session.
Port	Session port.
Sessions	Number of sessions.
L2TP	L2TP class name.

The following sample output is from the **show l2tp tunnel detail** command:

```
RP/0/RP0/CPU0:router(config-l2vpn-encap-mpls)# show l2tp tunnel detail
Tue Jun 10 12:47:36.638 UTC
Tunnel id 1487464659 is up, remote id is 2064960537, 2 active sessions
  Remotely initiated tunnel
  Tunnel state is established, time since change 4d19h
  Tunnel transport is IP (115)
  Remote tunnel name is ASR9K-PE2
    Internet Address 26.26.26.26, port 0
  Local tunnel name is PRABHRAM-PE1
    Internet Address 25.25.25.25, port 0
  VRF table id is 0xe0000000
  Tunnel group id
  L2TP class for tunnel is L2TPV3_CLASS
```

```

Control Ns 4178, Nr 4181
Local RWS 512 (default), Remote RWS 512
Control channel Congestion Control is disabled
Tunnel PMTU checking disabled
Retransmission time 1, max 1 seconds
Unsent queuesize 0, max 0
Resend queuesize 0, max 1
Total resends 0, ZLB ACKs sent 4177
Total out-of-order dropped pkts 0
Total out-of-order reorder pkts 0
Total peer authentication failures 0
Current no session pak queue check 0 of 5
Retransmit time distribution: 0 0 0 0 0 0 0 0
Control message authentication is disabled

```

Related Commands	Command	Description
	show l2tp session, on page 59	Displays information about L2TP sessions.

show l2vpn

To display L2VPN information, use the **show l2vpn** command in EXEC mode.

show l2vpn

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

Example

The following example displays output for the **show l2vpn** command. The output provides an overview of the state of the globally configured features.

```
RP/0/RP0/CPU0:router# show l2vpn
Mon May  7 15:01:17.963 BST
PW-Status: disabled
PW-Grouping: disabled
Logging PW: disabled
Logging BD state changes: disabled
Logging VFI state changes: disabled
Logging NSR state changes: disabled
TCN propagation: disabled
PWOAMRefreshTX: 30s
```

Related Commands	Command	Description
	l2vpn, on page 34	Enters L2VPN configuration mode.
	pw-grouping, on page 50	Enables Pseudowire Grouping

show l2vpn atom-db

To display AToM database information, use the **show l2vpn atom-db** command in EXEC mode.

```
show l2vpn atom-db [{detail | l2-rid | ldp-rid | local-gid | neighbor | preferred-path | remote-gid | source}]
```

Syntax Description	Parameter	Description
	detail	Specifies the details of the database.
	l2-rid	Specifies the AToM database walking the L2 RID thread.
	ldp-rid	Specifies the AToM database walking the LDP RID thread.
	local-gid	Specifies the AToM database walking the Local GID thread.
	neighbor	Specifies the details of the neighbor database.
	preferred-path	Specifies the preferred path (tunnel) of the database
	remote-gid	Specifies the AToM database walking the Remote GID thread.
	source	Specifies the details of the source database.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID**Task Operations ID**

l2vpn read

Examples

This example shows the sample output of the **show l2vpn atom-db source 1.1.1.1** command:

```
RP/0/RP0/CPU0:router# show l2vpn atom-db source 1.1.1.1
Peer ID      Source      VC ID      Encap      Signaling  FEC      Discovery
2.2.2.2      1.1.1.1    1          MPLS       LDP        128     none
```

This example shows the sample output of the **show l2vpn atom-db source 1.1.1.1 detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn atom-db source 1.1.1.1 detail
PW: neighbor 2.2.2.2, PW ID 1, state is down ( provisioned )
PW class class1, XC ID 0x1
Encapsulation MPLS, protocol LDP
Source address 1.1.1.1
PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

MPLS          Local                      Remote
-----
Label         16000                      unknown
Group ID      0x20000060                 0x0
Interface     GigabitEthernet0/0/0/1.1   unknown
MTU           1504                       unknown
Control word  disabled                   unknown
PW type       Ethernet                   unknown
VCCV CV type  0x2                        0x0
                                   (none)
                                   (LSP ping verification)
VCCV CC type  0x6                        0x0
                                   (none)
                                   (router alert label)
                                   (TTL expiry)
-----
MIB cpwVcIndex: 4278194081
Create time: 13/12/2010 15:28:26 (20:32:27 ago)
Last time status changed: 13/12/2010 15:28:26 (20:32:27 ago)
Configuration info:
  PW class: class1
  Peer ID = 2.2.2.2, pseudowire ID = 1
  Control word is not set
  Transport mode: not set
    Configured (Static) Encapsulation: not set
    Provisioned Encapsulation: MPLS
  Static tag rewrite: not set
  MTU: 1504
  Tunnel interface: None
  IW type: 0
  PW type: Dynamic
  Pref path configured: No
  Bridge port: No
  BP learning disabled: No
```

show l2vpn collaborators

```

BP ucast flooding disabled: No
BP bcast flooding disabled: No
CW is mandatory: No
Label: local unassigned, remote unassigned
L2 Router-ID: 0.0.0.0
LDP Router-ID: 0.0.0.0
GR stale: No
LDP Status: local established, remote unknown
LDP tag rewrite: not set
Force switchover: inactive
MAC trigger: inactive
VC sane: Yes
Use PW Status: No
Local PW Status: Up(0x0); Remote PW Status: Up(0x0)
Peer FEC Failed: No
LSP: Down
Operational state:
  LDP session state: down
  TE tunnel transport: No
  VC in gr mode: No
  Peer state: up
  Transport LSP down: Yes
  Advertised label to LDP: No
  Received a label from LSD: Yes
  Need to send standby bit: No
  VC created from rbinding: No
  PW redundancy dampening on : No
  Notified up : No
Detailed segment state: down
PW event trace history [Total events: 8]
-----
Time          Event          Value
====          =====
12/13/2010 15:28:26 LSP Down      0
12/13/2010 15:28:26 Provision     0
12/13/2010 15:28:26 LSP Down      0
12/13/2010 15:28:26 Connect Req   0
12/13/2010 15:28:26 Rewrite create 0x100000
12/13/2010 15:28:26 Got label     0x3e80
12/13/2010 15:28:26 Local Mtu     0x5e0
12/13/2010 15:28:26 Peer Up       0

```

show l2vpn collaborators

To display information about the state of the interprocess communications connections between l2vpn_mgr and other processes, use the **show l2vpn collaborators** command in EXEC mode.

show l2vpn collaborators

Syntax Description	This command has no arguments or keywords.
Command Default	None
Command Modes	EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows sample output for the **show l2vpn collaborators** command:

```
RP/0/RP0/CPU0:router# show l2vpn collaborators
L2VPN Collaborator stats:
Name                State      Up Cnts    Down Cnts
-----
IMC                 Down       0           0
LSD                 Up         1           0
```

This table describes the significant fields shown in the display.

Table 5: show l2vpn collaborators Field Descriptions

Field	Description
Name	Abbreviated name of the task interacting with l2vpn_mgr.
State	Indicates if l2vpn_mgr has a working connection with the other process.
Up Cnts	Number of times the connection between l2vpn_mgr and the other process has been successfully established.
Down Cnts	Number of times that the connection between l2vpn_mgr and the other process has failed or been terminated.

Related Commands	Command	Description
	clear l2vpn collaborators, on page 16	Clears the state change counters for L2VPN collaborators.

show l2vpn database

To display L2VPN database, use the **show l2vpn database** command in EXEC mode.

```
show l2vpn database {ac | node}
```

show l2vpn database

Syntax Description	ac	Displays L2VPN Attachment Circuit (AC) database
	node	Displays L2VPN node database.

Command Default	None
------------------------	------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Even when xSTP (extended spanning tree protocol) operates in the PVRST mode, the output of the show or debug commands flag prefix is displayed as MSTP or MSTi, instead of PVRST.

Task ID	Task ID	Operation
		l2vpn

The following example displays output for the **show l2vpn database ac** command:

```
RP/0/RP0/CPU0:router# show l2vpn database ac
Bundle-Ether1.1:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x0
  Signaled capability valid: No
  Signaled capability flags: 0x0
  Configured capability flags: 0x0
  XCID: 0xffffffff
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-iframe: Bundle-Ether1.1
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x020000e0
    ac-type: 0x15
    interworking: 0x00
  AC info:
    seg-status-flags: 0x00000000
    segment mtu/l2-mtu: 1504/1518

GigabitEthernet0/0/0/0.4096:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x0
  Signaled capability valid: No
  Signaled capability flags: 0x0
  Configured capability flags: 0x0
```

```

XCID: 0x0
PSN Type: Undefined
ETH data:
  Xconnect tags: 0
  Vlan rewrite tag: 0
AC defn:
  ac-iframe: GigabitEthernet0_0_0_0.4096
  capabilities: 0x00368079
  extra-capabilities: 0x00000000
  parent-ifh: 0x040000c0
  ac-type: 0x15
  interworking: 0x00
AC info:
  seg-status-flags: 0x00000003
  segment mtu/l2-mtu: 1504/1518

```

The following example displays output for the **show l2vpn database node** command:

```

RP/0/RP0/CPU0:router# show l2vpn database node
0/RSP0/CPU0
MA: vlan_ma

AC event trace history [Total events: 4]
-----
Time          Event                               Num Rcvd   Num Sent
====          =====                               =
07/27/2012 15:00:31 Process joined                       0           0
07/27/2012 15:00:31 Process init success                    0           0
07/27/2012 15:00:31 Replay start rcvd                      0           0
07/27/2012 15:00:31 Replay end rcvd                          2           0

MA: ether_ma

AC event trace history [Total events: 4]
-----
Time          Event                               Num Rcvd   Num Sent
====          =====                               =
07/27/2012 15:00:31 Process joined                       0           0
07/27/2012 15:00:31 Process init success                    0           0
07/27/2012 15:00:31 Replay start rcvd                      0           0
07/27/2012 15:00:31 Replay end rcvd                          0           0

0/0/CPU0
MA: vlan_ma

AC event trace history [Total events: 4]
-----
Time          Event                               Num Rcvd   Num Sent
====          =====                               =
07/27/2012 15:00:31 Process joined                       0           0
07/27/2012 15:00:31 Process init success                    0           0
07/27/2012 15:00:31 Replay start rcvd                      0           0
07/27/2012 15:00:40 Replay end rcvd                   6006        6001

MA: ether_ma

AC event trace history [Total events: 4]
-----
Time          Event                               Num Rcvd   Num Sent
====          =====                               =

```

```

07/27/2012 15:00:31 Process joined                0          0
07/27/2012 15:00:31 Process init success         0          0
07/27/2012 15:00:31 Replay start rcvd           0          0
07/27/2012 15:00:31 Replay end rcvd             1          0

```

show l2vpn forwarding

To display forwarding information from the layer2_fib manager on the line card, use the **show l2vpn forwarding** command in EXEC mode.

show l2vpn forwarding {**xconnect** | **bridge-domain** | **counter** | **detail** | **hardware** | **inconsistent** | **interface** | **l2tp** | **location** [*node-id*] | **message** | **mstp** | **resource** | **retry-list** | **summary** | **unresolved**}

Syntax	Description
xconnect	Displays the cross-connect related information.
bridge-domain	Displays bridge domain related forwarding information.
counter	Displays the cross-connect counters.
detail	Displays detailed information from the layer2_fib manager.
hardware	Displays hardware-related layer2_fib manager information.
inconsistent	Displays inconsistent entries only.
interface	Displays the match AC subinterface.
l2tp	Displays L2TPv3 related forwarding information.
location <i>node-id</i>	Displays layer2_fib manager information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
message	Displays messages exchanged with collaborators.
mstp	Displays multi-spanning tree related forwarding information.
resource	Displays resource availability information in the layer2_fib manager.

retry-list	Displays retry list related information.
summary	Displays summary information about cross-connects in the layer2_fib manager.
unresolved	Displays unresolved entries only.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.4.0	This command was introduced.
	Release 3.7.0	Sample output was updated to add MAC information for the layer2_fib manager summary.

Usage Guidelines To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following sample output is from the **show l2vpn forwarding bridge detail location** command for IOS-XR releases 5.3.1 and earlier:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge detail location 0/2/cpu0
Bridge-domain name: bgl:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
IGMP snooping: disabled, flooding: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 1
Number of MAC addresses: 0
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/1.2, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0
Storm control drop counters:
```

```

    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

```

```

Bridge-domain name: bg1:bd2, id: 1, state: up
  Type: pbb-edge, I-SID: 1234
  Core-bridge: pbb-bd2
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  DHCPv4 snooping: profile not known on this node
  IGMP snooping: disabled, flooding: disabled
  Bridge MTU: 1500 bytes
  Number of bridge ports: 0
  Number of MAC addresses: 0
  Multi-spanning tree instance: 0

PBB Edge, state: up
  Number of MAC: 0
GigabitEthernet0/1/0/1.3, state: oper up
  Number of MAC: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

Bridge-domain name: bg1:bd3, id: 2, state: up
  Type: pbb-core
  Number of associated pbb-edge BDs: 1

MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  DHCPv4 snooping: profile not known on this node
  IGMP snooping: disabled, flooding: disabled
  Bridge MTU: 1500 bytes
  Number of bridge ports: 0
  Number of MAC addresses: 0
  Multi-spanning tree instance: 0

PBB Core, state: up
  Vlan-id: 1

GigabitEthernet0/1/0/1.4, state: oper up
  Number of MAC: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

```

The following sample output is from the **show l2vpn forwarding bridge detail location** command for IOS-XR 5.3.2 release:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge detail location 0/0/CPU0
```

```

Bridge-domain name: pbb:pbb_core1, id: 10, state: up
Type: pbb-core
Number of associated pbb-edge BDs: 1
MAC learning: enabled
MAC port down flush: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
MAC Secure: disabled, Logging: disabled
DHCPv4 snooping: profile not known on this node
Dynamic ARP Inspection: disabled, Logging: disabled
IP Source Guard: disabled, Logging: disabled
IGMP snooping: disabled, flooding: enabled
MLD snooping: disabled, flooding: disabled
MMRP Flood Optimization: disabled
Storm control: disabled
P2MP PW: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 1
Number of MAC addresses: 5
Multi-spanning tree instance: 0
PBB-EVPN: enabled
Statistics:
  packets: received 0, sent 963770
  bytes: received 0, sent 263433178

PBB Core, state: Up
Vlan-id: 1
XC ID: 0x80000010
Number of MAC: 0
Statistics:
  packets: received 0 (unicast 0), sent 0
  bytes: received 0 (unicast 0), sent 0
  MAC move: 0
Storm control drop counters:
  packets: broadcast 0, multicast 0, unknown unicast 0
  bytes: broadcast 0, multicast 0, unknown unicast 0

```

The following sample outputs shows the backup pseudowire information:

```

RP/0/RP0/CPU0:router#show l2vpn forwarding detail location 0/2/CPU0
Local interface: GigabitEthernet0/2/0/0.1, Xconnect id: 0x3000001, Status: up
Segment 1
  AC, GigabitEthernet0/2/0/0.1, Ethernet VLAN mode, status: Bound
  RG-ID 1, active
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0
Segment 2
  MPLS, Destination address: 101.101.101.101, pw-id: 1000, status: Bound
  Pseudowire label: 16000
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0
Backup PW
  MPLS, Destination address: 102.102.102.102, pw-id: 1000, status: Bound
  Pseudowire label: 16001
  Statistics:

```

show l2vpn forwarding

```

packets: received 0, sent 0
bytes: received 0, sent 0

```

```

RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain detail location 0/2/CPU0
Bridge-domain name: bg1:bd1, id: 0, state: up

```

```

...
GigabitEthernet0/2/0/0.4, state: oper up
  RG-ID 1, active
  Number of MAC: 0
  ....

```

```

Nbor 101.101.101.101 pw-id 5000
  Backup Nbor 101.101.101.101 pw-id 5000
  Number of MAC: 0

```

```

...

```

```

RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain detail location 0/2/CPU0
Bridge-domain name: bg1:bd1, id: 0, state: up

```

```

...
GigabitEthernet0/2/0/0.4, state: oper up
XC ID: 0x1880002
Number of MAC: 0
Statistics:

```

```

packets: received 0 (multicast 0, broadcast 0, unknown unicast 0, unicast 0), sent 963770
bytes: received 0 (multicast 0, broadcast 0, unknown unicast 0, unicast 0), sent 263433178
MAC move: 0

```

```

Storm control drop counters:
packets: broadcast 0, multicast 0, unknown unicast 0
bytes: broadcast 0, multicast 0, unknown unicast 0
Dynamic arp inspection drop counters:
packets: 0, bytes: 0
IP source guard drop counters:
packets: 0, bytes: 0

```

```

...

```

The following sample outputs displays the SPAN segment information of the xconnect:

```

RP/0/RP0/CPU0:router# show l2vpn forwarding counter location 0/7/CPU0
Legend: ST = State, DN = Down

```

Segment 1	Segment 2	ST	Byte	Switched
pw-span-test (Monitor-Session) mpls	2.2.2.2	UP	0	

```

RP/0/RP0/CPU0:router #Show l2vpn forwarding monitor-session location 0/7/CPU0
Segment 1          Segment 2          State
-----
pw-span-test(monitor-session) mpls    2.2.2.2          UP
pw-span-sess(monitor-session) mpls    3.3.3.3          UP

```

```

RP/0/RP0/CPU0:router #Show l2vpn forwarding monitor-session pw-span-test location 0/7/CPU0
Segment 1          Segment 2          State
-----
pw-span-test(Monitor-Session) mpls    2.2.2.2          UP

```

Example 4:

```
RP/0/RP0/CPU0:router #show l2vpn forwarding detail location 0/7/CPU0
Xconnect id: 0xc000001, Status: up
Segment 1
  Monitor-Session, pw-span-test, status: Bound
Segment 2
  MPLS, Destination address: 2.2.2.2, pw-id: 1, status: Bound
  Pseudowire label: 16001
Statistics:
  packets: received 0, sent 11799730
  bytes: received 0, sent 707983800
```

Example 5:

```
show l2vpn forwarding private location 0/11/CPU0
Xconnect ID 0xc000001
Xconnect info:
  Base info: version=0xaabbcc13, flags=0x0, type=2, reserved=0
  xcon_bound=TRUE, switching_type=0, data_type=3

AC info:
  Base info: version=0xaabbcc11, flags=0x0, type=3, reserved=0
  xcon_id=0xc000001, ifh= none, subifh= none, ac_id=0, ac_type=SPAN,
  ac_mtu=1500, iw_mode=none, adj_valid=FALSE, adj_addr none

PW info:
  Base info: version=0xaabbcc12, flags=0x0, type=4, reserved=0
  pw_id=1, nh_valid=TRUE, sig_cap_flags=0x20, context=0x0,
  MPLS, pw_label=16001
Statistics:
  packets: received 0, sent 11799730
  bytes: received 0, sent 707983800

Object: NHOP
Event Trace History [Total events: 5]
-----
      Time          Event          Flags
      ====          =====          =====
-----

Nextthop info:
  Base info: version=0xaabbcc14, flags=0x10000, type=5, reserved=0
  nh_addr=2.2.2.2, plat_data_valid=TRUE, plat_data_len=128, child_count=1

Object: XCON
Event Trace History [Total events: 16]
-----
      Time          Event          Flags
      ====          =====          =====
-----

RP/0/RP0/CPU0:router #show l2vpn forwarding summary location 0/7/CPU0
Major version num:1, minor version num:0
Shared memory timestamp:0x31333944cf
Number of forwarding xconnect entries:2
  Up:2  Down:0
  AC-PW:1 (1 mpls)  AC-AC:0  AC-BP:0  AC-Unknown:0
  PW-BP:0  PW-Unknown:0  Monitor-Session-PW:1
Number of xconnects down due to:
  AIB:0  L2VPN:0  L3FIB:0
Number of p2p xconnects: 2
Number of bridge-port xconnects: 0
```

```

Number of nexthops:1
  MPLS:   Bound:1 Unbound:0 Pending Registration:0
Number of bridge-domains: 0
Number of static macs: 0
Number of locally learned macs: 0
Number of remotely learned macs: 0
Number of total macs: 0

```

The following sample output is from the **show l2vpn forwarding** command:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding location 0/2/cpu0
```

```

ID   Segment 1           Segment 2
-----
1   Gi0/2/0/0 1         1.1.1.1 9)

```

The following sample output shows the MAC information in the layer2_fib manager summary:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding summary location 0/3/CPU0
```

```

Major version num:1, minor version num:0
Shared memory timestamp:0x66ff58e894
Number of forwarding xconnect entries:2
  Up:1 Down:0
  AC-PW:0 AC-AC:0 AC-BP:1 PW-BP:1
Number of xconnects down due to:
  AIB:0 L2VPN:0 L3FIB:0
Number of nexthops:1
Number of static macs: 5
Number of locally learned macs: 5
Number of remotely learned macs: 0
Number of total macs: 10

```

This example shows the sample output of a configured flow label:

```
RP/0/RP0/CPU0:router# show l2vpn for 0/0/cpu0
```

```

Local interface: GigabitEthernet0/0/1/1, Xconnect id: 0x1000002, Status: up
Segment 1
  AC, GigabitEthernet0/0/1/1, Ethernet port mode, status: Bound

Segment 2
  MPLS, Destination address: 3.3.3.3, pw-id: 2, status: Bound, Active
  Pseudowire label: 16004 Control word disabled
  Backup PW
    MPLS, Destination address: 2.2.2.2, pw-id: 6, status: Bound
    Pseudowire label: 16000
    Flow label enabled

  Xconnect id: 0xff000014, Status: down
Segment 1
  MPLS, Destination address: 2.2.2.2, pw-id: 1, status: Not bound
  Pseudowire label: UNKNOWN Control word disabled
  Flow label enabled

Segment 2
  Bridge id: 0, Split horizon group id: 0
  Storm control: disabled
  MAC learning: enabled
  MAC port down flush: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog

```

```

MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node, disabled
IGMP snooping profile: profile not known on this node
Router guard disabled

```

Related Commands	Command	Description
	clear l2vpn forwarding counters, on page 19	Clears L2VPN forwarding counters.

show l2vpn forwarding l2tp

To display L2VPN forwarding information, use the **show l2vpn forwarding l2tp** command in EXEC mode.

show l2vpn forwarding l2tp disposition {*local session id session-ID* | **hardware** | **location node-id**}
location node-id

Syntax Description	disposition
	Displays forwarding disposition information.
	<i>session-ID</i> Displays L2TPv3-related forwarding information for the specified local session ID. Range is 1-4294967295.
	hardware Displays L2TPv3-related forwarding information read from hardware.
	location Displays L2TPv3-related forwarding information for the specified location.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following example shows sample output for the **show l2vpn forwarding l2tp** command:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding l2tp disposition hardware location 0/3/1
```

show l2vpn generic-interface-list

```

ID      Segment 1          Segment 2
-----
1      Gi0/2/0/0 1        1.1.1.1 9)

```

Related Commands	Command	Description
	clear l2vpn forwarding counters, on page 19	Clears L2VPN forwarding counters.

show l2vpn generic-interface-list

To display all the L2VPN virtual interfaces, use the **show l2vpn generic-interface-list** command in EXEC mode.

show l2vpn generic-interface-list {**detail** | **name** | **private** | **summary**}

Syntax Description	Parameter	Description
	detail	Specifies the details of the interface.
	name	Specifies the name of the interface.
	private	Specifies the private details of the interface.
	summary	Specifies the summary information of the interface.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples

This example shows the sample output of the **show l2vpn generic-interface-list** command:

```

RP/0/RP0/CPU0:router# show l2vpn generic-interface-list
generic-interface-list: l1 (ID: 2, interfaces: 2) Number of items: 20
generic-interface-list: l2 (ID: 3, interfaces: 4) Number of items: 15

```

This example shows the sample output of the **show l2vpn generic-interface-list detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn generic-interface-list detail
generic-interface-list: 11 (ID: 2, interfaces: 2)
  GigabitEthernet0/1/0/0 - items pending 2
  GigabitEthernet0/1/0/1 - items pending 4
  Number of items: 27
  PW-Ether: 1-10, 12-21
  PW-IW: 1-7

generic-interface-list: 12 (ID: 3, interfaces: 4)
  GigabitEthernet0/1/0/0 - items pending 2
  GigabitEthernet0/1/0/1 - items pending 4
  GigabitEthernet0/1/0/2 - items pending 1
  GigabitEthernet0/1/0/3 - items pending 0
  Number of items: 20
  PW-Ether: 1-15
  PW-IW: 1-7
```

This example shows the sample output of the **show l2vpn generic-interface-list name | detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn generic-interface-list name 11 detail
generic-interface-list: 11 (ID: 2, interfaces: 2)
  GigabitEthernet0/1/0/0 - items pending 2
  GigabitEthernet0/1/0/1 - items pending 4
  Number of items: 20
  PW-Ether 1-10, 12-21
```

show l2vpn index

To display statistics about the index manager, use the **show l2vpn index** command in EXEC mode.

```
show l2vpn index [{location | private | standby}]
```

Syntax Description	location	(Optional) Displays index manager statistics for the specified location.
	private	(Optional) Detailed information about all indexes allocated for each pool.
	standby	(Optional) Displays Standby node specific information.
Command Default	None	
Command Modes	EXEC	
Command History	Release	Modification
	Release 4.2.1	This command was introduced.

Release	Modification
Release 4.3.0	The following keywords are introduced: <ul style="list-style-type: none"> • location • standby

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
l2vpn	read

Examples

This example shows the sample output of the **show l2vpn index** command:

```
RP/0/RP0/CPU0:router# show l2vpn index
Pool id: 0x4, App: RD
Pool size: 32767
zombied IDs: 0
allocated IDs: 0

Pool id: 0x5, App: IFLIST
Pool size: 65535
zombied IDs: 0
allocated IDs: 2

Pool id: 0xff000001, App: PW/PBB/Virtual AC
Pool size: 40960
zombied IDs: 0
allocated IDs: 1

Pool id: 0xff000002, App: BD
Pool size: 4095
zombied IDs: 0
allocated IDs: 2

Pool id: 0xff000003, App: MP2MP
Pool size: 65535
zombied IDs: 0
allocated IDs: 1
```

This example shows the sample output of the **show l2vpn index standby** command:

```
RP/0/RP0/CPU0:router# show l2vpn index standby
Pool id: 0xffffc0000, App: Global
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 98304
zombied IDs: 0
allocated IDs: 0

Pool id: 0xffffc0002, App: BD
Max number of ID mgr instances: 1
```

```

ID mgr instances in use: 1
Pool size: 8192
zombied IDs: 0
allocated IDs: 0

Pool id: 0xffffc0003, App: MP2MP
Max number of ID mgr instances: 1
ID mgr instances in use: 1
Pool size: 65535
zombied IDs: 0
allocated IDs: 0

```

show l2vpn nsr

To display the status of l2vpn non-stop routing, use the **show l2vpn nsr** command in EXEC mode.

```
show l2vpn nsr [{location | standby}]
```

Syntax Description	location (Optional) Displays non-stop routing information for the specified location.				
	standby (Optional) Displays Standby node specific information.				
Command Default	None				
Command Modes	EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.3.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.3.0	This command was introduced.
Release	Modification				
Release 4.3.0	This command was introduced.				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operation	l2vpn	read
Task ID	Operation				
l2vpn	read				

The following example displays output for the **show l2vpn nsr** command:

```

RP/0/RP0/CPU0:router# show l2vpn nsr

Mon May 30 19:32:01.045 UTC
L2VPN NSR information
NSR Status:
NSR Ready                : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Last NSR Withdraw Time  : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Standby Connected       : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
IDT Done                : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Number of XIDs sent     : Virtual AC: 0

```

```

AC          : 1
PW          : 1
BD          : 0
MP2MP      : 0
RD          : 0
PBB        : 0
IFLIST     : 0
ATOM       : 1
Global     : 0
PWGroup    : 0
EVPN       : 0

```

Related Commands	Command	Description
	l2vpn, on page 34	Enters L2VPN configuration mode.
	#unique_68	

show l2vpn provision queue

To display L2VPN configuration provisioning queue information, use the **show l2vpn provision queue** command in EXEC mode.

show l2vpn provision queue [{location | standby}]

Syntax Description	location	standby
	(Optional) Displays L2VPN configuration provisioning queue information for the specified location.	(Optional) Displays Standby node specific information.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

The following example displays output for the **show l2vpn provision queue** command:

```
RP/0/RP0/CPU0:router# show l2vpn provision queue
```

```
Legend: P/P/R = Priority/Provisioned/Require Provisioning.
Configuration Item      Object Type      Class      P/P/R Object
Key
-----
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS01
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS02
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS03
```

The following example displays output for the **show l2vpn provision queue standby** command:

```
RP/0/RP0/CPU0:router# show l2vpn provision queue standby
```

```
Legend: P/P/R = Priority/Provisioned/Require Provisioning.
Configuration Item      Object Type      Class      P/P/R Object
Key
-----
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS01
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS02
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS03
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS04
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS05
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS06
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS07
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS08
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS09
BD_NAME                bd_t            vpls_bd_class  0/0/0 BD
VPLS010
```

Related Commands	Command	Description
	l2vpn , on page 34	Enters L2VPN configuration mode.

show l2vpn pw-class

To display L2VPN pseudowire class information, use the **show l2vpn pw-class** command in EXEC mode.

```
show l2vpn pw-class [{detail | location | name class name | standby}]
```

Syntax Description	detail	(Optional) Displays detailed information.
	location	(Optional) Displays location specific information.

name <i>class-name</i>	(Optional) Displays information about a specific pseudowire class name.
standby	(Optional) Displays standby node specific information.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.5.0	This command was introduced.
	Release 4.3.0	The keywords location and standby were introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following example shows sample output for the **show l2vpn pw-class** command:

```
RP/0/RP0/CPU0:router# show l2vpn pw-class

Name                               Encapsulation   Protocol
-----                               -
```

mplsclass_75	MPLS	LDP
l2tp-dynamic	L2TPv3	L2TPv3

This example shows sample output for the **show l2vpn pw-class detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn pw-class detail
Encapsulation MPLS, protocol LDP
Transport mode not set, control word unset (default)
Sequencing not set
Static tag rewrite not set
PW Backup disable delay: 0 sec
MAC withdraw message is sent over PW: no
IPv4 source address 1.1.1.1
```

This table describes the significant fields shown in the display.

Table 6: show l2vpn pw-class Command Field Descriptions

Field	Description
Name	Displays the name of the pseudowire class.
Encapsulation	Displays the encapsulation type.

Field	Description
Protocol	Displays the protocol type.

Related Commands	Command	Description
	clear l2vpn forwarding counters, on page 19	Clears L2VPN forwarding counters.

show l2vpn pwhe

To display the pseudowire headend (PWHE) information, use the **show l2vpn pwhe** command in EXEC mode.

show l2vpn pwhe {**detail** | **interface** | **summary**}

Syntax Description	Field	Description
	detail	Specifies the details of the interface.
	interface	Specifies the name of the interface.
	summary	Specifies the summary information of the interface.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.2.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples

This example show the sample output for **show l2vpn pwhe detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn pwhe detail
Interface: PW-Ether1   Interface State: Down, Admin state: Up
  Interface handle 0x20000070
  MTU: 1514
  BW: 10000 Kbit
  Interface MAC addresses: 0279.96e9.8205
```

show l2vpn resource

```

Label: 16000
L2-overhead: 0
VC-type: 5
CW: N
Generic-interface-list: ifl1 (id: 1)
  Gi0/2/0/1, in bundle BE3, state: Up, replication: success
  Gi0/2/0/0, in bundle BE5, state: Up, replication: success
  Gi0/2/0/2, in bundle BE5, state: Up, replication: success
  Gi0/2/0/3, state: Up, replication: success

Interface: PW-IW1   Interface State: Up, Admin state: Up
Interface handle 0x20000070
MTU: 1514
BW: 10000 Kbit
VC-type: 11
CW: N
Generic-interface-list: ifl2 (id: 2)
  Gi0/3/0/1, in bundle BE6, state: Up, replication: success
  Gi0/3/0/0, in bundle BE6, state: Up, replication: success
  Gi0/3/0/2, state: Up, replication: success
  Gi0/3/0/3, state: Up, replication: success

```

This example show the sample output for **show l2vpn pwhe summary** command:

```

RP/0/RP0/CPU0:router# show l2vpn pwhe summary
Number of PW-HE interface: 1600
Up: 1300 Down: 300 Admindown: 0
Number of PW-Ether interfaces: 900
Up: 700 Down: 200 Admindown: 0
Number of PW-IW interfaces: 700
Up: 600 Down: 100 Admindown: 0

```

show l2vpn resource

To display the memory state in the L2VPN process, use the **show l2vpn resource** command in EXEC mode.

show l2vpn resource

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	EXEC
----------------------	------

Command History	Release	Modification
	Release 3.4.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following example shows sample output for the **show l2vpn resource** command:

```
RP/0/RP0/CPU0:router# show l2vpn resource
```

```
Memory: Normal
```

describes the significant fields shown in the display. [Table 7: show l2vpn resource Command Field Descriptions, on page 87](#)

Table 7: show l2vpn resource Command Field Descriptions

Field	Description
Memory	Displays memory status.

show l2vpn trace

To display trace data for L2VPN, use the **show l2vpn trace** command in EXEC mode.

```
show l2vpn trace [{checker|file|hexdump|last|location|reverse|stats|tailf|unique|usec|verbose|wide|wrapping}]
```

Syntax Description	Field	Description
	checker	Displays trace data for the L2VPN Uberverifier.
	file	Displays trace data for the specified file.
	hexdump	Display traces data in hexadecimal format.
	last	Display last <n> entries
	location	Displays trace data for the specified location.
	reverse	Display latest traces first
	stats	Display trace statistics
	tailf	Display new traces as they are added
	unique	Display unique entries with counts
	usec	Display usec details with timestamp
	verbose	Display internal debugging information
	wide	Display trace data excluding buffer name, node name, tid

wrapping Display wrapping entries

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 4.3.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operation
	l2vpn	read

This example displays output for the **show l2vpn trace** command:

```
RP/0/RP0/CPU0:router# show l2vpn trace
 310 unique entries (1775 possible, 0 filtered)
 Jul 27 14:39:51.786 l2vpn/fwd-detail 0/RSP0/CPU0 2# t1 FWD_DETAIL:415: l2tp session
table rebuilt
 Jul 27 14:39:52.106 l2vpn/issu 0/RSP0/CPU0 1# t1 ISSU:788: ISSU - imdr init called;
'infra/imdr' detected the 'informational' condition 'the service is not supported in the
node'
 Jul 27 14:39:52.107 l2vpn/issu 0/RSP0/CPU0 1# t1 ISSU:428: ISSU - attempt to start
COLLABORATOR wait timer while not in ISSU mode
 Jul 27 14:39:54.286 l2vpn/fwd-common 0/RSP0/CPU0 1# t1 FWD_COMMON:3257: show edm thread
initialized
 Jul 27 14:39:55.270 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC|ERR:783: Mac aging init
 Jul 27 14:39:55.286 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:1765: l2vpn_gsp_cons_init
returned No error
 Jul 27 14:39:55.340 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:1792: Client successfully
joined gsp group
 Jul 27 14:39:55.340 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:779: Initializing the
txlist IPC thread
 Jul 27 14:39:55.341 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:2971: gsp_optimal_msg_size
= 4832 (real: True)
 Jul 27 14:39:55.351 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:626: Entering mac aging
timer init
```

show l2vpn xconnect

To display brief information on configured cross-connects, use the **show l2vpn xconnect** command in EXEC mode.

```
show l2vpn xconnect [{brief | detail | encapsulation | group | groups | interface | location | mp2mp |
mspaw | neighbor | pw-class | standby | state | summary | type | state unresolved | pw-id value}]
```

Syntax Description	
brief	(Optional) Displays encapsulation brief information.
detail	(Optional) Displays detailed information.
<i>encapsulation</i>	(Optional) Filters on encapsulation type.
group	(Optional) Displays all cross-connects in a specified group.
groups	(Optional) Displays all groups information.
interface	(Optional) Filters the interface and subinterface.
location	(Optional) Displays location specific information.
mp2mp	(Optional) Displays MP2MP information.
mspaw	(Optional) Displays ms_pw information.
neighbor	(Optional) Filters the neighbor.
pw-class	(Optional) Filters on pseudowire class
standby	(Optional) Displays standby node specific information.
state	(Optional) Filters the following xconnect state types: <ul style="list-style-type: none"> • up • down
summary	(Optional) Displays AC information from the AC Manager database.
type	(Optional) Filters the following xconnect types: <ul style="list-style-type: none"> • ac-pw • locally switched
state unresolved	(Optional) Displays information about unresolved cross-connects.
pw-id value	Displays the filter for the pseudowire ID. The range is from 1 to 4294967295.
Command Default	None
Command Modes	EXEC

Command History

Release	Modification
Release 3.4.0	This command was introduced.
Release 3.4.1	VCCV-related show command output was added.
Release 3.6.0	Preferred-path-related show command output was added.
Release 3.7.0	Sample output was updated to display the backup pseudowire information.
Release 4.3.0	The following keywords were introduced: <ul style="list-style-type: none"> • brief • encapsulation • groups • location • mp2mp • mspw • pw-class • standby
Release 5.1.2	This command was modified to enable filtering the command output for a specific pseudowire with just the pseudowire ID.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If a specific cross-connect is specified in the command (for instance, AC_to_PW1) then only that cross-connect will be displayed; otherwise, all cross-connects are displayed.

When configuring Ethernet Connectivity Fault Management (CFM) over l2vpn cross-connect, the CFM Continuity Check Messages (CCM) packets are not accounted for in the cross-connect pseudowire packet counters displayed in this show command output.



Note For Cisco IOS XR software Release 5.1.2 and above, you can filter the command output for specific pseudowire with just the pseudowire ID. However, for pseudowire configurations with FEC 129 Type 2 (in VPWS), filtering the output for a specific pseudowire can only be done with the combination of the neighbour filter and the pseudowire ID.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows sample output for the **show l2vpn xconnect** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect
Wed May 21 09:06:47.944 UTC
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
        SB = Standby, SR = Standby Ready, (PP) = Partially Programmed
```

XConnect Group	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
L2TPV3_V4_XC_GRP	L2TPV3_P2P_1	UP	Gi0/2/0/1.2	UP	26.26.26.26 100	UP
L2TPV3_V4_XC_GRP	L2TPV3_P2P_2	UP	Gi0/2/0/1.3	UP	26.26.26.26 200	UP

The following sample output shows that the backup is in standby mode for the **show l2vpn xconnect detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect detail

Group siva_xc, XC siva_p2p, state is up; Interworking none
Monitor-Session: pw-span-test, state is configured
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 90
    byte totals: send 19056
PW: neighbor 10.1.1.1, PW ID 1, state is up ( established )
  PW class not set, XC ID 0x5000001
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word enabled, interworking none
  PW backup disable delay 0 sec
  Sequencing not set
    MPLS          Local          Remote
    -----
  Label          30005          16003
  Group ID       0x5000300      0x5000400
  Interface      GigabitEthernet0/4/0/1  GigabitEthernet0/4/0/2
  Interface      pw-span-test        GigabitEthernet0/3/0/1
  MTU            1500             1500
  Control word   enabled           enabled
  PW type        Ethernet         Ethernet
  VCCV CV type  0x2              0x2
                  (LSP ping verification)  (LSP ping verification)
  VCCV CC type  0x3              0x3
                  (control word)           (control word)
                  (router alert label)    (router alert label)
    -----
  Create time: 20/11/2007 21:45:07 (00:49:18 ago)
  Last time status changed: 20/11/2007 21:45:11 (00:49:14 ago)
  Statistics:
    packet totals: receive 0
    byte totals: receive 0

Backup PW:
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )
  Backup for neighbor 1.1.1.1 PW ID 1 ( standby )
```

```

PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS          Local          Remote
-----
Label          30006          16003
Group ID       unassigned     0x5000400
Interface      unknown       GigabitEthernet0/4/0/2
MTU            1500         1500
Control word   enabled       enabled
PW type        Ethernet     Ethernet
VCCV CV type  0x2          0x2
                (LSP ping verification)  (LSP ping verification)
VCCV CC type  0x3          0x3
                (control word)         (control word)
                (router alert label) (router alert label)
-----
Backup PW for neighbor 10.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:45 (00:48:40 ago)
Last time status changed: 20/11/2007 21:45:49 (00:48:36 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

The following sample output shows that the backup is active for the **show l2vpn xconnect detail** command:

```

RP/0/RP0/CPU0:router# show l2vpn xconnect detail

Group siva_xc, XC siva_p2p, state is down; Interworking none
Monitor-Session: pw-span-test, state is configured
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 98
    byte totals: send 20798
PW: neighbor 10.1.1.1, PW ID 1, state is down ( local ready )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS          Local          Remote
-----
Label          30005          unknown
Group ID       0x5000300     0x0
Interface      GigabitEthernet0/4/0/1  unknown
                pw-span-test          GigabitEthernet0/3/0/1
MTU            1500         unknown
Control word   enabled       unknown
PW type        Ethernet     unknown
VCCV CV type  0x2          0x0
                (LSP ping verification)  (none)
VCCV CC type  0x3          0x0
                (control word)         (none)
                (router alert label)
-----
Create time: 20/11/2007 21:45:06 (00:53:31 ago)
Last time status changed: 20/11/2007 22:38:14 (00:00:23 ago)

```

```

Statistics:
  packet totals: receive 0
  byte totals: receive 0

Backup PW:
PW: neighbor 10.2.2.2, PW ID 2, state is up ( established )
Backup for neighbor 10.1.1.1 PW ID 1 ( active )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

```

MPLS	Local	Remote
Label	30006	16003
Group ID	unassigned	0x5000400
Interface	unknown	GigabitEthernet0/4/0/2
MTU	1500	1500
Control word	enabled	enabled
PW type	Ethernet	Ethernet
VCCV CV type	0x2	0x2
	(LSP ping verification)	(LSP ping verification)
VCCV CC type	0x3	0x3
	(control word)	(control word)
	(router alert label)	(router alert label)

```

Backup PW for neighbor 10.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:44 (00:52:54 ago)
Last time status changed: 20/11/2007 21:45:48 (00:52:49 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

The following sample output displays the xconnects with switch port analyzer (SPAN) as one of the segments:

```

Show l2vpn xconnect type minotor-session-pw
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
        LU = Local Up, RU = Remote Up, CO = Connected

```

XConnect Group	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
g1	x1	UP	pw-span-test	UP	2.2.2.2 1	UP

The following sample output shows that one-way redundancy is enabled:

```

Group g1, XC x2, state is up; Interworking none
AC: GigabitEthernet0/2/0/0.2, state is up, active in RG-ID 1
Type VLAN; Num Ranges: 1
VLAN ranges: [2, 2]
MTU 1500; XC ID 0x3000002; interworking none
Statistics:
  packets: received 103, sent 103
  bytes: received 7348, sent 7348
  drops: illegal VLAN 0, illegal length 0
PW: neighbor 101.101.101.101, PW ID 2000, state is up ( established )
PW class class1, XC ID 0x3000002
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
PW backup disable delay 0 sec
One-way PW redundancy mode is enabled

```

show l2vpn xconnect

```

Sequencing not set
....
Incoming Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message
Outgoing Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message
....
Backup PW:
PW: neighbor 102.102.102.102, PW ID 3000, state is standby ( all ready )
Backup for neighbor 101.101.101.101 PW ID 2000 ( inactive )
PW class class1, XC ID 0x3000002
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
Sequencing not set
....
Incoming Status (PW Status TLV):
  Status code: 0x26 (Standby, AC Down) in Notification message
Outgoing Status (PW Status TLV):
  Status code: 0x0 (Up) in Notification message

```

The following example shows sample output for the **show l2vpn xconnect** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect
```

```
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,
        LU = Local Up, RU = Remote Up, CO = Connected
```

XConnect Group	Name	ST	Segment 1 Description	ST	Segment 2 Description	ST
siva_xc	siva_p2p	UP	Gi0/4/0/1	UP	1.1.1.1 1	UP
					Backup 2.2.2.2 2	UP

The following sample output shows that the backup is in standby mode for the **show l2vpn xconnect detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect detail
```

```

Group siva_xc, XC siva_p2p, state is up; Interworking none
AC: GigabitEthernet0/4/0/1, state is up
Type Ethernet
MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
Statistics:
  packet totals: received 90, sent 90
  byte totals: received 19056, sent 19056
PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

```

MPLS	Local	Remote
Label	30005	16003
Group ID	0x5000300	0x5000400
Interface	GigabitEthernet0/4/0/1	GigabitEthernet0/4/0/2
MTU	1500	1500
Control word	enabled	enabled
PW type	Ethernet	Ethernet
VCCV CV type	0x2	0x2
	(LSP ping verification)	(LSP ping verification)

```

VCCV CC type 0x3                                0x3
              (control word)                    (control word)
              (router alert label)              (router alert label)
-----
Create time: 20/11/2007 21:45:07 (00:49:18 ago)
Last time status changed: 20/11/2007 21:45:11 (00:49:14 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

Backup PW:
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )
Backup for neighbor 1.1.1.1 PW ID 1 ( standby )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS          Local                                Remote
-----
Label          30006                                16003
Group ID       unassigned                          0x5000400
Interface      unknown                            GigabitEthernet0/4/0/2
MTU            1500
Control word   enabled
PW type        Ethernet
VCCV CV type  0x2                                0x2
              (LSP ping verification)          (LSP ping verification)
VCCV CC type  0x3                                0x3
              (control word)                    (control word)
              (router alert label)              (router alert label)
-----
Backup PW for neighbor 1.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:45 (00:48:40 ago)
Last time status changed: 20/11/2007 21:45:49 (00:48:36 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

The following sample output shows that the backup is active for the **show l2vpn xconnect detail** command:

```

RP/0/RP0/CPU0:router# show l2vpn xconnect detail

Group siva_xc, XC siva_p2p, state is down; Interworking none
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 98
    byte totals: send 20798
PW: neighbor 1.1.1.1, PW ID 1, state is down ( local ready )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS          Local                                Remote
-----
Label          30005                                unknown
Group ID       0x5000300                            0x0
Interface      GigabitEthernet0/4/0/1                unknown
MTU            1500
Control word   enabled

```

show l2vpn xconnect

```

PW type      Ethernet      unknown
VCCV CV type 0x2          0x0
                                   (none)
                                   (LSP ping verification)
VCCV CC type 0x3          0x0
                                   (none)
                                   (control word)
                                   (router alert label)
-----
Create time: 20/11/2007 21:45:06 (00:53:31 ago)
Last time status changed: 20/11/2007 22:38:14 (00:00:23 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

Backup PW:
PW: neighbor 2.2.2.2, PW ID 2, state is up ( established )
Backup for neighbor 1.1.1.1 PW ID 1 ( active )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS      Local      Remote
-----
Label      30006      16003
Group ID   unassigned  0x5000400
Interface  unknown    GigabitEthernet0/4/0/2
MTU        1500      1500
Control word enabled  enabled
PW type    Ethernet  Ethernet
VCCV CV type 0x2      0x2
                                   (LSP ping verification)  (LSP ping verification)
VCCV CC type 0x3      0x3
                                   (control word)          (control word)
                                   (router alert label)    (router alert label)
-----
Backup PW for neighbor 1.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:44 (00:52:54 ago)
Last time status changed: 20/11/2007 21:45:48 (00:52:49 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

This example shows that the PW type changes to Ethernet, which is Virtual Circuit (VC) type 5, on the interface when a double tag rewrite option is used.

```
RP/0/RP0/CPU0:router# show l2vpn xconnect pw-class pw-class1 detail
```

```

Group VPWS, XC ac3, state is up; Interworking none
AC: GigabitEthernet0/7/0/5.3, state is up
Type VLAN; Num Ranges: 1
VLAN ranges: [12, 12]
MTU 1508; XC ID 0x2440096; interworking none
Statistics:
packets: received 26392092, sent 1336
bytes: received 1583525520, sent 297928
drops: illegal VLAN 0, illegal length 0
PW: neighbor 3.3.3.3, PW ID 3, state is up ( established )
PW class VPWS1, XC ID 0x2440096
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec

```

Sequencing not set

Preferred path tunnel TE 3, fallback disabled

PW Status TLV in use

MPLS	Local	Remote
Label	16147	21355
Group ID	0x120001c0	0x120001c0
Interface	GigabitEthernet0/7/0/5.3	GigabitEthernet0/7/0/5.3
MTU	1508	1508
Control word	disabled	disabled
PW type	Ethernet	Ethernet
VCCV CV type	0x2	0x2
	(LSP ping verification)	(LSP ping verification)
VCCV CC type	0x6	0x6
	(router alert label)	(router alert label)
	(TTL expiry)	(TTL expiry)

Incoming Status (PW Status TLV):

Status code: 0x0 (Up) in Notification message

Outgoing Status (PW Status TLV):

Status code: 0x0 (Up) in Notification message

MIB cpwVcIndex: 4294705365

Create time: 21/09/2011 08:05:01 (00:14:01 ago)

Last time status changed: 21/09/2011 08:07:01 (00:12:01 ago)

Statistics:

packets: received 1336, sent 26392092

bytes: received 297928, sent 1583525520

This example shows the sample output of a pseudowire headend (PWHE) cross connect:

RP/0/RP0/CPU0:router# **show l2vpn xconnect interface pw-ether 67 detail**

Group g1, XC xc1, state is down; Interworking none

AC:PW-Ether1, state is up

Type PW-Ether

Interface-list: interfacelist1

Replicate status:

Gi0/2/0/1: success

Gi0/3/0/1: pending

Gi0/4/0/1: failed

MTU 1500; interworking none

Statistics:

packets: received 0, sent 0

bytes: received 0, sent 0

PW: neighbor 130.130.130.130, PW ID 1234, state is down (provisioned)

PW class not set

Encapsulation MPLS, protocol LDP

PW type Ethernet VLAN, control word disabled, interworking none

Sequencing not set

Internal label: 16008

VLAN id imposed: 101

MPLS	Local	Remote
Label	16001	unknown
Group ID	0x2000600	0x0
Interface	PW-Ether1	unknown
MTU	1500	unknown
Control word	disabled	unknown
PW type	Ethernet VLAN	unknown
VCCV CV type	0x2	0x0
	(LSP ping verification)	(none)

```

VCCV CC type 0x6                                0x0
                                                (none)
                (router alert label)
                (TTL expiry)
-----
MIB cpwVcIndex: 2
Create time: 19/02/2010 23:13:01 (1w2d ago)
Last time status changed: 19/02/2010 23:13:16 (1w2d ago)
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

```

This example shows the sample output of a configured flow label:

```

RP/0/RP0/CPU0:router# show l2vpn xconnect detail
Group g1, XC pl, state is up; Interworking none
AC: GigabitEthernet0/0/1/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x1000002; interworking none
  Statistics:
    packets: received 24688, sent 24686
    bytes: received 1488097, sent 1487926
PW: neighbor 3.3.3.3, PW ID 2, state is up ( established )
  PW class class1, XC ID 0x1000002
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word disabled, interworking none
  PW backup disable delay 0 sec
Sequencing not set
Flow label flags configured (Rx=1,Tx=1), negotiated (Rx=0,Tx=1)

```

This table describes the significant fields shown in the display.

Table 8: show l2vpn xconnect Command Field Descriptions

Field	Description
XConnect Group	Displays a list of all configured cross-connect groups.
Group	Displays the cross-connect group number.
Name	Displays the cross-connect group name.
Description	Displays the cross-connect group description. If no description is configured, the interface type is displayed.
ST	State of the cross-connect group: up (UP) or down (DN).

Related Commands

Command	Description
xconnect group, on page 108	Configures cross-connect groups.

show tunnel-template

To display tunnel template information, use the **show tunnel-template** command in the EXEC mode.

show tunnel-template *template-name*

Syntax Description	<i>template-name</i> Name of the tunnel template.				
Command Default	None				
Command Modes	EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.5.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.5.0	This command was introduced.
Release	Modification				
Release 3.5.0	This command was introduced.				
Usage Guidelines					
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>tunnel</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operation	tunnel	read
Task ID	Operation				
tunnel	read				

Example

The following example shows the output of the **show tunnel-template test** command for Local PE Tunnel:

```
RP/0/RP0/CPU0:router# show tunnel-template test
Fri Jan 30 06:22:46.428 UTC

Tunnel template
-----
Name:      test (ifhandle: 0x00080030)
MTU:      1464
TTL:      255
TOS:      0
Tunnel ID: 1
Source:    25.25.25.25
Session ID: 0x1d174108 Cookie: 8 bytes [0x24FD3ADAA4485333] being rolled into
           Session ID: 0x15A86E93 Cookie: 8 bytes [0xF486195660CCD522]
Next Session-id/Cookie rollover happens in 1 minute 49 seconds
Transmit:  14213298 pkts  1250770344 bytes
Cookie Mismatch: 0 pkts
MTU Violation: 0 pkts
```

The following example shows the output of the **show tunnel-template test** command for Remote PE Tunnel:

```
RP/0/RP0/CPU0:router# show tunnel-template test
Fri Jan 30 06:04:29.800 UTC

Tunnel template
-----
Name:      test (ifhandle: 0x00080030)
MTU:      600
TTL:      255
TOS:      0
```

```
Tunnel ID: 1
Source: 35.35.35.35 Address Pool: 36.36.36.0/28
Session ID: 0x111F4312 Cookie: 8 bytes [0xB95A806145BE9BE7]
Transmit: 122168722 pkts 10750845295 bytes
Cookie Mismatch: 0 pkts
MTU Violation: 0 pkts
```

Related Commands	Command	Description
	tunnel-template , on page 107	Enters tunnel-template configuration submode.

storm-control

Storm control on ASR 9000 Series Routers can be applied at the following service attachment points:

- Bridge domain (BD)
- Attachment Circuit (AC)
- Access pseudowire (PW)

To enable storm control on all access circuits (AC) and access pseudowires (PW) in a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain configuration mode. To disable storm control, use the **no** form of this command.

To enable storm control on an access circuit (AC) under a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain access circuit configuration mode. To disable storm control, use the **no** form of this command.

To enable storm control on an access pseudowire (PW) in a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain neighbor configuration mode. To disable storm control, use the **no** form of this command.

```
storm-control {broadcast | multicast | unknown-unicast} {pps pps-value | kbps kbps-value}
no storm-control {broadcast | multicast | unknown-unicast} {pps pps-value | kbps kbps-value}
```

Syntax Description		
	broadcast	Configures storm control for broadcast traffic.
	multicast	Configures storm control for multicast traffic.
	unknown-unicast	Configures storm control for unknown unicast traffic. <ul style="list-style-type: none"> • Storm control does not apply to bridge protocol data unit (BPDU) packets. All BPDU packets are processed as if traffic storm control is not configured. • Storm control does not apply to internal communication and control packets, route updates, SNMP management traffic, Telnet sessions, or any other packets addressed to the router.
	pps <i>pps-value</i>	Configures the packets-per-second (pps) storm control threshold for the specified traffic type. Valid values range from 1 to 160000.

kbps *kbps-value* Configures the storm control in kilo bits per second (kbps). The range is from 64 to 1280000.

Command Default Storm control is disabled by default.

Command Modes l2vpn bridge group bridge-domain access circuit configuration

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

- Usage Guidelines**
- Bridge Protocol Data Unit (BPDU) packets are not filtered through the storm control feature.
 - The traffic storm control monitoring interval is set in the hardware and is not configurable. On Cisco ASR 9000 Series Router, the monitoring interval is always one second.
 - When there is a mix of kbps and pps storm control on bridge or bridge port, the pps value is translated to kbps inside the policer using 1000 bytes per packet as an average.
 - The hardware can only be programmed with a granularity of 8 pps, so values are not divisible by eight. These are rounded to the nearest increment of eight.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example enables storm control thresholds throughout the bridge domain:

```
RP/0/RSP0/CPU0:a9k1# configure
RP/0/RSP0/CPU0:a9k1(config)# l2vpn
RP/0/RSP0/CPU0:a9k1(config-l2vpn)# bridge group BG1
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg)# bridge-domain BD1
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# storm-control unknown-unicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# storm-control multicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# storm-control broadcast pps 100
```

The following example enables storm control thresholds on an access circuit:

```
RP/0/RSP0/CPU0:a9k1# configure
RP/0/RSP0/CPU0:a9k1(config)# l2vpn
RP/0/RSP0/CPU0:a9k1(config-l2vpn)# bridge group BG1
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# bridge-domain BD2
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# interface Bundle-Ether9001.2001
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-ac)# storm-control unknown-unicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-ac)# storm-control multicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-ac)# storm-control broadcast pps 100
```

The following example enables storm control thresholds on an access pseudowire:

```

RP/0/RSP0/CPU0:a9k1# configure
RP/0/RSP0/CPU0:a9k1(config)# l2vpn
RP/0/RSP0/CPU0:a9k1(config-l2vpn)# bridge group BG1
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd) # bridge-domain BD2
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-ac) # neighbor 10.1.1.1 pw-id 20011001
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-pw) # storm-control unknown-unicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-pw) # storm-control multicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-pw) # storm-control broadcast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-pw) # commit

```

Running Configuration

```

l2vpn
bridge group BG1
  bridge-domain BD1
    storm-control unknown-unicast pps 100
    storm-control multicast pps 100
    storm-control broadcast pps 100
  !
  bridge-domain BD2
    interface Bundle-Ether9001.2001
      storm-control unknown-unicast pps 100
      storm-control multicast pps 100
      storm-control broadcast pps 100
    !
    neighbor 10.1.1.1 pw-id 20011001
      storm-control unknown-unicast pps 100
      storm-control multicast pps 100
      storm-control broadcast pps 100
    !
  !
!
end
RP/0/RSP0/CPU0:a9k1(config)#

```

tag-impose

To specify a tag for a VLAN ID configuration, use the **tag-impose** command in l2vpn configuration submode. To remove the tag, use the **no** form of this command.

tag-impose *vlan value*
no tag-impose *vlan value*

Syntax Description	vlan VLAN in tagged mode.
	value Tag value. The range is from 1 to 4094. The default value is 0.
Command Default	None
Command Modes	L2VPN configuration

Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 4.2.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 4.2.1	This command was introduced.
Release	Modification				
Release 4.2.1	This command was introduced.				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	l2vpn	read, write
Task ID	Operations				
l2vpn	read, write				
Examples	<p>This example shows how to specify a tag for a VLAN:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group xc1 RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p grp1 RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.2 pw-id 78 RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# tag-impose vlan 8</pre>				
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>pw-class (L2VPN), on page 44</td> <td>Enters pseudowire class submode to define a pseudowire class template.</td> </tr> </tbody> </table>	Command	Description	pw-class (L2VPN), on page 44	Enters pseudowire class submode to define a pseudowire class template.
Command	Description				
pw-class (L2VPN), on page 44	Enters pseudowire class submode to define a pseudowire class template.				

tag-rewrite

To configure VLAN tag rewrite, use the **tag-rewrite** command in Encapsulation MPLS configuration mode. To disable VLAN tag rewrite, use the **no** form of this command.

```
tag-rewrite ingress vlan vlan-id
no tag-rewrite ingress vlan vlan-id
```

Syntax Description	<table border="1"> <tr> <td>ingress</td> <td>Configures ingress mode.</td> </tr> <tr> <td>vlan</td> <td>Configures VLAN tagged mode</td> </tr> <tr> <td><i>vlan-id</i></td> <td>Specifies the value of the ID of the VLAN.</td> </tr> </table>	ingress	Configures ingress mode.	vlan	Configures VLAN tagged mode	<i>vlan-id</i>	Specifies the value of the ID of the VLAN.
ingress	Configures ingress mode.						
vlan	Configures VLAN tagged mode						
<i>vlan-id</i>	Specifies the value of the ID of the VLAN.						
Command Default	None						
Command Modes	Encapsulation MPLS configuration						

timeout setup (L2TP)

Command History	Release	Modification
	Release 3.6.0	This command was introduced.

Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The tag-rewrite command is applicable only to pseudowires with MPLS encapsulation.</p>
------------------	---

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	<p>The following example shows how to configure preferred-path tunnel settings:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router (config)# l2vpn RP/0/RP0/CPU0:router (config-l2vpn)# pw-class kanata01 RP/0/RP0/CPU0:router (config-l2vpn-pwc)# encapsulation mpls RP/0/RP0/CPU0:router (config-l2vpn-pwc-encap-mpls)# tag-rewrite vlan 2000 RP/0/RP0/CPU0:router (config-l2vpn-pwc-encap-mpls)#</pre>
----------	--

Related Commands	Command	Description
	show l2vpn xconnect, on page 88	Displays brief information on configured cross-connects.

timeout setup (L2TP)

To configure timeout definitions for L2TP session setup, use the **timeout setup** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

timeout setup *seconds*
no timeout setup *seconds*

Syntax Description	<i>seconds</i> Time, in seconds, to setup a control channel. Range is 60 to 6000 seconds. Default is 300 seconds.				
Command Default	<i>seconds</i> : 300				
Command Modes	L2TP class configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.9.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.9.0	This command was introduced.
Release	Modification				
Release 3.9.0	This command was introduced.				

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Task Operations
l2vpn	read, write

Examples

The following example shows how to configure a timeout value for L2TP session setup of 400 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# timeout setup 400
```

Related Commands

Command	Description
authentication (L2TP), on page 10	Enables L2TP authentication for a specified L2TP class name.
hello-interval (L2TP), on page 24	Configures the hello-interval value for L2TP (duration between control channel hello packets).
hidden (L2TP), on page 25	Enables hidden attribute-value pairs (AVPs).
hostname (L2TP), on page 26	Defines the name used in the L2TP hostname AVP.
l2tp-class, on page 28	Enters L2TP class configuration mode where you can define an L2TP signaling template.
password (L2TP), on page 43	Defines the password and password encryption type for control channel authentication.
receive-window (L2TP), on page 52	Configures the receive window size for the L2TP server.
retransmit (L2TP), on page 53	Configures retransmit retry and timeout values.
show l2tp session, on page 59	Displays information about L2TP sessions.
show l2tp tunnel, on page 61	Displays information about L2TP tunnels.

transport mode (L2VPN)

To configure L2VPN pseudowire class transport mode, use the **transport mode** command in L2VPN pseudowire class MPLS encapsulation mode. To disable the L@VPN pseudowire class transport mode configuration, use the **no** form of this command.

```
transport mode {ethernet | vlan }
no transport mode {ethernet | vlan }
```

Syntax Description

ethernet Configures Ethernet port mode.

vlan Configures VLAN tagged mode.

Command Default None

Command Modes L2VPN pseudowire class MPLS encapsulation

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

This example shows how to configure Ethernet transport mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/RP0/CPU0:router(config-l2vpn-pw)# encapsulation mpls
RP/0/RP0/CPU0:router(config-l2vpn-encap-mpls)# transport-mode ethernet
```

Related Commands	Command	Description
	pw-class (L2VPN), on page 44	Enters pseudowire class submode to define a pseudowire class template.

transport mode vlan passthrough

To configure L2VPN bridge domain transport mode, use the **transport mode vlan passthrough** command in L2VPN bridge domain configuration mode. To disable the L2VPN bridge domain transport mode configuration, use the **no** form of this command.

transport mode vlan passthrough
no transport mode vlan passthrough

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes L2VPN bridge domain configuration

Command History	Release	Modification
	Release 4.3.1	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note All L2VPN configurations can be deleted using the **no l2vpn** command.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

This example shows how to configure transport mode vlan passthrough:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group bg1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bd1
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# transport mode vlan passthrough
```

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

tunnel-template

To enter tunnel-template configuration submode, use the **tunnel-template** command in global configuration mode.

tunnel-template *template name*
no tunnel-template *template-name*

Syntax Description *template-name* Configures a name for the tunnel template.

Command Default None

xconnect group

Command Modes Global configuration

Command History

Release	Modification
Release 3.5.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
tunnel	read, write

Examples The following example shows how to enter tunnel-template configuration submode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# tunnel-template template_01
```

Related Commands

Command	Description
xconnect group, on page 108	Configures cross-connect groups.

xconnect group

To configure cross-connect groups, use the **xconnect group** command in L2VPN configuration mode. To return to the default behavior, use the **no** form of this command.

```
xconnect group group-name
no xconnect group group-name
```

Syntax Description *group-name* Configures a cross-connect group name using a free-format 32-character string.

Command Default None

Command Modes L2VPN configuration

Command History

Release	Modification
Release 3.4.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



Note You can configure up to a maximum of 16K cross-connects per box.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to group all cross -connects for customer_atlantic:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group customer_atlantic
```

Related Commands

Command	Description
show l2vpn xconnect, on page 88	Displays brief information on configured cross-connects.



CHAPTER 3

Virtual Private LAN Services Commands

This module describes the commands used to configure, monitor, and troubleshoot Virtual Private LAN Services (VPLS).

For detailed information about virtual private network concepts, configuration tasks, and examples, refer to the *Virtual Private Configuration Guide*.

- [action \(VPLS\)](#), on page 112
- [aging \(VPLS\)](#), on page 113
- [bridge-domain \(VPLS\)](#), on page 114
- [bridge group \(VPLS\)](#), on page 115
- [clear l2vpn bridge-domain \(VPLS\)](#), on page 116
- [flooding disable](#), on page 117
- [interface \(VPLS\)](#), on page 118
- [learning disable \(VPLS\)](#), on page 120
- [limit \(VPLS\)](#), on page 121
- [mac \(VPLS\)](#), on page 122
- [maximum \(VPLS\)](#), on page 123
- [mpls static label \(VPLS\)](#), on page 125
- [mtu \(VPLS\)](#), on page 126
- [neighbor \(VPLS\)](#), on page 127
- [notification \(VPLS\)](#), on page 129
- [port-down flush disable \(VPLS\)](#), on page 130
- [pw-class \(VFI\)](#), on page 132
- [show l2vpn bridge-domain \(VPLS\)](#), on page 133
- [show l2vpn forwarding bridge-domain \(VPLS\)](#), on page 141
- [show l2vpn forwarding bridge-domain mac-address \(VPLS\)](#), on page 156
- [shutdown \(Bridge Domain\)](#), on page 167
- [shutdown \(VFI\)](#), on page 168
- [static-address \(VPLS\)](#), on page 169
- [static-mac-address \(VPLS\)](#), on page 170
- [time \(VPLS\)](#), on page 172
- [type \(VPLS\)](#), on page 173
- [vfi \(VPLS\)](#), on page 174
- [withdraw \(VPLS\)](#), on page 175

action (VPLS)

To configure the bridge behavior when the number of learned MAC addresses reaches the MAC limit configured, use the **action** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

action {**flood** | **no-flood** | **shutdown**}
no action {**flood** | **no-flood** | **shutdown**}

Syntax Description	
flood	Configures the action to flood all unknown unicast packets when the MAC limit is reached. If the action is set to flood, all unknown unicast packets, with unknown destinations addresses, are flooded over the bridge.
no-flood	Configures the action to no-flood so all unknown unicast packets are dropped when the MAC limit is reached. If the action is set to no-flood, all unknown unicast packets, with unknown destination addresses, are dropped.
shutdown	Stops forwarding when the MAC limit is reached. If the action is set to shutdown, all packets are dropped.

Command Default No action is taken when the MAC address limit is reached.

Command Modes L2VPN bridge group bridge domain MAC limit configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **action** command to specify the type of action to be taken when the action is violated.

The configured action has no impact if the MAC limit has not been reached.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to configure the bridge bar to flood all unknown unicast packets when the number of MAC addresses learned by the bridge reaches 10:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router (config)#l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)#bridge group 1
```

```
RP/0/RP0/CPU0:router(config-l2vpn-bg) #bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd) #mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac) #limit
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit) #action flood
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit) #maximum 10
```

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	limit (VPLS), on page 121	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.
	maximum (VPLS), on page 123	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
	notification (VPLS), on page 129	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

aging (VPLS)

To enter the MAC aging configuration submode to set the aging parameters such as time and type, use the **aging** command in L2VPN bridge group bridge domain configuration mode. To return to the default value for all parameters that are attached to this configuration submode, use the **no** form of this command.

```
aging
no aging
```

Syntax Description	This command has no keywords or arguments.				
Command Default	No defaults are attached to this parameter since it is used as a configuration submode. See defaults that are assigned to the time (VPLS), on page 172 and the type (VPLS), on page 173 parameters.				
Command Modes	L2VPN bridge group bridge domain MAC configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.8.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.8.0	This command was introduced.
Release	Modification				
Release 3.8.0	This command was introduced.				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				

Use the **aging** command to enter L2VPN bridge group bridge domain MAC aging configuration mode.

Task ID	Task Operations ID
	l2vpn read, write

Examples

The following example shows how to enter MAC aging configuration submode and to set the MAC aging time to 120 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac)# aging
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac-aging)# time 120
```

Related Commands

Commands	Description
bridge-domain (VPLS), on page 114	Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then assigns network interfaces to the bridge domain.
l2vpn, on page 34	Enters L2VPN configuration mode.
mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.
time (VPLS), on page 172	Configures the maximum aging time.
type (VPLS), on page 173	Configures the type for MAC address aging.

bridge-domain (VPLS)

To establish a bridge domain and to enter L2VPN bridge group bridge domain configuration mode, use the **bridge-domain** command in L2VPN bridge group configuration mode. To return to a single bridge domain, use the **no** form of this command.

```
bridge-domain bridge-domain-name
no bridge-domain bridge-domain-name
```

Syntax Description

bridge-domain-name Name of the bridge domain.

Note The maximum number of characters that can be specified in the bridge domain name is 27.

Command Default The default value is a single bridge domain.

Command Modes L2VPN bridge group configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines Use the **bridge-domain** command to enter L2VPN bridge group bridge domain configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to configure a bridge domain:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)#
```

Related Commands	Command	Description
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.

bridge group (VPLS)

To create a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain, use the **bridge group** command in L2VPN configuration mode. To remove all the bridge domains that are created under this bridge group and to remove all network interfaces that are assigned under this bridge group, use the **no** form of this command.

bridge group *bridge-group-name*
no bridge-group *bridge-group-name*

Syntax Description *bridge-group-name* Number of the bridge group to which the interface belongs.

Command Default No bridge group is created.

Command Modes L2VPN configuration

clear l2vpn bridge-domain (VPLS)

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
	Use the bridge group command to enter L2VPN bridge group configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples	The following example shows that bridge group 1 is assigned:
	<pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)#</pre>

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	l2vpn, on page 34	Enters L2VPN configuration mode.

clear l2vpn bridge-domain (VPLS)

To clear the MAC addresses and to restart the bridge domains on the router, use the **clear l2vpn bridge-domain** command in EXEC mode.

```
clear l2vpn bridge-domain {all | bd-name name | group group}
```

Syntax Description	all	Clears and restarts all the bridge domains on the router.
	bd-name <i>name</i>	Clears and restarts the specified bridge domain. The <i>name</i> argument specifies the name of the bridge-domain.
	group <i>group</i>	Clears and restarts all the bridge domains that are part of the bridge group.

Command Default	None
Command Modes	EXEC

Command History	Release	Modification
	Release 3.8.0	This command was introduced.
Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>This is the method that allows a bridge to forward again after it was put in Shutdown state as a result of exceeding the configured MAC limit.</p>	
Task ID	Task ID	Operations
	l2vpn	read, write
Examples	<p>The following example shows how to clear all the MAC addresses and to restart all the bridge domains on the router:</p> <pre>RP/0/RP0/CPU0:router# clear l2vpn bridge-domain all</pre>	
Related Commands	Command	Description
	show l2vpn bridge-domain (VPLS), on page 133	Display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains.

flooding disable

To configure flooding for traffic at the bridge domain level or at the bridge port level, use the **flooding disable** command in L2VPN bridge group bridge domain configuration mode. To return the bridge to normal flooding behavior when all unknown unicast packets, all broadcast packets, and all multicast packets are flooded over all other bridge domain network interfaces, use the **no** form of this command.

flooding disable
no flooding disable

This command has no keywords or arguments.

Command Default	The default behavior is that packets are flooded when their destination MAC address is not found.	
Command Modes	L2VPN bridge group bridge domain configuration	
Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **flooding disable** command to override the parent bridge configuration.

By default, bridge ports inherit the flooding behavior of the bridge domain.

When flooding is disabled, all unknown unicast packets, all broadcast packets, and all multicast packets are discarded.

Task ID

Task ID	Task Operations
l2vpn	read, write

Examples

The following example shows how to disable flooding on the bridge domain called bar:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# flooding disable
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 34	Enters L2VPN configuration mode.
mtu (VPLS), on page 126	Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.

interface (VPLS)

To add an interface to a bridge domain that allows packets to be forwarded and received from other interfaces that are part of the same bridge domain, use the **interface** command in L2VPN bridge group bridge domain configuration mode. To remove an interface from a bridge domain, use the **no** form of this command.

```
interface type interface-path-id
no interface type interface-path-id
```

Syntax Description

<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
-------------	---

interface-path-id Physical interface or virtual interface.

Note Use the **show interfaces** command to see a list of all interfaces currently configured on the router.

For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

None

Command Modes

L2VPN bridge group bridge domain configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface** command to enter L2VPN bridge group bridge domain attachment circuit configuration mode. In addition, the **interface** command enters the interface configuration submode to configure parameters specific to the interface.

By default, an interface is not part of a bridge.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the bundle Ethernet interface as an attachment circuit:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# interface gigabitethernet 0/1/0/9
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-ac)#
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 34	Enters L2VPN configuration mode.

learning disable (VPLS)

To override the MAC learning configuration of a parent bridge or to set the MAC learning configuration of a bridge, use the **learning disable** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command.

learning disable
no learning disable

Syntax Description	This command has no keywords or arguments.				
Command Default	By default, learning is enabled on all bridge domains and all interfaces on that bridge inherits this behavior.				
Command Modes	L2VPN bridge group bridge domain MAC configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.8.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.8.0	This command was introduced.
Release	Modification				
Release 3.8.0	This command was introduced.				

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When set, the **learning disable** command stops all MAC learning either on the specified interface or the bridge domain.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

In the following example, MAC learning is disabled on all ports in the bridge domain called bar, which is applied to all interfaces in the bridge unless the interface has its own MAC learning enable command.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac)# learning disable
```

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.

Command	Description
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 34	Enters L2VPN configuration mode.
mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.

limit (VPLS)

To set the MAC address limit for action, maximum, and notification and to enter L2VPN bridge group bridge domain MAC limit configuration mode, use the **limit** command in L2VPN bridge group bridge domain MAC configuration mode. To remove all limits that were previously configured under the MAC configuration submodes, use the **no** form of this command.

limit
no limit

Syntax Description	This command has no keywords or arguments.				
Command Default	None				
Command Modes	L2VPN bridge group bridge domain MAC configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.8.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.8.0	This command was introduced.
Release	Modification				
Release 3.8.0	This command was introduced.				

Usage Guidelines	<p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the limit command to enter L2VPN bridge group bridge domain MAC limit configuration mode. The limit command specifies that one syslog message is sent or a corresponding trap is generated with the MAC limit when the action is violated.</p>
-------------------------	--

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how the MAC limit for the bridge bar is set to 100 with an action of shutdown. After the configuration, the bridge stops all forwarding after 100 MAC addresses are learned. When this happens, a syslog message and an SNMP trap are created.

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 100
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action shutdown
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# notification both
```

Related Commands	Command	Description
	action (VPLS), on page 112	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.
	maximum (VPLS), on page 123	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
	notification (VPLS), on page 129	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

mac (VPLS)

To enter L2VPN bridge group bridge domain MAC configuration mode, use the **mac** command in L2VPN bridge group bridge domain configuration mode. To disable all configurations added under the MAC configuration submodes, use the **no** form of this command.

```
mac
no mac
```

Syntax Description	This command has no keywords or arguments.				
Command Default	None				
Command Modes	L2VPN bridge group bridge domain configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.8.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.8.0	This command was introduced.
Release	Modification				
Release 3.8.0	This command was introduced.				

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **mac** command to enter L2VPN bridge group bridge domain MAC configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to enter L2VPN bridge group bridge domain MAC configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)#
```

Related Commands	Command	Description
	aging (VPLS), on page 113	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	learning disable (VPLS), on page 120	Overrides the MAC learning configuration of a parent bridge or sets the MAC learning configuration of a bridge.
	limit (VPLS), on page 121	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.
	static-address (VPLS), on page 169	Adds static entries to the MAC address for filtering.
	withdraw (VPLS), on page 175	Disables MAC address withdrawal for a specified bridge domain

maximum (VPLS)

To configure the specified action when the number of MAC addresses learned on a bridge is reached, use the **maximum** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

```
maximum value
no maximum value
```

maximum (VPLS)

Syntax Description *value* Maximum number of learned MAC addresses.
The range is from 5 to 512000.

Command Default The default maximum value is 4000.

Command Modes L2VPN bridge group bridge domain MAC limit configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The action can either be flood, no flood, or shutdown. Depending on the configuration, a syslog, an SNMP trap notification, or both are issued.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows when the number of MAC address learned on the bridge reaches 5000 and the bridge stops learning but continues flooding:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac)# limit
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac-limit)# maximum 5000
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac-limit)# action no-flood
```

Related Commands	Command	Description
	action (VPLS), on page 112	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	limit (VPLS), on page 121	Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode.

Command	Description
mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.
notification (VPLS), on page 129	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

mpls static label (VPLS)

To configure the MPLS static labels and the static labels for the access pseudowire configuration, use the **mpls static label** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To assign the dynamic MPLS labels to either the virtual forwarding interface (VFI) pseudowire or the access pseudowire, use the **no** form of this command.

mpls static label local *value value* **remote** *value*
no mpls static label local *value value* **remote** *value*

Syntax Description

local <i>value</i>	Configures the local pseudowire label.
Note	Use the show mpls label range command to obtain the range for the local labels.
remote <i>value</i>	Configures the remote pseudowire label.
Note	The range of values for the remote labels depends on the label allocator of the remote router.

Command Default

By default, the router attempts to assign dynamic labels to the pseudowire.

Command Modes

L2VPN bridge group bridge domain Access/VFI pseudowire configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Ensure that both ends of the pseudowire have matching static labels.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the VFI pseudowire 10.1.1.2 with pseudowire ID of 1000 to use MPLS label 800 and remote MPLS label 500:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# mpls static label local 800 remote 500
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 34	Enters L2VPN configuration mode.
neighbor (VPLS), on page 127	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
pw-class (VFI), on page 132	Configures the pseudowire class template name to use for the pseudowire.
vfi (VPLS), on page 174	Configures virtual forwarding interface (VFI) parameters.

mtu (VPLS)

To adjust the maximum packet size or maximum transmission unit (MTU) size for the bridge domain, use the **mtu** command in L2VPN bridge group bridge domain configuration mode. To disable this feature, use the **no** form of this command.

```
mtu bytes
no mtu
```

Syntax Description

bytes MTU size, in bytes. The range is from 46 to 65535.

Command Default

The default MTU value is 1500.

Command Modes

L2VPN bridge group bridge domain configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Each interface has a default maximum packet size or MTU size. This number generally defaults to the largest size possible for that interface type. On serial interfaces, the MTU size varies, but cannot be set smaller than 64 bytes.

The MTU for the bridge domain includes only the payload of the packet. For example, a configured bridge MTU of 1500 allows tagged packets of 1518 bytes (6 bytes DA, 6 bytes SA, 2 bytes ethertype, or 4 bytes qtag).

Task ID**Task Operations**

Task ID	Operations
l2vpn	read, write

Examples

The following example specifies an MTU of 1000 bytes:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mtu 1000
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
flooding disable, on page 117	Configures flooding for traffic at the bridge domain level or at the bridge port level.
l2vpn, on page 34	Enters L2VPN configuration mode.

neighbor (VPLS)

To add an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI), use the **neighbor** command in the appropriate L2VPN bridge group bridge domain configuration submode. To remove the pseudowire either from the bridge or from the VFI, use the **no** form of this command.

```
neighbor A.B.C.D pw-id value
no neighbor A.B.C.D pw-id value
```

Syntax Description

A.B.C.D	IP address of the cross-connect peer.
---------	---------------------------------------

pw-id Configures the pseudowire ID and ID value. Range is 1 to 4294967295.
value

Command Default None

Command Modes L2VPN bridge group bridge domain configuration
L2VPN bridge group bridge domain VFI configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **neighbor** command to enter L2VPN bridge group bridge domain VFI pseudowire configuration mode. Alternatively, use the **neighbor** command to enter L2VPN bridge group bridge domain access pseudowire configuration mode.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to configure an access pseudowire directly under a bridge domain in L2VPN bridge group bridge domain configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-pw)#
```

The following example shows how to configure the parameters for any pseudowire in L2VPN bridge group bridge domain VFI configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# vfi v1
```

```
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-vfi) # neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-vfi-pw) #
```

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mpls static label (VPLS), on page 125	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
	pw-class (VFI), on page 132	Configures the pseudowire class template name to use for the pseudowire.
	static-mac-address (VPLS), on page 170	Configures the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface.
	vfi (VPLS), on page 174	Configures virtual forwarding interface (VFI) parameters.

notification (VPLS)

To specify the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit, use the **notification** command in L2VPN bridge group bridge domain MAC limit configuration mode. To use the notification as only a syslog entry, use the **no** form of this command.

```
notification {both | none | trap}
no notification {both | none | trap}
```

Syntax Description	
	both Sends syslog and trap notifications when the action is violated.
	none Specifies no notification.
	trap Sends trap notifications when the action is violated.

Command Default By default, only a syslog message is sent when the number of learned MAC addresses reaches the maximum configured.

Command Modes L2VPN bridge group bridge domain MAC limit configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A syslog message and an SNMP trap is generated. Alternatively, an SNMP trap is generated. Finally, no notification is generated.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how both a syslog message and an SNMP trap are generated with the bridge bar and learns more MAC addresses than the configured limit:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac)# limit
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac-limit)# notification both
```

Related Commands	Command	Description
	action (VPLS), on page 112	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.
	maximum (VPLS), on page 123	Configures the specified action when the number of MAC addresses learned on a bridge is reached.

port-down flush disable (VPLS)

To disable MAC flush when the bridge port is nonfunctional, use the **port-down flush disable** command in the L2VPN bridge group bridge domain MAC configuration mode. Use the **no** form of this command to enable the MAC flush when the bridge port is nonfunctional.

port-down flush disable
no port-down flush disable

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **port-down flush disable** command disables the MAC flush when the bridge port is nonfunctional.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to disable MAC flush when the bridge port is nonfunctional:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# port-down flush disable
```

Related Commands	Command	Description
	action (VPLS), on page 112	Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.
	maximum (VPLS), on page 123	Configures the specified action when the number of MAC addresses learned on a bridge is reached.
	notification (VPLS), on page 129	Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.

pw-class (VFI)

To configure the pseudowire class template name to use for the pseudowire, use the **pw-class** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To delete the pseudowire class, use the **no** form of this command.

pw-class *class-name*
no pw-class *class-name*

Syntax Description	<i>class-name</i> Pseudowire class name.						
Command Default	None						
Command Modes	L2VPN bridge group bridge domain VFI pseudowire configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.8.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.8.0	This command was introduced.		
Release	Modification						
Release 3.8.0	This command was introduced.						
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.						
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Task</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td></td> <td>l2vpn</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Task	Operations		l2vpn	read, write
Task ID	Task	Operations					
	l2vpn	read, write					
Examples	<p>The following example shows how to attach the pseudowire class to the pseudowire:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1 RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000 RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# pw-class canada</pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>bridge-domain (VPLS), on page 114</td> <td>Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.</td> </tr> <tr> <td>bridge group (VPLS), on page 115</td> <td>Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.</td> </tr> </tbody> </table>	Command	Description	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
Command	Description						
bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.						
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.						

Command	Description
l2vpn , on page 34	Enters L2VPN configuration mode.
mpls static label (VPLS) , on page 125	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
neighbor (VPLS) , on page 127	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
vfi (VPLS) , on page 174	Configures virtual forwarding interface (VFI) parameters.

show l2vpn bridge-domain (VPLS)

To display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains, use the **show l2vpn bridge-domain** command in EXEC mode.

```
show l2vpn bridge-domain [{bd-name bridge-domain-name | brief | detail | group
bridge-domain-group-name | interface type interface-path-id | pw-id value }] neighbor IP-address
[{pw-id value | summary}]
```

Syntax Description

bd-name <i>bridge-domain-name</i>	(Optional) Displays the bridges by the bridge ID. The <i>bridge-domain-name</i> argument is used to name a bridge domain.
brief	(Optional) Displays brief information about the bridges.
detail	(Optional) Displays the output for the Layer 2 VPN (L2VPN) to indicate whether or not the MAC withdrawal feature is enabled and the number of MAC withdrawal messages that are sent or received from the pseudowire.
group <i>bridge-domain-group-name</i>	(Optional) Displays filter information on the bridge-domain group name. The <i>bridge-domain-group-name</i> argument is used to name the bridge domain group.
interface	(Optional) Displays the filter information for the interface on the bridge domain.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
neighbor <i>IP-address</i>	(Optional) Displays only the bridge domain that contains the pseudowires to match the filter for the neighbor. The <i>IP-address</i> argument is used to configure IP address of the neighbor.
pw-id <i>value</i>	(Optional) Displays the filter for the pseudowire ID. The range is from 1 to 4294967295.

show l2vpn bridge-domain (VPLS)

summary	(Optional) Displays the summary information for the bridge domain.
----------------	--

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	Release 3.8.0	This command was introduced.
	Release 5.1.2	This command was modified to enable filtering the command output for specific pseudowire with just the pseudowire ID.

Usage Guidelines To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

Use the **interface** keyword to display only the bridge domain that contains the specified interface as an attachment circuit. In the sample output, only the attachment circuit matches the filter that is displayed. No pseudowires are displayed.



Note For Cisco IOS XR software Release 5.1.2 and above, you can filter the command output for a specific pseudowire with just the pseudowire ID. However, in case of configurations with BGP Auto-discovery with BGP or LDP signaling (in VPLS), you can specify the pseudowire only with the combination of the neighbor filter and the pseudowire ID.

Task ID	Task ID	Operations
	l2vpn	read

Examples This is the sample output for **show l2vpn bridge-domain** command with VxLAN parameters configured:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain bd-name bg1_bd1 detail
Legend: pp = Partially Programmed.
Bridge group: bg1, bridge-domain: bg1_bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Coupled state: disabled
  MAC learning: enabled
  MAC withdraw: enabled
    MAC withdraw for Access PW: enabled
    MAC withdraw sent on: bridge port up
    MAC withdraw relaying (access to access): disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
```

```

MAC limit reached: no
MAC port down flush: enabled
MAC Secure: disabled, Logging: disabled
Split Horizon Group: none
Dynamic ARP Inspection: disabled, Logging: disabled
IP Source Guard: disabled, Logging: disabled
DHCPv4 snooping: disabled
IGMP Snooping: enabled
IGMP Snooping profile: none
MLD Snooping profile: none
Storm Control: disabled
Bridge MTU: 1500
MIB cvplsConfigIndex: 1
Filter MAC addresses:
P2MP PW: disabled
Create time: 30/03/2015 22:25:38 (00:26:08 ago)
No status change since creation
ACs: 2 (2 up), VFIs: 1, PWs: 0 (0 up), PBBs: 0 (0 up)
List of ACs:
  AC: BV11, state is up
    Type Routed-Interface
    MTU 1514; XC ID 0x80000001; interworking none
    BVI MAC address:
      1000.4444.0001
  AC: GigabitEthernet0/8/0/0.1, state is up
    Type VLAN; Num Ranges: 1
    Outer Tag: 1
    VLAN ranges: [1001, 1001]
    MTU 1508; XC ID 0x508000a; interworking none
    MAC learning: enabled
    Flooding:
      Broadcast & Multicast: enabled
      Unknown unicast: enabled
    MAC aging time: 300 s, Type: inactivity
    MAC limit: 4000, Action: none, Notification: syslog
    MAC limit reached: no
    MAC port down flush: enabled
    MAC Secure: disabled, Logging: disabled
    Split Horizon Group: none
    Dynamic ARP Inspection: disabled, Logging: disabled
    IP Source Guard: disabled, Logging: disabled
    DHCPv4 snooping: disabled
    IGMP Snooping: enabled
    IGMP Snooping profile: none
    MLD Snooping profile: none
    Storm Control: bridge-domain policer
    Static MAC addresses:

    Storm control drop counters:
      packets: broadcast 0, multicast 0, unknown unicast 0
      bytes: broadcast 0, multicast 0, unknown unicast 0
    Dynamic ARP inspection drop counters:
      packets: 0, bytes: 0
    IP source guard drop counters:
      packets: 0, bytes: 0
List of VNIs:
  VNI 1, state is up
    XC ID 0x80000014
    Encap type VXLAN
    Overlay nve100, Source 1.1.1.1, Multicast Group 225.1.1.1, UDP Port 4789
    Anycast VTEP 100.1.1.1, Anycast Multicast Group 224.10.10.1
    MAC learning: enabled
    Flooding:
      Broadcast & Multicast: enabled

```

show l2vpn bridge-domain (VPLS)

```

Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
MAC port down flush: enabled
MAC Secure: disabled, Logging: disabled
Split Horizon Group: none
Dynamic ARP Inspection: disabled, Logging: disabled
IP Source Guard: disabled, Logging: disabled
DHCPv4 snooping: disabled
IGMP Snooping: enabled
IGMP Snooping profile: none
MLD Snooping profile: none
Storm Control: bridge-domain policer

List of Access PWs:
List of VFIs:
VFI bgl_bd1_vfi (up)
VFI Statistics:
drops: illegal VLAN 0, illegal length 0

```

This table describes the significant fields shown in the display.

The following sample output shows information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
VFI 1
Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

This table describes the significant fields shown in the display.

Table 9: show l2vpn bridge-domain Command Field Descriptions

Field	Description
Bridge group	Name of bridge domain group is displayed.
bridge-domain	Name of bridge domain is displayed.
id	ID assigned to this bridge domain is displayed.
state	Current state of the bridge domain is displayed.

The following example shows sample output for a bridge named bd1:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain bd-name bd1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0

```

```

ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows brief information about the bridges:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain brief
```

```

Bridge Group/Bridge-Domain Name  ID    State    Num ACs/up    Num PWs/up
-----
g1/bd1                            0     up        1/1            1/1

```

This table describes the significant fields shown in the display.

Table 10: show l2vpn bridge-domain brief Command Field Descriptions

Field	Description
Bridge Group/Bridge-Domain Name	Bridge domain group name followed by the bridge domain name are displayed.
ID	ID assigned to this bridge domain is displayed.
State	Current state of the bridge domain is displayed.
Num ACs/up	Total number of attachment circuits that are up in this bridge domain is displayed.
Num PWs/up	Total number of pseudowires that are up in this bridge domain is displayed. The count includes both VFI pseudowires and access pseudowires.

The following sample output shows detailed information:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain detail
```

```

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
MAC learning: enabled
MAC withdraw: disabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
MTU: 1500
Filter MAC addresses:
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  AC: GigabitEthernet0/1/0/0, state is up
    Type Ethernet
    MTU 1500; XC ID 0x2000001; interworking none; MSTi 0 (unprotected)
    MAC learning: enabled
    Flooding:
      Broadcast & Multicast: enabled

```

show l2vpn bridge-domain (VPLS)

```

Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: disabled
Static MAC addresses:
    0000.0000.0000
    0001.0002.0003
Statistics:
    packet totals: receive 3919680,send 9328
    byte totals: receive 305735040,send 15022146
List of Access PWs:
List of VFIs:
VFI 1
PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )
PW class mpls, XC ID 0xff000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
          MPLS           Local           Remote
-----
Label      16003
Group ID   0x0
Interface  1
MTU        1500
Control word disabled
PW type    Ethernet
VCCV CV type 0x2
           (LSP ping verification)
           (LSP ping verification)
VCCV CC type 0x2
           (router alert label)
           (router alert label)
-----
Create time: 12/03/2008 14:03:00 (17:17:30 ago)
Last time status changed: 13/03/2008 05:57:58 (01:22:31 ago)
MAC withdraw message: send 0 receive 0
Static MAC addresses:
Statistics:
    packet totals: receive 3918814, send 3918024
    byte totals: receive 305667492, send 321277968
VFI Statistics:
    drops: illegal VLAN 0, illegal length 0

```

The following sample output shows that when a bridge operates in VPWS mode, the irrelevant information for MAC learning is suppressed:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain detail

Bridge group: foo_group, bridge-domain: foo_bd, id: 0, state: up, ShgId: 0
VPWS Mode
MTU: 1500
ACs: 1 (0 up), VFIs: 1, PWs: 2 (2 up)
List of ACs:
  AC: GigabitEthernet0/5/1/4, state is admin down
  Type Ethernet      MTU 1500; XC ID 1; interworking none
Static MAC addresses:
Statistics:
  packet totals: receive 0,send 0
  byte totals: receive 0,send 0
List of VFIs:
  VFI foo_vfi
  PW: neighbor 1.1.1.1, PW ID 1, state is up ( established )

```

```

PW class not set
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
Sequencing not set
MPLS          Local                      Remote
-----
Label          16001                          16001
Group ID      unassigned                          unknown
Interface     siva/vfi                              siva/vfi
MTU           1500                                  1500
Control word  enabled                              enabled
PW type       Ethernet                          Ethernet
VCCV CV type  0x2                                  0x2
              (LSP ping verification)          (LSP ping verification)
VCCV CC type  0x3                                  0x3
              (control word)                    (control word)
              (router alert label)          (router alert label)
-----
Create time: 25/06/2007 05:29:42 (2w0d ago)
Last time status changed: 27/06/2007 06:50:35 (1w5d ago)
Static MAC addresses:
PW: neighbor 1.1.1.1, PW ID 2, state is up ( established )
PW class not set
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
Sequencing not set
MPLS          Local                      Remote
-----
Label          16002                          16002
Group ID      unassigned                          unknown
Interface     siva/vfi                              siva/vfi
MTU           1500                                  1500
Control word  enabled                              enabled
PW type       Ethernet                          Ethernet
VCCV CV type  0x2                                  0x2
              (LSP ping verification)          (LSP ping verification)
VCCV CC type  0x3                                  0x3
              (control word)                    (control word)
              (router alert label)          (router alert label)
-----
Create time: 25/06/2007 05:29:42 (2w0d ago)
Last time status changed: 27/06/2007 06:50:35 (1w5d ago)
Static MAC addresses:
Statistics:
drops: illegal VLAN 0, illegal length 0

```

This table describes the significant fields shown in the display.

Table 11: show l2vpn bridge-domain detail Command Field Descriptions

Field	Description
Bridge group	Name of bridge domain group is displayed.
bridge-domain	Name of bridge domain is displayed.
ID	ID assigned to this bridge domain is displayed.
state	Current state of the bridge domain is displayed.
MSTi	ID for the Multiple Spanning Tree.

show l2vpn bridge-domain (VPLS)

The following sample output shows filter information about the bridge-domain group named g1:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain group g1

Bridge group: g1, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 1.1.1.1 pw-id 1, state: up, Static MAC addresses: 0
```

The following sample output shows display the filter information for the interface on the bridge domain:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain interface gigabitEthernet 0/1/0/0

Bridge group: g1, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
```

The following sample output shows that the bridge domain contains the pseudowires to match the filter for the neighbor:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain neighbor 1.1.1.1

Bridge group: g1, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 1.1.1.1 pw-id 1, state: up, Static MAC addresses: 0
```

The following sample output shows the summary information for the bridge domain:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain summary

Number of groups: 1, bridge-domains: 1, Up: 1, Shutdown: 0
Number of ACs: 1 Up: 1, Down: 0
Number of PWs: 1 Up: 1, Down: 0
```

This example shows the sample output of a configured flow label:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain detail
Bridge group: g1, bridge-domain: dl, id: 0, state: up, ShgId: 0, MSTi: 0
.....
PW: neighbor 3.3.3.3, PW ID 2, state is up ( established )
  PW class class1, XC ID 0x1000002
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word disabled, interworking none
  PW backup disable delay 0 sec
Sequencing not set
Flow label flags configured (Rx=1,Tx=1), negotiated (Rx=0,Tx=1)
```

This table describes the significant fields shown in the display.

Table 12: show l2vpn bridge-domain summary Command Field Descriptions

Field	Description
Number of groups	Number of configured bridge domain groups is displayed.
bridge-domains	Number of configured bridge domains is displayed.
Shutdown	Number of bridge domains that are in Shutdown state is displayed.
Number of ACs	Number of attachment circuits that are in Up state and Down state are displayed.
Number of PWs	Number of pseudowires that are in Up state and Down state are displayed. This includes the VFI pseudowire and the access pseudowire.

Related Commands

Command	Description
clear l2vpn bridge-domain (VPLS), on page 116	Clears the MAC addresses and restarts the bridge domains on the router.

show l2vpn forwarding bridge-domain (VPLS)

To display information on the bridge that is used by the forwarding layer, use the **show l2vpn forwarding bridge-domain** command in EXEC mode.

```
show l2vpn forwarding bridge-domain [bridge-domain-name] {detail | hardware {egress | ingress}}
location node-id
```

Syntax Description

<i>bridge-domain-name</i>	(Optional) Name of a bridge domain.
detail	Displays all the detailed information on the attachment circuits and pseudowires.
hardware	Displays the hardware location entry.
egress	Reads information from the egress PSE.
ingress	Reads information from the ingress PSE.
location <i>node-id</i>	Displays the bridge-domain information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

Command Default

None

Command Modes

EXEC

show l2vpn forwarding bridge-domain (VPLS)

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For each bridge, you can display summary information about the number of bridge ports, number of MAC addresses, configured VXLANs and so forth.

The **detail** keyword displays detailed information on the attachment circuits and pseudowires, and is meant for field investigation by a specialized Cisco engineer.



Note All bridge ports in the bridge domain on that line card are displayed. Therefore, if the bridge domain contains non-local bridge ports, those are displayed as well.

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following sample output shows bridge-domain information for location 0/1/CPU0:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain location 0/1/CPU0

Bridge-Domain Name          ID      Ports addr  Flooding Learning State
-----
g1:bd1

Bridge-domain name: g1:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/0, state: oper up
  Number of MAC: 32770
  Sent(Packets/Bytes): 0/21838568
  Received(Packets/Bytes): 5704781/444972918

Nbor 1.1.1.1 pw-id 1
  Number of MAC: 32766
  Sent(Packets/Bytes): 0/0
```

```

Received(Packets/Bytes): 5703987/444910986
0      2      65536 Enabled Enabled UP

```

The following sample output shows detailed information for hardware location 0/1/CPU0 from the egress pse:

```

RP/0/RP0/CPU0:router

Bridge-domain name: gl:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0

===== GSR HW Information =====

-----
SHG-TX rewrite details
-----

HW Rewrite 0 Detail :
-----
Rewrite HW Address : 0x00060000
packets 0 bytes 0
Raw data:
[ 0x04018180 04018190 040181a0 040181b0 ]
[ 0x04018170 00000000 80360000 000bfff4 ]
[ 0x00000000 00000000 00000000 00000000 ]

-----

SHG-TX encap details
-----
outer_etype:          0
outer_vlan_id:        0
gather_profile:       0
inner_vlan_id:        0
so_l2_len_adjust:     0

-----

SHG-TX mgid details
-----

Base MGIDs for default mgid
base_mgid[0]:         0x0003ffff
base_mgid[1]:         0x0003ffff
base_mgid[2]:         0x0003ffff
base_mgid[3]:         0x0003ffff
base_mgid[4]:         0x0003ffff
base_mgid[5]:         0x0003ffff
base_mgid[6]:         0x0003ffff
base_mgid[7]:         0x0003ffff
MGID Entries for default mgid
oi[0]:                0
oq[0]:                16384
xc_id[0]:              1
mgid_idx[0]:          0x00000000

```

show l2vpn forwarding bridge-domain (VPLS)

```

next_mgid[0]:      0x00000000
-----
VMR 0 Details
-----
vmrid: 0x5f002010
Value: 0xc0 0x00 0x1f 0xff 0xff 0xff 0xff 0xff 0xfd
Mask : 0x00 0x00 0x1f 0xff 0xff 0xff 0xff 0xff 0xe0
Result 0x32003000
=====

GigabitEthernet0/1/0/0, state: oper up
  Number of MAC: 32770
  Sent(Packets/Bytes): 749/22989834
  Received(Packets/Bytes): 5732104/447104112

===== GSR HW Information =====

-----
BP-TX-AC rewrite details
-----

BP is local

-----
BP L2 Uidb Details
-----
l2fwd_enabled:      true
plim_enabled:       true
l2fwd_type:         4
l2_ac_type:         0
xconn_id:           0
bridge_id:          0
shg id:             0
unicast flooding enabled: 0
multicast flooding enabled: 0
broadcast flooding enabled: 0
mac learning enabled: 0
Is AC Port mode?:   0

-----
HW Rewrite 0 Detail :
-----
Rewrite HW Address : 0x59eff314
packets 0 bytes 0
HFA Bits 0x0 gp 0 mtu 1580 (REW)
OI 0x3fffc OutputQ 0 Output-port 0x36 local_outputq 0x0
Raw data:
[ 0x00000000 0036062c 0003fffc 00000000 ]
[ 0x00000000 00000000 0d103600 00000010 ]
[ 0x00000000 00000000 00000000 00000000 ]

-----
BP OI/OQ Details
-----
oi[0]:      0x00000000      oq[0]      16384
oi[1]:      0x00000000      oq[1]      65535
oi[2]:      0x00000000      oq[2]      65535
oi[3]:      0x00000000      oq[3]      65535
oi[4]:      0x00000000      oq[4]      65535
oi[5]:      0x00000000      oq[5]      65535
oi[6]:      0x00000000      oq[6]      65535
oi[7]:      0x00000000      oq[7]      65535

-----
Sram table entry details

```

```

-----
sram_data: 0xa000400c
=====

Nbor 1.1.1.1 pw-id 1
  Number of MAC: 32766
  Sent(Packets/Bytes): 0/0
  Received(Packets/Bytes): 5731250/447037500

===== GSR HW Information =====

-----
                BP-TX-AC rewrite details
-----

BP OI/OQ Details
-----
oi[0]:          0x00000000          oq[0]          65535
oi[1]:          0x00000000          oq[1]          65535
oi[2]:          0x00000000          oq[2]          65535
oi[3]:          0x00000000          oq[3]          65535
oi[4]:          0x00000000          oq[4]          65535
oi[5]:          0x00000000          oq[5]          65535
oi[6]:          0x00000000          oq[6]          65535
oi[7]:          0x00000000          oq[7]          65535
-----

BP Encap Info
-----
mac_length:    0
mac_string:
egress_slot:   2
num_tags:      1
  tags:        {16001, }
if_handle:     0x03000500
=====

```

The following sample output shows the bridge-domain information for the specified location:

```

RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0

Bridge-Domain Name          ID      Ports addr  Flooding Learning State
-----
g1:bd1                      0       2      65536  Enabled  Enabled  UP

```

The following sample output shows the hardware information for a specific bridge-domain:

```

RP/0/RP0/CPU0:router#show l2vpn bridge-domain hardware

Bridge group: aa, bridge-domain name: g1, id:0
  FGID Boardcast [version 1]:
    Allocate_count: 2048, Retry_count: 0, Realloc_on: Off
    Status_flag: (0x4) Replay-end
    ALL 44032, VFI 44033

Bridge group: aa, bridge-domain name: g2, id:1
  FGID Boardcast [version 1]:
    Allocate_count: 2048, Retry_count: 0, Realloc_on: Off
    Status_flag: (0x4) Replay-end
    ALL 44034, VFI 44035

```

The following sample output shows the hardware information for the line card, for a specific bridge-domain on the ingress detail location:

show l2vpn forwarding bridge-domain (VPLS)

```

RP/0/RP0/CPU0:router#
show l2vpn forwarding bridge-domain hardware ingress detail location 0/2/CPU0

Bridge-domain name: aa:gl, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 4
Number of MAC addresses: 0
Multi-spanning tree instance: 0

INGRESS BRIDGE [version, state]: [1, CREATED]

  TCAM entry seq#: 1024 Key: [BID: 0 MAC: default]
  HW: 0x4c000000 0x000080ac 0x00010000 0x80ac0100
  SW: 0x4c000000 0x000080ac 0x00010000 0x80ac0100

  SMAC: action: PUNT state: NO REFRESH
  DMAC: action: FLOOD, flood_enable: enable
  FGID: All: 44032, VFI: 44033, MCAST_Sponge_q: 16
  Fabric_multicast1: 1 Fabric_multicast2: 1

  Admin State: UP
  MTU: 1500
  Number of MAC addresses: 1 (0 MAC + 1 default)
  ACL NAME (ACL-ID): VPLS Special (4096)
  TCAM region handle : 5

GigabitEthernet0/2/0/1.1, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 1 (0x1280001)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1 : 0x4c00
  RX TLU2 : 0x1013c00
  RX TLU3 : 0x200ba00
  RX TLU4 : 0x3000c00

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [1] TCAM-Key: (UIDB:0x2 O-vlan:1 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24001000 0x01280001 0x10128000 0xc7ff7d00
  SW: 0x24001000 0x01280001 0x10128000 0xc7ff7d00

  Service type: 4 (bridging pmp)
  Entry type: 1 (fwd)
  Bridge_ID : 0
  ACL_ID : 4096
  Xconnect_ID : 0x1280001
  SplitHorizonGroup_ID : 0

```

```

Rewrite supported: 0 (No)
PW_mode: 0 (vc-type 5)
AC-type: 1 (vlan-mode)
Interface handle: 0x128000
Ingress AC stats: 0x7ff7d

SMAC Learning: enable
DMAC Flooding: enable

GigabitEthernet0/2/0/1.2, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 2 (0x1280002)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c01
  RX TLU2   : 0x1013c01
  RX TLU3   : 0x200ba01
  RX TLU4   : 0x3000c01

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [2] TCAM-Key: (UIDB:0x2 O-vlan:2 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24001000 0x01280002 0x10128002 0xc7ff7a00
  SW: 0x24001000 0x01280002 0x10128002 0xc7ff7a00

  Service type: 4 (bridging pmp)
  Entry type: 1 (fwd)
  Bridge_ID : 0
  ACL_ID : 4096
  Xconnect_ID : 0x1280002
  SplitHorizonGroup_ID : 0
  Rewrite supported: 0 (No)
  PW_mode: 0 (vc-type 5)
  AC-type: 1 (vlan-mode)
  Interface handle: 0x128002
  Ingress AC stats: 0x7ff7a

  SMAC Learning: enable
  DMAC Flooding: enable

GigabitEthernet0/2/0/1.3, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 3 (0x1280003)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c02
  RX TLU2   : 0x1013c02
  RX TLU3   : 0x200ba02
  RX TLU4   : 0x3000c02

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [3] TCAM-Key: (UIDB:0x2 O-vlan:3 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24001000 0x01280003 0x10128004 0xc7ff7700

```

show l2vpn forwarding bridge-domain (VPLS)

```

SW: 0x24001000 0x01280003 0x10128004 0xc7ff7700

Service type: 4 (bridging pmp)
Entry type: 1 (fwd)
Bridge_ID : 0
ACL_ID : 4096
Xconnect_ID : 0x1280003
SplitHorizonGroup_ID : 0
Rewrite supported: 0 (No)
PW_mode: 0 (vc-type 5)
AC-type: 1 (vlan-mode)
Interface handle: 0x128004
Ingress AC stats: 0x7ff77

SMAC Learning: enable
DMAC Flooding: enable

Nbor 5.0.0.5 pw-id 1
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: ATOM
  XID: 127/15/CPU0 : 1 (0xffff80001)
  Bridge ID: 0, Split Horizon ID: 1
  VC label: 16006
  Control-word supported: No

Bridge-domain name: aa:g2, id: 1, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 0
Multi-spanning tree instance: 0

INGRESS BRIDGE [version, state]: [1, CREATED]

TCAM entry seq#: 1025 Key: [BID: 1 MAC: default]
HW: 0x4c000000 0x000080ac 0x02010000 0x80ac0300
SW: 0x4c000000 0x000080ac 0x02010000 0x80ac0300

SMAC: action: PUNT state: NO REFRESH
DMAC: action: FLOOD, flood_enable: enable
FGID: All: 44034, VFI: 44035, MCAST_Sponge_q: 16
Fabric_multicast1: 1 Fabric_multicast2: 1

Admin State: UP
MTU: 1500
Number of MAC addresses: 1 (0 MAC + 1 default)
ACL NAME (ACL-ID): VPLS Special (4097)
TCAM region handle : 5

```

```

GigabitEthernet0/2/0/1.4, state: oper up
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 4 (0x1280004)
  Bridge ID: 1, Split Horizon ID: 0
  RX TLU1   : 0x4c03
  RX TLU2   : 0x1013c03
  RX TLU3   : 0x200ba03
  RX TLU4   : 0x3000c03

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [4] TCAM-Key: (UIDB:0x2 O-vlan:4 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24003001 0x01280004 0x10128006 0xc7ff7400
  SW: 0x24003001 0x01280004 0x10128006 0xc7ff7400

  Service type: 4 (bridging pmp)
  Entry type: 1 (fwd)
  Bridge_ID : 1
  ACL_ID : 4097
  Xconnect_ID : 0x1280004
  SplitHorizonGroup_ID : 0
  Rewrite supported: 0 (No)
  PW_mode: 0 (vc-type 5)
  AC-type: 1 (vlan-mode)
  Interface handle: 0x128006
  Ingress AC stats: 0x7ff74

  SMAC Learning: enable
  DMAC Flooding: enable

Nbor 5.0.0.5 pw-id 2
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: ATOM
  XID: 127/15/CPU0 : 2 (0xffff80002)
  Bridge ID: 1, Split Horizon ID: 1
  VC label: 16008
  Control-word supported: No

```

The following sample output shows the hardware information of the route processor, for a specific bridge-domain on the ingress detail location:

```
RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain hardware ingress detail location 0/RP0/CPU0
```

```

Bridge-domain name: aa:g1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no

```

show l2vpn forwarding bridge-domain (VPLS)

```

Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 4
Number of MAC addresses: 0
Multi-spanning tree instance: 0

BRIDGE [version, state]: [1, CREATED]
  Bridge ID: 0
    FGID1: 44032   NodeCount: 1   Info_len: 24   XID_count: 4
    FGID2: 44033   NodeCount: 1   Info_len: 20   XID_count: 3

  FGID1 Membership list:
    node-id: 0/2/CPU0 (0x21)   RSI: 0x25   XID_count: 4
    XID: 0x1280001           0x1280002   0x1280003   0xffff80001

  FGID2 Membership list:
    node-id: 0/2/CPU0 (0x21)   RSI: 0x25   XID_count: 3
    XID: 0x1280001           0x1280002   0x1280003

GigabitEthernet0/2/0/1.1, state: oper up
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

AC [version, state]: [1, BOUND]
  XID: 0x1280001   RSI: 0x25   Bridging: TRUE

GigabitEthernet0/2/0/1.2, state: oper up
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

AC [version, state]: [1, BOUND]
  XID: 0x1280002   RSI: 0x25   Bridging: TRUE

GigabitEthernet0/2/0/1.3, state: oper up
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

AC [version, state]: [1, BOUND]
  XID: 0x1280003   RSI: 0x25   Bridging: TRUE

Nbor 5.0.0.5 pw-id 1
  Number of MAC: 0

Bridge-domain name: aa:g2, id: 1, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node

```

```

Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 0
Multi-spanning tree instance: 0

BRIDGE [version, state]: [1, CREATED]
  Bridge ID: 1
    FGID1: 44034   NodeCount: 1   Info_len: 16   XID_count: 2
    FGID2: 44035   NodeCount: 1   Info_len: 12   XID_count: 1

  FGID1 Membership list:
    node-id: 0/2/CPU0 (0x21)   RSI: 0x25   XID_count: 2
    XID: 0x1280004             0xffff80002

  FGID2 Membership list:
    node-id: 0/2/CPU0 (0x21)   RSI: 0x25   XID_count: 1
    XID: 0x1280004

GigabitEthernet0/2/0/1.4, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

AC [version, state]: [1, BOUND]
  XID: 0x1280004   RSI: 0x25   Bridging: TRUE

Nbor 5.0.0.5 pw-id 2
Number of MAC: 0

```

The following sample output shows the hardware information of the line card, for a specific bridge-domain on the egress detail location:

```

RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain hardware egress detail location
0/2/CPU0

Bridge-domain name: aa:gl, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 4
Number of MAC addresses: 0
Multi-spanning tree instance: 0

EGRESS BRIDGE [version, state]: [1, CREATED]

  BID: 0   Total_oif_count: 4
  AC:   oif_count: 3   head_ptr: 0x9ff6e4f8   tail_ptr: 0x9ff6e480
  PW:   oif_count: 1   head_ptr: 0x9ff6e570

  PLU RESULT Key[Bridge-ID: 0]
  HW: 0x04008000 0x000a01c0 0x00000000 0x00000000
  SW: 0x04008000 0x000a01c0 0x00000000 0x00000000
  Entry_type: 1
  OLIST pointer: 0xa01

```

show l2vpn forwarding bridge-domain (VPLS)

```

OLIST channel: 3
OLIST count: 4

OIF[0] seg_type: AC xid: 0x1280003 Gi0/2/0/1.3 (ifh: 0x1280042)
TLU RESULT tlu_addr: 0x3000a01 ch: 3 seg_type: 1
HW: 0x80000002 0x00ba0080 0x01280003 0x00000000
SW: 0x80000002 0x00ba0080 0x01280003 0x00000000
SHG: 0
UIDB: 2
XID: 0x1280003
OLIST pointer: 0xba00
OLIST channel: 2

OIF[1] seg_type: AC xid: 0x1280002 Gi0/2/0/1.2 (ifh: 0x1280022)
TLU RESULT tlu_addr: 0x200ba00 ch: 2 seg_type: 1
HW: 0x80000002 0x000a00c0 0x01280002 0x00000000
SW: 0x80000002 0x000a00c0 0x01280002 0x00000000
SHG: 0
UIDB: 2
XID: 0x1280002
OLIST pointer: 0xa00
OLIST channel: 3

OIF[2] seg_type: AC xid: 0x1280001 Gi0/2/0/1.1 (ifh: 0x1280002)
TLU RESULT tlu_addr: 0x3000a00 ch: 3 seg_type: 1
HW: 0x80000002 0x00ba0180 0x01280001 0x00000000
SW: 0x80000002 0x00ba0180 0x01280001 0x00000000
SHG: 0
UIDB: 2
XID: 0x1280001
OLIST pointer: 0xba01
OLIST channel: 2

OIF[3] seg_type: PW xid: 0xffff80001 ecd_ptr: 0x5206
TLU RESULT tlu_addr: 0x200ba01 ch: 2 seg_type: 0
HW: 0x01005206 0x00000000 0xffff80001 0x03e86000
SW: 0x01005206 0x00000000 0xffff80001 0x03e86000
SHG: 1
XID: 0xffff80001
OLIST pointer: 0x0
OLIST channel: 0
Control Word: Disabled
VC label: 16006
ECD/TLU1 pointer: 0x5206

GigabitEthernet0/2/0/1.1, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 1 (0x1280001)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c00
  RX TLU2   : 0x1013c00
  RX TLU3   : 0x200ba00
  RX TLU4   : 0x3000c00

EGRESS AC [version, state]: [1, BOUND]

Xconnect-ID: [1] TLU2-entry-addr: [0x200a001]
HW: 0x8018b000 0x0000000b 0x00004001 0xfb7ba000

```

```
SW: 0x8018b000 0x0000000b 0x00004001 0xfb7ba000

Entry status: 1 (Fwd)
AC_type: 1 (vlan-mode)
Outer-vlan: 1
Inner-vlan: 0
Outer Ether Type: 0 (dot1q)
AC_mtu: 1580
Adjacency_type: 0
Default EgressQ (SharqQ): 11
PW mode: 0 (vc-type 5)
Rewrite supported: 0 (No)
Control-word supported: 0 (No)
Egress AC stats: 0x7dbdd

GigabitEthernet0/2/0/1.2, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 2 (0x1280002)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c01
  RX TLU2   : 0x1013c01
  RX TLU3   : 0x200ba01
  RX TLU4   : 0x3000c01

EGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [2] TLU2-entry-addr: [0x200a002]
  HW: 0x8018b000 0x0000000b 0x00004002 0xfb7b4000
  SW: 0x8018b000 0x0000000b 0x00004002 0xfb7b4000

Entry status: 1 (Fwd)
AC_type: 1 (vlan-mode)
Outer-vlan: 2
Inner-vlan: 0
Outer Ether Type: 0 (dot1q)
AC_mtu: 1580
Adjacency_type: 0
Default EgressQ (SharqQ): 11
PW mode: 0 (vc-type 5)
Rewrite supported: 0 (No)
Control-word supported: 0 (No)
Egress AC stats: 0x7dbda

GigabitEthernet0/2/0/1.3, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 3 (0x1280003)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c02
  RX TLU2   : 0x1013c02
  RX TLU3   : 0x200ba02
```

show l2vpn forwarding bridge-domain (VPLS)

```

RX TLU4      : 0x3000c02

EGRESS AC [version, state]: [1, BOUND]

Xconnect-ID: [3] TLU2-entry-addr: [0x200a003]
HW: 0x8018b000 0x0000000b 0x00004003 0xfb7ae000
SW: 0x8018b000 0x0000000b 0x00004003 0xfb7ae000

Entry status: 1 (Fwd)
AC_type: 1 (vlan-mode)
Outer-vlan: 3
Inner-vlan: 0
Outer Ether Type: 0 (dot1q)
AC_mtu: 1580
Adjacency_type: 0
Default EgressQ (SharqQ): 11
PW mode: 0 (vc-type 5)
Rewrite supported: 0 (No)
Control-word supported: 0 (No)
Egress AC stats: 0x7dbd7

Nbor 5.0.0.5 pw-id 1
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
Bridge Port Type: ATOM
XID: 127/15/CPU0 : 1 (0xfff80001)
Bridge ID: 0, Split Horizon ID: 1
VC label: 16006
Control-word supported: No

Bridge-domain name: aa:g2, id: 1, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 0
Multi-spanning tree instance: 0

EGRESS BRIDGE [version, state]: [1, CREATED]

  BID: 1   Total_oif_count: 2
  AC:   oif_count: 1   head_ptr: 0x9ff6e534   tail_ptr: 0x9ff6e534
  PW:   oif_count: 1   head_ptr: 0x9ff6e5ac

  PLU RESULT Key[Bridge-ID: 1]
  HW: 0x04004000 0x000a02c0 0x00000000 0x00000000
  SW: 0x04004000 0x000a02c0 0x00000000 0x00000000
  Entry_type: 1
  OLIST pointer: 0xa02

```

```

OLIST channel: 3
OLIST count: 2

OIF[0] seg_type: AC xid: 0x1280004 Gi0/2/0/1.4 (ifh: 0x1280062)
TLU RESULT tlu_addr: 0x3000a02 ch: 3 seg_type: 1
HW: 0x80000002 0x00ba0280 0x01280004 0x00000000
SW: 0x80000002 0x00ba0280 0x01280004 0x00000000
SHG: 0
UIDB: 2
XID: 0x1280004
OLIST pointer: 0xba02
OLIST channel: 2

OIF[1] seg_type: PW xid: 0xffff80002 ecd_ptr: 0x5200
TLU RESULT tlu_addr: 0x200ba02 ch: 2 seg_type: 0
HW: 0x01005200 0x00000000 0xffff80002 0x03e88000
SW: 0x01005200 0x00000000 0xffff80002 0x03e88000
SHG: 1
XID: 0xffff80002
OLIST pointer: 0x0
OLIST channel: 0
Control Word: Disabled
VC label: 16008
ECD/TLU1 pointer: 0x5200

GigabitEthernet0/2/0/1.4, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
Bridge Port Type: AC
XID: 0/2/CPU0 : 4 (0x1280004)
Bridge ID: 1, Split Horizon ID: 0
RX TLU1   : 0x4c03
RX TLU2   : 0x1013c03
RX TLU3   : 0x200ba03
RX TLU4   : 0x3000c03

EGRESS AC [version, state]: [1, BOUND]

Xconnect-ID: [4] TLU2-entry-addr: [0x200a004]
HW: 0x8018b000 0x0000000b 0x00004004 0xfb7a8000
SW: 0x8018b000 0x0000000b 0x00004004 0xfb7a8000

Entry status: 1 (Fwd)
AC_type: 1 (vlan-mode)
Outer-vlan: 4
Inner-vlan: 0
Outer Ether Type: 0 (dot1q)
AC_mtu: 1580
Adjacency_type: 0
Default EgressQ (SharqQ): 11
PW mode: 0 (vc-type 5)
Rewrite supported: 0 (No)
Control-word supported: 0 (No)
Egress AC stats: 0x7dbd4

Nbor 5.0.0.5 pw-id 2
Number of MAC: 0
Statistics:
  packets: received 0, sent 0

```

show l2vpn forwarding bridge-domain mac-address (VPLS)

```
bytes: received 0, sent 0
```

```
EGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: ATOM
  XID: 127/15/CPU0 : 2 (0xffff80002)
  Bridge ID: 1, Split Horizon ID: 1
  VC label: 16008
  Control-word supported: No
```

This table describes the significant fields shown in the display.

Table 13: show l2vpn forwarding bridge-domain Command Field Descriptions

Field	Description
Bridge-Domain Name	Name of bridge domain is displayed.
Bridge ID	ID assigned to this bridge domain is displayed.
Ports	Number of ports that are part of this bridge domain is displayed.
MAC Addr	Number of MAC addresses that are learned on this bridge domain is displayed.
Flooding	Flooding of packets are displayed if they are enabled on this bridge domain.
Learning	Learning of MAC addresses are displayed if they are enabled on this bridge domain.
State	Current state of the bridge domain is displayed.

Related Commands

Command	Description
clear l2vpn bridge-domain (VPLS), on page 116	Clears the MAC addresses and restarts the bridge domains on the router.

show l2vpn forwarding bridge-domain mac-address (VPLS)

To display the summary information for the MAC address, use the **show l2vpn forwarding bridge-domain mac-address** command in EXEC mode.

```
show l2vpn forwarding bridge-domain [bridge-domain-name] mac-address {MAC-address | detail | hardware {egress | ingress} | interface type interface-path-id | neighbor address pw-id pw-id} location node-id
```

Syntax Description

bridge-domain-name (Optional) Name of a bridge domain.

MAC-address MAC address.

detail Displays detailed information for the MAC address.

hardware Reads information from the hardware.

egress Reads information from the egress PSE.

ingress	Reads information from the ingress PSE.
interface	Displays the match for the attachment circuit subinterface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
neighbor address	Displays the match for the neighbor IP address.
pw-id pw-id	Displays the match for the pseudowire ID.
location node-id	Displays the bridge-domain information for the MAC address of the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 3.7.0	This command was introduced.
	Release 3.7.2	This command was introduced.
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read

Examples

The following sample output shows the specified location of the bridge-domain name g1:bd1 for the MAC address:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0
Bridge-Domain Name          Bridge ID   Ports   MAC addr   Flooding   Learning   State
-----
g1:bd1                      0          2       65536     Enabled   Enabled   UP
```

show l2vpn forwarding bridge-domain mac-address (VPLS)

The following sample output shows the list of MAC addresses that are learned on a specified bridge and summary information for the addresses:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain mac-address location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
0000.0001.0112	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 22s
....				

The following sample output shows the MAC address on a specified interface on a specified bridge:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address 1.2.3 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0001.0002.0003	static	Gi0/1/0/0	N/A	N/A

The following sample output shows the hardware information from the egress pse:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address hardware egress location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s
0000.0001.0111	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 24s

```
0000.0001.0112 dynamic Gi0/1/0/0          0/1/CPU0 0d 0h 2m 24s
0000.0001.0113 dynamic Gi0/1/0/0          0/1/CPU0 0d 0h 2m 24s
0000.0001.0114 dynamic Gi0/1/0/0          0/1/CPU0 0d 0h 2m 24s
...
```

The following sample output shows the MAC addresses that are learned on a specified pseudowire on a specified bridge:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain mac-address neighbor 1.1.1.1 pw-id
1 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0003.0101	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0102	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0103	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0104	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0105	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0106	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0107	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0108	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0109	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010a	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010b	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010c	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010d	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010e	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.010f	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0110	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0111	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0112	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0113	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0114	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
0000.0003.0115	dynamic	1.1.1.1, 1	0/1/CPU0	0d 0h 0m 30s
...				

The following sample output shows the detailed information for MAC addresses that are learned on a specified interface and on specified bridge of a specified interface card. The sample output lists all the MAC addresses, the learned location, and the current age.

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address interface
gigabitEthernet 0/1/0/0 location 0/1/CPU0
```

Mac Address	Type	Learned from/Filtered on	LC learned	Age
0000.0000.0000	static	Gi0/1/0/0	N/A	N/A
0000.0001.0101	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0102	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0103	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0104	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0105	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0106	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0107	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0108	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0109	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010a	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010b	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010c	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010d	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010e	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.010f	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s
0000.0001.0110	dynamic	Gi0/1/0/0	0/1/CPU0	0d 0h 2m 14s

show l2vpn forwarding bridge-domain mac-address (VPLS)

```

0000.0001.0111 dynamic Gi0/1/0/0          0/1/CPU0  0d 0h 2m 14s
0000.0001.0112 dynamic Gi0/1/0/0          0/1/CPU0  0d 0h 2m 14s
0000.0001.0113 dynamic Gi0/1/0/0          0/1/CPU0  0d 0h 2m 14s
0000.0001.0114 dynamic Gi0/1/0/0          0/1/CPU0  0d 0h 2m 14s

```

The following sample output shows the MAC address hardware information on the line card, for a specific bridge-domain on the ingress detail location:

```

RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain mac hardware ingress detail location
0/2/CPU0

```

```

Bridge-domain name: aa:gl, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 4
Number of MAC addresses: 10
Multi-spanning tree instance: 0

INGRESS BRIDGE [version, state]: [1, CREATED]

  TCAM entry seq#: 1024 Key: [BID: 0 MAC: default]
  HW: 0x4c000000 0x000080ac 0x00010000 0x80ac0100
  SW: 0x4c000000 0x000080ac 0x00010000 0x80ac0100

  SMAC: action: PUNT state: NO REFRESH
  DMAC: action: FLOOD, flood_enable: enable
  FGID: All: 44032, VFI: 44033, MCAST_Sponge_q: 16
  Fabric_multicast1: 1 Fabric_multicast2: 1

  Admin State: UP
  MTU: 1500
  Number of MAC addresses: 11 (10 MAC + 1 default)
  ACL NAME (ACL-ID): VPLS Special (4096)
  TCAM region handle : 5

GigabitEthernet0/2/0/1.1, state: oper up
Number of MAC: 10
Statistics:
  packets: received 0, sent 121515
  bytes: received 0, sent 7290900

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 1 (0x1280001)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1 : 0x4c00
  RX TLU2 : 0x1013c00
  RX TLU3 : 0x200ba00
  RX TLU4 : 0x3000c00

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [1] TCAM-Key: (UIDB:0x2 O-vlan:1 I-vlan:0 Ether-Type:0x8100)

```

```

HW: 0x24001000 0x01280001 0x10128000 0xc7ff7d00
SW: 0x24001000 0x01280001 0x10128000 0xc7ff7d00

Service type: 4 (bridging pmp)
Entry type: 1 (fwd)
Bridge_ID : 0
ACL_ID : 4096
Xconnect_ID : 0x1280001
SplitHorizonGroup_ID : 0
Rewrite supported: 0 (No)
PW_mode: 0 (vc-type 5)
AC-type: 1 (vlan-mode)
Interface handle: 0x128000
Ingress AC stats: 0x7ff7d

SMAC Learning: enable
DMAC Flooding: enable

Mac Address: 0000.0022.2222, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

TCAM entry seq#: 0 Key: [BID: 0 MAC: 0000.0022.2222]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID : 0
Entry Flag : FWD
Entry Type : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1 : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
label: 0 num of labels: 0
entry type: FWD next ptr: 0x00013c00
num of entries: 1
BGP next-hop: 0.0.0.0

TLU2 : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
label1: 1 label2: 0
num of labels: 1 next ptr: 0x0000ba00

TLU3 : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
num. entries : 1
num. labels : 0
label 1 : 0
label 2 : 0
next ptr : 0xc00

TLU4 : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
dest. addr : 0x20
sponge queue : 130

```

show l2vpn forwarding bridge-domain mac-address (VPLS)

```

    egress port      : 0x128004
    rp destined      : no
    rp drop          : no
    hash type        : 0
    uidb index       : 0x2

Mac Address: 0000.0022.2223, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

TCAM entry seq#: 1 Key: [BID: 0 MAC: 0000.0022.2223]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag  : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
label:          0      num of labels:          0
entry type:     FWD   next ptr:          0x00013c00
num of entries: 1
BGP next-hop:  0.0.0.0

TLU2          : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
label1:         1      label2:         0
num of labels:  1      next ptr: 0x0000ba00

TLU3          : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
num. entries   : 1
num. labels    : 0
label 1        : 0
label 2        : 0
next ptr       : 0xc00

TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
dest. addr     : 0x20
sponge queue   : 130
egress port    : 0x128004
rp destined     : no
rp drop        : no
hash type      : 0
uidb index     : 0x2

Mac Address: 0000.0022.2224, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

```

```

TCAM entry seq#: 2 Key: [BID: 0 MAC: 0000.0022.2224]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag  : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
label:          0      num of labels:      0
entry type:     FWD   next ptr:          0x00013c00
num of entries: 1
BGP next-hop:  0.0.0.0

TLU2          : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
label1:         1      label2:         0
num of labels:  1      next ptr: 0x0000ba00

TLU3          : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
num. entries   : 1
num. labels    : 0
label 1        : 0
label 2        : 0
next ptr       : 0xc00

TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
dest. addr     : 0x20
sponge queue   : 130
egress port    : 0x128004
rp destined    : no
rp drop        : no
hash type      : 0
uidb index     : 0x2

Mac Address: 0000.0022.2225, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

```

```
INGRESS MAC [version, state]: [1, CREATED]
```

```

TCAM entry seq#: 3 Key: [BID: 0 MAC: 0000.0022.2225]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag  : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00

```

show l2vpn forwarding bridge-domain mac-address (VPLS)

```

Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:      0
  entry type:     FWD    next ptr:      0x00013c00
  num of entries: 1
  BGP next-hop:   0.0.0.0

TLU2          : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
  label1:         1      label2:         0
  num of labels:  1      next ptr: 0x0000ba00

TLU3          : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries   : 1
  num. labels    : 0
  label 1       : 0
  label 2       : 0
  next ptr      : 0xc00

TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr     : 0x20
  sponge queue   : 130
  egress port    : 0x128004
  rp destined    : no
  rp drop        : no
  hash type      : 0
  uidb index     : 0x2

```

```

Mac Address: 0000.0022.2226, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

```

```

INGRESS MAC [version, state]: [1, CREATED]

```

```

TCAM entry seq#: 4 Key: [BID: 0 MAC: 0000.0022.2226]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

```

```

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

```

```

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

```

```

TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:      0
  entry type:     FWD    next ptr:      0x00013c00
  num of entries: 1
  BGP next-hop:   0.0.0.0

TLU2          : 0x1013c00

```

```

[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
  label1:          1      label2:          0
  num of labels:   1      next ptr: 0x0000ba00

TLU3              : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries   : 1
  num. labels    : 0
  label 1       : 0
  label 2       : 0
  next ptr      : 0xc00

TLU4              : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr     : 0x20
  sponge queue   : 130
  egress port    : 0x128004
  rp destined    : no
  rp drop        : no
  hash type      : 0
  uidb index     : 0x2

Mac Address: 0000.0022.2227, LC learned: 0/2/CPU0
  Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

TCAM entry seq#: 5 Key: [BID: 0 MAC: 0000.0022.2227]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag  : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1              : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:      0
  entry type:     FWD    next ptr:      0x00013c00
  num of entries: 1
  BGP next-hop:  0.0.0.0

TLU2              : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
  label1:          1      label2:          0
  num of labels:   1      next ptr: 0x0000ba00

TLU3              : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries   : 1
  num. labels    : 0
  label 1       : 0
  label 2       : 0
  next ptr      : 0xc00

```

show l2vpn forwarding bridge-domain mac-address (VPLS)

```

TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr   : 0x20
  sponge queue : 130
  egress port  : 0x128004
  rp destined  : no
  rp drop      : no
  hash type    : 0
  uidb index   : 0x2

Mac Address: 0000.0022.2228, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

TCAM entry seq#: 6 Key: [BID: 0 MAC: 0000.0022.2228]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID : 0
Entry Flag : FWD
Entry Type : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:      0
  entry type:     FWD   next ptr:      0x00013c00
  num of entries: 1
  BGP next-hop:  0.0.0.0

TLU2          : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
  label1:         1      label2:         0
  num of labels:  1      next ptr: 0x0000ba00

TLU3          : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries   : 1
  num. labels    : 0
  label 1       : 0
  label 2       : 0
  next ptr      : 0xc00

TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr     : 0x20
  sponge queue   : 130
  egress port    : 0x128004
  rp destined    : no
  rp drop        : no
  hash type      : 0
  uidb index     : 0x2

```

```
Mac Address: 0000.0022.2229, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local
```

Related Commands	Command	Description
	show l2vpn forwarding bridge-domain (VPLS), on page 141	Displays information on the bridge that is used by the forwarding layer.

shutdown (Bridge Domain)

To shut down a bridge domain to bring the bridge and all attachment circuits and pseudowires under it to admin down state, use the **shutdown** command in L2VPN bridge group bridge domain configuration mode. To re-enable the bridge domain, use the **no** form of this command.

```
shutdown
no shutdown
```

Syntax Description This command has no keywords or arguments.

Command Default By default, the bridge is not shutdown.

Command Modes L2VPN bridge group bridge domain configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When a bridge domain is disabled, all VFIs associated with the bridge domain are disabled. You can still attach or detach members to or from the bridge domain as well as the VFIs associated with the bridge domain.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to disable the bridge domain named bar:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
```

shutdown (VFI)

```
RP/0/RP0/CPU0:router (config-l2vpn-bg) # bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd) # shutdown
```

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.

shutdown (VFI)

To disable virtual forwarding interface (VFI), use the **shutdown** command in L2VPN bridge group bridge domain VFI configuration mode. To re-enable VFI, use the **no** form of this command.

shutdown
no shutdown

Syntax Description This command has no keywords or arguments.

Command Default By default, the VFI is not shutdown.

Command Modes L2VPN bridge group bridge domain VFI configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples The following example shows how to disable VFI:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config) # l2vpn
RP/0/RP0/CPU0:router (config-l2vpn) # bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg) # bridge-domain bar
```

```
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# shutdown
```

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mpls static label (VPLS), on page 125	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
	neighbor (VPLS), on page 127	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).

static-address (VPLS)

To add static entries to the MAC address for filtering, use the **static-address** command in L2VPN bridge group bridge domain MAC configuration mode. To remove entries profiled by the combination of a specified entry information, use the **no** form of this command.

```
static-address MAC-address drop
no static-address MAC-address drop
```

Syntax Description	
<i>MAC-address</i>	Static MAC address that is used to filter on the bridge domain.
drop	Drops all traffic that is going to the configured MAC address.

Command Default No static MAC address is configured.

Command Modes L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to add static MAC entries in L2VPN bridge group bridge domain MAC configuration mode. This entry causes all packets with destination MAC address 1.1.1 to be dropped.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac)# static-address 1.1.1 drop
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 34	Enters L2VPN configuration mode.
mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.

static-mac-address (VPLS)

To configure the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface, use the **static-mac-address** command in the appropriate L2VPN bridge group bridge domain configuration submode. To disable this feature, use the **no** form of this command.

```
static-mac-address MAC-address
no static-mac-address MAC-address
```

Syntax Description

MAC-address Static address to add to the MAC address.

Command Default

None

Command Modes

L2VPN bridge group bridge domain VFI pseudowire configuration
L2VPN bridge group bridge domain attachment circuit configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to associate a remote MAC address with a pseudowire:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# static-mac-address 1.1.1
```

The following example shows how to associate a GigabitEthernet interface from a bridge domain to static MAC address 1.1.1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# interface GigabitEthernet 0/1/0/0
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-ac)# static-mac-address 1.1.1
```

The following example shows how to associate an access pseudowire to static MAC address 2.2.2:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 2000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-pw)# static-mac-address 2.2.2
```

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mpls static label (VPLS), on page 125	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
	neighbor (VPLS), on page 127	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).
	vfi (VPLS), on page 174	Configures virtual forwarding interface (VFI) parameters.

time (VPLS)

To configure the maximum aging time, use the **time** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

time *seconds*
no time *seconds*

Syntax Description

seconds MAC address table entry maximum age. The range is from 300 to 30000 seconds. Aging time is counted from the last time that the switch saw the MAC address. The default value is 300 seconds.

Command Default

seconds: 300

Command Modes

L2VPN bridge group bridge domain MAC aging configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If no packets are received from the MAC address for the duration of the maximum aging time, the dynamic MAC entry previously learned is removed from the forwarding table.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to increase the maximum aging time to 600 seconds. After 600 seconds of inactivity from a MAC address, the MAC address is removed from the forwarding table.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# l2vpn
RP/0/RP0/CPU0:router (config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router (config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac)# aging
RP/0/RP0/CPU0:router (config-l2vpn-bg-bd-mac-aging)# time 600
```

Related Commands

Command	Description
aging (VPLS), on page 113	Enters the MAC aging configuration submode to set the aging parameters such as time and type.

Command	Description
bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 34	Enters L2VPN configuration mode.
mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.
type (VPLS), on page 173	Configures the type for MAC address aging.

type (VPLS)

To configure the type for MAC address aging, use the **type** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

```
type {absolute | inactivity}
no type {absolute | inactivity}
```

Syntax Description

absolute Configures the absolute aging type.

inactivity Configures the inactivity aging type.

Command Default

By default, the inactivity type is configured.

Command Modes

L2VPN bridge group bridge domain MAC aging configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In general, the type is set to inactivity. With an inactivity type configuration, a MAC address is removed from the forwarding table after the MAC address is inactive for the configured aging time.

With an absolute type configuration, a MAC address is always removed from the forwarding table after the aging time has elapsed once it is initially learned.

Task ID

Task ID	Operations
l2vpn	read, write

Examples

The following example shows how to configure the MAC address aging type to absolute for every member of the bridge domain named bar:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# aging
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# type absolute
```

Related Commands	Command	Description
	aging (VPLS), on page 113	Enters the MAC aging configuration submode to set the aging parameters such as time and type.
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.
	time (VPLS), on page 172	Configures the maximum aging time.

vfi (VPLS)

To configure virtual forwarding interface (VFI) parameters and to enter L2VPN bridge group bridge domain VFI configuration mode, use the **vfi** command in L2VPN bridge group bridge domain configuration mode. To remove all configurations that are made under the specified VFI, use the **no** form of this command.

```
vfi vfi-name
no vfi vfi-name
```

Syntax Description	<i>vfi-name</i> Name of the specified virtual forwarding interface.				
Command Default	None				
Command Modes	L2VPN bridge group bridge domain configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.8.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.8.0	This command was introduced.
Release	Modification				
Release 3.8.0	This command was introduced.				

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **vfi** command to enter L2VPN bridge group bridge domain VFI configuration mode.

You cannot configure a pseudowire directly under a bridge domain. Therefore, a pseudowire must be configured under a VFI, which is configured under a bridge domain.

Task ID**Task Operations ID**

l2vpn read,
write

Examples

The following example shows how to create a VFI:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi vl
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)#
```

Related Commands

Command	Description
bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
l2vpn, on page 34	Enters L2VPN configuration mode.
mpls static label (VPLS), on page 125	Configures the MPLS static labels and the static labels for the access pseudowire configuration.
neighbor (VPLS), on page 127	Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).

withdraw (VPLS)

To enable MAC address withdrawal for a specified bridge domain, use the **withdraw** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command

```
withdraw { disable }
no withdraw { disable }
```

Syntax Description

disable Disables MAC address withdrawal.

Command Default

By default, MAC address withdrawal is enabled.

withdraw (VPLS)

Command Modes L2VPN bridge group bridge domain MAC configuration

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	l2vpn	read, write

Examples

The following example shows how to enable disable MAC withdrawal:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# withdraw disable
```

The following example shows how to disable sending MAC withdrawal messages to access pseudowires:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# withdraw access-pw disable
```

Related Commands	Command	Description
	bridge-domain (VPLS), on page 114	Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.
	bridge group (VPLS), on page 115	Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.
	l2vpn, on page 34	Enters L2VPN configuration mode.
	mac (VPLS), on page 122	Enters L2VPN bridge group bridge domain MAC configuration mode.



CHAPTER 4

Generic Routing Encapsulation Commands

This module describes the commands used to configure generic routing encapsulation (GRE).

For detailed information about GRE concepts, configuration tasks, and examples, refer to the .

- [interface tunnel-ip](#), on page 177
- [keepalive](#), on page 178
- [tunnel destination](#), on page 179
- [tunnel dfbit](#) , on page 180
- [tunnel mode](#), on page 181
- [tunnel source](#), on page 182
- [tunnel tos](#), on page 183
- [tunnel ttl](#), on page 184

interface tunnel-ip

To configure a tunnel interface, use the **interface tunnel-ip** command in the interface global configuration mode. To disable this feature, use the **no** form of this command.

```
interface tunnel-ip number  
no interface tunnel-ip number
```

Syntax Description	<i>number</i> Specifies the instance number of the interface to be configured.				
Command Default	None				
Command Modes	interface configuration				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Release 3.9.0</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Release 3.9.0	This command was introduced.
Release	Modification				
Release 3.9.0	This command was introduced.				

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface tunnel-ip** command to enter the interface global configuration mode.

Task ID	Task ID	Operations
	interface	read, write

Examples

This example shows how to configure a tunnel interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)#
```

keepalive

To enable keepalive for a tunnel interface, use the **keepalive** command. To remove keepalive, use the **no** form of this command.

keepalive [*time_in_seconds* [*retry_num*]]
no keepalive

Syntax Description	
<i>time_in_seconds</i>	Specifies the frequency (in seconds) at which keepalive check is performed. The default is 10 seconds. The minimum value is 1 second.
<i>retry_num</i>	Specifies the number of keepalive retries before declaring that a tunnel destination is unreachable. The default is 3 retries. The minimum value is 1 retry.

Command Default None

Command Modes interface configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **keepalive** command to enable keepalive for a tunnel interface.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# keepalive 30
```

tunnel destination

To specify a tunnel interface's destination address, use the **tunnel destination** command. To remove the destination address, use the **no** form of this command.



Note The tunnel will not be operational until the tunnel destination is specified.

tunnel destination *ip-address*
no tunnel destination *ip-address*

Syntax Description *ip-address* Specifies the IPv4 address of the host destination.

Command Default None

Command Modes interface configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel destination 10.10.10.1
```

Related Commands	Command	Description
	tunnel mode, on page 181	Configures the encapsulation mode of the tunnel interface.
	tunnel source, on page 182	Sets a tunnel interface's source address.
	tunnel tos, on page 183	Specifies the value of the TOS field in the tunnel encapsulating packets.
	tunnel ttl, on page 184	Configures the Time-To-Live (TTL) for packets entering the tunnel.

tunnel dfbit

To configure the DF bit setting in the tunnel transport header, use the **tunnel dfbit** command. To revert to the default DF bit setting value, use the **no** form of this command.

```
tunnel dfbit disable
no tunnel dfbit
```

Syntax Description

Syntax Description	disable
	Disables the DF bit in the outer packet. This allows the outer packet to be fragmented, if required.

Command Default

The DF bit value in the outer packet is disabled. This allows outer packet fragmentation, if required.

Command Modes

interface configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
interface	read, write

Examples

The following example shows how to enable fragmentation over an interface tunnel.

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel dfbit disable
```

Related Commands	Command	Description
	tunnel destination, on page 179	Specifies a tunnel interface's destination address.
	tunnel mode, on page 181	Configures the encapsulation mode of the tunnel interface.
	tunnel source, on page 182	Sets a tunnel interface's source address.
	tunnel tos, on page 183	Specifies the value of the TOS field in the tunnel encapsulating packets.
	tunnel ttl, on page 184	Configures the Time-To-Live (TTL) for packets entering the tunnel.

tunnel mode

To configure the encapsulation mode of the tunnel interface, use the **tunnel mode** command. To revert the encapsulation to the default IPv4 GRE tunnel mode, use the **no** form of this command.

```
tunnel mode gre ipv4}
no tunnel mode
```

Syntax Description

Syntax Description	gre	ipv4	
			Specifies the tunnel as a GRE tunnel over an IPv4 transport network.

Command Default

The default tunnel mode is set as a GRE tunnel over an IPv4 transport network.

Command Modes

interface configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
interface	read, write

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel mode gre ipv4
```

Related Commands	Command	Description
	tunnel destination, on page 179	Specifies a tunnel interface's destination address.
	tunnel source, on page 182	Sets a tunnel interface's source address.
	tunnel tos, on page 183	Specifies the value of the TOS field in the tunnel encapsulating packets.
	tunnel ttl, on page 184	Configures the Time-To-Live (TTL) for packets entering the tunnel.

tunnel source

To set a tunnel interface's source address, use the **tunnel source** command. To remove the source address, use the **no** form of this command.



Note The tunnel will not be operational until the tunnel source is specified.

```
tunnel source {interface_name | ip-address}
no tunnel source {interface_name | ip-address}
```

Syntax Description	
<i>interface_name</i>	Specifies the name of the interface whose IP address will be used as the source address of the tunnel. The interface name can be of a loopback interface or a physical interface.
<i>ip-address</i>	Specifies the IPv4 address to use as the source address for packets in the tunnel.

Command Default None

Command Modes interface configuration

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

It is recommended that the tunnel source is identified using the interface ID and not the IP address. Using the interface ID enables the router to mark the tunnel as down when the interface is down and the routing protocol tries to find and use an alternate route to the tunnel route.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel source 10.10.10.1
```

Related Commands	Command	Description
	tunnel destination, on page 179	Specifies a tunnel interface's destination address.
	tunnel mode, on page 181	Configures the encapsulation mode of the tunnel interface.
	tunnel tos, on page 183	Specifies the value of the TOS field in the tunnel encapsulating packets.
	tunnel ttl, on page 184	Configures the Time-To-Live (TTL) for packets entering the tunnel.

tunnel tos

To specify the value of the TOS field in the tunnel encapsulating packets, use the **tunnel tos** command. To return to the default TOS value, use the **no** form of this command.

```
tunnel tos tos_value
no tunnel tos tos_value
```

Syntax Description	<i>tos_value</i> Specifies the value of the TOS field in the tunnel encapsulating packets. The TOS value ranges between 0 to 255.				
Command Default	Copies the TOS/COS bits of the internal IP header to the GRE IP header. In case of labeled payload, EXP bits are copied to TOS bits of the GRE IP header.				
Command Modes	interface configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 3.9.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 3.9.0	This command was introduced.
Release	Modification				
Release 3.9.0	This command was introduced.				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel tos 100
```

Related Commands	Command	Description
	tunnel destination, on page 179	Specifies a tunnel interface's destination address.
	tunnel mode, on page 181	Configures the encapsulation mode of the tunnel interface.
	tunnel source, on page 182	Sets a tunnel interface's source address.
	tunnel ttl, on page 184	Configures the Time-To-Live (TTL) for packets entering the tunnel.

tunnel ttl

To configure the Time-To-Live (TTL) for packets entering the tunnel, use the **tunnel ttl** command. To undo the configuration, use the **no** form of this command.

```
tunnel ttl ttl_value
no tunnel ttl ttl_value
```

Syntax Description	<i>ttl_value</i>
	Specifies the value of TTL for packets entering the tunnel. The TTL value ranges between 1 to 255.

Command Default	The default TTL value is set to 255.
-----------------	--------------------------------------

Command Modes	interface configuration
---------------	-------------------------

Command History	Release	Modification
	Release 3.9.0	This command was introduced.

Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
------------------	---

This command specifies the Time-To-Live for packets entering the tunnel so that the packets are not dropped inside the carrier network before reaching the tunnel destination.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)#tunnel source 10.10.10.1
```

Related Commands	Command	Description
	tunnel destination, on page 179	Specifies a tunnel interface's destination address.
	tunnel mode, on page 181	Configures the encapsulation mode of the tunnel interface.
	tunnel tos, on page 183	Specifies the value of the TOS field in the tunnel encapsulating packets.
	tunnel source, on page 182	Sets a tunnel interface's source address.

tunnel ttl