



## **Virtual Private Network Command Reference for Cisco CRS Series Routers, IOS XR Release 6.6.x**

**First Published:** 2019-12-01

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

# Full Cisco Trademarks with Software License

---

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on standards documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on standards documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2019 Cisco Systems, Inc. All rights reserved.





# CONTENTS

## Full Cisco Trademarks with Software License ii

---

### PREFACE

#### Preface ix

Changes to This Document ix

Communications, Services, and Additional Information ix

---

### CHAPTER 1

#### Ethernet Interfaces Commands 1

encapsulation dot1ad dot1q 2

encapsulation dot1q 4

encapsulation dot1q second-dot1q 5

l2transport (Ethernet) 6

rewrite ingress tag 7

---

### CHAPTER 2

#### Virtual Private Network Commands 9

authentication (L2TP) 11

backup disable (L2VPN) 13

clear l2tp counters control session 15

clear l2tp counters control tunnel 16

clear l2tp tunnel 17

clear l2vpn collaborators 18

clear l2vpn counters l2tp 19

clear l2vpn counters bridge mac-withdrawal 20

clear l2vpn forwarding counters 21

clear l2vpn forwarding mac-address-table 22

clear l2vpn forwarding message counters 24

clear l2vpn forwarding table 25

|                                       |    |
|---------------------------------------|----|
| digest (L2TP)                         | 26 |
| hello-interval (L2TP)                 | 28 |
| hidden (L2TP)                         | 30 |
| hostname (L2TP)                       | 32 |
| interface (p2p)                       | 34 |
| l2tp-class                            | 36 |
| l2transport                           | 37 |
| l2transport l2protocol                | 39 |
| l2transport propagate                 | 41 |
| l2transport service-policy            | 43 |
| l2vpn                                 | 44 |
| load-balancing flow-label             | 45 |
| logging (l2vpn)                       | 47 |
| logging nsr                           | 48 |
| monitor-session (l2vpn)               | 49 |
| mpls static label (L2VPN)             | 50 |
| neighbor (L2VPN)                      | 52 |
| nsr (L2VPN)                           | 54 |
| password (L2TP)                       | 55 |
| pw-class (L2VPN)                      | 57 |
| pw-class encapsulation l2tpv3         | 58 |
| pw-class encapsulation mpls           | 60 |
| pw-ether                              | 62 |
| pw-grouping                           | 64 |
| p2p                                   | 65 |
| receive-window (L2TP)                 | 66 |
| retransmit (L2TP)                     | 68 |
| rollover (L3VPN)                      | 70 |
| show generic-interface-list           | 71 |
| show l2tp class                       | 73 |
| show l2tp counters forwarding session | 75 |
| show l2tp session                     | 77 |
| show l2tp tunnel                      | 79 |
| show l2vpn                            | 81 |

|                                   |     |
|-----------------------------------|-----|
| show l2vpn atom-db                | 82  |
| show l2vpn collaborators          | 85  |
| show l2vpn database               | 87  |
| show l2vpn forwarding             | 90  |
| show l2vpn forwarding l2tp        | 98  |
| show l2vpn generic-interface-list | 99  |
| show l2vpn index                  | 101 |
| show l2vpn nsr                    | 103 |
| show l2vpn provision queue        | 105 |
| show l2vpn pw-class               | 107 |
| show l2vpn pwhe                   | 109 |
| show l2vpn resource               | 111 |
| show l2vpn trace                  | 112 |
| show l2vpn xconnect               | 114 |
| show tunnel-template              | 124 |
| storm-control                     | 126 |
| tag-impose                        | 129 |
| tag-rewrite                       | 130 |
| timeout setup (L2TP)              | 131 |
| transport mode (L2VPN)            | 133 |
| transport mode vlan passthrough   | 134 |
| tunnel-template                   | 135 |
| xconnect group                    | 136 |

---

## CHAPTER 3      **Virtual Private LAN Services Commands**      137

|                                  |     |
|----------------------------------|-----|
| action (VPLS)                    | 138 |
| aging (VPLS)                     | 140 |
| bridge-domain (VPLS)             | 142 |
| bridge group (VPLS)              | 143 |
| clear l2vpn bridge-domain (VPLS) | 144 |
| flooding disable                 | 145 |
| interface (VPLS)                 | 147 |
| learning disable (VPLS)          | 149 |
| limit (VPLS)                     | 151 |

|  |     |
|--|-----|
| mac (VPLS)   | 153 |
| maximum (VPLS)   | 155 |
| mpls static label (VPLS)                               | 157 |
| mtu (VPLS)   | 159 |
| neighbor (VPLS)  | 161 |
| notification (VPLS)                                    | 163 |
| port-down flush disable (VPLS)                         | 165 |
| pw-class (VFI)   | 167 |
| show l2vpn bridge-domain (VPLS)                        | 169 |
| show l2vpn forwarding bridge-domain (VPLS)             | 178 |
| show l2vpn forwarding bridge-domain mac-address (VPLS) | 194 |
| shutdown (Bridge Domain)                               | 205 |
| shutdown (VFI)   | 206 |
| static-address (VPLS)                                  | 208 |
| static-mac-address (VPLS)                              | 210 |
| time (VPLS)  | 212 |
| type (VPLS)  | 214 |
| vfi (VPLS)   | 216 |
| withdraw (VPLS)  | 218 |

---

**CHAPTER 4**
**Generic Routing Encapsulation Commands 221**

|                     |     |
|---------------------|-----|
| interface tunnel-ip | 222 |
| keepalive           | 223 |
| tunnel destination  | 224 |
| tunnel dfbit        | 225 |
| tunnel mode         | 226 |
| tunnel source       | 227 |
| tunnel tos          | 229 |
| tunnel ttl          | 230 |





## Preface

---

The preface contains these sections:

- [Changes to This Document, on page ix](#)
- [Communications, Services, and Additional Information, on page ix](#)

## Changes to This Document



---

**Note** *This software release has reached end-of-life status. For more information, see the [End-of-Life and End-of-Sale Notices](#).*

---

The following table lists the technical changes made to this document since it was first published.

| Date          | Change Summary                    |
|---------------|-----------------------------------|
| December 2019 | Initial release of this document. |

## Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

**Cisco Bug Search Tool**

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



# Ethernet Interfaces Commands

---

This module describes the Cisco IOS XR software commands used to configure the Ethernet interfaces on the Cisco CRS Router.



---

**Note** This module does not include the commands for Management Ethernet interfaces and Ethernet OAM. To configure a Management Ethernet interface for routing or modify the configuration of a Management Ethernet interface or to configure Ethernet OAM, use the commands described in the *Interface and Hardware Component Configuration Guide for Cisco CRS Routers*

---

Refer to the *Interface and Hardware Component Command Reference for Cisco CRS Routers* for more information on the Ethernet Interfaces and Ethernet OAM commands.

- [encapsulation dot1ad dot1q, on page 2](#)
- [encapsulation dot1q, on page 4](#)
- [encapsulation dot1q second-dot1q, on page 5](#)
- [l2transport \(Ethernet\), on page 6](#)
- [rewrite ingress tag, on page 7](#)

# encapsulation dot1ad dot1q

To define the matching criteria to be used in order to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance, use the **encapsulation dot1ad dot1q** command in subinterface configuration mode. To delete the matching criteria to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance, use the **no** form of this command.

**encapsulation dot1ad** *vlan-id* **dot1q** {*vlan-id* | **any**}  
**no encapsulation dot1ad** *vlan-id* **dot1q** {*vlan-id* | **any**}

## Syntax Description

**dot1ad** Indicates that the IEEE 802.1ad provider bridges encapsulation type is used for the outer tag.

**dot1q** Indicates that the IEEE 802.1q standard encapsulation type is used for the inner tag.

*vlan-id* VLAN ID, integer in the range 1 to 4094.

**any** Matches any VLAN ID.

## Command Default

No matching criteria are defined.

## Command Modes

Subinterface configuration

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 5.1.1 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The outer VLAN tag is an 802.1ad VLAN tag, instead of an 802.1Q tag. An 802.1ad tag has an ethertype value of 0x88A8, instead of 0x8100 that 802.1Q uses.

Some of the fields in the 802.1ad VLAN header are interpreted differently per 802.1ad standard. A **tunneling ethertype** command applied to the main interface does not apply to an 802.1ad subinterface.

An interface with encapsulation dot1ad causes the router to categorize the interface as an 802.1ad interface. This causes special processing for certain protocols and other features:

- MSTP uses the IEEE 802.1ad MAC STP address instead of the STP MAC address.
- Certain QoS functions may use the Drop Eligibility (DE) bit of the IEEE 802.1ad tag.

## Examples

The following example shows how to map single-tagged 802.1ad ingress frames to a service instance:

```
RP/0/RP0/CPU0:router(config-subif)# encapsulation dot1ad 100 dot1q 20
```

**Related Commands**

| Command  | Description   |
|--|---|
| <a href="#">encapsulation dot1q, on page 4</a> | Defines the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance. |

# encapsulation dot1q

To define the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance, use the **encapsulation dot1q** command in the subinterface configuration mode. To delete the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance, use the **no** form of this command.

**encapsulation dot1q** *vlan-id*  
**no encapsulation**

|                           |   |
|---------------------------|---|
| <b>Syntax Description</b> | <b>vlan-id</b> VLAN ID, integer in the range 1 to 4094. |
|---------------------------|---|

|                        |                                   |
|------------------------|-----------------------------------|
| <b>Command Default</b> | No matching criteria are defined. |
|------------------------|-----------------------------------|

|                      |                            |
|----------------------|----------------------------|
| <b>Command Modes</b> | Subinterface configuration |
|----------------------|----------------------------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 5.1.1  | This command was introduced. |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Only one encapsulation statement can be applied to a subinterface. Encapsulation statements cannot be applied to main interfaces.

A single encapsulation dot1q statement specifies matching for frames with a single VLAN ID.

## Examples

The following example shows how to map 802.1Q frames ingress on an l2transport subinterface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/1/0/3.10 l2transport
RP/0/RP0/CPU0:router(config-subif)# encapsulation dot1q 10
```

|                         |   |  |
|-------------------------|---|--|
| <b>Related Commands</b> | <b>Command</b>  | <b>Description</b>   |
|                         | <a href="#">encapsulation dot1ad dot1q, on page 2</a>       | Defines the matching criteria to be used in order to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance. |
|                         | <a href="#">encapsulation dot1q second-dot1q, on page 5</a> | Defines the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance.                                    |

# encapsulation dot1q second-dot1q

To define the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance, use the **encapsulation dot1q second-dot1q** command in the subinterface configuration mode. To delete the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance, use the **no** form of this command.

**encapsulation dot1q** {any | *vlan-id* } **second-dot1q** {any | *vlan-id* }  
**no encapsulation dot1q** {any | *vlan-id* } **second-dot1q** {any | *vlan-id* }

|                           |                     |  |
|---------------------------|---------------------|--|
| <b>Syntax Description</b> | <i>vlan-id</i>      | VLAN ID, integer in the range 1 to 4094.<br><br>A maximum of nine ranges or individual values may be specified. The values must not overlap. |
|                           | <b>second-dot1q</b> | (Optional) Specifies IEEE 802.1Q VLAN tagged packets.  |
|                           | <b>any</b>          | Any second tag in the range 1 to 4094.   |

**Command Default** No matching criteria are defined.

**Command Modes** Subinterface configuration

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 5.1.1  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The criteria for this command are: the outer tag must be unique and the inner tag may be a single VLAN.

QinQ service instance, allows single, multiple or range on second-dot1q.

Only one encapsulation command must be configured per service instance.

## Examples

The following example shows how to map ingress frames to a service instance:

```
RP/0/RP0/CPU0:router(config-subif)# encapsulation dot1q second-dot1q 20
```

|                         |   |  |
|-------------------------|---|--|
| <b>Related Commands</b> | <b>Command</b>  | <b>Description</b>   |
|                         | <a href="#">encapsulation dot1ad dot1q, on page 2</a> | Defines the matching criteria to be used in order to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance. |
|                         | <a href="#">encapsulation dot1q, on page 4</a>        | Defines the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance.                                    |

# l2transport (Ethernet)

To enable Layer 2 transport port mode on an Ethernet interface and enter Layer 2 transport configuration mode, use the **l2transport** command in interface or subinterface configuration mode for an Ethernet interface. To disable Layer 2 transport port mode on an Ethernet interface, use the **no** form of this command.

**l2transport**

**no l2transport**

This command has no keywords or arguments.

## Command Default

None

## Command Modes

Interface or Subinterface configuration

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 5.1.1 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

## Examples

The following example shows how to use the l2transport command on an Ethernet subinterface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/1/0/3.10 l2transport
RP/0/RP0/CPU0:router(config-subif)# encapsulation dot1q 10
```

## Related Commands

| Command                    | Description   |
|----------------------------|---|
| <b>show interfaces</b>     | Displays statistics for all interfaces configured on the router or for a specific node. |
| <b>show l2vpn xconnect</b> | Displays brief information on configured xconnects.                                     |



## rewrite ingress tag

To specify the encapsulation adjustment that is to be performed on the frame ingress to the service instance, use the **rewrite ingress tag** command in the subinterface configuration mode. To delete the encapsulation adjustment that is to be performed on the frame ingress to the service instance, use the **no** form of this command.

```
rewrite ingress tag {push {dot1q vlan-id | dot1q vlan-id second-dot1q vlan-id | dot1ad vlan-id
dot1q vlan-id} | pop {1 | 2} | translate {1to1 {dot1q vlan-id | dot1ad vlan-id} | 2-to-1 dot1q vlan-id
| dot1ad vlan-id} | 1-to-2 {dot1q vlan-id second-dot1q vlan-id | dot1ad vlan-id dot1q vlan-id} | 2-to-2
{dot1q vlan-id second-dot1q vlan-id | dot1ad vlan-id dot1q vlan-id}} [symmetric]
no rewrite tag [symmetric]
```

| Syntax Description  |  |  |
|---|--|--|
| <i>vlan-id</i>  |  | VLAN ID, integer in the range 1 to 4094.   |
| <b>push dot1q</b> <i>vlan-id</i>  |  | Pushes one 802.1Q tag with <i>vlan-id</i> .  |
| <b>push dot1q</b> <i>vlan-id</i> <b>second-dot1q</b> <i>vlan-id</i>             |  | Pushes a pair of 802.1Q tags in the order first, second.   |
| <b>pop</b> {1   2}  |  | One or two tags are removed from the packet. This command can be combined with a push (pop N and subsequent push <i>vlan-id</i> ). |
| <b>translate 1-to-1 dot1q</b> <i>vlan-id</i>                                    |  | Replaces the incoming tag (defined in the encapsulation command) into a different 802.1Q tag at the ingress service instance.      |
| <b>translate 2-to-1 dot1q</b> <i>vlan-id</i>                                    |  | Replaces a pair of tags defined in the <b>encapsulation</b> command by <i>vlan-id</i> .  |
| <b>translate 1-to-2 dot1q</b> <i>vlan-id</i> <b>second-dot1q</b> <i>vlan-id</i> |  | Replaces the incoming tag defined by the encapsulation command by a pair of 802.1Q tags.   |
| <b>translate 2-to-2 dot1q</b> <i>vlan-id</i> <b>second-dot1q</b> <i>vlan-id</i> |  | Replaces the pair of tags defined by the encapsulation command by a pair of VLANs defined by this rewrite.                         |
| <b>symmetric</b>  |  | (Optional) A rewrite operation is applied on both ingress and egress. The operation on egress is the inverse operation as ingress. |

**Command Default** The frame is left intact on ingress.

**Command Modes** Subinterface configuration

| Command History | Release       | Modification                 |
|-----------------|---------------|------------------------------|
|                 | Release 5.1.1 | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **symmetric** keyword is accepted only when a single VLAN is configured in encapsulation. If a list of VLANs or a range VLAN is configured in encapsulation, the **symmetric** keyword is accepted only for push rewrite operations; all other rewrite operations are rejected.

The **pop** command assumes the elements being popped are defined by the encapsulation type. The exception case should be drop the packet.

The **rewrite ingress tag translate** command assume the tags being translated from are defined by the encapsulation type. In the 2-to-1 option, the “2” means “2 tags of a type defined by the **encapsulation** command. The translation operation requires at least “from” tag in the original packet. If the original packet contains more tags than the ones defined in the “from”, then the operation should be done beginning on the outer tag. Exception cases should be dropped.

## Examples

The following example shows how to specify the encapsulation adjustment that is to be performed on the frame ingress to the service instance:

```
RP/0/RP0/CPU0:router(config-subif)# rewrite ingress push dot1q 200
```

## Related Commands

| Command   | Description  |
|---|--|
| <a href="#">encapsulation dot1ad dot1q, on page 2</a>       | Defines the matching criteria to be used in order to map single-tagged 802.1ad frames ingress on an interface to the appropriate service instance. |
| <a href="#">encapsulation dot1q, on page 4</a>              | Defines the matching criteria to map 802.1Q frames ingress on an interface to the appropriate service instance.                                    |
| <a href="#">encapsulation dot1q second-dot1q, on page 5</a> | Defines the matching criteria to map Q-in-Q ingress frames on an interface to the appropriate service instance.                                    |



## Virtual Private Network Commands

For detailed information about virtual private network concepts, configuration tasks, and examples, refer to the *Virtual Private Network Configuration Guide for Cisco CRS Routers*

- [authentication \(L2TP\), on page 11](#)
- [backup disable \(L2VPN\), on page 13](#)
- [clear l2tp counters control session, on page 15](#)
- [clear l2tp counters control tunnel, on page 16](#)
- [clear l2tp tunnel, on page 17](#)
- [clear l2vpn collaborators, on page 18](#)
- [clear l2vpn counters l2tp, on page 19](#)
- [clear l2vpn counters bridge mac-withdrawal, on page 20](#)
- [clear l2vpn forwarding counters, on page 21](#)
- [clear l2vpn forwarding mac-address-table, on page 22](#)
- [clear l2vpn forwarding message counters, on page 24](#)
- [clear l2vpn forwarding table, on page 25](#)
- [digest \(L2TP\), on page 26](#)
- [hello-interval \(L2TP\), on page 28](#)
- [hidden \(L2TP\), on page 30](#)
- [hostname \(L2TP\), on page 32](#)
- [interface \(p2p\), on page 34](#)
- [l2tp-class, on page 36](#)
- [l2transport, on page 37](#)
- [l2transport l2protocol, on page 39](#)
- [l2transport propagate, on page 41](#)
- [l2transport service-policy, on page 43](#)
- [l2vpn, on page 44](#)
- [load-balancing flow-label, on page 45](#)
- [logging \(l2vpn\), on page 47](#)
- [logging nsr, on page 48](#)
- [monitor-session \(l2vpn\), on page 49](#)
- [mpls static label \(L2VPN\), on page 50](#)
- [neighbor \(L2VPN\), on page 52](#)
- [nsr \(L2VPN\), on page 54](#)
- [password \(L2TP\), on page 55](#)

- pw-class (L2VPN), on page 57
- pw-class encapsulation l2tpv3, on page 58
- pw-class encapsulation mpls, on page 60
- pw-ether, on page 62
- pw-grouping, on page 64
- p2p, on page 65
- receive-window (L2TP), on page 66
- retransmit (L2TP), on page 68
- rollover (L3VPN), on page 70
- show generic-interface-list , on page 71
- show l2tp class, on page 73
- show l2tp counters forwarding session, on page 75
- show l2tp session, on page 77
- show l2tp tunnel, on page 79
- show l2vpn, on page 81
- show l2vpn atom-db, on page 82
- show l2vpn collaborators, on page 85
- show l2vpn database, on page 87
- show l2vpn forwarding, on page 90
- show l2vpn forwarding l2tp, on page 98
- show l2vpn generic-interface-list, on page 99
- show l2vpn index, on page 101
- show l2vpn nsr , on page 103
- show l2vpn provision queue, on page 105
- show l2vpn pw-class, on page 107
- show l2vpn pwhe, on page 109
- show l2vpn resource, on page 111
- show l2vpn trace, on page 112
- show l2vpn xconnect, on page 114
- show tunnel-template, on page 124
- storm-control , on page 126
- tag-impose, on page 129
- tag-rewrite, on page 130
- timeout setup (L2TP), on page 131
- transport mode (L2VPN), on page 133
- transport mode vlan passthrough, on page 134
- tunnel-template, on page 135
- xconnect group, on page 136

# authentication (L2TP)

To enable L2TP authentication for a specified L2TP class name, use the **authentication** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**authentication**  
**no authentication**

| <b>Syntax Description</b> | This command has no arguments or keywords.  |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | None  |         |              |               |                              |
| <b>Command Modes</b>      | L2TP class configuration  |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.9.0</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 3.9.0 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 3.9.0             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |         |              |               |                              |



**Note** You can also enable L2TP authentication for a specified class name from L2TP class configuration submode. To enter this submode, enter the **l2tp-class** command followed by the class name.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

## Examples

The following example shows how to configure L2TP authentication for the specified L2TP class name “cisco”:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# authentication
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">hello-interval (L2TP), on page 28</a> | Configures the hello-interval value for L2TP (duration between control channel hello packets). |
|                  | <a href="#">hidden (L2TP), on page 30</a>         | Enables hidden attribute-value pairs (AVPs).   |
|                  | <a href="#">hostname (L2TP), on page 32</a>       | Defines the name used in the L2TP hostname AVP.  |

| Command   | Description   |
|---|---|
| <a href="#">l2tp-class, on page 36</a>            | Enters L2TP class configuration mode where you can define an L2TP signaling template. |
| <a href="#">password (L2TP), on page 55</a>       | Defines the password and password encryption type for control channel authentication. |
| <a href="#">receive-window (L2TP), on page 66</a> | Configures the receive window size for the L2TP server.                               |
| <a href="#">retransmit (L2TP), on page 68</a>     | Configures retransmit retry and timeout values.                                       |

# backup disable (L2VPN)

To specify how long a backup pseudowire should wait before resuming primary pseudowire operation after the failure with primary pseudowire has been cleared, use the **backup disable** command in L2VPN pseudowire class configuration mode. To disable this feature, use the **no** form of this command.

**backup disable** {**delay** *value* | **never**}  
**no backup disable** {**delay** *value* | **never**}

| <b>Syntax Description</b> | <div> <div><b>delay</b><br/><i>value</i></div> <div>Specifies the number of seconds that elapse after the failure with primary pseudowire has been cleared before the Cisco IOS XR software attempts to activate the primary pseudowire.<br/><br/>The range, in seconds, is from 0 to 180. The default is 0.</div> </div> <div> <div><b>never</b></div> <div>Specifies that the secondary pseudowire does not fall back to the primary pseudowire if the primary pseudowire becomes available again, unless the secondary pseudowire fails.</div> </div> |         |              |               |                              |               |                              |
|---------------------------|--|---------|--------------|---------------|------------------------------|---------------|------------------------------|
| <b>Command Default</b>    | The default disable delay is the value of 0, which means that the primary pseudowire is activated immediately when it comes back up.   |         |              |               |                              |               |                              |
| <b>Command Modes</b>      | L2VPN pseudowire class configuration   |         |              |               |                              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> <tr> <td>Release 5.2.1</td><td>This command was introduced.</td></tr> </table>   | Release | Modification | Release 3.8.0 | This command was introduced. | Release 5.2.1 | This command was introduced. |
| Release                   | Modification   |         |              |               |                              |               |                              |
| Release 3.8.0             | This command was introduced.   |         |              |               |                              |               |                              |
| Release 5.2.1             | This command was introduced.   |         |              |               |                              |               |                              |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.  |         |              |               |                              |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>  | Task ID | Operations   | l2vpn         | read,<br>write               |               |                              |
| Task ID                   | Operations   |         |              |               |                              |               |                              |
| l2vpn                     | read,<br>write   |         |              |               |                              |               |                              |

## Examples

The following example shows how a backup delay is configured for point-to-point pseudowire in which the backup disable delay is set to 50 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class class1
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# backup disable delay 50
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# exit
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group A
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p rtrx
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.1 pw-id 2
```

```
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# pw-class class1
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# backup neighbor 10.2.2.2 pw-id 5
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)#
```

| Related Commands | Command                                      | Description  |
|------------------|--|--|
|                  | <a href="#">l2vpn, on page 44</a>            | Enters L2VPN configuration mode.   |
|                  | <a href="#">neighbor (L2VPN), on page 52</a> | Configures a pseudowire for a cross-connect.                                 |
|                  | <a href="#">p2p, on page 65</a>              | Enters p2p configuration submode to configure point-to-point cross-connects. |
|                  | <a href="#">pw-class (L2VPN), on page 57</a> | Enters pseudowire class submode to define a pseudowire class template.       |
|                  | <a href="#">xconnect group, on page 136</a>  | Configures cross-connect groups.   |



# clear l2tp counters control session

To clear L2TP control counters for a session, use the **clear l2tp counters control session** command in EXEC mode.

**clear l2tp counters control session fsm** [{event | state transition}]

## Syntax Description

|                   |  |
|-------------------|--|
| <b>fsm</b>        | (Optional) Clears finite state machine counters.     |
| <b>event</b>      | (Optional) Clears state machine event counters.      |
| <b>state</b>      | (Optional) Clears state machine state counters.      |
| <b>transition</b> | (Optional) Clears state machine transition counters. |

## Command Default

None

## Command Modes

EXEC

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.7.0 | This command was introduced. |
| Release 5.2.1 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

## Examples

The following example shows how to clear all L2TP state machine transition counters:

```
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw-backup)## clear l2tp counters control session fsm state transition
```

## Related Commands

| Command  | Description   |
|--|---|
| <a href="#">clear l2tp counters control tunnel, on page 16</a> | Clears L2TP control counters for a tunnel.                      |
| <a href="#">clear l2vpn counters l2tp, on page 19</a>          | Clears L2VPN statistical information, such as, packets dropped. |

# clear l2tp counters control tunnel

To clear L2TP control counters for a tunnel, use the **clear l2tp counters control tunnel** command in EXEC mode.

**clear l2tp counters control tunnel** {all | authentication | id *tunnel id*}

|                           |                            |  |
|---------------------------|----------------------------|--|
| <b>Syntax Description</b> | <b>all</b>                 | Clears all L2TP counters, except authentication counters |
|                           | <b>authentication</b>      | Clears tunnel authentication counters.                   |
|                           | <b>id <i>tunnel id</i></b> | Clears a specified counter. Range is 1 to 4294967295.    |

**Command Default** None

**Command Modes** EXEC

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.9.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

**Examples** The following example shows how to clear all L2TP control tunnel counters:

```
RP/0/RP0/CPU0:router# clear l2tp counters control tunnel all
```

|                         |   |   |
|-------------------------|---|---|
| <b>Related Commands</b> | <b>Command</b>  | <b>Description</b>  |
|                         | <a href="#">clear l2tp counters control session, on page 15</a> | Clears L2TP control counters for a session.                     |
|                         | <a href="#">clear l2vpn counters l2tp, on page 19</a>           | Clears L2VPN statistical information, such as, packets dropped. |

# clear l2tp tunnel

To clear L2TP tunnels, use the **clear l2tp tunnel** command in EXEC mode.

**clear l2tp tunnel** {**all** | **id** *tunnel id* | **l2tp-class** *class name* | **local ipv4** *ipv4 address* | **remote ipv4** *ipv4 address*}

|                    |  |  |
|--------------------|--|--|
| Syntax Description | <b>all</b>                             | Clears all L2TP tunnels.   |
|                    | <b>id</b> <i>tunnel id</i>             | Clears a specified tunnel.   |
|                    | <b>l2tp-class</b> <i>class name</i>    | Clears all L2TP tunnels based on L2TP class name.                    |
|                    | <b>local ipv4</b> <i>ipv4 address</i>  | Clears all local tunnels based on the specified local IPv4 address.  |
|                    | <b>remote ipv4</b> <i>ipv4 address</i> | Clears all remote tunnels based on the specified local IPv4 address. |

|                 |      |
|-----------------|------|
| Command Default | None |
|-----------------|------|

|               |      |
|---------------|------|
| Command Modes | EXEC |
|---------------|------|

|                 |                |                              |
|-----------------|----------------|------------------------------|
| Command History | <b>Release</b> | <b>Modification</b>          |
|                 | Release 3.9.0  | This command was introduced. |

|                  |   |
|------------------|---|
| Usage Guidelines | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|------------------|---|

|         |                |                   |
|---------|----------------|-------------------|
| Task ID | <b>Task ID</b> | <b>Operations</b> |
|         | l2vpn          | read,<br>write    |

|          |  |
|----------|--|
| Examples | The following example shows how to clear all L2TP tunnels: |
|----------|--|

```
RP/0/RP0/CPU0:router# clear l2tp tunnel all
```

|                  |   |   |
|------------------|---|---|
| Related Commands | <b>Command</b>  | <b>Description</b>                          |
|                  | <a href="#">clear l2tp counters control session, on page 15</a> | Clears L2TP control counters for a session. |
|                  | <a href="#">clear l2tp counters control tunnel, on page 16</a>  | Clears L2TP control counters for a tunnel.  |

# clear l2vpn collaborators

To clear the state change counters for L2VPN collaborators, use the **clear l2vpn collaborators** command in EXEC mode.

**clear l2vpn collaborators**

|                           |  |
|---------------------------|--|
| <b>Syntax Description</b> | This command has no arguments or keywords. |
|---------------------------|--|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |      |
|----------------------|------|
| <b>Command Modes</b> | EXEC |
|----------------------|------|

| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|------------------------|----------------|------------------------------|
|                        | Release 3.4.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|

| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|----------------|----------------|-------------------|
|                | l2vpn          | read,<br>write    |

|                 |   |
|-----------------|---|
| <b>Examples</b> | The following example shows how to clear change counters for L2VPN collaborators: |
|-----------------|---|

```
RP/0/RP0/CPU0:router# clear l2vpn collaborators
```

| <b>Related Commands</b> | <b>Command</b>                                       | <b>Description</b>   |
|-------------------------|--|--|
|                         | <a href="#">show l2vpn collaborators, on page 85</a> | Displays information about the state of the interprocess communications connections between l2vpn_mgr and other processes. |

# clear l2vpn counters l2tp

To clear L2VPN statistical information, such as, packets dropped, use the **clear l2vpn counters l2tp** command in EXEC mode.

**clear l2vpn counters l2tp** [**neighbor** *ip-address* [**pw-id** *value*]]

|                    |   |  |  |
|--------------------|---|--|--|
| Syntax Description | <b>l2tp</b>   | Clears all L2TP counters.  |  |
|                    | <b>neighbor</b><br><i>ip-address</i>  | (Optional) Clears all L2TP counters for the specified neighbor.  |  |
|                    | <b>pw-id</b> <i>value</i>   | (Optional) Configures the pseudowire ID. The range is from 1 to 4294967295.  |  |
| Command Default    | None  |  |  |
| Command Modes      | EXEC  |  |  |
| Command History    | <b>Release</b>  | <b>Modification</b>  |  |
|                    | Release 3.9.0   | This command was introduced.   |  |
| Usage Guidelines   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |  |  |
| Task ID            | <b>Task ID</b>  | <b>Operations</b>  |  |
|                    | l2vpn   | read,<br>write   |  |
| Examples           | The following example shows how to clear all L2TP counters:<br><br>RP/0/RP0/CPU0:router# <b>clear l2vpn counters l2tp</b>   |  |  |
| Related Commands   | <b>Command</b>  | <b>Description</b>   |  |
|                    | <a href="#">show l2vpn collaborators, on page 85</a>  | Displays information about the state of the interprocess communications connections between l2vpn_mgr and other processes. |  |

# clear l2vpn counters bridge mac-withdrawal

To clear the MAC withdrawal statistics for the counters of the bridge domain, use the **clear l2vpn counters bridge mac-withdrawal** command in EXEC mode.

**clear l2vpn counters bridge mac-withdrawal** {**all** | **group** *group-name* **bd-name** *bd-name* | **neighbor** *ip-address* **pw-id** *value*}

|                           |                                   |  |
|---------------------------|-----------------------------------|--|
| <b>Syntax Description</b> | <b>all</b>                        | Clears the MAC withdrawal statistics over all the bridges.   |
|                           | <b>group</b> <i>group-name</i>    | Clears the MAC withdrawal statistics over the specified group.   |
|                           | <b>bd-name</b> <i>bd-name</i>     | Clears the MAC withdrawal statistics over the specified bridge.  |
|                           | <b>neighbor</b> <i>ip-address</i> | Clears the MAC withdrawal statistics over the specified neighbor.                                      |
|                           | <b>pw-id</b> <i>value</i>         | Clears the MAC withdrawal statistics over the specified pseudowire. The range is from 1 to 4294967295. |

**Command Default** None

**Command Modes** EXEC

| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|------------------------|----------------|------------------------------|
|                        | Release 3.9.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|----------------|----------------|-------------------|
|                | l2vpn          | read,<br>write    |

**Examples** The following example shows how to clear the MAC withdrawal statistics over all the bridges:

```
RP/0/RP0/CPU0:router# clear l2vpn counters bridge mac-withdrawal all
```

# clear l2vpn forwarding counters

To clear L2VPN forwarding counters, use the **clear l2vpn forwarding counters** command in EXEC mode.

**clear l2vpn forwarding counters**

|                           |  |
|---------------------------|--|
| <b>Syntax Description</b> | This command has no arguments or keywords. |
|---------------------------|--|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |      |
|----------------------|------|
| <b>Command Modes</b> | EXEC |
|----------------------|------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.4.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

|                 |   |
|-----------------|---|
| <b>Examples</b> | The following example shows how to clear L2VPN forwarding counters: |
|-----------------|---|

```
RP/0/RP0/CPU0:router# clear l2vpn forwarding counters
```

|                         |   |   |
|-------------------------|---|---|
| <b>Related Commands</b> | <b>Command</b>                                    | <b>Description</b>  |
|                         | <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card. |

# clear l2vpn forwarding mac-address-table

To clear L2VPN forwarding MAC address tables, use the **clear l2vpn forwarding mac-address-table** command in EXEC mode.

**clear l2vpn forwarding mac-address-table** {**address** *address* | **bridge-domain** *name* | **interface** *type* *interface-path-id* | **location** *node-id*}

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <i>address</i>  | Clears a specified MAC address.   |
|                           | <b>bridge-domain</b> <i>name</i>  | Clears bridge domains learned from a MAC address table.   |
|                           | <i>type</i>   | (Optional) Interface type. For more information, use the question mark (?) online help function.  |
|                           | <i>interface-path-id</i>  | Physical interface or a virtual interface.<br><br><b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.<br><br>For more information about the syntax for the router, use the question mark (?) online help function. |
|                           | <b>location</b> <i>node-id</i>  | Clears L2VPN forwarding message counters for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.  |
|                           |   |   |
| <b>Command Default</b>    | None  |   |
| <b>Command Modes</b>      | EXEC  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>   |
|                           | Release 3.5.0   | This command was introduced.  |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>   |
|                           | l2vpn   | read, write, execute  |
| <b>Examples</b>           | The following example shows how to clear L2VPN forwarding MAC address tables on a specified node:   |   |



```
RP/0/RP0/CPU0:router# clear l2vpn forwarding mac-address location 1/1/1
```

**Related Commands**

| Command   | Description   |
|---|---|
| <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card. |

# clear l2vpn forwarding message counters

To clear L2VPN forwarding message counters, use the **clear l2vpn forwarding message counters** command in EXEC mode.

**clear l2vpn forwarding message counters location** *node-id*

| Syntax Description                                | <b>location</b> Clears L2VPN forwarding message counters for the specified location.<br><i>node-id</i>  |  |         |              |   |   |
|---|---|--|---------|--------------|---|---|
| Command Default                                   | None  |  |         |              |   |   |
| Command Modes                                     | EXEC  |  |         |              |   |   |
| Command History                                   | <table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 3.5.0</td><td>This command was introduced.</td></tr></table>   |  | Release | Modification | Release 3.5.0                                     | This command was introduced.  |
| Release   | Modification  |  |         |              |   |   |
| Release 3.5.0                                     | This command was introduced.  |  |         |              |   |   |
| Usage Guidelines                                  | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |  |         |              |   |   |
| Task ID   | <table><tr><th>Task ID</th><th>Operations</th></tr><tr><td>l2vpn</td><td>read,<br/>write</td></tr></table>  |  | Task ID | Operations   | l2vpn   | read,<br>write  |
| Task ID   | Operations  |  |         |              |   |   |
| l2vpn   | read,<br>write  |  |         |              |   |   |
| Examples  | The following example shows how to clear L2VPN forwarding message counters on a specified node:<br><br>RP/0/RP0/CPU0:router# <b>clear l2vpn forwarding message counters location 0/6/CPU0</b>   |  |         |              |   |   |
| Related Commands                                  | <table><tr><th>Command</th><th>Description</th></tr><tr><td><a href="#">show l2vpn forwarding, on page 90</a></td><td>Displays forwarding information from the layer2_fib manager on the line card.</td></tr></table>                 |  | Command | Description  | <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card. |
| Command   | Description   |  |         |              |   |   |
| <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card.   |  |         |              |   |   |

# clear l2vpn forwarding table

To clear an L2VPN forwarding table at a specified location, use the **clear l2vpn forwarding table** command in EXEC mode.

**clear l2vpn forwarding table location** *node-id*

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <b>location</b> Clears L2VPN forwarding tables for the specified location.<br><i>node-id</i>  |   |
| <b>Command Default</b>    | None  |   |
| <b>Command Modes</b>      | EXEC  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>   |
|                           | Release 3.4.0   | This command was introduced.  |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>   |
|                           | l2vpn   | read,<br>write  |
| <b>Examples</b>           | The following example shows how to clear an L2VPN forwarding table from a specified location:<br><br>RP/0/RP0/CPU0:router# <b>clear l2vpn forwarding table location 1/2/3/5</b>   |   |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>  |
|                           | <a href="#">show l2vpn forwarding, on page 90</a>   | Displays forwarding information from the layer2_fib manager on the line card. |

# digest (L2TP)

To configure digest options, use the **digest** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

```
digest {check disable | hash {MD5 | SHA1} | secret {0 | 7word}}
no digest {check disable | hash {MD5 | SHA1} | secret {0 | 7word}}
```

## Syntax Description

|   |  |
|---|--|
| <b>check disable</b>                                | Disables digest checking.  |
| <b>hash</b> { <b>MD5</b>   <b>SHA1</b> }            | Configures the digest hash method (MD5 or SHA1). Default is MD5. |
| <b>secret</b> { <b>0</b>   <b>7</b>   <i>word</i> } | Configures a shared secret for message digest.                   |

## Command Default

**check disable:** Digest checking is enabled by default.

**hash:** Default is MD5 if the **digest** command is issued without the secret keyword option and L2TPv3 integrity checking is enabled.

## Command Modes

L2TP class configuration

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The digest secret and hash algorithm can be configured in the l2tp-class configuration for authentication of the control channel. For control channel authentication to work correctly, however, both sides of the L2TP control channel connection must share a common secret and hash algorithm.

To update of digest secret without network disruption, Cisco supports a maximum to two digest secrets. You can configure a new secret while keeping the old secret valid. You can safely remove the old secret after you update all affected peer nodes with a new secret,

## Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

## Examples

The following example shows how to configure digest options for L2TP:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
```

```
RP/0/RP0/CPU0:router(config-l2tp-class)# digest check disable  
RP/0/RP0/CPU0:router(config-l2tp-class)# digest secret cisco hash md5
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">authentication (L2TP), on page 11</a> | Enables L2TP authentication for a specified L2TP class name.                                   |
|                  | <a href="#">hello-interval (L2TP), on page 28</a> | Configures the hello-interval value for L2TP (duration between control channel hello packets). |
|                  | <a href="#">hidden (L2TP), on page 30</a>         | Enables hidden attribute-value pairs (AVPs).   |
|                  | <a href="#">hostname (L2TP), on page 32</a>       | Defines the name used in the L2TP hostname AVP.  |
|                  | <a href="#">l2tp-class, on page 36</a>            | Enters L2TP class configuration mode where you can define an L2TP signaling template.          |
|                  | <a href="#">password (L2TP), on page 55</a>       | Defines the password and password encryption type for control channel authentication.          |
|                  | <a href="#">receive-window (L2TP), on page 66</a> | Configures the receive window size for the L2TP server.  |
|                  | <a href="#">retransmit (L2TP), on page 68</a>     | Configures retransmit retry and timeout values.  |

# hello-interval (L2TP)

To configure the hello-interval value for L2TP (duration between control channel hello packets), use the **hello-interval (L2TP)** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**hello-interval** *interval*  
**no hello-interval** *interval*

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <i>interval</i> Interval (in seconds) between control channel hello packets. The range is from 0 to 1000. Default is 60 seconds.  |   |
| <b>Command Default</b>    | <i>interval</i> : 60 seconds  |   |
| <b>Command Modes</b>      | L2TP class configuration  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>   |
|                           | Release 3.9.0   | This command was introduced.  |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.                     |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>   |
|                           | l2vpn   | read,<br>write  |
| <b>Examples</b>           | <p>The following example shows how to configure the hello-interval value for L2TP to 22 seconds:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2tp-class cisco RP/0/RP0/CPU0:router(config-l2tp-class)# hello-interval 22</pre> |   |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>  |
|                           | <a href="#">authentication (L2TP), on page 11</a>   | Enables L2TP authentication for a specified L2TP class name.                          |
|                           | <a href="#">hidden (L2TP), on page 30</a>   | Enables hidden attribute-value pairs (AVPs).  |
|                           | <a href="#">hostname (L2TP), on page 32</a>   | Defines the name used in the L2TP hostname AVP.                                       |
|                           | <a href="#">l2tp-class, on page 36</a>  | Enters L2TP class configuration mode where you can define an L2TP signaling template. |
|                           | <a href="#">password (L2TP), on page 55</a>   | Defines the password and password encryption type for control channel authentication. |

| Command   | Description   |
|---|---|
| <a href="#">receive-window (L2TP), on page 66</a> | Configures the receive window size for the L2TP server. |
| <a href="#">retransmit (L2TP), on page 68</a>     | Configures retransmit retry and timeout values.         |

# hidden (L2TP)

To enable hidden attribute-value pairs (AVPs), use the **hidden** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**hidden**  
**no hidden**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** L2TP class configuration

| Command History | Release       | Modification                 |
|-----------------|---------------|------------------------------|
|                 | Release 3.9.0 | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

## Examples

The following example shows how to enable hidden AVPs:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# hidden
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">authentication (L2TP), on page 11</a> | Enables L2TP authentication for a specified L2TP class name.                                   |
|                  | <a href="#">hello-interval (L2TP), on page 28</a> | Configures the hello-interval value for L2TP (duration between control channel hello packets). |
|                  | <a href="#">hostname (L2TP), on page 32</a>       | Defines the name used in the L2TP hostname AVP.  |
|                  | <a href="#">l2tp-class, on page 36</a>            | Enters L2TP class configuration mode where you can define an L2TP signaling template.          |
|                  | <a href="#">password (L2TP), on page 55</a>       | Defines the password and password encryption type for control channel authentication.          |
|                  | <a href="#">receive-window (L2TP), on page 66</a> | Configures the receive window size for the L2TP server.  |



| Command                                       | Description                                     |
|---|---|
| <a href="#">retransmit (L2TP), on page 68</a> | Configures retransmit retry and timeout values. |

# hostname (L2TP)

To define the name used in the L2TP hostname AVP, use the **hostname** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**hostname** *name*  
**no hostname** *name*

## Syntax Description

*name* Hostname used to identify the router during L2TP control channel authentication.

## Command Default

None

## Command Modes

L2TP class configuration

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

## Examples

The following example shows how to configure a hostname using the word “cisco”:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# hostname cisco
```

## Related Commands

| Command   | Description  |
|---|--|
| <a href="#">authentication (L2TP), on page 11</a> | Enables L2TP authentication for a specified L2TP class name.                                   |
| <a href="#">hello-interval (L2TP), on page 28</a> | Configures the hello-interval value for L2TP (duration between control channel hello packets). |
| <a href="#">hidden (L2TP), on page 30</a>         | Enables hidden attribute-value pairs (AVPs).   |
| <a href="#">l2tp-class, on page 36</a>            | Enters L2TP class configuration mode where you can define an L2TP signaling template.          |
| <a href="#">password (L2TP), on page 55</a>       | Defines the password and password encryption type for control channel authentication.          |

| Command   | Description   |
|---|---|
| <a href="#">receive-window (L2TP), on page 66</a> | Configures the receive window size for the L2TP server. |
| <a href="#">retransmit (L2TP), on page 68</a>     | Configures retransmit retry and timeout values.         |

# interface (p2p)

To configure an attachment circuit, use the **interface** command in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

**interface** *type interface-path-id* [**PW-Ether** | **PW-IW**]  
**no interface** *type interface-path-id* [**PW-Ether** | **PW-IW**]

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <i>type</i>   | Interface type. For more information, use the question mark (?) online help function.                               |
|                           | <i>interface-path-id</i>  | Physical interface or a virtual interface.  |
|                           | <b>Note</b>   | Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router. |
|                           |   | For more information about the syntax for the router, use the question mark (?) online help function.               |
|                           | <b>PW-Ether</b>   | (Optional) Configures an Ethernet Interface.  |
| <b>Command Default</b>    | <b>PW-IW</b>  | (Optional) Configures an IP Interworking Interface.   |
|                           |   |   |
| <b>Command Modes</b>      | p2p configuration submode   |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>   |
|                           | Release 3.4.0   | This command was introduced.  |
|                           | Release 4.2.1   | The following keywords were added:  |
|                           |   | <ul style="list-style-type: none"> <li>• <b>PW-Ether</b></li> <li>• <b>PW-IW</b></li> </ul>                         |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>   |
|                           | l2vpn   | read,<br>write  |
| <b>Examples</b>           | <p>The following example shows how to configure an attachment circuit on a TenGigE interface:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn</pre>  |   |

```
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group gr1  
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p p001  
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# interface TenGigE 1/1/1/1
```

**Related Commands**

| Command                         | Description  |
|---------------------------------|--|
| <a href="#">p2p, on page 65</a> | Enters p2p configuration submode to configure point-to-point cross-connects. |

# l2tp-class

To enter L2TP class configuration mode where you can define an L2TP signaling template, use the **l2tp-class** command in global configuration mode. To delete the L2TP class, use the **no** form of this command.

**l2tp-class** *l2tp-class-name*  
**no l2tp-class** *l2tp-class-name*

|                           |   |
|---------------------------|---|
| <b>Syntax Description</b> | <i>l2tp-class-name</i> L2TP class name. |
|---------------------------|---|

|                        |                              |
|------------------------|------------------------------|
| <b>Command Default</b> | No L2TP classes are defined. |
|------------------------|------------------------------|

|                      |                      |
|----------------------|----------------------|
| <b>Command Modes</b> | Global configuration |
|----------------------|----------------------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.9.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|



|             |  |
|-------------|--|
| <b>Note</b> | An L2TP class name must be defined before configuring L2TP control plane configuration settings. |
|-------------|--|

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

## Examples

The following example shows how to enter L2TP configuration mode to create a template of L2TP control plane configuration settings that can be inherited by different pseudowire classes (in this case, the word “cisco” is used):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)#
```

# l2transport

To configure a physical interface to operate in Layer 2 transport mode, use the **l2transport** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

**l2transport**  
**no l2transport**

This command has no arguments or keywords.

## Command Default

None

## Command Modes

Interface configuration

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.4.0 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The l2transport command and these configuration items are mutually exclusive:

- IPv4 address and feature (for example, ACL) configuration
- IPv4 enable, address and feature (for example, ACL) configuration
- Bundle-enabling configuration
- L3 subinterfaces
- Layer 3 QoS Policy



### Note

After an interface or connection is set to Layer 2 switched, commands such as **ipv4 address** are not usable. If you configure routing commands on the interface, **l2transport** is rejected.

## Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

## Examples

The following example shows how to configure an interface or connection as Layer 2 switched under several different modes:

### Ethernet Port Mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RP0/CPU0:router(config-if)# l2transport
```

**Ethernet VLAN Mode:**

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/RP0/CPU0:router(config-if)# encapsulation dot1q 100dot1q vlan 999
```

**Ethernet VLAN Mode (QinQ):**

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/RP0/CPU0:router(config-if)# encapsulation dot1q 20 second-dot1q 10vlan 999 888
```

**Ethernet VLAN Mode (QinAny):**

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0.900 l2transport
RP/0/RP0/CPU0:router(config-if)# encapsulation dot1q 30 second-dot1q dot1q vlan 999 any
```

**Related Commands**

| Command   | Description   |
|---|---|
| <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card. |



# l2transport l2protocol

To configure Layer 2 protocol handling, use the **l2transport l2protocol** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

**l2transport l2protocol** {**cdp** | **pvst** | **stp** | **vtp**} {**drop** | **experimental bits** | **tunnel experimental bits**}  
**no l2transport l2protocol** {**cdp** | **pvst** | **stp** | **vtp**} {**drop** | **experimental bits** | **tunnel experimental bits**}

|                           |                                 |  |
|---------------------------|---------------------------------|--|
| <b>Syntax Description</b> | <b>cdp</b>                      | Configures Cisco Discovery Protocol (CDP).         |
|                           | <b>pvst</b>                     | Configures Per VLAN Spanning Tree protocol (PVST). |
|                           | <b>stp</b>                      | Configures Spanning Tree Protocol (STP).           |
|                           | <b>vtp</b>                      | Configures VLAN Trunk Protocol (VTP).              |
|                           | <b>drop</b>                     | Drops the selected protocol packets.               |
|                           | <b>experimental bits</b>        | Modifies the MPLS experimental bits.               |
|                           | <b>tunnel experimental bits</b> | Configures tunnel protocol packets.                |

**Command Default** None

**Command Modes** Interface configuration

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.9.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

These L2 protocols are available:

- Cisco Discovery Protocol (CDP)—CDP is protocol-independent and is used to obtain protocol addresses, platform information, and other data about neighboring devices.
- PVST maintains a spanning tree instance for each VLAN configured in the network and permits a VLAN trunk to be forwarding for some VLANs and not for others. It can also load balance Layer 2 traffic by forwarding some VLANs on one trunk and other VLANs on others.
- Spanning-Tree Protocol (STP)—STP is a link management protocol that provides path redundancy in the network. For Ethernet networks to function properly, only one active path can exist between two stations.

- VLAN Trunk Protocol (VTP)—VTP is a Cisco-proprietary protocol that reduces administration in a switched network. When you configure a new VLAN on one VTP server, the VLAN is distributed through all switches in the domain.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |
|         | atm     | read,<br>write |

## Examples

The following example shows how to configure Layer 2 protocol handling:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RP0/CPU0:router(config-if)# l2transport l2protocol cpsv reverse-tunnelstp drop
```

| Related Commands | Command   | Description   |
|------------------|---|---|
|                  | <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card. |

# l2transport propagate

To propagate Layer 2 transport events, use the **l2transport propagate** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

**l2transport propagate remote-status**  
**no l2transport propagate remote-status**

|                           |   |
|---------------------------|---|
| <b>Syntax Description</b> | <b>remote-status</b> Propagates remote link status changes. |
|---------------------------|---|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |                         |
|----------------------|-------------------------|
| <b>Command Modes</b> | Interface configuration |
|----------------------|-------------------------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.6.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **l2transport propagate** command provides a mechanism for the detection and propagation of remote link failure for port mode EoMPLS.



**Note** If you configure the propagate Layer 2 transport using this command on both ends of the PW (head and tail end), the PW might flap continuously. Use the **carrier-delay** command on the attachment circuit to stabilize the PW.

To display the state of l2transport events, use the **show controller internal** command in *Interface and Hardware Component Configuration Guide for Cisco CRS Routers*



**Note** This command is supported on the following Cisco CRS Router SPA cards:

- Cisco 1-Port 10 Gigabit Ethernet Shared Port Adapter, Version 2
- Cisco 2-port, 5-port, 8-port, and 10-port Gigabit Ethernet Shared Port Adapters
- Cisco 2-, 5-, 8-, and 10-Port Gigabit Ethernet Shared Port Adapters, Version 2
- Cisco 1-Port 10 Gigabit Ethernet LAN/WAN-PHY Shared Port Adapter

Any port on 6-10GE-WLO-FLEX (irrespective of SPA or fixed) does not support the **l2transport propagate** command.

For more information about the Ethernet remote port shutdown feature, see *MPLS Configuration Guide for the Cisco CRS Routers*.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

### Examples

The following example shows how to propagate remote link status changes:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RP0/CPU0:router(config-if)# l2transport propagate remote remote-status
```

| Related Commands | Command   | Description   |
|------------------|---|---|
|                  | <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card. |

# l2transport service-policy

To configure a Layer 2 transport quality of service (QoS) policy, use the **l2transport service-policy** command in interface configuration mode. To return to the default behavior, use the **no** form of this command.

**l2transport service-policy** {**input** *policy-name* | **output** *policy-name*}  
**no l2transport service-policy** {**input** *policy-name* | **output** *policy-name*}

## Syntax Description

|                                  |   |
|----------------------------------|---|
| <b>input</b> <i>policy-name</i>  | Configures the direction of service policy application: input.  |
| <b>output</b> <i>policy-name</i> | Configures the direction of service policy application: output. |

## Command Default

None

## Command Modes

Interface configuration

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |
| atm     | read,<br>write |

## Examples

The following example shows how configure an L2 transport quality of service (QoS) policy:

```
RP/0/RSP0RP00/CPU0:router# configure
RP/0/RSP0RP00/CPU0:router(config)# interface GigabitEthernet 0/0/0/0
RP/0/RSP0RP00/CPU0:router(config-if)# l2transport service-policy input sp_0001
```

## Related Commands

| Command   | Description   |
|---|---|
| <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card. |

# l2vpn

To enter L2VPN configuration mode, use the **l2vpn** command in global configuration mode. To return to the default behavior, use the **no** form of this command.

**l2vpn**  
**no l2vpn**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Global configuration

| Command History | Release       | Modification                 |
|-----------------|---------------|------------------------------|
|                 | Release 3.4.0 | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** All L2VPN configuration can be deleted using the **no l2vpn** command.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

## Examples

The following example shows how to enter L2VPN configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)#
```

| Related Commands | Command   | Description   |
|------------------|---|---|
|                  | <a href="#">show l2vpn forwarding, on page 90</a> | Displays forwarding information from the layer2_fib manager on the line card. |

# load-balancing flow-label

To balance the load based on flow-labels, use the **load-balancing flow label** command in the l2vpn pseudowire class mpls configuration submode or l2vpn bridge group bridge-domain vfi autodiscovery bgp or ldp signaling submodes. To undo flow-label based load-balancing, use the **no** form of this command.

**load-balancing flow-label** {**both** | **code** | **receive** | **transmit**}[**{static}**]  
**no load-balancing flow-label** {**both** | **code** | **receive** | **transmit**}[**{static}**]

|                           |  |  |
|---------------------------|--|--|
| <b>Syntax Description</b> | <b>both</b>  | Inserts or discards flow labels on transmit or receive.                      |
|                           | <b>code</b>  | Specifies the flow label TLV (type-length-value) code. The code value is 17. |
|                           | <b>receive</b>   | Discards flow label on receive.  |
|                           | <b>transmit</b>  | Inserts flow label on transmit.  |
|                           | <b>static</b>  | Sets flow label parameters statically.                                       |
| <b>Command Default</b>    | None   |  |
| <b>Command Modes</b>      | L2vpn pseudowire class mpls configuration submode  |  |
|                           | L2vpn bridge group bridge-domain vfi autodiscovery bgp signaling submode   |  |
|                           | L2vpn bridge group bridge-domain vfi autodiscovery ldp signaling submode   |  |
| <b>Command History</b>    | <b>Release</b>   | <b>Modification</b>  |
|                           | Release 4.2.0  | This command was introduced.   |
|                           | Release 4.3.2  | The <b>code</b> keyword was introduced.                                      |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.  |  |
|                           | In the <a href="#">draft-ietf-pwe3-fat-pw</a> document, the flow label sub-TLV identifier for the Flow Aware Transport Pseudowire (FAT PW) was 0x11. This value has been changed to 0x17, which is also the sub-TLV identifier assigned by the Internet Assigned Numbers Authority (IANA). |  |
|                           | Use the <b>load-balancing flow label code</b> command to toggle between the sub-TLV identifiers—0x11 and 0x17. If there is a mismatch between two endpoints in the load-balancing flow label code, then the PWs will have a mismatched TLV value resulting in a load balancing failure.    |  |
|                           | The <b>no</b> form of the <b>load-balancing flow label code</b> command uses the flow label sub-TLV identifier 0x11.   |  |

| Task ID | Task ID | Operation      |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

This example shows the output of the **load-balancing flow-label** command of the **both** keyword.

```
RP/0/RP0/CPU0:router#config
RP/0/RP0/CPU0:router(config)#l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)#pw-class p1
RP/0/RP0/CPU0:router(config-l2vpn-pwc)#encapsulation
RP/0/RP0/CPU0:router(config-l2vpn-pwc)#encapsulation mpls
RP/0/RP0/CPU0:router(config-l2vpn-pwc-mpls)#load-balancing
RP/0/RP0/CPU0:router(config-l2vpn-pwc-mpls)#load-balancing flow-label
RP/0/RP0/CPU0:router(config-l2vpn-pwc-mpls)#load-balancing flow-label both
RP/0/RP0/CPU0:router(config-l2vpn-pwc-mpls)#load-balancing flow-label both static
```

#### Related Commands

| Command   | Description                               |
|---|---|
| <a href="#">pw-class encapsulation mpls, on page 60</a> | Configures MPLS pseudowire encapsulation. |



# logging (l2vpn)

To enable cross-connect logging, use the **logging** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

**logging pseudowire status**  
**no logging pseudowire status**

|                           |  |
|---------------------------|--|
| <b>Syntax Description</b> | pseudowire status Enables pseudowire state change logging. |
|---------------------------|--|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |                             |
|----------------------|-----------------------------|
| <b>Command Modes</b> | L2VPN configuration submode |
|----------------------|-----------------------------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.5.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|



|             |   |
|-------------|---|
| <b>Note</b> | All L2VPN configuration can be deleted using the <b>no l2vpn</b> command. |
|-------------|---|

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

## Examples

The following example shows how to enable cross-connect logging:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# logging pseudowire status
```

|                         |                                   |                                  |
|-------------------------|-----------------------------------|----------------------------------|
| <b>Related Commands</b> | <b>Command</b>                    | <b>Description</b>               |
|                         | <a href="#">l2vpn, on page 44</a> | Enters L2VPN configuration mode. |

# logging nsr

To enable non-stop routing logging, use the **logging nsr** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

**logging nsr**  
**no logging nsr**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN configuration submode

| Command History | Release       | Modification                 |
|-----------------|---------------|------------------------------|
|                 | Release 4.3.0 | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** All L2VPN configuration can be deleted using the **no l2vpn** command.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

**Examples** The following example shows how to enable non-stop routing logging:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# logging nsr
```

| Related Commands | Command                           | Description                      |
|------------------|-----------------------------------|----------------------------------|
|                  | <a href="#">l2vpn, on page 44</a> | Enters L2VPN configuration mode. |

## monitor-session (l2vpn)

To attach a traffic monitoring session as one of the segments for a cross connect, use the **monitor-session** command in point-to-point cross connect configuration mode. To remove the association between a traffic mirroring session and a cross connect, use the **no** form of this command.

**monitor-session** *session-name*  
**no monitor-session** *session-name*

|                           |   |                              |
|---------------------------|---|------------------------------|
| <b>Syntax Description</b> | <i>session-name</i> Name of the monitor session to configure.   |                              |
| <b>Command Default</b>    | No default behavior or values   |                              |
| <b>Command Modes</b>      | Point-to-point cross connect configuration  |                              |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>          |
|                           | Release 4.0.0   | This command was introduced. |
| <b>Usage Guidelines</b>   | <p>Before you can attach a traffic mirroring session to a cross connect, you must define it using the <b>monitor-session</b> global configuration command. Once the traffic mirroring session is defined, use the <b>monitor-session</b> point-to-point cross connect configuration command to attach this session as one of the segments for the cross connect. Once attached, all traffic replicated from the monitored interfaces (in other words, interfaces that are associated with the monitor-session) is replicated to the pseudowire that is attached to the other segment of the cross-connect.</p> <p>The <i>session-name</i> argument should be different than any interface names currently used in the system.</p> |                              |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>            |
|                           | l2vpn   | read,<br>write               |
| <b>Examples</b>           | <p>This example shows how to attach a traffic mirroring session as segment for the xconnect:</p> <pre>RP/0/RSP0/CPU0:router(config)# l2vpn RP/0/RSP0/CPU0:router(config-l2vpn)# xconnect group g1 RP/0/RSP0/CPU0:router(config-l2vpn-xc)# p2p xcon1 RP/0/RSP0/CPU0:router(config-l2vpn-xc-p2p)# monitor-session mon1</pre>  |                              |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>           |
|                           | See the <b>monitor session</b> command in the <i>Interface and Hardware Component Command Reference for Cisco CRS Routers</i> .   |                              |

## mpls static label (L2VPN)

To configure static labels for MPLS L2VPN, use the **mpls static label** command in L2VPN cross-connect P2P pseudowire configuration mode. To have MPLS assign a label dynamically, use the **no** form of this command.

**mpls static label local** *label* **remote** *value*  
**no mpls static label local** *label* **remote** *value*

|                    |  |  |
|--------------------|--|--|
| Syntax Description | <b>local</b> <i>label</i> Configures a local pseudowire label. Range is 16 to 15999.   |  |
|                    | <b>remote</b> <i>value</i> Configures a remote pseudowire label. Range is 16 to 15999.   |  |
| Command Default    | The default behavior is a dynamic label assignment.  |  |
| Command Modes      | L2VPN cross-connect P2P pseudowire configuration   |  |
| Command History    | Release  | Modification   |
|                    | Release 3.7.0    This command was introduced.  |  |
| Usage Guidelines   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.  |  |
| Task ID            | Task ID  | Operations   |
|                    | l2vpn  | read,<br>write   |
| Examples           | The following example shows how to configure static labels for MPLS L2VPN:<br><br>RP/0/RP0/CPU0:router# <b>configure</b><br>RP/0/RP0/CPU0:router(config)# <b>l2vpn xconnect group l2vpn</b><br>RP/0/RP0/CPU0:router(config-l2vpn-xc)# <b>p2p rtrA_to_rtrB</b><br>RP/0/RP0/CPU0:router(config-xc-p2p)# <b>neighbor 10.1.1.2 pw-id 1000</b><br>RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# <b>mpls static label local 800 remote 500</b> |  |
| Related Commands   | Command  | Description  |
|                    | <a href="#">l2vpn, on page 44</a>  | Enters L2VPN configuration mode.   |
|                    | <a href="#">neighbor (L2VPN), on page 52</a>   | Configures a pseudowire for a cross-connect.                                 |
|                    | <a href="#">p2p, on page 65</a>  | Enters p2p configuration submode to configure point-to-point cross-connects. |

| Command                                     | Description                      |
|---|----------------------------------|
| <a href="#">xconnect group, on page 136</a> | Configures cross-connect groups. |

## neighbor (L2VPN)

To configure a pseudowire for a cross-connect, use the **neighbor** command in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

**neighbor** *A.B.C.D* **pw-id** *value* [{**backup** | **mpls** | | **pw-class** | **tag-impose**}]  
**no neighbor** *A.B.C.D* **pw-id** *value* [{**backup** | **mpls** | | **pw-class** | **tag-impose**}]

### Syntax Description

|                              |  |
|------------------------------|--|
| <i>A.B.C.D</i>               | IP address of the cross-connect peer.                                |
| <b>pw-id</b><br><i>value</i> | Configures the pseudowire ID and ID value. Range is 1 to 4294967295. |
| <b>tag-impose</b>            | Optional Specifies a tag during a VLAN ID configuration.             |

### Command Default

None

### Command Modes

p2p configuration submode

### Command History

| Release       | Modification  |
|---------------|---|
| Release 3.4.0 | This command was introduced.  |
| Release 3.4.1 | The <b>vccv disable</b> keyword was added.  |
| Release 3.7.0 | These keywords were removed: <ul style="list-style-type: none"> <li>• <b>control-word</b></li> <li>• <b>pw-static-label local</b></li> <li>• <b>remote</b></li> <li>• <b>vccv</b></li> <li>• <b>transport-mode</b></li> </ul> |
| Release 4.2.1 | The keyword <b>tag-impose</b> was introduced.   |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

A cross-connect may have two segments:

1. An Attachment Circuit (AC)
2. An second AC or a pseudowire



#### Note

The pseudowire is identified by two keys: neighbor and pseudowire ID. There may be multiple pseudowires going to the same neighbor. It is not possible to configure only a neighbor.

All L2VPN configurations can be deleted using the **no l2vpn** command.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

### Examples

This example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000 pw-class class12
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.3 pw-id 1001 pw-class class13
RP/0/RP0/CPU0:router(config-xc)# p2p rtrC_to_rtrD
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.2.2.3 pw-id 200 pw-class class23
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.2.2.4 pw-id 201 pw-class class24
```

This example shows a point-to-point cross-connect configuration (including pseudowire configuration):

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn xconnect group l2vpn
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 10.1.1.2 pw-id 1000 pw-class foo
RP/0/RP0/CPU0:router(config-xc)# p2p rtrC_to_rtrD
RP/0/RP0/CPU0:router(config-xc-p2p)# neighbor 20.2.2.3 pw-id 200 pw-class bar1
```

| Related Commands | Command                                      | Description  |
|------------------|--|--|
|                  | <a href="#">l2vpn, on page 44</a>            | Enters L2VPN configuration mode.   |
|                  | <a href="#">p2p, on page 65</a>              | Enters p2p configuration submode to configure point-to-point cross-connects. |
|                  | <a href="#">pw-class (L2VPN), on page 57</a> | Enters pseudowire class submode to define a pseudowire class template.       |
|                  | <a href="#">xconnect group, on page 136</a>  | Configures cross-connect groups.   |

## nsr (L2VPN)

To configure non-stop routing, use the **nsr** command in L2VPN configuration submode. To return to the default behavior, use the **no** form of this command.

**nsr**  
**no nsr**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** L2VPN configuration submode

| Command History | Release       | Modification                 |
|-----------------|---------------|------------------------------|
|                 | Release 4.3.0 | This command was introduced. |

**Usage Guidelines** All L2VPN configuration can be deleted using the **no l2vpn** command.



**Note** NSR is enabled by default for L2VPN On Cisco IOS XR 64 bit operating system. You cannot configure the **nsr** command under L2VPN configuration submode.

| Task ID | Task ID | Operation      |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

The following example shows how to configure non-stop routing:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# nsr
```

| Related Commands | Command                           | Description                      |
|------------------|-----------------------------------|----------------------------------|
|                  | <a href="#">l2vpn, on page 44</a> | Enters L2VPN configuration mode. |



## password (L2TP)

To define the password and password encryption type for control channel authentication, use the **password** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**password** [{0 | 7}] *password*  
**no password**

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <b>0</b>  | (Optional) Specifies that an unencrypted password will follow.                                 |
|                           | <b>7</b>  | (Optional) Specifies that an encrypted password will follow.                                   |
|                           | <i>password</i>   | Unencrypted or clear text user password.   |
| <b>Command Default</b>    | None  |  |
| <b>Command Modes</b>      | Global configuration  |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 3.9.0   | This command was introduced.   |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.   |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | l2vpn   | read,<br>write   |
| <b>Examples</b>           | <p>The following example shows how to define an unencrypted password using the word “cisco” for control channel authentication:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2tp-class sanjose RP/0/RP0/CPU0:router(config-l2tp-class)# password 0 cisco</pre> |  |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>   |
|                           | <a href="#">authentication (L2TP), on page 11</a>   | Enables L2TP authentication for a specified L2TP class name.                                   |
|                           | <a href="#">hello-interval (L2TP), on page 28</a>   | Configures the hello-interval value for L2TP (duration between control channel hello packets). |

| Command   | Description   |
|---|---|
| <a href="#">hidden (L2TP), on page 30</a>         | Enables hidden attribute-value pairs (AVPs).  |
| <a href="#">hostname (L2TP), on page 32</a>       | Defines the name used in the L2TP hostname AVP.                                       |
| <a href="#">l2tp-class, on page 36</a>            | Enters L2TP class configuration mode where you can define an L2TP signaling template. |
| <a href="#">receive-window (L2TP), on page 66</a> | Configures the receive window size for the L2TP server.                               |
| <a href="#">retransmit (L2TP), on page 68</a>     | Configures retransmit retry and timeout values.                                       |

# pw-class (L2VPN)

To enter pseudowire class submode to define a pseudowire class template, use the **pw-class** command in L2VPN configuration submode. To delete the pseudowire class, use the **no** form of this command.

**pw-class** *class-name*  
**no pw-class** *class-name*

|                           |  |
|---------------------------|--|
| <b>Syntax Description</b> | <i>class-name</i> Pseudowire class name. |
|---------------------------|--|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |                             |
|----------------------|-----------------------------|
| <b>Command Modes</b> | L2VPN configuration submode |
|----------------------|-----------------------------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.5.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|



|             |  |
|-------------|--|
| <b>Note</b> | All L2VPN configurations can be deleted using the <b>no l2vpn</b> command. |
|-------------|--|

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

|                 |   |
|-----------------|---|
| <b>Examples</b> | The following example shows how to define a simple pseudowire class template: |
|-----------------|---|

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group l1vpn
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p rtrA_to_rtrB
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# pw-class kanata01
```

|                         |                                 |  |
|-------------------------|---------------------------------|--|
| <b>Related Commands</b> | <b>Command</b>                  | <b>Description</b>   |
|                         | <a href="#">p2p, on page 65</a> | Enters p2p configuration submode to configure point-to-point cross-connects. |

## pw-class encapsulation l2tpv3

To configure L2TPv3 pseudowire encapsulation, use the **pw-class encapsulation l2tpv3** command in L2VPN pseudowire class configuration mode. To return to the default behavior, use the **no** form of this command.

```
pw-class class name encapsulation l2tpv3 [{cookie size {0 | 4 | 8} | ipv4 source address | pmtu max 68-65535 | protocol l2tpv3 class name | tos {reflect value 0-255 | value 0-255} | ttl value}]
no pw-class class name encapsulation l2tpv3 [{cookie size {0 | 4 | 8} | ipv4 source address | pmtu max 68-65535 | protocol l2tpv3 class name | tos {reflect value 0-255 | value 0-255} | ttl value}]
```

### Syntax Description

|   |   |
|---|---|
| <b>class name</b>   | Configures an encapsulation class name.   |
| <b>cookie size</b> {0   4   8}                                | (Optional) Configures the L2TPv3 cookie size setting: <ul style="list-style-type: none"> <li>• 0—Cookie size is 0 bytes.</li> <li>• 4—Cookie size is 4 bytes.</li> <li>• 8—Cookie size is 8 bytes.</li> </ul> |
| <b>ipv4 source</b> <i>address</i>                             | (Optional) Configures the local source IPv4 address.  |
| <b>pmtu max</b> 68-65535                                      | (Optional) Configures the value of the maximum allowable session MTU.   |
| <b>protocol l2tpv3 class</b> <i>name</i>                      | (Optional) Configures L2TPv3 as the signaling protocol for the pseudowire class.  |
| <b>tos</b> { <b>reflect value</b> 0-255   <b>value</b> 0-255} | (Optional) Configures TOS and the TOS value. Range is 0 to 255.   |
| <b>ttl</b> <i>value</i>                                       | Configures the Time-to-live (TTL) value. Range is 1 to 255.   |

### Command Default

None

### Command Modes

L2VPN pseudowire class configuration

### Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** All L2VPN configurations can be deleted using the **no l2vpn** command.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

### Examples

The following example shows how to define L2TPV3 pseudowire encapsulation:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# encapsulation l2tpv3
```

The following example shows how to set the encapsulation and protocol to L2TPV3:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# encapsulation l2tpv3
RP/0/RP0/CPU0:router(config-l2vpn-pwc-l2tpv3)# protocol l2tpv3
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">pw-class (L2VPN), on page 57</a>            | Enters pseudowire class submode to define a pseudowire class template. |
|                  | <a href="#">pw-class encapsulation mpls, on page 60</a> | Configures MPLS pseudowire encapsulation.                              |

## pw-class encapsulation mpls

To configure MPLS pseudowire encapsulation, use the **pw-class encapsulation mpls** command in L2VPN pseudowire class configuration mode. To undo the configuration, use the **no** form of this command.

```
pw-class class-name encapsulation mpls {control word | ipv4 | load-balancing flow-label |
preferred-path | protocol ldp | sequencing | tag-rewrite | transport-mode | vccv verification-type none}
no pw-class class-name encapsulation mpls {control word | ipv4 | load-balancing flow-label |
preferred-path | protocol ldp | sequencing | tag-rewrite | transport-mode | vccv verification-type none}
```

### Syntax Description

|                                  |   |
|----------------------------------|---|
| <i>class-name</i>                | Encapsulation class name.   |
| <b>control word</b>              | Disables control word for MPLS encapsulation. Disabled by default.  |
| <b>ipv4</b>                      | Sets the local source IPv4 address.                                 |
| <b>load-balancing flow-label</b> | Sets flow label-based load balancing.                               |
| <b>preferred-path</b>            | Configures the preferred path tunnel settings.                      |
| <b>protocol ldp</b>              | Configures LDP as the signaling protocol for this pseudowire class. |
| <b>sequencing</b>                | Configures sequencing on receive or transmit.                       |
| <b>tag-rewrite</b>               | Configures VLAN tag rewrite.  |
| <b>transport-mode</b>            | Configures transport mode to be either Ethernet or VLAN.            |
| <b>vccv none</b>                 | Enables or disables the VCCV verification type.                     |

### Command Default

None

### Command Modes

L2VPN pseudowire class configuration

### Command History

| Release       | Modification   |
|---------------|--|
| Release 3.5.0 | This command was introduced.   |
| Release 3.8.0 | The keywords <b>control word disable</b> and <b>vccv none</b> were replaced by the keywords <b>control word</b> and <b>vccv verification-type none</b> . |

| Release | Modification |
|---------|--------------|
|---------|--------------|

|               |                                    |
|---------------|------------------------------------|
| Release 3.9.0 | The following keywords were added: |
|---------------|------------------------------------|

- |   |
|---|
| <ul style="list-style-type: none"> <li>• <b>preferred-path</b></li> <li>• <b>sequencing</b></li> <li>• <b>tag-rewrite</b></li> <li>• <b>transport-mode</b></li> </ul> |
|---|

|               |  |
|---------------|--|
| Release 4.3.0 | The keyword <b>load-balancing flow-label</b> was introduced. |
|---------------|--|

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.



**Note** All L2VPN configurations can be deleted using the **no l2vpn** command.

### Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

### Examples

This example shows how to define MPLS pseudowire encapsulation:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/RP0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls
```

### Related Commands

| Command   | Description  |
|---|--|
| <a href="#">pw-class (L2VPN), on page 57</a>              | Enters pseudowire class submode to define a pseudowire class template. |
| <a href="#">pw-class encapsulation l2tpv3, on page 58</a> | Configures L2TPv3 pseudowire encapsulation.                            |

# pw-ether

To configure a PWHE Ethernet interface, use the **pw-ether** command in global configuration mode or in p2p configuration submode. To return to the default behavior, use the **no** form of this command.

**pw-ether** *value*  
**no pw-ether** *value*

|                           |   |                              |
|---------------------------|---|------------------------------|
| <b>Syntax Description</b> | <i>value</i> Value of the PWHE Ethernet interface. The range is from 1 to 32768.  |                              |
| <b>Command Default</b>    | None  |                              |
| <b>Command Modes</b>      | Global configuration<br>p2p configuration   |                              |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>          |
|                           | Release 4.2.1   | This command was introduced. |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |                              |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operation</b>             |
|                           | interface (global configuration)  | read, write                  |
|                           | l2vpn (p2p configuration)   | read, write                  |

This example shows the sample output of a PWHE Ethernet interface configuration in global configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# attach generic-interface-list interfacelist1
```

This example shows the sample output of a PWHE Ethernet interface configuration in p2p configuration submode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group xc1
RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p grp1
RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# interface pw-ether 78
```

This example shows the sample output of L2 overhead configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
```



```
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# load-interval 32
```

This example shows the sample output of Load-interval configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# load-interval 60
```

This example shows the sample output of how to set logging of interface state change for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# logging events link-status
```

This example shows the sample output of MAC address configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# mac-address 44-37-E6-89-C3-93
```

This example shows the sample output of MTU configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# mtu 128
```

This example shows the sample output of bandwidth configuration for the PW-HE interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface pw-ether 78
RP/0/RP0/CPU0:router(config-if)# bandwidth 256
```

#### Related Commands

| Command                         | Description  |
|---------------------------------|--|
| <a href="#">p2p, on page 65</a> | Enters p2p configuration submode to configure point-to-point cross-connects. |

# pw-grouping

To enable Pseudowire Grouping, use the **pw-grouping** command in L2vpn configuration submode. To return to the default behavior, use the **no** form of this command.

**pw-grouping**  
**no pw-grouping**

|   |   |                                  |
|---|---|----------------------------------|
| <b>Syntax Description</b>   | <b>pw-grouping</b> Enables Pseudowire Grouping.   |                                  |
| <b>Command Default</b>  | PW-grouping is disabled by default.   |                                  |
| <b>Command Modes</b>  | L2VPN configuration submode   |                                  |
| <b>Command History</b>  | <b>Release</b>  | <b>Modification</b>              |
|   | Release 4.3.0   | This command was introduced.     |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |                                  |
| <b>Task ID</b>  | <b>Task ID</b>  | <b>Operation</b>                 |
|   | l2vpn   | read,<br>write                   |
| <p>This example shows the sample output of pw-grouping configuration in L2VPN configuration submode:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# pw-grouping</pre> |   |                                  |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>               |
|   | <a href="#">l2vpn, on page 44</a>   | Enters L2VPN configuration mode. |
|   | <a href="#">show l2vpn, on page 81</a>  | Displays L2VPN information       |

# p2p

To enter p2p configuration submode to configure point-to-point cross-connects, use the **p2p** command in L2VPN xconnect mode. To return to the default behavior, use the **no** form of this command.

**p2p** *xconnect-name*  
**no p2p** *xconnect-name*

|                           |  |                                   |
|---------------------------|--|-----------------------------------|
| <b>Syntax Description</b> | <i>xconnect-name</i> (Optional) Configures the name of the point-to-point cross- connect.  |                                   |
| <b>Command Default</b>    | None   |                                   |
| <b>Command Modes</b>      | L2VPN xconnect   |                                   |
| <b>Command History</b>    | <b>Release</b>   | <b>Modification</b>               |
|                           | Release 3.4.0  | This command was introduced.      |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The name of the point-to-point cross-connect string is a free format description string.</p> |                                   |
| <b>Task ID</b>            | <b>Task ID</b>   | <b>Operations</b>                 |
|                           | l2vpn  | read,<br>write                    |
| <b>Examples</b>           | <p>The following example shows a point-to-point cross-connect configuration (including pseudowire configuration):</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group group 1 RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p xc1</pre>                               |                                   |
| <b>Related Commands</b>   | <b>Command</b>   | <b>Description</b>                |
|                           | <a href="#">interface (p2p), on page 34</a>  | Configures an attachment circuit. |

# receive-window (L2TP)

To configure the receive window size for the L2TP server, use the **receive-window** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**receive-window** *size*  
**no receive-window** *size*

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <i>size</i> Maximum number of packets that are received from a peer before back-off is applied. Default is 512.   |  |
| <b>Command Default</b>    | <i>size</i> : 512   |  |
| <b>Command Modes</b>      | L2TP class configuration  |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 3.9.0   | This command was introduced.   |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.                               |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | l2vpn   | read,<br>write   |
| <b>Examples</b>           | <p>The following example shows how to configure the receive window size for the L2TP server to 10 packets:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2tp-class cisco RP/0/RP0/CPU0:router(config-l2tp-class)# receive-window 10</pre> |  |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>   |
|                           | <a href="#">authentication (L2TP), on page 11</a>   | Enables L2TP authentication for a specified L2TP class name.                                   |
|                           | <a href="#">hello-interval (L2TP), on page 28</a>   | Configures the hello-interval value for L2TP (duration between control channel hello packets). |
|                           | <a href="#">hidden (L2TP), on page 30</a>   | Enables hidden attribute-value pairs (AVPs).   |
|                           | <a href="#">hostname (L2TP), on page 32</a>   | Defines the name used in the L2TP hostname AVP.  |
|                           | <a href="#">l2tp-class, on page 36</a>  | Enters L2TP class configuration mode where you can define an L2TP signaling template.          |

| Command                                       | Description   |
|---|---|
| <a href="#">password (L2TP), on page 55</a>   | Defines the password and password encryption type for control channel authentication. |
| <a href="#">retransmit (L2TP), on page 68</a> | Configures retransmit retry and timeout values.                                       |

## retransmit (L2TP)

To configure retransmit retry and timeout values, use the **retransmit** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**retransmit** {**initial** *initial-retries* | **retries** *retries* | **timeout** {**max** | **min**} *timeout*}  
**no retransmit** {**initial** *initial-retries* | **retries** *retries* | **timeout** {**max** | **min**} *timeout*}

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <b>initial</b> <i>initial-retries</i>   | Configures the number of SCCRP messages resent before giving up on a particular control channel. Range is 1 to 1000. Default is 2.   |
|                           | <b>retries</b> <i>retries</i>   | Configures the maximum number of retransmissions before determining that peer router does not respond. Range is 5 to 1000. Default is 15.  |
|                           | <b>timeout</b> { <b>max</b>   <b>min</b> } <i>timeout</i>   | Configures the maximum and minimum retransmission interval in seconds for control packets. Range is 1 to 8. Maximum timeout default is 8 seconds. Minimum timeout default is 1 second. |
| <b>Command Default</b>    | <i>initial retries: 2</i><br><i>retries: 15</i><br><i>min timeout: 1</i><br><i>max timeout: 8</i>   |  |
| <b>Command Modes</b>      | L2TP class configuration  |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 3.9.0   | This command was introduced.   |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | l2vpn   | read,<br>write   |
| <b>Examples</b>           | <p>The following example shows how to configure a retransmit retry value to 1:</p> <pre>RP/0/RP0/CPU0:router# configure</pre>   |  |

```
RP/0/RP0/CPU0:router(config)# l2tp-class cisco
RP/0/RP0/CPU0:router(config-l2tp-class)# retransmit initial retries 1
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">authentication (L2TP), on page 11</a> | Enables L2TP authentication for a specified L2TP class name.                                   |
|                  | <a href="#">hello-interval (L2TP), on page 28</a> | Configures the hello-interval value for L2TP (duration between control channel hello packets). |
|                  | <a href="#">hidden (L2TP), on page 30</a>         | Enables hidden attribute-value pairs (AVPs).   |
|                  | <a href="#">hostname (L2TP), on page 32</a>       | Defines the name used in the L2TP hostname AVP.  |
|                  | <a href="#">l2tp-class, on page 36</a>            | Enters L2TP class configuration mode where you can define an L2TP signaling template.          |
|                  | <a href="#">password (L2TP), on page 55</a>       | Defines the password and password encryption type for control channel authentication.          |
|                  | <a href="#">receive-window (L2TP), on page 66</a> | Configures the receive window size for the L2TP server.  |

# rollover (L3VPN)

To configure rollover times for a tunnel-template, use the **rollover** command in tunnel encapsulation l2tp configuration mode. To return to the default behavior, use the **no** form of this command.

**rollover** *periodic time* **holdown time**  
**no rollover** *periodic time* **holdown time**

|                           |   |                                   |
|---------------------------|---|-----------------------------------|
| <b>Syntax Description</b> | <b>periodic time</b> Configures the periodic rollover time in seconds. Range is 60 to 31536000.   |                                   |
|                           | <b>holddowntime</b> Configures the holddown time for old session cookie values.   |                                   |
| <b>Command Default</b>    | None  |                                   |
| <b>Command Modes</b>      | tunnel encapsulation l2tp configuration   |                                   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>               |
|                           | Release 3.5.0   | This command was introduced.      |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |                                   |
|                           | The name of the point-to-point cross-connect string is a free format description string.  |                                   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>                 |
|                           | l2vpn   | read,<br>write                    |
| <b>Examples</b>           | The following example shows how to configure rollover times for a tunnel-template:  |                                   |
|                           | <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# tunnel-template kanata_9 RP/0/RP0/CPU0:router(config-tuntem) encapsulation l2tp RP/0/RP0/CPU0:router(config-tunencap-l2tp)# rollover</pre>                         |                                   |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>                |
|                           | <a href="#">interface (p2p), on page 34</a>   | Configures an attachment circuit. |



# show generic-interface-list

To display information about interface-lists, use the **show generic-interface-list** in EXEC mode.

**show generic-interface-list** [{ **location** | **name** | **retry** | **standby** }]

## Syntax Description

|                 |  |
|-----------------|--|
| <b>location</b> | (Optional) Displays information about interface-lists for the specified location.            |
| <b>name</b>     | (Optional) Displays information about interface-lists for the specified interface list name. |
| <b>retry</b>    | (Optional) Displays retry-list information.  |
| <b>standby</b>  | (Optional) Displays Standby node specific information.                                       |

## Command Default

None

## Command Modes

EXEC

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 4.3.0 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

| Task ID | Operation |
|---------|-----------|
| l2vpn   | read      |

The following example displays output for the **show generic-interface-list** command:

```
RP/0/RP0/CPU0:router# show generic-interface-list
Thu Aug  2 13:48:57.462 CDT
generic-interface-list: nsrIL (ID: 1, interfaces: 2)
  Bundle-Ether2 - items pending 0, downloaded to FIB
  GigabitEthernet0/0/0/1 - items pending 0, downloaded to FIB
Number of items: 400
List is downloaded to FIB
```

The following example displays output for the **show generic-interface-list retry private** command:

```
RP/0/RP0/CPU0:router# show generic-interface-list retry private
Thu Aug  2 14:20:42.883 CDT
total: 0 items
```

The following example displays output for the **show generic-interface-list standby** command:

```
RP/0/RP0/CPU0:router# show generic-interface-list standby
```

**show generic-interface-list**

```
Thu Aug 2 14:25:01.749 CDT
generic-interface-list: nsrIL (ID: 0, interfaces: 2)
Bundle-Ether2 - items pending 0, NOT downloaded to FIB
GigabitEthernet0/0/0/1 - items pending 0, NOT downloaded to FIB
Number of items: 0
List is not downloaded to FIB
```

**Related Commands**

| Command                           | Description                      |
|-----------------------------------|----------------------------------|
| <a href="#">l2vpn, on page 44</a> | Enters L2VPN configuration mode. |

# show l2tp class

To display information about an L2TP class, use the **show l2tp class** command in EXEC mode.

**show l2tp class name** *name*

| <b>Syntax Description</b> | <table> <tr> <td><b>name</b></td><td>Configures an L2TP class name.</td></tr> <tr> <td><i>name</i></td><td></td></tr> </table>  | <b>name</b> | Configures an L2TP class name. | <i>name</i>   |                              |
|---------------------------|---|-------------|--------------------------------|---------------|------------------------------|
| <b>name</b>               | Configures an L2TP class name.  |             |                                |               |                              |
| <i>name</i>               |   |             |                                |               |                              |
| <b>Command Default</b>    | None  |             |                                |               |                              |
| <b>Command Modes</b>      | EXEC  |             |                                |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.9.0</td><td>This command was introduced.</td></tr> </table>  | Release     | Modification                   | Release 3.9.0 | This command was introduced. |
| Release                   | Modification  |             |                                |               |                              |
| Release 3.9.0             | This command was introduced.  |             |                                |               |                              |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |             |                                |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>   | Task ID     | Operations                     | l2vpn         | read,<br>write               |
| Task ID                   | Operations  |             |                                |               |                              |
| l2vpn                     | read,<br>write  |             |                                |               |                              |

## Examples

The following example shows sample output for the **show l2vtp session class** command:

```
RP/0/RP0/CPU0:router# show l2tp class name kanata_02

l2tp-class kanata_02
  manually configured class
  configuration parameters:
    (not) hidden
    (no) authentication
    (no) digest
    digest check enable
    hello 60
    (no) hostname
    (no) password
    (no) accounting
    (no) security crypto-profile
    (no) ip vrf
    receive-window 888
    retransmit retries 15
    retransmit timeout max 8
    retransmit timeout min 1
    retransmit initial retries 2
    retransmit initial timeout max 8
```

```
retransmit initial timeout min 1
timeout setup 300
```

This table describes the significant fields shown in the display.

**Table 1: show l2tp class brief Field Descriptions**

| Field                    | Description   |
|--------------------------|---|
| l2tp-class               | Shows the L2TP class name and the manner of its creation. For example, manually configured class. |
| configuration parameters | Displays a complete list and state of all configuration parameters.                               |

#### Related Commands

| Command                                | Description   |
|--|---|
| <a href="#">l2tp-class, on page 36</a> | Enters L2TP class configuration mode where you can define an L2TP signaling template. |

# show l2tp counters forwarding session

To display L2TP forward session counters, use the **show l2tp counter forwarding session** command in EXEC mode.

**show l2tp counters forwarding session** [{**id** *identifier* | **name** *local-name remote-name*}]

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <b>id</b> <i>identifier</i>               | (Optional) Configures the session counter identifier.                   |
|                           | <b>name</b> <i>local-name remote name</i> | (Optional) Configures the local and remote names for a session counter. |

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |      |
|----------------------|------|
| <b>Command Modes</b> | EXEC |
|----------------------|------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.9.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

|                 |   |
|-----------------|---|
| <b>Examples</b> | The following example shows sample output for the <b>show l2tp counters forwarding session</b> command: |
|-----------------|---|

```
RP/0/RP00/CPU0:router(config-l2vpn)# pw-class kanata01show l2tp counters forwarding session
```

|       |       |       |         |          |          |           |
|-------|-------|-------|---------|----------|----------|-----------|
| LocID | RemID | TunID | Pkts-In | Pkts-Out | Bytes-In | Bytes-Out |
| 22112 | 15584 | 14332 | 0       | 0        | 0        | 0         |

This table describes the significant fields shown in the display.

**Table 2: show l2tp counters forwarding session Field Descriptions**

| Field | Description                       |
|-------|-----------------------------------|
| LocID | Local session ID.                 |
| RemID | Remote session ID.                |
| TunID | Local Tunnel ID for this session. |

 show l2tp counters forwarding session

| Field     | Description                              |
|-----------|--|
| Pkts-In   | Number of packets input in the session.  |
| Pkts-Out  | Number of packets output in the session. |
| Bytes-In  | Number of bytes input in the session.    |
| Bytes-Out | Number of bytes output in the session.   |

---

**Related Commands**

| Command                    | Description |
|----------------------------|-------------|
| <a href="#">#unique_59</a> |             |

# show l2tp session

To display information about L2TP sessions, use the **show l2tp session** command in EXEC mode.

**show l2tp session** [{**detail** | **brief** | **interworking** | **circuit** | **sequence** | **state**}] [**id** *id* | **name** *name*]

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <b>brief</b>  | (Optional) Displays summary output for a session.                     |
|                           | <b>circuit</b>  | (Optional) Displays attachment circuit information for a session.     |
|                           | <b>detail</b>   | (Optional) Displays detailed output for a session.                    |
|                           | <b>interworking</b>   | (Optional) Displays interworking information for a session.           |
|                           | <b>sequence</b>   | (Optional) Displays data packet sequencing information for a session. |
|                           | <b>state</b>  | (Optional) Displays control plane state information for a session.    |
|                           | <b>id</b> <i>id</i>   | Configures the local tunnel ID. Range is 0 to 4294967295.             |
|                           | <b>name</b> <i>name</i>   | Configures the tunnel name.   |
| <b>Command Default</b>    | None  |   |
| <b>Command Modes</b>      | EXEC  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>   |
|                           | Release 3.9.0   | This command was introduced.  |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.   |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>   |
|                           | l2vpn   | read,<br>write  |
| <b>Examples</b>           | <p>The following sample output is from the <b>show l2tp session brief</b> command:</p> <pre>RP/0/RP00/CPU0:router(config-l2vpn-pw)# show l2tp session brief Tue Jun 10 12:51:30.901 UTC LocID      TunID      Peer-address  State      Username, Intf/sess/cir  Vcid, Circuit 1606803058 1487464659 26.26.26.26   est,UP     101, Gi0/2/0/1.101 3663696887 1487464659 26.26.26.26   est,UP     100, Gi0/2/0/1.100</pre> |   |

This table describes the significant fields shown in the display.

**Table 3: show l2tp session brief Field Descriptions**

| Field        | Description   |
|--------------|---|
| LocID        | Local session ID.   |
| TunID        | Local tunnel ID for this session.   |
| Peer-address | The IP address of the other end of the session.   |
| State        | The state of the session.   |
| Vcid         | The Virtual Circuit ID of the session. This is the same value of the pseudowire ID for l2vpn. |

The following sample output is from the **show l2tp session detail** command:

```
RP/0/RP00/CPU0:router(config-l2vpn-pw)# show l2tp session detail
Tue Jun 10 12:53:19.842 UTC
Session id 1606803058 is up, tunnel id 1487464659, logical session id 131097
  Remote session id is 2602674409, remote tunnel id 2064960537
  Remotely initiated session
  Call serial number is 4117500017
  Remote tunnel name is ASR9K-PE2
    Internet address is 26.26.26.26:1248
  Local tunnel name is PRABHRAM-PE1
    Internet address is 25.25.25.25:4272
IP protocol 115
  Session is L2TP signaled
  Session state is established, time since change 00:07:28
  UDP checksums are disabled
  Session cookie information:
    local cookie, size 4 bytes, value 6d 3e 03 67
    remote cookie, size 4 bytes, value 0d ac 7a 3b
  Tie breaker is 0xfee65781a2fa2cfd, enabled TRUE.
  Sequencing is off
  Conditional debugging is disabled
  Unique ID is 101
Session Layer 2 circuit
  Payload type is Ethernet, Name is GigabitEthernet0_2_0_1.101
  Session vcid is 101
  Circuit state is UP
    Local circuit state is UP
    Remote circuit state is UP
```

## Related Commands

| Command                    | Description |
|----------------------------|-------------|
| <a href="#">#unique_59</a> |             |



# show l2tp tunnel

To display information about L2TP tunnels, use the **show l2tp tunnel** command in EXEC mode.

**show l2tp tunnel** {**detail** | **brief** | **state** | **transport**} {**id** *identifier* | **name** *local-name remote-name*}

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <b>detail</b>   | Displays detailed output for L2TP tunnels.                             |
|                           | <b>brief</b>  | Displays summary information for the tunnel.                           |
|                           | <b>state</b>  | Displays control plane state information.                              |
|                           | <b>transport</b>  | Displays transport information (IP) for each selected control channel. |
|                           | <b>id</b> <i>identifier</i>   | Displays local control channel identifiers.                            |
|                           | <b>name</b> <i>local-name remote-name</i>   | Displays the local and remote names of a control channel.              |
| <b>Command Default</b>    | None  |  |
| <b>Command Modes</b>      | EXEC  |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 3.9.0   | This command was introduced.   |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | l2vpn   | read,<br>write   |

## Examples

The following sample output is from the **show l2tp tunnel brief** command:

```
RP/0/RP0/CPU0:router(config-l2vpn-encap-mps)# show l2tp tunnel brief
Tue Jun 10 12:46:04.421 UTC
LocTunID  RemTunID  Remote Name  State  Vrf Name  Remote Address  Sessn L2TP Class/Count
VPDN Group
1487464659 2064960537 ASR9K-PE2    est           26.26.26.26      2      L2TPV3_CLASS
```

This table describes the significant fields shown in the display.

Table 4: show l2tp tunnel Field Descriptions

| Field          | Description                    |
|----------------|--------------------------------|
| LocTunID       | Local session ID.              |
| RemTunID       | Remote session ID.             |
| Remote Name    | Remote name of the session.    |
| State          | State of the session.          |
| Remote Address | Remote address of the session. |
| Port           | Session port.                  |
| Sessions       | Number of sessions.            |
| L2TP           | L2TP class name.               |

The following sample output is from the **show l2tp tunnel detail** command:

```
RP/0/RP0/CPU0:router(config-l2vpn-encap-mpls)# show l2tp tunnel detail
Tue Jun 10 12:47:36.638 UTC
Tunnel id 1487464659 is up, remote id is 2064960537, 2 active sessions
  Remotely initiated tunnel
  Tunnel state is established, time since change 4d19h
  Tunnel transport is IP (115)
  Remote tunnel name is ASR9K-PE2
    Internet Address 26.26.26.26, port 0
  Local tunnel name is PRABHRAM-PE1
    Internet Address 25.25.25.25, port 0
  VRF table id is 0xe0000000
  Tunnel group id
  L2TP class for tunnel is L2TPV3_CLASS
  Control Ns 4178, Nr 4181
  Local RWS 512 (default), Remote RWS 512
  Control channel Congestion Control is disabled
  Tunnel PMTU checking disabled
  Retransmission time 1, max 1 seconds
  Unsent queuesize 0, max 0
  Resend queuesize 0, max 1
  Total resends 0, ZLB ACKs sent 4177
  Total out-of-order dropped pkts 0
  Total out-of-order reorder pkts 0
  Total peer authentication failures 0
  Current no session pak queue check 0 of 5
  Retransmit time distribution: 0 0 0 0 0 0 0 0
  Control message authentication is disabled
```

## Related Commands

| Command                                       | Description                               |
|---|---|
| <a href="#">show l2tp session, on page 77</a> | Displays information about L2TP sessions. |

# show l2vpn

To display L2VPN information, use the **show l2vpn** command in EXEC mode.

## show l2vpn

|                           |   |                              |
|---------------------------|---|------------------------------|
| <b>Syntax Description</b> | This command has no keywords or arguments.  |                              |
| <b>Command Default</b>    | None  |                              |
| <b>Command Modes</b>      | EXEC  |                              |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>          |
|                           | Release 4.3.0   | This command was introduced. |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |                              |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operation</b>             |
|                           | l2vpn   | read                         |

## Example

The following example displays output for the **show l2vpn** command. The output provides an overview of the state of the globally configured features.

```
RP/0/RP0/CPU0:router# show l2vpn
Mon May  7 15:01:17.963 BST
PW-Status: disabled
PW-Grouping: disabled
Logging PW: disabled
Logging BD state changes: disabled
Logging VFI state changes: disabled
Logging NSR state changes: disabled
TCN propagation: disabled
PWOAMRefreshTX: 30s
```

| Related Commands | Command                                 | Description                      |
|------------------|---|----------------------------------|
|                  | <a href="#">l2vpn, on page 44</a>       | Enters L2VPN configuration mode. |
|                  | <a href="#">pw-grouping, on page 64</a> | Enables Pseudowire Grouping      |

# show l2vpn atom-db

To display AToM database information, use the **show l2vpn atom-db** command in EXEC mode.

**show l2vpn atom-db** [{**detail** | **l2-rid** | **ldp-rid** | **local-gid** | **neighbor** | **preferred-path** | **remote-gid** | **source**}]

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <b>detail</b>   | Specifies the details of the database.                     |
|                           | <b>l2-rid</b>   | Specifies the AToM database walking the L2 RID thread.     |
|                           | <b>ldp-rid</b>  | Specifies the AToM database walking the LDP RID thread.    |
|                           | <b>local-gid</b>  | Specifies the AToM database walking the Local GID thread.  |
|                           | <b>neighbor</b>   | Specifies the details of the neighbor database.            |
|                           | <b>preferred-path</b>   | Specifies the preferred path (tunnel) of the database      |
|                           | <b>remote-gid</b>   | Specifies the AToM database walking the Remote GID thread. |
|                           | <b>source</b>   | Specifies the details of the source database.              |
| <b>Command Default</b>    | None  |  |
| <b>Command Modes</b>      | EXEC  |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 4.2.1   | This command was introduced.                               |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | l2vpn   | read   |

## Examples

This example shows the sample output of the **show l2vpn atom-db source 10.0.0.1** command:

```
RP/0/RP0/CPU0:router# show l2vpn atom-db source 10.0.0.1
Peer ID      Source      VC ID      Encap      Signaling   FEC      Discovery
172.16.0.1   10.0.0.1    1          MPLS       LDP         128     none
```

This example shows the sample output of the **show l2vpn atom-db source 10.0.0.1 detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn atom-db source 10.0.0.1 detail
PW: neighbor 172.16.0.1, PW ID 1, state is down ( provisioned )
PW class class1, XC ID 0x1
Encapsulation MPLS, protocol LDP
Source address 10.0.0.1
PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
```

| MPLS         | Local                    | Remote  |
|--------------|--------------------------|---------|
| Label        | 16000                    | unknown |
| Group ID     | 0x20000060               | 0x0     |
| Interface    | GigabitEthernet0/0/0/1.1 | unknown |
| MTU          | 1504                     | unknown |
| Control word | disabled                 | unknown |
| PW type      | Ethernet                 | unknown |
| VCCV CV type | 0x2                      | 0x0     |
|              |                          | (none)  |
|              | (LSP ping verification)  |         |
| VCCV CC type | 0x6                      | 0x0     |
|              |                          | (none)  |
|              | (router alert label)     |         |
|              | (TTL expiry)             |         |

```
-----
MIB cpwVcIndex: 4278194081
Create time: 13/12/2010 15:28:26 (20:32:27 ago)
Last time status changed: 13/12/2010 15:28:26 (20:32:27 ago)
Configuration info:
  PW class: class1
  Peer ID = 172.16.0.1, pseudowire ID = 1
  Control word is not set
  Transport mode: not set
    Configured (Static) Encapsulation: not set
    Provisioned Encapsulation: MPLS
  Static tag rewrite: not set
  MTU: 1504
  Tunnel interface: None
  IW type: 0
  PW type: Dynamic
  Pref path configured: No
  Bridge port: No
  BP learning disabled: No
  BP ucast flooding disabled: No
  BP bcast flooding disabled: No
  CW is mandatory: No
  Label: local unassigned, remote unassigned
  L2 Router-ID: 0.0.0.0
  LDP Router-ID: 0.0.0.0
  GR stale: No
LDP Status: local established, remote unknown
LDP tag rewrite: not set
Force switchover: inactive
MAC trigger: inactive
VC sane: Yes
Use PW Status: No
Local PW Status: Up(0x0); Remote PW Status: Up(0x0)
Peer FEC Failed: No
LSP: Down
Operational state:
  LDP session state: down
  TE tunnel transport: No
  VC in gr mode: No
  Peer state: up
```

```

Transport LSP down: Yes
Advertised label to LDP: No
Received a label from LSD: Yes
Need to send standby bit: No
VC created from rbinding: No
PW redundancy dampening on : No
Notified up : No
Detailed segment state: down
PW event trace history [Total events: 8]
-----

```

| Time                | Event          | Value    |
|---------------------|----------------|----------|
| ====                | =====          | =====    |
| 12/13/2010 15:28:26 | LSP Down       | 0        |
| 12/13/2010 15:28:26 | Provision      | 0        |
| 12/13/2010 15:28:26 | LSP Down       | 0        |
| 12/13/2010 15:28:26 | Connect Req    | 0        |
| 12/13/2010 15:28:26 | Rewrite create | 0x100000 |
| 12/13/2010 15:28:26 | Got label      | 0x3e80   |
| 12/13/2010 15:28:26 | Local Mtu      | 0x5e0    |
| 12/13/2010 15:28:26 | Peer Up        | 0        |

# show l2vpn collaborators

To display information about the state of the interprocess communications connections between l2vpn\_mgr and other processes, use the **show l2vpn collaborators** command in EXEC mode.

## show l2vpn collaborators

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC

**Command History**

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.4.0 | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID**

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

## Examples

The following example shows sample output for the **show l2vpn collaborators** command:

```
RP/0/RP0/CPU0:router# show l2vpn collaborators
L2VPN Collaborator stats:
Name                State           Up Cnts         Down Cnts
-----
IMC                  Down            0                0
LSD                  Up              1                0
```

This table describes the significant fields shown in the display.

**Table 5: show l2vpn collaborators Field Descriptions**

| Field   | Description   |
|---------|---|
| Name    | Abbreviated name of the task interacting with l2vpn_mgr.  |
| State   | Indicates if l2vpn_mgr has a working connection with the other process.                                   |
| Up Cnts | Number of times the connection between l2vpn_mgr and the other process has been successfully established. |

 show l2vpn collaborators

| Field     | Description  |
|-----------|--|
| Down Cnts | Number of times that the connection between l2vpn_mgr and the other process has failed or been terminated. |

---

**Related Commands**

| Command   | Description   |
|---|---|
| <a href="#">clear l2vpn collaborators, on page 18</a> | Clears the state change counters for L2VPN collaborators. |



# show l2vpn database

To display L2VPN database, use the **show l2vpn database** command in EXEC mode.

**show l2vpn database {ac | node}**

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <b>ac</b>   | Displays L2VPN Attachment Circuit (AC) database |
|                           | <b>node</b>   | Displays L2VPN node database.                   |
| <b>Command Default</b>    | None  |   |
| <b>Command Modes</b>      | EXEC  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>                             |
|                           | Release 4.3.0   | This command was introduced.                    |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |   |
|                           | Even when xSTP (extended spanning tree protocol) operates in the PVRST mode, the output of the show or debug commands flag prefix is displayed as MSTP or MSTi, instead of PVRST.   |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operation</b>                                |
|                           | l2vpn   | read  |

The following example displays output for the **show l2vpn database ac** command:

```
RP/0/RP0/CPU0:router# show l2vpn database ac
Bundle-Ether1.1:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x0
  Signaled capability valid: No
  Signaled capability flags: 0x0
  Configured capability flags: 0x0
  XCID: 0xffffffff
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-ifname: Bundle-Ether1.1
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x020000e0
    ac-type: 0x15
    interworking: 0x00
  AC info:
```

**show l2vpn database**

```

        seg-status-flags: 0x00000000
        segment mtu/l2-mtu: 1504/1518

GigabitEthernet0/0/0/0.4096:
  Other-Segment MTU: 0
  Other-Segment status flags: 0x0
  Signaled capability valid: No
  Signaled capability flags: 0x0
  Configured capability flags: 0x0
  XCID: 0x0
  PSN Type: Undefined
  ETH data:
    Xconnect tags: 0
    Vlan rewrite tag: 0
  AC defn:
    ac-ifname: GigabitEthernet0_0_0_0.4096
    capabilities: 0x00368079
    extra-capabilities: 0x00000000
    parent-ifh: 0x040000c0
    ac-type: 0x15
    interworking: 0x00
  AC info:
    seg-status-flags: 0x00000003
    segment mtu/l2-mtu: 1504/1518

```

The following example displays output for the **show l2vpn database node** command:

```

RP/0/RP0/CPU0:router# show l2vpn database node
0/RSP0/CPU0
  MA: vlan_ma

    AC event trace history [Total events: 4]
    -----
    Time                Event                Num Rcvd    Num Sent
    ====                =====
    07/27/2012 15:00:31 Process joined          0           0
    07/27/2012 15:00:31 Process init success    0           0
    07/27/2012 15:00:31 Replay start rcvd       0           0
    07/27/2012 15:00:31 Replay end rcvd        2           0

  MA: ether_ma

    AC event trace history [Total events: 4]
    -----
    Time                Event                Num Rcvd    Num Sent
    ====                =====
    07/27/2012 15:00:31 Process joined          0           0
    07/27/2012 15:00:31 Process init success    0           0
    07/27/2012 15:00:31 Replay start rcvd       0           0
    07/27/2012 15:00:31 Replay end rcvd        0           0

0/0/CPU0
  MA: vlan_ma

    AC event trace history [Total events: 4]
    -----
    Time                Event                Num Rcvd    Num Sent
    ====                =====
    07/27/2012 15:00:31 Process joined          0           0
    07/27/2012 15:00:31 Process init success    0           0
    07/27/2012 15:00:31 Replay start rcvd       0           0

```

```
07/27/2012 15:00:40 Replay end rcvd          6006          6001
```

```
MA: ether_ma
```

```
AC event trace history [Total events: 4]
```

```
-----
```

| Time                | Event                | Num Rcvd | Num Sent |
|---------------------|----------------------|----------|----------|
| ====                | =====                | =====    | =====    |
| 07/27/2012 15:00:31 | Process joined       | 0        | 0        |
| 07/27/2012 15:00:31 | Process init success | 0        | 0        |
| 07/27/2012 15:00:31 | Replay start rcvd    | 0        | 0        |
| 07/27/2012 15:00:31 | Replay end rcvd      | 1        | 0        |

# show l2vpn forwarding

To display forwarding information from the layer2\_fib manager on the line card, use the **show l2vpn forwarding** command in EXEC mode.

**show l2vpn forwarding** {**xconnect** | **bridge-domain** | **counter** | **detail** | **hardware** | **inconsistent** | **interface** | **l2tp** | **location** [*node-id*] | **message** | **mstp** | **resource** | **retry-list** | **summary** | **unresolved**}

| Syntax Description |                                |   |
|--------------------|--------------------------------|---|
|                    | <b>xconnect</b>                | Displays the cross-connect related information.   |
|                    | <b>bridge-domain</b>           | Displays bridge domain related forwarding information.  |
|                    | <b>counter</b>                 | Displays the cross-connect counters.  |
|                    | <b>detail</b>                  | Displays detailed information from the layer2_fib manager.  |
|                    | <b>hardware</b>                | Displays hardware-related layer2_fib manager information.   |
|                    | <b>inconsistent</b>            | Displays inconsistent entries only.   |
|                    | <b>interface</b>               | Displays the match AC subinterface.   |
|                    | <b>l2tp</b>                    | Displays L2TPv3 related forwarding information.   |
|                    | <b>location</b> <i>node-id</i> | Displays layer2_fib manager information for the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation. |
|                    | <b>message</b>                 | Displays messages exchanged with collaborators.   |
|                    | <b>mstp</b>                    | Displays multi-spanning tree related forwarding information.  |
|                    | <b>resource</b>                | Displays resource availability information in the layer2_fib manager.   |
|                    | <b>retry-list</b>              | Displays retry list related information.  |

|                   |  |
|-------------------|--|
| <b>summary</b>    | Displays summary information about cross-connects in the layer2_fib manager. |
| <b>unresolved</b> | Displays unresolved entries only.  |

**Command Default**

None

**Command Modes**

EXEC

**Command History**

| Release       | Modification   |
|---------------|--|
| Release 3.4.0 | This command was introduced.   |
| Release 3.7.0 | Sample output was updated to add MAC information for the layer2_fib manager summary. |

**Usage Guidelines**

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

**Task ID**

| Task ID | Operations |
|---------|------------|
| l2vpn   | read       |

**Examples**

The following sample output is from the **show l2vpn forwarding bridge detail location** command for IOS-XR releases 5.3.1 and earlier:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge detail location 0/2/cpu0
Bridge-domain name: bgl:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
IGMP snooping: disabled, flooding: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 1
Number of MAC addresses: 0
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/1.2, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0
Storm control drop counters:
  packets: broadcast 0, multicast 0, unknown unicast 0
  bytes: broadcast 0, multicast 0, unknown unicast 0
```

## show l2vpn forwarding

```

Bridge-domain name: bg1:bd2, id: 1, state: up
  Type: pbb-edge, I-SID: 1234
  Core-bridge: pbb-bd2
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  DHCPv4 snooping: profile not known on this node
  IGMP snooping: disabled, flooding: disabled
  Bridge MTU: 1500 bytes
  Number of bridge ports: 0
  Number of MAC addresses: 0
  Multi-spanning tree instance: 0

PBB Edge, state: up
  Number of MAC: 0
GigabitEthernet0/1/0/1.3, state: oper up
  Number of MAC: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

Bridge-domain name: bg1:bd3, id: 2, state: up
  Type: pbb-core
  Number of associated pbb-edge BDs: 1

MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  DHCPv4 snooping: profile not known on this node
  IGMP snooping: disabled, flooding: disabled
  Bridge MTU: 1500 bytes
  Number of bridge ports: 0
  Number of MAC addresses: 0
  Multi-spanning tree instance: 0

PBB Core, state: up
  Vlan-id: 1

GigabitEthernet0/1/0/1.4, state: oper up
  Number of MAC: 0
  Storm control drop counters:
    packets: broadcast 0, multicast 0, unknown unicast 0
    bytes: broadcast 0, multicast 0, unknown unicast 0

```

The following sample output is from the **show l2vpn forwarding bridge detail location** command for IOS-XR 5.3.2 release:

```

RP/0/RP0/CPU0:router# show l2vpn forwarding bridge detail location 0/0/CPU0

Bridge-domain name: pbb:pbb_core1, id: 10, state: up
  Type: pbb-core
  Number of associated pbb-edge BDs: 1

```

```

MAC learning: enabled
MAC port down flush: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
MAC Secure: disabled, Logging: disabled
DHCPv4 snooping: profile not known on this node
Dynamic ARP Inspection: disabled, Logging: disabled
IP Source Guard: disabled, Logging: disabled
IGMP snooping: disabled, flooding: enabled
MLD snooping: disabled, flooding: disabled
MMRP Flood Optimization: disabled
Storm control: disabled
P2MP PW: disabled
Bridge MTU: 1500 bytes
Number of bridge ports: 1
Number of MAC addresses: 5
Multi-spanning tree instance: 0
PBB-EVPN: enabled
Statistics:
  packets: received 0, sent 963770
  bytes: received 0, sent 263433178

PBB Core, state: Up
Vlan-id: 1
XC ID: 0x80000010
Number of MAC: 0
Statistics:
  packets: received 0 (unicast 0), sent 0
  bytes: received 0 (unicast 0), sent 0
  MAC move: 0
Storm control drop counters:
  packets: broadcast 0, multicast 0, unknown unicast 0
  bytes: broadcast 0, multicast 0, unknown unicast 0

```

The following sample outputs shows the backup pseudowire information:

```

RP/0/RP0/CPU0:router#show l2vpn forwarding detail location 0/2/CPU0
Local interface: GigabitEthernet0/2/0/0.1, Xconnect id: 0x3000001, Status: up
Segment 1
  AC, GigabitEthernet0/2/0/0.1, Ethernet VLAN mode, status: Bound
  RG-ID 1, active
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0
Segment 2
  MPLS, Destination address: 101.101.101.101, pw-id: 1000, status: Bound
  Pseudowire label: 16000
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0
Backup PW
  MPLS, Destination address: 102.102.102.102, pw-id: 1000, status: Bound
  Pseudowire label: 16001
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

```

## show l2vpn forwarding

```
RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain detail location 0/2/CPU0
Bridge-domain name: bg1:bd1, id: 0, state: up
```

```
...
  GigabitEthernet0/2/0/0.4, state: oper up
    RG-ID 1, active
    Number of MAC: 0
    ...

  Nbor 101.101.101.101 pw-id 5000
    Backup Nbor 101.101.101.101 pw-id 5000
    Number of MAC: 0
  ...
```

```
RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain detail location 0/2/CPU0
Bridge-domain name: bg1:bd1, id: 0, state: up
```

```
...
GigabitEthernet0/2/0/0.4, state: oper up
XC ID: 0x1880002
Number of MAC: 0
Statistics:
packets: received 0 (multicast 0, broadcast 0, unknown unicast 0, unicast 0), sent 963770
bytes: received 0 (multicast 0, broadcast 0, unknown unicast 0, unicast 0), sent 263433178
MAC move: 0
Storm control drop counters:
packets: broadcast 0, multicast 0, unknown unicast 0
bytes: broadcast 0, multicast 0, unknown unicast 0
Dynamic arp inspection drop counters:
packets: 0, bytes: 0
IP source guard drop counters:
packets: 0, bytes: 0
```

```
...
```

The following sample outputs displays the SPAN segment information of the xconnect:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding counter location 0/7/CPU0
Legend: ST = State, DN = Down
```

| Segment 1                           | Segment 2  | ST | Byte | Switched |
|-------------------------------------|------------|----|------|----------|
| pw-span-test (Monitor-Session) mpls | 172.16.0.1 | UP | 0    |          |

```
RP/0/RP0/CPU0:router #Show l2vpn forwarding monitor-session location 0/7/CPU0
Segment 1                               Segment 2                               State
-----
pw-span-test (monitor-session) mpls     172.16.0.1                               UP
pw-span-sess (monitor-session) mpls     192.168.0.1                              UP
```

```
RP/0/RP0/CPU0:router #Show l2vpn forwarding monitor-session pw-span-test location 0/7/CPU0
Segment 1                               Segment 2                               State
-----
pw-span-test (Monitor-Session) mpls     172.16.0.1                               UP
```

Example 4:

```
RP/0/RP0/CPU0:router #show l2vpn forwarding detail location 0/7/CPU0
Xconnect id: 0xc000001, Status: up
Segment 1
```



```

    Monitor-Session, pw-span-test, status: Bound
Segment 2
    MPLS, Destination address: 172.16.0.1, pw-id: 1, status: Bound
    Pseudowire label: 16001
    Statistics:
        packets: received 0, sent 11799730
        bytes: received 0, sent 707983800

Example 5:
show l2vpn forwarding private location 0/11/CPU0
Xconnect ID 0xc000001
Xconnect info:
    Base info: version=0xaabbcc13, flags=0x0, type=2, reserved=0
    xcon_bound=TRUE, switching_type=0, data_type=3

AC info:
    Base info: version=0xaabbcc11, flags=0x0, type=3, reserved=0
    xcon_id=0xc000001, ifh= none, subifh= none, ac_id=0, ac_type=SPAN,
    ac_mtu=1500, iw_mode=none, adj_valid=FALSE, adj_addr none

PW info:
    Base info: version=0xaabbcc12, flags=0x0, type=4, reserved=0
    pw_id=1, nh_valid=TRUE, sig_cap_flags=0x20, context=0x0,
    MPLS, pw_label=16001
    Statistics:
        packets: received 0, sent 11799730
        bytes: received 0, sent 707983800

Object: NHOP
Event Trace History [Total events: 5]
-----
      Time          Event          Flags
      ====          =====          =====
-----

Nexthop info:
    Base info: version=0xaabbcc14, flags=0x10000, type=5, reserved=0
    nh_addr=172.16.0.1, plat_data_valid=TRUE, plat_data_len=128, child_count=1

Object: XCON
Event Trace History [Total events: 16]
-----
      Time          Event          Flags
      ====          =====          =====
-----

RP/0/RP0/CPU0:router #show l2vpn forwarding summary location 0/7/CPU0
Major version num:1, minor version num:0
Shared memory timestamp:0x31333944cf
Number of forwarding xconnect entries:2
    Up:2   Down:0
    AC-PW:1 (1 mpls)  AC-AC:0  AC-BP:0  AC-Unknown:0
    PW-BP:0  PW-Unknown:0  Monitor-Session-PW:1
Number of xconnects down due to:
    AIB:0  L2VPN:0  L3FIB:0
Number of p2p xconnects: 2
Number of bridge-port xconnects: 0
Number of nexthops:1
    MPLS:   Bound:1  Unbound:0  Pending Registration:0
Number of bridge-domains: 0

```

```

Number of static macs: 0
Number of locally learned macs: 0
Number of remotely learned macs: 0
Number of total macs: 0

```

The following sample output is from the **show l2vpn forwarding** command:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding location 0/2/cpu0
```

```

ID   Segment 1           Segment 2
-----
1    Gi0/2/0/0 1        10.0.0.1  9)

```

The following sample output shows the MAC information in the layer2\_fib manager summary:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding summary location 0/3/CPU0
```

```

Major version num:1, minor version num:0
Shared memory timestamp:0x66ff58e894
Number of forwarding xconnect entries:2
  Up:1  Down:0
  AC-PW:0  AC-AC:0  AC-BP:1  PW-BP:1
Number of xconnects down due to:
  AIB:0  L2VPN:0  L3FIB:0
Number of nexthops:1
Number of static macs: 5
Number of locally learned macs: 5
Number of remotely learned macs: 0
Number of total macs: 10

```

This example shows the sample output of a configured flow label:

```
RP/0/RP0/CPU0:router# show l2vpn for 0/0/cpu0
```

```
Local interface: GigabitEthernet0/0/1/1, Xconnect id: 0x1000002, Status: up
```

```

Segment 1
  AC, GigabitEthernet0/0/1/1, Ethernet port mode, status: Bound

```

```

Segment 2
  MPLS, Destination address: 192.168.0.1, pw-id: 2, status: Bound, Active
  Pseudowire label: 16004    Control word disabled
  Backup PW
    MPLS, Destination address: 172.16.0.1, pw-id: 6, status: Bound
    Pseudowire label: 16000
  Flow label enabled

```

```
  Xconnect id: 0xff000014, Status: down
```

```

Segment 1
  MPLS, Destination address: 172.16.0.1, pw-id: 1, status: Not bound
  Pseudowire label: UNKNOWN    Control word disabled
  Flow label enabled

```

```

Segment 2
  Bridge id: 0, Split horizon group id: 0
  Storm control: disabled
  MAC learning: enabled
  MAC port down flush: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  DHCPv4 snooping: profile not known on this node, disabled

```

```
IGMP snooping profile: profile not known on this node
Router guard disabled
```

**Related Commands**

| Command   | Description                       |
|---|-----------------------------------|
| <a href="#">clear l2vpn forwarding counters, on page 21</a> | Clears L2VPN forwarding counters. |

# show l2vpn forwarding l2tp

To display L2VPN forwarding information, use the **show l2vpn forwarding l2tp** command in EXEC mode.

**show l2vpn forwarding l2tp disposition** {**local session id** *session-ID* | **hardware** | **location** *node-id*}  
**location** *node-id*

|                    |   |                                   |
|--------------------|---|-----------------------------------|
| Syntax Description | <b>disposition</b> Displays forwarding disposition information.   |                                   |
|                    | <i>session-ID</i> Displays L2TPv3-related forwarding information for the specified local session ID. Range is 1-4294967295.   |                                   |
|                    | <b>hardware</b> Displays L2TPv3-related forwarding information read from hardware.  |                                   |
|                    | <b>location</b> Displays L2TPv3-related forwarding information for the specified location.  |                                   |
| Command Default    | None  |                                   |
| Command Modes      | EXEC  |                                   |
| Command History    | <b>Release</b>  | <b>Modification</b>               |
|                    | Release 3.9.0   | This command was introduced.      |
| Usage Guidelines   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.   |                                   |
| Task ID            | <b>Task ID</b>  | <b>Operations</b>                 |
|                    | l2vpn   | read                              |
| Examples           | The following example shows sample output for the <b>show l2vpn forwarding l2tp</b> command:<br><br>RP/0/RP0/CPU0:router# show l2vpn forwarding l2tp disposition hardware location 0/3/1<br><br>ID      Segment 1                      Segment 2<br>-----<br>1      Gi0/2/0/0 1                      10.0.0.1      9) |                                   |
| Related Commands   | <b>Command</b>  | <b>Description</b>                |
|                    | <a href="#">clear l2vpn forwarding counters, on page 21</a>   | Clears L2VPN forwarding counters. |

# show l2vpn generic-interface-list

To display all the L2VPN virtual interfaces, use the **show l2vpn generic-interface-list** command in EXEC mode.

**show l2vpn generic-interface-list** {**detail** | **name** | **private** | **summary**}

|                           |                |   |
|---------------------------|----------------|---|
| <b>Syntax Description</b> | <b>detail</b>  | Specifies the details of the interface.             |
|                           | <b>name</b>    | Specifies the name of the interface.                |
|                           | <b>private</b> | Specifies the private details of the interface.     |
|                           | <b>summary</b> | Specifies the summary information of the interface. |

**Command Default** None

**Command Modes** EXEC

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 4.2.1  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read              |

## Examples

This example shows the sample output of the **show l2vpn generic-interface-list** command:

```
RP/0/RP0/CPU0:router# show l2vpn generic-interface-list
generic-interface-list: 11 (ID: 2, interfaces: 2)  Number of items: 20
generic-interface-list: 12 (ID: 3, interfaces: 4)  Number of items: 15
```

This example shows the sample output of the **show l2vpn generic-interface-list detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn generic-interface-list detail
generic-interface-list: 11 (ID: 2, interfaces: 2)
  GigabitEthernet0/1/0/0 - items pending 2
  GigabitEthernet0/1/0/1 - items pending 4
  Number of items: 27
  PW-Ether: 1-10, 12-21
  PW-IW: 1-7

generic-interface-list: 12 (ID: 3, interfaces: 4)
```

**show l2vpn generic-interface-list**

```
GigabitEthernet0/1/0/0 - items pending 2
GigabitEthernet0/1/0/1 - items pending 4
GigabitEthernet0/1/0/2 - items pending 1
GigabitEthernet0/1/0/3 - items pending 0
Number of items: 20
  PW-Ether: 1-15
  PW-IW: 1-7
```

This example shows the sample output of the **show l2vpn generic-interface-list name | detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn generic-interface-list name 11 detail
generic-interface-list: 11 (ID: 2, interfaces: 2)
  GigabitEthernet0/1/0/0 - items pending 2
  GigabitEthernet0/1/0/1 - items pending 4
  Number of items: 20
  PW-Ether 1-10, 12-21
```

# show l2vpn index

To display statistics about the index manager, use the **show l2vpn index** command in EXEC mode.

**show l2vpn index** [{**location** | **private** | **standby**}]

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <b>location</b>   | (Optional) Displays index manager statistics for the specified location.   |
|                           | <b>private</b>  | (Optional) Detailed information about all indexes allocated for each pool.   |
|                           | <b>standby</b>  | (Optional) Displays Standby node specific information.   |
| <b>Command Default</b>    | None  |  |
| <b>Command Modes</b>      | EXEC  |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 4.2.1   | This command was introduced.   |
|                           | Release 4.3.0   | The following keywords are introduced: <ul style="list-style-type: none"> <li>• location</li> <li>• standby</li> </ul> |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.   |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | l2vpn   | read   |
| <b>Examples</b>           | <p>This example shows the sample output of the <b>show l2vpn index</b> command:</p> <pre>RP/0/RP0/CPU0:router# show l2vpn index Pool id: 0x4, App: RD Pool size: 32767 zombied IDs: 0 allocated IDs: 0  Pool id: 0x5, App: IFLIST</pre> |  |

```

Pool size: 65535
zombied IDs: 0
allocated IDs: 2

Pool id: 0xff000001, App: PW/PBB/Virtual AC
Pool size: 40960
zombied IDs: 0
allocated IDs: 1

Pool id: 0xff000002, App: BD
Pool size: 4095
zombied IDs: 0
allocated IDs: 2

Pool id: 0xff000003, App: MP2MP
Pool size: 65535
zombied IDs: 0
allocated IDs: 1

```

This example shows the sample output of the **show l2vpn index standby** command:

```

RP/0/RP0/CPU0:router# show l2vpn index standby
  Pool id: 0xffffc0000, App: Global
    Max number of ID mgr instances: 1
    ID mgr instances in use: 1
    Pool size: 98304
    zombied IDs: 0
    allocated IDs: 0

  Pool id: 0xffffc0002, App: BD
    Max number of ID mgr instances: 1
    ID mgr instances in use: 1
    Pool size: 8192
    zombied IDs: 0
    allocated IDs: 0

  Pool id: 0xffffc0003, App: MP2MP
    Max number of ID mgr instances: 1
    ID mgr instances in use: 1
    Pool size: 65535
    zombied IDs: 0
    allocated IDs: 0

```



# show l2vpn nsr

To display the status of l2vpn non-stop routing, use the **show l2vpn nsr** command in EXEC mode.

**show l2vpn nsr** [{location | standby}]

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <b>location</b>   | (Optional) Displays non-stop routing information for the specified location. |
|                           | <b>standby</b>  | (Optional) Displays Standby node specific information.                       |
| <b>Command Default</b>    | None  |  |
| <b>Command Modes</b>      | EXEC  |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 4.3.0   | This command was introduced.   |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operation</b>   |
|                           | l2vpn   | read   |

The following example displays output for the **show l2vpn nsr** command:

```
RP/0/RP0/CPU0:router# show l2vpn nsr

Mon May 30 19:32:01.045 UTC
L2VPN NSR information
NSR Status:
NSR Ready                : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Last NSR Withdraw Time   : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Standby Connected        : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
IDT Done                 : Fri May 27 10:50:59 UTC 2016 (3d08h ago)
Number of XIDs sent      : Virtual AC: 0
                          AC          : 1
                          PW          : 1
                          BD          : 0
                          MP2MP       : 0
                          RD          : 0
                          PBB         : 0
                          IFLIST      : 0
                          ATOM        : 1
                          Global      : 0
                          PWGroup     : 0
```

show l2vpn nsr

EVPN : 0

| Related Commands | Command                           | Description                      |
|------------------|-----------------------------------|----------------------------------|
|                  | <a href="#">l2vpn, on page 44</a> | Enters L2VPN configuration mode. |
|                  | <a href="#">#unique_68</a>        |                                  |

# show l2vpn provision queue

To display L2VPN configuration provisioning queue information, use the **show l2vpn provision queue** command in EXEC mode.

**show l2vpn provision queue** [{location | standby}]

| <b>Syntax Description</b> | <p><b>location</b> (Optional) Displays L2VPN configuration provisioning queue information for the specified location.</p> <p><b>standby</b> (Optional) Displays Standby node specific information.</p>                                |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | None  |         |              |               |                              |
| <b>Command Modes</b>      | EXEC  |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 4.3.0</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 4.3.0 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 4.3.0             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |         |              |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>l2vpn</td><td>read</td></tr> </table>   | Task ID | Operation    | l2vpn         | read                         |
| Task ID                   | Operation   |         |              |               |                              |
| l2vpn                     | read  |         |              |               |                              |

The following example displays output for the **show l2vpn provision queue** command:

```
RP/0/RP0/CPU0:router# show l2vpn provision queue

Legend: P/P/R = Priority/Provisioned/Require Provisioning.
Configuration Item      Object Type      Class              P/P/R Object
Key
-----
BD_NAME                 bd_t             vpls_bd_class      0/0/0 BD
VPLS01
BD_NAME                 bd_t             vpls_bd_class      0/0/0 BD
VPLS02
BD_NAME                 bd_t             vpls_bd_class      0/0/0 BD
VPLS03
```

The following example displays output for the **show l2vpn provision queue standby** command:

```
RP/0/RP0/CPU0:router# show l2vpn provision queue standby

Legend: P/P/R = Priority/Provisioned/Require Provisioning.
Configuration Item      Object Type      Class              P/P/R Object
Key
```

show l2vpn provision queue

|         |      |                |          |
|---------|------|----------------|----------|
| -----   |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS01  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS02  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS03  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS04  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS05  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS06  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS07  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS08  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS09  |      |                |          |
| BD_NAME | bd_t | vppls_bd_class | 0/0/0 BD |
| VPLS010 |      |                |          |

|                  |                                   |                                  |
|------------------|-----------------------------------|----------------------------------|
| Related Commands | Command                           | Description                      |
|                  | <a href="#">l2vpn, on page 44</a> | Enters L2VPN configuration mode. |

# show l2vpn pw-class

To display L2VPN pseudowire class information, use the **show l2vpn pw-class** command in EXEC mode.

**show l2vpn pw-class** [{**detail** | **location** | **name** *class name* | **standby**}]

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <b>detail</b>   | (Optional) Displays detailed information.                               |
|                           | <b>location</b>   | (Optional) Displays location specific information.                      |
|                           | <b>name</b><br><i>class-name</i>  | (Optional) Displays information about a specific pseudowire class name. |
|                           | <b>standby</b>  | (Optional) Displays standby node specific information.                  |
| <b>Command Default</b>    | None  |   |
| <b>Command Modes</b>      | EXEC  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>   |
|                           | Release 3.5.0   | This command was introduced.  |
|                           | Release 4.3.0   | The keywords <b>location</b> and <b>standby</b> were introduced.        |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>   |
|                           | l2vpn   | read  |

## Examples

The following example shows sample output for the **show l2vpn pw-class** command:

```
RP/0/RP0/CPU0:router# show l2vpn pw-class

Name                               Encapsulation   Protocol
-----
mplsclass_75                       MPLS             LDP
l2tp-dynamic                       L2TPv3          L2TPv3
```

This example shows sample output for the **show l2vpn pw-class detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn pw-class detail
Encapsulation MPLS, protocol LDP
Transport mode not set, control word unset (default)
Sequencing not set
Static tag rewrite not set
```

**show l2vpn pw-class**

```

PW Backup disable delay: 0 sec
MAC withdraw message is sent over PW: no
IPv4 source address 10.0.0.1

```

This table describes the significant fields shown in the display.

**Table 6: show l2vpn pw-class Command Field Descriptions**

| Field         | Description                                |
|---------------|--|
| Name          | Displays the name of the pseudowire class. |
| Encapsulation | Displays the encapsulation type.           |
| Protocol      | Displays the protocol type.                |

**Related Commands**

| Command   | Description                       |
|---|-----------------------------------|
| <a href="#">clear l2vpn forwarding counters, on page 21</a> | Clears L2VPN forwarding counters. |

# show l2vpn pwhe

To display the pseudowire headend (PWHE) information, use the **show l2vpn pwhe** command in EXEC mode.

**show l2vpn pwhe** {**detail** | **interface** | **summary**}

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <b>detail</b>   | Specifies the details of the interface.             |
|                           | <b>interface</b>  | Specifies the name of the interface.                |
|                           | <b>summary</b>  | Specifies the summary information of the interface. |
| <b>Command Default</b>    | None  |   |
| <b>Command Modes</b>      | EXEC  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>                                 |
|                           | Release 4.2.1   | This command was introduced.                        |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>                                   |
|                           | l2vpn   | read  |

## Examples

This example show the sample output for **show l2vpn pwhe detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn pwhe detail
Interface: PW-Ether1   Interface State: Down, Admin state: Up
  Interface handle 0x20000070
  MTU: 1514
  BW: 10000 Kbit
  Interface MAC addresses: 0279.96e9.8205
  Label: 16000
  L2-overhead: 0
  VC-type: 5
  CW: N
  Generic-interface-list: ifl1 (id: 1)
    Gi0/2/0/1, in bundle BE3, state: Up, replication: success
    Gi0/2/0/0, in bundle BE5, state: Up, replication: success
    Gi0/2/0/2, in bundle BE5, state: Up, replication: success
    Gi0/2/0/3, state: Up, replication: success

Interface: PW-IW1     Interface State: Up, Admin state: Up
  Interface handle 0x20000070
```

```
MTU: 1514
BW: 10000 Kbit
VC-type: 11
CW: N
Generic-interface-list: ifl2 (id: 2)
  Gi0/3/0/1, in bundle BE6, state: Up, replication: success
  Gi0/3/0/0, in bundle BE6, state: Up, replication: success
  Gi0/3/0/2, state: Up, replication: success
  Gi0/3/0/3, state: Up, replication: success
```

This example show the sample output for **show l2vpn pwhe summary** command:

```
RP/0/RP0/CPU0:router# show l2vpn pwhe summary
Number of PW-HE interface: 1600
Up: 1300 Down: 300 Admindown: 0
Number of PW-Ether interfaces: 900
Up: 700 Down: 200 Admindown: 0
Number of PW-IW interfaces: 700
Up: 600 Down: 100 Admindown: 0
```



# show l2vpn resource

To display the memory state in the L2VPN process, use the **show l2vpn resource** command in EXEC mode.

**show l2vpn resource**

|                           |  |
|---------------------------|--|
| <b>Syntax Description</b> | This command has no arguments or keywords. |
|---------------------------|--|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |      |
|----------------------|------|
| <b>Command Modes</b> | EXEC |
|----------------------|------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.4.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read              |

## Examples

The following example shows sample output for the **show l2vpn resource** command:

```
RP/0/RP0/CPU0:router# show l2vpn resource
```

```
Memory: Normal
```

describes the significant fields shown in the display. [Table 7: show l2vpn resource Command Field Descriptions, on page 111](#)

**Table 7: show l2vpn resource Command Field Descriptions**

| Field  | Description             |
|--------|-------------------------|
| Memory | Displays memory status. |

# show l2vpn trace

To display trace data for L2VPN, use the **show l2vpn trace** command in EXEC mode.

**show l2vpn trace** [{**checker** | **file** | **hexdump** | **last** | **location** | **reverse** | **stats** | **tailf** | **unique** | **usec** | **verbose** | **wide** | **wrapping**}]

## Syntax Description

|                 |  |
|-----------------|--|
| <b>checker</b>  | Displays trace data for the L2VPN Uerverifier.           |
| <b>file</b>     | Displays trace data for the specified file.              |
| <b>hexdump</b>  | Display traces data in hexadecimal format.               |
| <b>last</b>     | Display last <n> entries                                 |
| <b>location</b> | Displays trace data for the specified location.          |
| <b>reverse</b>  | Display latest traces first                              |
| <b>stats</b>    | Display trace statistics                                 |
| <b>tailf</b>    | Display new traces as they are added                     |
| <b>unique</b>   | Display unique entries with counts                       |
| <b>usec</b>     | Display usec details with timestamp                      |
| <b>verbose</b>  | Display internal debugging information                   |
| <b>wide</b>     | Display trace data excluding buffer name, node name, tid |
| <b>wrapping</b> | Display wrapping entries                                 |

## Command Default

None

## Command Modes

EXEC

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 4.3.0 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

| Task ID | Operation |
|---------|-----------|
| l2vpn   | read      |

This example displays output for the **show l2vpn trace** command:

```
RP/0/RP0/CPU0:router# show l2vpn trace
310 unique entries (1775 possible, 0 filtered)
Jul 27 14:39:51.786 l2vpn/fwd-detail 0/RSP0/CPU0 2# t1 FWD_DETAIL:415: l2tp session
table rebuilt
Jul 27 14:39:52.106 l2vpn/issu 0/RSP0/CPU0 1# t1 ISSU:788: ISSU - iMDR init called;
'infra/imdr' detected the 'informational' condition 'the service is not supported in the
node'
Jul 27 14:39:52.107 l2vpn/issu 0/RSP0/CPU0 1# t1 ISSU:428: ISSU - attempt to start
COLLABORATOR wait timer while not in ISSU mode
Jul 27 14:39:54.286 l2vpn/fwd-common 0/RSP0/CPU0 1# t1 FWD_COMMON:3257: show edm thread
initialized
Jul 27 14:39:55.270 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC|ERR:783: Mac aging init
Jul 27 14:39:55.286 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:1765: l2vpn_gsp_cons_init
returned No error
Jul 27 14:39:55.340 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:1792: Client successfully
joined gsp group
Jul 27 14:39:55.340 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:779: Initializing the
txlist IPC thread
Jul 27 14:39:55.341 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:2971: gsp_optimal_msg_size
= 4832 (real: True)
Jul 27 14:39:55.351 l2vpn/fwd-mac 0/RSP0/CPU0 1# t1 FWD_MAC:626: Entering mac aging
timer init
```

# show l2vpn xconnect

To display brief information on configured cross-connects, use the **show l2vpn xconnect** command in EXEC mode.

**show l2vpn xconnect** [{**brief** | **detail** | **encapsulation** | **group** | **groups** | **interface** | **location** | **mp2mp** | **mspw** | **neighbor** | **pw-class** | **standby** | **state** | **summary** | **type** | **state unresolved** | **pw-id** *value*}]

| Syntax Description        |  |  |
|---------------------------|--|--|
| <b>brief</b>              | (Optional) Displays encapsulation brief information.   |  |
| <b>detail</b>             | (Optional) Displays detailed information.  |  |
| <i>encapsulation</i>      | (Optional) Filters on encapsulation type.  |  |
| <b>group</b>              | (Optional) Displays all cross-connects in a specified group.   |  |
| <b>groups</b>             | (Optional) Displays all groups information.  |  |
| <b>interface</b>          | (Optional) Filters the interface and subinterface.   |  |
| <b>location</b>           | (Optional) Displays location specific information.   |  |
| <b>mp2mp</b>              | (Optional) Displays MP2MP information.   |  |
| <b>mspw</b>               | (Optional) Displays ms_pw information.   |  |
| <b>neighbor</b>           | (Optional) Filters the neighbor.   |  |
| <b>pw-class</b>           | (Optional) Filters on pseudowire class   |  |
| <b>standby</b>            | (Optional) Displays standby node specific information.   |  |
| <b>state</b>              | (Optional) Filters the following xconnect state types: <ul style="list-style-type: none"> <li>• up</li> <li>• down</li> </ul>          |  |
| <b>summary</b>            | (Optional) Displays AC information from the AC Manager database.   |  |
| <b>type</b>               | (Optional) Filters the following xconnect types: <ul style="list-style-type: none"> <li>• ac-pw</li> <li>• locally switched</li> </ul> |  |
| <b>state unresolved</b>   | (Optional) Displays information about unresolved cross-connects.   |  |
| <b>pw-id</b> <i>value</i> | Displays the filter for the pseudowire ID. The range is from 1 to 4294967295.  |  |

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |      |
|----------------------|------|
| <b>Command Modes</b> | EXEC |
|----------------------|------|

| Command History | Release       | Modification   |
|-----------------|---------------|--|
|                 | Release 3.4.0 | This command was introduced.   |
|                 | Release 3.4.1 | VCCV-related show command output was added.  |
|                 | Release 3.6.0 | Preferred-path-related show command output was added.  |
|                 | Release 3.7.0 | Sample output was updated to display the backup pseudowire information.  |
|                 | Release 4.3.0 | The following keywords were introduced: <ul style="list-style-type: none"> <li>• brief</li> <li>• encapsulation</li> <li>• groups</li> <li>• location</li> <li>• mp2mp</li> <li>• mspw</li> <li>• pw-class</li> <li>• standby</li> </ul> |
|                 | Release 5.1.2 | This command was modified to enable filtering the command output for a specific pseudowire with just the pseudowire ID.  |

|                         |  |
|-------------------------|--|
| <b>Usage Guidelines</b> | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> |
|-------------------------|--|

If a specific cross-connect is specified in the command (for instance, AC\_to\_PW1) then only that cross-connect will be displayed; otherwise, all cross-connects are displayed.

When configuring Ethernet Connectivity Fault Management (CFM) over l2vpn cross-connect, the CFM Continuity Check Messages (CCM) packets are not accounted for in the cross-connect pseudowire packet counters displayed in this show command output.



|             |  |
|-------------|--|
| <b>Note</b> | <p>For Cisco IOS XR software Release 5.1.2 and above, you can filter the command output for specific pseudowire with just the pseudowire ID. However, for pseudowire configurations with FEC 129 Type 2 (in VPWS), filtering the output for a specific pseudowire can only be done with the combination of the neighbour filter and the pseudowire ID.</p> |
|-------------|--|

**show l2vpn xconnect****Task ID****Task ID      Operations**

|       |                |
|-------|----------------|
| l2vpn | read,<br>write |
|-------|----------------|

**Examples**

The following example shows sample output for the **show l2vpn xconnect** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect
```

```
Wed May 21 09:06:47.944 UTC
```

```
Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,  
        SB = Standby, SR = Standby Ready, (PP) = Partially Programmed
```

| XConnect Group   |  | Name         | ST | Segment 1 Description | ST | Segment 2 Description | ST |
|------------------|--|--------------|----|-----------------------|----|-----------------------|----|
| L2TPV3_V4_XC_GRP |  | L2TPV3_P2P_1 | UP | Gi0/2/0/1.2           | UP | 26.26.26.26 100       | UP |
| L2TPV3_V4_XC_GRP |  | L2TPV3_P2P_2 | UP | Gi0/2/0/1.3           | UP | 26.26.26.26 200       | UP |

The following sample output shows that the backup is in standby mode for the **show l2vpn xconnect detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect detail
```

```
Group siva_xc, XC siva_p2p, state is up; Interworking none
```

```
Monitor-Session: pw-span-test, state is configured
```

```
AC: GigabitEthernet0/4/0/1, state is up
```

```
Type Ethernet
```

```
MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
```

```
Statistics:
```

```
packet totals: send 90
```

```
byte totals: send 19056
```

```
PW: neighbor 10.1.1.1, PW ID 1, state is up ( established )
```

```
PW class not set, XC ID 0x5000001
```

```
Encapsulation MPLS, protocol LDP
```

```
PW type Ethernet, control word enabled, interworking none
```

```
PW backup disable delay 0 sec
```

```
Sequencing not set
```

| MPLS         | Local                   | Remote                  |
|--------------|-------------------------|-------------------------|
| Label        | 30005                   | 16003                   |
| Group ID     | 0x5000300               | 0x5000400               |
| Interface    | GigabitEthernet0/4/0/1  | GigabitEthernet0/4/0/2  |
| Interface    | pw-span-test            | GigabitEthernet0/3/0/1  |
| MTU          | 1500                    | 1500                    |
| Control word | enabled                 | enabled                 |
| PW type      | Ethernet                | Ethernet                |
| VCCV CV type | 0x2                     | 0x2                     |
|              | (LSP ping verification) | (LSP ping verification) |
| VCCV CC type | 0x3                     | 0x3                     |
|              | (control word)          | (control word)          |
|              | (router alert label)    | (router alert label)    |

```
Create time: 20/11/2007 21:45:07 (00:49:18 ago)
```

```

Last time status changed: 20/11/2007 21:45:11 (00:49:14 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

## Backup PW:

```

PW: neighbor 172.16.0.1, PW ID 2, state is up ( established )
Backup for neighbor 10.0.0.1 PW ID 1 ( standby )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec

```

## Sequencing not set

| MPLS         | Local                   | Remote                  |
|--------------|-------------------------|-------------------------|
| Label        | 30006                   | 16003                   |
| Group ID     | unassigned              | 0x5000400               |
| Interface    | unknown                 | GigabitEthernet0/4/0/2  |
| MTU          | 1500                    | 1500                    |
| Control word | enabled                 | enabled                 |
| PW type      | Ethernet                | Ethernet                |
| VCCV CV type | 0x2                     | 0x2                     |
|              | (LSP ping verification) | (LSP ping verification) |
| VCCV CC type | 0x3                     | 0x3                     |
|              | (control word)          | (control word)          |
|              | (router alert label)    | (router alert label)    |

```

Backup PW for neighbor 10.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:45 (00:48:40 ago)
Last time status changed: 20/11/2007 21:45:49 (00:48:36 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

The following sample output shows that the backup is active for the **show l2vpn xconnect detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect detail
```

```

Group siva_xc, XC siva_p2p, state is down; Interworking none
Monitor-Session: pw-span-test, state is configured
AC: GigabitEthernet0/4/0/1, state is up
Type Ethernet
MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
Statistics:
  packet totals: send 98
  byte totals: send 20798
PW: neighbor 10.1.1.1, PW ID 1, state is down ( local ready )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

```

| MPLS         | Local                  | Remote                 |
|--------------|------------------------|------------------------|
| Label        | 30005                  | unknown                |
| Group ID     | 0x5000300              | 0x0                    |
| Interface    | GigabitEthernet0/4/0/1 | unknown                |
| Interface    | pw-span-test           | GigabitEthernet0/3/0/1 |
| MTU          | 1500                   | unknown                |
| Control word | enabled                | unknown                |
| PW type      | Ethernet               | unknown                |
| VCCV CV type | 0x2                    | 0x0                    |
|              |                        | (none)                 |

## show l2vpn xconnect

```

                                (LSP ping verification)
VCCV CC type 0x3                                0x0
                                                (none)
                                (control word)
                                (router alert label)
-----
Create time: 20/11/2007 21:45:06 (00:53:31 ago)
Last time status changed: 20/11/2007 22:38:14 (00:00:23 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

Backup PW:
PW: neighbor 10.2.2.2, PW ID 2, state is up ( established )
  Backup for neighbor 10.1.1.1 PW ID 1 ( active )
  PW class not set, XC ID 0x0
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word enabled, interworking none
  PW backup disable delay 0 sec
  Sequencing not set
    MPLS          Local          Remote
    -----
    Label          30006          16003
    Group ID        unassigned      0x5000400
    Interface        unknown        GigabitEthernet0/4/0/2
    MTU              1500           1500
    Control word     enabled         enabled
    PW type          Ethernet        Ethernet
    VCCV CV type     0x2            0x2
                        (LSP ping verification)  (LSP ping verification)
    VCCV CC type     0x3            0x3
                        (control word)          (control word)
                        (router alert label)      (router alert label)
    -----
Backup PW for neighbor 10.1.1.1 PW ID 1
Create time: 20/11/2007 21:45:44 (00:52:54 ago)
Last time status changed: 20/11/2007 21:45:48 (00:52:49 ago)
Statistics:
  packet totals: receive 0
  byte totals: receive 0

```

The following sample output displays the xconnects with switch port analyzer (SPAN) as one of the segments:

```
Show l2vpn xconnect type minotor-session-pw
```

Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,  
LU = Local Up, RU = Remote Up, CO = Connected

| XConnect |      | Segment 1 |              | Segment 2 |              | ST |
|----------|------|-----------|--------------|-----------|--------------|----|
| Group    | Name | ST        | Description  | ST        | Description  |    |
| g1       | x1   | UP        | pw-span-test | UP        | 172.16.0.1 1 | UP |

The following sample output shows that one-way redundancy is enabled:

```

Group g1, XC x2, state is up; Interworking none
AC: GigabitEthernet0/2/0/0.2, state is up, active in RG-ID 1
Type VLAN; Num Ranges: 1
VLAN ranges: [2, 2]
MTU 1500; XC ID 0x3000002; interworking none
Statistics:
  packets: received 103, sent 103

```



```

        bytes: received 7348, sent 7348
        drops: illegal VLAN 0, illegal length 0
PW: neighbor 101.101.101.101, PW ID 2000, state is up ( established )
    PW class class1, XC ID 0x3000002
    Encapsulation MPLS, protocol LDP
    PW type Ethernet VLAN, control word disabled, interworking none
PW backup disable delay 0 sec
One-way PW redundancy mode is enabled
Sequencing not set
....
    Incoming Status (PW Status TLV):
        Status code: 0x0 (Up) in Notification message
    Outgoing Status (PW Status TLV):
        Status code: 0x0 (Up) in Notification message
....
    Backup PW:
PW: neighbor 102.102.102.102, PW ID 3000, state is standby ( all ready )
    Backup for neighbor 101.101.101.101 PW ID 2000 ( inactive )
    PW class class1, XC ID 0x3000002
    Encapsulation MPLS, protocol LDP
    PW type Ethernet VLAN, control word disabled, interworking none
    Sequencing not set
....
    Incoming Status (PW Status TLV):
        Status code: 0x26 (Standby, AC Down) in Notification message
    Outgoing Status (PW Status TLV):
        Status code: 0x0 (Up) in Notification message

```

The following example shows sample output for the **show l2vpn xconnect** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect
```

Legend: ST = State, UP = Up, DN = Down, AD = Admin Down, UR = Unresolved,  
LU = Local Up, RU = Remote Up, CO = Connected

| XConnect |          | Segment 1 |             | Segment 2 |             |      |
|----------|----------|-----------|-------------|-----------|-------------|------|
| Group    | Name     | ST        | Description | ST        | Description | ST   |
| siva_xc  | siva_p2p | UP        | Gi0/4/0/1   | UP        | 10.0.0.1    | 1 UP |
|          |          |           |             |           | Backup      |      |
|          |          |           |             |           | 172.16.0.1  | 2 UP |

The following sample output shows that the backup is in standby mode for the **show l2vpn xconnect detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect detail
```

```

Group siva_xc, XC siva_p2p, state is up; Interworking none
AC: GigabitEthernet0/4/0/1, state is up
Type Ethernet
MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
Statistics:
    packet totals: received 90, sent 90
    byte totals: received 19056, sent 19056
PW: neighbor 10.0.0.1, PW ID 1, state is up ( established )
    PW class not set, XC ID 0x5000001
    Encapsulation MPLS, protocol LDP
    PW type Ethernet, control word enabled, interworking none
    PW backup disable delay 0 sec
    Sequencing not set
        MPLS          Local          Remote
-----

```

## show l2vpn xconnect

```

Label          30005                               16003
Group ID       0x5000300                           0x5000400
Interface      GigabitEthernet0/4/0/1              GigabitEthernet0/4/0/2
MTU            1500                                1500
Control word   enabled                            enabled
PW type        Ethernet                            Ethernet
VCCV CV type   0x2                                0x2
                (LSP ping verification)            (LSP ping verification)
VCCV CC type   0x3                                0x3
                (control word)                      (control word)
                (router alert label)                (router alert label)
-----
Create time: 20/11/2007 21:45:07 (00:49:18 ago)
Last time status changed: 20/11/2007 21:45:11 (00:49:14 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

Backup PW:
PW: neighbor 172.16.0.1, PW ID 2, state is up ( established )
Backup for neighbor 10.0.0.1 PW ID 1 ( standby )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
      MPLS          Local                               Remote
-----
Label          30006                               16003
Group ID       unassigned                           0x5000400
Interface      unknown                             GigabitEthernet0/4/0/2
MTU            1500                                1500
Control word   enabled                            enabled
PW type        Ethernet                            Ethernet
VCCV CV type   0x2                                0x2
                (LSP ping verification)            (LSP ping verification)
VCCV CC type   0x3                                0x3
                (control word)                      (control word)
                (router alert label)                (router alert label)
-----
Backup PW for neighbor 10.0.0.1 PW ID 1
Create time: 20/11/2007 21:45:45 (00:48:40 ago)
Last time status changed: 20/11/2007 21:45:49 (00:48:36 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

The following sample output shows that the backup is active for the **show l2vpn xconnect detail** command:

```
RP/0/RP0/CPU0:router# show l2vpn xconnect detail
```

```

Group siva_xc, XC siva_p2p, state is down; Interworking none
AC: GigabitEthernet0/4/0/1, state is up
  Type Ethernet
  MTU 1500; XC ID 0x5000001; interworking none; MSTi 0
  Statistics:
    packet totals: send 98
    byte totals: send 20798
PW: neighbor 10.0.0.1, PW ID 1, state is down ( local ready )
PW class not set, XC ID 0x5000001
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec

```

```

Sequencing not set
  MPLS      Local      Remote
-----
Label       30005      unknown
Group ID    0x5000300      0x0
Interface   GigabitEthernet0/4/0/1      unknown
MTU         1500      unknown
Control word enabled      unknown
PW type     Ethernet      unknown
VCCV CV type 0x2      0x0
              (none)
              (LSP ping verification)
VCCV CC type 0x3      0x0
              (none)
              (control word)
              (router alert label)
-----
Create time: 20/11/2007 21:45:06 (00:53:31 ago)
Last time status changed: 20/11/2007 22:38:14 (00:00:23 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

Backup PW:
PW: neighbor 172.16.0.1, PW ID 2, state is up ( established )
Backup for neighbor 10.0.0.1 PW ID 1 ( active )
PW class not set, XC ID 0x0
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
  MPLS      Local      Remote
-----
Label       30006      16003
Group ID    unassigned      0x5000400
Interface   unknown      GigabitEthernet0/4/0/2
MTU         1500      1500
Control word enabled      enabled
PW type     Ethernet      Ethernet
VCCV CV type 0x2      0x2
              (LSP ping verification)      (LSP ping verification)
VCCV CC type 0x3      0x3
              (control word)      (control word)
              (router alert label)      (router alert label)
-----
Backup PW for neighbor 10.0.0.1 PW ID 1
Create time: 20/11/2007 21:45:44 (00:52:54 ago)
Last time status changed: 20/11/2007 21:45:48 (00:52:49 ago)
Statistics:
  packet totals: received 0, sent 0
  byte totals: received 0, sent 0

```

This example shows that the PW type changes to Ethernet, which is Virtual Circuit (VC) type 5, on the interface when a double tag rewrite option is used.

```
RP/0/RP0/CPU0:router# show l2vpn xconnect pw-class pw-class1 detail
```

```

Group VPWS, XC ac3, state is up; Interworking none
AC: GigabitEthernet0/7/0/5.3, state is up
Type VLAN; Num Ranges: 1
VLAN ranges: [12, 12]
MTU 1508; XC ID 0x2440096; interworking none
Statistics:

```

**show l2vpn xconnect**

```

packets: received 26392092, sent 1336
bytes: received 1583525520, sent 297928
drops: illegal VLAN 0, illegal length 0
PW: neighbor 192.168.0.1, PW ID 3, state is up ( established )
PW class VPWS1, XC ID 0x2440096
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec
Sequencing not set

Preferred path tunnel TE 3, fallback disabled
PW Status TLV in use

```

| MPLS         | Local                    | Remote                   |
|--------------|--------------------------|--------------------------|
| -----        | -----                    | -----                    |
| Label        | 16147                    | 21355                    |
| Group ID     | 0x120001c0               | 0x120001c0               |
| Interface    | GigabitEthernet0/7/0/5.3 | GigabitEthernet0/7/0/5.3 |
| MTU          | 1508                     | 1508                     |
| Control word | disabled                 | disabled                 |
| PW type      | Ethernet                 | Ethernet                 |
| VCCV CV type | 0x2                      | 0x2                      |
|              | (LSP ping verification)  | (LSP ping verification)  |
| VCCV CC type | 0x6                      | 0x6                      |
|              | (router alert label)     | (router alert label)     |
|              | (TTL expiry)             | (TTL expiry)             |
| -----        | -----                    | -----                    |

```

Incoming Status (PW Status TLV):
Status code: 0x0 (Up) in Notification message
Outgoing Status (PW Status TLV):
Status code: 0x0 (Up) in Notification message
MIB cpwVcIndex: 4294705365
Create time: 21/09/2011 08:05:01 (00:14:01 ago)
Last time status changed: 21/09/2011 08:07:01 (00:12:01 ago)
Statistics:
packets: received 1336, sent 26392092
bytes: received 297928, sent 1583525520

```

This example shows the sample output of a pseudowire headend (PWHE) cross connect:

```

RP/0/RP0/CPU0:router# show l2vpn xconnect interface pw-ether 67 detail
Group g1, XC xc1, state is down; Interworking none
AC:PW-Ether1, state is up
Type PW-Ether
Interface-list: interfacelist1
Replicate status:
Gi0/2/0/1: success
Gi0/3/0/1: pending
Gi0/4/0/1: failed
MTU 1500; interworking none
Statistics:
packets: received 0, sent 0
bytes: received 0, sent 0
PW: neighbor 130.130.130.130, PW ID 1234, state is down ( provisioned )
PW class not set
Encapsulation MPLS, protocol LDP
PW type Ethernet VLAN, control word disabled, interworking none
Sequencing not set
Internal label: 16008
VLAN id imposed: 101

```

| MPLS  | Local | Remote  |
|-------|-------|---------|
| ----- | ----- | -----   |
| Label | 16001 | unknown |

```

Group ID      0x2000600                                0x0
Interface     PW-Ether1                                unknown
MTU           1500                                    unknown
Control word  disabled                                unknown
PW type       Ethernet VLAN                            unknown
VCCV CV type  0x2                                      0x0
                                                    (none)
                (LSP ping verification)
VCCV CC type  0x6                                      0x0
                                                    (none)
                (router alert label)
                (TTL expiry)
-----
MIB cpwVcIndex: 2
Create time: 19/02/2010 23:13:01 (1w2d ago)
Last time status changed: 19/02/2010 23:13:16 (1w2d ago)
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

```

This example shows the sample output of a configured flow label:

```

RP/0/RP0/CPU0:router# show l2vpn xconnect detail
Group g1, XC p1, state is up; Interworking none
AC: GigabitEthernet0/0/1/1, state is up
Type Ethernet
MTU 1500; XC ID 0x1000002; interworking none
Statistics:
  packets: received 24688, sent 24686
  bytes: received 1488097, sent 1487926
PW: neighbor 192.168.0.1, PW ID 2, state is up ( established )
PW class class1, XC ID 0x1000002
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word disabled, interworking none
PW backup disable delay 0 sec
Sequencing not set
Flow label flags configured (Rx=1,Tx=1), negotiated (Rx=0,Tx=1)

```

This table describes the significant fields shown in the display.

**Table 8: show l2vpn xconnect Command Field Descriptions**

| Field          | Description   |
|----------------|---|
| XConnect Group | Displays a list of all configured cross-connect groups.   |
| Group          | Displays the cross-connect group number.  |
| Name           | Displays the cross-connect group name.  |
| Description    | Displays the cross-connect group description. If no description is configured, the interface type is displayed. |
| ST             | State of the cross-connect group: up (UP) or down (DN).   |

#### Related Commands

| Command                                     | Description                      |
|---|----------------------------------|
| <a href="#">xconnect group, on page 136</a> | Configures cross-connect groups. |

# show tunnel-template

To display tunnel template information, use the **show tunnel-template** command in the EXEC mode.

**show tunnel-template** *template-name*

| <b>Syntax Description</b> | <i>template-name</i> Name of the tunnel template.  |         |              |               |                              |
|---------------------------|--|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | None   |         |              |               |                              |
| <b>Command Modes</b>      | EXEC   |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.5.0</td><td>This command was introduced.</td></tr> </table> | Release | Modification | Release 3.5.0 | This command was introduced. |
| Release                   | Modification   |         |              |               |                              |
| Release 3.5.0             | This command was introduced.   |         |              |               |                              |
| <b>Usage Guidelines</b>   |  |         |              |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>tunnel</td><td>read</td></tr> </table>                                   | Task ID | Operation    | tunnel        | read                         |
| Task ID                   | Operation  |         |              |               |                              |
| tunnel                    | read   |         |              |               |                              |

## Example

The following example shows the output of the **show tunnel-template test** command for Local PE Tunnel:

```
RP/0/RP0/CPU0:router# show tunnel-template test
Fri Jan 30 06:22:46.428 UTC

Tunnel template
-----
Name:          test (ifhandle: 0x00080030)
MTU:           1464
TTL:           255
TOS:           0
Tunnel ID:     1
Source:        25.25.25.25
Session ID: 0x1D174108 Cookie: 8 bytes [0x24FD3ADAA4485333] being rolled into
               Session ID: 0x15A86E93 Cookie: 8 bytes [0xF486195660CCD522]
Next Session-id/Cookie rollover happens in 1 minute 49 seconds
Transmit:      14213298 pkts  1250770344 bytes
Cookie Mismatch: 0 pkts
MTU Violation: 0 pkts
```

The following example shows the output of the **show tunnel-template test** command for Remote PE Tunnel:

```
RP/0/RP0/CPU0:router# show tunnel-template test
Fri Jan 30 06:04:29.800 UTC
```

## Tunnel template

```
-----  
Name:      test (ifhandle: 0x00080030)  
MTU:       600  
TTL:       255  
TOS:       0  
Tunnel ID: 1  
Source:    35.35.35.35    Address Pool: 36.36.36.0/28  
Session ID: 0x111F4312 Cookie: 8 bytes [0xB95A806145BE9BE7]  
Transmit:   122168722 pkts 10750845295 bytes  
Cookie Mismatch: 0 pkts  
MTU Violation: 0 pkts
```

## Related Commands

| Command                                      | Description                                   |
|--|---|
| <a href="#">tunnel-template, on page 135</a> | Enters tunnel-template configuration submenu. |

# storm-control

Storm control on ASR 9000 Series Routers can be applied at the following service attachment points:

- Bridge domain (BD)
- Attachment Circuit (AC)
- Access pseudowire (PW)

To enable storm control on all access circuits (AC) and access pseudowires (PW) in a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain configuration mode. To disable storm control, use the **no** form of this command.

To enable storm control on an access circuit (AC) under a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain access circuit configuration mode. To disable storm control, use the **no** form of this command.

To enable storm control on an access pseudowire (PW) in a VPLS bridge, use the **storm-control** command in l2vpn bridge group bridge-domain neighbor configuration mode. To disable storm control, use the **no** form of this command.

**storm-control** {**broadcast** | **multicast** | **unknown-unicast**} {**pps** *pps-value* | **kbps** *kbps-value* }  
**no storm-control** {**broadcast** | **multicast** | **unknown-unicast**} {**pps** *pps-value* | **kbps** *kbps-value* }

|                    |   |   |
|--------------------|---|---|
| Syntax Description | <b>broadcast</b>  | Configures storm control for broadcast traffic.   |
|                    | <b>multicast</b>  | Configures storm control for multicast traffic.   |
|                    | <b>unknown-unicast</b>  | Configures storm control for unknown unicast traffic. <ul style="list-style-type: none"> <li>• Storm control does not apply to bridge protocol data unit (BPDU) packets. All BPDU packets are processed as if traffic storm control is not configured.</li> <li>• Storm control does not apply to internal communication and control packets, route updates, SNMP management traffic, Telnet sessions, or any other packets addressed to the router.</li> </ul> |
|                    | <b>pps</b> <i>pps-value</i>                                   | Configures the packets-per-second (pps) storm control threshold for the specified traffic type. Valid values range from 1 to 160000.  |
|                    | <b>kbps</b> <i>kbps-value</i>                                 | Configures the storm control in kilo bits per second (kbps). The range is from 64 to 1280000.   |
| Command Default    | Storm control is disabled by default.                         |   |
| Command Modes      | l2vpn bridge group bridge-domain access circuit configuration |   |
| Command History    | <b>Release</b>  | <b>Modification</b>   |
|                    | Release 3.7.2   | This command was introduced.  |



## Usage Guidelines

- Bridge Protocol Data Unit (BPDU) packets are not filtered through the storm control feature.
- The traffic storm control monitoring interval is set in the hardware and is not configurable. On Cisco ASR 9000 Series Router, the monitoring interval is always one second.
- When there is a mix of kbps and pps storm control on bridge or bridge port, the pps value is translated to kbps inside the policer using 1000 bytes per packet as an average.
- The hardware can only be programmed with a granularity of 8 pps, so values are not divisible by eight. These are rounded to the nearest increment of eight.

## Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

## Examples

The following example enables storm control thresholds throughout the bridge domain:

```
RP/0/RSP0/CPU0:a9k1# configure
RP/0/RSP0/CPU0:a9k1(config)# l2vpn
RP/0/RSP0/CPU0:a9k1(config-l2vpn)# bridge group BG1
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg)# bridge-domain BD1
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# storm-control unknown-unicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# storm-control multicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# storm-control broadcast pps 100
```

The following example enables storm control thresholds on an access circuit:

```
RP/0/RSP0/CPU0:a9k1# configure
RP/0/RSP0/CPU0:a9k1(config)# l2vpn
RP/0/RSP0/CPU0:a9k1(config-l2vpn)# bridge group BG1
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# bridge-domain BD2
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# interface Bundle-Ether9001.2001
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-ac)# storm-control unknown-unicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-ac)# storm-control multicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-ac)# storm-control broadcast pps 100
```

The following example enables storm control thresholds on an access pseudowire:

```
RP/0/RSP0/CPU0:a9k1# configure
RP/0/RSP0/CPU0:a9k1(config)# l2vpn
RP/0/RSP0/CPU0:a9k1(config-l2vpn)# bridge group BG1
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd)# bridge-domain BD2
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-ac)# neighbor 10.1.1.1 pw-id 20011001
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-pw)# storm-control unknown-unicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-pw)# storm-control multicast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-pw)# storm-control broadcast pps 100
RP/0/RSP0/CPU0:a9k1(config-l2vpn-bg-bd-pw)# commit
```

## Running Configuration

```
l2vpn
 bridge group BG1
  bridge-domain BD1
    storm-control unknown-unicast pps 100
```

```
storm-control multicast pps 100
storm-control broadcast pps 100
!
bridge-domain BD2
interface Bundle-Ether9001.2001
storm-control unknown-unicast pps 100
storm-control multicast pps 100
storm-control broadcast pps 100
!
neighbor 10.1.1.1 pw-id 20011001
storm-control unknown-unicast pps 100
storm-control multicast pps 100
storm-control broadcast pps 100
!
!
!
end
RP/0/RSP0/CPU0:a9k1(config)#
```

# tag-impose

To specify a tag for a VLAN ID configuration, use the **tag-impose** command in l2vpn configuration submode. To remove the tag, use the **no** form of this command.

**tag-impose vlan** *value*  
**no tag-impose vlan** *value*

|                           |  |  |
|---------------------------|--|--|
| <b>Syntax Description</b> | <b>vlan</b>  | VLAN in tagged mode.   |
|                           | <b>value</b>   | Tag value. The range is from 1 to 4094. The default value is 0.        |
| <b>Command Default</b>    | None   |  |
| <b>Command Modes</b>      | L2VPN configuration  |  |
| <b>Command History</b>    | <b>Release</b>   | <b>Modification</b>  |
|                           | Release 4.2.1  | This command was introduced.   |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.  |  |
| <b>Task ID</b>            | <b>Task ID</b>   | <b>Operations</b>  |
|                           | l2vpn  | read,<br>write   |
| <b>Examples</b>           | <p>This example shows how to specify a tag for a VLAN:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group xc1 RP/0/RP0/CPU0:router(config-l2vpn-xc)# p2p grp1 RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p)# neighbor 10.1.1.2 pw-id 78 RP/0/RP0/CPU0:router(config-l2vpn-xc-p2p-pw)# tag-impose vlan 8</pre> |  |
| <b>Related Commands</b>   | <b>Command</b>   | <b>Description</b>   |
|                           | <a href="#">pw-class (L2VPN), on page 57</a>   | Enters pseudowire class submode to define a pseudowire class template. |

# tag-rewrite

To configure VLAN tag rewrite, use the **tag-rewrite** command in Encapsulation MPLS configuration mode. To disable VLAN tag rewrite, use the **no** form of this command.

```
tag-rewrite ingress vlan vlan-id
no tag-rewrite ingress vlan vlan-id
```

|                    |   |  |
|--------------------|---|--|
| Syntax Description | <b>ingress</b>  | Configures ingress mode.                                 |
|                    | <b>vlan</b>   | Configures VLAN tagged mode                              |
|                    | <i>vlan-id</i>  | Specifies the value of the ID of the VLAN.               |
| Command Default    | None  |  |
| Command Modes      | Encapsulation MPLS configuration  |  |
| Command History    | <b>Release</b>  | <b>Modification</b>                                      |
|                    | Release 3.6.0   | This command was introduced.                             |
| Usage Guidelines   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The <b>tag-rewrite</b> command is applicable only to pseudowires with MPLS encapsulation.</p>   |  |
| Task ID            | <b>Task ID</b>  | <b>Operations</b>  |
|                    | l2vpn   | read,<br>write   |
| Examples           | <p>The following example shows how to configure preferred-path tunnel settings:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01 RP/0/RP0/CPU0:router(config-l2vpn-pwc)# encapsulation mpls RP/0/RP0/CPU0:router(config-l2vpn-pwc-encap-mpls)# tag-rewrite vlan 2000 RP/0/RP0/CPU0:router(config-l2vpn-pwc-encap-mpls)#</pre> |  |
| Related Commands   | <b>Command</b>  | <b>Description</b>                                       |
|                    | <a href="#">show l2vpn xconnect, on page 114</a>  | Displays brief information on configured cross-connects. |

## timeout setup (L2TP)

To configure timeout definitions for L2TP session setup, use the **timeout setup** command in L2TP class configuration mode. To return to the default behavior, use the **no** form of this command.

**timeout setup** *seconds*  
**no timeout setup** *seconds*

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <i>seconds</i> Time, in seconds, to setup a control channel. Range is 60 to 6000 seconds. Default is 300 seconds.   |  |
| <b>Command Default</b>    | <i>seconds</i> : 300  |  |
| <b>Command Modes</b>      | L2TP class configuration  |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 3.9.0   | This command was introduced.   |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.                           |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | l2vpn   | read,<br>write   |
| <b>Examples</b>           | <p>The following example shows how to configure a timeout value for L2TP session setup of 400 seconds:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2tp-class cisco RP/0/RP0/CPU0:router(config-l2tp-class)# timeout setup 400</pre> |  |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>   |
|                           | <a href="#">authentication (L2TP), on page 11</a>   | Enables L2TP authentication for a specified L2TP class name.                                   |
|                           | <a href="#">hello-interval (L2TP), on page 28</a>   | Configures the hello-interval value for L2TP (duration between control channel hello packets). |
|                           | <a href="#">hidden (L2TP), on page 30</a>   | Enables hidden attribute-value pairs (AVPs).   |
|                           | <a href="#">hostname (L2TP), on page 32</a>   | Defines the name used in the L2TP hostname AVP.  |
|                           | <a href="#">l2tp-class, on page 36</a>  | Enters L2TP class configuration mode where you can define an L2TP signaling template.          |

| Command   | Description   |
|---|---|
| <a href="#">password (L2TP), on page 55</a>       | Defines the password and password encryption type for control channel authentication. |
| <a href="#">receive-window (L2TP), on page 66</a> | Configures the receive window size for the L2TP server.                               |
| <a href="#">retransmit (L2TP), on page 68</a>     | Configures retransmit retry and timeout values.                                       |
| <a href="#">show l2tp session, on page 77</a>     | Displays information about L2TP sessions.   |
| <a href="#">show l2tp tunnel, on page 79</a>      | Displays information about L2TP tunnels.  |

## transport mode (L2VPN)

To configure L2VPN pseudowire class transport mode, use the **transport mode** command in L2VPN pseudowire class MPLS encapsulation mode. To disable the L@VPN pseudowire class transport mode configuration, use the **no** form of this command.

```
transport mode {ethernet | vlan }
no transport mode {ethernet | vlan }
```

| <b>Syntax Description</b> | <p><b>ethernet</b> Configures Ethernet port mode.</p> <p><b>vlan</b> Configures VLAN tagged mode.</p>   |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | None  |         |              |               |                              |
| <b>Command Modes</b>      | L2VPN pseudowire class MPLS encapsulation   |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.7.2</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 3.7.2 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 3.7.2             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |         |              |               |                              |



**Note** All L2VPN configurations can be deleted using the **no l2vpn** command.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

### Examples

This example shows how to configure Ethernet transport mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# pw-class kanata01
RP/0/RP0/CPU0:router(config-l2vpn-pw)# encapsulation mpls
RP/0/RP0/CPU0:router(config-l2vpn-encap-mpls)# transport-mode ethernet
```

| Related Commands | Command                                      | Description  |
|------------------|--|--|
|                  | <a href="#">pw-class (L2VPN), on page 57</a> | Enters pseudowire class submode to define a pseudowire class template. |

# transport mode vlan passthrough

To configure L2VPN bridge domain transport mode, use the **transport mode vlan passthrough** command in L2VPN bridge domain configuration mode. To disable the L2VPN bridge domain transport mode configuration, use the **no** form of this command.

**transport mode vlan passthrough**  
**no transport mode vlan passthrough**

| <b>Syntax Description</b> | This command has no keywords or arguments.  |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | None  |         |              |               |                              |
| <b>Command Modes</b>      | L2VPN bridge domain configuration   |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 4.3.1</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 4.3.1 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 4.3.1             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |         |              |               |                              |



**Note** All L2VPN configurations can be deleted using the **no l2vpn** command.

| Task ID | Task ID | Operations     |
|---------|---------|----------------|
|         | l2vpn   | read,<br>write |

## Examples

This example shows how to configure transport mode vlan passthrough:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group bg1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bd1
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# transport mode vlan passthrough
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode. |



# tunnel-template

To enter tunnel-template configuration submode, use the **tunnel-template** command in global configuration mode.

**tunnel-template** *template name*  
**no tunnel-template** *template-name*

|                           |   |                                  |
|---------------------------|---|----------------------------------|
| <b>Syntax Description</b> | <i>template-name</i> Configures a name for the tunnel template.   |                                  |
| <b>Command Default</b>    | None  |                                  |
| <b>Command Modes</b>      | Global configuration  |                                  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>              |
|                           | Release 3.5.0   | This command was introduced.     |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |                                  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>                |
|                           | tunnel  | read,<br>write                   |
| <b>Examples</b>           | The following example shows how to enter tunnel-template configuration submode:<br><br>RP/0/RP0/CPU0:router# <b>configure</b><br>RP/0/RP0/CPU0:router(config)# <b>tunnel-template template_01</b>                                     |                                  |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>               |
|                           | <a href="#">xconnect group, on page 136</a>   | Configures cross-connect groups. |

# xconnect group

To configure cross-connect groups, use the **xconnect group** command in L2VPN configuration mode. To return to the default behavior, use the **no** form of this command.

**xconnect group** *group-name*  
**no xconnect group** *group-name*

|                           |  |
|---------------------------|--|
| <b>Syntax Description</b> | <i>group-name</i> Configures a cross-connect group name using a free-format 32-character string. |
|---------------------------|--|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |                     |
|----------------------|---------------------|
| <b>Command Modes</b> | L2VPN configuration |
|----------------------|---------------------|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.4.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|



|             |  |
|-------------|--|
| <b>Note</b> | You can configure up to a maximum of 16K cross-connects per box. |
|-------------|--|

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

|                 |   |
|-----------------|---|
| <b>Examples</b> | The following example shows how to group all cross -connects for customer_atlantic: |
|-----------------|---|

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# xconnect group customer_atlantic
```

|                         |  |  |
|-------------------------|--|--|
| <b>Related Commands</b> | <b>Command</b>                                   | <b>Description</b>                                       |
|                         | <a href="#">show l2vpn xconnect, on page 114</a> | Displays brief information on configured cross-connects. |



## Virtual Private LAN Services Commands

This module describes the commands used to configure, monitor, and troubleshoot Virtual Private LAN Services (VPLS).

For detailed information about virtual private network concepts, configuration tasks, and examples, refer to the *Virtual Private Configuration Guide*.

- [action \(VPLS\), on page 138](#)
- [aging \(VPLS\), on page 140](#)
- [bridge-domain \(VPLS\), on page 142](#)
- [bridge group \(VPLS\), on page 143](#)
- [clear l2vpn bridge-domain \(VPLS\), on page 144](#)
- [flooding disable, on page 145](#)
- [interface \(VPLS\), on page 147](#)
- [learning disable \(VPLS\), on page 149](#)
- [limit \(VPLS\), on page 151](#)
- [mac \(VPLS\), on page 153](#)
- [maximum \(VPLS\), on page 155](#)
- [mpls static label \(VPLS\), on page 157](#)
- [mtu \(VPLS\), on page 159](#)
- [neighbor \(VPLS\), on page 161](#)
- [notification \(VPLS\), on page 163](#)
- [port-down flush disable \(VPLS\), on page 165](#)
- [pw-class \(VFI\), on page 167](#)
- [show l2vpn bridge-domain \(VPLS\), on page 169](#)
- [show l2vpn forwarding bridge-domain \(VPLS\), on page 178](#)
- [show l2vpn forwarding bridge-domain mac-address \(VPLS\), on page 194](#)
- [shutdown \(Bridge Domain\), on page 205](#)
- [shutdown \(VFI\), on page 206](#)
- [static-address \(VPLS\), on page 208](#)
- [static-mac-address \(VPLS\), on page 210](#)
- [time \(VPLS\), on page 212](#)
- [type \(VPLS\), on page 214](#)
- [vfi \(VPLS\), on page 216](#)
- [withdraw \(VPLS\), on page 218](#)

## action (VPLS)

To configure the bridge behavior when the number of learned MAC addresses reaches the MAC limit configured, use the **action** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

**action** {**flood** | **no-flood** | **shutdown**}

**no action** {**flood** | **no-flood** | **shutdown**}

|                           |                 |   |
|---------------------------|-----------------|---|
| <b>Syntax Description</b> | <b>flood</b>    | Configures the action to flood all unknown unicast packets when the MAC limit is reached. If the action is set to flood, all unknown unicast packets, with unknown destinations addresses, are flooded over the bridge.     |
|                           | <b>no-flood</b> | Configures the action to no-flood so all unknown unicast packets are dropped when the MAC limit is reached. If the action is set to no-flood, all unknown unicast packets, with unknown destination addresses, are dropped. |
|                           | <b>shutdown</b> | Stops forwarding when the MAC limit is reached. If the action is set to shutdown, all packets are dropped.  |

**Command Default** No action is taken when the MAC address limit is reached.

**Command Modes** L2VPN bridge group bridge domain MAC limit configuration

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.8.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **action** command to specify the type of action to be taken when the action is violated.

The configured action has no impact if the MAC limit has not been reached.

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

### Examples

The following example shows how to configure the bridge bar to flood all unknown unicast packets when the number of MAC addresses learned by the bridge reaches 10:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)#bridge group 1
```

```

RP/0/RP0/CPU0:router(config-l2vpn-bg) #bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd) #mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac) #limit
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit) #action flood
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit) #maximum 10

```

## Related Commands

| Command   | Description  |
|---|--|
| <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.   |
| <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.                   |
| <a href="#">limit (VPLS), on page 151</a>         | Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode. |
| <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |
| <a href="#">mac (VPLS), on page 153</a>           | Enters L2VPN bridge group bridge domain MAC configuration mode.  |
| <a href="#">maximum (VPLS), on page 155</a>       | Configures the specified action when the number of MAC addresses learned on a bridge is reached.   |
| <a href="#">notification (VPLS), on page 163</a>  | Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.                     |

## aging (VPLS)

To enter the MAC aging configuration submode to set the aging parameters such as time and type, use the **aging** command in L2VPN bridge group bridge domain configuration mode. To return to the default value for all parameters that are attached to this configuration submode, use the **no** form of this command.

**aging**  
**no aging**

| <b>Syntax Description</b> | This command has no keywords or arguments.  |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | No defaults are attached to this parameter since it is used as a configuration submode. See defaults that are assigned to the <a href="#">time (VPLS), on page 212</a> and the <a href="#">type (VPLS), on page 214</a> parameters.   |         |              |               |                              |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain MAC configuration  |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 3.8.0 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 3.8.0             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>aging</b> command to enter L2VPN bridge group bridge domain MAC aging configuration mode.</p>  |         |              |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>   | Task ID | Operations   | l2vpn         | read,<br>write               |
| Task ID                   | Operations  |         |              |               |                              |
| l2vpn                     | read,<br>write  |         |              |               |                              |
| <b>Examples</b>           | <p>The following example shows how to enter MAC aging configuration submode and to set the MAC aging time to 120 seconds:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# aging RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# time 120</pre> |         |              |               |                              |

| <b>Related Commands</b>                           | <table> <tr> <th>Commands</th><th>Description</th></tr> <tr> <td><a href="#">bridge-domain (VPLS), on page 142</a></td><td>Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.</td></tr> </table> | Commands | Description | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode. |
|---|---|----------|-------------|---|---|
| Commands  | Description   |          |             |   |   |
| <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain and enters L2VPN bridge group bridge domain configuration mode.   |          |             |   |   |

| Commands   | Description  |
|--|--|
| <a href="#">bridge group (VPLS), on page 143</a> | Creates a bridge group so that it can contain bridge domains and then assigns network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                | Enters L2VPN configuration mode.   |
| <a href="#">mac (VPLS), on page 153</a>          | Enters L2VPN bridge group bridge domain MAC configuration mode.  |
| <a href="#">time (VPLS), on page 212</a>         | Configures the maximum aging time.   |
| <a href="#">type (VPLS), on page 214</a>         | Configures the type for MAC address aging.   |

## bridge-domain (VPLS)

To establish a bridge domain and to enter L2VPN bridge group bridge domain configuration mode, use the **bridge-domain** command in L2VPN bridge group configuration mode. To return to a single bridge domain, use the **no** form of this command.

**bridge-domain** *bridge-domain-name*  
**no bridge-domain** *bridge-domain-name*

|                           |   |
|---------------------------|---|
| <b>Syntax Description</b> | <i>bridge-domain-name</i> Name of the bridge domain.  |
|                           | <b>Note</b> The maximum number of characters that can be specified in the bridge domain name is 27.   |
| <b>Command Default</b>    | The default value is a single bridge domain.  |
| <b>Command Modes</b>      | L2VPN bridge group configuration  |
| <b>Command History</b>    | <b>Release</b> <b>Modification</b>  |
|                           | Release 3.8.0 This command was introduced.  |
| <b>Usage Guidelines</b>   | Use the <b>bridge-domain</b> command to enter L2VPN bridge group bridge domain configuration mode.  |
| <b>Task ID</b>            | <b>Task ID</b> <b>Operations</b>  |
|                           | l2vpn      read,<br>write   |
| <b>Examples</b>           | <p>The following example shows how to configure a bridge domain:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)#</pre> |
| <b>Related Commands</b>   | <b>Command</b> <b>Description</b>   |
|                           | <a href="#">bridge group (VPLS), on page 143</a> Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.   |
|                           | <a href="#">l2vpn, on page 44</a> Enters L2VPN configuration mode.  |



## bridge group (VPLS)

To create a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain, use the **bridge group** command in L2VPN configuration mode. To remove all the bridge domains that are created under this bridge group and to remove all network interfaces that are assigned under this bridge group, use the **no** form of this command.

**bridge group** *bridge-group-name*  
**no bridge-group** *bridge-group-name*

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <i>bridge-group-name</i> Number of the bridge group to which the interface belongs.   |  |
| <b>Command Default</b>    | No bridge group is created.   |  |
| <b>Command Modes</b>      | L2VPN configuration   |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 3.8.0   | This command was introduced.   |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>bridge group</b> command to enter L2VPN bridge group configuration mode.</p> |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | l2vpn   | read,<br>write   |
| <b>Examples</b>           | <p>The following example shows that bridge group 1 is assigned:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)#</pre>  |  |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>   |
|                           | <a href="#">bridge-domain (VPLS), on page 142</a>   | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode. |
|                           | <a href="#">l2vpn, on page 44</a>   | Enters L2VPN configuration mode.   |

## clear l2vpn bridge-domain (VPLS)

To clear the MAC addresses and to restart the bridge domains on the router, use the **clear l2vpn bridge-domain** command in EXEC mode.

**clear l2vpn bridge-domain** {all | bd-name *name* | group *group*}

|                           |                            |  |
|---------------------------|----------------------------|--|
| <b>Syntax Description</b> | <b>all</b>                 | Clears and restarts all the bridge domains on the router.  |
|                           | <b>bd-name</b> <i>name</i> | Clears and restarts the specified bridge domain. The <i>name</i> argument specifies the name of the bridge-domain. |
|                           | <b>group</b> <i>group</i>  | Clears and restarts all the bridge domains that are part of the bridge group.                                      |

**Command Default** None

**Command Modes** EXEC

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.8.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This is the method that allows a bridge to forward again after it was put in Shutdown state as a result of exceeding the configured MAC limit.

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

### Examples

The following example shows how to clear all the MAC addresses and to restart all the bridge domains on the router:

```
RP/0/RP0/CPU0:router# clear l2vpn bridge-domain all
```

|                         |  |   |
|-------------------------|--|---|
| <b>Related Commands</b> | <b>Command</b>   | <b>Description</b>  |
|                         | <a href="#">show l2vpn bridge-domain (VPLS), on page 169</a> | Display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains. |

# flooding disable

To configure flooding for traffic at the bridge domain level or at the bridge port level, use the **flooding disable** command in L2VPN bridge group bridge domain configuration mode. To return the bridge to normal flooding behavior when all unknown unicast packets, all broadcast packets, and all multicast packets are flooded over all other bridge domain network interfaces, use the **no** form of this command.

**flooding disable**

**no flooding disable**

This command has no keywords or arguments.

|                        |   |
|------------------------|---|
| <b>Command Default</b> | The default behavior is that packets are flooded when their destination MAC address is not found. |
|------------------------|---|

|                      |  |
|----------------------|--|
| <b>Command Modes</b> | L2VPN bridge group bridge domain configuration |
|----------------------|--|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.8.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|

Use the **flooding disable** command to override the parent bridge configuration.

By default, bridge ports inherit the flooding behavior of the bridge domain.

When flooding is disabled, all unknown unicast packets, all broadcast packets, and all multicast packets are discarded.

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

|                 |  |
|-----------------|--|
| <b>Examples</b> | The following example shows how to disable flooding on the bridge domain called bar: |
|-----------------|--|

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# flooding disable
```

|                         |   |  |
|-------------------------|---|--|
| <b>Related Commands</b> | <b>Command</b>                                    | <b>Description</b>   |
|                         | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode. |

| Command  | Description  |
|--|--|
| <a href="#">bridge group (VPLS), on page 143</a> | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                | Enters L2VPN configuration mode.   |
| <a href="#">mtu (VPLS), on page 159</a>          | Adjusts the maximum packet size or maximum transmission unit (MTU) size for the bridge domain.                           |

# interface (VPLS)

To add an interface to a bridge domain that allows packets to be forwarded and received from other interfaces that are part of the same bridge domain, use the **interface** command in L2VPN bridge group bridge domain configuration mode. To remove an interface from a bridge domain, use the **no** form of this command.

**interface** *type interface-path-id*  
**no interface** *type interface-path-id*

|                           |                          |  |
|---------------------------|--------------------------|--|
| <b>Syntax Description</b> | <i>type</i>              | Interface type. For more information, use the question mark (?) online help function.                      |
|                           | <i>interface-path-id</i> | Physical interface or virtual interface.   |
|                           | <b>Note</b>              | Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router. |
|                           |                          | For more information about the syntax for the router, use the question mark (?) online help function.      |

**Command Default** None

**Command Modes** L2VPN bridge group bridge domain configuration

| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|------------------------|----------------|------------------------------|
|                        | Release 3.8.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface** command to enter L2VPN bridge group bridge domain attachment circuit configuration mode. In addition, the **interface** command enters the interface configuration submode to configure parameters specific to the interface.

By default, an interface is not part of a bridge.

| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|----------------|----------------|-------------------|
|                | l2vpn          | read,<br>write    |

## Examples

The following example shows how to configure the bundle Ethernet interface as an attachment circuit:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
```

**interface (VPLS)**

```
RP/0/RP0/CPU0:router(config-l2vpn-bg) # bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd) # interface gigabitethernet 0/1/0/9
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-ac) #
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                  | <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                  | <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |

# learning disable (VPLS)

To override the MAC learning configuration of a parent bridge or to set the MAC learning configuration of a bridge, use the **learning disable** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command.

**learning disable**  
**no learning disable**

|                           |  |  |
|---------------------------|--|--|
| <b>Syntax Description</b> | This command has no keywords or arguments.   |  |
| <b>Command Default</b>    | By default, learning is enabled on all bridge domains and all interfaces on that bridge inherits this behavior.  |  |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain MAC configuration   |  |
| <b>Command History</b>    | <b>Release</b>   | <b>Modification</b>  |
|                           | Release 3.8.0  | This command was introduced.   |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>When set, the <b>learning disable</b> command stops all MAC learning either on the specified interface or the bridge domain.</p>   |  |
| <b>Task ID</b>            | <b>Task ID</b>   | <b>Operations</b>  |
|                           | l2vpn  | read,<br>write   |
| <b>Examples</b>           | <p>In the following example, MAC learning is disabled on all ports in the bridge domain called bar, which is applied to all interfaces in the bridge unless the interface has its own MAC learning enable command.</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# learning disable</pre> |  |
| <b>Related Commands</b>   | <b>Command</b>   | <b>Description</b>   |
|                           | <a href="#">bridge-domain (VPLS), on page 142</a>  | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode. |

| Command  | Description  |
|--|--|
| <a href="#">bridge group (VPLS), on page 143</a> | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                | Enters L2VPN configuration mode.   |
| <a href="#">mac (VPLS), on page 153</a>          | Enters L2VPN bridge group bridge domain MAC configuration mode.  |



# limit (VPLS)

To set the MAC address limit for action, maximum, and notification and to enter L2VPN bridge group bridge domain MAC limit configuration mode, use the **limit** command in L2VPN bridge group bridge domain MAC configuration mode. To remove all limits that were previously configured under the MAC configuration submodes, use the **no** form of this command.

**limit**  
**no limit**

|                           |  |                              |
|---------------------------|--|------------------------------|
| <b>Syntax Description</b> | This command has no keywords or arguments.   |                              |
| <b>Command Default</b>    | None   |                              |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain MAC configuration   |                              |
| <b>Command History</b>    | <b>Release</b>   | <b>Modification</b>          |
|                           | Release 3.8.0  | This command was introduced. |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>limit</b> command to enter L2VPN bridge group bridge domain MAC limit configuration mode. The <b>limit</b> command specifies that one syslog message is sent or a corresponding trap is generated with the MAC limit when the action is violated.</p> |                              |
| <b>Task ID</b>            | <b>Task ID</b>   | <b>Operations</b>            |
|                           | l2vpn  | read,<br>write               |

## Examples

The following example shows how the MAC limit for the bridge bar is set to 100 with an action of shutdown. After the configuration, the bridge stops all forwarding after 100 MAC addresses are learned. When this happens, a syslog message and an SNMP trap are created.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 100
```

```
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action shutdown
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# notification both
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">action (VPLS), on page 138</a>        | Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.                    |
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                  | <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                  | <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |
|                  | <a href="#">mac (VPLS), on page 153</a>           | Enters L2VPN bridge group bridge domain MAC configuration mode.  |
|                  | <a href="#">maximum (VPLS), on page 155</a>       | Configures the specified action when the number of MAC addresses learned on a bridge is reached.                         |
|                  | <a href="#">notification (VPLS), on page 163</a>  | Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.   |

## mac (VPLS)

To enter L2VPN bridge group bridge domain MAC configuration mode, use the **mac** command in L2VPN bridge group bridge domain configuration mode. To disable all configurations added under the MAC configuration submodes, use the **no** form of this command.

**mac**  
**no mac**

|                           |  |
|---------------------------|--|
| <b>Syntax Description</b> | This command has no keywords or arguments. |
|---------------------------|--|

|                        |      |
|------------------------|------|
| <b>Command Default</b> | None |
|------------------------|------|

|                      |  |
|----------------------|--|
| <b>Command Modes</b> | L2VPN bridge group bridge domain configuration |
|----------------------|--|

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.8.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|

Use the **mac** command to enter L2VPN bridge group bridge domain MAC configuration mode.

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | l2vpn          | read,<br>write    |

### Examples

The following example shows how to enter L2VPN bridge group bridge domain MAC configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)#
```

|                         |   |   |
|-------------------------|---|---|
| <b>Related Commands</b> | <b>Command</b>                                    | <b>Description</b>  |
|                         | <a href="#">aging (VPLS), on page 140</a>         | Enters the MAC aging configuration submode to set the aging parameters such as time and type. |
|                         | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.  |

| Command  | Description  |
|--|--|
| <a href="#">bridge group (VPLS), on page 143</a>     | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.                   |
| <a href="#">l2vpn, on page 44</a>                    | Enters L2VPN configuration mode.   |
| <a href="#">learning disable (VPLS), on page 149</a> | Overrides the MAC learning configuration of a parent bridge or sets the MAC learning configuration of a bridge.                            |
| <a href="#">limit (VPLS), on page 151</a>            | Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode. |
| <a href="#">static-address (VPLS), on page 208</a>   | Adds static entries to the MAC address for filtering.  |
| <a href="#">withdraw (VPLS), on page 218</a>         | Disables MAC address withdrawal for a specified bridge domain  |

## maximum (VPLS)

To configure the specified action when the number of MAC addresses learned on a bridge is reached, use the **maximum** command in L2VPN bridge group bridge domain MAC limit configuration mode. To disable this feature, use the **no** form of this command.

**maximum** *value*  
**no maximum** *value*

| <b>Syntax Description</b> | <p><i>value</i> Maximum number of learned MAC addresses.</p> <p>The range is from 5 to 512000.</p>  |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | The default maximum value is 4000.  |         |              |               |                              |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain MAC limit configuration  |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 3.8.0 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 3.8.0             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The action can either be flood, no flood, or shutdown. Depending on the configuration, a syslog, an SNMP trap notification, or both are issued.</p>   |         |              |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>   | Task ID | Operations   | l2vpn         | read,<br>write               |
| Task ID                   | Operations  |         |              |               |                              |
| l2vpn                     | read,<br>write  |         |              |               |                              |
| <b>Examples</b>           | <p>The following example shows when the number of MAC address learned on the bridge reaches 5000 and the bridge stops learning but continues flooding:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# limit</pre> |         |              |               |                              |

**maximum (VPLS)**

```
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# maximum 5000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# action no-flood
```

**Related Commands**

| Command   | Description  |
|---|--|
| <a href="#">action (VPLS), on page 138</a>        | Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.                                      |
| <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.   |
| <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.                   |
| <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |
| <a href="#">limit (VPLS), on page 151</a>         | Sets the MAC address limit for action, maximum, and notification and enters L2VPN bridge group bridge domain MAC limit configuration mode. |
| <a href="#">mac (VPLS), on page 153</a>           | Enters L2VPN bridge group bridge domain MAC configuration mode.  |
| <a href="#">notification (VPLS), on page 163</a>  | Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.                     |

## mpls static label (VPLS)

To configure the MPLS static labels and the static labels for the access pseudowire configuration, use the **mpls static label** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To assign the dynamic MPLS labels to either the virtual forwarding interface (VFI) pseudowire or the access pseudowire, use the **no** form of this command.

**mpls static label local** *value value* **remote** *value*  
**no mpls static label local** *value value* **remote** *value*

|                           |  |  |
|---------------------------|--|--|
| <b>Syntax Description</b> | <b>local</b> <i>value</i>  | Configures the local pseudowire label.   |
|                           | <b>Note</b>  | Use the <b>show mpls label range</b> command to obtain the range for the local labels.         |
|                           | <b>remote</b> <i>value</i>   | Configures the remote pseudowire label.  |
|                           | <b>Note</b>  | The range of values for the remote labels depends on the label allocator of the remote router. |
| <b>Command Default</b>    | By default, the router attempts to assign dynamic labels to the pseudowire.  |  |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain Access/VFI pseudowire configuration   |  |
| <b>Command History</b>    | <b>Release</b>   | <b>Modification</b>  |
|                           | Release 3.8.0  | This command was introduced.   |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Ensure that both ends of the pseudowire have matching static labels.</p>   |  |
| <b>Task ID</b>            | <b>Task ID</b>   | <b>Operations</b>  |
|                           | l2vpn  | read,<br>write   |
| <b>Examples</b>           | <p>The following example shows how to configure the VFI pseudowire 10.1.1.2 with pseudowire ID of 1000 to use MPLS label 800 and remote MPLS label 500:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi model</pre> |  |

## mpls static label (VPLS)

```
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# mpls static label local 800 remote 500
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                  | <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                  | <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |
|                  | <a href="#">neighbor (VPLS), on page 161</a>      | Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).        |
|                  | <a href="#">pw-class (VFI), on page 167</a>       | Configures the pseudowire class template name to use for the pseudowire.   |
|                  | <a href="#">vfi (VPLS), on page 216</a>           | Configures virtual forwarding interface (VFI) parameters.  |



## mtu (VPLS)

To adjust the maximum packet size or maximum transmission unit (MTU) size for the bridge domain, use the **mtu** command in L2VPN bridge group bridge domain configuration mode. To disable this feature, use the **no** form of this command.

**mtu** *bytes*  
**no mtu**

|                           |  |                              |
|---------------------------|--|------------------------------|
| <b>Syntax Description</b> | <i>bytes</i> MTU size, in bytes. The range is from 46 to 65535.  |                              |
| <b>Command Default</b>    | The default MTU value is 1500.   |                              |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain configuration   |                              |
| <b>Command History</b>    | <b>Release</b>   | <b>Modification</b>          |
|                           | Release 3.8.0  | This command was introduced. |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.  |                              |
|                           | Each interface has a default maximum packet size or MTU size. This number generally defaults to the largest size possible for that interface type. On serial interfaces, the MTU size varies, but cannot be set smaller than 64 bytes. |                              |
|                           | The MTU for the bridge domain includes only the payload of the packet. For example, a configured bridge MTU of 1500 allows tagged packets of 1518 bytes (6 bytes DA, 6 bytes SA, 2 bytes ethertype, or 4 bytes qtag).                  |                              |
| <b>Task ID</b>            | <b>Task ID</b>   | <b>Operations</b>            |
|                           | l2vpn  | read,<br>write               |
| <b>Examples</b>           | <p>The following example specifies an MTU of 1000 bytes:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1</pre>   |                              |

```
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mtu 1000
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                  | <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                  | <a href="#">flooding disable, on page 145</a>     | Configures flooding for traffic at the bridge domain level or at the bridge port level.                                  |
|                  | <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |

## neighbor (VPLS)

To add an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI), use the **neighbor** command in the appropriate L2VPN bridge group bridge domain configuration submode. To remove the pseudowire either from the bridge or from the VFI, use the **no** form of this command.

**neighbor** *A.B.C.D* **pw-id** *value*  
**no neighbor** *A.B.C.D* **pw-id** *value*

| <b>Syntax Description</b>    | <table> <tr> <td><i>A.B.C.D</i></td><td>IP address of the cross-connect peer.</td></tr> <tr> <td><b>pw-id</b><br/><i>value</i></td><td>Configures the pseudowire ID and ID value. Range is 1 to 4294967295.</td></tr> </table>  | <i>A.B.C.D</i> | IP address of the cross-connect peer. | <b>pw-id</b><br><i>value</i> | Configures the pseudowire ID and ID value. Range is 1 to 4294967295. |
|------------------------------|---|----------------|---------------------------------------|------------------------------|--|
| <i>A.B.C.D</i>               | IP address of the cross-connect peer.   |                |                                       |                              |  |
| <b>pw-id</b><br><i>value</i> | Configures the pseudowire ID and ID value. Range is 1 to 4294967295.  |                |                                       |                              |  |
| <b>Command Default</b>       | None  |                |                                       |                              |  |
| <b>Command Modes</b>         | L2VPN bridge group bridge domain configuration<br>L2VPN bridge group bridge domain VFI configuration  |                |                                       |                              |  |
| <b>Command History</b>       | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> </table>  | Release        | Modification                          | Release 3.8.0                | This command was introduced.   |
| Release                      | Modification  |                |                                       |                              |  |
| Release 3.8.0                | This command was introduced.  |                |                                       |                              |  |
| <b>Usage Guidelines</b>      | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>neighbor</b> command to enter L2VPN bridge group bridge domain VFI pseudowire configuration mode. Alternatively, use the <b>neighbor</b> command to enter L2VPN bridge group bridge domain access pseudowire configuration mode.</p> |                |                                       |                              |  |
| <b>Task ID</b>               | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>   | Task ID        | Operations                            | l2vpn                        | read,<br>write   |
| Task ID                      | Operations  |                |                                       |                              |  |
| l2vpn                        | read,<br>write  |                |                                       |                              |  |
| <b>Examples</b>              | <p>The following example shows how to configure an access pseudowire directly under a bridge domain in L2VPN bridge group bridge domain configuration mode:</p>   |                |                                       |                              |  |

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-pw)#
```

The following example shows how to configure the parameters for any pseudowire in L2VPN bridge group bridge domain VFI configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)#
```

#### Related Commands

| Command  | Description  |
|--|--|
| <a href="#">bridge-domain (VPLS), on page 142</a>      | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
| <a href="#">bridge group (VPLS), on page 143</a>       | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                      | Enters L2VPN configuration mode.   |
| <a href="#">mpls static label (VPLS), on page 157</a>  | Configures the MPLS static labels and the static labels for the access pseudowire configuration.                         |
| <a href="#">pw-class (VFI), on page 167</a>            | Configures the pseudowire class template name to use for the pseudowire.   |
| <a href="#">static-mac-address (VPLS), on page 210</a> | Configures the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface.     |
| <a href="#">vfi (VPLS), on page 216</a>                | Configures virtual forwarding interface (VFI) parameters.  |

## notification (VPLS)

To specify the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit, use the **notification** command in L2VPN bridge group bridge domain MAC limit configuration mode. To use the notification as only a syslog entry, use the **no** form of this command.

**notification** {both | none | trap}  
**no notification** {both | none | trap}

| <b>Syntax Description</b> | <p><b>both</b> Sends syslog and trap notifications when the action is violated.</p> <p><b>none</b> Specifies no notification.</p> <p><b>trap</b> Sends trap notifications when the action is violated.</p>   |         |              |               |                              |
|---------------------------|--|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | By default, only a syslog message is sent when the number of learned MAC addresses reaches the maximum configured.   |         |              |               |                              |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain MAC limit configuration   |         |              |               |                              |
| <b>Command History</b>    | <table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> </tbody> </table>  | Release | Modification | Release 3.8.0 | This command was introduced. |
| Release                   | Modification   |         |              |               |                              |
| Release 3.8.0             | This command was introduced.   |         |              |               |                              |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>A syslog message and an SNMP trap is generated. Alternatively, an SNMP trap is generated. Finally, no notification is generated.</p> |         |              |               |                              |
| <b>Task ID</b>            | <table border="1"> <thead> <tr> <th>Task ID</th><th>Operations</th></tr> </thead> <tbody> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </tbody> </table>   | Task ID | Operations   | l2vpn         | read,<br>write               |
| Task ID                   | Operations   |         |              |               |                              |
| l2vpn                     | read,<br>write   |         |              |               |                              |
| <b>Examples</b>           | <p>The following example shows how both a syslog message and an SNMP trap are generated with the bridge bar and learns more MAC addresses than the configured limit:</p>   |         |              |               |                              |

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
```

```
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# limit
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-limit)# notification both
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">action (VPLS), on page 138</a>        | Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured.                    |
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                  | <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                  | <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |
|                  | <a href="#">mac (VPLS), on page 153</a>           | Enters L2VPN bridge group bridge domain MAC configuration mode.  |
|                  | <a href="#">maximum (VPLS), on page 155</a>       | Configures the specified action when the number of MAC addresses learned on a bridge is reached.                         |

# port-down flush disable (VPLS)

To disable MAC flush when the bridge port is nonfunctional, use the **port-down flush disable** command in the L2VPN bridge group bridge domain MAC configuration mode. Use the **no** form of this command to enable the MAC flush when the bridge port is nonfunctional.

**port-down flush disable**  
**no port-down flush disable**

| <b>Syntax Description</b> | This command has no keywords or arguments.  |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | None  |         |              |               |                              |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain MAC configuration  |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.9.0</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 3.9.0 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 3.9.0             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>The <b>port-down flush disable</b> command disables the MAC flush when the bridge port is nonfunctional.</p>  |         |              |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>   | Task ID | Operations   | l2vpn         | read,<br>write               |
| Task ID                   | Operations  |         |              |               |                              |
| l2vpn                     | read,<br>write  |         |              |               |                              |
| <b>Examples</b>           | <p>The following example shows how to disable MAC flush when the bridge port is nonfunctional:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# port-down flush disable</pre> |         |              |               |                              |

| Related Commands | Command   | Description   |
|------------------|---|---|
|                  | <a href="#">action (VPLS), on page 138</a>        | Configures bridge behavior when the number of learned MAC addresses reaches the MAC limit configured. |
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.          |

| Command  | Description  |
|--|--|
| <a href="#">bridge group (VPLS), on page 143</a> | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                | Enters L2VPN configuration mode.   |
| <a href="#">mac (VPLS), on page 153</a>          | Enters L2VPN bridge group bridge domain MAC configuration mode.  |
| <a href="#">maximum (VPLS), on page 155</a>      | Configures the specified action when the number of MAC addresses learned on a bridge is reached.                         |
| <a href="#">notification (VPLS), on page 163</a> | Specifies the type of notification that is sent when the number of learned MAC addresses exceeds the configured limit.   |



## pw-class (VFI)

To configure the pseudowire class template name to use for the pseudowire, use the **pw-class** command in L2VPN bridge group bridge domain VFI pseudowire configuration mode. To delete the pseudowire class, use the **no** form of this command.

**pw-class** *class-name*  
**no pw-class** *class-name*

| <b>Syntax Description</b>                         | <i>class-name</i> Pseudowire class name.   |         |              |   |  |  |  |
|---|--|---------|--------------|---|--|--|--|
| <b>Command Default</b>                            | None   |         |              |   |  |  |  |
| <b>Command Modes</b>                              | L2VPN bridge group bridge domain VFI pseudowire configuration  |         |              |   |  |  |  |
| <b>Command History</b>                            | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> </table>   | Release | Modification | Release 3.8.0                                     | This command was introduced.   |  |  |
| Release   | Modification   |         |              |   |  |  |  |
| Release 3.8.0                                     | This command was introduced.   |         |              |   |  |  |  |
| <b>Usage Guidelines</b>                           | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.  |         |              |   |  |  |  |
| <b>Task ID</b>                                    | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>  | Task ID | Operations   | l2vpn   | read,<br>write   |  |  |
| Task ID   | Operations   |         |              |   |  |  |  |
| l2vpn   | read,<br>write   |         |              |   |  |  |  |
| <b>Examples</b>                                   | <p>The following example shows how to attach the pseudowire class to the pseudowire:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1 RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000 RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# pw-class canada</pre> |         |              |   |  |  |  |
| <b>Related Commands</b>                           | <table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><a href="#">bridge-domain (VPLS), on page 142</a></td><td>Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.</td></tr> <tr> <td><a href="#">bridge group (VPLS), on page 143</a></td><td>Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.</td></tr> </table>                                   | Command | Description  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode. | <a href="#">bridge group (VPLS), on page 143</a> | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| Command   | Description  |         |              |   |  |  |  |
| <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.   |         |              |   |  |  |  |
| <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain.   |         |              |   |  |  |  |

| Command   | Description   |
|---|---|
| <a href="#">l2vpn, on page 44</a>                     | Enters L2VPN configuration mode.  |
| <a href="#">mpls static label (VPLS), on page 157</a> | Configures the MPLS static labels and the static labels for the access pseudowire configuration.                  |
| <a href="#">neighbor (VPLS), on page 161</a>          | Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI). |
| <a href="#">vfi (VPLS), on page 216</a>               | Configures virtual forwarding interface (VFI) parameters.   |

## show l2vpn bridge-domain (VPLS)

To display information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains, use the **show l2vpn bridge-domain** command in EXEC mode.

**show l2vpn bridge-domain** [{**bd-name** *bridge-domain-name* | **brief** | **detail** | **group** *bridge-domain-group-name* | **interface** *type interface-path-id* | **pw-id** *value* }] **neighbor** *IP-address* [{**pw-id** *value* | **summary**}]

| Syntax Description                           |  |  |
|--|--|--|
| <b>bd-name</b> <i>bridge-domain-name</i>     | (Optional) Displays the bridges by the bridge ID. The <i>bridge-domain-name</i> argument is used to name a bridge domain.  |  |
| <b>brief</b>                                 | (Optional) Displays brief information about the bridges.   |  |
| <b>detail</b>                                | (Optional) Displays the output for the Layer 2 VPN (L2VPN) to indicate whether or not the MAC withdrawal feature is enabled and the number of MAC withdrawal messages that are sent or received from the pseudowire. |  |
| <b>group</b> <i>bridge-domain-group-name</i> | (Optional) Displays filter information on the bridge-domain group name. The <i>bridge-domain-group-name</i> argument is used to name the bridge domain group.  |  |
| <b>interface</b>                             | (Optional) Displays the filter information for the interface on the bridge domain.   |  |
| <i>type</i>                                  | Interface type. For more information, use the question mark (?) online help function.  |  |
| <i>interface-path-id</i>                     | Physical interface or virtual interface.   |  |
|  | <b>Note</b>  | Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router. |
|  | For more information about the syntax for the router, use the question mark (?) online help function.  |  |
| <b>neighbor</b> <i>IP-address</i>            | (Optional) Displays only the bridge domain that contains the pseudowires to match the filter for the neighbor. The <i>IP-address</i> argument is used to configure IP address of the neighbor.                       |  |
| <b>pw-id</b> <i>value</i>                    | (Optional) Displays the filter for the pseudowire ID. The range is from 1 to 4294967295.   |  |
| <b>summary</b>                               | (Optional) Displays the summary information for the bridge domain.   |  |
| <b>Command Default</b>                       | None   |  |
| <b>Command Modes</b>                         | EXEC mode  |  |
| <b>Command History</b>                       | <b>Release</b>   | <b>Modification</b>  |
|  | Release 3.8.0  | This command was introduced.   |

| Release       | Modification  |
|---------------|---|
| Release 5.1.2 | This command was modified to enable filtering the command output for specific pseudowire with just the pseudowire ID. |

**Usage Guidelines**

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

Use the **interface** keyword to display only the bridge domain that contains the specified interface as an attachment circuit. In the sample output, only the attachment circuit matches the filter that is displayed. No pseudowires are displayed.



**Note** For Cisco IOS XR software Release 5.1.2 and above, you can filter the command output for a specific pseudowire with just the pseudowire ID. However, in case of configurations with BGP Auto-discovery with BGP or LDP signaling (in VPLS), you can specify the pseudowire only with the combination of the neighbor filter and the pseudowire ID.

**Task ID**

| Task ID | Operations |
|---------|------------|
|---------|------------|

|       |      |
|-------|------|
| l2vpn | read |
|-------|------|

**Examples**

This is the sample output for **show l2vpn bridge-domain** command with VxLAN parameters configured:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain bd-name bg1_bd1 detail
Legend: pp = Partially Programmed.
Bridge group: bg1, bridge-domain: bg1_bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Coupled state: disabled
  MAC learning: enabled
  MAC withdraw: enabled
    MAC withdraw for Access PW: enabled
    MAC withdraw sent on: bridge port up
    MAC withdraw relaying (access to access): disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  MAC port down flush: enabled
  MAC Secure: disabled, Logging: disabled
  Split Horizon Group: none
  Dynamic ARP Inspection: disabled, Logging: disabled
  IP Source Guard: disabled, Logging: disabled
  DHCPv4 snooping: disabled
  IGMP Snooping: enabled
  IGMP Snooping profile: none
  MLD Snooping profile: none
```

```
Storm Control: disabled
Bridge MTU: 1500
MIB cvplsConfigIndex: 1
Filter MAC addresses:
P2MP PW: disabled
Create time: 30/03/2015 22:25:38 (00:26:08 ago)
No status change since creation
ACs: 2 (2 up), VFIs: 1, PWs: 0 (0 up), PBBs: 0 (0 up)
List of ACs:
  AC: BV11, state is up
    Type Routed-Interface
    MTU 1514; XC ID 0x80000001; interworking none
    BVI MAC address:
      1000.4444.0001
  AC: GigabitEthernet0/8/0/0.1, state is up
    Type VLAN; Num Ranges: 1
    Outer Tag: 1
    VLAN ranges: [1001, 1001]
    MTU 1508; XC ID 0x508000a; interworking none
    MAC learning: enabled
    Flooding:
      Broadcast & Multicast: enabled
      Unknown unicast: enabled
    MAC aging time: 300 s, Type: inactivity
    MAC limit: 4000, Action: none, Notification: syslog
    MAC limit reached: no
    MAC port down flush: enabled
    MAC Secure: disabled, Logging: disabled
    Split Horizon Group: none
    Dynamic ARP Inspection: disabled, Logging: disabled
    IP Source Guard: disabled, Logging: disabled
    DHCPv4 snooping: disabled
    IGMP Snooping: enabled
    IGMP Snooping profile: none
    MLD Snooping profile: none
    Storm Control: bridge-domain policer
    Static MAC addresses:

    Storm control drop counters:
      packets: broadcast 0, multicast 0, unknown unicast 0
      bytes: broadcast 0, multicast 0, unknown unicast 0
    Dynamic ARP inspection drop counters:
      packets: 0, bytes: 0
    IP source guard drop counters:
      packets: 0, bytes: 0
List of VNIs:
  VNI 1, state is up
    XC ID 0x80000014
    Encap type VXLAN
    Overlay nve100, Source 10.0.0.1, Multicast Group 225.1.1.1, UDP Port 4789
    Anycast VTEP 100.1.1.1, Anycast Multicast Group 224.10.10.1
    MAC learning: enabled
    Flooding:
      Broadcast & Multicast: enabled
      Unknown unicast: enabled
    MAC aging time: 300 s, Type: inactivity
    MAC limit: 4000, Action: none, Notification: syslog
    MAC limit reached: no
    MAC port down flush: enabled
    MAC Secure: disabled, Logging: disabled
    Split Horizon Group: none
    Dynamic ARP Inspection: disabled, Logging: disabled
    IP Source Guard: disabled, Logging: disabled
    DHCPv4 snooping: disabled
```

**show l2vpn bridge-domain (VPLS)**

```

IGMP Snooping: enabled
IGMP Snooping profile: none
MLD Snooping profile: none
Storm Control: bridge-domain policer

List of Access PWs:
List of VFIs:
  VFI bgl_bdl_vfi (up)
  VFI Statistics:
    drops: illegal VLAN 0, illegal length 0

```

This table describes the significant fields shown in the display.

The following sample output shows information for the bridge ports such as attachment circuits and pseudowires for the specific bridge domains:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain

Bridge group: g1, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

This table describes the significant fields shown in the display.

**Table 9: show l2vpn bridge-domain Command Field Descriptions**

| Field         | Description                                      |
|---------------|--|
| Bridge group  | Name of bridge domain group is displayed.        |
| bridge-domain | Name of bridge domain is displayed.              |
| id            | ID assigned to this bridge domain is displayed.  |
| state         | Current state of the bridge domain is displayed. |

The following example shows sample output for a bridge named bd1:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain bd-name bd1

Bridge group: g1, bridge-domain: bdl, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.1.1.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows brief information about the bridges:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain brief
```

| Bridge Group/Bridge-Domain Name | ID | State | Num ACs/up | Num PWs/up |
|---------------------------------|----|-------|------------|------------|
| g1/bd1                          | 0  | up    | 1/1        | 1/1        |

This table describes the significant fields shown in the display.

**Table 10: show l2vpn bridge-domain brief Command Field Descriptions**

| Field                           | Description   |
|---------------------------------|---|
| Bridge Group/Bridge-Domain Name | Bridge domain group name followed by the bridge domain name are displayed.  |
| ID                              | ID assigned to this bridge domain is displayed.   |
| State                           | Current state of the bridge domain is displayed.  |
| Num ACs/up                      | Total number of attachment circuits that are up in this bridge domain is displayed.   |
| Num PWs/up                      | Total number of pseudowires that are up in this bridge domain is displayed. The count includes both VFI pseudowires and access pseudowires. |

The following sample output shows detailed information:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain detail
```

```
Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  MAC learning: enabled
  MAC withdraw: disabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: yes
  Security: disabled
  DHCPv4 snooping: disabled
  MTU: 1500
  Filter MAC addresses:
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
  List of ACs:
    AC: GigabitEthernet0/1/0/0, state is up
      Type Ethernet
      MTU 1500; XC ID 0x2000001; interworking none; MSTi 0 (unprotected)
      MAC learning: enabled
      Flooding:
        Broadcast & Multicast: enabled
        Unknown unicast: enabled
      MAC aging time: 300 s, Type: inactivity
      MAC limit: 4000, Action: none, Notification: syslog
      MAC limit reached: yes
      Security: disabled
      DHCPv4 snooping: disabled
      Static MAC addresses:
        0000.0000.0000
        0001.0002.0003
```

**show l2vpn bridge-domain (VPLS)**

```

Statistics:
  packet totals: receive 3919680,send 9328
  byte totals: receive 305735040,send 15022146
List of Access PWs:
List of VFIs:
VFI 1
  PW: neighbor 10.0.0.1, PW ID 1, state is up ( established )
  PW class mpls, XC ID 0xff000001
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word disabled, interworking none
  PW backup disable delay 0 sec
  Sequencing not set
      MPLS              Local              Remote
      -----
      Label             16003              16003
      Group ID          0x0                0x0
      Interface         1                  1
      MTU               1500              1500
      Control word      disabled            disabled
      PW type           Ethernet            Ethernet
      VCCV CV type      0x2                0x2
                        (LSP ping verification)  (LSP ping verification)
      VCCV CC type      0x2                0x2
                        (router alert label)    (router alert label)
      -----
Create time: 12/03/2008 14:03:00 (17:17:30 ago)
Last time status changed: 13/03/2008 05:57:58 (01:22:31 ago)
MAC withdraw message: send 0 receive 0
Static MAC addresses:
Statistics:
  packet totals: receive 3918814, send 3918024
  byte totals: receive 305667492, send 321277968
VFI Statistics:
  drops: illegal VLAN 0, illegal length 0

```

The following sample output shows that when a bridge operates in VPWS mode, the irrelevant information for MAC learning is suppressed:

```
RP/0/RP0/CPU0:router# show l2vpn bridge-domain detail
```

```

Bridge group: foo_group, bridge-domain: foo_bd, id: 0, state: up, ShgId: 0
VPWS Mode
MTU: 1500
ACs: 1 (0 up), VFIs: 1, PWs: 2 (2 up)
List of ACs:
  AC: GigabitEthernet0/5/1/4, state is admin down
  Type Ethernet      MTU 1500; XC ID 1; interworking none
  Static MAC addresses:
  Statistics:
    packet totals: receive 0,send 0
    byte totals: receive 0,send 0
List of VFIs:
  VFI foo_vfi
  PW: neighbor 10.0.0.1, PW ID 1, state is up ( established )
  PW class not set
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word enabled, interworking none
  Sequencing not set
      MPLS              Local              Remote
      -----
      Label             16001              16001
      Group ID          unassigned            unknown
      Interface         siva/vfi              siva/vfi

```



```

MTU          1500                      1500
Control word enabled                      enabled
PW type      Ethernet                    Ethernet
VCCV CV type 0x2                          0x2
              (LSP ping verification)      (LSP ping verification)
VCCV CC type 0x3                          0x3
              (control word)                (control word)
              (router alert label)          (router alert label)
-----
Create time: 25/06/2007 05:29:42 (2w0d ago)
Last time status changed: 27/06/2007 06:50:35 (1w5d ago)
Static MAC addresses:
PW: neighbor 10.0.0.1, PW ID 2, state is up ( established )
PW class not set
Encapsulation MPLS, protocol LDP
PW type Ethernet, control word enabled, interworking none
Sequencing not set
MPLS          Local                      Remote
-----
Label          16002                      16002
Group ID       unassigned                  unknown
Interface      siva/vfi                    siva/vfi
MTU            1500                        1500
Control word   enabled                      enabled
PW type        Ethernet                    Ethernet
VCCV CV type   0x2                          0x2
              (LSP ping verification)      (LSP ping verification)
VCCV CC type   0x3                          0x3
              (control word)                (control word)
              (router alert label)          (router alert label)
-----
Create time: 25/06/2007 05:29:42 (2w0d ago)
Last time status changed: 27/06/2007 06:50:35 (1w5d ago)
Static MAC addresses:
Statistics:
drops: illegal VLAN 0, illegal length 0

```

This table describes the significant fields shown in the display.

**Table 11: show l2vpn bridge-domain detail Command Field Descriptions**

| Field         | Description                                      |
|---------------|--|
| Bridge group  | Name of bridge domain group is displayed.        |
| bridge-domain | Name of bridge domain is displayed.              |
| ID            | ID assigned to this bridge domain is displayed.  |
| state         | Current state of the bridge domain is displayed. |
| MSTi          | ID for the Multiple Spanning Tree.               |

The following sample output shows filter information about the bridge-domain group named g1:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain group g1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
Filter MAC addresses: 0
ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)

```

**show l2vpn bridge-domain (VPLS)**

```

List of ACs:
  Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)
List of Access PWs:
List of VFIs:
  VFI 1
    Neighbor 10.0.0.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows display the filter information for the interface on the bridge domain:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain interface gigabitEthernet 0/1/0/0

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
  List of ACs:
    Gi0/1/0/0, state: up, Static MAC addresses: 2, MSTi: 0 (unprotected)

```

The following sample output shows that the bridge domain contains the pseudowires to match the filter for the neighbor:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain neighbor 10.0.0.1

Bridge group: g1, bridge-domain: bd1, id: 0, state: up, ShgId: 0, MSTi: 0
  Aging: 300 s, MAC limit: 4000, Action: none, Notification: syslog
  Filter MAC addresses: 0
  ACs: 1 (1 up), VFIs: 1, PWs: 1 (1 up)
  List of Access PWs:
  List of VFIs:
    VFI 1
      Neighbor 10.0.0.1 pw-id 1, state: up, Static MAC addresses: 0

```

The following sample output shows the summary information for the bridge domain:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain summary

Number of groups: 1, bridge-domains: 1, Up: 1, Shutdown: 0
Number of ACs: 1 Up: 1, Down: 0
Number of PWs: 1 Up: 1, Down: 0

```

This example shows the sample output of a configured flow label:

```

RP/0/RP0/CPU0:router# show l2vpn bridge-domain detail
Bridge group: g1, bridge-domain: d1, id: 0, state: up, ShgId: 0, MSTi: 0
.....
PW: neighbor 192.168.0.1, PW ID 2, state is up ( established )
  PW class class1, XC ID 0x1000002
  Encapsulation MPLS, protocol LDP
  PW type Ethernet, control word disabled, interworking none
  PW backup disable delay 0 sec
  Sequencing not set
  Flow label flags configured (Rx=1,Tx=1), negotiated (Rx=0,Tx=1)

```

This table describes the significant fields shown in the display.

**Table 12: show l2vpn bridge-domain summary Command Field Descriptions**

| Field            | Description  |
|------------------|--|
| Number of groups | Number of configured bridge domain groups is displayed.  |
| bridge-domains   | Number of configured bridge domains is displayed.  |
| Shutdown         | Number of bridge domains that are in Shutdown state is displayed.  |
| Number of ACs    | Number of attachment circuits that are in Up state and Down state are displayed.   |
| Number of PWs    | Number of pseudowires that are in Up state and Down state are displayed. This includes the VFI pseudowire and the access pseudowire. |

**Related Commands**

| Command   | Description   |
|---|---|
| <a href="#">clear l2vpn bridge-domain (VPLS), on page 144</a> | Clears the MAC addresses and restarts the bridge domains on the router. |

## show l2vpn forwarding bridge-domain (VPLS)

To display information on the bridge that is used by the forwarding layer, use the **show l2vpn forwarding bridge-domain** command in EXEC mode.

**show l2vpn forwarding bridge-domain** [*bridge-domain-name*] {**detail** | **hardware** {**egress** | **ingress**}}  
**location** *node-id*

### Syntax Description

*bridge-domain-name* (Optional) Name of a bridge domain.

**detail** Displays all the detailed information on the attachment circuits and pseudowires.

**hardware** Displays the hardware location entry.

**egress** Reads information from the egress PSE.

**ingress** Reads information from the ingress PSE.

**location** *node-id* Displays the bridge-domain information for the specified location. The *node-id* argument is entered in the *rack/slot/module* notation.

### Command Default

None

### Command Modes

EXEC

### Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.8.0 | This command was introduced. |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For each bridge, you can display summary information about the number of bridge ports, number of MAC addresses, configured VXLANs and so forth.

The **detail** keyword displays detailed information on the attachment circuits and pseudowires, and is meant for field investigation by a specialized Cisco engineer.



#### Note

All bridge ports in the bridge domain on that line card are displayed. Therefore, if the bridge domain contains non-local bridge ports, those are displayed as well.

### Task ID

| Task ID | Operations |
|---------|------------|
| l2vpn   | read       |

## Examples

The following sample output shows bridge-domain information for location 0/1/CPU0:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain location 0/1/CPU0

Bridge-Domain Name          ID      Ports addr  Flooding Learning State
-----
g1:bd1

Bridge-domain name: g1:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0

GigabitEthernet0/1/0/0, state: oper up
Number of MAC: 32770
Sent(Packets/Bytes): 0/21838568
Received(Packets/Bytes): 5704781/444972918

Nbor 10.0.0.1 pw-id 1
Number of MAC: 32766
Sent(Packets/Bytes): 0/0
Received(Packets/Bytes): 5703987/444910986
0      2      65536 Enabled Enabled UP
```

The following sample output shows detailed information for hardware location 0/1/CPU0 from the egress pse:

```
RP/0/RP0/CPU0:router

Bridge-domain name: g1:bd1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: yes
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 65536
Multi-spanning tree instance: 0

===== GSR HW Information =====

-----
SHG-TX rewrite details
-----
HW Rewrite 0 Detail :
-----
```

**show l2vpn forwarding bridge-domain (VPLS)**

```

Rewrite HW Address : 0x00060000
packets 0 bytes 0
Raw data:
[ 0x04018180 04018190 040181a0 040181b0 ]
[ 0x04018170 00000000 80360000 000bfff4 ]
[ 0x00000000 00000000 00000000 00000000 ]

-----
SHG-TX encap details
-----
outer_etype:          0
outer_vlan_id:        0
gather_profile:        0
inner_vlan_id:         0
so_l2_len_adjust:     0
-----
SHG-TX mgid details
-----
Base MGIDs for default mgid
base_mgid[0]:          0x0003ffff
base_mgid[1]:          0x0003ffff
base_mgid[2]:          0x0003ffff
base_mgid[3]:          0x0003ffff
base_mgid[4]:          0x0003ffff
base_mgid[5]:          0x0003ffff
base_mgid[6]:          0x0003ffff
base_mgid[7]:          0x0003ffff
MGID Entries for default mgid
oi[0]:                 0
oq[0]:                 16384
xc_id[0]:               1
mgid_idx[0]:            0x00000000
next_mgid[0]:           0x00000000
-----
VMR 0 Details
-----
vmrid: 0x5f002010
Value: 0xc0 0x00 0x1f 0xff 0xff 0xff 0xff 0xff 0xfd
Mask : 0x00 0x00 0x1f 0xff 0xff 0xff 0xff 0xff 0xe0
Result 0x32003000
=====

GigabitEthernet0/1/0/0, state: oper up
Number of MAC: 32770
Sent (Packets/Bytes): 749/22989834
Received (Packets/Bytes): 5732104/447104112

===== GSR HW Information =====

-----
BP-TX-AC rewrite details
-----

BP is local

-----
BP L2 Uidb Details
-----
l2fwd_enabled:         true
plim_enabled:          true
l2fwd_type:             4
l2_ac_type:             0
xconn_id:              0

```

```

bridge_id:                                0
shg id:                                   0
unicast flooding enabled:                  0
multicast flooding enabled:                0
broadcast flooding enabled:                0
mac learning enabled:                      0
Is AC Port mode?:                          0
-----
HW Rewrite 0 Detail :
-----
Rewrite HW Address : 0x59eff314
packets 0 bytes 0
HFA Bits 0x0 gp 0 mtu 1580 (REW)
OI 0x3fffc OutputQ 0 Output-port 0x36 local_outputq 0x0
Raw data:
[ 0x00000000 0036062c 0003fffc 00000000 ]
[ 0x00000000 00000000 0d103600 00000010 ]
[ 0x00000000 00000000 00000000 00000000 ]
-----
BP OI/OQ Details
-----
oi[0]:      0x00000000      oq[0]      16384
oi[1]:      0x00000000      oq[1]      65535
oi[2]:      0x00000000      oq[2]      65535
oi[3]:      0x00000000      oq[3]      65535
oi[4]:      0x00000000      oq[4]      65535
oi[5]:      0x00000000      oq[5]      65535
oi[6]:      0x00000000      oq[6]      65535
oi[7]:      0x00000000      oq[7]      65535
-----
Sram table entry details
-----
sram_data: 0xa000400c
=====

Nbor 10.0.0.1 pw-id 1
Number of MAC: 32766
Sent(Packets/Bytes): 0/0
Received(Packets/Bytes): 5731250/447037500

===== GSR HW Information =====

-----
BP-TX-AC rewrite details
-----
BP OI/OQ Details
-----
oi[0]:      0x00000000      oq[0]      65535
oi[1]:      0x00000000      oq[1]      65535
oi[2]:      0x00000000      oq[2]      65535
oi[3]:      0x00000000      oq[3]      65535
oi[4]:      0x00000000      oq[4]      65535
oi[5]:      0x00000000      oq[5]      65535
oi[6]:      0x00000000      oq[6]      65535
oi[7]:      0x00000000      oq[7]      65535
-----
BP Encap Info
-----
mac_length: 0
mac_string:
egress_slot: 2
num_tags: 1

```

**show l2vpn forwarding bridge-domain (VPLS)**

```
tags:          {16001, }
if_handle:     0x03000500
=====
```

The following sample output shows the bridge-domain information for the specified location:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0
```

| Bridge-Domain Name | ID | Ports | addr  | Flooding | Learning | State |
|--------------------|----|-------|-------|----------|----------|-------|
| g1:bd1             | 0  | 2     | 65536 | Enabled  | Enabled  | UP    |

The following sample output shows the hardware information for a specific bridge-domain:

```
RP/0/RP0/CPU0:router#show l2vpn bridge-domain hardware
```

```
Bridge group: aa, bridge-domain name: g1, id:0
FGID Boardcast [version 1]:
  Allocate_count: 2048, Retry_count: 0, Realloc_on: Off
  Status_flag: (0x4) Replay-end
  ALL 44032, VFI 44033
```

```
Bridge group: aa, bridge-domain name: g2, id:1
FGID Boardcast [version 1]:
  Allocate_count: 2048, Retry_count: 0, Realloc_on: Off
  Status_flag: (0x4) Replay-end
  ALL 44034, VFI 44035
```

The following sample output shows the hardware information for the line card, for a specific bridge-domain on the ingress detail location:

```
RP/0/RP0/CPU0:router#
```

```
show l2vpn forwarding bridge-domain hardware ingress detail location 0/2/CPU0
```

```
Bridge-domain name: aa:g1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 4
Number of MAC addresses: 0
Multi-spanning tree instance: 0

INGRESS BRIDGE [version, state]: [1, CREATED]

TCAM entry seq#: 1024 Key: [BID: 0 MAC: default]
HW: 0x4c000000 0x000080ac 0x00010000 0x80ac0100
SW: 0x4c000000 0x000080ac 0x00010000 0x80ac0100

SMAC:  action: PUNT  state: NO REFRESH
DMAC:  action: FLOOD, flood_enable: enable
FGID:  All: 44032, VFI: 44033, MCAST_Sponge_q: 16
Fabric_multicast1: 1 Fabric_multicast2: 1

Admin State: UP
MTU: 1500
```



```

Number of MAC addresses: 1 (0 MAC + 1 default)
ACL NAME (ACL-ID): VPLS Special (4096)
TCAM region handle : 5

GigabitEthernet0/2/0/1.1, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 1 (0x1280001)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c00
  RX TLU2   : 0x1013c00
  RX TLU3   : 0x200ba00
  RX TLU4   : 0x3000c00

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [1] TCAM-Key: (UIDB:0x2 O-vlan:1 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24001000 0x01280001 0x10128000 0xc7ff7d00
  SW: 0x24001000 0x01280001 0x10128000 0xc7ff7d00

  Service type: 4 (bridging pmp)
  Entry type: 1 (fwd)
  Bridge_ID : 0
  ACL_ID : 4096
  Xconnect_ID : 0x1280001
  SplitHorizonGroup_ID : 0
  Rewrite supported: 0 (No)
  PW_mode: 0 (vc-type 5)
  AC-type: 1 (vlan-mode)
  Interface handle: 0x128000
  Ingress AC stats: 0x7ff7d

  SMAC Learning: enable
  DMAC Flooding: enable

GigabitEthernet0/2/0/1.2, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 2 (0x1280002)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c01
  RX TLU2   : 0x1013c01
  RX TLU3   : 0x200ba01
  RX TLU4   : 0x3000c01

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [2] TCAM-Key: (UIDB:0x2 O-vlan:2 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24001000 0x01280002 0x10128002 0xc7ff7a00
  SW: 0x24001000 0x01280002 0x10128002 0xc7ff7a00

  Service type: 4 (bridging pmp)
  Entry type: 1 (fwd)

```

**show l2vpn forwarding bridge-domain (VPLS)**

```

    Bridge_ID : 0
    ACL_ID : 4096
    Xconnect_ID : 0x1280002
    SplitHorizonGroup_ID : 0
    Rewrite supported: 0 (No)
    PW_mode: 0 (vc-type 5)
    AC-type: 1 (vlan-mode)
    Interface handle: 0x128002
    Ingress AC stats: 0x7ff7a

    SMAC Learning: enable
    DMAC Flooding: enable

GigabitEthernet0/2/0/1.3, state: oper up
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 3 (0x1280003)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1 : 0x4c02
  RX TLU2 : 0x1013c02
  RX TLU3 : 0x200ba02
  RX TLU4 : 0x3000c02

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [3] TCAM-Key: (UIDB:0x2 O-vlan:3 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24001000 0x01280003 0x10128004 0xc7ff7700
  SW: 0x24001000 0x01280003 0x10128004 0xc7ff7700

  Service type: 4 (bridging pmp)
  Entry type: 1 (fwd)
  Bridge_ID : 0
  ACL_ID : 4096
  Xconnect_ID : 0x1280003
  SplitHorizonGroup_ID : 0
  Rewrite supported: 0 (No)
  PW_mode: 0 (vc-type 5)
  AC-type: 1 (vlan-mode)
  Interface handle: 0x128004
  Ingress AC stats: 0x7ff77

  SMAC Learning: enable
  DMAC Flooding: enable

Nbor 5.0.0.5 pw-id 1
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: ATOM
  XID: 127/15/CPU0 : 1 (0xffff80001)
  Bridge ID: 0, Split Horizon ID: 1
  VC label: 16006
  Control-word supported: No

Bridge-domain name: aa:g2, id: 1, state: up

```

```

MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 0
Multi-spanning tree instance: 0

INGRESS BRIDGE [version, state]: [1, CREATED]

  TCAM entry seq#: 1025 Key: [BID: 1 MAC: default]
  HW: 0x4c000000 0x000080ac 0x02010000 0x80ac0300
  SW: 0x4c000000 0x000080ac 0x02010000 0x80ac0300

  SMAC: action: PUNT state: NO REFRESH
  DMAC: action: FLOOD, flood_enable: enable
  FGID: All: 44034, VFI: 44035, MCAST_Sponge_q: 16
  Fabric_multicast1: 1 Fabric_multicast2: 1

  Admin State: UP
  MTU: 1500
  Number of MAC addresses: 1 (0 MAC + 1 default)
  ACL NAME (ACL-ID): VPLS Special (4097)
  TCAM region handle : 5

GigabitEthernet0/2/0/1.4, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 4 (0x1280004)
  Bridge ID: 1, Split Horizon ID: 0
  RX TLU1 : 0x4c03
  RX TLU2 : 0x1013c03
  RX TLU3 : 0x200ba03
  RX TLU4 : 0x3000c03

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [4] TCAM-Key: (UIDB:0x2 O-vlan:4 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24003001 0x01280004 0x10128006 0xc7ff7400
  SW: 0x24003001 0x01280004 0x10128006 0xc7ff7400

  Service type: 4 (bridging pmp)
  Entry type: 1 (fwd)
  Bridge_ID : 1
  ACL_ID : 4097
  Xconnect_ID : 0x1280004
  SplitHorizonGroup_ID : 0
  Rewrite supported: 0 (No)
  PW_mode: 0 (vc-type 5)
  AC-type: 1 (vlan-mode)
  Interface handle: 0x128006
  Ingress AC stats: 0x7ff74

```

**show l2vpn forwarding bridge-domain (VPLS)**

```

        SMAC Learning: enable
        DMAC Flooding: enable

Nbor 5.0.0.5 pw-id 2
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: ATOM
  XID: 127/15/CPU0 : 2 (0xffff80002)
  Bridge ID: 1, Split Horizon ID: 1
  VC label: 16008
  Control-word supported: No

```

The following sample output shows the hardware information of the route processor, for a specific bridge-domain on the ingress detail location:

**RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain hardware ingress detail location 0/RP0/CPU0**

```

Bridge-domain name: aa:gl, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 4
Number of MAC addresses: 0
Multi-spanning tree instance: 0

BRIDGE [version, state]: [1, CREATED]
  Bridge ID: 0
    FGID1: 44032   NodeCount: 1   Info_len: 24   XID_count: 4
    FGID2: 44033   NodeCount: 1   Info_len: 20   XID_count: 3

  FGID1 Membership list:
    node-id: 0/2/CPU0 (0x21)   RSI: 0x25   XID_count: 4
    XID: 0x1280001   0x1280002   0x1280003   0xffff80001

  FGID2 Membership list:
    node-id: 0/2/CPU0 (0x21)   RSI: 0x25   XID_count: 3
    XID: 0x1280001   0x1280002   0x1280003

GigabitEthernet0/2/0/1.1, state: oper up
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

AC [version, state]: [1, BOUND]
  XID: 0x1280001   RSI: 0x25   Bridging: TRUE

GigabitEthernet0/2/0/1.2, state: oper up
  Number of MAC: 0

```

```

Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

AC [version, state]: [1, BOUND]
  XID: 0x1280002  RSI: 0x25  Bridging: TRUE

GigabitEthernet0/2/0/1.3, state: oper up
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

AC [version, state]: [1, BOUND]
  XID: 0x1280003  RSI: 0x25  Bridging: TRUE

Nbor 5.0.0.5 pw-id 1
  Number of MAC: 0

Bridge-domain name: aa:g2, id: 1, state: up
  MAC learning: enabled
  Flooding:
    Broadcast & Multicast: enabled
    Unknown unicast: enabled
  MAC aging time: 300 s, Type: inactivity
  MAC limit: 4000, Action: none, Notification: syslog
  MAC limit reached: no
  Security: disabled
  DHCPv4 snooping: profile not known on this node
  Bridge MTU: 1500 bytes
  Number of bridge ports: 2
  Number of MAC addresses: 0
  Multi-spanning tree instance: 0

BRIDGE [version, state]: [1, CREATED]
  Bridge ID: 1
    FGID1: 44034  NodeCount: 1  Info_len: 16  XID_count: 2
    FGID2: 44035  NodeCount: 1  Info_len: 12  XID_count: 1

  FGID1 Membership list:
    node-id: 0/2/CPU0 (0x21)  RSI: 0x25  XID_count: 2
    XID: 0x1280004  0xffff80002

  FGID2 Membership list:
    node-id: 0/2/CPU0 (0x21)  RSI: 0x25  XID_count: 1
    XID: 0x1280004

GigabitEthernet0/2/0/1.4, state: oper up
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

AC [version, state]: [1, BOUND]
  XID: 0x1280004  RSI: 0x25  Bridging: TRUE

Nbor 5.0.0.5 pw-id 2
  Number of MAC: 0

```

**show l2vpn forwarding bridge-domain (VPLS)**

The following sample output shows the hardware information of the line card, for a specific bridge-domain on the egress detail location:

```
RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain hardware egress detail location 0/2/CPU0
```

```
Bridge-domain name: aa:gl, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 4
Number of MAC addresses: 0
Multi-spanning tree instance: 0

EGRESS BRIDGE [version, state]: [1, CREATED]

  BID: 0   Total_oif_count: 4
  AC:  oif_count: 3   head_ptr: 0x9ff6e4f8   tail_ptr: 0x9ff6e480
  PW:  oif_count: 1   head_ptr: 0x9ff6e570

  PLU RESULT Key[Bridge-ID: 0]
  HW: 0x04008000 0x000a01c0 0x00000000 0x00000000
  SW: 0x04008000 0x000a01c0 0x00000000 0x00000000
  Entry_type: 1
  OLIST pointer: 0xa01
  OLIST channel: 3
  OLIST count: 4

  OIF[0] seg_type: AC xid: 0x1280003 Gi0/2/0/1.3 (ifh: 0x1280042)
  TLU RESULT tlu_addr: 0x3000a01 ch: 3 seg_type: 1
  HW: 0x80000002 0x00ba0080 0x01280003 0x00000000
  SW: 0x80000002 0x00ba0080 0x01280003 0x00000000
  SHG: 0
  UIDB: 2
  XID: 0x1280003
  OLIST pointer: 0xba00
  OLIST channel: 2

  OIF[1] seg_type: AC xid: 0x1280002 Gi0/2/0/1.2 (ifh: 0x1280022)
  TLU RESULT tlu_addr: 0x200ba00 ch: 2 seg_type: 1
  HW: 0x80000002 0x000a00c0 0x01280002 0x00000000
  SW: 0x80000002 0x000a00c0 0x01280002 0x00000000
  SHG: 0
  UIDB: 2
  XID: 0x1280002
  OLIST pointer: 0xa00
  OLIST channel: 3

  OIF[2] seg_type: AC xid: 0x1280001 Gi0/2/0/1.1 (ifh: 0x1280002)
  TLU RESULT tlu_addr: 0x3000a00 ch: 3 seg_type: 1
  HW: 0x80000002 0x00ba0180 0x01280001 0x00000000
  SW: 0x80000002 0x00ba0180 0x01280001 0x00000000
  SHG: 0
  UIDB: 2
  XID: 0x1280001
  OLIST pointer: 0xba01
```

```

OLIST channel: 2

OIF[3] seg_type: PW xid: 0xffff80001 ecd_ptr: 0x5206
TLU RESULT tlu_addr: 0x200ba01 ch: 2 seg_type: 0
HW: 0x01005206 0x00000000 0xffff80001 0x03e86000
SW: 0x01005206 0x00000000 0xffff80001 0x03e86000
SHG: 1
XID: 0xffff80001
OLIST pointer: 0x0
OLIST channel: 0
Control Word: Disabled
VC label: 16006
ECD/TLU1 pointer: 0x5206

GigabitEthernet0/2/0/1.1, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 1 (0x1280001)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c00
  RX TLU2   : 0x1013c00
  RX TLU3   : 0x200ba00
  RX TLU4   : 0x3000c00

EGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [1] TLU2-entry-addr: [0x200a001]
  HW: 0x8018b000 0x0000000b 0x00004001 0xfb7ba000
  SW: 0x8018b000 0x0000000b 0x00004001 0xfb7ba000

  Entry status: 1 (Fwd)
  AC_type: 1 (vlan-mode)
  Outer-vlan: 1
  Inner-vlan: 0
  Outer Ether Type: 0 (dot1q)
  AC_mtu: 1580
  Adjacency_type: 0
  Default EgressQ (SharqQ): 11
  PW mode: 0 (vc-type 5)
  Rewrite supported: 0 (No)
  Control-word supported: 0 (No)
  Egress AC stats: 0x7dbdd

GigabitEthernet0/2/0/1.2, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 2 (0x1280002)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1   : 0x4c01
  RX TLU2   : 0x1013c01
  RX TLU3   : 0x200ba01
  RX TLU4   : 0x3000c01

```

**show l2vpn forwarding bridge-domain (VPLS)**

```

EGRESS AC [version, state]: [1, BOUND]

Xconnect-ID: [2] TLU2-entry-addr: [0x200a002]
HW: 0x8018b000 0x0000000b 0x00004002 0xfb7b4000
SW: 0x8018b000 0x0000000b 0x00004002 0xfb7b4000

Entry status: 1 (Fwd)
AC_type: 1 (vlan-mode)
Outer-vlan: 2
Inner-vlan: 0
Outer Ether Type: 0 (dot1q)
AC_mtu: 1580
Adjacency_type: 0
Default EgressQ (SharqQ): 11
PW mode: 0 (vc-type 5)
Rewrite supported: 0 (No)
Control-word supported: 0 (No)
Egress AC stats: 0x7dbda

```

```

GigabitEthernet0/2/0/1.3, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

```

```

EGRESS BRIDGE PORT [version, state]: [1, BOUND]

Bridge Port Type: AC
XID: 0/2/CPU0 : 3 (0x1280003)
Bridge ID: 0, Split Horizon ID: 0
RX TLU1   : 0x4c02
RX TLU2   : 0x1013c02
RX TLU3   : 0x200ba02
RX TLU4   : 0x3000c02

```

```

EGRESS AC [version, state]: [1, BOUND]

Xconnect-ID: [3] TLU2-entry-addr: [0x200a003]
HW: 0x8018b000 0x0000000b 0x00004003 0xfb7ae000
SW: 0x8018b000 0x0000000b 0x00004003 0xfb7ae000

Entry status: 1 (Fwd)
AC_type: 1 (vlan-mode)
Outer-vlan: 3
Inner-vlan: 0
Outer Ether Type: 0 (dot1q)
AC_mtu: 1580
Adjacency_type: 0
Default EgressQ (SharqQ): 11
PW mode: 0 (vc-type 5)
Rewrite supported: 0 (No)
Control-word supported: 0 (No)
Egress AC stats: 0x7dbd7

```

```

Nbor 5.0.0.5 pw-id 1
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

```

```

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
Bridge Port Type: ATOM

```



```

XID: 127/15/CPU0 : 1 (0xffff80001)
Bridge ID: 0, Split Horizon ID: 1
VC label: 16006
Control-word supported: No

```

```

Bridge-domain name: aa:g2, id: 1, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 2
Number of MAC addresses: 0
Multi-spanning tree instance: 0

```

```
EGRESS BRIDGE [version, state]: [1, CREATED]
```

```

  BID: 1   Total_oif_count: 2
  AC:  oif_count: 1   head_ptr: 0x9ff6e534   tail_ptr: 0x9ff6e534
  PW:  oif_count: 1   head_ptr: 0x9ff6e5ac

```

```

  PLU RESULT Key[Bridge-ID: 1]
  HW: 0x04004000 0x000a02c0 0x00000000 0x00000000
  SW: 0x04004000 0x000a02c0 0x00000000 0x00000000
  Entry_type: 1
  OLIST pointer: 0xa02
  OLIST channel: 3
  OLIST count: 2

```

```

  OIF[0] seg_type: AC xid: 0x1280004 Gi0/2/0/1.4 (ifh: 0x1280062)
  TLU RESULT tlu_addr: 0x3000a02 ch: 3 seg_type: 1
  HW: 0x80000002 0x00ba0280 0x01280004 0x00000000
  SW: 0x80000002 0x00ba0280 0x01280004 0x00000000
  SHG: 0
  UIDB: 2
  XID: 0x1280004
  OLIST pointer: 0xba02
  OLIST channel: 2

```

```

  OIF[1] seg_type: PW xid: 0xffff80002 ecd_ptr: 0x5200
  TLU RESULT tlu_addr: 0x200ba02 ch: 2 seg_type: 0
  HW: 0x01005200 0x00000000 0xffff80002 0x03e88000
  SW: 0x01005200 0x00000000 0xffff80002 0x03e88000
  SHG: 1
  XID: 0xffff80002
  OLIST pointer: 0x0
  OLIST channel: 0
  Control Word: Disabled
  VC label: 16008
  ECD/TLU1 pointer: 0x5200

```

```

GigabitEthernet0/2/0/1.4, state: oper up
Number of MAC: 0
Statistics:
  packets: received 0, sent 0
  bytes: received 0, sent 0

```

**show l2vpn forwarding bridge-domain (VPLS)**

```

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 4 (0x1280004)
  Bridge ID: 1, Split Horizon ID: 0
  RX TLU1      : 0x4c03
  RX TLU2      : 0x1013c03
  RX TLU3      : 0x200ba03
  RX TLU4      : 0x3000c03

EGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [4] TLU2-entry-addr: [0x200a004]
  HW: 0x8018b000 0x0000000b 0x00004004 0xfb7a8000
  SW: 0x8018b000 0x0000000b 0x00004004 0xfb7a8000

  Entry status: 1 (Fwd)
  AC_type: 1 (vlan-mode)
  Outer-vlan: 4
  Inner-vlan: 0
  Outer Ether Type: 0 (dot1q)
  AC_mtu: 1580
  Adjacency_type: 0
  Default EgressQ (SharqQ): 11
  PW mode: 0 (vc-type 5)
  Rewrite supported: 0 (No)
  Control-word supported: 0 (No)
  Egress AC stats: 0x7dbd4

Nbor 5.0.0.5 pw-id 2
  Number of MAC: 0
  Statistics:
    packets: received 0, sent 0
    bytes: received 0, sent 0

EGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: ATOM
  XID: 127/15/CPU0 : 2 (0xfff80002)
  Bridge ID: 1, Split Horizon ID: 1
  VC label: 16008
  Control-word supported: No

```

This table describes the significant fields shown in the display.

**Table 13: show l2vpn forwarding bridge-domain Command Field Descriptions**

| Field              | Description  |
|--------------------|--|
| Bridge-Domain Name | Name of bridge domain is displayed.  |
| Bridge ID          | ID assigned to this bridge domain is displayed.                                    |
| Ports              | Number of ports that are part of this bridge domain is displayed.                  |
| MAC Addr           | Number of MAC addresses that are learned on this bridge domain is displayed.       |
| Flooding           | Flooding of packets are displayed if they are enabled on this bridge domain.       |
| Learning           | Learning of MAC addresses are displayed if they are enabled on this bridge domain. |
| State              | Current state of the bridge domain is displayed.                                   |

**Related Commands**

| Command   | Description   |
|---|---|
| <a href="#">clear l2vpn bridge-domain (VPLS), on page 144</a> | Clears the MAC addresses and restarts the bridge domains on the router. |

# show l2vpn forwarding bridge-domain mac-address (VPLS)

To display the summary information for the MAC address, use the **show l2vpn forwarding bridge-domain mac-address** command in EXEC mode.

**show l2vpn forwarding bridge-domain** [*bridge-domain-name*] **mac-address** {*MAC-address* | **detail** | **hardware** {*egress* | *ingress*} | **interface** *type interface-path-id* | **neighbor** *address pw-id pw-id* | **location** *node-id*}

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <i>bridge-domain-name</i> (Optional) Name of a bridge domain. |   |
|                           | <i>MAC-address</i>  | MAC address.  |
|                           | <b>detail</b>   | Displays detailed information for the MAC address.  |
|                           | <b>hardware</b>   | Reads information from the hardware.  |
|                           | <b>egress</b>   | Reads information from the egress PSE.  |
|                           | <b>ingress</b>  | Reads information from the ingress PSE.   |
|                           | <b>interface</b>  | Displays the match for the attachment circuit subinterface.   |
|                           | <i>type</i>   | Interface type. For more information, use the question mark (?) online help function.   |
|                           | <i>interface-path-id</i>                                      | Physical interface or virtual interface.  |
|                           | <b>Note</b>   | Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  |
|                           |   | For more information about the syntax for the router, use the question mark (?) online help function.   |
|                           | <b>neighbor</b> <i>address</i>                                | Displays the match for the neighbor IP address.   |
|                           | <b>pw-id</b> <i>pw-id</i>                                     | Displays the match for the pseudowire ID.   |
|                           | <b>location</b> <i>node-id</i>                                | Displays the bridge-domain information for the MAC address of the specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation. |
| <b>Command Default</b>    | None  |   |
| <b>Command Modes</b>      | EXEC  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>   |
|                           | Release 3.7.0   | This command was introduced.  |
|                           | Release 3.7.2   | This command was introduced.  |
|                           | Release 3.8.0   | This command was introduced.  |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

**Task ID****Task Operations**

| Task ID | Operations |
|---------|------------|
| l2vpn   | read       |

**Examples**

The following sample output shows the specified location of the bridge-domain name g1:bd1 for the MAC address:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 location 0/1/CPU0
```

| Bridge-Domain Name | Bridge ID | Ports | MAC addr | Flooding | Learning | State |
|--------------------|-----------|-------|----------|----------|----------|-------|
| g1:bd1             | 0         | 2     | 65536    | Enabled  | Enabled  | UP    |

The following sample output shows the list of MAC addresses that are learned on a specified bridge and summary information for the addresses:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain mac-address location 0/1/CPU0
```

| Mac Address    | Type    | Learned from/Filtered on | LC learned | Age          |
|----------------|---------|--------------------------|------------|--------------|
| 0000.0000.0000 | static  | Gi0/1/0/0                | N/A        | N/A          |
| 0000.0001.0101 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0102 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0103 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0104 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0105 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0106 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0107 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0108 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0109 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.010a | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.010b | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.010c | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.010d | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.010e | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.010f | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0110 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0111 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| 0000.0001.0112 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 22s |
| ....           |         |                          |            |              |

The following sample output shows the MAC address on a specified interface on a specified bridge:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address 1.2.3 location 0/1/CPU0
```

| Mac Address    | Type   | Learned from/Filtered on | LC learned | Age |
|----------------|--------|--------------------------|------------|-----|
| 0001.0002.0003 | static | Gi0/1/0/0                | N/A        | N/A |

The following sample output shows the hardware information from the egress pse:

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address hardware egress
```

**show l2vpn forwarding bridge-domain mac-address (VPLS)**

**location 0/1/CPU0**

| Mac Address    | Type    | Learned from/Filtered on | LC learned | Age          |
|----------------|---------|--------------------------|------------|--------------|
| 0000.0000.0000 | static  | Gi0/1/0/0                | N/A        | N/A          |
| 0000.0001.0101 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0102 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0103 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0104 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0105 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0106 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0107 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0108 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0109 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.010a | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.010b | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.010c | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.010d | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.010e | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.010f | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0110 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0111 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0112 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0113 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| 0000.0001.0114 | dynamic | Gi0/1/0/0                | 0/1/CPU0   | 0d 0h 2m 24s |
| ...            |         |                          |            |              |

The following sample output shows the MAC addresses that are learned on a specified pseudowire on a specified bridge:

RP/0/RP0/CPU0:router# **show l2vpn forwarding bridge-domain mac-address neighbor 10.0.0.1 pw-id 1 location 0/1/CPU0**

| Mac Address    | Type    | Learned from/Filtered on | LC learned | Age          |
|----------------|---------|--------------------------|------------|--------------|
| 0000.0003.0101 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0102 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0103 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0104 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0105 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0106 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0107 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0108 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0109 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.010a | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.010b | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.010c | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.010d | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.010e | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.010f | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0110 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0111 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0112 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0113 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0114 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| 0000.0003.0115 | dynamic | 10.0.0.1, 1              | 0/1/CPU0   | 0d 0h 0m 30s |
| ...            |         |                          |            |              |

The following sample output shows the detailed information for MAC addresses that are learned on a specified interface and on specified bridge of a specified interface card. The sample output lists all the MAC addresses, the learned location, and the current age.

```
RP/0/RP0/CPU0:router# show l2vpn forwarding bridge-domain g1:bd1 mac-address interface
gigabitEthernet 0/1/0/0 location 0/1/CPU0
```

| Mac Address    | Type    | Learned from/Filtered on | LC learned Age        |
|----------------|---------|--------------------------|-----------------------|
| 0000.0000.0000 | static  | Gi0/1/0/0                | N/A                   |
| 0000.0001.0101 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0102 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0103 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0104 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0105 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0106 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0107 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0108 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0109 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.010a | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.010b | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.010c | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.010d | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.010e | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.010f | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0110 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0111 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0112 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0113 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |
| 0000.0001.0114 | dynamic | Gi0/1/0/0                | 0/1/CPU0 0d 0h 2m 14s |

The following sample output shows the MAC address hardware information on the line card, for a specific bridge-domain on the ingress detail location:

```
RP/0/RP0/CPU0:router#show l2vpn forwarding bridge-domain mac hardware ingress detail location
0/2/CPU0
```

```
Bridge-domain name: aa:g1, id: 0, state: up
MAC learning: enabled
Flooding:
  Broadcast & Multicast: enabled
  Unknown unicast: enabled
MAC aging time: 300 s, Type: inactivity
MAC limit: 4000, Action: none, Notification: syslog
MAC limit reached: no
Security: disabled
DHCPv4 snooping: profile not known on this node
Bridge MTU: 1500 bytes
Number of bridge ports: 4
Number of MAC addresses: 10
Multi-spanning tree instance: 0

INGRESS BRIDGE [version, state]: [1, CREATED]

TCAM entry seq#: 1024 Key: [BID: 0 MAC: default]
HW: 0x4c000000 0x000080ac 0x00010000 0x80ac0100
SW: 0x4c000000 0x000080ac 0x00010000 0x80ac0100

SMAC: action: PUNT state: NO REFRESH
DMAC: action: FLOOD, flood_enable: enable
FGID: All: 44032, VFI: 44033, MCAST_Sponge_q: 16
Fabric_multicast1: 1 Fabric_multicast2: 1

Admin State: UP
MTU: 1500
```

**show l2vpn forwarding bridge-domain mac-address (VPLS)**

```

Number of MAC addresses: 11 (10 MAC + 1 default)
ACL NAME (ACL-ID): VPLS Special (4096)
TCAM region handle : 5

GigabitEthernet0/2/0/1.1, state: oper up
Number of MAC: 10
Statistics:
  packets: received 0, sent 121515
  bytes: received 0, sent 7290900

INGRESS BRIDGE PORT [version, state]: [1, BOUND]
  Bridge Port Type: AC
  XID: 0/2/CPU0 : 1 (0x1280001)
  Bridge ID: 0, Split Horizon ID: 0
  RX TLU1      : 0x4c00
  RX TLU2      : 0x1013c00
  RX TLU3      : 0x200ba00
  RX TLU4      : 0x3000c00

INGRESS AC [version, state]: [1, BOUND]

  Xconnect-ID: [1] TCAM-Key: (UIDB:0x2 O-vlan:1 I-vlan:0 Ether-Type:0x8100)
  HW: 0x24001000 0x01280001 0x10128000 0xc7ff7d00
  SW: 0x24001000 0x01280001 0x10128000 0xc7ff7d00

  Service type: 4 (bridging pmp)
  Entry type: 1 (fwd)
  Bridge_ID : 0
  ACL_ID : 4096
  Xconnect_ID : 0x1280001
  SplitHorizonGroup_ID : 0
  Rewrite supported: 0 (No)
  PW_mode: 0 (vc-type 5)
  AC-type: 1 (vlan-mode)
  Interface handle: 0x128000
  Ingress AC stats: 0x7ff7d

  SMAC Learning: enable
  DMAC Flooding: enable

Mac Address: 0000.0022.2222, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

  TCAM entry seq#: 0 Key: [BID: 0 MAC: 0000.0022.2222]
  HW: 0x22004c00 0x00000001 0x00000000 0x01280001
  SW: 0x22004c00 0x00000001 0x00000000 0x01280001

  SMAC: action: FWD state: REFRESH
  XID: 0/2/CPU0 : 1 (0x1280001)
  DMAC: action: FWD, BridgePort type: AC
  SHG ID      : 0
  Entry Flag : FWD
  Entry Type : DYNAMIC
  Local Switching: enabled
  Next (tlu0) addr: 0x4c00
  Control-word supported: No

  Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

  TLU1          : 0x4c00

```



```

[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:      0
  entry type:      FWD    next ptr:          0x00013c00
  num of entries:   1
  BGP next-hop:    0.0.0.0

TLU2              : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
  label1:          1      label2:            0
  num of labels:    1      next ptr: 0x0000ba00

TLU3              : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries      : 1
  num. labels       : 0
  label 1           : 0
  label 2           : 0
  next ptr          : 0xc00

TLU4              : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr        : 0x20
  sponge queue      : 130
  egress port       : 0x128004
  rp destined       : no
  rp drop           : no
  hash type         : 0
  uidb index        : 0x2

Mac Address: 0000.0022.2223, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

TCAM entry seq#: 1 Key: [BID: 0 MAC: 0000.0022.2223]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag  : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1              : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:      0
  entry type:      FWD    next ptr:          0x00013c00
  num of entries:   1
  BGP next-hop:    0.0.0.0

TLU2              : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
  label1:          1      label2:            0
  num of labels:    1      next ptr: 0x0000ba00

TLU3              : 0x200ba00

```

# show l2vpn forwarding bridge-domain mac-address (VPLS)

```

[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries : 1
  num. labels  : 0
  label 1     : 0
  label 2     : 0
  next ptr    : 0xc00

TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr   : 0x20
  sponge queue : 130
  egress port  : 0x128004
  rp destined  : no
  rp drop      : no
  hash type    : 0
  uidb index   : 0x2

Mac Address: 0000.0022.2224, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

TCAM entry seq#: 2 Key: [BID: 0 MAC: 0000.0022.2224]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag  : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:          0
  entry type:     FWD    next ptr:      0x00013c00
  num of entries: 1
  BGP next-hop:   0.0.0.0

TLU2          : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
  label1:         1      label2:          0
  num of labels:   1      next ptr: 0x0000ba00

TLU3          : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries : 1
  num. labels  : 0
  label 1     : 0
  label 2     : 0
  next ptr    : 0xc00

TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr   : 0x20
  sponge queue : 130
  egress port  : 0x128004

```

```
rp destined    : no
rp drop        : no
hash type      : 0
uidb index     : 0x2
```

```
Mac Address: 0000.0022.2225, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local
```

```
INGRESS MAC [version, state]: [1, CREATED]
```

```
TCAM entry seq#: 3 Key: [BID: 0 MAC: 0000.0022.2225]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001
```

```
SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag  : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No
```

```
Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)
```

```
TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
label:         0      num of labels:      0
entry type:    FWD    next ptr:      0x00013c00
num of entries: 1
BGP next-hop:  0.0.0.0
```

```
TLU2          : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
label1:        1      label2:      0
num of labels: 1      next ptr: 0x0000ba00
```

```
TLU3          : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
num. entries   : 1
num. labels    : 0
label 1        : 0
label 2        : 0
next ptr       : 0xc00
```

```
TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
dest. addr     : 0x20
sponge queue   : 130
egress port    : 0x128004
rp destined    : no
rp drop        : no
hash type      : 0
uidb index     : 0x2
```

```
Mac Address: 0000.0022.2226, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local
```

```
INGRESS MAC [version, state]: [1, CREATED]
```

```
TCAM entry seq#: 4 Key: [BID: 0 MAC: 0000.0022.2226]
```

# show l2vpn forwarding bridge-domain mac-address (VPLS)

```

HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID : 0
Entry Flag : FWD
Entry Type : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1 : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
label: 0 num of labels: 0
entry type: FWD next ptr: 0x00013c00
num of entries: 1
BGP next-hop: 0.0.0.0

TLU2 : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
label1: 1 label2: 0
num of labels: 1 next ptr: 0x0000ba00

TLU3 : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
num. entries : 1
num. labels : 0
label 1 : 0
label 2 : 0
next ptr : 0xc00

TLU4 : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
dest. addr : 0x20
sponge queue : 130
egress port : 0x128004
rp destined : no
rp drop : no
hash type : 0
uidb index : 0x2

Mac Address: 0000.0022.2227, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

INGRESS MAC [version, state]: [1, CREATED]

TCAM entry seq#: 5 Key: [BID: 0 MAC: 0000.0022.2227]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID : 0
Entry Flag : FWD
Entry Type : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

```

```

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:      0
  entry type:     FWD    next ptr:      0x00013c00
  num of entries:  1
  BGP next-hop:   0.0.0.0

TLU2          : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]
  label1:         1      label2:         0
  num of labels:   1      next ptr: 0x0000ba00

TLU3          : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries   : 1
  num. labels    : 0
  label 1       : 0
  label 2       : 0
  next ptr      : 0xc00

TLU4          : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr     : 0x20
  sponge queue   : 130
  egress port    : 0x128004
  rp destined    : no
  rp drop        : no
  hash type      : 0
  uidb index     : 0x2

Mac Address: 0000.0022.2228, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

```

```
INGRESS MAC [version, state]: [1, CREATED]
```

```

TCAM entry seq#: 6 Key: [BID: 0 MAC: 0000.0022.2228]
HW: 0x22004c00 0x00000001 0x00000000 0x01280001
SW: 0x22004c00 0x00000001 0x00000000 0x01280001

SMAC: action: FWD state: REFRESH
XID: 0/2/CPU0 : 1 (0x1280001)
DMAC: action: FWD, BridgePort type: AC
SHG ID      : 0
Entry Flag  : FWD
Entry Type  : DYNAMIC
Local Switching: enabled
Next (tlu0) addr: 0x4c00
Control-word supported: No

```

```

Destination AC: Gi0/2/0/1.1 (ifh: 0x1280002)

TLU1          : 0x4c00
[HW: 0x00000000 0x00013c00 0x00000000 0x00000100]
  label:          0      num of labels:      0
  entry type:     FWD    next ptr:      0x00013c00
  num of entries:  1
  BGP next-hop:   0.0.0.0

TLU2          : 0x1013c00
[HW: 0x00000008 0x00000000 0x00001000 0x00ba0000]

```

**show l2vpn forwarding bridge-domain mac-address (VPLS)**

```

label1:          1      label2:          0
num of labels:   1      next ptr: 0x0000ba00

TLU3             : 0x200ba00
[HW: 0x00010000 0x00000000 0x00000000 0x000c0000]
  num. entries   : 1
  num. labels    : 0
  label 1        : 0
  label 2        : 0
  next ptr       : 0xc00

TLU4             : 0x3000c00
[HW: 0x00000000 0x20082000 0x01280040 0x00020000]
  dest. addr     : 0x20
  sponge queue   : 130
  egress port    : 0x128004
  rp destined    : no
  rp drop        : no
  hash type      : 0
  uidb index     : 0x2

Mac Address: 0000.0022.2229, LC learned: 0/2/CPU0
Age: 0d 0h 0m 21s, Flag: local

```

**Related Commands**

| Command   | Description  |
|---|--|
| <a href="#">show l2vpn forwarding bridge-domain (VPLS), on page 178</a> | Displays information on the bridge that is used by the forwarding layer. |

# shutdown (Bridge Domain)

To shut down a bridge domain to bring the bridge and all attachment circuits and pseudowires under it to admin down state, use the **shutdown** command in L2VPN bridge group bridge domain configuration mode. To re-enable the bridge domain, use the **no** form of this command.

**shutdown**  
**no shutdown**

| <b>Syntax Description</b> | This command has no keywords or arguments.  |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | By default, the bridge is not shutdown.   |         |              |               |                              |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain configuration  |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 3.8.0 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 3.8.0             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>When a bridge domain is disabled, all VFI's associated with the bridge domain are disabled. You can still attach or detach members to or from the bridge domain as well as the VFI's associated with the bridge domain.</p> |         |              |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>   | Task ID | Operations   | l2vpn         | read,<br>write               |
| Task ID                   | Operations  |         |              |               |                              |
| l2vpn                     | read,<br>write  |         |              |               |                              |
| <b>Examples</b>           | <p>The following example shows how to disable the bridge domain named bar:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# shutdown</pre>  |         |              |               |                              |

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                  | <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                  | <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |

## shutdown (VFI)

To disable virtual forwarding interface (VFI), use the **shutdown** command in L2VPN bridge group bridge domain VFI configuration mode. To re-enable VFI, use the **no** form of this command.

**shutdown**  
**no shutdown**

|                           |  |
|---------------------------|--|
| <b>Syntax Description</b> | This command has no keywords or arguments. |
|---------------------------|--|

|                        |                                      |
|------------------------|--------------------------------------|
| <b>Command Default</b> | By default, the VFI is not shutdown. |
|------------------------|--------------------------------------|

|                      |  |
|----------------------|--|
| <b>Command Modes</b> | L2VPN bridge group bridge domain VFI configuration |
|----------------------|--|

| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|------------------------|----------------|------------------------------|
|                        | Release 3.8.0  | This command was introduced. |

|                         |   |
|-------------------------|---|
| <b>Usage Guidelines</b> | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |
|-------------------------|---|

| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|----------------|----------------|-------------------|
|                | l2vpn          | read,<br>write    |

**Examples**

The following example shows how to disable VFI:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# shutdown
```

| <b>Related Commands</b> | <b>Command</b>  | <b>Description</b>   |
|-------------------------|---|--|
|                         | <a href="#">bridge-domain (VPLS), on page 142</a>     | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                         | <a href="#">bridge group (VPLS), on page 143</a>      | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                         | <a href="#">l2vpn, on page 44</a>                     | Enters L2VPN configuration mode.   |
|                         | <a href="#">mpls static label (VPLS), on page 157</a> | Configures the MPLS static labels and the static labels for the access pseudowire configuration.                         |



| Command                                      | Description   |
|--|---|
| <a href="#">neighbor (VPLS), on page 161</a> | Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI). |

## static-address (VPLS)

To add static entries to the MAC address for filtering, use the **static-address** command in L2VPN bridge group bridge domain MAC configuration mode. To remove entries profiled by the combination of a specified entry information, use the **no** form of this command.

**static-address** *MAC-address* **drop**  
**no static-address** *MAC-address* **drop**

| <b>Syntax Description</b>                         | <table> <tr> <td><i>MAC-address</i></td><td>Static MAC address that is used to filter on the bridge domain.</td></tr> <tr> <td><b>drop</b></td><td>Drops all traffic that is going to the configured MAC address.</td></tr> </table>  | <i>MAC-address</i> | Static MAC address that is used to filter on the bridge domain. | <b>drop</b>                                       | Drops all traffic that is going to the configured MAC address.                               |
|---|---|--------------------|---|---|--|
| <i>MAC-address</i>                                | Static MAC address that is used to filter on the bridge domain.   |                    |   |   |  |
| <b>drop</b>                                       | Drops all traffic that is going to the configured MAC address.  |                    |   |   |  |
| <b>Command Default</b>                            | No static MAC address is configured.  |                    |   |   |  |
| <b>Command Modes</b>                              | L2VPN bridge group bridge domain MAC configuration  |                    |   |   |  |
| <b>Command History</b>                            | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> </table>  | Release            | Modification  | Release 3.8.0                                     | This command was introduced.   |
| Release   | Modification  |                    |   |   |  |
| Release 3.8.0                                     | This command was introduced.  |                    |   |   |  |
| <b>Usage Guidelines</b>                           | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.   |                    |   |   |  |
| <b>Task ID</b>                                    | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>   | Task ID            | Operations  | l2vpn   | read,<br>write   |
| Task ID   | Operations  |                    |   |   |  |
| l2vpn   | read,<br>write  |                    |   |   |  |
| <b>Examples</b>                                   | <p>The following example shows how to add static MAC entries in L2VPN bridge group bridge domain MAC configuration mode. This entry causes all packets with destination MAC address 1.1.1 to be dropped.</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# static-address 1.1.1 drop</pre> |                    |   |   |  |
| <b>Related Commands</b>                           | <table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><a href="#">bridge-domain (VPLS), on page 142</a></td><td>Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.</td></tr> </table>   | Command            | Description   | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode. |
| Command   | Description   |                    |   |   |  |
| <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.  |                    |   |   |  |

| Command  | Description  |
|--|--|
| <a href="#">bridge group (VPLS), on page 143</a> | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                | Enters L2VPN configuration mode.   |
| <a href="#">mac (VPLS), on page 153</a>          | Enters L2VPN bridge group bridge domain MAC configuration mode.  |

## static-mac-address (VPLS)

To configure the static MAC address to associate a remote MAC address with a pseudowire or any other bridge interface, use the **static-mac-address** command in the appropriate L2VPN bridge group bridge domain configuration submode. To disable this feature, use the **no** form of this command.

**static-mac-address** *MAC-address*  
**no static-mac-address** *MAC-address*

| <b>Syntax Description</b> | <i>MAC-address</i> Static address to add to the MAC address.  |         |              |               |                              |
|---------------------------|---|---------|--------------|---------------|------------------------------|
| <b>Command Default</b>    | None  |         |              |               |                              |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain VFI pseudowire configuration<br>L2VPN bridge group bridge domain attachment circuit configuration  |         |              |               |                              |
| <b>Command History</b>    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.8.0</td><td>This command was introduced.</td></tr> </table>  | Release | Modification | Release 3.8.0 | This command was introduced. |
| Release                   | Modification  |         |              |               |                              |
| Release 3.8.0             | This command was introduced.  |         |              |               |                              |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |         |              |               |                              |
| <b>Task ID</b>            | <table> <tr> <th>Task ID</th><th>Operations</th></tr> <tr> <td>l2vpn</td><td>read,<br/>write</td></tr> </table>   | Task ID | Operations   | l2vpn         | read,<br>write               |
| Task ID                   | Operations  |         |              |               |                              |
| l2vpn                     | read,<br>write  |         |              |               |                              |

### Examples

The following example shows how to associate a remote MAC address with a pseudowire:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi model
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)# neighbor 10.1.1.2 pw-id 1000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi-pw)# static-mac-address 1.1.1
```

The following example shows how to associate a GigabitEthernet interface from a bridge domain to static MAC address 1.1.1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
```

```
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd) # interface GigabitEthernet 0/1/0/0
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-ac) # static-mac-address 1.1.1
```

The following example shows how to associate an access pseudowire to static MAC address 2.2.2:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config) # l2vpn
RP/0/RP0/CPU0:router(config-l2vpn) # bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg) # bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd) # neighbor 10.1.1.2 pw-id 2000
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-pw) # static-mac-address 2.2.2
```

#### Related Commands

| Command   | Description  |
|---|--|
| <a href="#">bridge-domain (VPLS), on page 142</a>     | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
| <a href="#">bridge group (VPLS), on page 143</a>      | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                     | Enters L2VPN configuration mode.   |
| <a href="#">mpls static label (VPLS), on page 157</a> | Configures the MPLS static labels and the static labels for the access pseudowire configuration.                         |
| <a href="#">neighbor (VPLS), on page 161</a>          | Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).        |
| <a href="#">vfi (VPLS), on page 216</a>               | Configures virtual forwarding interface (VFI) parameters.  |

## time (VPLS)

To configure the maximum aging time, use the **time** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

**time** *seconds*

**no time** *seconds*

|                           |   |   |
|---------------------------|---|---|
| <b>Syntax Description</b> | <i>seconds</i> MAC address table entry maximum age. The range is from 300 to 30000 seconds. Aging time is counted from the last time that the switch saw the MAC address. The default value is 300 seconds.   |   |
| <b>Command Default</b>    | <i>seconds</i> : 300  |   |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain MAC aging configuration  |   |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>   |
|                           | Release 3.8.0   | This command was introduced.  |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>If no packets are received from the MAC address for the duration of the maximum aging time, the dynamic MAC entry previously learned is removed from the forwarding table.</p>  |   |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>   |
|                           | l2vpn   | read,<br>write  |
| <b>Examples</b>           | <p>The following example shows how to increase the maximum aging time to 600 seconds. After 600 seconds of inactivity from a MAC address, the MAC address is removed from the forwarding table.</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# aging RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# time 600</pre> |   |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>  |
|                           | <a href="#">aging (VPLS), on page 140</a>   | Enters the MAC aging configuration submode to set the aging parameters such as time and type. |

| Command   | Description  |
|---|--|
| <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
| <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |
| <a href="#">mac (VPLS), on page 153</a>           | Enters L2VPN bridge group bridge domain MAC configuration mode.  |
| <a href="#">type (VPLS), on page 214</a>          | Configures the type for MAC address aging.   |

## type (VPLS)

To configure the type for MAC address aging, use the **type** command in L2VPN bridge group bridge domain MAC aging configuration mode. To disable this feature, use the **no** form of this command.

**type** {absolute | inactivity}  
**no type** {absolute | inactivity}

### Syntax Description

**absolute** Configures the absolute aging type.

**inactivity** Configures the inactivity aging type.

### Command Default

By default, the inactivity type is configured.

### Command Modes

L2VPN bridge group bridge domain MAC aging configuration

### Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.8.0 | This command was introduced. |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In general, the type is set to inactivity. With an inactivity type configuration, a MAC address is removed from the forwarding table after the MAC address is inactive for the configured aging time.

With an absolute type configuration, a MAC address is always removed from the forwarding table after the aging time has elapsed once it is initially learned.

### Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

### Examples

The following example shows how to configure the MAC address aging type to absolute for every member of the bridge domain named bar:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
```



```
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# aging  
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac-aging)# type absolute
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">aging (VPLS), on page 140</a>         | Enters the MAC aging configuration submode to set the aging parameters such as time and type.                            |
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                  | <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                  | <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |
|                  | <a href="#">mac (VPLS), on page 153</a>           | Enters L2VPN bridge group bridge domain MAC configuration mode.  |
|                  | <a href="#">time (VPLS), on page 212</a>          | Configures the maximum aging time.   |

## vfi (VPLS)

To configure virtual forwarding interface (VFI) parameters and to enter L2VPN bridge group bridge domain VFI configuration mode, use the **vfi** command in L2VPN bridge group bridge domain configuration mode. To remove all configurations that are made under the specified VFI, use the **no** form of this command.

**vfi** *vfi-name*  
**no vfi** *vfi-name*

|                           |  |  |
|---------------------------|--|--|
| <b>Syntax Description</b> | <i>vfi-name</i> Name of the specified virtual forwarding interface.  |  |
| <b>Command Default</b>    | None   |  |
| <b>Command Modes</b>      | L2VPN bridge group bridge domain configuration   |  |
| <b>Command History</b>    | <b>Release</b>   | <b>Modification</b>  |
|                           | Release 3.8.0  | This command was introduced.   |
| <b>Usage Guidelines</b>   | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>Use the <b>vfi</b> command to enter L2VPN bridge group bridge domain VFI configuration mode.</p> <p>You cannot configure a pseudowire directly under a bridge domain. Therefore, a pseudowire must be configured under a VFI, which is configured under a bridge domain.</p> |  |
| <b>Task ID</b>            | <b>Task ID</b>   | <b>Operations</b>  |
|                           | l2vpn  | read,<br>write   |
| <b>Examples</b>           | <p>The following example shows how to create a VFI:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# l2vpn RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1 RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# vfi v1 RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-vfi)#</pre>  |  |
| <b>Related Commands</b>   | <b>Command</b>   | <b>Description</b>   |
|                           | <a href="#">bridge-domain (VPLS), on page 142</a>  | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode. |

| Command   | Description  |
|---|--|
| <a href="#">bridge group (VPLS), on page 143</a>      | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
| <a href="#">l2vpn, on page 44</a>                     | Enters L2VPN configuration mode.   |
| <a href="#">mpls static label (VPLS), on page 157</a> | Configures the MPLS static labels and the static labels for the access pseudowire configuration.                         |
| <a href="#">neighbor (VPLS), on page 161</a>          | Adds an access pseudowire port to a bridge domain or a pseudowire to a bridge virtual forwarding interface (VFI).        |

## withdraw (VPLS)

To enable MAC address withdrawal for a specified bridge domain, use the **withdraw** command in L2VPN bridge group bridge domain MAC configuration mode. To disable this feature, use the **no** form of this command

```
withdraw { disable }
no withdraw { disable }
```

### Syntax Description

**disable** Disables MAC address withdrawal.

### Command Default

By default, MAC address withdrawal is enabled.

### Command Modes

L2VPN bridge group bridge domain MAC configuration

### Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.8.0 | This command was introduced. |

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

### Task ID

| Task ID | Operations     |
|---------|----------------|
| l2vpn   | read,<br>write |

### Examples

The following example shows how to enable disable MAC withdrawal:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd)# mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac)# withdraw disable
```

The following example shows how to disable sending MAC withdrawal messages to access pseudowires:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# l2vpn
RP/0/RP0/CPU0:router(config-l2vpn)# bridge group 1
RP/0/RP0/CPU0:router(config-l2vpn-bg)# bridge-domain bar
```

```
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd) # mac
RP/0/RP0/CPU0:router(config-l2vpn-bg-bd-mac) # withdraw access-pw disable
```

| Related Commands | Command   | Description  |
|------------------|---|--|
|                  | <a href="#">bridge-domain (VPLS), on page 142</a> | Establishes a bridge domain, and enters L2VPN bridge group bridge domain configuration mode.                             |
|                  | <a href="#">bridge group (VPLS), on page 143</a>  | Creates a bridge group so that it can contain bridge domains and then to assign network interfaces to the bridge domain. |
|                  | <a href="#">l2vpn, on page 44</a>                 | Enters L2VPN configuration mode.   |
|                  | <a href="#">mac (VPLS), on page 153</a>           | Enters L2VPN bridge group bridge domain MAC configuration mode.  |

 **withdraw (VPLS)**



## Generic Routing Encapsulation Commands

---

This module describes the commands used to configure generic routing encapsulation (GRE).

For detailed information about GRE concepts, configuration tasks, and examples, refer to the .

- [interface tunnel-ip, on page 222](#)
- [keepalive, on page 223](#)
- [tunnel destination, on page 224](#)
- [tunnel dfbit , on page 225](#)
- [tunnel mode, on page 226](#)
- [tunnel source, on page 227](#)
- [tunnel tos, on page 229](#)
- [tunnel ttl, on page 230](#)

# interface tunnel-ip

To configure a tunnel interface, use the **interface tunnel-ip** command in the interface global configuration mode. To disable this feature, use the **no** form of this command.

```
interface tunnel-ip number
no interface tunnel-ip number
```

| Syntax Description | <i>number</i> Specifies the instance number of the interface to be configured.   |         |              |               |                              |
|--------------------|--|---------|--------------|---------------|------------------------------|
| Command Default    | None   |         |              |               |                              |
| Command Modes      | interface configuration  |         |              |               |                              |
| Command History    | <table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 3.9.0</td><td>This command was introduced.</td></tr> </table> | Release | Modification | Release 3.9.0 | This command was introduced. |
| Release            | Modification   |         |              |               |                              |
| Release 3.9.0      | This command was introduced.   |         |              |               |                              |

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **interface tunnel-ip** command to enter the interface global configuration mode.

| Task ID | Task ID   | Operations     |
|---------|-----------|----------------|
|         | interface | read,<br>write |

**Examples**

This example shows how to configure a tunnel interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)#
```



# keepalive

To enable keepalive for a tunnel interface, use the **keepalive** command. To remove keepalive, use the **no** form of this command.

**keepalive** [*time\_in\_seconds* [*retry\_num*]]  
**no keepalive**

|                           |                        |  |
|---------------------------|------------------------|--|
| <b>Syntax Description</b> | <i>time_in_seconds</i> | Specifies the frequency (in seconds) at which keepalive check is performed. The default is 10 seconds. The minimum value is 1 second.                        |
|                           | <i>retry_num</i>       | Specifies the number of keepalive retries before declaring that a tunnel destination is unreachable. The default is 3 retries. The minimum value is 1 retry. |

**Command Default** None

**Command Modes** interface configuration

|                        |                |                              |
|------------------------|----------------|------------------------------|
| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|                        | Release 3.9.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **keepalive** command to enable keepalive for a tunnel interface.

|                |                |                   |
|----------------|----------------|-------------------|
| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|                | interface      | read,<br>write    |

**Examples** The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# keepalive 30
```

# tunnel destination

To specify a tunnel interface's destination address, use the **tunnel destination** command. To remove the destination address, use the **no** form of this command.



**Note** The tunnel will not be operational until the tunnel destination is specified.

**tunnel destination** *ip-address*  
**no tunnel destination** *ip-address*

**Syntax Description** *ip-address* Specifies the IPv4 address of the host destination.

**Command Default** None

**Command Modes** interface configuration

| Command History | Release       | Modification                 |
|-----------------|---------------|------------------------------|
|                 | Release 3.9.0 | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

| Task ID | Task ID   | Operations     |
|---------|-----------|----------------|
|         | interface | read,<br>write |

**Examples** The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel destination 10.10.10.1
```

| Related Commands | Command                                    | Description   |
|------------------|--|---|
|                  | <a href="#">tunnel mode, on page 226</a>   | Configures the encapsulation mode of the tunnel interface.                |
|                  | <a href="#">tunnel source, on page 227</a> | Sets a tunnel interface's source address.                                 |
|                  | <a href="#">tunnel tos, on page 229</a>    | Specifies the value of the TOS field in the tunnel encapsulating packets. |
|                  | <a href="#">tunnel ttl, on page 230</a>    | Configures the Time-To-Live (TTL) for packets entering the tunnel.        |

# tunnel dfbit

To configure the DF bit setting in the tunnel transport header, use the **tunnel dfbit** command. To revert to the default DF bit setting value, use the **no** form of this command.

**tunnel dfbit disable**  
**no tunnel dfbit**

## Syntax Description

| Syntax Description | disable  |
|--------------------|--|
|                    | Disables the DF bit in the outer packet. This allows the outer packet to be fragmented, if required. |

## Command Default

The DF bit value in the outer packet is disabled. This allows outer packet fragmentation, if required.

## Command Modes

interface configuration

## Command History

| Release       | Modification                 |
|---------------|------------------------------|
| Release 3.9.0 | This command was introduced. |

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

| Task ID   | Operations     |
|-----------|----------------|
| interface | read,<br>write |

## Examples

The following example shows how to enable fragmentation over an interface tunnel.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel dfbit disable
```

## Related Commands

| Command   | Description   |
|---|---|
| <a href="#">tunnel destination, on page 224</a> | Specifies a tunnel interface's destination address.                       |
| <a href="#">tunnel mode, on page 226</a>        | Configures the encapsulation mode of the tunnel interface.                |
| <a href="#">tunnel source, on page 227</a>      | Sets a tunnel interface's source address.                                 |
| <a href="#">tunnel tos, on page 229</a>         | Specifies the value of the TOS field in the tunnel encapsulating packets. |
| <a href="#">tunnel ttl, on page 230</a>         | Configures the Time-To-Live (TTL) for packets entering the tunnel.        |

# tunnel mode

To configure the encapsulation mode of the tunnel interface, use the **tunnel mode** command. To revert the encapsulation to the default IPv4 GRE tunnel mode, use the **no** form of this command.

```
tunnel mode gre ipv4}
no tunnel mode
```

| Syntax Description |     |  |
|--------------------|-----|--|
| Syntax Description | gre | ipv4   |
|                    |     | Specifies the tunnel as a GRE tunnel over an IPv4 transport network. |

**Command Default** The default tunnel mode is set as a GRE tunnel over an IPv4 transport network.

**Command Modes** interface configuration

| Command History | Release       | Modification                 |
|-----------------|---------------|------------------------------|
|                 | Release 3.9.0 | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

| Task ID | Task ID   | Operations     |
|---------|-----------|----------------|
|         | interface | read,<br>write |

**Examples** The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel mode gre ipv4
```

| Related Commands | Command   | Description   |
|------------------|---|---|
|                  | <a href="#">tunnel destination, on page 224</a> | Specifies a tunnel interface's destination address.                       |
|                  | <a href="#">tunnel source, on page 227</a>      | Sets a tunnel interface's source address.                                 |
|                  | <a href="#">tunnel tos, on page 229</a>         | Specifies the value of the TOS field in the tunnel encapsulating packets. |
|                  | <a href="#">tunnel ttl, on page 230</a>         | Configures the Time-To-Live (TTL) for packets entering the tunnel.        |

# tunnel source

To set a tunnel interface's source address, use the **tunnel source** command. To remove the source address, use the **no** form of this command.



**Note** The tunnel will not be operational until the tunnel source is specified.

**tunnel source** {**interface\_name** | *ip-address*}  
**no tunnel source** {**interface\_name** | *ip-address*}

|                           |                       |   |
|---------------------------|-----------------------|---|
| <b>Syntax Description</b> | <i>interface_name</i> | Specifies the name of the interface whose IP address will be used as the source address of the tunnel. The interface name can be of a loopback interface or a physical interface. |
|                           | <i>ip-address</i>     | Specifies the IPv4 address to use as the source address for packets in the tunnel.  |

**Command Default** None

**Command Modes** interface configuration

| <b>Command History</b> | <b>Release</b> | <b>Modification</b>          |
|------------------------|----------------|------------------------------|
|                        | Release 3.9.0  | This command was introduced. |

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

It is recommended that the tunnel source is identified using the interface ID and not the IP address. Using the interface ID enables the router to mark the tunnel as down when the interface is down and the routing protocol tries to find and use an alternate route to the tunnel route.

| <b>Task ID</b> | <b>Task ID</b> | <b>Operations</b> |
|----------------|----------------|-------------------|
|                | interface      | read,<br>write    |

## Examples

The following example shows how to configure interface tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel source 10.10.10.1
```

**Related Commands**

| Command   | Description   |
|---|---|
| <a href="#">tunnel destination, on page 224</a> | Specifies a tunnel interface's destination address.                       |
| <a href="#">tunnel mode, on page 226</a>        | Configures the encapsulation mode of the tunnel interface.                |
| <a href="#">tunnel tos, on page 229</a>         | Specifies the value of the TOS field in the tunnel encapsulating packets. |
| <a href="#">tunnel ttl, on page 230</a>         | Configures the Time-To-Live (TTL) for packets entering the tunnel.        |

# tunnel tos

To specify the value of the TOS field in the tunnel encapsulating packets, use the **tunnel tos** command. To return to the default TOS value, use the **no** form of this command.

**tunnel tos** *tos\_value*  
**no tunnel tos** *tos\_value*

|                           |   |  |
|---------------------------|---|--|
| <b>Syntax Description</b> | <i>tos_value</i> Specifies the value of the TOS field in the tunnel encapsulating packets. The TOS value ranges between 0 to 255.   |  |
| <b>Command Default</b>    | Copies the TOS/COS bits of the internal IP header to the GRE IP header. In case of labeled payload, EXP bits are copied to TOS bits of the GRE IP header.   |  |
| <b>Command Modes</b>      | interface configuration   |  |
| <b>Command History</b>    | <b>Release</b>  | <b>Modification</b>  |
|                           | Release 3.9.0   | This command was introduced.                                       |
| <b>Usage Guidelines</b>   | To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance. |  |
| <b>Task ID</b>            | <b>Task ID</b>  | <b>Operations</b>  |
|                           | interface   | read,<br>write   |
| <b>Examples</b>           | <p>The following example shows how to configure interface tunnel:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400 RP/0/RP0/CPU0:router(config-if)# tunnel tos 100</pre>                |  |
| <b>Related Commands</b>   | <b>Command</b>  | <b>Description</b>   |
|                           | <a href="#">tunnel destination, on page 224</a>   | Specifies a tunnel interface's destination address.                |
|                           | <a href="#">tunnel mode, on page 226</a>  | Configures the encapsulation mode of the tunnel interface.         |
|                           | <a href="#">tunnel source, on page 227</a>  | Sets a tunnel interface's source address.                          |
|                           | <a href="#">tunnel ttl, on page 230</a>   | Configures the Time-To-Live (TTL) for packets entering the tunnel. |

# tunnel ttl

To configure the Time-To-Live (TTL) for packets entering the tunnel, use the **tunnel ttl** command. To undo the configuration, use the **no** form of this command.

```
tunnel ttl ttl_value
no tunnel ttl ttl_value
```

|                    |  |
|--------------------|--|
| Syntax Description | ttl_value Specifies the value of TTL for packets entering the tunnel. The TTL value ranges between 1 to 255. |
|--------------------|--|

|                 |                                      |
|-----------------|--------------------------------------|
| Command Default | The default TTL value is set to 255. |
|-----------------|--------------------------------------|

|               |                         |
|---------------|-------------------------|
| Command Modes | interface configuration |
|---------------|-------------------------|

| Command History | Release       | Modification                 |
|-----------------|---------------|------------------------------|
|                 | Release 3.9.0 | This command was introduced. |

|                  |  |
|------------------|--|
| Usage Guidelines | <p>To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.</p> <p>This command specifies the Time-To-Live for packets entering the tunnel so that the packets are not dropped inside the carrier network before reaching the tunnel destination.</p> |
|------------------|--|

| Task ID | Task ID   | Operations     |
|---------|-----------|----------------|
|         | interface | read,<br>write |

|          |  |
|----------|--|
| Examples | The following example shows how to configure interface tunnel: |
|----------|--|

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface tunnel-ip 400
RP/0/RP0/CPU0:router(config-if)# tunnel source 10.10.10.1
```

| Related Commands | Command   | Description   |
|------------------|---|---|
|                  | <a href="#">tunnel destination, on page 224</a> | Specifies a tunnel interface's destination address.                       |
|                  | <a href="#">tunnel mode, on page 226</a>        | Configures the encapsulation mode of the tunnel interface.                |
|                  | <a href="#">tunnel tos, on page 229</a>         | Specifies the value of the TOS field in the tunnel encapsulating packets. |



| Command                                    | Description                               |
|--|---|
| <a href="#">tunnel source, on page 227</a> | Sets a tunnel interface's source address. |

tunnel ttl