



# CHAPTER 1

## ROM Monitor Overview and Basic Procedures

---

This chapter provides an overview of ROM Monitor concepts and operations. For instructions on how to perform various tasks in ROM Monitor mode (ROMMON), see the other chapters in this book.

This chapter includes the following main topics:

- [ROM Monitor Overview, page 1-1](#)
- [Entering ROM Monitor Mode, page 1-3](#)
- [ROM Monitor Commands, page 1-7](#)
- [Displaying the Configuration Register Setting, page 1-10](#)
- [Environment Variable Settings, page 1-11](#)
- [Viewing Chassis Serial Numbers \(Cisco CRS Routers\), page 1-13](#)
- [Exiting ROM Monitor Mode, page 1-14](#)
- [Additional References, page 1-17](#)

## ROM Monitor Overview

The *ROM Monitor* is a bootstrap program that initializes the hardware and boots the Cisco IOS XR software when you power on or reload a router. A version of the ROM Monitor software exists on each card. If the Cisco IOS XR software cannot boot on a card, the card startup ends in ROM Monitor mode. When you connect a terminal to a card that is in ROM Monitor mode, the ROM Monitor CLI prompt is displayed.

### Cisco CRS Prompt

```
rommon B1>
```

During normal operation, users do not see the ROM Monitor prompt or use ROM Monitor mode. ROM Monitor mode is used only in special circumstances, such as reinstalling the entire software set, resetting the router password, or specifying a configuration file to use at startup.

The ROM Monitor software is known by many names. It is sometimes called *ROMMON* because of the CLI prompt in ROM Monitor mode. The ROM Monitor software is also called the *boot software*, *boot image*, or *boot helper*. Although it is distributed with routers that use the Cisco IOS XR software, ROM Monitor is a separate program from the Cisco IOS XR software. During normal startup, the ROM Monitor initializes the cards, and then control passes to the Cisco IOS XR software. After the Cisco IOS XR software takes over, ROM Monitor is no longer in use.

A copy of the ROM Monitor software exists on each card. If a card fails to boot the Cisco IOS XR software, the ROM Monitor software takes control and places the card in ROM Monitor mode. Because a card in ROM Monitor mode is not running the Cisco IOS XR software, that card becomes unavailable for normal router operations.

### Understanding the Role of the DSC

The active Route Processor (RP) for the owner Secure Domain Router (SDR) is called the Designated Shelf Controller (DSC). This card performs system-wide functions, including the creation of additional non-owner SDRs. If the active DSC is placed in ROM Monitor mode, it is no longer running the Cisco IOS XR software. If a standby DSC is available, the standby RP resumes router operations. If a standby DSC is not available or is also placed in the ROM Monitor mode, then router operations stop.

### Designated Secure Domain Router Shelf Controller (DSDRSC)

In addition to the DSC, each SDR in the system contains at least one DSDRSC. The DSDRSCs provide configuration and administrative functions for a single SDR only. The DSC also serves as the DSDRSC for the owner SDR.

When the Designated Secure Domain Router Shelf Controller (DSDRSC) in an SDR is placed in ROM Monitor mode, the router operations are transferred to the standby DSDRSC (if available). If both the primary and standby DSDRSCs are in ROM Monitor mode, then the router operations cease because the Cisco IOS XR software is no longer running.

### Accessing ROM Monitor Mode on the DSC

In most situations, you interact with the ROM Monitor mode only on the DSC (DSDRSC for the owner SDR). The DSC contains the administration configuration for the entire system and distributes the required software to all the other nodes in the router. All the tasks in this document describe ROM Monitor mode accessed through the DSC for the system.

Remember, the DSC is also the following:

- Active RP of rack 0
- DSDRSC for the owner SDR

### Environmental Variables and the Configuration Register

Two primary connections exist between ROM Monitor and the Cisco IOS XR software: the ROM Monitor environment variables and the configuration register.

The ROM Monitor environment variables define the location of the Cisco IOS XR software and describe how to load it. After ROM Monitor has initialized the card, it uses the environment variables to locate and load the Cisco IOS XR software.

The *configuration register* is a software setting that controls how a card starts up. One of the primary uses of the configuration register is to control whether the card starts in ROM Monitor mode or Administration EXEC mode. The configuration register is set in either ROM Monitor mode or Administration EXEC mode as needed. Typically, you set the configuration register using the Cisco IOS XR software prompt on the active RP when you need to use ROM Monitor mode. When the maintenance in ROM Monitor mode is complete, you change the configuration register so the card reboots with the Cisco IOS XR software.



#### Note

Throughout this guide, the term *RP* is used to refer to the RP cards supported on Cisco CRS routers. If a feature or an issue applies to only one platform, the accompanying text specifies the platform.

### Accessing ROM Monitor Mode with a Terminal Connection

When an RP is in ROM Monitor mode, you can access the ROM Monitor software only from a terminal connected directly to the console port of the card. Because the Cisco IOS XR software (EXEC mode) is not operating, the nonmanagement interfaces (such as POS interfaces) are not accessible. Basically, all Cisco IOS XR software resources are unavailable. The hardware is there, but no configuration exists to make use of the hardware.

### Network Management Access and ROM Monitor Mode

Some people get confused when they start to use ROM Monitor mode. It is important to remember that ROM Monitor mode is a router mode, not a mode within the Cisco IOS XR software. It is best to remember that ROM Monitor software and the Cisco IOS XR software are two separate programs that run on the same router. At any given time, the router is running one of these programs, but it never runs both at the same time.

One area that can be confusing when using ROM Monitor and the Cisco IOS XR software is the area that defines the IP configuration for the Management Ethernet interface. Most router users get comfortable with configuring the Management Ethernet interface in the Cisco IOS XR software. When the router is in ROM Monitor mode, however, the router is not running the Cisco IOS XR software, so that Management Ethernet interface configuration is not available.

To access other devices, such as a TFTP server, while in ROM Monitor mode on the Cisco CRS, you must configure the ROM Monitor variables with IP access information.

## Entering ROM Monitor Mode

The following sections describe two ways to enter ROM Monitor mode:

- [Resetting the Configuration Register and Reloading a DSC to ROM Monitor Mode, page 1-3](#)
- [Manually Halting the Initialization Process During System Reload, page 1-7](#)

## Resetting the Configuration Register and Reloading a DSC to ROM Monitor Mode

In normal operating conditions, it should not be necessary to use ROM Monitor mode. If you do find it necessary to place a designated shelf controller (DSC) in ROM Monitor mode, make sure that the system is in a steady state and that you are prepared for the consequences of a system reload. In particular, verify the items described in the “Prerequisites” section on page 1-3.

### Prerequisites

Before you place a DSC in ROM Monitor mode, verify that the system is in a steady state:

1. Prepare the RP card:
  - a. Anticipate substantial downtime, including the loss of packet forwarding on the system.
  - b. Verify the sanity of the configuration file system using the **cfs check** command in EXEC mode.
  - c. Verify that all changes to the active router configuration are saved with the **commit** command in any configuration mode.
  - d. Verify that all changes to the active software set are saved with the **install commit** command in Administration EXEC mode.

- e. Verify that all install commit processes are complete with the **show install committed** command in Administration EXEC mode. This command displays the committed packages that become active during the next router boot. If any of the processes are not committed, use the **install commit** command in the Administration mode.
2. Verify that the other nodes in the system are in a steady state:
    - a. If a standby RP is installed, verify that it is in the ready state with the **show redundancy** command in EXEC mode.
    - b. Verify that all available nodes in the system are in IOS XR RUN state with the **show platform** command in EXEC mode.

After you have verified that the system is in a stable state, you can enter ROM Monitor mode by setting the configuration register setting and entering the **reload** command, as described in the following steps:


### SUMMARY STEPS

1. Verify that the router is in a steady state.
2. Connect a terminal to the DSC console port and log in to the router.
3. **admin**
4. Place the DSC, or all RPs in ROM Monitor mode:
  - Place only the DSC in the ROM Monitor mode:
    - a. **config-register 0x0**
    - b. **exit**
    - c. **reload**

or
  - Place all RPs in the ROM Monitor mode:
    - a. **config-register 0x0 location all**
    - b. **reload location all**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	Verify that the router is in a steady state.	Ensures that all configurations are saved and that no installation processes are running. <ul style="list-style-type: none"> <li>• For more information, see the <a href="#">“Prerequisites” section on page 1-3</a>.</li> </ul>
Step 2	Connect a terminal to the DSC console port and log in to the router.	Connects a terminal or PC to the DSC console port and establishes a router management session. <ul style="list-style-type: none"> <li>• For more information on connecting a terminal, see <i>“Connecting and Communicating with the Router”</i> in <i>Cisco IOS XR Getting Started Guide for the Cisco CRS Router</i>.</li> </ul>

	Command or Action	Purpose
Step 3	<b>admin</b>  <b>Example:</b> RP/0/RP0/CPU0:router# admin	Enters administration EXEC mode.
Step 4	<b>config-register 0x0</b> <b>exit</b> <b>reload</b> or <b>config-register 0x0 location all</b> <b>reload location all</b>  <b>Examples:</b> RP/0/RP0/CPU0:router(admin)# config-register 0x0 RP/0/RP0/CPU0:router(admin)# exit RP/0/RP0/CPU0:router# reload  Or,  RP/0/RP0/CPU0:router(admin)# config-register 0x0 location all RP/0/RP0/CPU0:router(admin)# reload location all	Enter the following commands to place only the DSC in ROM Monitor mode: <ol style="list-style-type: none"> <li>Enter the <b>config-register 0x0</b> command to set the configuration register for ROM Monitor mode during the next card reload.</li> <li>Enter the <b>exit</b> command to exit administration EXEC mode.</li> <li>Enter the <b>reload</b> command to reload the DSC and enter ROM Monitor mode.</li> </ol> <p><b>Note</b> If there is a standby DSC, the configuration register on the standby DSC is also set to 0x0. When you place the active RP in ROM Monitor mode, the system fails over to the standby RP, which then becomes the active RP. If both RPs need to be in ROM Monitor mode, connect to the new active RP and enter the <b>reload</b> command.</p> Enter the following commands to place all RPs and SCs in ROM Monitor mode: <ol style="list-style-type: none"> <li>Enter the <b>config-register 0x0 location all</b> command to reset the configuration register for all RPs in the system.</li> <li>Enter the <b>reload location all</b> command in administration EXEC mode to reload all RPs in the system.</li> </ol> <p><b>Note</b> Make sure you have access to the console ports of both RSP0 and RSP1 cards on the system. To enter the system to the ROM Monitor mode, press <b>Ctrl-C</b> a few times on both RSP0 and RSP1 consoles until you get to the ROM Monitor mode.</p> <p> <b>Caution</b> Resetting the configuration register may change the baud rate for the console.</p>

**Tip**

To verify the configuration register setting, enter the **show variables boot** command in the administration EXEC mode.

## Examples

The following examples show how to place the DSC in ROM Monitor mode:

- [Verifying the Router State: Example, page 1-6](#)
- [Placing the DSC in ROM Monitor Mode: Example, page 1-6](#)

### Verifying the Router State: Example

The following example shows the redundancy roles of both RPs and shows that both are operating in IOS XR RUN state:

```
RP/0/RP0/CPU0:router# show redundancy

Sun Jun  6 04:12:24.171 DST
Redundancy information for node 0/RP0/CPU0:
=====
Node 0/RP0/CPU0 is in ACTIVE role
Partner node (0/RP1/CPU0) is in STANDBY role
Standby node in 0/RP1/CPU0 is ready
Standby node in 0/RP1/CPU0 is NSR-ready

Reload and boot info
-----
RP reloaded Mon May 17 21:51:57 2010: 2 weeks, 5 days, 6 hours, 20 minutes ago
Active node booted Mon May 17 21:51:57 2010: 2 weeks, 5 days, 6 hours, 20 minutes ago
Standby node boot Mon May 17 21:51:32 2010: 2 weeks, 5 days, 6 hours, 20 minutes ago
Standby node last went not ready Mon May 17 22:03:03 2010: 2 weeks, 5 days, 6 hours, 9
minutes ago
Standby node last went ready Mon May 17 22:03:03 2010: 2 weeks, 5 days, 6 hours, 9 minutes
ago
Standby node last went not NSR-ready Fri Jun  4 17:59:52 2010: 1 day, 10 hours, 12 minutes
ago
Standby node last went NSR-ready Fri Jun  4 18:00:28 2010: 1 day, 10 hours, 11 minutes ago
There have been 0 switch-overs since reload

Active node reload "Cause: Lost DSC"
Standby node reload "Cause: User reload request"

RP/0/RP0/CPU0:router# show platform

Sun Jun  6 04:14:44.888 DST
Node          Type                PLIM                State                Config State
-----
0/6/CPU0      MSC                 Jacket Card         IOS XR RUN           PWR,NSHUT,MON
0/6/0         MSC(SPA)            4XOC3-POS          OK                   PWR,NSHUT,MON
0/6/1         MSC(SPA)            1x10GE             OK                   PWR,NSHUT,MON
0/6/4         MSC(SPA)            8XOC3/OC12-POS    OK                   PWR,NSHUT,MON
0/6/5         MSC(SPA)            8X1GE              OK                   PWR,NSHUT,MON
0/RP0/CPU0    RP(Active)          N/A                IOS XR RUN           PWR,NSHUT,MON
0/RP1/CPU0    RP(Standby)        N/A                IOS XR RUN           PWR,NSHUT,MON
```

### Placing the DSC in ROM Monitor Mode: Example

The following example shows how to place the RP0 in the ROM Monitor mode:

```
RP/0/RP0/CPU0:router# admin
RP/0/RP0/CPU0:router(admin)# config-register 0x0

Successfully set config-register to 0x0 on node 0/RP0/CPU0
Successfully set config-register to 0x0 on node 0/RP1/CPU0
RP/0/RP0/CPU0:router(admin)# reload

Configuring MPPs ...
```

```
Configuring PCMCIA slots ...

System Bootstrap, Version 1.53(20090311:225342) [CRS ROMMON],
Copyright (c) 1994-2009 by Cisco Systems, Inc.

Acquiring backplane mastership .... successful
Preparing for fan initialization..... ready
Setting fan speed to 4000 RPMs successful
Reading backplane EEPROM ...
Released backplane mastership ...

Board type is 0x100002 (1048578)

Switch 0 initialized
Backplane FE port Up... Enabling
Enabling watchdog
G4(7457-NonSMP-MV64360 Rev 3) platform with 4096 MB of main memory

rommon B1 >
```

## Manually Halting the Initialization Process During System Reload

To force the DSC to stop loading and enter ROM Monitor mode, press **Ctrl-C** when you see the following message:

```
MBI validation sending request.
HIT Ctrl-C to abort
```

This message usually appears during the first 20 seconds of system startup. Press the **Ctrl-C** key combination immediately. It may be necessary to press the **Ctrl-C** keys repeatedly during this time to ensure that the initialization process stops and the system enters ROM Monitor mode. This ends your Telnet session to the console or auxiliary port.

This operation can be performed only from a terminal directly connected to the DSC console port. For more information, see the “Connecting and Communicating with the Router” section in *Cisco IOS XR Getting Started Guide for the Cisco CRS Router*.

**Note**

---

When the DSC is placed in ROMMON, it switches over to the standby DSC, which can then also be placed in ROMMON. Repeat this process for both RP cards.

---

## ROM Monitor Commands


The commands in the ROM Monitor mode are different from those available in the Cisco IOS XR software. You can run ROM Monitor commands only while in ROM Monitor mode, and you cannot run Cisco IOS XR software commands. This section includes the following topics:

- [Commonly Used ROM Monitor Commands, page 1-8](#)
- [Displaying the Available ROM Monitor Commands, page 1-8](#)
- [Changing the ROM Monitor Prompt, page 1-10](#)

## Commonly Used ROM Monitor Commands

Table 1-1 summarizes the commands commonly used in ROM Monitor. For specific instructions on using these commands, refer to the relevant procedure in this document.

**Table 1-1** Commonly Used ROM Monitor Commands

ROMMON Command	Description
<code>boot image</code>	Manually boots a vm Cisco IOS XR software image.
<code>boot image -o config-file-path</code>	Manually boots the Cisco IOS XR software with a temporary alternative administration configuration file.
<code>boot image -a config-file-path</code>	Manually boots the Cisco IOS XR software with an alternative SDR configuration file.
<code>cookie</code>	Displays the system cookie.
<code>confreg</code>	Changes the config-register setting.   <b>Note</b> When the value of confreg is 0, it means autoboot is disabled and you need to manually boot the Cisco IOS XR software image from the ROM Monitor mode. However, if the value of confreg is non-zero value of 0x2, it means autoboot is enabled and the ROM Monitor mode automatically boots the Cisco IOS XR software image given in the BOOT= environment variable.
<code>dev</code>	Displays the available local storage devices (for example, disk0: and disk1:).
<code>dir</code>	Displays the files on a storage device.
<code>dumpplaneeprom</code>	Displays the chassis serial number in a Cisco CRS router.
<code>reset</code>	Resets the node.
<code>set</code>	Displays the currently set ROM Monitor environmental settings.
<code>sync</code>	Saves the new ROM Monitor environmental settings.
<code>unset</code>	Removes an environmental variable setting.
<code>version</code>	Displays the ROM Monitor version.

## Displaying the Available ROM Monitor Commands

Table 1-2 describes the available **help** commands for ROM Monitor mode.

**Table 1-2** Help Commands in ROMMON

Command	Description
<code>help</code> or <code>?</code>	Displays a summary of all available ROM Monitor commands.
<code>-?</code>	Displays information about command syntax.



**Note**

Commands are case sensitive. You can halt any command by pressing **Ctrl-C**.

## Examples

The following example shows what appears when you enter the **?** command on a Cisco CRS:

```
rommon B5> ?
addrloop          walk 1 thru range of addresses
alias            set and display aliases command
alter            alter locations in memory
bcm_init         Initialise Broadcom switch for ROMMON
getPciReg        Get BCM 5600 PCI memory mapped Reg.
setPciReg        Set BCM 5600 PCI Memory mapped Reg.
getSocReg        Get BCM 5600 On-chip reg value
setSocReg        Set BCM 5600 On-chip reg value
getMiiReg        Get BCM 5600 FE PHY Regs.
setMiiReg        Set BCM 5600 FE PHY Regs.
bcm_links_update Update links status of Bcm 5600
show_bcm_regs    Show all Broadcom switch registers
show_bcm_raw     Show Broadcom Switches port info
berrscan        scan range of addresses for bus errors
boot            boot up an external process
break          set/show/clear the breakpoint
call           call a subroutine at address with converted hex args
cat            concatenate files
checksum       checksum a block of memory
clrerr        clear the error log
compare       compare two blocks of memory
dcompare      compare two blocks of memory accessed as 8 bytes
confreg       configuration register utility
cont         continue executing a downloaded image
context       display the context of a loaded image
cpu           cpu / system information and control
dev           list the device table
dir           list files in file system
dis          disassemble instruction stream
dnld         serial download a program module
dump         display a block of memory
ddump        display a block of memory as double words
echo         monitor echo command
errlog       display the error log
fdump        file dump utility
fill         fill a block of memory
dfill        fill a block of memory with double words
dpar         test the CPU bus data parity
flash        flash services command
frame        print out a selected stack frame
getPci0ConfigReg print out PCI0 config space reg
getPci1ConfigReg print out PCI1 config space reg
setPci0ConfigReg set PCI0 config space reg
setPci1ConfigReg set PCI1 config space reg
help         monitor builtin command help
history      monitor command history
hang_i2c_bus cause a hang on the I2C bus
test_unhang_i2c_bus cause unhang sequence to be generated on the I2C bus
ifill        fill a block of memory w/incrementing pattern
initfs       re-initialize the file system access structures
jump         call a subroutine at address with argc/argv
launch       launch a downloaded image
memdebug     write/read/verify scope loop
```

meminfo	main memory information
memloop	write or read scope loop
memtest	simple memory test
move	move a block of memory
pingdsc	validate MBI and rack number w/ the dSC
prt6729	print CLPD6729 internal registers
dmove	move a block of memory accessed as 8 bytes
dumpspd	Dump the Serial Presents Detect info from the SDRAM DIMMs
dumpplaneeprom	Dump the contents of the back plane
dumpphys	Dumps registers of all ethernet phys
readi2c	read an I2c device
repeat	repeat a monitor command
reset	system reset
resetc	dump core and reset a card
resetsp	reset an sp card
scanpci0	scan for devices on PCI bus 0
scanpci1	scan for devices on PCI bus 1
set	display the monitor variables
setprocmask	Change the mask of CPUs passed to the OS in EMT_GET_SMP_MASK
setromA	Set rommon to force it to rommon A upon next reset
showerr	show crash error message
smptest	Test the other CPU on an SMP board
speed	timed performance loop
stack	produce a stack trace
sync	write monitor environment to NVRAM
tcal	timer calibration test
tftpdnld	tftpdnld no longer available, use boot
tscope	timer scope loop
unalias	unset an alias
unset	unset a monitor variable
version	display rommon software, board, version
watchdog	test watchdog rebooting of the box
writei2c	Write to an I2C device

The following example shows the parameters for the **dir** (directory) command:

```
rommon B5> dir -?
bad device name
usage: dir <device>
```

## Changing the ROM Monitor Prompt

You can change the prompt in ROM Monitor mode by using the **PS1=** command as shown in the following example:

```
rommon B5> PS1= "CRS_rp1_rommon ! >"
```

Changing the prompt is useful if you are working with multiple routers in ROM Monitor at the same time. This example specifies that the prompt is CRS\_rp1\_rommon followed by the line number.

## Displaying the Configuration Register Setting

To display the current configuration register setting, enter the **confreg** command without parameters as follows:

```
rommon B5> confreg
```

```

Configuration Summary
(Virtual Configuration Register: 0x0)
enabled are:
console baud: 9600
boot: the ROM Monitor

do you wish to change the configuration? y/n [n]:

```

The configuration register setting is labeled Virtual Configuration Register. Enter the **no** command to avoid changing the configuration register setting. For more information about exiting the ROM Monitor mode or changing the configuration setting, see the [“Exiting ROM Monitor Mode”](#) section on page 1-14.

## Environment Variable Settings

The ROM Monitor environment variables define the attributes of the ROM Monitor, such as the IP address for an RP control Ethernet port or the location of the Cisco IOS XR software and describe how to load it. Environmental variables are entered like commands and are always followed by the equal sign (=). Environment variable settings are entered in capital letters, followed by a definition. For example:

```
TURBOBOOT=on,disk0,format
```

Under normal operating conditions, you do not need to modify these variables. They are cleared or set only when you need to make changes to the way ROM Monitor operates.

This section includes the following topics:

- [Frequently Used Environmental Variables, page 1-11](#)
- [Displaying Environment Variable Settings, page 1-12](#)
- [Entering Environment Variable Settings, page 1-13](#)
- [Saving Environment Variable Settings, page 1-13](#)
- [Clearing Environment Variable Settings, page 1-13](#)

## Frequently Used Environmental Variables

[Table 1-3](#) shows the main ROM Monitor environmental variables. For instructions on how to use these variables, see the relevant instructions in this document.

**Table 1-3** *Frequently Used ROM Monitor Environmental Variables*

Environmental variable	Description
<code>IP_ADDRESS=ip_address</code>	Sets the IP address for the Management Ethernet interface on the DSC. (On the Cisco CRS RP only.)
<code>IP_SUBNET_MASK=ip_address</code>	Sets the subnet mask for the Management Ethernet interface on the DSC. (On the Cisco CRS RP only)

Table 1-3 Frequently Used ROM Monitor Environmental Variables (continued)

Environmental variable	Description
<b>DEFAULT_GATEWAY</b> = <i>ip_address</i>	Sets the default gateway that serves the DSC. (On the Cisco CRS RP only)  <b>Note</b> You must always add the DEFAULT_GATEWAY variable, even if CRS is directly connected in the same IP network.
<b>TFTP_SERVER</b> = <i>ip_address</i>	Sets the IP address of the TFTP server where a bootable software image is located.
<b>TFTP_FILE</b> = <i>drive : path / file</i>	Sets the directory and filename of a bootable software image.
<b>TURBOBOOT</b> = <i>on, boot-device, options</i>	Completely replaces the existing software when the router is reloaded.
<b>BOOT</b> = <i>drive : path / file</i>	Identifies the boot software for a node. This variable is usually set automatically when the router boots.
<b>AUX_AUTHEN_LEVEL</b> = <i>number</i>	Bypasses ksh authentication. A reboot is required only on the card that has to bypass authentication.
<b>IOX_ADMIN_CONFIG_FILE</b> = <i>drive : path / file</i>	Permanently changes the location of the default administration configuration file.
<b>IOX_CONFIG_FILE</b> = <i>drive : path / file</i>	Permanently changes the location of the SDR configuration file.
<b>IOX_CONFIG_MEDIUM</b> = <i>drive : path</i>	Permanently changes the default location where configuration files are saved.

## Displaying Environment Variable Settings

To display the current environment variable settings, enter the **set** command:

```
rommon B1> set

PS1=rommon ! >
TFTP_SERVER=172.23.16.81
IP_ADDRESS=172.29.52.71
IP_SUBNET_MASK=255.255.255.0
DEFAULT_GATEWAY=172.29.52.1
IOX_ADMIN_CONFIG_FILE=
TURBOBOOT=
BOOT_DEV_SEQ_CONF=disk0::disk1:
MIRROR_ENABLE=Y
?=0
ReloadReason=68
BSI=0
BOOT_DEV_SEQ_OPER=disk0::disk1:
EASYBAKE=0x0
BOOT=disk0:hfr-os-mbi-3.9.0.08I/mbihfr-rp.vm,1;
```

## Entering Environment Variable Settings

Environment variable settings are entered in capital letters, followed by a definition. The following example shows the environmental variables used to configure the control Ethernet port on a Cisco CRS:

```
rommon B1> IP_ADDRESS=1.1.1.1
rommon B2> IP_SUBNET_MASK=255.255.254.0
rommon B3> DEFAULT_GATEWAY=1.1.0.1
```

## Saving Environment Variable Settings

To save the current environment variable settings, enter the **sync** command:

```
rommon B1> sync
```

## Clearing Environment Variable Settings

To clear the environment variable settings, enter the **unset** command:

```
rommon B1> unset
```

To make the change permanent, use the **sync** command.



### Note

Environmental values that are not saved with the **sync** command are discarded whenever the system is reset or booted.

## Viewing Chassis Serial Numbers (Cisco CRS Routers)

The chassis serial number is required for multishelf routers and can be read from an SC or RP that is running in ROM Monitor mode. RP may be necessary if the physical label is missing or damaged.



### Note

You can view the chassis serial numbers using the Cisco IOS XR software. For more information, see “Displaying the Chassis Serial Numbers (Cisco CRS Routers)” in *Cisco IOS XR System Management Configuration Guide for the Cisco CRS Router*.

- Step 1** Attach a console to the console port of an SC or RP in the chassis. (Only the SC or RP needs to run to perform this procedure. Other cards need not be inserted.)
- Step 2** Apply power to the chassis.
- Step 3** Enter ROM Monitor mode, as described in the “Entering ROM Monitor Mode” section on page 1-3.
- Step 4** Enter the **dumpplaneeprom** command in privilege mode of the ROM Monitor prompt to display the chassis serial number. In the following example, the serial number is TBC0636606900000:

```
rommon B3 > priv
rommon B4 > dumpplaneeprom
EEPROM data backplane
000000 00 00 01 e2 00 00 00 00 00 00 00 00 00 00 00 00 .....
000010 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000020 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000030 00 00 00 00 00 00 08 00 45 3b 61 01 04 00 00 00 .....E;a.....
```

```

000040 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000050 54 42 43 30 36 33 36 36 30 36 39 30 30 30 30 30 TBC0636606900000
000060 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000070 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000080 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000090 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000a0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000b0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000c0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000d0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000e0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000f0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....

rommon B3 > priv
rommon B4 > dumpplaneeprom
EEPROM data backplane
000000 00 00 01 e2 00 00 00 00 00 00 00 00 00 00 00 .....
000010 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000020 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000030 00 00 00 00 00 00 00 08 00 45 3b 61 01 04 00 00 .....E;a.....
000040 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000050 54 42 43 30 36 33 36 36 30 36 39 30 30 30 30 TBC0636606900000
000060 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000070 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000080 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
000090 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000a0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000b0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000c0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000d0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000e0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
0000f0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....

```



**Note** The chassis serial number is displayed in the output to the right (row “00050”). A similar number is present for every chassis.

**Step 5** Return the router to EXEC mode, as described in the [“Exiting ROM Monitor Mode” section on page 1-14](#).

## Exiting ROM Monitor Mode

To exit ROM Monitor mode, you must change the configuration register to 0x102 and reset the RP. This process can be done by either entering CLI commands or responding to prompts.



**Tip**

The first RP to enter EXEC mode becomes the DSC. You can determine which RP is the DSC by resetting that card to EXEC mode first and then waiting 1 to 2 minutes to allow it to boot fully. You can also switchover to the standby DSDRSC at any time with the **redundancy switchover** command in EXEC mode.

The following sections describe ways to exit the ROM Monitor mode:

- [Resetting to EXEC Mode with CLI Commands, page 1-15](#)

- [Resetting the Configuration Register Using Prompts, page 1-15](#)

## Resetting to EXEC Mode with CLI Commands

Perform this task to reset the configuration register in ROM Monitor mode and start the RP in EXEC mode.

### SUMMARY STEPS

1. `confreg 0x102`
2. `reset`

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<code>confreg 0x102</code>  <b>Example:</b> <code>rommon B1&gt; confreg 0x102</code>	Resets the configuration register to enter EXEC mode after the system is reset.
Step 2	<code>reset</code>  <b>Example:</b> <code>rommon B1&gt; reset</code>	Resets and initializes the router.

## Resetting the Configuration Register Using Prompts

In ROM Monitor mode, you can change the configuration register value using the configuration register prompts, as shown in this procedure.

### SUMMARY STEPS

1. `confreg`
2. Respond to each prompt as instructed.
3. `reset`

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>confreg</b>  <b>Example:</b> rommon B1> confreg	Starts the configuration register configuration prompts.
Step 2	Respond to each prompt as instructed.	See the example that follows this procedure for more information.
Step 3	<b>reset</b>  <b>Example:</b> rommon B2> reset	Resets and initializes the router.

## Examples

The following example shows the commands required and the prompts that appear when you reset the RP to EXEC mode using the configuration register prompts:

```
rommon B1>
confreg

          Configuration Summary
    (Virtual Configuration Register: 0x0)
enabled are:
console baud: 9600
boot: the ROM Monitor

do you wish to change the configuration? y/n [n]: y
enable "diagnostic mode"? y/n [n]: n
change console baud rate? y/n [n]: n
change the boot characteristics? y/n [n]: y
enter to boot:
  0 = ROM Monitor
  1 = MBI Validation Boot Mode
  [0]: 1

          Configuration Summary
    (Virtual Configuration Register: 0x102)
enabled are:
console baud: 9600
boot: image specified by the boot system commands

do you wish to change the configuration? y/n [n]: n

You must reset or power cycle for new config to take effect
rommon B2> reset
```

**Note**

MBI validation mode causes the RP to boot the startup Cisco IOS XR software and configuration.



# Additional References

The following sections provide references related to the ROM Monitor.

## Related Documents

Related Topic	Document Title
Display chassis serial numbers (Cisco CRS Routers)	“Displaying the Chassis Serial Numbers (Cisco CRS Routers)” in <i>Cisco IOS XR System Management Configuration Guide for the Cisco CRS Router</i>
Connecting a terminal to a router	“Connecting and Communicating with the Router” in <i>Cisco IOS XR Getting Started Guide for the Cisco CRS Router</i>
Configuring a router with Cisco IOS XR software	Cisco IOS XR Software Documentation: <a href="http://www.cisco.com/en/US/products/ps5845/tsd_products_support_series_home.html">http://www.cisco.com/en/US/products/ps5845/tsd_products_support_series_home.html</a>

## Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	<a href="http://www.cisco.com/support">http://www.cisco.com/support</a>

