



# Preface

---

This section contains the following topics:

- [Objectives, on page i](#)
- [Revision History, on page i](#)
- [Document Conventions, on page i](#)
- [Related Documentation, on page iii](#)
- [Obtaining Documentation and Submitting a Service Request, on page iii](#)

## Objectives

This document provides an overview of the Cisco CSR 1000V Series Router deployment on Microsoft Azure. It is not intended as a comprehensive guide to all of the software features that can be run using the Cisco CSR 1000V Series router. For more information, see the [Cisco CSR 1000V Series Cloud Services Router Software Configuration Guide](#).

For information on general software features that are also available on the Cisco CSR 1000V Series router, see the [CSR 1000v Series Configuration Guides](#).

## Revision History

The Revision History records technical changes to this document. The table shows the Cisco IOS XE software release number, the date of the change, and a brief summary of the change

Release	Date	Change Summary
Cisco IOS XE Release 16 and Cisco IOS XE 3.16	June 8, 2016	First release.

## Document Conventions

This documentation uses the following conventions:

Convention	Description
<b>^</b> or <b>Ctrl</b>	The <b>^</b> and <b>Ctrl</b> symbols represent the Control key. For example, the key combination <b>^D</b> or <b>Ctrl-D</b> means hold down the <b>Control</b> key while you press the <b>D</b> key. Keys are indicated in capital letters but are not case sensitive.
<i>string</i>	A string is a nonquoted set of characters shown in italics. For example, when setting an SNMP <i>community</i> string to public, do not use quotation marks around the string or the string will include the quotation marks.

Command syntax descriptions use the following conventions:

Convention	Description
<b>bold</b>	Bold text indicates commands and keywords that you enter exactly as shown.
<i>italics</i>	Italic text indicates arguments for which you supply values.
[x]	Square brackets enclose an optional element (keyword or argument).
	A vertical line indicates a choice within an optional or required set of keywords or arguments.
[x   y]	Square brackets enclosing keywords or arguments separated by a vertical line indicate an optional choice.
{x   y}	Braces enclosing keywords or arguments separated by a vertical line indicate a required choice.
[x {y   z}]	Braces and a vertical line within square brackets indicate a required choice within an optional element.

Examples use the following conventions:

Convention	Description
screen	Examples of information displayed on the screen are set in Courier font.
<b>bold screen</b>	Examples of text that you must enter are set in Courier bold font.
<>	Angle brackets enclose text that is not printed to the screen, such as passwords.
!	An exclamation point at the beginning of a line indicates a comment line. (Exclamation points are also displayed by the Cisco IOS XE software for certain processes.)
[ ]	Square brackets enclose default responses to system prompts.

The following conventions are used to attract the attention of the reader:



**Note** Means *reader take note*. Notes contain helpful suggestions or references to materials that may not be contained in this manual.

**Caution**

Means *reader be careful* . In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

For related documentation, see Cisco CSR 1000v Documentation in the [Documentation Roadmap for Cisco CSR 1000v Series, Cisco IOS XE 16](#) .

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation* , which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

