



# Interface GCC Command Reference

---

This chapter describes commands to configure the Interface GCC.

- [interface gcc0, on page 2](#)
- [interface gcc1, on page 3](#)
- [ipv4 address odu, on page 4](#)
- [ipv4 address otu, on page 5](#)
- [show interfaces, on page 6](#)
- [show interfaces gcc0, on page 7](#)
- [show interfaces gcc1, on page 8](#)

# interface gcc0

To enter the configuration mode of GCC interface on an OTUk controller, use the **interface gcc0** command in the config mode.

**interface gcc0** [*R/S/I/P*]

<b>Syntax Description</b>	<i>R/S/I/P</i> Displays the Rack/Slot/Instance/Port of the controller.
---------------------------	--

<b>Command Default</b>	Disable
------------------------	---------

<b>Command Modes</b>	Config mode
----------------------	-------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.4	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	otn	write

## Example

This example shows how to enter the configuration mode of GCC interface on an OTU controller:

```
RP/0/RP0:hostname(config)# interface gcc0 0/0/0/0
```

# interface gcc1

To enter the configuration mode of GCC interface on an ODUk controller, use the **interface gcc1** command in the config mode. To delete the controller oduk, use the **no** form of this command.

**interface gcc1** [*R/S/I/P*]  
**no interface gcc1** [*R/S/I/P*]

## Syntax Description

<b>gcc1</b>	Enters the configuration mode.
<i>R/S/I/P</i>	Displays the Rack/Slot/Instance/Port of the controller.

## Command Default

Disable

## Command Modes

Config mode

## Command History

Release	Modification
Release 5.2.4	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
otn	write

## Example

This example shows how to enter the configuration mode of GCC interface on an ODU controller.

```
RP/0/RP0:hostname (config)# interface gcc1 0/0/0/0
```

## ipv4 address odu

To configure IP address for GCC on an ODUk controller, use the **ipv4 address** command in the config mode. To delete this feature, use the **no** form of this command.

**ipv4 address**  
**no ipv4 address**

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Config mode
----------------------	-------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.4	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	otn	write

### Example

This example shows how to configure IP address for GCC1 on the ODU controller.

```
RP/0/RP0:hostname (config-if)# ipv4 address 1.1.1.1/24
```

## ipv4 address otu

To configure IP address for GCC on an OTUk controller, use the **ipv4 address** command in the config mode. To delete this feature, use the **no** form of this command.

**ipv4 address**  
**no ipv4 address**

---

### Command Default

None

---

### Command Modes

Config mode

---

### Command History

Release	Modification
Release 5.2.4	This command was introduced.

---

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

---

### Task ID

Task ID	Operation
otn	write

### Example

This example shows how to configure IP address for GCC1 on the OTU controller.

```
RP/0/RP0:hostname (config-if)# ipv4 address 1.1.1.1/24
```

# show interfaces

To display IP address and status of all the interfaces, use the **show interfaces** command in the exec mode.

## show interfaces

This command has no keywords or arguments.

<b>Command Modes</b>	Exec mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.4	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	otn	read

## Example

This example shows how to display IP address and brief status of all the interfaces:

```
RP/0/RP0:hostname # show ip interfaces
```

```
Wed Jan  5 05:04:46.659 UTC
Interface          IP-Address      Status          Protocol
GCC00/0/0/0       1.1.1.1         Up              Down
MgmtEth0/RP1/CPU0/0 unassigned      Shutdown        Down
```

# show interfaces gcc0

To display all the interfaces on which GCC is configured, use the **show interfaces gcc0** command in the exec or config mode.

**show interfaces gcc0** [*R/S/I/P*]

<b>Syntax Description</b>	<i>R/S/I/P</i> Displays the Rack/Slot/Instance/Port of the controller.
---------------------------	--

<b>Command Modes</b>	Exec mode Config mode
----------------------	--------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.4	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	otn	read

## Example

This example shows how to display all the interfaces on which GCC is configured:

```
RP/0/RP0:hostname # show interfaces gcc0 0/1/0/0
```

```
GCC00/1/0/0 is up, line protocol is up
  Interface state transitions: 2
  Hardware is GCC0
  Internet address is 1.1.1.1/24
  MTU 4474 bytes, BW 4294967295 Kbit (Max: 4294967295 Kbit)
    reliability Unknown, txload Unknown, rxload Unknown
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
  LCP Open
  Open: IPCP
  Last input Unknown, output Unknown
  Last clearing of "show interface" counters Unknown
  Input/output data rate is disabled
```

# show interfaces gcc1

To display all the interfaces on which GCC is configured, use the **show interfaces gcc1** command in the exec mode.

**show interfaces gcc1** [*R/S/I/P*]

<b>Syntax Description</b>	<b>show gcc1</b> Shows the gcc1 configuration mode.
	<i>R/S/I/P</i> Displays the Rack/Slot/Instance/Port of the controller.

**Command Modes** Exec mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.2.4	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	otn	read

## Example

The following example shows how to display all the interfaces on which GCC is configured.

```
RP/0/RP0:hostname # show ip interface brief gcc1 0/2/0/1
```

```
GCC10/2/0/1 is up, line protocol is up
  Interface state transitions: 2
  Hardware is GCC1
  Internet address is 1.2.3.4/24
  MTU 4474 bytes, BW 4294967295 Kbit (Max: 4294967295 Kbit)
    reliability Unknown, txload Unknown, rxload Unknown
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
  LCP Open
  Req-Sent: IPCP
  Last input Unknown, output Unknown
  Last clearing of "show ip interface brief" counters Unknown
  Input/output data rate is disabled
```