

# Static MAC Address Support on Service Instances

The Multicast and Unicast static MAC address support on Service Instances feature supports configuration of a static MAC address on a pseudoport. Use of a static MAC address for Broadband Network Gateway (BNG) upstream traffic enables traffic forwarding while conserving MAC table resources and limiting the traffic flood by creating multicast groups.

- Prerequsites for Static MAC Address Support on Service Instances, on page 1
- Restrictions for Static MAC Address Support on Service Instances, on page 1
- Information about Static MAC Address Support on Service Instances, on page 2
- Configuring a Static MAC Address on a Service Instance, on page 2
- Verifying Configured Static MAC Addresses on a Service Instance, on page 4

# Prerequsites for Static MAC Address Support on Service Instances

- Knowledge of both port and bridge domain limitations.
- Knowledge of service instances.

# Restrictions for Static MAC Address Support on Service Instances

- Static MAC configuration is not allowed at secure service instance.
- Static MAC addresses are programmed only on switch processors (both active and standby).
- The Static MAC address on Pseudowires is not supported on the Cisco ASR 900 Series Routers.
- Static MAC address configuration is not supported on Trunk EFP.

## Information about Static MAC Address Support on Service Instances

Static MAC address configuration on service instances eliminates the need for MAC address learning, which is required for traffic forwarding. In the upstream direction, without MAC address learning, MAC address table resources can be conserved and network resources optimized.

When a bridge domain ID is either changed or deleted for a service instance, all static MAC addresses are removed.

When a service instance is deleted, all static MAC addresses on that pseudoport are removed.

### **Benefits of Static MAC Address Support on Service Instances**

- · Facilitates optimization of network resources
- Conserves MAC table resources when used for upstream traffic

### **Configuring a Static MAC Address on a Service Instance**

Perform this task to manually configure a static MAC address on a service instance.

#### **SUMMARY STEPS**

- 1. enable
- 2. configure terminal
- **3.** interface type number
- **4.** service instance *id* ethernet [*evc-id*]
- 5. encapsulation dot1q vlan-id [, vlan-id[- vlan-id]] [native]
- 6. bridge-domain bridge-id [split-horizon[group group-id]]
- 7. mac static address mac-addr [auto-learn]
- 8. exit

#### **DETAILED STEPS**

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	

	Command or Action	Purpose
Step 3	interface type number	Configures an interface type and enters interface configuration mode.
	Example:	
	Router(config)# interface GigabitEthernet 0/2/1	
Step 4	service instance <i>id</i> ethernet [ <i>evc-id</i> ]	Configures an Ethernet service instance on an interface and enters service instance configuration mode.
	Example:	
	Router(config-if)# service instance 1 ethernet	
Step 5	encapsulation dot1q vlan-id [, vlan-id[- vlan-id]] [native]	Enables IEEE 802.1Q encapsulation of traffic on a specified subinterface in a VLAN.
	Example:	
	Router(config-if-srv)# encapsulation dot1q 100	
Step 6	<b>bridge-domain</b> bridge-id [split-horizon[group group-id]]	Binds a service instance to a bridge domain instance.
	Example:	
	Router(config-if-srv)# bridge-domain 100	
Step 7	mac static address mac-addr [auto-learn]	Configures a static MAC address.
	Example:	
	Router(config-if-srv)# mac static address 0000.bbbb.cccc	
Step 8	exit	Returns the CLI to privileged EXEC mode.
	Example:	
	Router(config-if-srv)# exit	

### **Example for Configuring a Static MAC Address on a Service Instance**

```
Router> enable
Router# configure terminal
Router(config)# interface GigabitEthernet 0/2/1
Router(config-if)# service instance 1 ethernet
Router(config-if-srv)# encapsulation dotlq 100
Router(config-if-srv)# bridge-domain 100
Router(config-if-srv)# mac static address 0000.bbbb.cccc
Router(config-if-srv)# exit
```

## Verifying Configured Static MAC Addresses on a Service Instance

Use one or more of the following commands to verify the configured static MAC address on a service instance:

Action

- show bridge-domain
- show mac-address-table

### Example: Verifying Configured Static MAC Addresses on a Service Instance

#### show bridge-domain

The sample output for the show bridge-domain command:

Router# show bridge-domain 10 mac static address

Bridge-Domain ID : 10 Static MAC count : System : 1, bridge-domain : 1 Port Address Gi0/3/7 ServInst 10 aaa1.123c.bc32

#### show mac-address-table

The sample output for the show mac-address-table command:

Router# show mac-address-table bdomain 10

Nile Mac Address Entries BD mac addr type ports

10 aaa1.123c.bc32 STATIC Gi0/3/7.Efp10