



VPLS Configuration over MPLS-TP



Note This chapter is not applicable on the Cisco ASR 900 RSP3 Module.

This chapter describes how to configure VPLS over MPLS-TP on the Cisco ASR 903 Series Router. This chapter includes the following section:

For more information, see the [MPLS Transport Profile](#).

- [VPLS over MPLS-TP, on page 1](#)
- [Configuring VPLS over MPLS-TP, on page 2](#)
- [Verifying the Configuration, on page 12](#)
- [Configuration Examples, on page 13](#)
- [Feature Information for VPLS Configuration over MPLS-TP, on page 14](#)

VPLS over MPLS-TP

The sections below provide an overview of VPLS over MPLS-TP:

Multiprotocol Label Switching Overview

The Multiprotocol Label Switching (MPLS) Transport Profile (TP) enables you to create tunnels that provide the transport network service layer over which IP and MPLS traffic traverse. MPLS-TP tunnels enable a transition from Synchronous Optical Networking (SONET) and Synchronous Digital Hierarchy (SDH) time-division multiplexing (TDM) technologies to packet switching to support services with high bandwidth requirements, such as video.

Virtual Private LAN Services Overview

uses the provider core to join multiple attachment circuits together to simulate a virtual bridge that connects the multiple attachment circuits together. From a customer point of view, there is no topology for VPLS. All of the CE devices appear to connect to a logical bridge emulated by the provider core. See figure below.

VPLS over MPLS-TP Overview

VPLS over MPLS-TP allows you to deploy a multipoint-to-multipoint layer 2 operating environment over an MPLS-TP network for services such as Ethernet connectivity and multicast video.

References

For detailed information about the commands, see:

- Cisco IOS XE 3.5 MPLS Command Reference:
http://www.cisco.com/en/US/docs/ios/cether/command/reference/ce_book.html
- Master Command Index for Cisco IOS XE Release 3.5:
http://www.cisco.com/en/US/docs/ios/mcl/allreleasemcl/all_book.html

Configuring VPLS over MPLS-TP

The sections below describe how to configure VPLS over MPLS-TP:

Configuration Guidelines

VPLS over MPLS-TP is only supported on Gigabit Ethernet and Ten Gigabit Ethernet interfaces.

Configuring the MPLS Label Range

You must specify a static range of MPLS labels using the **mpls label range** command with the **static** keyword.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	mpls label range <i>minimum-value</i> <i>maximum-value</i> { static <i>minimum-static-value</i> <i>maximum-static-value</i> } Example: Router(config)# mpls label range 1001 1003 static 10000 25000	Specifies a static range of MPLS labels

Configuring the Router ID and Global ID

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none">• Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	mpls tp Example: Router(config)# mpls tp	Enters MPLS-TP configuration mode, from which you can configure MPLS-TP parameters for the router.
Step 4	router-id <i>node-id</i> Example: Router(config-mpls-tp)# router-id 10.10.10.10	Specifies the default MPLS-TP router ID, which is used as the default source node ID for all MPLS-TP tunnels configured on the router.
Step 5	global-id <i>num</i> Example: Router(config-mpls-tp)# global-id 1	(Optional) Specifies the default global ID used for all endpoints and midpoints. This command makes the router ID globally unique in a multiprovider tunnel. Otherwise, the router ID is only locally meaningful. The global ID is an autonomous system number, which is a controlled number space by which providers can identify each other. The router ID and global ID are also included in fault messages by routers at tunnel midpoints to help isolate the location of faults.

Configuring the Pseudowire Class

When you create the pseudowire class, you specify the parameters of the pseudowire, such as the use of the control word, and preferred path.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none">• Enter your password if prompted.

	Command or Action	Purpose
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	pseudowire-class <i>class-name</i> Example: Router(config)# pseudowire-class mpls-tp-class1	Creates a pseudowire class and enters pseudowire class configuration mode.
Step 4	encapsulation mpls Example: router(config-pw-class)# encapsulation mpls	Specifies the encapsulation type.
Step 5	control-word Example: Router(config-pw-class)# control-word	Enables the use of the control word.
Step 6	protocol {l2tpv2 l2tpv3 none}[l2tp-class-name] Example: Router(config-pw-class)# protocol none	Specifies the type of protocol.
Step 7	preferred-path {interface tunnel tunnel-number peer {ip-address host-name}} [disable-fallback] Example: Router(config-pw-class)# preferred-path interface tunnel-tp2	Specifies the tunnel to use as the preferred path.
Step 8	end Example: Router(config-pw-class)# end Router#	Exits configuration mode.

Configuring a BFD Template

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.

	Command or Action	Purpose
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	bfd-template single-hop <i>template-name</i> Example: Router(config)# bfd-template single-hop bfdtemplate1	Creates a BFD template and enters BFD configuration mode. The bfd-template command allows you to create a BFD template and enters BFD configuration mode. The template can be used to specify a set of BFD interval values. You can then invoke the BFD template when you set up the MPLS-TP tunnel.
Step 4	interval microseconds {both microseconds / min-tx microseconds min-rx microseconds} [multiplier multiplier-value] Example: Router(config-bfd)# interval microseconds both 3300 multiplier 3	Configures the transmit and receive intervals in microseconds between BFD packets, and specifies the number of consecutive BFD control packets that must be missed from a BFD peer before BFD declares that a peer is unavailable.
Step 5	interval {both milliseconds / min-tx milliseconds min-rx milliseconds} [multiplier multiplier-value] Example: Router(config-bfd)# interval both 120 multiplier 3	Configures the transmit and receive intervals in milliseconds between BFD packets, and specifies the number of consecutive BFD control packets that must be missed from a BFD peer before BFD declares that a peer is unavailable.
Step 6	end Example: Router(config-bfd)# end Router#	Exits configuration mode.

Configuring the MPLS-TP Tunnel

On the endpoint routers, create an MPLS TP tunnel and configure its parameters. See the **interface tunnel-tp** command for information on the parameters.

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	interface tunnel-tp <i>number</i> Example: Router(config)# interface tunnel-tp 2	Enters tunnel interface configuration mode. Tunnel numbers from 0 to 999 are supported.
Step 4	description tunnel-description Example: Router(config-if)# description headend tunnel	(Optional) Specifies a tunnel description.
Step 5	tp tunnel-name <i>name</i> Example: Router(config-if)# tp tunnel-name tunnel22	Specifies the name of the MPLS-TP tunnel. The TP tunnel name is displayed in the show mpls tp tunnel command output. This command is useful for consistently identifying the tunnel at all endpoints and midpoints.
Step 6	tp source <i>node-id [global-id num]</i> Example: Router(config-if)# tp source 10.10.11.11 global-id 10	(Optional) Specifies the tunnel source and endpoint. This command is and not typically used, because the global router ID and global ID can be used to identify the tunnel source at the endpoint. All tunnels on the router generally use the same (globally specified) source information.
Step 7	tp destination <i>node-id [[tunnel-tpnum] global-id num]</i> Example: Router(config-if)# tp destination 10.10.10.10	Specifies the destination node of the tunnel.
Step 8	bfd <i>bfd-template</i> Example: Router(config-if)# bfd template1	Specifies the BFD template.
Step 9	working-lsp Example: Router(config-if)# working-lsp	Specifies a working LSP, also known as the primary LSP. This LSP is used to route traffic. This command enters working LSP interface configuration mode (config-if-working).
Step 10	in-label <i>num</i> Example: Router(config-if-working)# in-label 10000	Specifies the in label.

	Command or Action	Purpose
Step 11	out-label <i>num</i> out-link <i>num</i> Example: <pre>Router(config-if-working)# out-label 10000 out-link 1</pre>	Specifies the out label and out link.
Step 12	exit Example: <pre>Router(config-if-working)# exit</pre>	Exits from working LSP interface configuration mode.
Step 13	protect-lsp Example: <pre>Router(config-if)# protect-lsp</pre>	Specifies a backup for a working LSP. If the working LSP fails, traffic is switched to the protect LSP until the working LSP is restored, at which time forwarding reverts back to the working LSP. This command enters protect LSP interface configuration mode (config-if-protect).
Step 14	in-label <i>num</i> Example: <pre>Router(config-if-protect)# in-label 10001</pre>	Specifies the in label.
Step 15	out-label <i>num</i> out-link <i>num</i> Example: <pre>Router(config-if-protect)# out-label 10001 out-link 2</pre>	Specifies the out label and out link.
Step 16	exit Example: <pre>Router(config-if-protect)# exit</pre>	Exits from protect LSP interface configuration mode.

Configuring MPLS-TP Links and Physical Interfaces

MPLS-TP link numbers may be assigned to physical interfaces only. Bundled interfaces and virtual interfaces are not supported for MPLS-TP link numbers.

The sections below describe how to configure physical interfaces for a VPLS over MPLS-TP link.

Configuring an Output Interface

Procedure

	Command or Action	Purpose
Step 1	enable Example: <pre>Router> enable</pre>	Enables privileged EXEC mode. Enter your password if prompted.

	Command or Action	Purpose
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	interface <i>type/num</i> Example: Router(config)# interface gigabitEthernet 1/0	Specifies the interface and enters interface configuration mode.
Step 4	no ip address Example: Router(config-if)# no ip address	Specifies that there is no IP address assigned to the interface.
Step 5	negotiation auto Example: Router(config-if)# negotiation auto	Enables the autonegotiation protocol to configure the speed, duplex, and automatic flow control of the Gigabit Ethernet interface.
Step 6	mpls tp link <i>link-num</i> { ipv4 <i>ip-address</i> / tx-mac <i>mac-address</i> } Example: Router(config-if)# mpls tp link 1 ipv4 10.0.0.2	Associates an MPLS-TP link number with a physical interface and next-hop node. On point-to-point interfaces or Ethernet interfaces designated as point-to-point using the medium p2p command, the next-hop can be implicit, so the mpls tp link command just associates a link number to the interface. Multiple tunnels and LSPs can refer to the MPLS-TP link to indicate they are traversing that interface. You can move the MPLS-TP link from one interface to another without reconfiguring all the MPLS-TP tunnels and LSPs that refer to the link. Link numbers a must be unique on the router or node.
Step 7	exit Example: Router(config-if)# exit	Exits interface configuration mode.
Step 8	exit Example: Router(config)# exit	Exits global configuration mode.
Step 9	show mpls tp link-numbers Example: Router# show mpls tp link-numbers	Displays the configured links.

Configuring an Access Interface

Procedure

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none">• Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	interface <i>type/num</i> Example: Router(config)# interface gigabitethernet 1/0	Specifies the interface and enters interface configuration mode.
Step 4	no ip address Example: Router(config-if)# no ip address	Specifies that there is no IP address assigned to the interface.
Step 5	negotiation auto Example: Router(config-if)# negotiation auto	Enables the autonegotiation protocol to configure the speed, duplex, and automatic flow control of the Gigabit Ethernet interface.
Step 6	service instance <i>id service-type</i> Example: Router(config)# service instance 1 ethernet	Configures an Ethernet service instance.
Step 7	encapsulation dot1q <i>vlan-id</i> second-dot1q {any / <i>vlan-id</i> / <i>vlan-id-vlan-id</i> [, <i>vlan-id-vlan-id</i>]} Example: Router(config-if)# encapsulation dot1q 2	Enables IEEE 802.1Q encapsulation of traffic on a specified subinterface in a VLAN.
Step 8	bridge-domain <i>vlan-id</i> [access dot1q [<i>tag</i>] / dot1q-tunnel] [broadcast] [ignore-bpdu-pid] [pvst-tlv <i>CE-vlan</i>] [increment] [lan-fcs] [split-horizon] Example: Router(config-if)# bridge-domain 1000	Places the interface in the same bridge domain as the VFI interface.
Step 9	exit Example: Router(config-if)# exit	Exits interface configuration mode.

Configuring the VFI in the PE

The virtual switch instance (VFI) specifies the VPN ID of a VPLS domain, the addresses of other PE routers in this domain, and the type of tunnel signaling and encapsulation mechanism for each peer. (This is where you create the VSI and associated VCs.) Configure a VFI as follows:



Note Only MPLS encapsulation is supported.

Procedure

	Command or Action	Purpose
Step 1	l2 vfi name manual Example: Router(config)# l2 vfi vfi17 manual	Enables the Layer 2 VFI manual configuration mode.
Step 2	vpn id <i>vpn-id</i> Example: Router(config-vfi)# vpn id 1000	Configures a VPN ID for a VPLS domain. The emulated VCs bound to this Layer 2 VRF use this VPN ID for signaling.
Step 3	bridge-domain <i>vlan-id</i> [access dot1q [<i>tag</i>] / dot1q-tunnel] [broadcast] [ignore-bpdu-pid] [pvst-tlv <i>CE-vlan</i>] [increment] [lan-fcs] [split-horizon] Example: Router(config-vfi)# bridge-domain 1000	Places the VFI in the same bridge domain as the access interface.
Step 4	neighbor <i>remote router id</i> [<i>vc-id-value</i>] {encapsulation mpls} [no-split-horizon] Example: Router(config-vfi)# neighbor 1.5.1.1 101 encapsulation mpls	Specifies the remote peering router ID and the tunnel encapsulation type or the pseudo wire property to be used to set up the emulated VC. Note Split horizon is the default configuration to avoid broadcast packet looping and to isolate Layer 2 traffic. Use the no-split-horizon keyword to disable split horizon and to configure multiple VCs per spoke into the same VFI. Note The optional VC ID value identifies the emulated VC between a pair of peering PE routers.
Step 5	shutdown Example: Router(config-vfi)# shutdown	Disconnects all emulated VCs previously established under the Layer 2 VFI and prevents the establishment of new attachment circuits.

	Command or Action	Purpose
		Note It does not prevent the establishment of new attachment circuits configured with the Layer 2 VFI using CLI.

Configuring a Virtual Loopback Interface

This task explains how to configure a basic loopback interface.

The IP address of a loopback interface must be unique across all routers on the network. It must not be used by another interface on the router, and it must not be used by an interface on any other router on the network.

Procedure

	Command or Action	Purpose
Step 1	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 2	interface loopback <i>interface-path-id</i> Example: Router#(config)# interface Loopback 3	Enters interface configuration mode and names the new loopback interface.
Step 3	ipv4 address <i>ip-address</i> Example: Router(config-if)# ipv4 address 172.18.189.38	Assigns an IP address and subnet mask to the virtual loopback interface using the ipv4 address configuration command.
Step 4	end Example: Router(config-if)# end	Saves configuration changes. When you issue the end command, the system prompts you to commit changes: Uncommitted changes found, commit them before exiting(yes/no/cancel)? [cancel]: <ul style="list-style-type: none"> • Entering yes saves configuration changes to the running configuration file, exits the configuration session, and returns the router to EXEC mode. • Entering no exits the configuration session and returns the router to EXEC mode without committing the configuration changes. • Entering cancel leaves the router in the current configuration session without exiting or committing the configuration changes.

	Command or Action	Purpose
		Note Use the commit command to save the configuration changes to the running configuration file and remain within the configuration session.
Step 5	show interfaces <i>type interface-path-id</i> Example: <pre>router# show interfaces Loopback 3</pre>	(Optional) Displays the configuration of the loopback interface.

Verifying the Configuration

You can use the following commands to verify your configuration:

- **show mpls l2transport vc**—Displays information about Any Transport over MPLS (AToM) virtual circuits (VCs) and static pseudowires that have been enabled to route Layer 2 packets on the router.
- **show mpls tp**—Displays information about Multiprotocol Label Switching (MPLS) transport profile (TP) tunnels.
- **show bfd summary**—Displays summary information for Bidirectional Forwarding Protocol (BFD).
- **show xconnect**—Displays information about xconnect attachment circuits and pseudowires.

You can use the following commands to debug your configuration:

- **debug mpls tp all**—Debug for all MPLS-TP information.
- **debug mpls tp cli**—Debug for MPLS-TP CLI
- **debug mpls tp error**—Debug for MPLS-TP errors
- **debug mpls tp event**—Debug for MPLS events
- **debug mpls tp fault-oam**—Debug for Fault-OAM
- **debug mpls tp ha**—Debug for High availability
- **debug mpls tp init**—Debug for MPLS-TP initialization
- **debug mpls tp link-management**—Debug for link management
- **debug mpls tp link-num**—Debug for link number database
- **debug mpls tp lsp-db**—Debug for LSP database
- **debug mpls tp lsp-ep**—Debug for endpoint LSP configuration and operation
- **debug mpls tp lsp-mp**—Debug for midpoint LSP configuration and operation
- **debug mpls tp mem**—Debug for memory allocation and usage
- **debug mpls tp tun-db**—Debug for the tunnel database
- **debug mpls tp tunnel**—Debug for tunnel configuration and operation

Configuration Examples

PE Configuration

```

!
mpls label range 1001 4000 static 16 1000
mpls tp
  router-id 10.10.10.10
!
bfd-template single-hop testbfd
interval microseconds min-tx 50000 min-rx 50000 multiplier 3
!
! Output link
interface GigabitEthernet0/0/0
  no ip address
  negotiation auto
  mpls tp link 2 tx-mac 88f0.7768.2300
!

! Output link
interface GigabitEthernet0/2/0
  no ip address
  negotiation auto
  mpls tp link 1 tx-mac 88f0.7768.2310
!
!
interface Tunnel-tp1
ip unnumbered Loopback0
  no keepalive
  tp source 10.10.10.10 global-id 0
  tp destination 192.168.1.1 global-id 0
  bfd testbfd
  working-lsp
    out-label 100 out-link 1
    in-label 200
    lsp-number 0
  protect-lsp
    out-label 300 out-link 2
    in-label 400
    lsp-number 102
!
!
pseudowire-class myclass
  encapsulation mpls
  preferred-path interface Tunnel-tp1
!
!
!VFI definition
l2 vfi VPLS manual
  vpn id 1000
  bridge-domain 1000
  neighbor 192.168.1.1 pw-class myclass
!
!
interface Loopback0
  ip address 10.10.10.10 255.255.255.255
!
! Access interface
interface GigabitEthernet0/1/0
  no ip address
  negotiation auto

```

```

service instance 1 ethernet
  encapsulation dot1q 2
  bridge-domain 1000
!
```

P Configuration (Midpoint)

```

!
interface loopback 0
ip address 9.9.9.9 255.255.255.255
!
mpls label range 1001 4000 static 16 1000
mpls t
router-id 9.9.9.9
!
mpls tp lsp source 10.10.10.10 tunnel-tp 1 lsp working destination 192.168.1.1 tunnel-tp 1
  forward-lsp
    in-label 100 out-label 300 out-link 1
  reverse-lsp
    in-label 400 out-label 200 out-link 2
!
out-link 1 connected to 192.168.1.1
out-link 2 connected to 10.10.10.10
```

Feature Information for VPLS Configuration over MPLS-TP

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 1: Feature Information for VPLS Configuration over MPLS-TP

Feature Name	Release	Feature Information
VPLS Configuration over MPLS-TP	IOS XE 3.5	This feature was introduced on the Cisco RSP1 Module in this release.
VPLS Configuration over MPLS-TP	IOS XE 3.13	This feature was introduced on the Cisco RSP2 Module in this release.
VPLS Configuration over MPLS-TP	IOS XE 3.16	This feature was introduced on the Cisco RSP3 Module in this release.
Feature Name	Release	Feature Information
VPLS Configuration over MPLS-TP	IOS XE 3.18SP	This feature was introduced on the Cisco NCS 4200 Series.