



Network Virtualization Configuration Guide, Cisco IOS XE 17 (Cisco NCS 4200 Series)

[Overview](#) 2

Revised: October 11, 2023

Overview

The Satellite Network Virtualization (nV) feature allows you to configure remote routers to act as remote virtual switch interfaces on the ASR 9000. IOS XE Release 3.8 introduces support for nV mode on the Cisco ASR 903 Router, allowing it to act as a satellite nV device, controlled by the ASR 9000 using the IOS XR CLI.

The Satellite Network Virtualization (nV) feature allows you to configure remote routers to act as remote virtual switch interfaces. nV mode allows the router to act as a satellite nV device, controlled using the CLI.

Limitations

The following limitations apply when enabling nV satellite mode:

- An in-service software upgrade (ISSU) is not supported while the router is acting as an nV satellite device.
- RSP redundancy is not supported while the router is acting as a satellite nV device.
- Online Insertion and Removal (OIR) of interface modules (IMs) is not supported when the router is operating in nV satellite mode.
- Supported connections to the satellite host include
 - Gigabit Ethernet interfaces
 - Ethernet transported over optical interfaces
 - 10 Gigabit Ethernet interfaces (slots 1 and 2 only)Other connection types are not supported.
- Local switching on the satellite device is not supported. The packets are always sent to the host for layer 2 and layer 3 switching.
- Network clocking is not supported when the router is operating in nV satellite mode.
- Reverting from a satellite mode image to the base image requires that you download the original image using TFTP; an inband download is not supported. For more information, see *Removing a Satellite Image*.

Installing a Satellite Image

Follow these steps to install a satellite nV image on the Cisco NCS 4200 Series Router:

Procedure

- Step 1** Download a Cisco NCS 4200 Series satellite nV image from Cisco.com and copy the image to a TFTP server.
- Step 2** Create a console connection to the management port of the Cisco NCS 4200 Series. For more information about creating a console connection, see *Cisco NCS 4200 Series Router Hardware Installation Guide*.
- Step 3** Copy nV compatible binary image to flash or bootflash.

```
Router# copy tftp://10.10.10.10//tftpboot//ncs4200_sat-universalk9_npe.03.08.00.S.153-1.S.bin bootflash:
```

Step 4 Set the configuration register to 0x2042.

```
Router(config)# config-register 0x2042
```

Step 5 Erase the existing configuration.

```
Router# write erase
```

Step 6 Specify the boot image.

```
Router(config)# boot system bootflash:ncs4200_sat-universalk9_npe.03.08.00.S.153-1.S.bin
```

Step 7 Save the configuration.

```
Router# copy running-configuration startup-configuration
```

Step 8 Reload the router

```
Router(config)# reload
```

The system boots in nV mode and is detectable by the nV host.



Note You can use the **show nv satellite status** command to verify the image version.

Removing a Satellite Image

Restoring the Cisco NCS 4200 Series Router to a normal IOS XE image requires that you load an image in ROMmon mode using trivial file transfer protocol (TFTP). For instructions on how to remove a satellite image, please contact Cisco support.

Configuring Satellite Mode Sequence

When booting to a satellite nV image, the router

- enables Ethernet ports in IEEE mode.
- enables inter-chassis links (IC links).
- uses Satellite Discovery and Control (SDAC) to establish a connection to the host nV device.
- establishes a control path between the host nV device and the router.

Once the connection is established, the ASR 9000 provides an IP address, software, and configuration commands to the Cisco ASR 903 Router. For instructions on configuring Satellite nV on the ASR 9000 and managing satellite nV devices, see *Satellite Network Virtualization (nV) System for Cisco ASR 9000 series*.

Once the connection is established, the ASR 9000 provides an IP address, software, and configuration commands to the Cisco NCS 4200 Series Router. For instructions on configuring Satellite nV on the ASR 9000 and managing satellite nV devices, see *Satellite Network Virtualization (nV) System for Cisco ASR 9000 series*.

Upgrading the Satellite Image

After you connect the satellite to the host, the host verifies the satellite software version. If there is a version mismatch, the host displays a syslog notification indicating that the satellite device requires an image upgrade. To upgrade the image using the host satellite device, see configuring the *Satellite Network Virtualization (nV) System for Cisco ASR 9000 series*.

Use the **show nv satellite status** command to verify the image version.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2020–2022 Cisco Systems, Inc. All rights reserved.



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters
CiscoSystems(USA)Pte.Ltd.
Singapore

Europe Headquarters
CiscoSystemsInternationalBV
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.