

Port-Shaper and LLQ in the Presence of EFPs

The Port-Shaper and LLQ in the Presence of EFPs feature allows network designers to configure port and class policies on ports that contain Ethernet Flow Points (EFPs). These policies support Low Latency Queueing (LLQ) and traffic prioritization across the EFPs.

- Finding Feature Information, on page 1
- Restrictions for Port-Shaper and LLQ in the Presence of EFPs, on page 1
- Information About Port-Shaper and LLQ in the Presence of EFPs, on page 2
- How to Configure Port-Shaper and LLQ in the Presence of EFPs, on page 2
- Configuration Examples for Port-Shaper and LLQ in the Presence of EFPs, on page 10
- Additional References, on page 12

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see Bug Search Tool and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Restrictions for Port-Shaper and LLQ in the Presence of EFPs

- If you configure port level shaper with the policy applied at EFP level then port shaper does not work. However, 3 level HQoS policy with port and logical shaper can be applied at the EFP level. Logical shaper configured at logical level does work but port shaper does not work.
- If you configure a class-based HQOS or LLQ policy on the port, you cannot configure service-policies on Ethernet Flow Points (EFPs). The only exception to this is the class-default shaper policy and match EFP policy.
- If you configure a class-based policy on the port, you cannot configure service-policies on EFPs.
- If you configure a class-default port-shaper based policy on the port, you can configure service-policy on EFPs.

• Usage of bandwidth remaining percentage (BRP) in the absence of priority class, allocates the available bandwidth in an iterative way. For example, the bandwidth is allocated for the first BRP class as per the percentage of share configured in the respective class-map and the remaining bandwidth is iteratively allocated to all other BRP classes until the bandwidth is exhausted.

Information About Port-Shaper and LLQ in the Presence of EFPs

Ethernet Flow Points and LLQ

An Ethernet Flow Point (EFP) is a forwarding decision point in the provider edge (PE) router, which gives network designers flexibility to make many Layer 2 flow decisions within the interface. Many EFPs can be configured on a single physical port. (The number varies from one device to another.) EFPs are the logical demarcation points of an Ethernet virtual connection (EVC) on an interface. An EVC that uses two or more User-Network Interfaces (UNIs) requires an EFP on the associated ingress and egress interfaces of every device that the EVC passes through.

The Egress HQoS with Port Level Shaping feature allows network designers to configure port and class policies on ports that contain EFPs. These policies support Low Latency Queueing (LLQ) and traffic prioritization across the EFPs.

For information on how to configure LLQ, see the QoS Congestion Management Configuration Guide.

How to Configure Port-Shaper and LLQ in the Presence of EFPs

To configure the Port-Shaper and LLQ in the Presence of EFPs feature, you first create either a hierarchical or flat policy map that supports Low Latency Queueing (LLQ), which you then attach to an EFP interface.

Configuring Hierarchical Policy Maps

To configure hierarchical policy maps, you create child policies which you then attach to a parent policy. The parent policy is then attached to an interface.

Procedure

enable
Example:
Device> enable
Enables privileged EXEC mode.
• Enter your password if prompted.
configure terminal Example:

	Device# configure terminal
	Enters global configuration mode.
Step 3	policy-map policy-map-name
	Example:
	Device(config)# policy-map child-llq
	Creates or modifies the child policy and enters QoS policy-map configuration mode.
	• child-llq is the name of the child policy map.
Step 4	class class-map-name
	Example:
	Device(config-pmap)# class precedenc-1
	Assigns the traffic class you specify to the policy map and enters QoS policy-map class configuration mode.
	• precedenc-1 is the name of a previously configured class map and is the traffic class for which you want to define QoS actions.
Step 5	set cos value
	Example:
	Device(config-pmap-c)# set cos 5
	(Optional) Sets the Layer 2 class of service (CoS) value of an outgoing packet.
	• The value is a specific IEEE 802.1Q CoS value from 0 to 7.
Step 6	bandwidth percent percent
	Example:
	Device(config-pmap-c)# bandwidth percent 20
	(Optional) Specifies a bandwidth percent for class-level queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic) to allocate to nonpriority queues.
Step 7	exit
	Example:
	Device(config-pmap-c)# exit
	Exits QoS policy-map class configuration mode.
Step 8	class class-map-name
	Example:
	<pre>Device(config-pmap)# class precedenc-2</pre>
	Assigns the traffic class you specify to the policy map and enters QoS policy-map class configuration mode.

 precedenc-2 is the name of a previously configured class map and is the traffic class for which you want to define QoS actions.

Step 9 bandwidth percent percent

Example:

Device(config-pmap-c) # bandwidth percent 80

(Optional) Specifies a bandwidth percent for class-level queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic) to allocate to nonpriority queues.

Step 10 exit Example: Device (config-pmap-c) # exit Exits QoS policy-map class configuration mode. Step 11 policy-map policy-map-name Example: Device(config-pmap)# policy-map parent-llq Creates or modifies the parent policy. • parent-llq is the name of the parent policy map. Step 12 class class-default Example: Device (config-pmap) # class class-default Configures or modifies the parent class-default class and enters QoS policy-map class configuration mode. • You can configure only the class-default class in a parent policy. Do not configure any other traffic class. Step 13 service-policy policy-map-name Example: Device(config-pmap-c)# service-policy child-llq Applies the child policy to the parent class-default class. • child-llq is the name of the child policy map configured in step 1.

Configuring Class-default Port-Shaper Policy Maps

To configure hierarchical policy maps, first create the child policies and then attach it to a parent policy. The parent policy must be attached to an interface.

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 3	policy-map policy-map-name	Creates or modifies the child policy and enters QoS policy-map configuration mode.
	Example:	• child-llq is the name of the child policy
	Device(config)# policy-map child-llq	map.
Step 4	class class-default	Configures or modifies the parent class-default
	Example:	class and enters QoS policy-map class configuration mode.
	Device(config-pmap)# class class-default	• You can configure only the class-default class in a parent policy. Do not configure any other traffic class.
Step 5	shape-average shape-value	Configures a shape entity with a Comitted
	Example:	Information Rate of 200 Mb/s.
	Device(config-pmap-c)#shape average 200000000	
Step 6	exit	Exits QoS policy-map class configuration mode.
	Example:	
	Device(config-pmap-c)# exit	

Procedure

Configuring Port-Shaper Policy Maps

Procedure

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	• Enter your password if prompted.
	Device> enable	

I

	Command or Action	Purpose	
Step 2	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 3	policy-map policy-map-name	Creates or modifies the child policy and enters	
	Example:	QoS policy-map configuration mode.	
	Device(config)# policy-map def		
Step 4	class class-default	Assigns the traffic class you specify to the	
	Example:	policy map and enters QoS policy-map class configuration mode.	
	Device(config-pmap)# class class-default		
Step 5	shape-average shape-value	Configures a shape entity with a Comitted	
	Example:	Information Rate of 200 Mb/s.	
	Device(config-pmap-c)#shape average 200000000		
Step 6	service-policy policy-map-name	Applies the child policy to the parent	
	Example:	class-default class.	
	<pre>Device(config-pmap-c)# service-policy child-llq</pre>	 child-llq is the name of the child policy map configured in Configuring Class-default Port-Shaper Policy Maps, on page 4. 	

Configuring an LLQ Policy Map

Procedure

Step 1	enable Example:
	Device> enable Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	configure terminal Example:
	Device# configure terminal

	Enters global configuration mode.
Step 3	policy-map policy-map-name
	Example:
	Device(config)# policy-map llq-flat
	Creates a policy and enters QoS policy-map configuration mode.
Step 4	class class-map-name
	Example:
	Assigns the traffic class you specify to the policy map and enters policy-map class configuration mode.
Step 5	priority
	Example:
	Device(config-pmap-c)# priority
	Configures LLQ, providing strict priority queueing (PQ) for class-based weighted fair queueing (CBWFQ).
Step 6	exit
	Example:
	Device(config-pmap-c)# exit
	Exits QoS policy-map class configuration mode.
Step 7	class class-map-name
	Example:
	Assigns the traffic class you specify to the policy map and enters QoS policy-map class configuration mode.
Step 8	shape average value
	Example:
	Device(config-pmap-c)# shape average 200000000
	Configures a shape entity with a Comitted Information Rate of 200 Mb/s.
Step 9	exit
	Example:
	Device(config-pmap-c)# exit
	Exits QoS policy-map class configuration mode.
Step 10	class class-map-name
	Example:
	Assigns the traffic class you specify to the policy map and enters QoS policy-map class configuration mode.
Step 11	bandwidth percent
	Example:

Device(config-pmap-c)# bandwidth 4000000

(Optional) Specifies a bandwidth percent for class-level queues to be used during congestion to determine the amount of excess bandwidth (unused by priority traffic) to allocate to non-priority queues.

Step 12 exit

Example:

Device(config-pmap-c) # exit

Exits QoS policy-map class configuration mode.

Configuring Port Level Shaping on the Main Interface with Ethernet Flow Points

To configure port level shaping on the main interface with EFPS, first you enable the autonegotiation protocol on the interface, then you attach a policy map to the interface and finally you configure the Ethernet service instance.

	Procedure
Step 1	enable
	Example:
	Device> enable
	Enables privileged EXEC mode.
	• Enter your password if prompted.
Step 2	configure terminal
	Example:
	Device# configure terminal
	Enters global configuration mode.
Step 3	interface type number
	Example:
	Device(config)# interface GigabitEthernet 0/0/1
	Configures an interface type and enters interface configuration mode.
	• Enter the interface type number.
Step 4	no ip address

Example:

Device(config-if) # no ip address

Disables IP routing on the interface.

Step 5 negotiation auto

Example:

Device(config-if) # negotiation auto

Enables the autonegotiation protocol to configure the speed, duplex, and automatic flow control of the Gigabit Ethernet interface.

Step 6 service-policy output policy-map-name

Example:

Device(config-if) # service-policy output parent-llq

Specifies the name of the policy map to be attached to the input or output direction of the interface.

• You can enter the name of a hierarchical or a flat policy map.

Step 7	service instance <i>id</i> ethernet
	Example:
	Device(config-if)# service instance 1 ethernet
	Configures an Ethernet service instance on an interface and enters service instance configuration mode.
Step 8	encapsulation dot1q vlan-id
	Example:
	Device(config-if-srv)# encapsulation dot1q 100
	Defines the matching criteria to map 802.1Q frames' ingress on an interface to the service instance.
Step 9	bridge-domain bridge-domain-id
	Example:
	Device(config-if-srv)# bridge-domain 100
	Binds the bridge domain to the service instance.
Step 10	exit
	Example:
	Device(config-if-serv)# exit
	Exits service instance configuration mode.
Step 11	service instance <i>id</i> ethernet
	Example:

	Device(config-if)# service instance 2 ethernet
	Configures an Ethernet service instance on an interface and enters service instance configuration mode.
Step 12	encapsulation dot1q vlan-id
	Example:
	Device(config-if-srv)# encapsulation dot1q 101
	Defines the matching criteria to map 802.1Q frames' ingress on an interface to the service instance.
Step 13	bridge-domain bridge-domain-id
	Example:
	Device(config-if-srv)# bridge-domain 101
	Binds the bridge domain to the service instance.
Step 14	exit
	Example:
	Device(config-if-srv)# exit
	Exits QoS policy-map class configuration mode.
Step 15	end
	Example:
	Device(config-if)# end
	(Optional) Exits interface configuration mode.

Configuration Examples for Port-Shaper and LLQ in the Presence of EFPs

Example: Configuring Hierarchical QoS Port Level Shaping on the Main Interface with EFPs

The following example shows how to configure hierarchical QoS port level shaping on a main physical interface to support traffic prioritization and Low Level Queueing across all EFPs configured on the interface:

```
policy-map parent-llq
class class-default
  service-policy child-llq
```

```
policy-map child-llq
 class precedenc-1
 set cos 5
 bandwidth percent 20
 class precedenc-2
 bandwidth percent 80
interface GigabitEthernet 0/0/1
no ip address
negotiation auto
 service-policy output parent-llq
 service instance 1 ethernet
 encapsulation dotlg 100
 bridge-domain 100
 Т
 service instance 2 ethernet
 encapsulation dot1q 101
 bridge-domain 101
```



Note

Only match EFP and match qos-group is supported on RSP3 in egress policy map.

Configuration Example: Class-default Port-Shaper and EFP policy

The following example shows how to configure class-default port-shaper and EFP policy, where the main interface can have the class-default shaper policy and EFP can have the HQOS policies.

```
policy-map co12
class class-default
shape average 50m
policy-map def
class class-default
shape average 500m
service-policy co12
```

Example: Configuring Port Level Shaping on the Main Interface with EFPs

The following example shows how to configure port level shaping on a main physical interface to support traffic prioritization and Low Level Queueing across all Ethernet Flow Points (EFPs) configured on the interface:

```
policy-map llq_flat
class dscp-af1
priority
class dscp-af2
shape average 200000000
class dscp-af3
bandwidth 400000
interface GigabitEthernet 0/0/1
no ip address
```

```
negotiation auto
service-policy output llq_flat
service instance 1 ethernet
encapsulation dotlq 100
bridge-domain 100
!
service instance 2 ethernet
encapsulation dotlq 101
bridge-domain 101
```

Additional References

Related Documents

Related Topic	Document Title
Cisco IOS commands	Cisco IOS Master Commands List, All Releases
QoS commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	Cisco IOS QoS Command Reference
Policing and shaping	"Policing and Shaping Overview" module
Class maps	"Applying QoS Features Using the MQC" module
Policy maps	"Applying QoS Features Using the MQC" module
Low Latency Queueing	QoS Congestion Management Configuration Guide

Standards and RFCs

Standard	Title
No new or modified standards are supported, and support for existing standards has not been modified.	

MIBs

МІВ	MIBs Link
No new or modified MIBs are supported, and support for existing MIBs has not been modified.	To locate and download MIBs for selected platforms, Cisco IOS XE software releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

Technical Assistance

Description	Link
The Cisco Support and Documentation website provides online resources to download documentation, software, and tools. Use these resources to install and configure the software and to troubleshoot and resolve technical issues with Cisco products and technologies. Access to most tools on the Cisco Support and Documentation website requires a Cisco.com user ID and password.	

I