



Programmability Command Reference for Cisco NCS 5500 Series Routers

First Published: 2024-03-12

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

PREFACE

[Preface](#) v

[Communications, Services, and Additional Information](#) v

CHAPTER 1

[grpc-commands](#) 1

[port \(gRPC\)](#) 2

[gnmi](#) 3

[grpc](#) 5

[grpc aaa accounting history-memory](#) 7

[grpc aaa accounting queue-size](#) 8

[grpc certificate common-name](#) 9

[gnsi load service authorization policy](#) 10

[grpc gnsi service certz ssl-profile-id](#) 11

[grpc max-concurrent-streams](#) 12

[grpc remote-connection disable](#) 13

[script exec](#) 14

[show gnsi acctz statistics](#) 16

[show grpc certificate](#) 21

[show gnsi service authorization policy](#) 23

[show tech-support script](#) 25

CHAPTER 2

[YANG Commands](#) 27

[yang-server module-set](#) 28



Preface

- [Communications, Services, and Additional Information](#), on page v

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business results you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco DevNet](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



grpc-commands

- [port \(gRPC\), on page 2](#)
- [gnmi, on page 3](#)
- [grpc, on page 5](#)
- [grpc aaa accounting history-memory, on page 7](#)
- [grpc aaa accounting queue-size, on page 8](#)
- [grpc certificate common-name, on page 9](#)
- [gnsi load service authorization policy, on page 10](#)
- [grpc gnsi service certz ssl-profile-id, on page 11](#)
- [grpc max-concurrent-streams, on page 12](#)
- [grpc remote-connection disable, on page 13](#)
- [script exec, on page 14](#)
- [show gnsi acctz statistics, on page 16](#)
- [show grpc certificate, on page 21](#)
- [show gnsi service authorization policy, on page 23](#)
- [show tech-support script, on page 25](#)

port (gRPC)

To set custom ports for gNMI, gRIBI, and P4RT services within the defined range, including default IANA ports like 9339, 9340, and 9559 (respectively), use the **port** command under the service submode.

port *portnum*

Syntax Description

portnum

Specifies the server listening port for the gRPC service.

- gNMI service port: default: 9339, range: 57344-57999
- gRIBI service port: default: 9340, range: 57344-57999
- p4RT service port: default: 9559, range: 57344-57999

Command Default

None

Command History

Release

Modification

Release 24.1.1

This command was introduced.

Usage Guidelines

Disabling the **port** command will cause the service to use the default or IANA port.

Task ID

Task ID

Operations

config-services read,
write

Examples

The following example shows how to configure a port for any available gRPC service (gNMI, P4RT, gRIBI) :

For P4RT service:

```
Router(config-grpc) #p4rt
Router(config-grpc-p4rt) #port 9559
Router(config-grpc-p4rt) #commit
```

Verify the port number.

```
Router#show running-config grpc
grpc
  p4rt
    port 9559
!
```


gnmi

To create a gRPC listener with the default or IANA ratified gNMI port of 9339, use the **gnmi** command in Global Configuration Mode.

gnmi port *portnum*

Syntax Description	<i>portnum</i> Specifies the server listening port for the gRPC service. • gNMI service port: default: 9339, range: 57344-57999	
Command Default	None	
Command Modes	Global Configuration Mode	
Command History	Release	Modification
	Release 24.1.1	This command was introduced.
Usage Guidelines	Unconfiguring gNMI will disable requests on port 9339. The allowed ports within this range are 9339 (IANA ratified port) and 57344-57999 (Linux application port range)	
Task ID	Task ID	Operations
	config-services	read, write

Examples

The following example shows how to configure gNMI as a submode under gRPC and committing this configuration would create a gRPC listener with the default or IANA ratified gNMI port of 9339.

```
Router(config-grpc) gnmi
Router(config-grpc-gnmi) commit
```

Verify the submode configuration.

```
Router#show running-config grpc
grpc
  gnmi
!
```

The **port** command under gNMI submode allows the port to be modified in the port range or IANA ratified port.

```
Router(config-grpc) #gnmi
Router(config-grpc-gnmi) #port 9339
Router(config-grpc-gnmi) #commit
```

Verify the port number.

```
Router#show running-config grpc
grpc
```

```
gnmi
  port 9339
!
```

gRPC

To configure network devices and view operational data, use the **gRPC** command in the XR Config mode. To remove the **gRPC** protocol, use the **no** form of this command.

gRPC { **address-family** | **certificate-authentication** | **dscp** | **local-connection** | **max-concurrent-streams** | **max-request-per-user** | **max-request-total** | **max-streams** | **max-streams-per-user** | **tls-max-version** | **tls-min-version** | **no-tls** | **tlsv1-disable** | **tls-cipher** | **tls-mutual** | **tls-trustpoint** | **service-layer** | **vrf** }

Syntax Description	
address-family	Specifies the address family identifier type.
certificate-authentication	It enables certificate-based authentication.
dscp	Specifies QoS marking DSCP on transmitted gRPC.
local-connection	It enables gRPC server over unix socket.
max-concurrent-streams	Specifies the limit on the maximum concurrent streams per gRPC connection to be applied on the server.
max-request-per-user	Specifies the maximum concurrent requests per user.
max-request-total	Specifies the maximum concurrent requests in total.
max-streams	Specifies the maximum number of concurrent gRPC requests. The maximum subscription limit is 128 requests. The default is 32 requests.
max-streams-per-user	Specifies the maximum concurrent gRPC requests for each user. The maximum subscription limit is 128 requests. The default is 32 requests.
tls-max-version	Specifies the maximum version that TLS supports. It supports 1.0, 1.1, 1.2, and 1.3
tls-min-version	Specifies the minimum version that TLS supports. It supports 1.0, 1.1, 1.2, and 1.3
no-tls	It disable transport layer security (TLS). The TLS is enabled by default.
tlsv1-disable	It disable TLS version 1.0
tls-cipher	It enable the gRPC TLS cipher suites.
tls-mutual	Specifies the mutual authentication.
tls-trustpoint	It configure trustpoint.
service-layer	It enable the gRPC service layer configuration.
vrf	It enable server vrf.

Command Default None

Command Modes XR Config mode

Command History	Release	Modification
	Release 24.1.1	This command was introduced.

Usage Guidelines This command is supported on Cisco IOS XR 64-bit OS.

Task ID	Task ID	Operations
	config-services	read

The following example shows how to enable gRPC over an HTTP/2 connection:

```
Router#configure
Router(config)#grpc
Router(config-grpc)#port <port-number>
```

grpc aaa accounting history-memory

To configure the maximum memory allocated for cached accounting history records, use the **grpc aaa accounting history-memory** command in the XR Config mode.

This command should be used in conjunction with the **queue-size** parameter to effectively limit the EMSD memory used by cached accounting history records. The approximate worst case memory usage would be (N+1)* history-memory, where N is the number of collectors connected.

grpc aaa accounting history-memory *size*

Syntax Description	<i>size</i> Specifies the maximum memory allocated for cached accounting history records.					
Command Default	The default size of the history memory is 40 MB. The size range is 1-400 MB.					
Command Modes	XR Config mode					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>Release 24.4.1</td><td>The command was introduced.</td></tr></table>		Release	Modification	Release 24.4.1	The command was introduced.
Release	Modification					
Release 24.4.1	The command was introduced.					
Usage Guidelines	None					
Task ID	<table><tr><th>Task ID</th><th>Operation</th></tr><tr><td>config-services</td><td>read, write</td></tr></table>		Task ID	Operation	config-services	read, write
Task ID	Operation					
config-services	read, write					

This example configures the maximum memory allocated for cached accounting history records to the specified size.

```
Router(config)#grpc aaa accounting history-memory 20
```

This example displays the memory configuration specified in the previous example.

```
Router(config)#show
Tue Jul 23 06:12:38.693 UTC
!! Building configuration...
!! IOS XR Configuration 24.4.1.17I
grpc
  aaa accounting history-memory 20
!
```

```
RP/0/RP0/CPU0:ios(config)#commit
Tue Jul 23 06:12:41.336 UTC
Router(config)#
```

Use the **show gnsi acctz statistics** command to display the maximum records in the history memory with the maximum queue size configured using the **grpc aaa accounting queue-size** command.

grpc aaa accounting queue-size

To configure the number of accounting records in a queue, use the **grpc aaa accounting queue-size** command in the XR Config mode.

grpc aaa accounting queue-size *size*

Syntax Description	<i>size</i>	Specifies the number of accounting history records in a queue. The default value is 40, and it ranges from 1—512.
Command Default	None	
Command Modes	Global Configuration mode	
Command History	Release	Modification
	Release 24.3.1	The command was introduced.
Usage Guidelines	None	
Task ID	Task ID	Operation
	config-services	read, write

This example configures the maximum size for history record processing queues to the specified value.

```
Router# configure
Router(config)# grpc aaa accounting queue-size 30
Router(config)# end
```

grpc certificate common-name

To allow the router (tunnel client) to dial out to a collector (tunnel server), use the **grpc** command in the XR Config mode. To remove the **gRPC** service, use the **no** form of this command.

grpc certificate common-name *WORD*

Syntax Description	<i>WORD</i>	Specifies the common name when certificate is generated, default: ems.cisco.com .
Command Default	None	
Command Modes	XR Config mode	
Command History	Release	Modification
	Release 24.1.1	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	config-services	read, write
Examples	<p>The following example shows how to specify a common-name:</p> <pre>Router(config)#grpc Router(config-grpc)#certificate common-name Router(config-grpc)#commit</pre>	

gnsi load service authorization policy

To instruct the router to load the service authorization policy file into its memory and update the policy, use the **gnsi load service authorization policy** command in Global Configuration Mode.

gnsi load service authorization policy *file_path*

Syntax Description	<i>file-path</i> Specifies the path of the policy file.				
Command Default	Enabled, by default				
Command Modes	Global Configuration Mode				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Release 7.11.1</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Release 7.11.1	This command was introduced.
Release	Modification				
Release 7.11.1	This command was introduced.				
Usage Guidelines	A policy file which has no specified or the policy is invalid, the default behavior will transition to the zero-policy behavior. Zero-policy allows all gRPC services to all the users if their profiles are configured.				
Task ID	<table> <tr> <th>Task ID</th><th>Operation</th></tr> <tr> <td>config-services</td><td>read, write</td></tr> </table>	Task ID	Operation	config-services	read, write
Task ID	Operation				
config-services	read, write				

This example shows how to activate the authorization policy test.json in the router.

```
Router(config)#gnsi load service authorization policy /disk0:/test.json
Successfully loaded policy
```


grpc gnsi service certz ssl-profile-id

To instruct the router to load the certz.proto, use the **grpc gnsi service certz ssl-profile-id** command in Global Configuration Mode. To disable the SSL profiles configured with certz.proto, use the no form of the command.

grpc gnsi service certz ssl-profile-id *ssl-profile name*

Syntax Description	<i>ssl-profile name</i> Specifies the SSL-profile name for which certz. proto needs to be activated.	
Command Default	None	
Command Modes	Global Configuration Mode	
Command History	Release	Modification
	Release 24.1.1	This command was introduced.
Usage Guidelines	If Certz. proto is not active, then gNOI cert.proto is taken into consideration. If niether certz.proto nor cert.proto is active, then TLS trustpoint's data is considered.	
Task ID	Task ID	Operation
	config-services	read, write

This example shows how to activate the certz.proto in the router.

```
Router(config)#grpc gnsi service certz ssl-profile-id gNxI
Router(config)#commit
```

grpc max-concurrent-streams

To specify a limit on the number of concurrent streams per gRPC connection to be applied on the server, use the **grpc max-concurrent-streams** command in the Global Configuration mode. To restore the default value, use the **no** form of this command.

grpc max-concurrent-streams limit

Syntax Description	max-concurrent-streams limit Specifies the limit on the number of concurrent streams per gRPC connection to be applied on the server. The range is from 1 to 128. The command default is 32.	
Command Default	By default, the maximum concurrent streams per gRPC connection is 32.	
Command Modes	Global Configuration mode	
Command History	Release	Modification
	Release 24.1.1	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	config-services	read, write
Examples	<p>The following example shows how to set the limit of the number of concurrent streams per gRPC connection to 40:</p> <pre>Router#configure Router(config)#grpc max-concurrent-streams 40</pre>	

grpc remote-connection disable

To disable TCP, use the **grpc remote-connection disable** command in Global Configuration mode.

grpc remote-connection disable

Syntax Description	<i>grpc remote-connection disable</i> disables TCP.
---------------------------	---

Command Default	Enabled, by default
------------------------	---------------------

Command Modes	Global Configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Release 25.2.1	The command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operation
	config-services	read

This example displays the disabling of TCP on the router:

```
Router# configure
Router(config)# grpc
Router(config-grpc)# remote-connection disable
```

script exec

To execute a script provided by Cisco, use the **script exec** command in XR EXEC mode.

```
script exec { auto-update file-name remote-server-path condition [ manual | on-run | schedule ] |
file-name }
```

Syntax Description

auto-update	It enables routers to automatically update the local copy of the scripts with the latest copy of the scripts on the server.
manual	It enables routers to update the scripts at any specific time.
on-run	It enables routers to update the scripts during run time. Only the exec scripts support the on-run option.
schedule	It enables routers to update the scripts at a scheduled time. The schedule option does not support SCP protocol.
file-name	Specifies the file name of the script file. The script file must be in .py format.

Command Default

None

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.5.1	This command was introduced.

Usage Guidelines

The script EXEC command opens the script utility, which allows you to execute Cisco-supplied scripts. The script utility can read standard terminal input from the user if the script you run requires input from the user.



Note The script utility is designed to run only Cisco-supplied scripts. You cannot execute script files that lack Cisco signatures or that have been corrupted or modified.

When you run the script, the script is downloaded and the checksum is automatically configured on the router.

- If on-run option is configured, running the script run command downloads the script.
- If manual option is configured, then you must run script update Exec command.
- If schedule option is selected, then the script is automatically updated after the specified interval.

Task ID

Task ID	Operations
config-services	read, write

The following example displays sample3.py script is automatically updated from the remote server at <http://10.23.255.205>:

```
Router# configure  
Router(config)# script exec auto-update sample3.py http://10.23.255.205 condition manual
```

show gnsi acctz statistics

To display the detailed statistics for GNSI Acctz accounting, use the **show gnsi acctz statistics** command in the XR EXEC mode.

This command provides these information:

- per service counter
- drop counter
- rate of accounting events
- history
- connected collectors
- collector per service record counters

show gnsi acctz statistics

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 24.3.1	The command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	config-services	read, write

This example displays detailed statistics for GNSI Acctz accounting with the maximum queue size specified in the [gRPC aaa accounting queue-size](#) command configuration examples respectively.

```
Router#show gnsi acctz statistics
Tue Jul 23 05:59:28.755 UTC
Acctz History Buffer:
  Total Records                : 80029
  Total History Truncation     : 0
  Grpc Service Records:
    GNMI                       : 80002
    GNOI                       : 0
    GNSI                       : 4
    GRIBI                     : 0
    P4RT                      : 0
```

```

        Unspecified                : 0
    Cmd Service Records:
        Shell                      : 0
        Cli                       : 23
        Netconf                   : 0
        Unspecified               : 0
    History snapshot:
        Max Memory Size           : 20 MB
        Memory Used               : 0 MB
        Max Number Of Records     : 30
        Records Used              : 30
    gRPC Accounting Queue:
    Grpc services:
        GNMI                      : 80002 sent, 0 dropped, 0 truncated
        GNOI                     : 0 sent, 0 dropped, 0 truncated
        GNSI                     : 4 sent, 0 dropped, 4 truncated
        GRIBI                    : 0 sent, 0 dropped, 0 truncated
        P4RT                     : 0 sent, 0 dropped, 0 truncated
        Unspecified              : 0 sent, 0 dropped, 0 truncated
    Queue Rate:
        Input                     : 80000
        Output                    : 80000
        Drop                      : 0
    Stats:
        Queue Buffer Used         : 0 MB
        Queue Enqueue            : 80006
        Queue Dequeue            : 80006
        Queue Drops              : 0
        Queue Max Time           : 14311 usec
        Queue Min Time           : 1 usec
        Queue Avg Time           : 504 usec
    Channel Stats:
        Queue Channel Size       : 512
        Queue Channel Length     : 0
        Queue Inuse Size         : 0
        Queue Size               : 30
        Queue Low Water Mark     : 1
        Queue Water Mark         : false
        Queue Channel Closed     : false
        Queue Status              : 2
        Queue Enqueue Count      : 80006
        Queue Decrement Count    : 80006
        Queue Retry Count        : 0
        Queue Retry Full Count   : 0
    Errors:
        Queue Init Failure       : 0
        Queue Update Failure     : 0
        Queue Dequeue Failure    : 0
        Queue Invalid Parameters : 0
    SendtoAAA Accounting Queue:
    Grpc services:
        GNMI                      : 80002 sent, 0 dropped, 0 truncated
        GNOI                     : 0 sent, 0 dropped, 0 truncated
        GNSI                     : 4 sent, 0 dropped, 0 truncated
        GRIBI                    : 0 sent, 0 dropped, 0 truncated
        P4RT                     : 0 sent, 0 dropped, 0 truncated
        Unspecified              : 0 sent, 0 dropped, 0 truncated
    Queue Rate:
        Input                     : 80000
        Output                    : 80000
        Drop                      : 0
    Stats:
        Queue Buffer Used         : 0 MB
        Queue Enqueue            : 80006

```

```

Queue Dequeue           : 80006
Queue Drops             : 0
Queue Max Time          : 66549 usec
Queue Min Time          : 1 usec
Queue Avg Time          : 2544 usec
Channel Stats:
Queue Channel Size      : 512
Queue Channel Length    : 0
Queue Inuse Size        : 0
Queue Size              : 40
Queue Low Water Mark    : 1
Queue Water Mark        : false
Queue Channel Closed    : false
Queue Status            : 2
Queue Enqueue Count     : 80006
Queue Decrement Count   : 80006
Queue Retry Count       : 0
Queue Retry Full Count  : 0
Errors:
Queue Init Failure      : 0
Queue Update Failure    : 0
Queue Dequeue Failure   : 0
Queue Invalid Parameters : 0
Cmd Accounting Queue:
Cmd services:
Shell                   : 0 sent, 0 dropped, 0 truncated
Cli                     : 23 sent, 0 dropped, 0 truncated
Netconf                 : 0 sent, 0 dropped, 0 truncated
Unspecified             : 0 sent, 0 dropped, 0 truncated
Queue Rate:
Input                   : 2
Output                  : 2
Drop                    : 0
Stats:
Queue Buffer Used        : 0 MB
Queue Enqueue           : 23
Queue Dequeue           : 23
Queue Drops             : 0
Queue Max Time          : 248 usec
Queue Min Time          : 26 usec
Queue Avg Time          : 94 usec
Channel Stats:
Queue Channel Size      : 512
Queue Channel Length    : 0
Queue Inuse Size        : 0
Queue Size              : 40
Queue Low Water Mark    : 1
Queue Water Mark        : false
Queue Channel Closed    : false
Queue Status            : 2
Queue Enqueue Count     : 23
Queue Decrement Count   : 23
Queue Retry Count       : 0
Queue Retry Full Count  : 0
Errors:
Queue Init Failure      : 0
Queue Update Failure    : 0
Queue Dequeue Failure   : 0
Queue Invalid Parameters : 0
Client Stats:
Number Of Clients        : 2
History Truncation Events : 0
Client Idle Timeouts     : 0
Record Requests          : 4

```



```

Record Responses                               : 80029
Collectors:
Collector Statistics:
  IP                                             : 192.168.122.1
  Port                                          : 25906
  Total                                         : Records: 80029, Drops: 0
  Total History Truncation                     : 0
  Grpc Service Records:
    gNMI                                        : Records: 80002, Drops: 0
    gNOI                                        : Records: 0, Drops: 0
    gNSI                                        : Records: 4, Drops: 0
    gRIBI                                       : Records: 0, Drops: 0
    P4RT                                        : Records: 0, Drops: 0
    Unspecified                                : Records: 0, Drops: 0
  Cmd Service Records:
    Shell                                       : Records: 0, Drops: 0
    CLI                                         : Records: 23, Drops: 0
    Netconf                                    : Records: 0, Drops: 0
    Unspecified                                : Records: 0, Drops: 0
gRPC Stream Stats:
gRPC Stream Status                             : 2
gRPC Send Status                              : 1
gRPC Send Error Channel Length                : 0
gRPC Send Errors                              : 0
gRPC Send Enqueue Count                       : 80029
gRPC Send Close Count                         : 0
gRPC Stream Send Count                        : 80029
gRPC Stream Send Error Count                  : 0
Send Channel Stats:
Queue Channel Size                            : 512
Queue Channel Length                          : 0
Queue Inuse Size                              : 0
Queue Size                                    : 40
Queue Low Water Mark                          : 0
Queue Water Mark                              : false
Queue Channel Closed                          : false
Queue Status                                  : 2
Queue Enqueue Count                           : 80029
Queue Decrement Count                         : 80029
Queue Retry Count                             : 0
Queue Retry Full Count                       : 0
Collector Statistics:
  IP                                             : 192.168.122.1
  Port                                          : 25912
  Total                                         : Records: 80029, Drops: 0
  Total History Truncation                     : 0
  Grpc Service Records:
    gNMI                                        : Records: 80002, Drops: 0
    gNOI                                        : Records: 0, Drops: 0
    gNSI                                        : Records: 4, Drops: 0
    gRIBI                                       : Records: 0, Drops: 0
    P4RT                                        : Records: 0, Drops: 0
    Unspecified                                : Records: 0, Drops: 0
  Cmd Service Records:
    Shell                                       : Records: 0, Drops: 0
    CLI                                         : Records: 23, Drops: 0
    Netconf                                    : Records: 0, Drops: 0
    Unspecified                                : Records: 0, Drops: 0
gRPC Stream Stats:
gRPC Stream Status                             : 2
gRPC Send Status                              : 1
gRPC Send Error Channel Length                : 0
gRPC Send Errors                              : 0
gRPC Send Enqueue Count                       : 80029

```

```

    gRPC Send Close Count      : 0
    gRPC Stream Send Count    : 80029
    gRPC Stream Send Error Count : 0
  Send Channel Stats:
    Queue Channel Size        : 512
    Queue Channel Length      : 0
    Queue Inuse Size          : 0
    Queue Size                 : 40
    Queue Low Water Mark      : 0
    Queue Water Mark          : false
    Queue Channel Closed      : false
    Queue Status               : 2
    Queue Enqueue Count       : 80029
    Queue Decrement Count     : 80029
    Queue Retry Count         : 0
    Queue Retry Full Count    : 0
  Accounting Stats:
    Grpc Accounting           : 80006
    Cmd Accounting            : 23
  Error Stats:
    AAA Dequeue Failed        : 0
    AAA Payload Failed        : 0
    Send To AAA Failed        : 0
    gRPC Dequeue Failed       : 0
    Cmd Dequeue Failed        : 0
    Accounting Payload Failed : 0
    Record Create Failed      : 0
    Get RPC Failed            : 0
    Get Method Failed         : 0
    Serialize Payload Failed  : 0
    Record Response Payload Failed : 0
    Get Local Info Failed     : 0
    Get Remote Info Failed    : 0
    Get Username Failed       : 0
    Locald Invalid Service Type : 0

```

show grpc certificate

To display the active gRPC certificate management policies on the router, use the **show grpc certificate** command in EXEC mode.

show grpc certificate

Syntax Description	This command has no keywords or arguments.	
Command Default	None	
Command Modes	EXEC mode	
Command History	Release	Modification
	Release 24.1.1	The command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	config-services	read

This example displays the active gRPC certificate management policies on the router. The below-mentioned command output is truncated version.

```
Router#show grpc certificate
Certificate:
  Data:
    Version: 3 (0x2)
    Serial Number: 32 (0x20)
    Signature Algorithm: sha256WithRSAEncryption
    Issuer: CN=localhost,O=OpenConfig,C=US
    Validity
      Not Before: Nov  8 08:49:38 2023 GMT
      Not After : Mar 22 08:49:38 2025 GMT
    Subject: CN=ems,O=OpenConfig,C=US
    Subject Public Key Info:
      Public Key Algorithm: rsaEncryption
      RSA Public-Key: (4096 bit)
      Modulus:
        00:ea:6a:6c:25:be:9f:15:71:ce:74:89:03:ec:ef:
        0b:3b:de:58:a8:7e:28:b8:cf:b3:82:91:b4:5c:42:
        e7:d8:28:98:35:bd:35:60:a7:4e:f8:77:02:46:5f:
        27:a4:16:cf:3c:e3:24:28:69:9c:22:1e:e3:52:96:
        71:87:7c:40:0c:1f:dd:30:ea:dc:40:ca:93:00:54:
        5e:de:20:54:5b:f4:2f:9f:19:6f:71:61:28:69:3d:
        97:26:ab:e1:5f:53:3c:f1:a2:c3:14:f4:01:90:1a:
        .
        .
        .
```

```

        Exponent: 65537 (0x10001)
X509v3 extensions:
    X509v3 Key Usage: critical
        Digital Signature
    X509v3 Extended Key Usage:
        TLS Web Client Authentication, TLS Web Server Authentication
    X509v3 Authority Key Identifier:
        keyid:0A:A8:9A:6A:23:34:AE:CA:96:00:2C:F3:04:38:14:E3:D4:8D:77:BD

    X509v3 Subject Alternative Name:
        DNS, IP Address:64.103.223.56
Signature Algorithm: sha256WithRSAEncryption
b9:89:ec:60:3d:8d:7d:9c:dc:08:56:89:99:44:92:98:45:b6:
97:ba:e3:e5:f2:48:b2:44:8d:db:23:bb:a1:c0:62:79:78:18:
d7:55:f6:4a:67:5b:75:e0:c0:0b:52:51:07:36:d5:6c:c7:67:
48:86:8d:dd:70:1c:9f:7c:a1:7b:aa:a5:4e:e1:ad:cf:4c:e5:
81:db:92:cf:88:70:5a:1c:8d:de:0d:e8:b3:05:de:b9:04:4d:
23:e1:de:66:e5:08:bd:2e:31:0a:07:a6:c0:00:3a:38:2f:00:
.
.
.
```

show gnsi service authorization policy

To display the active gRPC service authorization policies on the router, use the **show gnsi service authorization policy** command in Global Configuration mode.

show gnsi service authorization policy

Syntax Description	This command has no keywords or arguments.	
Command Default	Enabled, by default	
Command Modes	Global Configuration mode	
Command History	Release	Modification
	Release 7.11.1	The command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	config-services	read

This example displays the policy which is active on the router:

```
Router#show gnsi service authorization policy
Wed Jul 19 10:56:14.509 UTC{
  "version": "1.0",
  "created_on": 1700816204,
  "policy": {
    "name": "authz",
    "allow_rules": [
      {
        "name": "allow all gNMI for all users",
        "request": {
          "paths": [
            "*"
          ]
        },
        "source": {
          "principals": [
            "*"
          ]
        }
      }
    ],
    "deny_rules": [
      {
        "name": "deny gNMI set for oper users",
        "request": {
          "paths": [
            "/gnmi.gNMI/*"
          ]
        }
      }
    ]
  }
}
```

```
    ]  
    },  
    "source": {  
        "principals": [  
            "User1"  
        ]  
    }  
}  
  
]  
  
}
```

show tech-support script

To collect logs that contain debug information for logical traces and tech-support data, use the **show tech-support script** command in XR EXEC mode.

script tech-support script { **file** *filepath_filename* | **list-CLIs** | **time-out** }

Syntax Description	file <i>filepath_filename</i>	Specifies the complete path to a file, including the filename to save the log.
	list-CLIs	Creates a log zip file containing a list of all CLI commands executed as part of the tech-support script. The CLI commands are only listed, not executed.
	time-out	Specifies the timeout value for each command in seconds ranging from 120-3600 seconds. By default, the timeout is 900 seconds.
Command Default	None	
Command Modes	XR EXEC mode	
Command History	Release	Modification
	Release 7.5.1	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operations
	config-services	read, write

This example displays how to save the logical traces and tech-support data in the test file in the disk0 path:

```
Router# show tech-support script file disk0:/test.log
Wed Sep 25 07:11:39.915 PDT
++ Show tech start time: 2024-Sep-25.071140.PDT ++
Wed Sep 25 07:11:40 PDT 2024 Waiting for gathering to complete
.....
Wed Sep 25 07:12:49 PDT 2024 Compressing show tech output
Show tech output available at 0/RP0/CPU0 : /disk0:/test.log.tgz
++ Show tech end time: 2024-Sep-25.071250.PDT ++
```




YANG Commands

This module outlines the commands necessary to utilize the YANG server module configuration protocol, which defines network operations using data models.

For detailed information about YANG data model concepts, configuration tasks, and examples, see the *Drive Network Automation Using Programmable YANG Data Models* in the *Cisco 8000 Series Router* module in the *Programmability Configuration Guide for Cisco 8000 Series Routers*.

- [yang-server module-set](#), on page 28

yang-server module-set

To enable a certain set of YANG models, use the **yang-server module-set** command in the Global Configuration mode.

yang-server module-set

Syntax Description	UM-preferred	This set uses applicable unified models.
	XR-only	This set uses native models.
Command Default	None	
Command Modes	Global Configuration mode	
Command History	Release	Modification
	Release 5.3.1	This command was introduced.
Usage Guidelines	The yang-server module-set command is applied to only config models. When this command is configured, all externally defined YANG models, including OpenConfig models, are disabled.	
Task ID	Task ID	Operation
	config-services	read, write

Example

This command shows how to use the **yang-server module-set** command:

```
Router# config
Router(config)# yang-server module-set XR-only
Router# end
```