

Multiple Spanning Tree Protocol

The Multiple Spanning Tree Protocol (MSTP) is an STP variant that allows multiple and independent spanning trees to be created over the same physical network. The parameters for each spanning tree can be configured separately, so as to cause a different network devices to be selected as the root bridge or different paths to be selected to form the loop-free topology. Consequently, a given physical interface can be blocked for some of the spanning trees and unblocked for others.

Having set up multiple spanning trees, the set of VLANs in use can be partitioned among them; for example, VLANs 1 - 100 can be assigned to spanning tree 1, VLANs 101 - 200 can be assigned to spanning tree 2, VLANs 201 - 300 can be assigned to spanning tree 3, and so on. Since each spanning tree has a different active topology with different active links, this has the effect of dividing the data traffic among the available redundant links based on the VLAN - a form of load balancing.

- Restrictions for configuring MSTP, on page 1
- How to Configure MST Protocol, on page 1

Restrictions for configuring MSTP

- RSTP is not supported. To support RSTP, all vlans are mapped to MSTI 0 when no instance is created for MSTP.
- PVSTP is not supported.
- Supports only 16 instances.
- Untagged EVCs do not participate in MST loop detection.

How to Configure MST Protocol

This section describes the procedure for configuring MSTP:

Enabling Multiple Spanning Tree Protocol

By default, MSTP is disabled on all interfaces. MSTP need not be enabled explicitly on each interfaces. By turning the global configuration on, it is enabled on all interfaces.

Configuring Multiple Spanning Tree Protocol

Describes steps to configure MST

SUMMARY STEPS

- 1. configure
- **2**. spanning-tree mode mst
- 3. spanning-tree mst configuration
- 4. instance vlan-id vlan vlan-range
- 5. name region
- **6.** revision revision -number
- 7. end

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure	Enters global configuration mode.
	Example:	
	Device> configure	
Step 2	spanning-tree mode mst	Enables MSTP configuration mode.
	Example:	
	Device> spanning-tree mode mst	
Step 3	spanning-tree mst configuration	Enters the MSTP configuration submode.
	Example:	
	Device(config)#spanning-tree mst configuration	
Step 4	instance vlan-id vlan vlan-range	Maps the VLANs to an MST instance
	Example:	
	Device(config-mstp-inst)# instance 1 vlan 450-480	
Step 5	name region	Sets the name of the MSTP region.
	Example:	
	Device(config-mstp)# name m1	
Step 6	revision revision -number	Sets the revision level of the MSTP region.
	Example:	
	Device(config-mstp)#)revision 1	
Step 7	end	Returns to privileged EXEC mode.
	Example:	
	Device(config-mstp-if)# end	

Configuring Untagged EFP over MST Interface

Describes steps to configure untagged EFP over MST:

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- **3. interface** *interface number*
- 4. no ip address
- 5. service instance number ethernet [name]
- 6. bridge-domain bridge-id
- 7. encapsulation untagged
- 8. l2protocol peer stp
- **9**. end

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
	Example:	
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	interface interface number	Specifies the Gigabit Ethernet interface to configure, where:
	Example:	slot/subslot/port-Specifies the location of the interface.
	<pre>Router(config)# interface gigabitEthernet 0/0/5</pre>	
Step 4	no ip address	Disables the IP address on the interface.
	Example:	
	Router (config-if)# no ip address	
Step 5	service instance number ethernet [name]	Configure an EFP (service instance) and enter service instance configuration mode.
	Example:	
	Router (config-if) #service instance 200 ethernet	
Step 6	bridge-domain bridge-id	Creates a list of bridge domains for an EFP trunk port using the bridge-domain IDs derived from the encapsulation VLAN numbers.
	Example:	
	Router (config-if-srv)# bridge-domain from-encapsulation	
Step 7	encapsulation untagged	Configures the encapsulation. Defines the matching criteria that maps the untagged frames on an interface for the appropriate service instance.
	Example:	
	Router (config-if-srv)# encapsulation untagged	

	Command or Action	Purpose
Step 8	l2protocol peer stp	Configures STP to peer with a neighbor on a port that has
	Example:	an EFP service instance.
	Router (config-if-srv)# 12protocol peer stp	
Step 9	end	Returns to privileged EXEC mode.
	Example:	
	Device(config-mstp-if)# end	

Configuration Example

This example shows how to configure STP to peer with a neighbor on a service instance.

```
interface GigabitEthernet0/0/0
no ip address
negotiation auto
service instance trunk 10 ethernet
    encapsulation dot1q 10-20
    bridge-domain from-encapsulation
!
service instance 1024 ethernet
    encapsulation untagged
    l2protocol peer stp
    bridge-domain 1024
!
end
```