



Configuring an SLM

Synthetic loss measurement (SLM) is part of the ITU-T Y.1731 standard. It can be used to periodically measure Frame Loss and Forward Loss Ratio (FLR) between a pair of point to point MEPs. Measurements are made between two MEPs that belong to the same domain and MA.

- [Configuring an SLM, on page 1](#)

Configuring an SLM

To configure an SLM, execute the following commands:

SUMMARY STEPS

1. **enable**
2. **configure terminal** *operation number*
3. **ip sla** *operation number*
4. **ethernet y1731 loss SLM domain** *domain-name* {**evc** *evc-id* | **vlan** *vlan-id*} {**mpid** *target-mp-id* | **mac-address-target** *-address*} **cos** *cos* {**source** {**mpid** *source-mp-id* | **mac-address** *source-address*}}
5. **aggregate interval** *seconds*
6. **availability algorithm** { **sliding-window** | **static-window 1** } **symmetric**
7. **frame consecutive** *value*
8. **frame interval** *milliseconds*
9. **frame size** *bytes*
10. **history interval** *intervals-stored*
11. **exit**
12. **ip sla reaction-configuration** *operation-number* [**react** {**unavailableDS** | **unavailableSD** | **loss-ratioDS** | **loss-ratioSD**}] [**threshold-type** {**average** [*number -of-measurements*] | **consecutive** [*occurrences*] | **immediate**}] [**threshold-value** *upper -threshold lower-threshold*]
13. **ip sla logging traps**
14. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.

	Command or Action	Purpose
	<p>Example:</p> <pre>Router > enable</pre>	<ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	<p>configure terminal <i>operation number</i></p> <p>Example:</p> <pre>Device# configure terminal</pre>	<p>—Identifies the IP SLAs' operation you want to configure.</p> <p>Enters global configuration mode.</p>
Step 3	<p>ip sla <i>operation number</i></p> <p>Example:</p> <pre>Router(config)# ip sla 11</pre>	<p>Configures an IP SLA operation and enters IP SLA configuration mode.</p> <ul style="list-style-type: none"> • <i>operation-number</i>—Identifies the IP SLAs' operation you want to configure.
Step 4	<p>ethernet y1731 loss SLM domain <i>domain-name</i> {evc <i>evc-id</i> vlan <i>vlan-id</i>} {mpid <i>target-mp-id</i> mac-address-target <i>-address</i>} cos <i>cos</i> {source {mpid <i>source-mp-id</i> mac-address <i>source-address</i>}}</p> <p>Example:</p> <pre>Router(config-ip-sla)# ethernet y1731 loss SLM domain xxx evc yyy mpid 101 cos 4 source mpid 100</pre>	<p>Configures a single-ended synthetic loss measurement and enters IP SLA Y.1731 loss configuration mode.</p> <ul style="list-style-type: none"> • EVC—Specifies the ethernet virtual circuit name. • SLM—Specifies that the frames sent are Synthetic Loss Measurement (SLM) frames. • domain <i>domain-name</i>—Specifies the name of the Ethernet Connectivity Fault Management (CFM) maintenance domain. • vlan <i>vlan-id</i>—Specifies the VLAN identification number. The range is from 1 to 4094. • mpid <i>target-mp-id</i>—Specifies the maintenance endpoint identification numbers of the MEP at the destination. The range is from 1 to 8191. • mac-address <i>target-address</i>—Specifies the MAC address of the MEP at the destination. • cos <i>cos</i>—Specifies, for this MEP, the class of service (CoS) that will be sent in the Ethernet message. The range is from 0 to 7. • source—Specifies the source MP ID or MAC address. • mpid <i>source-mp-id</i>—Specifies the maintenance endpoint identification numbers of the MEP being configured. The range is from 1 to 8191. • mac-address <i>source-address</i>—Specifies the MAC address of the MEP being configured.

	Command or Action	Purpose
Step 5	aggregate interval <i>seconds</i> Example: <pre>Router(config-sla-y1731-loss)# aggregate interval 900</pre>	(Optional) Configures the length of time during which the performance measurements are conducted and the results stored. <ul style="list-style-type: none"> • <i>seconds</i>—Specifies the length of time in seconds. The range is from 1 to 65535. The default is 900.
Step 6	availability algorithm { sliding-window static-window } symmetric Example: <pre>Router(config-sla-y1731-loss)# availability algorithm static-window</pre>	(Optional) Specifies availability algorithm used. <ul style="list-style-type: none"> • sliding-window—Specifies a sliding-window control algorithm. • static-window—Specifies static-window control algorithm.
Step 7	frame consecutive <i>value</i> Example: <pre>Router(config-sla-y1731-loss)# frame consecutive 10.</pre>	(Optional) Specifies number of consecutive measurements to be used to determine availability or unavailability status. <ul style="list-style-type: none"> • <i>value</i>—Specifies the number of consecutive measurements. The range is from 1 to 10. The default is 10.
Step 8	frame interval <i>milliseconds</i> Example: <pre>Router(config-sla-y1731-loss)# frame interval 1000</pre>	(Optional) Sets the gap between successive frames. <ul style="list-style-type: none"> • <i>milliseconds</i>—Specifies the length of time in milliseconds (ms) between successive synthetic frames. The default is 1000
Step 9	frame size <i>bytes</i> Example: <pre>Router(config-sla-y1731-loss)# frame size 64</pre>	(Optional) Configures padding size for frames. <ul style="list-style-type: none"> • <i>bytes</i>—Specifies the padding size, in four-octet increments, for the synthetic frames. The default is 64.
Step 10	history interval <i>intervals-stored</i> Example: <pre>Router(config-sla-y1731-loss)# history interval 2</pre>	(Optional) Sets the number of statistics distributions kept during the lifetime of an IP SLAs Ethernet operation. <ul style="list-style-type: none"> • <i>intervals-stored</i>—Specifies the number of statistics distributions. The range is from 1 to 10. The default is 2.
Step 11	exit Example: <pre>Router(config-sla-y1731-loss)# exit</pre>	Exits IP SLA Y.1731 loss configuration mode and enters IP SLA configuration mode.
Step 12	ip sla reaction-configuration <i>operation-number</i> [react { unavailableDS unavailableSD loss-ratioDS loss-ratioSD }] [threshold-type { average [<i>number-of-measurements</i>] consecutive [<i>occurrences</i>]	(Optional) Configures proactive threshold monitoring for frame loss measurements. <ul style="list-style-type: none"> • <i>operation-number</i>—Identifies the IP SLAs operation for which reactions are to be configured.

	Command or Action	Purpose
	<p>immediate }] [threshold-value <i>upper -threshold lower-threshold</i>]</p> <p>Example:</p> <pre>Router(config)# ip sla reaction-configuration 11 react unavailableDS</pre>	<ul style="list-style-type: none"> • react—(Optional) Specifies the element to be monitored for threshold violations. • unavailableDS—Specifies that a reaction should occur if the percentage of destination-to-source Frame Loss Ratio (FLR) violates the upper threshold or lower threshold. • unavailableSD—Specifies that a reaction should occur if the percentage of source-to-destination FLR violates the upper threshold or lower threshold. • loss-ratioDS—Specifies that a reaction should occur if the one-way destination-to-source loss-ratio violates the upper threshold or lower threshold. • loss-ratioSD—Specifies that a reaction should occur if the one way source-to-destination loss-ratio violates the upper threshold or lower threshold. • threshold-type average[<i>number-of-measurements</i>]—(Optional) When the average of a specified number of measurements for the monitored element exceeds the upper threshold or when the average of a specified number of measurements for the monitored element drops below the lower threshold, perform the action defined by the action-type keyword. The default number of 5 averaged measurements can be changed using the number-of-measurements argument. The range is from 1 to 16. • threshold-type consecutive[<i>occurrences</i>]—(Optional) When a threshold violation for the monitored element is met consecutively for a specified number of times, perform the action defined by the action-type keyword. The default number of 5 consecutive occurrences can be changed using the occurrences argument. The range is from 1 to 16. • threshold-type immediate—(Optional) When a threshold violation for the monitored element is met, immediately perform the action defined by the action-type keyword. • threshold-value<i>upper-threshold lower-threshold</i>—(Optional) Specifies the upper-threshold and lower-threshold values of the applicable monitored elements.
<p>Step 13</p>	<p>ip sla logging traps</p> <p>Example:</p>	<p>(Optional) Enables IP SLAs syslog messages from CISCO-RTTMON-MIB.</p>

	Command or Action	Purpose
	<code>Router(config)# ip sla logging traps</code>	
Step 14	exit Example: <code>Router(config)# exit</code>	Exits global configuration mode and enters privileged EXEC mode.

What to do next

Once the SLM is configured, you have to schedule an IP SLA operation.

Scheduling an IP SLA Operation

To schedule an IP SLA operation, execute the following commands:

SUMMARY STEPS

1. enable
2. configure terminal
3. ip sla schedule operation-number [life { forever | seconds }] [start-time {hh :mm [:ss] [month day | day month] | pending | now | after hh:mm:ss | random milliseconds}]
4. exit

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: <code>Router> enable</code>	Enables the privileged EXEC mode. Enter your password if prompted.
Step 2	configure terminal Example: <code>Router# configure terminal</code>	Enters the global configuration mode.
Step 3	ip sla schedule operation-number [life { forever seconds }] [start-time {hh :mm [:ss] [month day day month] pending now after hh:mm:ss random milliseconds}] Example: <code>Router(config)# ip sla schedule 10 start-time now life forever</code>	Configures the scheduling parameters for an individual IP SLA operation or Specifies an IP SLA operation group number and the range of operation numbers to be scheduled for a multi-operation scheduler. <ul style="list-style-type: none"> • <i>operation-number</i>—Identifies the IP SLAs operation for which reactions are to be configured. • life forever— (Optional) Schedules the operation to run indefinitely. • life seconds —(Optional) Number of seconds the operation actively collects information. The default is 3600 seconds (one hour).

	Command or Action	Purpose
		<ul style="list-style-type: none"> • start-time —(Optional) Time when the operation starts. • hh:mm[:ss]—Specifies an absolute start time using hour, minute, and (optionally) second. Use the 24-hour clock notation. For example, start-time 01:02 means “start at 1:02 a.m.,” and start-time 13:01:30 means “start at 1:01 p.m. and 30 seconds.” The current day is implied unless you specify a month and day. • month —(Optional) Name of the month to start the operation in. If month is not specified, the current month is used. Use of this argument requires that a day be specified. You can specify the month by using either the full English name or the first three letters of the month. • day —(Optional) Number of the day (in the range 1 to 31) to start the operation on. If a day is not specified, the current day is used. Use of this argument requires that a month be specified. • pending —(Optional) No information is collected. This is the default value. • now —(Optional) Indicates that the operation should start immediately. • after hh:mm:ss—(Optional) Indicates that the operation should start hh hours, mm minutes, and ss seconds after this command was entered. • random milliseconds—(Optional) Adds a random number of milliseconds (between 0 and the specified value) to the current time, after which the operation will start. The range is from 0 to 10000.
Step 4	exit Example: <pre>Router(config)# exit</pre>	Exits the global configuration mode and enters the privileged EXEC mode.