



System Security Command Reference for Cisco NCS 6000 Series Routers

First Published: 2013-09-19

Last Modified: 2021-07-01

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on standards documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2013–2021 Cisco Systems, Inc. All rights reserved.



CONTENTS

PREFACE

Preface ix

Changes to This Document ix

Communications, Services, and Additional Information x

CHAPTER 1

Authentication, Authorization, and Accounting Commands 1

aaa accounting 2

aaa accounting system default 4

aaa accounting update 5

aaa authentication (XR-VM) 6

aaa authorization (XR-VM) 8

aaa authorization (System Admin-VM) 11

show nacm (XR-VM) 12

aaa default-taskgroup 15

aaa group server radius 16

aaa group server tacacs+ 17

aaa password-policy 19

accounting (line) 23

authorization (line) 24

deadtime (server-group configuration) 25

description (AAA) 26

group (AAA) 27

holddown-time (TACACS+) 28

inherit taskgroup 30

inherit usergroup 31

key (TACACS+) 32

login authentication 33

password (AAA)	34
policy (AAA)	36
radius-server dead-criteria time	37
radius-server dead-criteria tries	38
radius-server deadtime(BNG)	39
radius-server key	40
radius-server retransmit	41
radius-server timeout	41
radius source-interface	42
secret	43
server (RADIUS)	46
server (TACACS+)	47
server-private (RADIUS)	48
show aaa (XR-VM)	49
show aaa accounting	54
show aaa password-policy	55
show radius	56
show radius accounting	58
show radius authentication	59
show radius dead-criteria	61
show radius server-groups	62
show tacacs	64
show tacacs server-groups	65
show user	67
show aaa user-group	69
show tech-support aaa	69
single-connection	70
single-connection-idle-timeout	71
tacacs-server host	72
tacacs-server key	75
tacacs-server timeout	76
tacacs source-interface	77
task	78
taskgroup	80

timeout (TACACS+)	81
timeout login response	82
usergroup	83
username	84
users group	91
vrf (RADIUS)	92

CHAPTER 2
IPSec Commands 95

clear crypto ipsec sa	95
description (IPSec profile)	96
show crypto ipsec sa	97
show crypto ipsec summary	100
show crypto ipsec transform-set	101

CHAPTER 3
Keychain Management Commands 103

accept-lifetime	103
ao	104
accept-tolerance	105
clear type6 client	106
key (key chain)	107
key (tcp ao keychain)	108
keychain	109
key chain (key chain)	109
key config-key password-encryption	110
key-string (keychain)	111
send-lifetime	113
show key chain	114
show type6	115
tcp ao	117

CHAPTER 4
Lawful Intercept Commands 119

overlap-tap enable	119
--------------------	-----

CHAPTER 5
Management Plane Protection Commands 121

address ipv4 (MPP) 121
 allow 122
 control-plane 124
 inband 125
 interface (MPP) 126
 management-plane 127
 out-of-band 128
 show mgmt-plane 129
 vrf (MPP) 131

CHAPTER 6

Public Key Infrastructure Commands 133

clear crypto ca certificates 134
 clear crypto ca crl 134
 crl optional (trustpoint) 135
 crypto ca authenticate 136
 crypto ca cancel-enroll 138
 crypto ca enroll 139
 crypto ca import 140
 crypto ca trustpoint 141
 crypto ca trustpool import url 142
 crypto ca trustpool policy 144
 crypto key generate dsa 145
 crypto key generate ecDSA 146
 crypto key generate rsa 147
 crypto key import authentication rsa 148
 crypto key zeroize dsa 148
 crypto key zeroize ecDSA 149
 crypto key zeroize rsa 150
 description (trustpoint) 151
 enrollment retry count 152
 enrollment retry period 153
 enrollment terminal 154
 enrollment url 155
 ip-address (trustpoint) 156

query url	157
rsakeypair	158
serial-number (trustpoint)	159
sftp-password (trustpoint)	160
sftp-username (trustpoint)	161
subject-name (trustpoint)	162
show crypto ca certificates	163
show crypto ca crls	165
show crypto ca trustpool policy	166
show crypto key mypubkey dsa	166
show crypto key mypubkey ecdsa	167
show crypto key mypubkey rsa	168

CHAPTER 7
Software Authentication Manager Commands 171

sam add certificate	171
sam delete certificate	173
sam prompt-interval	174
sam verify	176
show sam certificate	177
show sam crl	181
show sam log	183
show sam package	184
show sam sysinfo	186

CHAPTER 8
Secure Shell Commands 189

clear ssh	190
netconf-yang agent ssh	191
sftp	192
sftp (Interactive Mode)	195
show ssh	198
show ssh history	201
show ssh history details	202
show ssh rekey	203
show ssh session details	204

show tech-support ssh	206
ssh	207
ssh algorithms cipher	208
ssh client enable cipher	209
ssh client knownhost	210
ssh client source-interface	211
ssh client vrf	212
ssh server	213
ssh server algorithms host-key	215
ssh disable hmac	216
ssh server enable cipher	217
ssh server rekey-time	217
ssh server rekey-volume	218
ssh server logging	219
ssh server rate-limit	220
ssh server session-limit	221
ssh server v2	222
ssh server netconf port	222
ssh timeout	223

CHAPTER 9	Secure Socket Layer Protocol Commands	225
	show ssl	225



Preface

This guide describes the commands used to display and configure system security on Cisco IOS XR software. For System Security configuration information and examples, refer to the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

The preface contains the following sections:

- [Changes to This Document, on page ix](#)
- [Communications, Services, and Additional Information, on page x](#)

Changes to This Document

This table lists the technical changes made to this document since it was first printed.

Table 1: Changes to This Document

Date	Change Summary
September 2013	Initial release of this document.
August 2014	Republished for Release 5.2.1.
January 2015	Republished for Release 5.2.3.
August 2016	Republished for Release 6.1.2.
March 2017	Republished for Release 6.2.1.
July 2017	Republished for Release 6.2.2.
September 2017	Republished for Release 6.3.1.
March 2018	Republished for Release 6.3.2.
March 2018	Republished for Release 6.4.1.
December 2018	Republished for Release 6.6.1.
August 2019	Republished for Release 7.0.1.
August 2020	Republished for Release 7.2.1.

Date	Change Summary
August 2020	Republished for Release 7.1.2.
July 2021	Republished for Release 7.4.1.

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco Marketplace](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



CHAPTER

1

Authentication, Authorization, and Accounting Commands

This module describes the commands used to configure authentication, authorization, and accounting (AAA) services.

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

For detailed information about AAA concepts, configuration tasks, and examples, see the *Configuring AAA Services on Cisco IOS XR Software* chapter in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

- [aaa accounting](#), on page 2
- [aaa accounting system default](#), on page 4
- [aaa accounting update](#), on page 5
- [aaa authentication \(XR-VM\)](#), on page 6
- [aaa authorization \(XR-VM\)](#), on page 8
- [aaa authorization \(System Admin-VM\)](#), on page 11
- [show nacm \(XR-VM\)](#), on page 12
- [aaa default-taskgroup](#), on page 15
- [aaa group server radius](#), on page 16
- [aaa group server tacacs+](#), on page 17
- [aaa password-policy](#), on page 19
- [accounting \(line\)](#), on page 23
- [authorization \(line\)](#), on page 24
- [deadtime \(server-group configuration\)](#), on page 25
- [description \(AAA\)](#), on page 26
- [group \(AAA\)](#), on page 27
- [holddown-time \(TACACS+\)](#), on page 28
- [inherit taskgroup](#), on page 30
- [inherit usergroup](#), on page 31
- [key \(TACACS+\)](#), on page 32
- [login authentication](#), on page 33
- [password \(AAA\)](#), on page 34
- [policy \(AAA\)](#), on page 36

- radius-server dead-criteria time, on page 37
- radius-server dead-criteria tries, on page 38
- radius-server deadtime(BNG), on page 39
- radius-server key, on page 40
- radius-server retransmit, on page 41
- radius-server timeout, on page 41
- radius source-interface, on page 42
- secret, on page 43
- server (RADIUS), on page 46
- server (TACACS+), on page 47
- server-private (RADIUS), on page 48
- show aaa (XR-VM), on page 49
- show aaa accounting, on page 54
- show aaa password-policy, on page 55
- show radius, on page 56
- show radius accounting, on page 58
- show radius authentication, on page 59
- show radius dead-criteria, on page 61
- show radius server-groups, on page 62
- show tacacs, on page 64
- show tacacs server-groups, on page 65
- show user, on page 67
- show aaa user-group, on page 69
- **show tech-support aaa** , on page 69
- single-connection, on page 70
- single-connection-idle-timeout, on page 71
- tacacs-server host, on page 72
- tacacs-server key, on page 75
- tacacs-server timeout, on page 76
- tacacs source-interface, on page 77
- task, on page 78
- taskgroup, on page 80
- timeout (TACACS+), on page 81
- timeout login response, on page 82
- usergroup, on page 83
- username, on page 84
- users group, on page 91
- vrf (RADIUS), on page 92

aaa accounting

To create a method list for accounting, use the **aaa accounting** command in XR Config mode. To remove a list name from the system, use the **no** form of this command.

```
aaa accounting {commands | exec | network | subscriber | system} {default | list-name} {start-stop | stop-only} {none | method}
```

Syntax Description	commands	Enables accounting for XR EXEC shell commands.
	exec	Enables accounting of a XR EXEC session.
	network	Enables accounting for all network-related service requests, such as Internet Key Exchange (IKE) and Point-to-Point Protocol (PPP).
	subscriber	Sets accounting lists for subscribers.
	system	Enables accounting for all system-related events.
	event manager	Sets the authorization list for XR EXEC.

Command Default AAA accounting is disabled.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **aaa accounting** command to create default or named method lists defining specific accounting methods and that can be used on a per-line or per-interface basis. You can specify up to four methods in the method list. The list name can be applied to a line (console,, or vty template) to enable accounting on that particular line.

The Cisco IOS XR software supports both TACACS+ and RADIUS methods for accounting. The router reports user activity to the security server in the form of accounting records, which are stored on the security server.



Note This command cannot be used with TACACS or extended TACACS.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to define a default commands accounting method list, where accounting services are provided by a TACACS+ security server, with a stop-only restriction:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa accounting commands default stop-only group tacacs+
```

Related Commands	Command	Description
	aaa authorization (XR-VM), on page 8	Creates a method list for authorization.

aaa accounting system default

To enable authentication, authorization, and accounting (AAA) system accounting, use the **aaa accounting system default** command in XR Config mode. To disable system accounting, use the **no** form of this command.

aaa accounting system default {start-stop} {none | method}

Syntax Description	start-stop
	Sends a “start accounting” notice during system bootup and a “stop accounting” notice during system shutdown or reload.
	none Uses no accounting.
	<i>method</i> Method used to enable AAA system accounting. The value is one of the following options: <ul style="list-style-type: none"> • group tacacs+—Uses the list of all TACACS+ servers for accounting. • group radius—Uses the list of all RADIUS servers for accounting. • group named-group—Uses a named subset of TACACS+ or RADIUS servers for accounting, as defined by the aaa group server tacacs+ or aaa group server radius command.

Command Default AAA accounting is disabled.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines System accounting does not use named accounting lists; you can define only the default list for system accounting.

The default method list is automatically applied to all interfaces or lines. If no default method list is defined, then no accounting takes place.

You can specify up to four methods in the method list.

Task ID	Task ID	Operations
	aaa	read, write

Examples

This example shows how to cause a “start accounting” record to be sent to a TACACS+ server when a router initially boots. A “stop accounting” record is also sent when a router is shut down or reloaded.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa accounting system default start-stop group tacacs+
```

Related Commands	Command	Description
	aaa authentication (XR-VM), on page 6	Creates a method list for authentication.
	aaa authorization (XR-VM), on page 8	Creates a method list for authorization.

aaa accounting update

To enable periodic interim accounting records to be sent to the accounting server, use the **aaa accounting update** command in XR Config mode. To disable the interim accounting updates, use the **no** form of this command.

```
aaa accounting update {periodic minutes}
```

Syntax Description	periodic minutes	(Optional) Sends an interim accounting record to the accounting server periodically, as defined by the <i>minutes</i> argument, which is an integer that specifies the number of minutes. The range is from 1 to 35791394 minutes.
--------------------	---------------------	--

Command Default AAA accounting update is disabled.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines When used with the **periodic** keyword, interim accounting records are sent periodically as defined by the *minutes* argument. The interim accounting record contains all the accounting information recorded for that user up to the time the accounting record is sent.



Caution Using the **aaa accounting update** command with the **periodic** keyword can cause heavy congestion when many users are logged into the network.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to send periodic interim accounting records to the RADIUS server at 30-minute intervals:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# aaa accounting update periodic 30
```

Related Commands	Command	Description
	aaa accounting, on page 2	Creates a method list for accounting.
	aaa authorization (XR-VM), on page 8	Creates a method list for authorization.

aaa authentication (XR-VM)

To create a method list for authentication, use the **aaa authentication** command. To disable this authentication method, use the **no** form of this command.

aaa authentication {**login** | **ppp**} {**default***list-name*} *method-list*

Syntax Description		
login	Sets authentication for login.	
ppp	Sets authentication for Point-to-Point Protocol.	
default	Uses the listed authentication methods that follow this keyword as the default list of methods for authentication.	
subscriber	Sets the authentication list for the subscriber.	
<i>list-name</i>	Character string used to name the authentication method list.	
<i>method-list</i>	Method used to enable AAA system accounting. The value is one of the following options:	
	<ul style="list-style-type: none"> • group tacacs+—Specifies a method list that uses the list of all configured TACACS+ servers for authentication. • group radius—Specifies a method list that uses the list of all configured RADIUS servers for authentication. • group <i>named-group</i>—Specifies a method list that uses a named subset of TACACS+ or RADIUS servers for authentication, as defined by the aaa group server tacacs+ or aaa group server radius command. • local—Specifies a method list that uses the local username database method for authentication. AAA method rollover happens beyond the local method if username is not defined in the local group. • line—Specifies a method list that uses the line password for authentication. 	

Command Default Default behavior applies the local authentication on all ports.

Command Modes XR Config mode
System Admin Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **aaa authentication** command to create a series of authentication methods, or method list. You can specify up to four methods in the method list. A *method list* is a named list describing the authentication methods (such as TACACS+ or RADIUS) in sequence. The subsequent methods of authentication are used only if the initial method is not available, not if it fails.

The default method list is applied for all interfaces for authentication, except when a different named method list is explicitly specified—in which case the explicitly specified method list overrides the default list.

For console and vty access, if no authentication is configured, a default of local method is applied.

**Note**

- The **group tacacs+**, **group radius**, and **group group-name** forms of this command refer to a set of previously defined TACACS+ or RADIUS servers.
- Use the **tacacs-server host** or **radius-server host** command to configure the host servers.
- Use the **aaa group server tacacs+** or **aaa group server radius** command to create a named subset of servers.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to specify the default method list for authentication, and also enable authentication for console in XR config mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa authentication login default group tacacs+
```

Related Commands

Command	Description
aaa accounting, on page 2	Creates a method list for accounting.
aaa authorization (XR-VM), on page 8	Creates a method list for authorization.
aaa group server radius, on page 16	Groups different RADIUS server hosts into distinct lists and distinct methods.
aaa group server tacacs+, on page 17	Groups different TACACS+ server hosts into distinct lists and distinct methods.
login authentication, on page 33	Enables AAA authentication for logins.

Command	Description
tacacs-server host , on page 72	Specifies a TACACS+ host.

aaa authorization (XR-VM)

To create a method list for authorization, use the **aaa authorization** command in XR Config mode. To disable authorization for a function, use the **no** form of this command.

```
aaa authorization { commands | eventmanager | exec | network | subscriber | nacm } { default
list-name } { none | local | prefer-external | only-external | group { tacacs + | radius group-name
} }
```

Syntax Description

commands	Configures authorization for all XR EXEC shell commands.
eventmanager	Applies an authorization method for authorizing an event manager (fault manager).
exec	Configures authorization for an interactive (XR EXEC) session.
network	Configures authorization for network services, such as PPP or Internet Key Exchange (IKE).
subscriber	Sets the authorization lists for the subscriber.
nacm	Enables the nacm functionality.
default	Uses the listed authorization methods that follow this keyword as the default list of methods for authorization.
<i>list-name</i>	Character string used to name the list of authorization methods.
none	Uses no authorization. If you specify none , no subsequent authorization methods is attempted. However, the task ID authorization is always required and cannot be disabled.
local	Uses local authorization.
prefer-external	Adds the external group names to the list of local group names to determine the access control rules.
only-external	Uses the external group names to determine the access control rules.
group tacacs+	Uses the list of all configured TACACS+ servers for authorization.
group radius	Uses the list of all configured RADIUS servers for authorization. This method of authorization is not available for command authorization.
group group-name	Uses a named subset of TACACS+ or RADIUS servers for authorization as defined by the aaa group server tacacs+ or aaa group server radius command.

Command Default

Authorization is disabled for all actions (equivalent to the method **none** keyword).

Command Modes XR Config mode

Command History	Release	Modification
	Release 7.4.1	NACM prefer-external and only-external keywords are introduced.
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **aaa authorization** command to create method lists defining specific authorization methods that can be used on a per line or a per interface basis. You can specify up to four methods in the method list.



Note NACM authorization cannot be configured on a per line or a per interface basis.



Note The NACM authorization mentioned here applies to the one performed by an external AAA server and *not* for task-based authorization.

Method lists for authorization define the ways authorization will be performed and the sequence in which these methods will be performed. A method list is a named list describing the authorization methods (such as TACACS+), in sequence. Method lists enable you to designate one or more security protocols for authorization, thus ensuring a backup system in case the initial method fails. Cisco IOS XR software uses the first method listed to authorize users for specific network services; if that method fails to respond, Cisco IOS XR software selects the next method listed in the method list. This process continues until there is successful communication with a listed authorization method or until all methods defined have been exhausted.



Note Cisco IOS XR software attempts authorization with the next listed method only when there is no response (not a failure) from the previous method. If authorization fails at any point in this cycle—meaning that the security server or local username database responds by denying the user services—the authorization process stops and no other authorization methods are attempted.

The Cisco IOS XR software supports the following methods for authorization:

- **none**—The router does not request authorization information; authorization is not performed over this line or interface.
- **local**—Use the local database for authorization.
- **prefer-external**—Use the external database for authorization. The external group names are added to the list of local group names list to determine the access control rules. External group names are preferred from the list. If the option is not mentioned, the local group names are preferred from the list.
- **only-external**—Use only external group names to determine the access control rules.
- **group tacacs+**—Use the list of all configured TACACS+ servers for authorization.
- **group radius**—Use the list of all configured RADIUS servers for authorization.
- **group group-name**—Uses a named subset of TACACS+ or RADIUS servers for authorization.



Note The group RADIUS is not applicable to NACM and command authorizations.

Method lists are specific to the type of authorization being requested. Cisco IOS XR software supports four types of AAA authorization:

- **Commands authorization**—Applies to the XR EXEC mode commands a user issues. Command authorization attempts authorization for all XR EXEC mode commands.



Note “Command” authorization is distinct from “task-based” authorization, which is based on the task profile established during authentication.

- **XR EXEC authorization**—Applies authorization for starting an XR EXEC session.
- **Network authorization**—Applies authorization for network services, such as IKE.
- **Event manager authorization**—Applies an authorization method for authorizing an event manager (fault manager). You are allowed to use TACACS+ or LOCAL.

When you create a named method list, you are defining a particular list of authorization methods for the indicated authorization type. When defined, method lists must be applied to specific lines or interfaces before any of the defined methods are performed.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to define the network authorization method list named listname1, which specifies that TACACS+ authorization is used:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa authorization commands listname1 group tacacs+
```

Examples

The following example shows how to enable the NACM authorization to use the external group names for determining the access control rules. NACM is disabled by default. To enable NACM, you must have `root-lr` or `aaa write` task privilege to enable or disable NACM.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa authorization nacm default only-external local
```

Related Commands

Command	Description
aaa accounting, on page 2	Creates a method list for accounting.

aaa authorization (System Admin-VM)

To create command rules and data rules on System Admin VM for user authorization, use the **aaa authorization** command in System Admin Config mode. To delete the command rules and data rules, use the **no** form of this command.

```
aaa authorization { cmdrules cmdrule { integer | range integer } [{ action action-type |
command cmd-name | context context-name | group group-name | ops ops-type }] | commands
group { none | tacacs } | datarules datarule { integer | range integer } [{ action action-type
| context context-name | group group-name | keypath keypath-name | namespace namespace-string
| ops ops-type } ] }
```

Syntax Description		
cmdrules		Configures command rules.
cmdrule <i>integer</i>		Specifies the command rule number.
range <i>integer</i>		Specifies the range of the command rules or data rules to be configured.
action		Specifies whether users are permitted or not allowed to perform the operation specified for the ops keyword.
<i>action-type</i>		Specifies the action type for the command rule or data rule. Available options are: accept , accept_log and reject .
command <i>cmd-name</i>		Specifies the command to which the command rule applies. The command must be entered within double-quotes. Example, get .
context <i>context-name</i>		Specifies to which type of connection the command rule or data rule applies. The connection type can be netconf, cli, or xml.
group <i>group-name</i>		Specifies the group to which the command rule or data rule applies. Example, admin-r .
ops <i>ops-type</i>		Specifies whether the user has read, execute, or read and execute permissions for the command. Available options for command rules are: r , rx , and x . To know the available options for data rules, use a ? after the ops keyword.
commands group		Sets the command authorization lists for server groups. Available options are none that specifies no authorization and tacacs that specifies use of the list of all tacacs+ hosts.
datarules		Configures data rules.
datarule <i>integer</i>		Specifies the data rule number.
keypath		Specifies the keypath of the data element. If you enter an asterisk '*' for keypath, it indicates that the command rule is applicable to all configuration data.

namespace	Enter asterisk "*" to indicate that the data rule is applicable for all namespace values.
------------------	---

Command Default	None
------------------------	------

Command Modes	System Admin Config mode
----------------------	--------------------------

Command History	Release	Modification
	Release 6.1.2	This command was introduced.

Usage Guidelines

From Cisco IOS XR Software Release 7.4.1 and later, the system internally maps the users configured on the XR VM to System Admin VM of the router, based on the task table of the user on the XR VM. With this feature, NETCONF and gRPC users can access the admin-related information on the router even if their user profiles do not exist on System Admin VM. For a sample configuration, see the example section.

For more details, see the *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

This example shows how to create a command rule:

```
sysadmin-vm:0_RP0#config
sysadmin-vm:0_RP0(config)#aaa authorization cmdrules cmdrule 10 action accept command "show platform" context cli group group1 ops rx
```

This example shows how to create a data rule:

```
sysadmin-vm:0_RP0#config
sysadmin-vm:0_RP0(config)#aaa authorization datarules datarule 20 action accept context cli group group10 keypath * namespace * ops rx
```

This example shows how to configure a command rule for a NETCONF or gRPC session to allow read access for **admin-r** group users:

```
sysadmin-vm:0_RP0(config)#aaa authorization cmdrules cmdrule 6 context netconf command get group admin-r ops rx action accept
```

show nacm (XR-VM)

To display information about NETCONF Access Control information such as users, groups, rule-lists and traces, use the **show nacm** command in XR Config mode. To disable authorization for a function, use the **no** form of this command.

```
show nacm {summary || users [<user-name>] || groups [<group-name>] || rule-list [<rule-list-name>] | rule [<rule-name>] ] ] | trace}
```

Syntax Description	summary	Displays NACM summary information.
---------------------------	----------------	------------------------------------

	Users	Displays list of users in NACM database.
--	--------------	--

	user-name	Displays info for a given user-name.
--	------------------	--------------------------------------

groups	Displas list of groups in the NACM database.
<i>group-name</i>	Displays information for a given group name.
rule-list	Displays list of rule-lists in the NACM database.
<i>rule-list-name</i>	Displays info for given rule-list-name.
rule	Displays list of rules under the rule-list in the NACM database.
<i>rule-name</i>	Displays info for given rule-name under rule-name in the NACM database.
trace tacacs+	Displays NACM process traces.

Command Default

None

Command Modes

XR Config mode

Command History

Release	Modification
Release 6.4.1	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
nacm	read

Examples

The following example shows how to use the show nacm command:

```
RP/0/RP0/CPU0:xr-nacm #show nacm summary
NACM SUMMARY
-----
Enable Nacm : False
Enable External Groups : True
Number of Groups : 2
Number of Users : 2
Number of Rules : 2
Number of Rulelist : 2
Default Read : permit
Default Write : permit
Default Exec : permit
Denied Operations : 0
Denied Data Writes : 0
Denied Notifications : 0
-----
RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm users
USERS LIST:
-----
lab,      admin,
-----
```

show nacm (XR-VM)

```

RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm users lab

USER NAME: lab
-----
Groups List For User:
root-lr,    root-system,
-----

RP/0/RP0/CPU0:xr-nacm#

RP/0/RP0/CPU0:xr-nacm#show nacm groups

GROUPS LIST:
-----
root-system,    root-lr,
-----

RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm groups root-system

GROUP NAME: root-system
-----
Users List:
admin,    lab,
Rules List:
rule-list-1,    rule-list-2,
-----

RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm rule-list
RULELISTS:
-----
      Rulelist Index      Rulelist Name
      rule-list-2         rule-list-2
      rule-list-1         rule-list-1
-----

RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm rule-list rule-list-1,rule-list-1
RULELIST NAME: rule-list-1
-----
      Rule Index          Rule Name
      rule1               rule1
      rule2               rule2
      Group List
root-system,    root-lr,
-----

RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm rule-list rule-list-1,rule-list-1 rule

Rule Info:
      Name:                rule1
      Index:               rule1
      Value:                edit-config
      ModuleName:          *
      Action:               permit
      RuleType:             Rpc
      Comment:
      AccessOperations:     All
      HitCount:             0
-----

Rule Info:
      Name:                rule2
      Index:               rule2
      Value:                /nacm/rule-list

```

```

ModuleName:          ietf-netconf-acm
Action:              deny
RuleType:            Data
Comment:
AccessOperations:    Read,
HitCount:            0
-----
RP/0/RP0/CPU0:xr-nacm#
RP/0/RP0/CPU0:xr-nacm#show nacm rule-list rule-list-1,rule-list-1 rule rule2,rule2
RULELIST NAME: rule-list-1
-----
Rule Info:
Name:                rule2
Index:               rule2
Value:               /nacm/rule-list
ModuleName:          ietf-netconf-acm
Action:              deny
RuleType:            Data
Comment:
AccessOperations:    Read,
HitCount:            0
-----
RP/0/RP0/CPU0:xr-nacm#

```

Related Commands	Command	Description
	aaa accounting, on page 2	Creates a method list for accounting.

aaa default-taskgroup

To specify a task group for both remote TACACS+ authentication and RADIUS authentication, use the **aaa default-taskgroup** command in XR Config mode. To remove this default task group, enter the **no** form of this command.

aaa default-taskgroup *taskgroup-name*

Syntax Description	<i>taskgroup-name</i> Name of an existing task group.				
Command Default	No default task group is assigned for remote authentication.				
Command Modes	XR Config mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.				

Use the **aaa default-taskgroup** command to specify an existing task group for remote TACACS+ authentication.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to specify taskgroup1 as the default task group for remote TACACS+ authentication:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# aaa default-taskgroup taskgroup1
```

aaa group server radius

To group different RADIUS server hosts into distinct lists, use the **aaa group server radius** command in XR Config mode. To remove a group server from the configuration list, enter the **no** form of this command.

aaa group server radius *group-name*

Syntax Description *group-name* Character string used to name the group of servers.

Command Default This command is not enabled.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **aaa group server radius** command to group existing server hosts, which allows you to select a subset of the configured server hosts and use them for a particular service. A server group is used in conjunction with a global server-host list. The server group lists the IP addresses or hostnames of the selected server hosts.

Server groups can also include multiple host entries for the same server, as long as each entry has a unique identifier. The combination of an IP address and User Datagram Protocol (UDP) port number creates a unique identifier, allowing different ports to individually defined as RADIUS hosts providing a specific authentication, authorization, and accounting (AAA) service. In other words, this unique identifier enables RADIUS requests to be sent to different UDP ports on a server at the same IP address. If two different host entries on the same RADIUS server are configured for the same service, for example, accounting, the second host entry acts as an automatic switchover backup to the first host entry. Using this example, if the first host entry fails to provide accounting services, the network access server tries the second host entry on the same device for accounting services. The RADIUS host entries are tried in the order in which they are configured in the server group.

All members of a server group must be the same type, that is, RADIUS.

The server group cannot be named radius or tacacs.

This command enters server group configuration mode. You can use the server command to associate a particular RADIUS server with the defined server group.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows the configuration of an AAA group server named radgroup1, which comprises three member servers:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa group server radius radgroup1
RP/0/RP0/CPU0:router(config-sg-radius)# server 10.0.0.5 auth-port 1700 acct-port 1701
RP/0/RP0/CPU0:router(config-sg-radius)# server 10.0.0.10 auth-port 1702 acct-port 1703
RP/0/RP0/CPU0:router(config-sg-radius)# server 10.0.0.20 auth-port 1705 acct-port 1706
```



Note If the **auth-port** *port-number* and **acct-port** *port-number* keywords and arguments are not specified, the default value of the *port-number* argument for the **auth-port** keyword is 1645 and the default value of the *port-number* argument for the **acct-port** keyword is 1646.

Related Commands	Command	Description
	radius source-interface , on page 42	Forces RADIUS to use the IP address of a specified interface or subinterface for all outgoing RADIUS packets.
	server (RADIUS) , on page 46	Associates a RADIUS server with a defined server group.
	server-private (RADIUS) , on page 48	Configures the IP address of the private RADIUS server for the group server.
	vrf (RADIUS) , on page 92	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group.

aaa group server tacacs+

To group different TACACS+ server hosts into distinct lists, use the **aaa group server tacacs+** command in XR Config mode. To remove a server group from the configuration list, enter the **no** form of this command.

```
aaa group server tacacs+ group-name
```

Syntax Description *group-name* Character string used to name a group of servers.

Command Default This command is not enabled.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines The AAA server-group feature introduces a way to group existing server hosts. The feature enables you to select a subset of the configured server hosts and use them for a particular service.

The **aaa group server tacacs+** command enters server group configuration mode. The **server** command associates a particular TACACS+ server with the defined server group.

A *server group* is a list of server hosts of a particular type. The supported server host type is TACACS+ server hosts. A server group is used with a global server host list. The server group lists the IP addresses or hostnames of the selected server hosts.

The server group cannot be named radius or tacacs.



Note Group name methods refer to a set of previously defined TACACS+ servers. Use the **tacacs-server host** command to configure the host servers.

From Cisco IOS XR Software Release 7.4.1 and later, you can configure a hold-down timer for TACACS+ server. For details, see the **holddown-time** command.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows the configuration of an AAA group server named tacgroup1, which comprises three member servers:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa group server tacacs+ tacgroup1
RP/0/RP0/CPU0:router(config-sg-tacacs)# server 192.168.200.226
RP/0/RP0/CPU0:router(config-sg-tacacs)# server 192.168.200.227
RP/0/RP0/CPU0:router(config-sg-tacacs)# server 192.168.200.228
```

Related Commands

Command	Description
aaa accounting, on page 2	Creates a method list for accounting.
aaa authentication (XR-VM), on page 6	Creates a method list for authentication.
aaa authorization (XR-VM), on page 8	Creates a method list for authorization.

Command	Description
server (TACACS+), on page 47	Specifies the host name or IP address of an external TACACS+ server.
tacacs-server host, on page 72	Specifies a TACACS+ host.

aaa password-policy

To define a AAA password security policy, use the **aaa password-policy** command in XR Config mode. To remove the AAA password security policy, use the **no** form of this command.

```
aaa password-policy policy-name {min-length min-length | max-length max-length | special-char
special-char | upper-case upper-case | lower-case lower-case | numeric numeric | lifetime {years |
months | days | hours | minutes | seconds} lifetime | min-char-change min-char-change |
authen-max-attempts authen-max-attempts | lockout-time {days | hours | minutes | seconds} lockout-time
| warn-interval { years | months | days | hours | minutes | seconds } | restrict-old-time { years
| months | days } | max-char-repetition max-char-repetition | restrict-old-count restrict-old-count
| restrict-password-advanced | restrict-password-reverse | restrict-username |
restrict-username-reverse }
```

Syntax Description	
<i>policy-name</i>	Specifies the name of the password, in characters.
min-length	Specifies the minimum length of the password, in integer.
max-length	Specifies the maximum length of the password, in integer.
special-char	Specifies the number of special characters allowed in the password policy, in integer.
upper-case	Specifies the number of upper case alphabets allowed in the password policy, in integer.
lower-case	Specifies the number of lower case alphabets allowed in the password policy, in integer.
numeric	Specifies the number of numerals allowed in the password policy, in integer.
lifetime	Specifies the maximum lifetime for the password, the value of which is specified in integer, as years, months, days, hours, minutes or seconds.
min-char-change	Specifies the number of character change required between subsequent passwords, in integer.
authen-max-attempts	Specifies, in integer, the maximum number of authentication failure attempts allowed for a user, in order to restrict users who authenticate with invalid login credentials.
lockout-time	Specifies, in integer, the duration (in days, hours, minutes or seconds) for which the user is locked out when he exceeds the maximum limit of authentication failure attempts allowed.

warn-interval	Specifies the amount of time to notify the user about an expiring password, the value of which is specified in integer, as years, months, days, hours, minutes or seconds.
restrict-old-time	Specifies, in integer, the amount of time for which an old password is considered as valid. The value is specified in years, months, or days.
max-char-repetition	Specifies the consecutive number of times a character can be repeated in a password.
restrict-old-count	Specifies the count for the number of old passwords that cannot be reused.
restrict-password-advanced	Specifies the advanced restrictions on a new password.
restrict-password-reverse	Restricts the new password from being the same as the reversed old password.
restrict-username	Restricts the use of an associated username as a password.
restrict-username-reverse	Restricts the usage of associated username reversed as a password.

Command Default

None

Command Modes

XR Config mode

Command History

Release	Modification
Release 6.2.1	This command was introduced.
Release 7.2.1	The command options (except a few mentioned in the usage guidelines section) were extended to user secret as well.

Usage Guidelines

AAA password security policy works as such for Cisco IOS XR platforms. Whereas, this feature is supported only on XR VM, for Cisco IOS XR 64 bit platforms and Cisco NCS 6000 Series Routers.

For more details on the usage of each option of this command, refer the section on *AAA Password Security for FIPS Compliance* in *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

You must configure both **authen-max-attempts** and **lockout-time** in order for the lock out functionality to take effect.

The **min-char-change** option is effective only for password change through logon, and not for password change by configuration.

Use **username** command along with **password-policy** option, in the XR Config mode, to associate the password policy with a particular user.

When **warn-interval** is enabled and it expires, the user is prompted at login to change the password or has the option to skip. If **warn-interval** and **lifetime** have both expired, the user must change their password.

From Cisco IOS XR Software Release 7.2.1 and later, most of the options of the **aaa password-policy** command listed in the syntax above are applicable to user password as well as secret. Whereas, the options listed below are supported only for password, and not for secret:

- **max-char-repetition**
- **min-char-change**
- **restrict-password-reverse**
- **restrict-password-advanced**

This table lists the default, maximum and minimum values of various command variables:

Command Variables	Default Value	Maximum Value	Minimum Value
<i>policy-name</i>	None	253	1
<i>max-length</i>	253	253	2
<i>min-length</i>	2	253	2
<i>special-char</i>	0	253	0
<i>upper-case</i>	0	253	0
<i>lower-case</i>	0	253	0
<i>numeric</i>	0	253	0
For lifetime :			
years	0	99	1
months	0	11	1
days	0	30	1
hours	0	23	1
minutes	0	59	1
seconds	0	59	1
<i>min-char-change</i>	4	253	0
<i>authen-max-attempts</i>	0	24	1
For lockout-time :			
days	0	225	1
hours	0	23	1
minutes	0	59	1
seconds	0	59	1
For warn-interval :			
years	0	99	1

Command Variables	Default Value	Maximum Value	Minimum Value
months	0	11	1
days	0	30	1
hours	0	23	1
minutes	0	59	1
seconds	0	59	1
For restrict-old-time :			
years	0	99	1
months	0	11	1
days	0	30	1
<i>max-char-repetition</i>	0	5	2
<i>restrict-old-count</i>	0	10	1

Task ID**Task ID Operation**

aaa	read, write
-----	----------------

This example shows how to define a AAA password security policy:

```
RP/0/RP0/CPU0:router (config) #aaa password-policy test-policy
RP/0/RP0/CPU0:router (config-aaa) #min-length 8
RP/0/RP0/CPU0:router (config-aaa) #max-length 15
RP/0/RP0/CPU0:router (config-aaa) #lifetime months 3
RP/0/RP0/CPU0:router (config-aaa) #min-char-change 5
RP/0/RP0/CPU0:router (config-aaa) #authen-max-attempts 3
RP/0/RP0/CPU0:router (config-aaa) #lockout-time days 1
RP/0/RP0/CPU0:router (config-aaa) #warn-interval months 2
RP/0/RP0/CPU0:router (config-aaa) #restrict-old-time years 3
RP/0/RP0/CPU0:router (config-aaa) #max-char-repetition 3
RP/0/RP0/CPU0:router (config-aaa) #restrict-old-count 3
RP/0/RP0/CPU0:router (config-aaa) #restrict-password-reverse
RP/0/RP0/CPU0:router (config-aaa) #restrict-password-advanced
RP/0/RP0/CPU0:router (config-aaa) #restrict-username
RP/0/RP0/CPU0:router (config-aaa) #restrict-username-reverse
```

Related Commands

Command	Description
show aaa password-policy, on page 55	Displays the details of AAA password policy.
username, on page 84	

accounting (line)

To enable authentication, authorization, and accounting (AAA) accounting services for a specific line or group of lines, use the **accounting** command in line template configuration mode. To disable AAA accounting services, use the **no** form of this command.

accounting {**commands** | **exec**} {**default***list-name*}

Syntax Description	
commands	Enables accounting on the selected lines for all XR EXEC shell commands.
exec	Enables accounting of XR EXEC session.
default	The name of the default method list, created with the aaa accounting command.
<i>list-name</i>	Specifies the name of a list of accounting methods to use. The list is created with the aaa accounting command.

Command Default Accounting is disabled.

Command Modes Line template configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines After you enable the **aaa accounting** command and define a named accounting method list (or use the default method list) for a particular type of accounting, you must apply the defined lists to the appropriate lines for accounting services to take place. Use the **accounting** command to apply the specified method lists to the selected line or group of lines. If a method list is not specified this way, no accounting is applied to the selected line or group of lines.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to enable command accounting services using the accounting method list named *listname2* on a line template named *configure*:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# line template configure
RP/0/RP0/CPU0:router(config-line)# accounting commands listname2
```

Related Commands	Command	Description
	aaa accounting, on page 2	Creates a method list for accounting.

authorization (line)

To enable authentication, authorization, and accounting (AAA) authorization for a specific line or group of lines, use the **authorization** command in line template configuration mode. To disable authorization, use the **no** form of this command.

authorization {**commands** | **exec** | **eventmanager**} {**default***list-name*}

Syntax Description	Parameter	Description
	commands	Enables authorization on the selected lines for all commands.
	exec	Enables authorization for an interactive (EXEC)(XR EXEC) session.
	default	Applies the default method list, created with the aaa authorization command.
	eventmanager	Sets eventmanager authorization method. This method is used for the embedded event manager.
	<i>list-name</i>	Specifies the name of a list of authorization methods to use. If no list name is specified, the system uses the default. The list is created with the aaa authorization command.

Command Default Authorization is not enabled.

Command Modes Line template configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines After you use the **aaa authorization** command to define a named authorization method list (or use the default method list) for a particular type of authorization, you must apply the defined lists to the appropriate lines for authorization to take place. Use the **authorization** command to apply the specified method lists (or, if none is specified, the default method list) to the selected line or group of lines.

Task ID	Task ID	Operations
	aaa	read, write

Examples The following example shows how to enable command authorization using the method list named *listname4* on a line template named *configure*:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# line template configure
RP/0/RP0/CPU0:router(config-line)# authorization commands listname4
```

Related Commands	Command	Description
	aaa authorization (XR-VM), on page 8	Creates a method list for authorization.

deadtime (server-group configuration)

To configure the deadtime value at the RADIUS server group level, use the **deadtime** command in server-group configuration mode. To set deadtime to 0, use the **no** form of this command.

deadtime *minutes*

Syntax Description	
	<i>minutes</i> Length of time, in minutes, for which a RADIUS server is skipped over by transaction requests, up to a maximum of 1440 (24 hours). The range is from 1 to 1440.

Command Default	
	Deadtime is set to 0.

Command Modes	
	Server-group configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines	
	The value of the deadtime set in the server groups overrides the deadtime that is configured globally. If the deadtime is omitted from the server group configuration, the value is inherited from the primary list. If the server group is not configured, the default value of 0 applies to all servers in the group. If the deadtime is set to 0, no servers are marked dead.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example specifies a one-minute deadtime for RADIUS server group **group1** when it has failed to respond to authentication requests for the **deadtime** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa group server radius group1
RP/0/RP0/CPU0:router(config-sg-radius)# server 10.1.1.1 auth-port 1645 acct-port 1646
RP/0/RP0/CPU0:router(config-sg-radius)# server 10.2.2.2 auth-port 2000 acct-port 2001
RP/0/RP0/CPU0:router(config-sg-radius)# deadtime 1
```

Related Commands	Command	Description
	aaa group server tacacs+ , on page 17	Groups different RADIUS server hosts into distinct lists and distinct methods.
	radius-server dead-criteria time , on page 37	Forces one or both of the criteria that is used to mark a RADIUS server as dead.
	radius-server deadtime(BNG) , on page 39	Defines the length of time in minutes for a RADIUS server to remain marked dead.

description (AAA)

To create a description of a task group or user group during configuration, use the **description** command in task group configuration or user group configuration mode. To delete a task group description or user group description, use the **no** form of this command.

description *string*

Syntax Description *string* Character string describing the task group or user group.

Command Default None

Command Modes Task group configuration
User group configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines Use the **description** command inside the task or user group configuration submode to define a description for the task or user group, respectively.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows the creation of a task group description:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# taskgroup alpha
RP/0/RP0/CPU0:router(config-tg)# description this is a sample taskgroup
```

The following example shows the creation of a user group description:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# usergroup alpha
RP/0/RP0/CPU0:router(config-ug)# description this is a sample user group
```

Related Commands	Command	Description
	taskgroup, on page 80	Accesses task group configuration mode and configures a task group by associating it with a set of task IDs.
	usergroup, on page 83	Accesses user group configuration mode and configures a user group by associating it with a set of task groups.

group (AAA)

To add a user to a group, use the **group** command in username configuration mode. To remove the user from a group, use the **no** form of this command.

```
group {root-lr | netadmin | sysadmin | operator | cisco-support | serviceadmin}group-name}
```

Syntax Description	Option	Description
	root-lr	Adds the user to the predefined root-lr group. Only users with root-lr authority may use this option.
	netadmin	Adds the user to the predefined network administrators group.
	sysadmin	Adds the user to the predefined system administrators group.
	operator	Adds the user to the predefined operator group.
	cisco-support	Adds the user to the predefined Cisco support personnel group.
	Note	Starting from IOS XR 4.3.1 release, the cisco-support group is combined with the root-system group. This means a user who is part of the root-system group can also access commands that are included in the cisco-support group.
	serviceadmin	Adds the user to the predefined service administrators group.
	group-name	Adds the user to a named user group that has already been defined with the usergroup command.

Command Modes Username configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **group** command in username configuration mode. To access username configuration mode, use the [username, on page 84](#) command in XR Config mode.

The privileges associated with the cisco-support group are now included in the root-system group. The cisco-support group is no longer required to be used for configuration.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to assign the user group operator to the user named user1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# username user1
RP/0/RP0/CPU0:router (config-un)# group operator
```

Related Commands

Command	Description
password (AAA), on page 34	Creates a login password for a user.
usergroup, on page 83	Configures a user group and associates it with a set of task groups.
username, on page 84	Accesses username configuration mode, configures a new user with a username, and establishes a password and permissions for that user.

holddown-time (TACACS+)

To specify a duration for which an unresponsive TACACS+ server is to be marked as down, and not be used for sending further client requests for that duration, use the **holddown-time** command in various configuration modes. To disable this feature, use the **no** form of this command or configure the hold down timer value as zero.

holddown-time *time*

Syntax Description

time Specifies the hold-down timer value, in seconds.

The range is from 0 to 1200. Zero indicates that the hold-down timer feature is disabled.

Command Default

By default, the TACACS+ hold-down timer is disabled.

Command Modes

TACACS server
TACACS+ server group
TACACS+ private server

Command History	Release	Modification
	Release 7.4.1	This command was introduced for Cisco IOS XR 64-bit platforms.

Usage Guidelines



Note To set the hold-down timer at global level, use the **tacacs-server holddown-time** command in XR Config mode.

While selecting the timer at various configuration levels, the system gives preference to the one which is more specific to the server. That is, the server-level timer has the highest precedence, followed by server group-level and finally, the global-level.

Also, see the *Guidelines for Configuring Hold-Down Timer for TACACS+* section in the *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

Task ID	Task ID	Operations
	aaa	read, write

Examples

This example shows how to mark an unresponsive TACACS+ server as being down, and not to use it for sending further client requests for a duration of 35 seconds:

```
Router(config)#tacacs-server host 10.105.236.102 port 2020
Router(config-tacacs-host)#holddown-time 35
```

This example shows how to set a hold-down timer at global level:

```
Router#configure
Router(config)#tacacs-server holddown-time 30
```

This example shows how to set a hold-down timer at server-group level:

```
Router#configure
Router(config)#aaa group server tacacs+ test-group
Router(config-sg-tacacs)#holddown-time 40
```

This example shows how to set a hold-down timer at private server level:

```
Router(config)#aaa group server tacacs+ test-group
Router(config-sg-tacacs)#server-private 10.105.236.109 port 2020
Router(config-sg-tacacs-private)#holddown-time 55
Router(config-sg-tacacs-private)#commit
```

Related Commands	Command	Description
	aaa group server tacacs+, on page 17	Groups different TACACS+ server hosts into distinct lists.

Command	Description
tacacs-server host , on page 72	Configures a TACACS+ host server.

inherit taskgroup

To enable a task group to derive permissions from another task group, use the **inherit taskgroup** command in task group configuration mode.

inherit taskgroup {*taskgroup-name* | **netadmin** | **operator** | **sysadmin** | **cisco-support** | **root-lr** | **serviceadmin**}

Syntax Description	
<i>taskgroup-name</i>	Name of the task group from which permissions are inherited.
netadmin	Inherits permissions from the network administrator task group.
operator	Inherits permissions from the operator task group.
sysadmin	Inherits permissions from the system administrator task group.
cisco-support	Inherits permissions from the cisco support task group.
root-lr	Inherits permissions from the root-lr task group.
serviceadmin	Inherits permissions from the service administrators task group.

Command Default None

Command Modes Task group configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **inherit taskgroup** command to inherit the permissions (task IDs) from one task group into another task group. Any changes made to the taskgroup from which they are inherited are reflected immediately in the group from which they are inherited.

Task ID	Task ID	Operations
	aaa	read, write

Examples

In the following example, the permissions of task group tg2 are inherited by task group tg1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# taskgroup tg1
RP/0/RP0/CPU0:router(config-tg)# inherit taskgroup tg2
RP/0/RP0/CPU0:router(config-tg)# end
```

inherit usergroup

To enable a user group to derive characteristics of another user group, use the **inherit usergroup** command in user group configuration mode.

inherit usergroup *usergroup-name*

Syntax Description

usergroup-name Name of the user group from which permissions are to be inherited.

Command Default

None

Command Modes

User group configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Each user group is associated with a set of task groups applicable to the users in that group. A task group is defined by a collection of task IDs. Task groups contain task ID lists for each class of action. The task permissions for a user are derived (at the start of the EXEC or XML session) from the task groups associated with the user groups to which that user belongs.

User groups support inheritance from other user groups. Use the **inherit usergroup** command to copy permissions (task ID attributes) from one user group to another user group. The “destination” user group inherits the properties of the inherited group and forms a union of all task IDs specified in those groups. For example, when user group A inherits user group B, the task map of the user group A is a union of that of A and B. Cyclic inclusions are detected and rejected. User groups cannot inherit properties from predefined groups, such as , root-sdr users, netadmin users, and so on. Any changes made to the usergroup from which it is inherited are reflected immediately in the group from which it is inherited.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to enable the purchasing user group to inherit properties from the sales user group:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# usergroup purchasing
RP/0/RP0/CPU0:router(config-ug)# inherit usergroup sales
```

Related Commands	Command	Description
	description (AAA), on page 26	Creates a description of a task group in task group configuration mode, or creates a description of a user group in user group configuration mode.
	taskgroup, on page 80	Configures a task group to be associated with a set of task IDs.
	usergroup, on page 83	Configures a user group to be associated with a set of task groups.

key (TACACS+)

To specify an authentication and encryption key shared between the AAA server and the TACACS+ server, use the **key (TACACS+)** command in TACACS host configuration mode. To disable this feature, use the **no** form of this command.

key {**0** *clear-text-key* | **7** *encrypted-keyauth-key*}

Syntax Description	
0 <i>clear-text-key</i>	Specifies an unencrypted (cleartext) shared key.
7 <i>encrypted-key</i>	Specifies an encrypted shared key.
<i>auth-key</i>	Specifies the unencrypted key between the AAA server and the TACACS+ server.

Command Default None

Command Modes TACACS host configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines The TACACS+ packets are encrypted using the key, and it must match the key used by the TACACS+ daemon. Specifying this key overrides the key set by the **tacacs-server key** command for this server only.

The key is used to encrypt the packets that are going from TACACS+, and it should match with the key configured on the external TACACS+ server so that the packets are decrypted properly. If a mismatch occurs, the result fails.

Task ID	Task ID	Operations
	aaa	read, write

Examples The following example shows how to set the encrypted key to anykey

```
RP/0/RP0/CPU0:router(config)# tacacs-server host 209.165.200.226
RP/0/RP0/CPU0:router(config-tacacs-host)# key anykey
```

Related Commands	Command	Description
	tacacs-server host, on page 72	Specifies a TACACS+ host.
	tacacs-server key, on page 75	Globally sets the authentication encryption key used for all TACACS+ communications between the router and the TACACS+ daemon.

login authentication

To enable authentication, authorization, and accounting (AAA) authentication for logins, use the **login authentication** command in line template configuration mode. To return to the default authentication settings, use the **no** form of this command.

login authentication {**default**/*list-name*}

Syntax Description	default
	Default list of AAA authentication methods, as set by the aaa authentication login command.
<i>list-name</i>	Name of the method list used for authenticating. You specify this list with the aaa authentication login command.

Command Default This command uses the default set with the **aaa authentication login** command.

Command Modes Line template configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines The **login authentication** command is a per-line command used with AAA that specifies the name of a list of AAA authentication methods to try at login.



Caution If you use a *list-name* value that was not configured with the **aaa authentication login** command, the configuration is rejected.

Entering the **no** form of the **login authentication** command has the same effect as entering the command with the **default** keyword.

Before issuing this command, create a list of authentication processes by using the **aaa authentication login** command.

Task ID	Task ID	Operations
	aaa	read, write
	tty-access	read, write

Examples

The following example shows that the default AAA authentication is used for the line template *template1*:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# line template template1
RP/0/RP0/CPU0:router(config-line)# login authentication default
```

The following example shows that the AAA authentication list called *list1* is used for the line template *template2*:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# line template template2
RP/0/RP0/CPU0:router(config-line)# login authentication list1
```

Related Commands

Command	Description
aaa authentication (XR-VM), on page 6	Creates a method list for authentication.

password (AAA)

To create a login password for a user, use the **password** command in username configuration mode or line template configuration mode. To remove the password, use the **no** form of this command.

password {[0] | 7 *password*}

Syntax Description

0	(Optional) Specifies that an unencrypted clear-text password follows.
7	Specifies that an encrypted password follows.
<i>password</i>	Specifies the unencrypted password text to be entered by the user to log in, for example, "lab". If encryption is configured, the password is not visible to the user. Can be up to 253 characters in length.

Command Default

The password is in unencrypted clear text.

Command Modes

Username configuration
Line template configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines You can specify one of two types of passwords: encrypted or clear text.

When an XR EXEC process is started on a line that has password protection, the process prompts for the password. If the user enters the correct password, the process issues the prompt. The user can try three times to enter a password before the process exits and returns the terminal to the idle state.

Passwords are two-way encrypted and should be used for applications such as PPP that need decryptable passwords that can be decrypted.



Note The **show running-config** command always displays the clear-text login password in encrypted form when the **0** option is used.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to establish the unencrypted password *pwd1* for user. The output from the **show** command displays the password in its encrypted form.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# username user1
RP/0/RP0/CPU0:router(config-un)# password 0 pwd1
RP/0/RP0/CPU0:router(config-un)# commit
RP/0/RP0/CPU0:router(config-un)# show running-config
Building configuration...
username user1
password 7 141B1309
```

Related Commands	Command	Description
	group (AAA), on page 27	Adds a user to a group.
	usergroup, on page 83	Accesses user group configuration mode and configures a user group, associating it with a set of task groups.
	username, on page 84	Accesses username configuration mode and configures a new user with a username, establishing a password and granting permissions for that user.
	line	Enters line template configuration mode for the specified line template. For more information, see the <i>Cisco IOS XR System Management Command Reference</i> .

policy (AAA)

To configure a policy that is common for user password as well as secret, use the **policy** command in username configuration mode. To remove this configuration, use the **no** form of this command.

policy *policy-name*

Syntax Description	<i>policy-name</i> Specifies the name of the policy that is common for user password as well as secret.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	username
----------------------	----------

Command History	Release	Modification
	Release 7.2.1	This command was introduced.

Usage Guidelines	For detailed usage guidelines for this command, see the <i>Guidelines to Configure Password Policy for User Secret</i> section in the <i>System Security Configuration Guide for Cisco NCS 6000 Series Routers</i> .
-------------------------	--

Task ID	Task ID	Operation
	aaa	read, write

This example shows how to configure a password policy that applies to both the password and the secret of the user.

```
Router#configure
Router(config)#username user1
Router(config-un)#policy test-policy1
Router(config-un)#secret 10
$6$dmuW0Ajjcf98W0.$y/vzynWF1/OcGxwBwHs79VAy5ZZLhoHd7TicR4mOo81IVriYCGAKW0A.w1JvTPO7IbZry.DxHrE3SN2BBzBJe0
Router(config-un)#commit
```

Related Commands	Command	Description
	aaa password-policy, on page 19	Defines the FIPS-compliant AAA password security policy.
	username, on page 84	

radius-server dead-criteria time

To specify the minimum amount of time, in seconds, that must elapse from the time that the router last received a valid packet from the RADIUS server to the time the server is marked as dead, use the **radius-server dead-criteria time** command in XR Config mode mode. To disable the criteria that were set, use the **no** form of this command.

radius-server dead-criteria time *seconds*

Syntax Description	<p><i>seconds</i> Length of time, in seconds. The range is from 1 to 120 seconds. If the <i>seconds</i> argument is not configured, the number of seconds ranges from 10 to 60, depending on the transaction rate of the server.</p> <p>Note The time criterion must be met for the server to be marked as dead.</p>				
Command Default	If this command is not used, the number of seconds ranges from 10 to 60 seconds, depending on the transaction rate of the server.				
Command Modes	XR Config mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				

Usage Guidelines



Note If you configure the **radius-server dead-criteria time** command before the **radius-server deadtime** command, the **radius-server dead-criteria time** command may not be enforced.

If a packet has not been received since the router booted and there is a timeout, the time criterion is treated as though it were met.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to establish the time for the dead-criteria conditions for a RADIUS server to be marked as dead for the **radius-server dead-criteria time** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# radius-server dead-criteria time 5
```

Related Commands	Command	Description
	radius-server dead-criteria tries, on page 38	Specifies the number of consecutive timeouts that must occur on the router before the RADIUS server is marked as dead.
	radius-server deadtime(BNG), on page 39	Defines the length of time, in minutes, for a RADIUS server to remain marked dead.
	show radius dead-criteria, on page 61	Displays information for the dead-server detection criteria.

radius-server dead-criteria tries

To specify the number of consecutive timeouts that must occur on the router before the RADIUS server is marked as dead, use the **radius-server dead-criteria tries** command in XR Config mode. To disable the criteria that were set, use the **no** form of this command.

radius-server dead-criteria tries

Syntax Description *tries* Number of timeouts from 1 to 100. If the *tries* argument is not configured, the number of consecutive timeouts ranges from 10 to 100, depending on the transaction rate of the server and the number of configured retransmissions.

Note The tries criterion must be met for the server to be marked as dead.

Command Default If this command is not used, the number of consecutive timeouts ranges from 10 to 100, depending on the transaction rate of the server and the number of configured retransmissions.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines If the server performs both authentication and accounting, both types of packet are included in the number. Improperly constructed packets are counted as though they were timeouts. All transmissions, including the initial transmit and all retransmits, are counted.



Note If you configure the **radius-server dead-criteria tries** command before the **radius-server deadtime** command, the **radius-server dead-criteria tries** command may not be enforced.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to establish the number of tries for the dead-criteria conditions for a RADIUS server to be marked as dead for the **radius-server dead-criteria tries** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# radius-server dead-criteria tries 4
```

Related Commands	Command	Description
	radius-server dead-criteria time, on page 37	Defines the length of time in seconds that must elapse from the time that the router last received a valid packet from the RADIUS server to the time the server is marked as dead.
	radius-server deadtime(BNG), on page 39	Defines the length of time, in minutes, for a RADIUS server to remain marked dead.
	show radius dead-criteria, on page 61	Displays information for the dead-server detection criteria.

radius-server deadtime(BNG)

To improve RADIUS response times when some servers are unavailable and cause the unavailable servers to be skipped immediately, use the **radius-server deadtime** command in XR Config mode. To set deadtime to 0, use the **no** form of this command.

radius-server deadtime *minutes*

Syntax Description	<i>minutes</i> Length of time, in minutes, for which a RADIUS server is skipped over by transaction requests, up to a maximum of 1440 (24 hours). The range is from 1 to 1440. The default value is 0.				
Command Default	Dead time is set to 0.				
Command Modes	XR Config mode				
Usage Guidelines	A RADIUS server marked as dead is skipped by additional requests for the duration of minutes unless all other servers are marked dead and there is no rollover method.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>aaa</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	aaa	read, write
Task ID	Operations				
aaa	read, write				

Examples

The following example specifies five minutes of deadtime for RADIUS servers that fail to respond to authentication requests for the **radius-server deadtime** command:

```
RP/0//CPU0:router# configure
RP/0//CPU0:router(config)# radius-server deadtime 5
```

radius-server key

To set the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon, use the **radius-server key** command in XR Config mode. To disable the key, use the **no** form of this command.

radius-server key {**0** *clear-text-key* | **7** *encrypted-keyclear-text-key*}

Syntax Description	
0	Specifies an unencrypted (cleartext) shared key. <i>clear-text-key</i>
7	Specifies a encrypted shared key. <i>encrypted-key</i>
<i>clear-text-key</i>	Specifies an unencrypted (cleartext) shared key.

Command Default The authentication and encryption key is disabled.

Command Modes XR Config mode

Usage Guidelines The key entered must match the key used on the RADIUS server. All leading spaces are ignored, but spaces within and at the end of the key are used. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks themselves are part of the key.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to set the cleartext key to “samplekey”

```
RP/0//CPU0:router# configure
RP/0//CPU0:router(config)# radius-server key 0 samplekey
```

The following example shows how to set the encrypted shared key to “anykey”

```
RP/0//CPU0:router# configure
RP/0//CPU0:router(config)# radius-server key 7 anykey
```

Related Commands

Command	Description
key (RADIUS)	Specifies the authentication and encryption key that is used between the router and the RADIUS daemon running on the RADIUS server.
server-private (RADIUS), on page 48	Configures the IP address of the private RADIUS server for the group server.

radius-server retransmit

To specify the number of times the Cisco IOS XR software retransmits a packet to a server before giving up, use the **radius-server retransmit** command in XR Config mode. To disable retransmission, use the **no** form of this command.

radius-server retransmit *retries*

Syntax Description

retries Maximum number of retransmission attempts. The range is from 1 to 100. Default is 3.

Command Default

The RADIUS servers are retried three times, or until a response is received.

Command Modes

XR Config mode

Usage Guidelines

The RADIUS client tries all servers, allowing each one to time out before increasing the retransmit count.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to specify a retransmit counter value of five times:

```
RP/0//CPU0:router# configure
RP/0//CPU0:router(config)# radius-server retransmit 5
```

Related Commands

Command	Description
radius-server key , on page 40	Sets the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon.
retransmit (RADIUS)	Specifies the number of times a RADIUS request is resent to a server if the server is not responding or is responding slowly.
server-private (RADIUS) , on page 48	Configures the IP address of the private RADIUS server for the group server.

radius-server timeout

To set the interval for which a router waits for a server host to reply before timing out, use the **radius-server timeout** command in XR Config mode. To restore the default, use the **no** form of this command.

radius-server timeout *seconds*

Syntax Description	<i>seconds</i> Number that specifies the timeout interval, in seconds. Range is from 1 to 1000.
Command Default	5 seconds
Command Modes	XR Config mode
Usage Guidelines	Use the radius-server timeout command to set the number of seconds a router waits for a server host to reply before timing out.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to change the interval timer to 10 seconds:

```
RP/0//CPU0:router# configure
RP/0//CPU0:router(config)# radius-server timeout 10
```

Related Commands

Command	Description
radius-server key, on page 40	Sets the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon.
server-private (RADIUS), on page 48	Configures the IP address of the private RADIUS server for the group server.
timeout (RADIUS)	Specifies the number of seconds the router waits for the RADIUS server to reply before retransmitting.

radius source-interface

To force RADIUS to use the IP address of a specified interface or subinterface for all outgoing RADIUS packets, use the **radius source-interface** command in XR Config mode. To prevent only the specified interface from being the default and not from being used for all outgoing RADIUS packets, use the **no** form of this command.

radius source-interface *interface-name* [**vrf** *vrf-id*]

Syntax Description	<i>interface-name</i> Name of the interface that RADIUS uses for all of its outgoing packets.
vrf vrf-id	Specifies the name of the assigned VRF.

Command Default	If a specific source interface is not configured, or the interface is down or does not have an IP address configured, the system selects an IP address.
------------------------	---

Command Modes XR Config mode

Usage Guidelines Use the **radius source-interface** command to set the IP address of the specified interface or subinterface for all outgoing RADIUS packets. This address is used as long as the interface or subinterface is in the up state. In this way, the RADIUS server can use one IP address entry for every network access client instead of maintaining a list of IP addresses.

The specified interface or subinterface must have an IP address associated with it. If the specified interface or subinterface does not have an IP address or is in the down state, then RADIUS reverts to the default. To avoid this, add an IP address to the interface or subinterface or bring the interface to the up state.

The **radius source-interface** command is especially useful in cases in which the router has many interfaces or subinterfaces and you want to ensure that all RADIUS packets from a particular router have the same IP address.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to make RADIUS use the IP address of subinterface s2 for all outgoing RADIUS packets:

```
RP/0//CPU0:router# configure
RP/0//CPU0:router(config)# radius source-interface Loopback 10 vrf -
```

Related Commands

Command	Description
aaa group server tacacs+, on page 17	Groups different RADIUS server hosts into distinct lists.
radius-server key, on page 40	Sets the authentication and encryption key for all RADIUS communications between the router and the RADIUS daemon.

secret

To configure an encrypted or clear-text password for the user, use the **secret** command in username configuration mode or line template configuration mode. To remove this configuration, use the **no** form of this command.

```
secret [{0 [enc-type enc-type-value] | 5 | 8 | 9 | 10}] secret-login
```

Syntax Description	0	(Optional) Specifies that an unencrypted (clear-text) password follows.
	5	Specifies that an MD5-encrypted password (secret) follows.
	8	(Optional) Specifies that SHA256-encrypted password follows.
	9	(Optional) Specifies that scrypt-encrypted password follows.

10 (Optional) Specifies that SHA512-encrypted password follows.

secret-login Configures the specified secret for the user.

Can be clear text (for Type 0 secret) or text string in alphanumeric characters that is stored as encrypted password entered by the user in association with the user's login ID.

Can be up to 253 characters in length.

Note The characters entered must conform to the respective encryption standards.

enc-type (Optional) Configures the encryption type for a password entered in clear text.

enc-type-value Specifies the encryption type to be used.

Prior to Release 6.3.1, the only supported value was 5. (See Release History and Usage Guidelines sections for the currently supported values).

Command Default

No password is specified.

Command Modes

Username configuration

Line template configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.
Release 7.0.1	Added the support for Type 8 (SHA256), Type 9 (scrypt) and Type 10 (SHA512) encryption for secret configuration.
	Added the support for enc-type option under secret 0 to specify the type of encryption for password entered in clear-text format.

Usage Guidelines

From Release 7.0.1 and later, Type 10 encryption is applied as the default encryption type for the **secret** on Cisco IOS XR 64-bit operating systems. Prior to this, Type 5 (MD5) was the default one.

Prior to Release 7.0.1, Cisco IOS XR software allows you to configure only Message Digest 5 (MD5) encryption for username logins and passwords. MD5 encryption is a one-way hash function that makes reversal of an encrypted password impossible, providing strong encryption protection. Using MD5 encryption, you cannot retrieve clear-text passwords. Therefore, MD5 encrypted passwords cannot be used with protocols that require the clear-text password to be retrievable, such as Challenge Handshake Authentication Protocol (CHAP).

When an XR EXEC process is started on a line that has password protection, the process prompts for the secret. If the user enters the correct secret, the process issues the prompt. The user can try entering the secret thrice before the terminal returns to the idle state.

Secrets are one-way encrypted and should be used for login activities that do not require a decryptable secret.

To verify that respective password encryption has been enabled, use the **show running-config** command. For example, if the command output shows "username name secret 5", it means that enhanced password security with MD5 encryption is enabled.



Note The **show running-config** command does not display the login password in clear text when the **0** option is used to specify an unencrypted password. See the “Examples” section.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to establish the clear-text secret “lab” for the user *user2*:

```
RP/0//CPU0:router# configure
RP/0//CPU0:router (config)# username user2
RP/0//CPU0:router (config-un)# secret 0 lab
RP/0//CPU0:router (config-un)# commit
RP/0//CPU0:router (config-un)# show running-config
Building configuration...
username user2
  secret 5 $1$DTmd$q7C6fhzje7Cc7Xzmu2FrX1
!
end
```

The following examples show how to configure a Type 10 (SHA512) password for the user, *user10*. You can also see the examples and usage of the [username, on page 84](#) command.

You can specify Type as '10' under the **secret** keyword, to explicitly configure Type 10 password.

```
Router#configure
Router (config)#username user10 secret 10
$6$9UwJidvsTEqgkAPU$3CL1Ei/F.E4v/Hi.UaqLwX8UsSEr9ApG6c5pzhMjMztgW4jObAQ7meAwyhu5VM/aRFJqe/jxZG17h6xPrvJWF1
Router (config-un)#commit
```

You can also use the **enc-type** keyword under the **secret 0** option, to specify Type 10 as the encryption for a password entered in clear text.

```
Router#configure
Router (config)#username user10 secret 0 enc-type 10 testpassword
Router (config-un)#commit
```

Related Commands

Command	Description
group (AAA), on page 27	Adds a user to a group.
password (AAA), on page 34	Creates a login password for a user.
usergroup, on page 83	Accesses user group configuration mode and configures a user group, associating it with a set of task groups.
username, on page 84	Accesses username configuration mode and configures a new user with a username, establishing a password and granting permissions for that user.

server (RADIUS)

To associate a particular RADIUS server with a defined server group, use the **server** command in RADIUS server-group configuration mode. To remove the associated server from the server group, use the **no** form of this command.

```
server ip-address [auth-port port-number] [acct-port port-number]
```

Syntax Description

<i>ip-address</i>	IP address of the RADIUS server host.
auth-port <i>port-number</i>	(Optional) Specifies the User Datagram Protocol (UDP) destination port for authentication requests. The <i>port-number</i> argument specifies the port number for authentication requests. The host is not used for authentication if this value is set to 0. Default is 1645.
acct-port <i>port-number</i>	(Optional) Specifies the UDP destination port for accounting requests. The <i>port-number</i> argument specifies the port number for accounting requests. The host is not used for accounting services if this value is set to 0. Default is 1646.

Command Default

If no port attributes are defined, the defaults are as follows:

- Authentication port: 1645
- Accounting port: 1646

Command Modes

RADIUS server-group configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **server** command to associate a particular RADIUS server with a defined server group.

There are two different ways in which you can identify a server, depending on the way you want to offer AAA services. You can identify the server simply by using its IP address, or you can identify multiple host instances or entries using the optional **auth-port** and **acct-port** keywords.

When you use the optional keywords, the network access server identifies RADIUS security servers and host instances associated with a group server based on their IP address and specific UDP port numbers. The combination of the IP address and UDP port number creates a unique identifier, allowing different ports to be individually defined as RADIUS host entries providing a specific AAA service. If two different host entries on the same RADIUS server are configured for the same service, for example, accounting, the second host entry configured acts as an automatic switchover backup to the first one. Using this example, if the first host entry fails to provide accounting services, the network access server tries the second host entry configured on the same device for accounting services. (The RADIUS host entries are tried in the order they are configured.)

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to use two different host entries on the same RADIUS server that are configured for the same services—authentication and accounting. The second host entry configured acts as switchover backup to the first one.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa group server radius group1
RP/0/RP0/CPU0:router(config-sg-radius)# server 10.1.1.1 auth-port 1645 acct-port 1646
RP/0/RP0/CPU0:router(config-sg-radius)# server 10.2.2.2 auth-port 2000 acct-port 2001
```

Related Commands

Command	Description
aaa group server radius, on page 16	Groups different RADIUS server hosts into distinct lists and distinct methods.
deadtime (server-group configuration), on page 25	Configures the deadtime value at the RADIUS server group level.
server-private (RADIUS), on page 48	Configures the IP address of the private RADIUS server for the group server.

server (TACACS+)

To associate a particular TACACS+ server with a defined server group, use the **server** command in TACACS+ server-group configuration mode. To remove the associated server from the server group, use the **no** form of this command.

```
server {hostnameip-address}
```

Syntax Description

hostname Character string used to name the server host.

ip-address IP address of the server host.

Command Default

None

Command Modes

TACACS+ server-group configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

The server need not be accessible during configuration. Later, you can reference the configured server group from the method lists used to configure authentication, authorization, and accounting (AAA).

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to associate the TACACS+ server with the IP address 192.168.60.15 with the server group tac1:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa group server tacacs+ tac1
RP/0/RP0/CPU0:router(config-sg-tacacs+)# server 192.168.60.15
```

Related Commands

Command	Description
aaa group server tacacs+, on page 17	Groups different TACACS+ server hosts into distinct lists.

server-private (RADIUS)

To configure the IP address of the private RADIUS server for the group server, use the **server-private** command in RADIUS server-group configuration mode. To remove the associated private server from the AAA group server, use the **no** form of this command

server-private *ip-address* [**auth-port** *port-number*] [**acct-port** *port-number*]

Syntax Description

<i>ip-address</i>	IP address of the RADIUS server host.
auth-port <i>port-number</i>	(Optional) Specifies the User Datagram Protocol (UDP) destination port for authentication requests. The <i>port-number</i> argument specifies the port number for authentication requests. The host is not used for authentication if this value is set to 0. The default value is 1645.
acct-port <i>port-number</i>	(Optional) Specifies the UDP destination port for accounting requests. The <i>port-number</i> argument specifies the port number for accounting requests. The host is not used for accounting services if this value is set to 0. The default value is 1646.

Command Default

If no port attributes are defined, the defaults are as follows:

- Authentication port: 1645
- Accounting port: 1646

Command Modes

RADIUS server-group configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **server-private** command to associate a particular private server with a defined server group. Possible overlapping of IP addresses between VRF instances are permitted. Private servers (servers with private addresses) can be defined within the server group and remain hidden from other groups, while the servers in the global pool (for example, default radius server group) can still be referred to by IP addresses and port numbers. Thus, the list of servers in server groups includes references to the hosts in the configuration and the definitions of private servers.

Both the **auth-port** and **acct-port** keywords enter RADIUS server-group private configuration mode.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to define the group1 RADIUS group server, to associate private servers with it, and to enter RADIUS server-group private configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa group server radius group1
RP/0/RP0/CPU0:router(config-sg-radius)# server-private 10.1.1.1 auth-port 300
RP/0/RP0/CPU0:router(config-sg-radius-private)# exit
(config-sg-radius)# server-private 10.2.2.2 auth-port 300
RP/0/RP0/CPU0:router(config-sg-radius-private)#
```

Related Commands	Command	Description
	aaa group server tacacs+, on page 17	Groups different RADIUS server hosts into distinct lists and distinct methods.
	radius-server key, on page 40	Sets the authentication and encryption key for all RADIUS communication between the router and the RADIUS daemon.
	radius-server retransmit, on page 41	Specifies the number of times the Cisco IOS XR software retransmits a packet to a server before giving up.
	radius-server timeout, on page 41	Sets the interval for which a router waits for a server host to reply before timing out.
	vrf (RADIUS), on page 92	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group.

show aaa (XR-VM)

To display information about an Internet Key Exchange (IKE) Security Protocol group, user group, local user, login traces, or task group; to list all task IDs associated with all IKE groups, user groups, local users, or task groups in the system; or to list all task IDs for a specified IKE group, user group, local user, or task group, use the **show aaa** command in XR EXEC mode.

```
show aaa {ikegroup ikegroup-name | login sync | usergroup [usergroup-name] | trace | userdb
[username] | task | taskgroup }
```

Syntax Description	ikegroup	Displays details for local IKE groups.
	<i>ikegroup-name</i>	(Optional) IKE group whose details are to be displayed.

locald	Displays local data for subsystem.
login	Displays data for login subsystem.
sync	Syncs data with the subsystem.
usergroup	Displays details for all user groups.
<i>usergroup-name</i>	(Optional) Usergroup name.
trace	Displays trace data for AAA subsystem.
userdb	Displays details for all local users and the usergroups to which each user belongs.
<i>username</i>	(Optional) User whose details are to be displayed.
task	Show task information.
taskgroup	Displays details for all task groups.
Note	For taskgroup keywords, see optional usergroup name keyword list.
<i>taskgroup-name</i>	(Optional) Task group whose details are to be displayed.

Command Default Details for all user groups, or all local users, or all task groups are listed if no argument is entered.

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **show aaa** command to list details for all IKE groups, user groups, local users, or task groups in the system. Use the optional *ikegroup-name*, *usergroup-name*, *username*, or *taskgroup-name* argument to display the details for a specified IKE group, user group, user, or task group, respectively.

Task ID	Task ID	Operations
	aaa	read

Examples The following sample output is from the **show aaa** command, using the **ikegroup** keyword:

```
RP/0/RP0/CPU0:router# show aaa ikegroup

IKE Group ike-group
    Max-Users = 50
IKE Group ikeuser
    Group-Key = test-password
    Default Domain = cisco.com
IKE Group ike-user
```

The following sample output is from the **show aaa** command, using the **usergroup** command:

```
RP/0/RP0/CPU0:router# show aaa usergroup operator

User group 'operator'
  Inherits from task group 'operator'
User group 'operator' has the following combined set
of task IDs (including all inherited groups):
Task:      basic-services  : READ   WRITE   EXECUTE  DEBUG
Task:      cdp             : READ
Task:      diag            : READ
Task:      ext-access      : READ           EXECUTE
Task:      logging         : READ
```

The following sample output is from the **show aaa** command, using the **taskgroup** keyword for a task group named netadmin:

```
RP/0/RP0/CPU0:router# show aaa taskgroup netadmin

Task group 'netadmin'

Task group 'netadmin' has the following combined set
of task IDs (including all inherited groups):

Task:      aaa             : READ
Task:      acl             : READ   WRITE   EXECUTE  DEBUG
Task:      admin           : READ
Task:      ancp            : READ   WRITE   EXECUTE  DEBUG
Task:      atm             : READ   WRITE   EXECUTE  DEBUG
Task:      basic-services  : READ   WRITE   EXECUTE  DEBUG
Task:      bcdl            : READ
Task:      bfd             : READ   WRITE   EXECUTE  DEBUG
Task:      bgp             : READ   WRITE   EXECUTE  DEBUG
Task:      boot            : READ   WRITE   EXECUTE  DEBUG
Task:      bundle          : READ   WRITE   EXECUTE  DEBUG
Task:      cdp             : READ   WRITE   EXECUTE  DEBUG
Task:      cef             : READ   WRITE   EXECUTE  DEBUG
Task:      cgn             : READ   WRITE   EXECUTE  DEBUG
Task:      config-mgmt     : READ   WRITE   EXECUTE  DEBUG
Task:      config-services : READ   WRITE   EXECUTE  DEBUG
Task:      crypto          : READ   WRITE   EXECUTE  DEBUG
Task:      diag            : READ   WRITE   EXECUTE  DEBUG
Task:      drivers         : READ
Task:      dwdm            : READ   WRITE   EXECUTE  DEBUG
Task:      eem             : READ   WRITE   EXECUTE  DEBUG
Task:      eigrp           : READ   WRITE   EXECUTE  DEBUG
Task:      ethernet-services : READ
Task:      ext-access      : READ   WRITE   EXECUTE  DEBUG
Task:      fabric          : READ   WRITE   EXECUTE  DEBUG
Task:      fault-mgr       : READ   WRITE   EXECUTE  DEBUG
Task:      filesystem      : READ   WRITE   EXECUTE  DEBUG
Task:      firewall        : READ   WRITE   EXECUTE  DEBUG
Task:      fr              : READ   WRITE   EXECUTE  DEBUG
Task:      hdlc            : READ   WRITE   EXECUTE  DEBUG
Task:      host-services   : READ   WRITE   EXECUTE  DEBUG
Task:      hsrp            : READ   WRITE   EXECUTE  DEBUG
Task:      interface       : READ   WRITE   EXECUTE  DEBUG
Task:      inventory       : READ
Task:      ip-services     : READ   WRITE   EXECUTE  DEBUG
Task:      ipv4            : READ   WRITE   EXECUTE  DEBUG
Task:      ipv6            : READ   WRITE   EXECUTE  DEBUG
Task:      isis            : READ   WRITE   EXECUTE  DEBUG
```

show aaa (XR-VM)

```

Task:          12vpn  : READ    WRITE    EXECUTE  DEBUG
Task:          li    : READ    WRITE    EXECUTE  DEBUG
Task:          logging : READ    WRITE    EXECUTE  DEBUG
Task:          lpts   : READ    WRITE    EXECUTE  DEBUG
Task:          monitor : READ
Task:          mpls-ldp : READ    WRITE    EXECUTE  DEBUG
Task:          mpls-static : READ    WRITE    EXECUTE  DEBUG
Task:          mpls-te  : READ    WRITE    EXECUTE  DEBUG
Task:          multicast : READ    WRITE    EXECUTE  DEBUG
Task:          netflow  : READ    WRITE    EXECUTE  DEBUG
Task:          network  : READ    WRITE    EXECUTE  DEBUG
Task:          ospf     : READ    WRITE    EXECUTE  DEBUG
Task:          ouni     : READ    WRITE    EXECUTE  DEBUG
Task:          pkg-mgmt  : READ
Task:          pos-dpt  : READ    WRITE    EXECUTE  DEBUG
Task:          ppp      : READ    WRITE    EXECUTE  DEBUG
Task:          qos      : READ    WRITE    EXECUTE  DEBUG
Task:          rib      : READ    WRITE    EXECUTE  DEBUG
Task:          rip      : READ    WRITE    EXECUTE  DEBUG

Task:          route-map : READ    WRITE    EXECUTE  DEBUG
Task:          route-policy : READ    WRITE    EXECUTE  DEBUG
Task:          sbc       : READ    WRITE    EXECUTE  DEBUG
Task:          snmp      : READ    WRITE    EXECUTE  DEBUG
Task:          sonet-sdh  : READ    WRITE    EXECUTE  DEBUG
Task:          static     : READ    WRITE    EXECUTE  DEBUG
Task:          sysmgr    : READ
Task:          system    : READ    WRITE    EXECUTE  DEBUG
Task:          transport : READ    WRITE    EXECUTE  DEBUG
Task:          tty-access : READ    WRITE    EXECUTE  DEBUG
Task:          tunnel    : READ    WRITE    EXECUTE  DEBUG
Task:          universal  : READ                                (reserved)
Task:          vlan      : READ    WRITE    EXECUTE  DEBUG
Task:          vrrp      : READ    WRITE    EXECUTE  DEBUG

```

The following sample output is from the **show aaa** command, using the **taskgroup** keyword for an operator. The task group operator has the following combined set of task IDs, which includes all inherited groups:

```

Task:          basic-services : READ    WRITE    EXECUTE  DEBUG
Task:          cdp           : READ
Task:          diag          : READ
Task:          ext-access     : READ    EXECUTE
Task:          logging        : READ

```

The following sample output is from the **show aaa** command, using the **task supported** keywords. Task IDs are displayed in alphabetic order.

```

RP/0/RP0/CPU0:router# show aaa task supported

aaa
acl
admin
atm
basic-services
bcdl
bfd
bgp
boot
bundle
cdp
cef

```

```

cisco-support
config-mgmt
config-services
crypto
diag
disallowed
drivers
eigrp
ext-access
fabric
fault-mgr
filesystem
firewall
fr
hdlc
host-services
hsrp
interface
inventory
ip-services
ipv4
ipv6
isis
logging
lpts
monitor
mpls-ldp
mpls-static
mpls-te
multicast
netflow
network
ospf
ouni
pkg-mgmt
pos-dpt
ppp
qos
rib
rip
root-

route-map
route-policy
sbc
snmp
sonet-sdh
static
sysmgr
system
transport
tty-access
tunnel
universal
vlan
vrrp

```

Related Commands

Command	Description
show user, on page 67	Displays task IDs enabled for the currently logged-in user.

show aaa accounting

To display command history with the date and time for AAA sub-system, use the **show aaa accounting** command in System Admin EXEC mode. You must have a group aaa-r or root-system on System Admin VM.

show aaa accounting

This command has no keywords or arguments.

Command Default	None	
Command Modes	System Admin EXEC mode	
Command History	Release	Modification
	Release 5.2.3	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	aaa	read

This is the sample output of the **show aaa accounting** command:

```

sysadmin-vm:0_RP0#show aaa accounting
Mon Nov  3 13:37:21.573 UTC

Detail audit log information
-----
Time                Username           Session-ID         Node-Information   Command
-----
2014-11-03.13:14:27 UTC    root              17                System             logged in from
the CLI with aaa disabled
..
...
2014-11-03.13:37:01 UTC    cisco             57                0/RP0              assigned to
groups: root-system
2014-11-03.13:37:03 UTC    cisco             57                0/RP0              CLI 'config
terminal'
2014-11-03.13:37:03 UTC    cisco             57                0/RP0              CLI done
2014-11-03.13:37:09 UTC    cisco             57                0/RP0              CLI 'aaa
authentication users user temp'
2014-11-03.13:37:09 UTC    cisco             57                0/RP0              CLI done
2014-11-03.13:37:11 UTC    cisco             57                0/RP0              CLI 'password
****
2014-11-03.13:37:11 UTC    cisco             57                0/RP0              CLI done
2014-11-03.13:37:12 UTC    cisco             57                0/RP0              CLI 'commit'
2014-11-03.13:37:14 UTC    cisco             57                0/RP0              CLI done
2014-11-03.13:37:16 UTC    cisco             57                0/RP0              CLI 'exit'
2014-11-03.13:37:16 UTC    cisco             57                0/RP0              CLI done
2014-11-03.13:37:18 UTC    cisco             57                0/RP0              CLI 'exit'

```

```

2014-11-03.13:37:18 UTC      cisco      57      0/RP0      CLI done
2014-11-03.13:37:21 UTC      cisco      57      0/RP0      CLI 'show aaa
accounting'

```

show aaa password-policy

To display the details of AAA password policy configured in a system, use the **show aaa password-policy** command in XR EXEC mode.

```
show aaa password-policy [policy-name]
```

Syntax Description	<i>policy-name</i> Specifies the name of password policy.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 6.2.1	This command was introduced.
	Release 7.2.1	This release introduces the following output: <ul style="list-style-type: none"> • Warning Interval • Restrict Old Time • Maximum Char Repetition • Restrict Old Count • Restrict Username • Restrict Username Reverse • Restrict Password Reverse • Restrict Password Advanced

Usage Guidelines	If the option <i>policy-name</i> is not specified, the command output displays the details of all password policies configured in the system.
-------------------------	---

Refer **aaa password-policy** command details of each field in this command output.

Task ID	Task ID	Operation
	aaa	read

This is a sample out of **show aaa password-policy** command:

```
RP/0/RP0/CPU0:router#show aaa password-policy test-policy
```

```
Fri Feb 3 16:50:58.086 EDT
Password Policy Name : test-policy
  Number of Users : 1
  Minimum Length : 2
  Maximum Length : 253
  Special Character Len : 0
  Uppercase Character Len : 0
  Lowercase Character Len : 1
  Numeric Character Len : 0
  Policy Life Time :
    seconds : 0
    minutes : 0
    hours : 0
    days : 0
    months : 0
    years : 0
  Warning Interval :
    seconds : 0
    minutes : 0
    hours : 0
    days : 0
    months : 2
    years : 0
  Lockout Time :
    seconds : 0
    minutes : 0
    hours : 0
    days : 0
    months : 0
    years : 0
  Restrict Old Time :
    days : 0
    months : 0
    years : 3
  Character Change Len : 4
  Maximum Failure Attempts : 3
  Reference Count : 0
  Error Count : 0
  Lockout Count Attempts : 0
  Maximum char repetition : 3
  Restrict Old count : 3
  Restrict Username : 1
  Restrict Username Reverse : 1
  Restrict Password Reverse : 1
  Restrict Password Advanced : 1
RP/0/RSP0/CPU0:ios#
```

Related Commands

Command	Description
aaa password-policy, on page 19	Defines the FIPS-compliant AAA password security policy.

show radius

To display information about the RADIUS servers that are configured in the system, use the **show radius** command in XR EXEC mode.

show radius

Syntax Description	This command has no keywords or arguments.						
Command Default	If no radius servers are configured, no output is displayed.						
Command Modes	XR EXEC mode						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.1.2</td> <td>This command was updated to display IPv6 address details.</td> </tr> </tbody> </table>	Release	Modification	Release 6.1.2	This command was updated to display IPv6 address details.		
Release	Modification						
Release 6.1.2	This command was updated to display IPv6 address details.						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.		
Release	Modification						
Release 5.0.0	This command was introduced.						
Usage Guidelines	Use the show radius command to display statistics for each configured RADIUS server.						
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Task</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td></td> <td>aaa</td> <td>read</td> </tr> </tbody> </table>	Task ID	Task	Operations		aaa	read
Task ID	Task	Operations					
	aaa	read					

Examples

The following sample output is for the **show radius** command:

Output for IPV4 server

```
RP/0/RP0/CPU0:router# show radius

Global dead time: 0 minute(s)
Number of Servers: 1

Server: 2.3.4.5/2000/2001 is UP
  Address family: IPv6
  Total Deadtime: 0s Last Deadtime: 0s
  Timeout: 5 sec, Retransmit limit: 3
  Quarantined: No
```

Output for IPV6 server

```
RP/0/RP0/CPU0:router# show radius

Global dead time: 0 minute(s)
Number of Servers: 1

Server: 2001:b::2/2000/2001 is UP
  Address family: IPv6
  Total Deadtime: 0s Last Deadtime: 0s
  Timeout: 5 sec, Retransmit limit: 3
  Quarantined: No
```

This table describes the significant fields shown in the display.

Table 2: show radius Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests/UDP destination port for accounting requests.
Timeout	Number of seconds the router waits for a server host to reply before timing out.
Retransmit limit	Number of times the Cisco IOS XR software searches the list of RADIUS server hosts before giving up.

Related Commands

Command	Description
vrf (RADIUS), on page 92	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group.
radius-server retransmit, on page 41	Specifies how many times Cisco IOS XR software searches the list of RADIUS server hosts before giving up.
radius-server timeout, on page 41	Sets the interval for which a router waits for a server host to reply.

show radius accounting

To obtain information and detailed statistics for the RADIUS accounting server and port, use the **show radius accounting** command in XR EXEC mode.

show radius accounting**Syntax Description**

This command has no keywords or arguments.

Command Default

If no RADIUS servers are configured on the router, the output is empty. If the default values are for the counter (for example, request and pending), the values are all zero because the RADIUS server was just defined and not used yet.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
aaa	read

Examples

The following sample output is displayed on a per-server basis for the **show radius accounting** command:

```
RP/0/RP0/CPU0:router# show radius accounting

Server: 12.26.25.61, port: 1813
0 requests, 0 pending, 0 retransmits
0 responses, 0 timeouts, 0 bad responses
0 bad authenticators, 0 unknown types, 0 dropped
0 ms latest rtt

Server: 12.26.49.12, port: 1813
0 requests, 0 pending, 0 retransmits
0 responses, 0 timeouts, 0 bad responses
0 bad authenticators, 0 unknown types, 0 dropped
0 ms latest rtt

Server: 12.38.28.18, port: 29199
0 requests, 0 pending, 0 retransmits
0 responses, 0 timeouts, 0 bad responses
0 bad authenticators, 0 unknown types, 0 dropped
0 ms latest rtt
```

This table describes the significant fields shown in the display.

Table 3: show radius accounting Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests; UDP destination port for accounting requests.

Related Commands

Command	Description
aaa accounting, on page 2	Creates a method list for accounting.
aaa authentication (XR-VM), on page 6	Creates a method list for authentication.
show radius authentication, on page 59	Obtains information and detailed statistics for the RADIUS authentication server and port.

show radius authentication

To obtain information and detailed statistics for the RADIUS authentication server and port, use the **show radius authentication** command in XR EXEC mode.

show radius authentication

Syntax Description

This command has no keywords or arguments.

show radius authentication

Command Default If no RADIUS servers are configured on the router, the output is empty. If the default values are for the counter (for example, request and pending), the values are all zero because the RADIUS server was just defined and not used yet.

Command Modes XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID

Task ID	Task	Operations
	aaa	read

Examples

The following sample output is for the **show radius authentication** command:

```
RP/0/RP0/CPU0:router# show radius authentication

Server: 12.26.25.61, port: 1812
0 requests, 0 pending, 0 retransmits
0 accepts, 0 rejects, 0 challenges
0 timeouts, 0 bad responses, 0 bad authenticators
0 unknown types, 0 dropped, 0 ms latest rtt

Server: 12.26.49.12, port: 1812
0 requests, 0 pending, 0 retransmits
0 accepts, 0 rejects, 0 challenges
0 timeouts, 0 bad responses, 0 bad authenticators
0 unknown types, 0 dropped, 0 ms latest rtt

Server: 12.38.28.18, port: 21099
0 requests, 0 pending, 0 retransmits
0 accepts, 0 rejects, 0 challenges
0 timeouts, 0 bad responses, 0 bad authenticators
0 unknown types, 0 dropped, 0 ms latest rtt
```

This table describes the significant fields shown in the display.

Table 4: show radius authentication Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests; UDP destination port for accounting requests.

Related Commands

Command	Description
aaa accounting, on page 2	Creates a method list for accounting.
aaa authentication (XR-VM), on page 6	Creates a method list for authentication.

Command	Description
show radius accounting, on page 58	Obtains information and detailed statistics for the RADIUS accounting server and port.

show radius dead-criteria

To obtain information about the dead server detection criteria, use the **show radius dead-criteria** command in XR EXEC mode.

```
show radius dead-criteria host ip-addr [auth-port auth-port] [acct-port acct-port]
```

Syntax Description

host <i>ip-addr</i>	Specifies the name or IP address of the configured RADIUS server.
auth-port <i>auth-port</i>	(Optional) Specifies the authentication port for the RADIUS server. The default value is 1645.
acct-port <i>acct-port</i>	(Optional) Specifies the accounting port for the RADIUS server. The default value is 1646.

Command Default

The default values for time and tries are not fixed to a single value; therefore, they are calculated and fall within a range of 10 to 60 seconds for time and 10 to 100 for tries.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
aaa	read

Examples

The following sample output is for the **show radius dead-criteria** command:

```
RP/0/RP0/CPU0:router# show radius dead-criteria host 12.26.49.12 auth-port 11000 acct-port 11001
```

```
Server: 12.26.49.12/11000/11001
Dead criteria time: 10 sec (computed) tries: 10 (computed)
```

This table describes the significant fields shown in the display.

Table 5: show radius dead-criteria Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests/UDP destination port for accounting requests.
Timeout	Number of seconds the router waits for a server host to reply before timing out.
Retransmits	Number of times Cisco IOS XR software searches the list of RADIUS server hosts before giving up.

Related Commands

Command	Description
radius-server dead-criteria time, on page 37	Forces one or both of the criteria that is used to mark a RADIUS server as dead.
radius-server deadtime(BNG), on page 39	Defines the length of time in minutes for a RADIUS server to remain marked dead.

show radius server-groups

To display information about the RADIUS server groups that are configured in the system, use the **show radius server-groups** command in XR EXEC mode.

show radius server-groups [*group-name* [**detail**]]

Syntax Description

group-name (Optional) Name of the server group. The properties are displayed.

detail (Optional) Displays properties for all the server groups.

Command Default

None

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **show radius server-groups** command to display information about each configured RADIUS server group, including the group name, numbers of servers in the group, and a list of servers in the named server group. A global list of all configured RADIUS servers, along with authentication and accounting port numbers, is also displayed.

Task ID	Task ID	Operations
	aaa	read

Examples

The inherited global message is displayed if no group level deadtime is defined for this group; otherwise, the group level deadtime value is displayed and this message is omitted. The following sample output is for the **show radius server-groups** command:

```
RP/0/RP0/CPU0:router# show radius server-groups
```

```
Global list of servers
  Contains 2 server(s)
    Server 10.1.1.1/1645/1646
    Server 10.2.2.2/1645/1646

Server group 'radgrp1' has 2 server(s)
  Dead time: 0 minute(s) (inherited from global)
  Contains 2 server(s)
    Server 10.1.1.1/1645/1646
    Server 10.2.2.2/1645/1646

Server group 'radgrp-priv' has 1 server(s)
  Dead time: 0 minute(s) (inherited from global)
  Contains 1 server(s)
    Server 10.3.3.3/1645/1646 [private]
```

The following sample output shows the properties for all the server groups in group “radgrp1:”

```
RP/0/RP0/CPU0:router# show radius server-groups radgrp1 detail
```

```
Server group 'radgrp1' has 2 server(s)
  VRF default (id 0x60000000)
  Dead time: 0 minute(s) (inherited from global)
  Contains 2 server(s)
    Server 10.1.1.1/1645/1646
  Authentication:
    0 requests, 0 pending, 0 retransmits
    0 accepts, 0 rejects, 0 challenges
    0 timeouts, 0 bad responses, 0 bad authenticators
    0 unknown types, 0 dropped, 0 ms latest rtt
  Accounting:
    0 requests, 0 pending, 0 retransmits
    0 responses, 0 timeouts, 0 bad responses
    0 bad authenticators, 0 unknown types, 0 dropped
    0 ms latest rtt
    Server 10.2.2.2/1645/1646
  Authentication:
    0 requests, 0 pending, 0 retransmits
    0 accepts, 0 rejects, 0 challenges
    0 timeouts, 0 bad responses, 0 bad authenticators
    0 unknown types, 0 dropped, 0 ms latest rtt
  Accounting:
    0 requests, 0 pending, 0 retransmits
    0 responses, 0 timeouts, 0 bad responses
    0 bad authenticators, 0 unknown types, 0 dropped
    0 ms latest rtt
```

The following sample output shows the properties for all the server groups in detail in the group “radgrp-priv.”

```
RP/0/RP0/CPU0:router# show radius server-groups radgrp-priv detail

Server group 'radgrp-priv' has 1 server(s)
  VRF default (id 0x60000000)
  Dead time: 0 minute(s) (inherited from global)
  Contains 1 server(s)
    Server 10.3.3.3/1645/1646 [private]
  Authentication:
    0 requests, 0 pending, 0 retransmits
    0 accepts, 0 rejects, 0 challenges
    0 timeouts, 0 bad responses, 0 bad authenticators
    0 unknown types, 0 dropped, 0 ms latest rtt
  Accounting:
    0 requests, 0 pending, 0 retransmits
    0 responses, 0 timeouts, 0 bad responses
    0 bad authenticators, 0 unknown types, 0 dropped
    0 ms latest rtt
```

This table describes the significant fields shown in the display.

Table 6: show radius server-groups Field Descriptions

Field	Description
Server	Server IP address/UDP destination port for authentication requests/UDP destination port for accounting requests.

Related Commands

Command	Description
vrf (RADIUS), on page 92	Configures the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group.

show tacacs

To display information about the TACACS+ servers that are configured in the system, use the **show tacacs** command in XR EXEC mode.

show tacacs

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **show tacacs** command to display statistics for each configured TACACS+ server.

Task ID

Task ID	Task Operations
aaa	read

Examples

The following is sample output from the **show tacacs** command:

```
RP/0/RP0/CPU0:router# show tacacs
```

```
For IPv4 IP addresses:
```

```
Server:10.1.1.1/21212 opens=0 closes=0 aborts=0 errors=0
      packets in=0 packets out=0
      status=up single-connect=false
```

```
Server:10.2.2.2/21232 opens=0 closes=0 aborts=0 errors=0
      packets in=0 packets out=0
      status=up single-connect=false
```

```
For IPv6 IP addresses:
```

```
Server: 10.2.3.5/49 family = AF_INET opens=0 closes=0 aborts=0 errors=0
      packets in=0 packets out=0
      status=up single-connect=false
```

This table describes the significant fields shown in the display.

Table 7: show tacacs Field Descriptions

Field	Description
Server	Server IP address.
opens	Number of socket opens to the external server.
closes	Number of socket closes to the external server.
aborts	Number of tacacs requests that have been terminated midway.
errors	Number of error replies from the external server.
packets in	Number of TCP packets that have been received from the external server.
packets out	Number of TCP packets that have been sent to the external server.

show tacacs server-groups

To display information about the TACACS+ server groups that are configured in the system, use the **show tacacs server-groups** command in XR EXEC mode.

```
show tacacs server-groups
```

show tacacs server-groups

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **show tacacs server-groups** command to display information about each configured TACACS+ server group, including the group name, numbers of servers in the group, and a list of servers in the named server group. A global list of all configured TACACS+ servers is also displayed.

Task ID	Task ID	Operations
	aaa	read

Examples

The following is sample output from the **show tacacs server-groups** command:

```
RP/0/RP0/CPU0:router# show tacacs server-groups

Global list of servers
  Server 192.168.25.61/23456
  Server 192.168.49.12/12345
  Server 192.168.49.12/9000
  Server 192.168.25.61/23432
  Server 10.5.5.5/23456
  Server 10.1.1.1/49
Server group 'tac100' has 1 servers
Server 192.168.49.12
```

This table describes the significant fields shown in the display.

Table 8: show tacacs server-groups Field Descriptions

Field	Description
Server	Server IP address.

Related Commands

Command	Description
tacacs-server host, on page 72	Specifies a TACACS+ host.

show user

To display all user groups and task IDs associated with the currently logged-in user, use the **show user** command in XR EXEC mode.

```
show user [{all | authentication | group | tasks}]
```

Syntax Description	
all	(Optional) Displays all user groups and task IDs for the currently logged-in user.
authentication	(Optional) Displays authentication method parameters for the currently logged-in user.
group	(Optional) Displays the user groups associated with the currently logged-in user.
tasks	(Optional) Displays task IDs associated with the currently logged-in user. The tasks keyword indicates which task is reserved in the sample output.

Command Default When the **show user** command is used without any option, it displays the ID of the user who is logged in currently.

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **show user** command to display all user groups and task IDs associated with the currently logged-in user.

Task ID	Task ID	Operations
	none	—

Examples

The following sample output displays the authentication method parameters from the **show user** command:

```
RP/0/RP0/CPU0:router# show user authentication
```

```
local
```

The following sample output displays the tasks and indicates which tasks are reserved from the **show user** command:

```
RP/0/RP0/CPU0:router# show user tasks
```

```
Task:          aaa : READ    WRITE    EXECUTE  DEBUG
Task:          : READ    WRITE    EXECUTE  DEBUG
Task:          : READ    WRITE    EXECUTE  DEBUG
Task:          : READ    WRITE    EXECUTE  DEBUG
```


Related Commands	Command	Description
	show aaa (XR-VM), on page 49	Displays the task maps for selected user groups, local users, or task groups.

show aaa user-group

To display user group information for AAA sub-system, use the **show aaa user-group** command in System Admin EXEC mode. You must have a group aaa-r or root-system on System Admin VM.

show aaa user-group

This command has no keywords or arguments.

Command Default None

Command Modes System Admin EXEC mode

Command History	Release	Modification
	Release 5.2.3	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	aaa	read

This is the sample output of the **show aaa user-group** command:

```
sysadmin-vm:0_RP0#show aaa user-group
Mon Nov 3 13:39:33.380 UTC

User group : root-system
sysadmin-vm:0_RP0#
```

show tech-support aaa

To collect AAA debug and trace files from System Admin VM, use the **show tech-support aaa** command in System Admin EXEC mode.

show tech-support aaa

This command has no keywords or arguments.

Command Default None

single-connection

Command Modes	System Admin EXEC mode	
Command History	Release	Modification
	Release 5.2.3	This command was introduced.
Usage Guidelines	No specific guidelines impact the use of this command.	
Task ID	Task ID	Operation
	aaa	read

This is the sample output of the **show tech-support aaa** command:

```

sysadmin-vm:0_RP0#show tech-support aaa
Mon Nov  3 13:39:33.380 UTC

Fri Oct 24 07:22:15.740 UTC ++ Show tech start time: 2014-Oct-24.072216.UTC ++
Waiting for gathering to complete /opt/cisco/calvados/script/show_tech_aaa: line 27: rse:
command not found .
Compressing show tech output
Show tech output available at /misc/disk1//showtech-aaa-admin-2014-Nov-04.082457.UTC.tgz
Please collect show tech-support ctrace in addition to any sysadmin show-tech-support
collection
++ Show tech end time: 2014-Nov-04.UTC ++
sysadmin-vm:0_RP0#

```

single-connection

To multiplex all TACACS+ requests to this server over a single TCP connection, use the **single-connection** command in TACACS host configuration mode. To disable the single TCP connection for all new sessions that use a separate connection, use the **no** form of this command.

single-connection

Syntax Description	This command has no keywords or arguments.
Command Default	By default, a separate connection is used for each session.
Command Modes	TACACS host configuration
Command History	Release Modification
	Release 5.0.0 This command was introduced.
Usage Guidelines	The single-connection command allows the TACACS+ server to handle a greater number of TACACS operations than would be possible if multiple TCP connections were used to send requests to a server.

The TACACS+ server that is being used must support single-connection mode for this to be effective; otherwise, the connection between the network access server and the TACACS+ server locks up or you can receive unauthentic errors.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to configure a single TCP connection to be made with the TACACS+ server (IP address 209.165.200.226) and all authentication, authorization, accounting requests to use this TCP connection. This works only if the TACACS+ server is also configured in single-connection mode. To configure the TACACS+ server in single connection mode, refer to the respective server manual.

```
RP/0/RP0/CPU0:router(config)# tacacs-server host 209.165.200.226
RP/0/RP0/CPU0:router(config-tacacs-host)# single-connection
```

Related Commands	Command	Description
	tacacs-server host, on page 72	Specifies a TACACS+ host.

single-connection-idle-timeout

To set the idle timeout value for the single TCP connection to the TACACS+ server, use the **single-connection-idle-timeout** command in *tacacs-server host* configuration mode. To remove the configuration or to disable the idle timeout for the single connection, use the **no** form of this command.

single-connection-idle-timeout *time-in-seconds*

Syntax Description *time-in-seconds* Specifies the single connection timeout value, in seconds.

The range is:

- 500 to 7200 (prior to Cisco IOS XR Software Release 7.4.1)
- 5 to 7200 (from Cisco IOS XR Software Release 7.4.1, and later)

Command Default Single connection idle timeout is not set, by default.

Command Modes tacacs-server host

Command History	Release	Modification
	Release 7.4.1	This command was modified to change the timeout range.

Release	Modification
---------	--------------

Release 6.6.3	This command was introduced.
---------------	------------------------------

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
aaa	read, write

Examples

This example shows how to set an idle timeout value of 500 seconds for the single TCP connections to the TACACS+ server:

```
RP/0/RP0/CPU0:router (config) #tacacs-server host 209.165.200.226
RP/0/RP0/CPU0:router (config-tacacs-host) #single-connection-idle-timeout 500
RP/0/RP0/CPU0:router (config-tacacs-host) #commit
```

Related Commands

Command	Description
single-connection, on page 70	Multiplexes all TACACS+ requests to the server over a single TCP connection.

tacacs-server host

To specify a TACACS+ host server, use the **tacacs-server host** command in XR Config mode. To delete the specified name or address, use the **no** form of this command.

```
tacacs-server host host-name [holddown-time time] [port port-number] [timeout seconds] [key
[{0|7}] auth-key] [single-connection]
[ single-connection-idle-timeout time-in-seconds ]
```

Syntax Description

<i>host-name</i>	Host or domain name or IP address of the TACACS+ server.
holddown-time <i>time</i>	Specifies a duration, in seconds, for which an unresponsive TACACS+ server is to be marked as DOWN. The range is from 0 to 1200. Zero indicates that the hold-down timer feature is disabled.
port <i>port-number</i>	(Optional) Specifies a server port number. This option overrides the default, which is port 49. Valid port numbers range from 1 to 65535.

timeout <i>seconds</i>	(Optional) Specifies a timeout value that sets the length of time the authentication, authorization, and accounting (AAA) server waits to receive a response from the TACACS+ server. This option overrides the global timeout value set with the tacacs-server timeout command for this server only. The valid timeout range is from 1 to 1000 seconds. Default is 5. Note: You can use this parameter only in the config-tacacs-host sub-mode.
key [0 7] <i>auth-key</i>	(Optional) Specifies an authentication and encryption key shared between the AAA server and the TACACS+ server. The TACACS+ packets are encrypted using this key. This key must match the key used by the TACACS+ daemon. Specifying this key overrides the key set by the tacacs-server key command for this server only. (Optional) Entering 0 specifies that an unencrypted (clear-text) key follows. (Optional) Entering 7 specifies that an encrypted key follows. The <i>auth-key</i> argument specifies the unencrypted key between the AAA server and the TACACS+ server. Note: You can use this parameter only in the config-tacacs-host sub-mode.
single-connection	(Optional) Multiplexes all TACACS+ requests to this server over a single TCP connection. By default, a separate connection is used for each session. Note: You can use this parameter only in the config-tacacs-host sub-mode.
single-connection-idle-timeout <i>time-in-seconds</i>	(Optional) Specifies the single connection idle timeout value, in seconds. The range is: <ul style="list-style-type: none"> • 500 to 7200 (prior to Cisco IOS XR Software Release 7.4.1) • 5 to 7200 (from Cisco IOS XR Software Release 7.4.1, and later)

Command Default

No TACACS+ host is specified.

The *port-name* argument, if not specified, defaults to the standard port 49.

The *seconds* argument, if not specified, defaults to 5 seconds.

Single connection idle timeout is not set, by default.

Command Modes

XR Config mode

Command History

Release	Modification
Release 7.4.1	This command was modified to include holddown-time option.
Release 7.4.1	This command was modified to change the range for single-connection-idle-timeout parameter.
Release 7.1.1	This command was modified to include single-connection-idle-timeout option.
Release 5.0.0	This command was introduced.

Usage Guidelines

You can use multiple **tacacs-server host** commands to specify additional hosts. Cisco IOS XR software searches for hosts in the order in which you specify them.

For details on TACACS+ hold-down timer, see the **holddown-time** command.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows how to specify a TACACS+ host with the IP address 209.165.200.226:

```
RP/0/RP0/CPU0:router(config)# tacacs-server host 209.165.200.226
RP/0/RP0/CPU0:router(config-tacacs-host)#
```

The following example shows that the default values from the **tacacs-server host** command are displayed from the **show run** command:

```
RP/0/RP0/CPU0:router# show run

Building configuration...
!! Last configuration change at 13:51:56 UTC Mon Nov 14 2005 by lab
!
tacacs-server host 209.165.200.226 port 49
  timeout 5
!
```

The following example shows how to specify that the router consult the TACACS+ server host named host1 on port number 51. The timeout value for requests on this connection is 30 seconds; the encryption key is a_secret.

```
RP/0/RP0/CPU0:router(config)# tacacs-server host host1 port 51
RP/0/RP0/CPU0:router(config-tacacs-host)# timeout 30
RP/0/RP0/CPU0:router(config-tacacs-host)# key a_secret
```

Related Commands

Command	Description
key (TACACS+), on page 32	Specifies an authentication and encryption key shared between the AAA server and the TACACS+ server.
single-connection, on page 70	Multiplexes all TACACS+ requests to this server over a single TCP connection.
single-connection-idle-timeout, on page 71	Sets the idle timeout value for the single TCP connection to the TACACS+ server.
tacacs-server key, on page 75	Globally sets the authentication encryption key used for all TACACS+ communications between the router and the TACACS+ daemon.
tacacs-server timeout, on page 76	Globally sets the interval that the router waits for a server host to reply.

Command	Description
timeout (TACACS+), on page 81	Specifies a timeout value that sets the length of time the authentication, authorization, and accounting (AAA) server waits to receive a response from the TACACS+ server.

tacacs-server key

To set the authentication encryption key used for all TACACS+ communications between the router and the TACACS+ daemon, use the **tacacs-server key** command in XR Config mode. To disable the key, use the **no** form of this command.

tacacs-server key {**0** *clear-text-key* | **7** *encrypted-keyauth-key*}

Syntax Description

0 *clear-text-key* Specifies an unencrypted (cleartext) shared key.

7 *encrypted-key* Specifies an encrypted shared key.

auth-key Specifies the unencrypted key between the AAA server and the TACACS+ server.

Command Default

None

Command Modes

XR Config mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

The key name entered must match the key used on the TACACS+ daemon. The key name applies to all servers that have no individual keys specified. All leading spaces are ignored; spaces within and after the key are not. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks themselves are part of the key.

The key name is valid only when the following guidelines are followed:

- The *clear-text-key* argument must be followed by the **0** keyword.
- The *encrypted-key* argument must be followed by the **7** keyword.

The TACACS server key is used only if no key is configured for an individual TACACS server. Keys configured for an individual TACACS server always override this global key configuration.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example sets the authentication and encryption key to key1:

```
RP/0/RP0/CPU0:router (config) # tacacs-server key key1
```

Related Commands

Command	Description
key (TACACS+), on page 32	Specifies an authentication and encryption key shared between the AAA server and the TACACS+ server.
tacacs-server host, on page 72	Specifies a TACACS+ host.

tacacs-server timeout

To set the interval that the server waits for a server host to reply, use the **tacacs-server timeout** command in XR Config mode. To restore the default, use the **no** form of this command.

tacacs-server timeout *seconds*

Syntax Description

seconds Integer that specifies the timeout interval (in seconds) from 1 to 1000.

Command Default

5 seconds

Command Modes

XR Config mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

The TACACS+ server timeout is used only if no timeout is configured for an individual TACACS+ server. Timeout intervals configured for an individual TACACS+ server always override this global timeout configuration.

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows the interval timer being changed to 10 seconds:

```
RP/0/RP0/CPU0:router (config) # tacacs-server timeout 10
```

Related Commands

Command	Description
tacacs-server host, on page 72	Specifies a TACACS+ host.

tacacs source-interface

To specify the source IP address of a selected interface for all outgoing TACACS+ packets, use the **tacacs source-interface** command in XR Config mode. To disable use of the specified interface IP address, use the **no** form of this command.

tacacs source-interface *type path-id*

Syntax Description	<p><i>type</i> Interface type. For more information, use the question mark (?) online help function.</p> <p><i>path-id</i> Physical interface or virtual interface.</p> <p>Note Use the show interfaces command in EXEC mode to see a list of all interfaces currently configured on the router.</p> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>				
Command Default	If a specific source interface is not configured, or the interface is down or does not have an IP address configured, the system selects an IP address.				
Command Modes	XR Config mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				
Usage Guidelines	<p>Use the tacacs source-interface command to set the IP address of the specified interface for all outgoing TACACS+ packets. This address is used as long as the interface is in the <i>up</i> state. In this way, the TACACS+ server can use one IP address entry associated with the network access client instead of maintaining a list of all IP addresses.</p> <p>This command is especially useful in cases where the router has many interfaces and you want to ensure that all TACACS+ packets from a particular router have the same IP address.</p> <p>When the specified interface does not have an IP address or is in a <i>down</i> state, TACACS+ behaves as if no source interface configuration is used.</p>				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>aaa</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	aaa	read, write
Task ID	Operations				
aaa	read, write				
Examples	<p>The following example shows how to set the IP address of the specified interface for all outgoing TACACS+ packets:</p> <pre>RP/0/RP0/CPU0:router# configure RP/0/RP0/CPU0:router(config)# tacacs source-interface GigabitEthernet 0/0/0/29</pre>				

Related Commands

Command	Description
aaa group server tacacs+ , on page 17	Groups different server hosts into distinct lists and distinct methods.

task

To add a task ID to a task group, use the **task** command in task group configuration mode. To remove a task ID from a task group, use the **no** form of this command.

task {**read** | **write** | **execute** | **debug**} *taskid-name*

Syntax Description

read	Enables read-only privileges for the named task ID.
write	Enables write privileges for the named task ID. The term “write” implies read also.
execute	Enables execute privileges for the named task ID.
debug	Enables debug privileges for the named task ID.
<i>taskid-name</i>	Name of the task ID.

Command Default

No task IDs are assigned to a newly created task group.

Command Modes

Task group configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **task** command in task group configuration mode. To access task group configuration mode, use the **taskgroup** command in global configuration mode.

Task IDs are the base of command authorization. Only users who have the required permissions can execute a particular command on the router. To execute a command, the user must be part of a user group that consists of task group(s) that includes required task IDs and privileges. Cisco IOS XR software supports multiple task IDs. For example, **aaa**, **config-services**, **crypto**, **system**, and so on. To see the list of task IDs available for the user, use the **show user tasks** command.

Likewise, all commands are associated with one or more task IDs, and their corresponding operations (such as **read**, **write**, **execute**, and **debug**) that denote the permissions required to execute those commands. You can use the **describe** command to know the task ID and permissions that are required to execute a particular command.

For example, the following output shows that the user needs **aaa** task ID with **read** and **write** permission to execute the **show run aaa** command. So, users can execute this command if they belong to a user group associated with a task group that includes this **aaa** task ID having read and write privileges.

```
Router# describe show run aaa
The command is defined in aaa_cmds.parser

User needs ALL of the following taskids:
```

```

aaa (READ WRITE) ----->

It will take the following actions:
Wed Mar 16 07:58:01.451 UTC
  Spawn the process:
    nvgen "-c" "-q" "gl/aaa/"
Router#

```

Root users have all task IDs, and hence will be able to execute all commands. Also, certain commands might not require any task ID as such to execute it. So, all users will have permission to execute such commands. If you do not have the required permission to execute a command, the command authorization fails. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

A few other examples that describe the commands to list the task ID:

```

Router#describe show interfaces
The command is defined in show_interface.parser

show_interface.parser
User needs ALL of the following taskids:

  interface (READ)----->

It will take the following actions:
Thu Mar 17 06:42:08.264 UTC
  Spawn the process:
    show_interface "-a"
Router#

```

```

Router(config)#describe ssh server
The command is defined in ssh.parser

ssh.parser
User needs ALL of the following taskids:

  crypto (READ WRITE) ----->

It will take the following actions:
  Create/Set the configuration item:
    Path: gl/crypto/ssh/server/sshd/vrf/default
    Value: packed[ 0x1 <string> <string> ]
Router(config)#

```

For more details, see *Configuring AAA Services* chapter in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to enable execute privileges for the config-services task ID and associate that task ID with the task group named taskgroup1:

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# taskgroup taskgroup1
RP/0/RP0/CPU0:router(config-tg)# task execute config-services
```

Related Commands

Command	Description
taskgroup, on page 80	Configures a task group to be associated with a set of task IDs.

taskgroup

To configure a task group to be associated with a set of task IDs, and to enter task group configuration mode, use the **taskgroup** command in XR Config mode. To delete a task group, use the **no** form of this command.

taskgroup *taskgroup-name* [{**description** *string* | **task** {**read** | **write** | **execute** | **debug**} *taskid-name* | **inherit taskgroup** *taskgroup-name*}]

Syntax Description

<i>taskgroup-name</i>	Name of a particular task group.
description	(Optional) Enables you to create a description for the named task group.
<i>string</i>	(Optional) Character string used for the task group description.
task	(Optional) Specifies that a task ID is to be associated with the named task group.
read	(Optional) Specifies that the named task ID permits read access only.
write	(Optional) Specifies that the named task ID permits read and write access only.
execute	(Optional) Specifies that the named task ID permits execute access.
debug	(Optional) Specifies that the named task ID permits debug access only.
<i>taskid-name</i>	(Optional) Name of a task: the task ID.
inherit taskgroup	(Optional) Copies permissions from the named task group.
<i>taskgroup-name</i>	(Optional) Name of the task group from which permissions are to be inherited.

Command Default

Five predefined user groups are available by default.

Command Modes

XR Config mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Task groups are configured with a set of task IDs for each action type. Deleting a task group that is still referenced in the system results in a warning and rejection of the deletion. For more details on task IDs, see the Usage Guidelines section of the **task** command.

You can use the **show user group** command in XR Config mode to know the group(s) that the current user is part of. Similarly, you can use the **show user all** to know the group or task information (such as username, groups, authentication method, task IDs, and so on) of the current user.

Entering the **taskgroup** command with no keywords or arguments enters task group configuration mode, in which you can use the **description**, **inherit**, **show**, and **task** commands.

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example assigns read bgp permission to the task group named alpha:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# taskgroup alpha
RP/0/RP0/CPU0:router(config-tg)# task read bgp
```

Related Commands	Command	Description
	description (AAA), on page 26	Creates a task group description in task configuration mode.
	task, on page 78	Adds a task ID to a task group.

timeout (TACACS+)

To specify a timeout value that sets the length of time the authentication, authorization, and accounting (AAA) server waits to receive a response from the TACACS+ server, use the **timeout (TACACS+)** command in TACACS host configuration mode. To disable this command and return to the default timeout value of 5 seconds, use the **no** form of this command.

timeout *seconds*

Syntax Description	<i>seconds</i> Timeout value (in seconds). The range is from 1 to 1000. If no timeout is specified, the global value is used.				
Command Default	<i>seconds</i> : 5				
Command Modes	TACACS host configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				
Usage Guidelines	The timeout (TACACS+) command overrides the global timeout value set with the tacacs-server timeout command for this server only.				

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to set the number of seconds for the timeout value:

```
RP/0/RP0/CPU0:router(config)# tacacs-server host 209.165.200.226
RP/0/RP0/CPU0:router(config-tacacs-host)# timeout 500
```

Related Commands

Command	Description
tacacs-server host, on page 72	Specifies a TACACS+ host.

timeout login response

To set the interval that the server waits for a reply to a login, use the **timeout login response** command in line template configuration mode. To restore the default, use the **no** form of this command.

timeout login response *seconds*

Syntax Description

seconds Integer that specifies the timeout interval (in seconds) from 0 to 300.

Command Default

seconds: 30

Command Modes

Line template configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **timeout login response** command in line template configuration mode to set the timeout value. This timeout value applies to all terminal lines to which the entered line template is applied. This timeout value cannot be applied to the line console. After the timeout value has expired, the user is prompted again. The retry is allowed three times.

Task ID

Task ID	Task ID	Operations
	aaa	read, write

Examples

The following example shows how to change the interval timer to 20 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# line template alpha
RP/0/RP0/CPU0:router(config-line)# timeout login response 20
```

Related Commands	Command	Description
	login authentication, on page 33	Enables AAA authentication for logging in.

usergroup

To configure a user group and associate it with a set of task groups, and to enter user group configuration mode, use the **usergroup** command in XR Config mode. To delete a user group, or to delete a task-group association with the specified user group, use the **no** form of this command.

usergroup *usergroup-name*

Syntax Description	
	<i>usergroup-name</i> Name of the user group. The <i>usergroup-name</i> argument can be only one word. Spaces and quotation marks are not allowed.

Command Default	
	Five predefined user groups are available by default.

Command Modes	
	XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines	
	User groups are configured with the command parameters for a set of users, such as task groups. You can remove specific user groups by using the no form of the usergroup command. You can remove the user group itself by using the no form of the command without giving any parameters. Deleting a user group that is still referenced in the system results in a warning and a rejection of the deletion.

Use the [inherit usergroup, on page 31](#) command to copy permissions from other user groups. The user group is inherited by the parent group and forms a union of all task IDs specified in those groups. Circular inclusions are detected and rejected. User groups cannot inherit properties from predefined groups, such as owner-sdr.

From global configuration mode, you can display all the configured user groups. However, you cannot display all the configured user groups in usergroup configuration mode.

Task ID	Task ID	Operations
	aaa	read, write

Examples	
	The following example shows how to add permissions from the user group beta to the user group alpha:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# usergroup alpha
RP/0/RP0/CPU0:router(config-ug)# inherit usergroup beta
```

Related Commands

Command	Description
description (AAA), on page 26	Creates a description of a task group during configuration.
inherit usergroup, on page 31	Enables a user group to derive permissions from another user group.
taskgroup, on page 80	Configures a task group to be associated with a set of task IDs.

username

To configure a new user with a username, establish a password, associate a password policy with the user, grant permissions for the user, and to enter username configuration mode, use the **username** command in XR Config mode or System Admin Config mode. To delete a user from the database, use the **no** form of this command.

```
username name [{ group name | policy name | [ password-policy name ] { password |
masked-password } [ type ] password | { secret | masked-secret } [{ type | 0 [ enc-type type ] secret
| login-history { enable | disable } } ] } ]
no username name [{ group name | policy | password | masked-password | secret | masked-secret
| password-policy name [ masked-password [ type ] password ] | login-history { enable | disable }
}]
```

Syntax Description

<i>name</i>	Name of the user. The <i>name</i> argument can be only one word. Spaces and quotation marks are not allowed. The allowed range for a user-defined username is 2-253 characters.
group <i>name</i>	Enables a user to be associated with a user group, as defined with the usergroup command.
policy <i>name</i>	Configures a password policy that is common to user password and secret.
password-policy <i>name</i>	(Optional) Specifies the password policy for cleartext and Type 7 password authentication.
password	Enables a password to be created for the specified user.

masked-password	Enables a password to be created for the specified user. When you key in the password, it is not visible on the screen.
<i>type password</i>	<p>Specifies the password type and the password to be keyed in.</p> <p>Enter 0 or 7 for the <i>type</i> argument. 0 specifies a cleartext password, and 7 specifies a Type 7 encrypted password.</p> <p>If Type 7 encryption is enabled with the password keyword, the password is not visible to the user. The password can be up to 253 characters in length.</p> <p>(Optional) <i>type</i> argument</p>
secret	Enables a secret to be created for the specified user.
masked-secret	Enables a secret to be created for the specified user. When you key in the secret, it is not visible on the screen.

type secret

Specifies the secret type and the secret to be keyed in.

Enter 0, or enter 5, 8, 9, or 10, for the *type* argument. Details:

- 0 specifies a cleartext secret that will be encrypted for use.
- 5 specifies a Type 5 password that uses MD5 hashing algorithm.
- 8 specifies a Type 8 password that uses SHA256 hashing algorithm.
- 9 specifies a Type 9 password that uses scrypthashing algorithm.
- 10 specifies a Type 10 password that uses SHA512 hashing algorithm.

Note Type 10 is only available for Cisco IOS XR 64 bit platforms.

(Optional) *type* argument.

0 enc-type *type secret*

Specifies that you enter a cleartext secret to be encrypted by a specified encryption method.

- 0 specifies that you should enter a cleartext secret.
- **enc-type** specifies that you enter 5, 8, 9, or 10, for the *type* argument.
- Enter the cleartext secret for the *secret* argument.

(Optional) **enc-type** *type* keyword-argument combination.

login-history { **enable** | **disable** }

Enables or disables the login history for a specified user.

Command Default

No usernames are defined in the system.

Command Modes

XR Config mode
System Admin Config mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.
Release 6.2.1	Added the support for password-policy , as part of AAA password security for FIPS compliance.
Release 7.0.1	Added the support for Type 8 (SHA256), Type 9 (scrypt) and Type 10 (SHA512) for secret configuration.
Release 7.2.1	Added the support for policy option to configure policy common to user password and secret.

Usage Guidelines**Note**

- A user is never allowed to have cisco-support privileges as the only group.
- The Type 10 for the **secret** configuration is available only on Cisco IOS XR 64-bit operating system.
- From Release 7.0.1 and later, Type 10 (SHA512) is applied as the default type for the **secret** configuration. Prior to this, Type 5 (MD5) was the default one.
- The support for Type 8 and 9 for the secret configuration on Cisco IOS XR 64-bit operating system is available only from Release 7.0.1 and later.

Use the **username** command to identify the user and enter username configuration mode. Password and user group assignments can be made from either XR Config mode mode or username configuration submode. Permissions (task IDs) are assigned by associating the user with one or more defined user groups.

Each user is identified by a username that is unique across the administrative domain. Each user should be made a member of at least one user group. Deleting a user group may orphan the users associated with that group. The AAA server authenticates orphaned users, but most commands are not authorized.

The **username** command is associated with a particular user for local login authentication by default. Alternatively, a user and password can be configured in the database of the TACACS+ server for TACACS+ login authentication. For more information, see the description of the [aaa authentication \(XR-VM\)](#), on page 6 command.

**Note**

To enable the local networking device to respond to remote Challenge Handshake Authentication Protocol (CHAP) challenges, one **username** command entry must be the same as the hostname entry that has already been assigned to the other networking device.

For more details on defining a password policy, see the **aaa password-policy** command and **policy** command. The AAA password security policy feature works as such for Cisco IOS XR platforms. Whereas, it is supported only on XR VM, for Cisco IOS XR 64 bit platforms and Cisco NCS 6000 Series Routers.

Password Masking guidelines for various command forms

- **username** *name* **password** *type password*

username *name* **masked-password** *type password*

Enter 0 or 7 for the *type* argument. 0 specifies a cleartext password, and 7 specifies a Type 7 encrypted password.

- **secret** *type secret*

masked-secret *type secret*

Enter 0, or enter 5, 8, 9, or 10, for the *type* argument. 0 specifies a cleartext secret, and 5, 8, 9, and 10 specify a Type 5, Type 8, Type 9, and Type 10 secret, respectively.

- **secret 0 enc-type** *type secret*

masked-secret 0 enc-type *type secret*

Enter 5, 8, 9, or 10, for the *type* argument.

- **masked-password** *type password*

masked-secret *type secret*

After specifying the password encryption type, press **Enter** or **return** on your keyboard. The password/secret option appears in the next line. Example:

```
Router(config)# masked-secret 10
```

```
Enter secret:
```

```
Re-enter secret:
```

Task ID

Task ID	Operations
aaa	read, write

Examples

The following example shows the commands available after executing the **username** command:

```
Router# config
Router(config)# username user1
Router(config-un)# ?
```

clear	Clear the uncommitted configuration
commit	Commit the configuration changes to running
describe	Describe a command without taking real actions
do	Run an exec command
exit	Exit from this submode
group	User group in which this user will be a member of
login-history	Option to set whether to display previous login details
no	Negate a command or set its defaults

password	Specify the password for the user
password-policy	Specify the password policy for the user
policy	Specify the policy common to password and secret for the user
pwd	Commands used to reach current submode
root	Exit to the XR Config mode
secret	Specify the secure password for the user
show	Show contents of configuration

The following example shows how to establish the clear-text password *password1* for the user name *user1*:

```
Router# configure
Router(config)# username user1
Router(config-un)# password 0 password1
```

This example shows how to apply a AAA password policy for a user:

```
Router# config
Router(config)# username user1 password-policy test-policy password abc
```

This example shows how to apply a password policy for the user secret:

```
Router#configure
Router(config)#username user1
Router(config-un)#policy test-policy1
Router(config-un)#secret 10
$6$dmwU0Ajicf98W0.$y/vzynWF1/OcGxwBwHs79VAy5ZZLhoHd7TicR4mOo8IIIVriYCGAKW0A.wlJvTPO7IbZry.DxHrE3SN2BBzBJe0
Router(config-un)#commit
```

The following example shows how to configure a Type 8 (SHA256) password for the user, *user8*. You can also see the examples and usage of the [secret, on page 43](#) command.

You can specify Type as '8' under the **secret** keyword, to explicitly configure Type 8 password.

```
Router#configure
Router(config)#username user8 secret 8
$8$ZYKGl1dzIw73D1$IUWJOqTLoMyExhsNKoL5vMtvCOYguM5ajXf4uGeQj6I
Router(config-un)#commit
```

This example shows how to configure Type 9 password:

```
Router#configure
Router(config)#username user9 secret 9
$9$/rIQl1B3rp1RBL$oS2fLWKfYH6B/kApxkkXmIqbPAHprZkPEoh3WqGbvWQ
Router(config-un)#commit
```

Similarly, this example shows how to configure Type 10 password :

```
Router#configure
Router(config)#username user10 secret 10
```

```
$6$9UvJidvsTEgkAPU$3CLEi/F.E4v/Hi.UaqLwX8UsSEr9ApG6c5pzhMjnztgW4jObAQ7meAwyhu5VM/aRFJqe/jxZG17h6xPrvJWf1
Router(config-un)#commit
```

This example shows how to specify the Type 10 password in System Admin VM:

```
Router#admin
sysadmin-vm:0_RP0# configure
sysadmin-vm:0_RP0(config)# aaa authentication users user user10 password testpassword
sysadmin-vm:0_RP0(config)# commit
```

This example shows how to enable login-history for user1:

```
Router(config)# username user1 login-history enable
```

This example shows login history information for a successful and an unsuccessful login from user1:

```
Username: user1
Password:
RP/0/RSP0/CPU0:Aug 21 17:20:35.566 UTC: exec[68609]: %SECURITY-LOGIN-4-AUTHEN_FAILED :
Failed authentication attempt by user '<unknown>' from 'console' on 'con0_RSP0_CPU0'
```

User Access Verification

```
Username: user1
Password:
User user1 failed to login 1 time(s)
Most recent Failure Fri Aug 21 2020 17:20:35 UTC
to con0_RSP0_CPU0 from console
```

```
User user1 last logged in successfully Fri Aug 21 2020 17:20:03 UTC
to con0_RSP0_CPU0 from console
```

Password Masking Examples

The following example shows how to enable password masking for a cleartext password entry:

In this example, for user us3, a cleartext password is entered.

```
Router(config)# username us3 masked-password 0
```

```
Enter password:
Re-enter password:
```

```
Router(config)#commit
```

In the **show** command output, you can see the encrypted password:

```
Router# show run aaa
..
username us3
password 7 105A1D0D
```

The encrypted password 105A1D0D is entered in the **Enter password:** and **Re-enter password:** fields, for Type 7 password encryption:

```
Router(config)# username us3 masked-password 7
```

```
Enter password:
Re-enter password:
```

```
Router(config)#commit
```

If there is a password mismatch between the two entries, an error message is displayed.

The following example shows how to enable password masking for a AAA password policy:

In this example, for user us6, a cleartext password is entered.

```
Router(config)# aaa password-policy security
Router(config)# username us6 password-policy security masked-password 0
```

```
Enter password:
Re-enter password:
```

```
Router(config)#commit
```

In the **show** command output, you can see the encrypted password.

```
Router# show run aaa
..
aaa password-policy security
..
username us6
 password-policy security password 7 0835585A
```

The encrypted password 0835585A is entered in the **Enter password:** and **Re-enter password:** fields for Type 7 password encryption.

```
Router(config)# username us6 password-policy test-policy masked-password 7
```

```
Enter password:
Re-enter password:
```

```
Router(config)#commit
```

Related Commands

Command	Description
aaa authentication (XR-VM), on page 6	Defines a method list for authentication.
aaa password-policy, on page 19	Defines the FIPS-compliant AAA password security policy
group (AAA), on page 27	Adds a user to a group.
password (AAA), on page 34	Creates a login password for a user.
policy (AAA), on page 36	Configures a policy that is common for user password as well as secret.
secret, on page 43	Creates a secure login secret for a user.

users group

To associate a user group and its privileges with a line, use the **users group** command in line template configuration mode. To delete a user group association with a line, use the **no** form of this command.

Syntax Description	<i>usergroup-name</i> Name of the user group. The <i>usergroup-name</i> argument can be only one word. Spaces and quotation marks are not allowed.
cisco-support	Specifies that users logging in through the line are given Cisco support personnel privileges.
netadmin	Specifies that users logging in through the line are given network administrator privileges.
operator	Specifies that users logging in through the line are given operator privileges.
root-lr	Specifies that users logging in through the line are given root logical router (LR) privileges.
serviceadmin	Specifies that users logging in through the line are given service administrator group privileges.
sysadmin	Specifies that users logging in through the line are given system administrator privileges.

Command Default None

Command Modes Line template configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **users group** command to enable a user group and its privileges to be associated with a line, meaning that users logging in through the line are given the privileges of the particular user group.

Task ID	Task ID	Operations
	aaa	read, write

Examples

In the following example, if a vty-pool is created with line template *vt*y, users logging in through vty are given operator privileges:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa authen login vty-authen line
RP/0/RP0/CPU0:router(config)# commit
RP/0/RP0/CPU0:router(config)# line template vty
RP/0/RP0/CPU0:router(config-line)# users group operator
RP/0/RP0/CPU0:router(config-line)# login authentication
```

vrf (RADIUS)

To configure the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an AAA RADIUS server group, use the **vrf** command in RADIUS server-group configuration mode. To enable server groups to use the global (default) routing table, use the **no** form of this command.

vrf *vrf-name*

Syntax Description *vrf-name* Name assigned to a VRF.

Command Default The default VRF is used.

Command Modes RADIUS server-group configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **vrf** command to specify a VRF for an AAA RADIUS server group and enable dial-up users to use AAA servers in different routing domains.

Task ID	Task ID	Operations
	aaa	read, write

Examples The following example shows how to use the **vrf** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# aaa group server radius group1
RP/0/RP0/CPU0:router(config-sg-radius)# vrf vrf1
```

Related Commands	Command	Description
	radius source-interface, on page 42	Forces RADIUS to use the IP address of a specified interface or subinterface for all outgoing RADIUS packets.
	server-private (RADIUS), on page 48	Configures the IP address of the private RADIUS server for the group server.



CHAPTER 2

IPSec Commands

This module describes the IPSec commands.



Note The following IPSec commands are available only if the <platform>-k9sec.pie is installed.

- [clear crypto ipsec sa](#), on page 95
- [description \(IPSec profile\)](#), on page 96
- [show crypto ipsec sa](#), on page 97
- [show crypto ipsec summary](#), on page 100
- [show crypto ipsec transform-set](#), on page 101

clear crypto ipsec sa

To delete specific security associations (SAs), or all SAs in the IP Security (IPSec) security associations database (SADB), use the **clear crypto ipsec sa** command.

```
clear crypto ipsec sa {sa-id | all | counters | {sa-id | all} | interface tunnel-ipsec}
```

Syntax Description	<i>sa-id</i>	Identifier for the SA. IPSec supports from 1 to 64,500 sessions.
	all	Deletes all IPSec SAs in the IPSec SADB.
	counters	Clears the counters in the IPSec SADB.
	interface	Clears the interfaces in the IPSec SADB.
	tunnel-ipsec	The range of tunnel-ipsec is <0-4294967295>.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines SAs are established to secure data flows in IPSec. Use the **clear crypto ipsec sa** command to delete active IPSec sessions or force IPSec to reestablish new SAs. Usually, the establishment of SAs is negotiated between peers through Internet Key Exchange (IKE) on behalf of IPSec.

Task ID	Task ID	Operations
	crypto	execute

Examples The following example shows how to remove the SA with ID 100 from the SADB:

```
RP/0/RP0/CPU0:router# clear crypto ipsec sa 100
```

Related Commands	Command	Description
	show crypto ipsec sa, on page 97	Displays the settings used by current SAs.

description (IPSec profile)

To create a description of an IPSec profile, use the **description** command in profile configuration mode. To delete a profile description, use the **no** form of this command.

description *string*

Syntax Description *string* Character string describing the IPSec profile.

Command Default None

Command Modes Crypto IPSec profile

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **description** command inside the profile configuration submode to create a description for an IPSec profile.

Task ID	Task ID	Operations
	profile configuration	read, write

Examples The following example shows the creation of a profile description:

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# crypto ipsec profile newprofile
RP/0/RP0/CPU0:router(config-newprofile)# description this is a sample profile
```

show crypto ipsec sa

To display security association (SA) information based on the rack/slot/module location, use the **show crypto ipsec sa** command in XR EXEC mode.

```
show crypto ipsec sa [{sa-id | peer ip-address | profile profile-name | detail | count | fvrf fvrf-name |
ivrf ivrf-name | location node-id}]
```

Syntax Description	
sa-id	(Optional) Identifier for the SA. The range is from 1 to 64500.
peer ip-address	(Optional) IP address used on the remote (PC) side. Invalid IP addresses are not accepted.
profile profile-name	(Optional) Specifies the alphanumeric name for a security profile. The character range is from 1 to 64. Profile names cannot be duplicated.
detail	(Optional) Provides additional dynamic SA information.
count	(Optional) Provides SA count.
fvrf fvrf-name	(Optional) Specifies that all existing SAs for front door virtual routing and forwarding (FVRF) is the same as the fvrf-name.
ivrf ivrf-name	(Optional) Specifies that all existing SAs for inside virtual routing and forwarding (IVRF) is the same as the ivrf-name.
location node-id	(Optional) Specifies that the SAs are configured on a specified location.

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines If no optional argument or keyword is used, all SAs are displayed within a flow. Within a flow, the SAs are listed by protocol (Encapsulating Security Payload [ESP] or Authentication Header [AH]) and direction (inbound or outbound).

The **detail** keyword provides additional information only for SAs that are configured in a software crypto engine. The SAs are configured by using tunnel-ipsec and transport.

Task ID	Task ID	Operations
	crypto	read

Examples

The following sample output is from the **show crypto ipsec sa** command:

```
RP/0/RP0/CPU0:router# show crypto ipsec sa

SSA id:          510
Node id:         0/1/0
SA Type:         MANUAL
interface:       service-ipsec22
profile :        p7
local ident (addr/mask/prot/port) : (0.0.0.0/0.0.0.255/512/0)
remote ident (addr/mask/prot/port) : (0.0.0.0/0.0.0.0/512/0)
local crypto endpt: 0.0.0.0, remote crypto endpt: 0.0.0.0, vrf default

#pkts tx         :0                #pkts rx         :0
#bytes tx        :0                #bytes rx        :0
#pkts encrypt    :0                #pkts decrypt    :0
#pkts digest     :0                #pkts verify     :0
#pkts encrpt fail:0                #pkts decrpt fail:0
#pkts digest fail:0                #pkts verify fail:0
#pkts replay fail:0                #pkts replay fail:0
#pkts tx errors  :0                #pkts rx errors  :0

outbound esp sas:
  spi: 0x322(802)
  transform: esp-3des-md5
  in use settings = Tunnel
  sa agreed lifetime: 3600s, 4194303kb
  sa timing: remaining key lifetime: 3142303931sec/0kb
  sa DPD: disable, mode none, timeout 0s
  sa idle timeout: disable, 0s
  sa anti-replay (HW accel): enable, window 64
inbound esp sas:
  spi: 0x322(802)
  transform: esp-3des-md5
  in use settings = Tunnel
  sa agreed lifetime: 3600s, 4194303kb
  sa timing: remaining key lifetime: 3142303931sec/0kb
  sa DPD: disable, mode none, timeout 0s
  sa idle timeout: disable, 0s
  sa anti-replay (HW accel): enable, window 64
```

This table describes the significant fields shown in the display.

Table 9: show crypto ipsec sa Field Descriptions

Field	Description
SA id	Identifier for the SA.
interface	Identifier for the interface.
profile	String of alphanumeric characters that specify the name of a security profile.
local ident	IP address, mask, protocol, and port of the local peer.
remote ident	IP address, mask, protocol and port of the remote peer.
outbound esp sas	Outbound ESP SAs.

Field	Description
inbound esp sas	Inbound ESP SAs.
transform	The transform being used in the SA.
sa lifetime	The lifetime value used in the SA.

The following sample output is from the **show crypto ipsec sa** command for the **profile** keyword for a profile named pn1:

```
RP/0/RP0/CPU0:router# show crypto ipsec sa profile pn1

SA id: 2
interface: tunnel0
profile: pn1
local ident (addr/mask/prot/port): (172.19.70.92/255.255.255.255/0/0)
remote ident (addr/mask/prot/port): (172.19.72.120/255.255.255.255/0/0)
local crypto endpt: 172.19.70.92, remote crypto endpt: 172.19.72.120
outbound esp sas:
spi: 0x8b0e950f (2332988687)
transform: esp-3des-sha
in use settings = Tunnel
sa lifetime: 3600s, 4194303kb

SA id: 2
interface: tunnel0
profile: pn1
local ident (addr/mask/prot/port): (172.19.72.120/255.255.255.255/0/0)
remote ident (addr/mask/prot/port): (172.19.70.92/255.255.255.255/0/0)
local crypto endpt: 172.19.72.120, remote crypto endpt: 172.19.70.92
inbound esp sas:
spi: 0x2777997c (662149500)
transform: esp-3des-sha
in use settings = Tunnel
sa lifetime: 3600s, 4194303kb
```

The following sample output is from the **show crypto ipsec sa** command for the **peer** keyword:

```
RP/0/RP0/CPU0:router# show crypto ipsec sa peer 172.19.72.120

SA id: 2
interface: tunnel0
profile: pn1
local ident (addr/mask/prot/port): (172.19.70.92/255.255.255.255/0/0)
remote ident (addr/mask/prot/port): (172.19.72.120/255.255.255.255/0/0)
local crypto endpt: 172.19.70.92, remote crypto endpt: 172.19.72.120
outbound esp sas:
spi: 0x8b0e950f (2332988687)
transform: esp-3des-sha
in use settings = Tunnel
sa lifetime: 3600s, 4194303kb

SA id: 2
interface: tunnel0
profile: pn1
local ident (addr/mask/prot/port): (172.19.72.120/255.255.255.255/0/0)
remote ident (addr/mask/prot/port): (172.19.70.92/255.255.255.255/0/0)
local crypto endpt: 172.19.72.120, remote crypto endpt: 172.19.70.92
inbound esp sas:
spi: 0x2777997c (662149500)
```

```
transform: esp-3des-sha
in use settings = Tunnel
sa lifetime: 3600s, 4194303kb
```

show crypto ipsec summary

To display IP Security (IPSec) summary information, use the **show crypto ipsec summary** command in XR EXEC mode.

show crypto ipsec summary

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	crypto	read

Examples

The following sample output is from the **show crypto ipsec summary** command:

```
RP/0/RP0/CPU0:router# show crypto ipsec summary

# * Attached to a transform indicates a bundle
# Active IPSec Sessions: 1

SA  Interface          Local Peer/Port  Remote Peer/Port  FVRF   Profile  Transform  Lifetime
-----
502 -ipsec100 70.70.70.2/500  60.60.60.2/500  default ipsec1   esp-3des  esp
3600/100000000
```

This table describes the significant fields shown in the display.

Table 10: show crypto ipsec summary Field Descriptions

Field	Description
SA	Identifier for the security association.
Node	Identifier for the node.

Field	Description
Local Peer	IP address of the local peer.
Remote Peer	IP address of the remote peer.
FVRF	The front door virtual routing and forwarding (FVRF) of the SA. If the FVRF is global, the output shows f_vrf as an empty field
Mode	Profile mode type.
Profile	Crypto profile in use.
Transform	Transform in use.
Lifetime	Lifetime value, displayed in seconds followed by kilobytes.

show crypto ipsec transform-set

To display the configured transform sets, use the **show crypto ipsec transform-set** command in XR EXEC mode.

```
show crypto ipsec transform-set [transform-set-name]
```

Syntax Description	<i>transform-set-name</i> (Optional) IPSec transform set with the specified value for the <i>transform-set-name</i> argument are displayed.
---------------------------	---

Command Default	No default values. The default behavior is to print all the available transform-sets.
------------------------	---

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines	If no transform is specified, all transforms are displayed.
-------------------------	---

Task ID	Task	Operations
	crypto	read

Examples The following sample output is from the **show crypto ipsec transform-set** command:

```
RP/0/RP0/CPU0:router# show crypto ipsec transform-set
```

show crypto ipsec transform-set

```
Transform set combined-des-sha: {esp-des esp-sha-hmac}
Transform set tsfm2: {esp-md5-hmac esp-3des }
      Mode: Transport
Transform set tsfm1: {esp-md5-hmac esp-3des }
      Mode: Tunnel
Transform set ts1: {esp-des  }
      Mode: Tunnel
```



CHAPTER 3

Keychain Management Commands

This module describes the commands used to configure keychain management.

For detailed information about keychain management concepts, configuration tasks, and examples, see the *Implementing Keychain Management on* configuration module in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

- [accept-lifetime](#), on page 103
- [ao](#), on page 104
- [accept-tolerance](#), on page 105
- [clear type6 client](#), on page 106
- [key \(key chain\)](#), on page 107
- [key \(tcp ao keychain\)](#), on page 108
- [keychain](#), on page 109
- [key chain \(key chain\)](#), on page 109
- [key config-key password-encryption](#), on page 110
- [key-string \(keychain\)](#), on page 111
- [send-lifetime](#), on page 113
- [show key chain](#), on page 114
- [show type6](#), on page 115
- [tcp ao](#), on page 117

accept-lifetime

To set the time period during which the authentication key on a keychain is received as valid, use the **accept-lifetime** command in key configuration mode. To revert to the default value, use the **no** form of this command.

accept-lifetime *start-time* [{**duration** *duration value* | **infinite***end-time*}]

Syntax Description

<i>start-time</i>	Start time, in <i>hh:mm:ss day month year</i> format, in which the key becomes valid. The range is from 0:0:0 to 23:59:59. The range for the number of days of the month is from 1 to 31. The range for the years is from 1993 to 2035.
-------------------	---

duration <i>duration value</i>	(Optional) Determines the lifetime of the key in seconds. The range is from 1-2147483646.
infinite	(Optional) Specifies that the key never expires after it becomes valid.
end-time	(Optional) Time, in <i>hh:mm:ss day month year</i> format, after which the key expires. The range is from 0:0:0 to 23:59:59.

Command Default None

Command Modes Key configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
system	read, write

Examples The following example shows how to use the **accept-lifetime** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)# key 8
RP/0/RP0/CPU0:router(config-isis-keys-0x8)# accept-lifetime 1:00:00 June 29 2006 infinite
```

Related Commands

Command	Description
key (key chain), on page 107	Creates or modifies a keychain key.
key chain (key chain), on page 109	Creates or modifies a keychain.
key-string (keychain), on page 111	Specifies the text for the key string.
send-lifetime, on page 113	Sends the valid key.
show key chain, on page 114	Displays the keychain.

ao

To specify the name the key chain used in the authentication option **ao** command in BGP neighbor configuration mode.

```
ao key-chain-name { inheritance-disable | include-tcp-options { disable | enable }
accept-ao-mismatch-connection }
```

Syntax Description	<i>key-chain-name</i>	Specifies the name of the key chain. String of maximum length of 32 characters.
	inheritance-disable	Prevents the key chain from being inherited from the parent.
	include-tcp-options	Includes or excludes other TCP options in the header for MAC calculation.
	disable	Excludes other TCP options in the header.
	enable	Includes other TCP options in the header.
	accept-ao-mismatch-connection	Accepts connection even if there is a mismatch of AO options between peers.

Command Default The key chain has no specified name.

Command Modes BGP neighbor

Command History	Release	Modification
	Release 6.5.1	This command was introduced.

This example shows how to specify the name the key chain used in the authentication option :

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#router bgp 100
RP/0/RP0/CPU0:router(config-bgp)#neighbor 10.51.51.1
RP/0/RP0/CPU0:router(config-bgp-nbr)#address-family vpnv4 unicast
RP/0/RP0/CPU0:router(config-bgp-nbr)#ao tcpa01 include-tcp-options disable
accept-ao-mismatch-connection
```

accept-tolerance

To specify the tolerance or acceptance limit, in seconds, for an accept key that is used by a peer, use the **accept-tolerance** command in keychain configuration mode. To disable this feature, use the **no** form of this command.

```
accept-tolerance [{value | infinite}]
```

Syntax Description	<i>value</i> (Optional) Tolerance range, in seconds. The range is from 1 to 8640000.
	infinite (Optional) Specifies that the tolerance specification is infinite. The accept key never expires. The tolerance limit of infinite indicates that an accept key is always acceptable and validated when used by a peer.

clear type6 client

Command Default The default value is 0, which is no tolerance.

Command Modes Keychain configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines If you do not configure the **accept-tolerance** command, the tolerance value is set to zero. Even though the key is outside the active lifetime, the key is deemed acceptable as long as it is within the tolerance limit (for example, either prior to the start of the lifetime, or after the end of the lifetime).

Task ID	Task ID	Operations
	system	read, write

Examples The following example shows how to use the **accept-tolerance** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)# accept-tolerance infinite
```

Related Commands

Command	Description
accept-lifetime, on page 103	Accepts the valid key.
key chain (key chain), on page 109	Creates or modifies a keychain.
show key chain, on page 114	Displays the keychain.

clear type6 client

To clear the Type 6 client state in case the primary key update process is stuck at any stage, use the **clear type6** command in XR EXEC mode.

```
clear type6 client { keychain | snmp }
```

Syntax Description **keychain** Clears the key chain client information.

snmp Clears the snmp client information.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines You can track the primary key update operation using the **show type6 server** command output. If the *Master key Inprogress* field in that output displays as *YES*, then you can use **show type6 masterkey update status** command (or, **show type6 clients** command, prior to Cisco IOS XR Software Release 7.0.2) to check which client has not completed the operation. Accordingly, you can clear that particular client using this **clear** command.

Task ID	Task ID	Operation
	system	read, write

This example shows how to clear the Type 6 client state:

```
Router#clear type6 client keychain
```

Related Commands	Command	Description
	show type6, on page 115	Displays Type 6 password encryption information.

key (key chain)

To create or modify a keychain key, use the **key** command in keychain-key configuration mode. To disable this feature, use the **no** form of this command.

key *key-id*

Syntax Description *key-id* 48-bit integer key identifier of from 0 to 281474976710655.

Command Default No default behavior or values

Command Modes Keychain-key configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines For a Border Gateway Protocol (BGP) keychain configuration, the range for the *key-id* argument must be from 0 to 63. If the range is above the value of 63, the BGP keychain operation is rejected.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to use the **key** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)# key 8
RP/0/RP0/CPU0:router(config-isis-keys-0x8)#
```

Related Commands

Command	Description
accept-lifetime, on page 103	Accepts the valid key.
key chain (key chain), on page 109	Creates or modifies a keychain.
key-string (keychain), on page 111	Specifies the text for the key string.
send-lifetime, on page 113	Sends the valid key.
show key chain, on page 114	Displays the keychain.

key (tcp ao keychain)

To configure in send and receive identifiers for the key, use the **key** command in TCP authentication option keychain configuration mode.

key *key-identifier* **sendID** *send-id-value* **ReceiveID** *receive-id-value*

Syntax Description		
<i>key-identifier</i>	Identifier of the key. Acceptable values are 48-bit integers. Range is 0 to 281474976710655.	
SendID <i>send-id-value</i>	Specifies the send identifier value. Range is 0 to 255.	
ReceiveID <i>receive-id-value</i>	Specifies the receive identifier value to be used for the key. The range is 0 to 255.	

Command Default The key is not enabled.

Command Modes TCP authentication option keychain

Command History	Release	Modification
	Release 6.5.1	This command was introduced.

Task ID	Task ID	Operations
	bgp	read

Examples

This example shows how to configure the send and receive identifier for the key.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# tcp ao
RP/0/RP0/CPU0:router(config-tcp-ao)# keychain tcpaol
RP/0/RP0/CPU0:router(config-tcp-ao-tpcaol)# key 10 sendID 5 receiveID 5
```

keychain

To configure the keychain to be used in TCP authentication option, use the **tcp ao** command in TCP authentication option configuration mode.

keychain *keychain-name*

Syntax Description	This command has no arguments or keywords.				
Command Default	The keychain is not enabled.				
Command Modes	TCP authentication option				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.5.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.5.1	This command was introduced.
Release	Modification				
Release 6.5.1	This command was introduced.				

Task ID	Task ID	Operations
	bgp	read

Examples

This example shows how to configure the **keychain** for TCP Authentication option:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# tcp ao
RP/0/RP0/CPU0:router(config-tcp-ao)# keychain tcpaol
```

key chain (key chain)

To create or modify a keychain, use the **key chain** command in XR Config mode. To disable this feature, use the **no** form of this command.

key chain *key-chain-name*

Syntax Description *key-chain-name* Specifies the name of the keychain. The maximum number of characters is 48.

Command Default No default behavior or values

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines You can configure a keychain for Border Gateway Protocol (BGP) as a neighbor, session group, or neighbor group. BGP can use the keychain to implement a hitless key rollover for authentication.

Task ID	Task ID	Operations
	system read, write	

Examples

The following example shows that the name of the keychain isis-keys is for the **key chain** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# key chain isis-keys
RP/0/RP0/CPU0:router (config-isis-keys)#
```

Related Commands

Command	Description
accept-lifetime, on page 103	Accepts the valid key.
accept-tolerance, on page 105	Configures a tolerance value to accept keys for the keychain.
key (key chain), on page 107	Creates or modifies a keychain key.
key-string (keychain), on page 111	Specifies the text for the key string.
send-lifetime, on page 113	Sends the valid key.
show key chain, on page 114	Displays the keychain.

key config-key password-encryption

To create a primary key for the Type 6 password encryption feature, use the **key config-key password-encryption** command in XR EXEC mode.

key config-key password-encryption [delete]

Syntax Description	delete (Optional) Deletes the primary key for Type 6 password encryption.				
Command Default	No primary key exists.				
Command Modes	XR EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.1	This command was introduced.
Release	Modification				
Release 7.0.1	This command was introduced.				

Examples

The following example shows how to create a primary key for Type 6 password encryption:

```
Router# key config-key password-encryption

New password Requirements: Min-length 6, Max-length 64
Characters restricted to [A-Z][a-z][0-9]
Enter new key :
Enter confirm key :
Master key operation is started in background
```

The following example shows how to delete a primary key for Type 6 password encryption:

```
Router# key config-key password-encryption delete

WARNING: All type 6 encrypted keys will become unusable
Continue with master key deletion ? [yes/no]: yes
Master key operation is started in background
```

Related Commands	Command	Description
	password6 encryption aes	Enables Type 6 password encryption feature.
	show type6 server	Displays Type 6 password information.

key-string (keychain)

To specify the text string for the key, use the **key-string** command in keychain-key configuration mode. To disable this feature, use the **no** form of this command.

key-string [{clear | password}] *key-string-text*

Syntax Description	clear	Specifies the key string in clear-text form.
	password	Specifies the key in encrypted form.

key-string-text Text string for the key, which is encrypted by the parser process before being saved to the configuration. The text string has the following character limitations:

- Plain-text key strings—Minimum of 1 character and a maximum of 32.
- Encrypted key strings—Minimum of 4 characters and no maximum.

Command Default

The default value is clear.

Command Modes

Keychain-key configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

For an encrypted password to be valid, the following statements must be true:

- String must contain an even number of characters, with a minimum of four.
- The first two characters in the password string must be decimal numbers and the rest must be hexadecimal.
- The first two digits must not be a number greater than 53.

Either of the following examples would be valid encrypted passwords:

1234abcd

or

50aefd

From Cisco IOS XR Software, Release 7.1.2, Release 7.2.1 and later, if you are using any **HMAC-SHA** algorithm for a session, then you must ensure that the configured *key-string* has a minimum length of 14 characters. Otherwise, the session goes down. This guideline is applicable only for FIPS mode.

Task ID

Task ID	Operations
	system read, write

Examples

The following example shows how to use the **keystring** command:

```
RP/0/RP0/CPU0:router:# configure
RP/0/RP0/CPU0:router(config)# key chain isis-keys
RP/0/RP0/CPU0:router(config-isis-keys)# key 8
RP/0/RP0/CPU0:router(config-isis-keys-0x8)# key-string password 850aefd
```

Related Commands

Command	Description
accept-lifetime, on page 103	Accepts the valid key.

Command	Description
key (key chain), on page 107	Creates or modifies a keychain key.
key chain (key chain), on page 109	Creates or modifies a keychain.
send-lifetime, on page 113	Sends the valid key.
show key chain, on page 114	Displays the keychain.

send-lifetime

To send the valid key and to authenticate information from the local host to the peer, use the **send-lifetime** command in keychain-key configuration mode. To disable this feature, use the **no** form of this command.

send-lifetime *start-time* [{**duration** *duration value* | **infinite***end-time*}]

Syntax Description	
<i>start-time</i>	Start time, in <i>hh:mm:ss day month year</i> format, in which the key becomes valid. The range is from 0:0:0 to 23:59:59. The range for the number of days of the month to start is from 1 to 31. The range for the years is from 1993 to 2035.
duration <i>duration value</i>	(Optional) Determines the lifetime of the key in seconds.
infinite	(Optional) Specifies that the key never expires once it becomes valid.
<i>end-time</i>	(Optional) Time, in <i>hh:mm:ss day month year</i> format, after which the key expires. The range is from 0:0:0 to 23:59:59

Command Default No default behavior or values

Command Modes Keychain-key configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task	Operations
	system	read, write

Examples The following example shows how to use the **send-lifetime** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# key chain isis-keys
RP/0/RP0/CPU0:router (config-isis-keys)# key 8
RP/0/RP0/CPU0:router (config-isis-keys-0x8)# send-lifetime 1:00:00 June 29 2006 infinite
```

Related Commands

Command	Description
accept-lifetime, on page 103	Accepts the valid key.
key (key chain), on page 107	Creates or modifies a keychain key.
key chain (key chain), on page 109	Creates or modifies a keychain.
key-string (keychain), on page 111	Specifies the text for the key string.

show key chain

To display the keychain, use the **show key chain** command in XR EXEC mode.

show key chain *key-chain-name*

Syntax Description

key-chain-name Names of the keys in the specified keychain. The maximum number of characters is 32.

Command Default

If the command is used without any parameters, then it lists out all the key chains.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
system	read

Examples

When a secure key storage becomes available, it is desirable for keychain management to alternatively prompt you for a primary password and display the key label after decryption. The following example displays only the encrypted key label for the **show key chain** command:

```
RP/0/RP0/CPU0:router# show key chain isis-keys
```

```
Key-chain: isis-keys/ -
```

```

accept-tolerance -- infinite
Key 8 -- text "8"
  cryptographic-algorithm -- MD5
  Send lifetime: 01:00:00, 29 Jun 2006 - Always valid [Valid now]
  Accept lifetime: 01:00:00, 29 Jun 2006 - Always valid [Valid now]

```

Related Commands

Command	Description
accept-lifetime, on page 103	Accepts the valid key.
accept-tolerance, on page 105	Configures a tolerance value to accept keys for the keychain.
key (key chain), on page 107	Creates or modifies a keychain key.
key chain (key chain), on page 109	Creates or modifies a keychain.
key-string (keychain), on page 111	Specifies the text for the key string.
send-lifetime, on page 113	Sends the valid key.

show type6

To view Type 6 password encryption information, use the **show type6** command in XR EXEC mode.

```

show type6 { clients | masterkey update status | server | trace server { all | error
| info } [ trace-server-parameter ] }

```

Syntax Description

clients	Displays Type 6 client information.
masterkey update status	Displays Type 6 primary key operation status.
server	Displays Type 6 server information.
trace server	Displays Type 6 trace server information.
all	Displays all Type 6 traces.
error	Displays Type 6 error traces.
info	Displays Type 6 information trace entries.
<i>trace-server-parameter</i>	(Optional) Displays Type 6 trace server information for the specified parameter. Use one from the list of parameters defined in the Usage Guidelines section.

Command Default

None.

Command Modes

XR EXEC mode

Command History**Release Modification**

 Release 7.0.1 This command was introduced.

 Release 7.0.2 This command was modified to include the **masterkey update status** option.

Usage Guidelines

In the command form **show type6 trace server info** *trace-server-parameter*, replace *trace-server-parameter* with one of the following parameters:

The **show type6 clients** command is deprecated with the introduction of **masterkey update status**.

Trace Server Parameter	Displayed Trace Server Information
file	The specified file.
hexdump	Hexadecimal format.
last	The most recent entries.
location	Line card location.
reverse	From the most recent entry to the first entry.
stats	Statistics information.
tailf	New traces as they are added.
udir	Copies trace information from remote locations to the specified temporary directory.
unique	Unique entries with counts.
usec	User security information, with time stamp.
verbose	Internal debugging information.
wide	Removes buffer name, node name, and tid information.
wrapping	Wrapping entries.

Examples

The following command displays Type 6 password encryption feature information:

```
Router# show type6 server
```

```
Server detail information:
```

```
=====
```

```
AES config State : Enabled
Masterkey config State : Enabled
Type6 feature State : Enabled
Master key Inprogress : No
```

```
Router# show type6 trace server all
```

```
Client file lib/type6/type6_server_wr
25 wrapping entries (18496 possible, 64 allocated, 0 filtered, 25 total)
Jul 19 09:59:27.168 lib/type6/type6_server_wr 0/RP0/CPU0 t7145 ***** Type6 server process
```

```

started Respawn count (1) ****
...
...
Jul 19 12:22:59.908 lib/type6/type6_server_wr 0/RP0/CPU0 t7145 User has started Master key
operation (CREATE)
Jul 19 12:22:59.908 lib/type6/type6_server_wr 0/RP0/CPU0 t7145 Created Master key in TAM
successfully
Jul 19 12:23:00.265 lib/type6/type6_server_wr 0/RP0/CPU0 t7145 Master key Available set to
(AVAILABLE)
Jul 19 12:23:00.272 lib/type6/type6_server_wr 0/RP0/CPU0 t7145 Master key inprogress set
to (NOT INPROGRESS)

```

```
Router# show type6 clients
```

```
Type6 Clients information:
```

```

Client Name   MK State
=====
keychain      UNKNOWN

```

This example shows a sample output of the **masterkey update status** command:

```

Router#show type6 masterkey update status
Thu Sep 17 06:50:07.980 UTC
Type6 masterkey operation is inprogress

```

```

Masterkey upate status information:
Client Name           Status
=====
keychain              INPROGRESS

```

Related Commands	Command	Description
	clear type6 client, on page 106	Clears the Type 6 client state.

tcp ao

To enable the TCP authentication option, use the **tcp ao** command in global configuration mode.

```

tcp ao
no tcp ao

```

Syntax Description	This command has no arguments or keywords.				
Command Default	The TCP authentication option is not enabled.				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.5.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.5.1	This command was introduced.
Release	Modification				
Release 6.5.1	This command was introduced.				

Task ID	Task ID	Operations
	bgp	read

Examples

This example shows how to configure the **tcp ao** command:

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router (config)# tcp ao
```



CHAPTER 4

Lawful Intercept Commands

This module describes the Cisco IOS XR software commands used to configure lawful intercept (LI).

For detailed information about keychain management concepts, configuration tasks, and examples, see the *Implementing Lawful Intercept in the Configuration Module* .

- [overlap-tap enable, on page 119](#)

overlap-tap enable

To configure traffic interception separately for two inter-communicating intercepted hosts, use the **overlap-tap enable** command in XR Config mode. To revert to the default configuration, use the **no** form of this command.

overlap-tap enable

Syntax Description

This command has no keywords or arguments.

Command Default

For two inter-communicating hosts where both the hosts are separately intercepted, only the ingress traffic on the ASR 9000 router related to one of the hosts is intercepted.

Command Modes

XR Config mode

Command History

Release	Modification
Release 5.3.2	This command was introduced.

Usage Guidelines

To use **overlap-tap enable** command, you must have lawful intercept configured by installing and activating **asr9k-li-px.pie**.

Task ID

Task ID	Operation
li	read

Example

The following example shows how to configure interception of both the ingress and egress traffic on the ASR 9000 router related to two inter-communicating hosts.

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router (config)# overlap-tap enable
```



CHAPTER 5

Management Plane Protection Commands

This module describes the commands used to configure management plane protection (MPP).

For detailed information about keychain management concepts, configuration tasks, and examples, see the *Implementing Management Plane Protection on* module in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

- [address ipv4 \(MPP\)](#), on page 121
- [allow](#), on page 122
- [control-plane](#), on page 124
- [inband](#), on page 125
- [interface \(MPP\)](#), on page 126
- [management-plane](#), on page 127
- [out-of-band](#), on page 128
- [show mgmt-plane](#), on page 129
- [vrf \(MPP\)](#), on page 131

address ipv4 (MPP)

To configure the peer IPv4 address in which management traffic is allowed on the interface, use the **address ipv4** command in interface peer configuration mode. To remove the IP address that was previously configured on this interface, use the **no** form of this command.

Syntax Description	<i>peer-ip-address</i> Peer IPv4 address in which management traffic is allowed on the interface. This address can effectively be the source address of the management traffic that is coming in on the configured interface.
	<i>peer ip-address/length</i> Prefix of the peer IPv4 <ul style="list-style-type: none">• IPv4—<i>A.B.C.D/length</i>
Command Default	If no specific peer is configured, all peers are allowed.
Command Modes	Interface peer configuration
Usage Guidelines	No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to configure the peer address for management traffic:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-mpp)# inband
RP/0/RP0/CPU0:router(config-mpp-inband)# interface all
RP/0/RP0/CPU0:router(config-mpp-inbandoutband-all)# allow all peer
RP/0/RP0/CPU0:router(config-telnetftp-peer)# address ipv4 10.1.0.0/16
```

allow

To configure an interface as an inband or out-of-band interface to allow all peer addresses for a specified protocol or all protocols, use the **allow** command in management plane protection inband interface configuration mode or management plane protection out-of-band interface configuration. To disallow a protocol on an interface, use the **no** form of this command.

allow {*protocol* | **all**} [**peer**]

Syntax Description

protocol Interface configured to allow peer-filtering for the following specified protocol's traffic:

- HTTP(S)
- SNMP (also versions)
- Secure Shell (v1 and v2)
- TFTP
- Telnet
- XML

all Configures the interface to allow peer-filtering for all the management traffic that is specified in the list of protocols.

peer (Optional) Configures the peer address on the interface. Peer refers to the neighboring router interface in which traffic might arrive to the main router.

Command Default

By default, no management protocol is allowed on any interface except the management interfaces.

Command Modes

Management plane protection inband interface configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines If you permit or allow a specific protocol to an interface, traffic is allowed only for that protocol, and all other management traffic is dropped.

After you configure the interface as inband or out-of-band, the specified protocol's traffic, or all protocol traffic, is allowed on the interface. Interfaces that are not configured as inband or out-of-band interfaces, drop the protocol traffic.

The IOS XR XML API provides a programmatic interface to the router for use by external management applications. This interface provides a mechanism for router configuration and monitoring utilizing XML formatted request and response streams. As one of the management services, XML should be capable of applying MPP. To secure XML MPP data, XML keyword has been added to the command.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to configure all management protocols for all inband interfaces:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-mpp)# inband
RP/0/RP0/CPU0:router(config-mpp-inband)# interface all
RP/0/RP0/CPU0:router(config-mpp-inband-all)# allow all
```

The following example shows how to configure peer interface for the TFTP protocol for out-of-band interfaces:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-mpp)# out-of-band
RP/0/RP0/CPU0:router(config-mpp-outband)# interface GigabitEthernet 0/1/1/2
RP/0/RP0/CPU0:router(config-mpp-outband-GigabitEthernet0_1_1_2)# allow TFTP peer
RP/0/RP0/CPU0:router(config-tftp-peer)#
```

The following example shows how to configure MPP support on an XML peer in-band interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-ctrl-mpp)# inband interface all allow xml peer address ipv4
172.10.10.1
```

Related Commands	Command	Description
	control-plane, on page 124	Configures the control plane.

Command	Description
inband , on page 125	Configures an inband interface or protocol.
interface (MPP) , on page 126	Configures a specific inband or out-of-band interface or all inband or out-of-band interfaces.
management-plane , on page 127	Configures management plane protection to allow and disallow protocols.
out-of-band , on page 128	Configures out-of-band interfaces or protocols and enters management plane protection out-of-band configuration mode.
show mgmt-plane , on page 129	Displays the management plane.

control-plane

To enter the control plane configuration mode, use the **control-plane** command in XR Config mode. To disable all the configurations under control plane mode, use the **no** form of this command.

control-plane

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **control-plane** command to enter control plane configuration mode.

Task ID	Task	Operations
	system	read, write

Examples

The following example shows how to enter control plane configuration mode using the **control-plane** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)#
```

Related Commands	Command	Description
	management-plane, on page 127	Configures management plane protection to allow and disallow protocols.

inband

To configure an inband interface and to enter management plane protection inband configuration mode, use the **inband** command in management plane protection configuration mode. To disable all configurations under inband configuration mode, use the **no** form of this command.

inband

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes Management plane protection configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **inband** command to enter management plane protection inband configuration mode.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to enter management plane protection inband configuration mode using the **inband** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-mpp)# inband
RP/0/RP0/CPU0:router(config-mpp-inband)#
```

Related Commands	Command	Description
	control-plane, on page 124	Configures the control plane.
	interface (MPP), on page 126	Configures a specific inband or out-of-band interface or all inband or out-of-band interfaces.
	management-plane, on page 127	Configures management plane protection to allow and disallow protocols.

Command	Description
out-of-band, on page 128	Configures out-of-band interfaces or protocols and enters management plane protection out-of-band configuration mode.
show mgmt-plane, on page 129	Displays the management plane.

interface (MPP)

To configure a specific interface or all interfaces as an inband or out-of-band interface, use the **interface** command in management plane protection inband configuration mode or management plane protection out-of-band configuration mode. To disable all the configurations under an interface mode, use the **no** form of this command.

interface {*type interface-path-id* | **all**}

Syntax Description	
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Virtual interface instance. Number range varies depending on interface type.
Note	Use the show interfaces command in EXEC mode to see a list of all interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark (?) online help function.
all	Configures all interfaces to allow for management traffic.

Command Default None

Command Modes Management plane protection out-of-band configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **interface** command to enter management plane protection inband interface configuration mode or management plane protection out-of-band interface configuration mode.

For the *instance* argument, you cannot configure Management Ethernet interfaces as inband interfaces.

Task ID	Task ID	Operations
	system	read, write

Examples The following example shows how to configure all inband interfaces for MPP:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-mpp)# inband
RP/0/RP0/CPU0:router(config-mpp-inband)# interface all
RP/0/RP0/CPU0:router(config-mpp-inband-all)#
```

The following example shows how to configure all out-of-band interfaces for MPP:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-mpp)# out-of-band
RP/0/RP0/CPU0:router(config-mpp-outband)# interface all
RP/0/RP0/CPU0:router(config-mpp-outband-all)#
```

Related Commands	Command	Description
	allow, on page 122	Configures an interface as an inband or out-of-band interface to allow all peer addresses for a specified protocol or all protocols.
	control-plane, on page 124	Configures the control plane.
	inband, on page 125	Configures an inband interface or protocol.
	management-plane, on page 127	Configures management plane protection to allow and disallow protocols.
	out-of-band, on page 128	Configures out-of-band interfaces or protocols and enters management plane protection out-of-band configuration mode.
	show mgmt-plane, on page 129	Displays the management plane.

management-plane

To configure management plane protection to allow and disallow protocols, use the **management-plane** command in control plane configuration mode. To disable all configurations under management-plane mode, use the **no** form of this command.

management-plane

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes Control plane configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **management-plane** command to enter the management plane protection configuration mode.

Task ID	Task ID	Operations
	system	read, write

Examples The following example shows how to enter management plane protection configuration mode using the **management-plane** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-mpp)#
```

out-of-band

To configure out-of-band interfaces or protocols and to enter management plane protection out-of-band configuration mode, use the **out-of-band** command in management plane protection configuration mode. To disable all configurations under management plane protection out-of-band configuration mode, use the **no** form of this command.

out-of-band

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes Management plane protection out-of-band configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **out-of-band** command to enter management plane protection out-of-band configuration mode.

Out-of-band refers to an interface that allows only management protocol traffic to be forwarded or processed. An *out-of-band management interface* is defined by the network operator to specifically receive network management traffic. The advantage is that forwarding (or customer) traffic cannot interfere with the management of the router.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to enter management plane protection out-of-band configuration mode using the **out-of-band** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# control-plane
RP/0/RP0/CPU0:router(config-ctrl)# management-plane
RP/0/RP0/CPU0:router(config-mpp)# out-of-band
RP/0/RP0/CPU0:router(config-mpp-outband)#
```

Related Commands

Command	Description
control-plane, on page 124	Configures the control plane.
inband, on page 125	Configures an inband interface or protocol.
interface (MPP), on page 126	Configures a specific inband or out-of-band interface or all inband or out-of-band interfaces.
management-plane, on page 127	Configures management plane protection to allow and disallow protocols.
show mgmt-plane, on page 129	Displays the management plane.
vrf (MPP), on page 131	Configures a Virtual Private Network (VPN) routing and forwarding (VRF) reference of an out-of-band interface.

show mgmt-plane

To display information about the management plane such as type of interface and protocols enabled on the interface, use the **show mgmt-plane** command in XR EXEC mode.

```
show mgmt-plane [{inband | out-of-band}] [{interface type interface-path-id | vrf}]
```

Syntax Description

inband	(Optional) Displays the inband management interface configurations that are the interfaces that process management packets as well as data-forwarding packets. An inband management interface is also called a <i>shared management interface</i> .
out-of-band	(Optional) Displays the out-of-band interface configurations. Out-of-band interfaces are defined by the network operator to specifically receive network management traffic.
interface	(Optional) Displays all the protocols that are allowed in the specified interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Interface instance. Number range varies depending on interface type.
Note	Use the show interfaces command to see a list of all interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark (?) online help function.

show mgmt-plane

vrf (Optional) Displays the Virtual Private Network (VPN) routing and forwarding reference of an out-of-band interface.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines The **vrf** keyword is valid only for out-of-band VRF configurations.

Task ID	Task ID	Operations
	system	read

Examples

The following sample output displays all the interfaces that are configured as inband or out-of-band interfaces under MPP:

```
RP/0/RP0/CPU0:router# show mgmt-plane

Management Plane Protection

inband interfaces
-----

interface - GigabitEthernet0_1_1_0
  ssh configured -
    All peers allowed
  telnet configured -
    peer v4 allowed - 10.1.0.0/16
  all configured -
    All peers allowed
interface - GigabitEthernet0_1_1_0
  telnet configured -
    peer v4 allowed - 10.1.0.0/16

interface - all
  all configured -
    All peers allowed

outband interfaces
-----

interface - GigabitEthernet0_1_1_0
  tftp configured -
    peer v6 allowed - 33::33
```

The following sample output displays the Virtual Private Network (VPN) routing and forwarding (VRF) reference of an out-of-band interface:

```
RP/0/RP0/CPU0:router# show mgmt-plane out-of-band vrf
```

```
Management Plane Protection -
  out-of-band VRF - my_out_of_band
```

Related Commands	Command	Description
	management-plane , on page 127	Configures management plane protection to allow and disallow protocols.

vrf (MPP)

To configure a Virtual Private Network (VPN) routing and forwarding (VRF) reference of an out-of-band interface, use the **vrf** command in management plane protection out-of-band configuration mode. To remove the VRF definition before the VRF name is used, use the **no** form of this command.

```
vrf vrf-name
```

Syntax Description *vrf-name* Name assigned to a VRF.

Command Default The VRF concept must be used to configure interfaces as out-of-band. If no VRF is configured during an out-of-band configuration, the interface goes into a default VRF.

Command Modes Management plane protection out-of-band configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines If the VRF reference is not configured, the default name MPP_OUTBAND_VRF is used. If there is an out-of-band configuration that is referring to a VRF and the VRF is deleted, all the MPP bindings are removed.

Task ID	Task ID	Operations
	system	read

Examples

The following example shows how to configure the VRF:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# vrf my_out_of_band
RP/0/RP0/CPU0:router(config-vrf)# address-family ipv4 unicast
RP/0/RP0/CPU0:router(config-vrf-af)# exit
RP/0/RP0/CPU0:router(config-vrf)# address-family ipv6 unicast
RP/0/RP0/CPU0:router(config-vrf-af)# commit
RP/0/RP0/CPU0:router(config-vrf-af)# end
RP/0/RP0/CPU0:router#
```

The following example shows how to configure the VRF definition for MPP:

```

RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# control-plane
RP/0/RP0/CPU0:router (config-ctrl)# management-plane
RP/0/RP0/CPU0:router (config-mpp)# out-of-band
RP/0/RP0/CPU0:router (config-mpp-outband)# vrf my_out_of_band

```

Related Commands

Command	Description
control-plane, on page 124	Configures the control plane.
interface (MPP), on page 126	Configures a specific inband or out-of-band interface or all inband or out-of-band interfaces.
management-plane, on page 127	Configures management plane protection to allow and disallow protocols.
out-of-band, on page 128	Configures out-of-band interfaces or protocols and enters management plane protection out-of-band configuration mode.
show mgmt-plane, on page 129	Displays the management plane.



CHAPTER 6

Public Key Infrastructure Commands

This module describes the commands used to configure Public Key Infrastructure (PKI).

For detailed information about PKI concepts, configuration tasks, and examples, see the *Implementing Certification Authority Interoperability on* module in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

- [clear crypto ca certificates](#), on page 134
- [clear crypto ca crl](#), on page 134
- [crl optional \(trustpoint\)](#), on page 135
- [crypto ca authenticate](#), on page 136
- [crypto ca cancel-enroll](#), on page 138
- [crypto ca enroll](#), on page 139
- [crypto ca import](#), on page 140
- [crypto ca trustpoint](#), on page 141
- [crypto ca trustpool import url](#), on page 142
- [crypto ca trustpool policy](#), on page 144
- [crypto key generate dsa](#), on page 145
- [crypto key generate ecdsa](#), on page 146
- [crypto key generate rsa](#), on page 147
- [crypto key import authentication rsa](#), on page 148
- [crypto key zeroize dsa](#), on page 148
- [crypto key zeroize ecdsa](#), on page 149
- [crypto key zeroize rsa](#), on page 150
- [description \(trustpoint\)](#), on page 151
- [enrollment retry count](#), on page 152
- [enrollment retry period](#), on page 153
- [enrollment terminal](#), on page 154
- [enrollment url](#), on page 155
- [ip-address \(trustpoint\)](#), on page 156
- [query url](#), on page 157
- [rsa-keypair](#), on page 158
- [serial-number \(trustpoint\)](#), on page 159
- [sftp-password \(trustpoint\)](#), on page 160
- [sftp-username \(trustpoint\)](#), on page 161
- [subject-name \(trustpoint\)](#), on page 162

- [show crypto ca certificates](#), on page 163
- [show crypto ca crls](#), on page 165
- [show crypto ca trustpool policy](#), on page 166
- [show crypto key mypubkey dsa](#), on page 166
- [show crypto key mypubkey ecdsa](#), on page 167
- [show crypto key mypubkey rsa](#), on page 168

clear crypto ca certificates

To clear certificates associated with trustpoints that no longer exist in the configuration file, use the **clear crypto ca certificates** command in XR EXEC mode.

clear crypto ca certificates *trustpoint*

Syntax Description

trustpoint Trustpoint name.

Command Default

None

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

If the router is loaded with a new configuration file and certificates in the new configuration file do not have their corresponding trustpoint configuration, use the **clear crypto ca certificates** command to clear the certificates associated with trustpoints that no longer exist in the configuration file.

The **clear crypto ca certificates** command deletes both certification authority (CA) and router certificates from the system.

Task ID

Task ID	Operations
crypto	execute

Examples

The following example shows how to clear the certificates associated with trustpoints that no longer exist in the configuration file:

```
RP/0/RP0/CPU0:router# clear crypto ca certificates tp_1
```

clear crypto ca crl

To clear all the Certificate Revocation Lists (CRLs) stored on the router, use the **clear crypto ca crl** command.

clear crypto ca crl

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **clear crypto ca crl** command to clear all CRLs stored on the router. As a result, the router goes through the certification authorities (CAs) to download new CRLs for incoming certificate validation requests.

Task ID	Task ID	Operations
	crypto	execute

Examples

The following example shows how to clear all CRLs stored on the router:

```
RP/0/RP0/CPU0:router# show crypto ca crls

CRL Entry
=====
  Issuer : cn=Certificate Manager,ou=HFR,o=Cisco Systems,l=San Jose,st=CA,c=US
  Last Update : [UTC] Wed Jun  5 02:40:04 2002
  Next Update : [UTC] Wed Jun  5 03:00:04 2002
  CRL Distribution Point :
  ldap://manager.cisco.com/CN=Certificate Manager,O=Cisco Systems

RP/0/RP0/CPU0:router# clear crypto ca crl
RP/0/RP0/CPU0:router# show crypto ca crls
RP/0/RP0/CPU0:router#
```

Related Commands	Command	Description
	show crypto ca crls, on page 165	Displays the information about CRLs on the router.

crl optional (trustpoint)

To allow the certificates of other peers to be accepted without trying to obtain the appropriate CRL, use the **crl optional** command in trustpoint configuration mode. To return to the default behavior in which CRL checking is mandatory before your router can accept a certificate, use the **no** form of this command.

crl optional

Syntax Description This command has no keywords or arguments.

Command Default The router must have and check the appropriate CRL before accepting the certificate of another IP security peer.

Command Modes Trustpoint configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines When your router receives a certificate from a peer, it searches its memory for the appropriate CRL. If the router finds the appropriate CRL, that CRL is used. Otherwise, the router downloads the CRL from either the certificate authority (CA) or from a CRL distribution point (CDP) as designated in the certificate of the peer. Your router will then check the CRL to ensure that the certificate that the peer sent has not been revoked. If the certificate appears on the CRL, your router cannot accept the certificate and will not authenticate the peer. To instruct the router not to download the CRL and treat the certificate as not revoked, use the **cr1 optional** command.

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example declares a CA and permits your router to accept certificates without trying to obtain a CRL. This example also specifies a nonstandard retry period and retry count.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint myca
RP/0/RP0/CPU0:router(config-trustp)# enrollment url http://ca_server
RP/0/RP0/CPU0:router(config-trustp)# enrollment retry period 20
RP/0/RP0/CPU0:router(config-trustp)# enrollment retry count 100
RP/0/RP0/CPU0:router(config-trustp)# cr1 optional
```

Related Commands

Command	Description
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
enrollment retry count, on page 152	Specifies how many times a router resends a certificate request.
enrollment retry period, on page 153	Specifies the wait period between certificate request retries.
enrollment url, on page 155	Specifies the URL of the CA.

crypto ca authenticate

To authenticate the certification authority (CA) by getting the certificate for the CA, use the **crypto ca authenticate** command in XR EXEC mode.

crypto ca authenticate {*ca-name*}

Syntax Description	<i>ca-name</i> Name of the CA Server.
---------------------------	---------------------------------------

Command Default	None
------------------------	------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines The **crypto ca authenticate** command is required when you initially configure CA support at your router.

This command authenticates the CA to your router by obtaining the CA certificate, which contains the public key for the CA. For self-signed root CA, because the CA signs its own certificate, you should manually authenticate the CA public key by contacting the CA administrator when you use this command. The certificate fingerprint matching is done out-of-band (for example, phone call, and so forth).

Authenticating a second-level CA requires prior authentication of the root CA.

After the **crypto ca authenticate** command is issued and the CA does not respond by the specified timeout period, you must obtain terminal control again to re-enter the command.

Task ID	Task ID	Operations
	crypto	execute

Examples

The CA sends the certificate, and the router prompts the administrator to verify the certificate by checking the certificate fingerprint (a unique identifier). The CA administrator can also display the CA certificate fingerprint, so you should compare what the CA administrator sees to what the router displays on the screen. If the fingerprint on the display matches the fingerprint displayed by the CA administrator, you should accept the certificate as valid.

The following example shows that the router requests the CA certificate:

```
Router# crypto ca authenticate msiox
Retrieve Certificate from SFTP server? [yes/no]: yes
Read 860 bytes as CA certificate
  Serial Number   : 06:A5:1B:E6:4F:5D:F7:83:41:11:D5:F9:22:7F:95:23
  Subject:
    Name: CA2
    CN= CA2
  Issued By      :
    cn=CA2
  Validity Start : 07:51:51 UTC Wed Jul 06 2005
  Validity End   : 08:00:43 UTC Tue Jul 06 2010
  CRL Distribution Point
    http://10.56.8.236/CertEnroll/CA2.crl
Certificate has the following attributes:
  Fingerprint: D0 44 36 48 CE 08 9D 29 04 C4 2D 69 80 55 53 A3

Do you accept this certificate? [yes/no]: yes
```

```
Router#:Apr 10 00:28:52.324 : cepki[335]: %SECURITY-CEPKI-6-INFO : certificate database
updated
Do you accept this certificate? [yes/no] yes
```

Related Commands	Command	Description
	crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
	show crypto ca certificates, on page 163	Displays information about your certificate and the certificate of the CA.

crypto ca cancel-enroll

To cancel a current enrollment request, use the **crypto ca cancel-enroll** command in XR EXEC mode.

crypto ca cancel-enroll *ca-name*

Syntax Description *ca-name* Name of the certification authority (CA).

Command Default None

Command Modes XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines Use the **crypto ca enroll** command to request certificates from the CA for the Rivest, Shamir, and Adelman (RSA) key pairs for the router defined by the [rsakeypair, on page 158](#) command in trustpoint configuration mode. If no [rsakeypair, on page 158](#) command is configured for the current trustpoint, the default RSA key pair is used for enrollment. This task is also known as enrolling with the CA. Use the **crypto ca cancel-enroll** command to cancel a current enrollment request.

Task ID

Task ID	Operations
crypto	execute

Examples The following example shows how to cancel a current enrollment request from a CA named **myca**:

```
RP/0/RP0/CPU0:router# crypto ca cancel-enroll myca
```

Related Commands	Command	Description
	crypto ca enroll, on page 139	Obtains a router certificate from the CA.
	rsa-keypair, on page 158	Specifies a named RSA key pair for a trustpoint.

crypto ca enroll

To obtain a router certificate from the certification authority (CA), use the **crypto ca enroll** command in XR EXEC mode.

```
crypto ca enroll {ca-name}
```

Syntax Description	<i>ca-name</i> Name of the CA Server.
---------------------------	---------------------------------------

Command Default	None
------------------------	------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **crypto ca enroll** command to request certificates from the CA for the Rivest, Shamir, and Adelman (RSA) key pairs for the router defined by the [rsa-keypair, on page 158](#) command in trustpoint configuration mode. If no [rsa-keypair, on page 158](#) command is configured for the current trustpoint, the default RSA key pair is used for enrollment. This task is also known as enrolling with the CA. (Enrolling and obtaining certificates are two separate events, but they both occur when the **crypto ca enroll** command is issued.) When using manual enrollment, these two operations occur separately.

The router needs a signed certificate from the CA for each of the RSA key pairs on the router; if you previously generated general-purpose keys, this command obtains the one certificate corresponding to the one general-purpose RSA key pair. If you previously generated special-usage keys, this command obtains two certificates corresponding to each of the special-usage RSA key pairs.

If you already have a certificate for your keys, you are unable to configure this command; instead, you are prompted to remove the existing certificate first. (You can remove existing certificates by removing the trustpoint configuration with the **no crypto ca trustpoint** command.)

The **crypto ca enroll** command is not saved in the router configuration.



Note The root certificate signs the leaf certificate.

Task ID	Task ID	Operations
	crypto	execute

Examples

The following sample output is from the **crypto ca enroll** command:

```
Router# crypto ca enroll msiox
% Start certificate enrollment...
% Create a challenge password. You will need to verbally provide this password to the
  CA Administrator in order to revoke your certificate.
% For security reasons your password will not be saved in the configuration.
% Please make a note of it.
%Password
re-enter Password:
  Fingerprint: 4F35ADC9 2791997A CE211437 AFC66CF7
RP/0/RP0/CPU0:May 29 18:49:15.572 : pki_cmd: %PKI-6-LOG_INFO : certificate request pending
RP/0/RP0/CPU0:May 29 18:52:17.705 : pki_get_cert: %PKI-6-LOG_INFO : certificate is granted
```

Related Commands

Command	Description
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
rsakeypair, on page 158	Specifies a named RSA key pair for a trustpoint.

crypto ca import

To import a certification authority (CA) certificate manually through TFTP, SFTP, or cut and paste it at the terminal, use the **crypto ca import** command in XR EXEC mode.

crypto ca import *name* *certificate*

Syntax Description

name Name of the certification authority (CA). This name is the same name used when the CA was declared with the [crypto ca trustpoint, on page 141](#) command.

Command Default

None

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
crypto	execute

Examples

The following example shows how to import a CA certificate through cut-and-paste. In this example, the certificate is myca.

```
RP/0/RP0/CPU0:router# crypto ca import myca certificate
```

Related Commands	Command	Description
	crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
	show crypto ca certificates, on page 163	Displays information about your certificate and the certification authority (CA) certificate.

crypto ca trustpoint

To configure a trusted point with a selected name, use the **crypto ca trustpoint** command. To unconfigure a trusted point, use the **no** form of this command in XR Config mode.

```
crypto ca trustpoint {ca-name}
```

Syntax Description	
	<i>ca-name</i> Name of the CA.

Command Default	
	None

Command Modes	
	XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines	
	Use the crypto ca trustpoint command to declare a CA.
	This command allows you to configure a trusted point with a selected name so that your router can verify certificates issued to peers. Your router need not enroll with the CA that issued the certificates to the peers.
	The crypto ca trustpoint command enters trustpoint configuration mode, in which you can specify characteristics for the CA with a set of commands. See the Related Commands section for details.

Task ID	Task ID	Operations
	crypto	execute

Examples	
	The following example shows how to use the crypto ca trustpoint command to create a trustpoint:

```
Router# configure
Router(config)# crypto ca trustpoint msiox
Router(config-trustp)# sftp-password xxxxxx
Router(config-trustp)# sftp-username tmordeko
Router(config-trustp)# enrollment url sftp://192.168..254.254/tftpboot/tmordeko/CAcert
```

```
Router(config-trustp)# rsakeypair label-2
```

Related Commands

Command	Description
crl optional (trustpoint), on page 135	Allows the certificates of other peers to be accepted without trying to obtain the appropriate CRL.
enrollment retry count, on page 152	Specifies how many times a router resends a certificate request.
enrollment retry period, on page 153	Specifies the wait period between certificate request retries.
enrollment url, on page 155	Specifies the URL of the CA.
ip-address (trustpoint), on page 156	Specifies a dotted IP address that is included as an unstructured address in the certificate request.
query url, on page 157	Specifies the LDAP URL of the CRL distribution point.
rsakeypair, on page 158	Specifies a named RSA key pair for this trustpoint.
serial-number (trustpoint), on page 159	Specifies a router serial number in the certificate request.
sftp-password (trustpoint), on page 160	Secures the FTP password.
sftp-username (trustpoint), on page 161	Secures the FTP username.
subject-name (trustpoint), on page 162	Specifies a subject name in the certificate request.

crypto ca trustpool import url

To manually update certificates in the trust pool if they are not current, are corrupt, or if certain certificates need to be updated, use the **crypto ca trustpool import url** command in XR EXEC mode.

```
crypto ca trustpool import url { clean URL }
```

Syntax Description

clean (Optional) Manually remove all downloaded certificate authority (CA) certificates.

URL Specify the URL from which the CA trust pool certificate bundle must be downloaded. This manually imports (downloads) the CA certificate bundle into the CA trust pool to update or replace the existing CA certificate bundle.

This parameter can either be the URL of an external server or the local folder path (**/tmp**) in the router where the certificate is available.

Command Default

The CA trust pool feature is enabled. The router uses the built-in CA certificate bundle in the CA trust pool which is updated automatically from Cisco.

Command Modes

XR EXEC mode

Command History	Release	Modification
	Release 5.2.0	This command was introduced.
	Release 7.1.2	This command was modified to also allow a local folder path (/tmp) in the router as the <i>URL</i> parameter.

Usage Guidelines

The CA trust pool feature is enabled by default and uses the built-in CA certificate bundle in the trust pool, which receives automatic updates from Cisco. Use the **crypto ca trustpool import url** command to manually update certificates in the trust pool if they are not current, are corrupt, or if certain certificates need to be updated.

From Cisco IOS XR Software Release 7.1.2 and later, you can also specify a local folder path (**/tmp**) in the router as the *URL* parameter for **crypto ca trustpool import url** command. This is useful in scenarios where the router does not have connectivity to an external server to download the certificate. In such cases, you can download the certificate from an external server to elsewhere, and then copy it to the **/tmp** folder in the router.



Note The local folder path in the router has to be **/tmp** itself; no other folder paths are allowed.

The format of the certificate can .pem, .der, or .p7b(bundle).

For example,

```
crypto ca trustpool import url /tmp/certificate.pem
```

```
crypto ca trustpool import url /tmp/certificate.der
```

```
crypto ca trustpool import url /tmp/pki_bundle_tmp.p7b
```

Task ID	Task ID	Operation
	crypto	execute

This example shows how to run the command to manually update certificates in the trust pool if they are not current, are corrupt, or if certain certificates need to be updated. The certificate is directly downloaded from an external server, in this case.

```
Router#crypto ca trustpool import url http://www.cisco.com/security/pki/trs/ios.p7b
```

This example shows how to import a certificate that resides in the local **/tmp** folder in the router:

```
Router#crypto ca trustpool import url /tmp/certificate.der
```

Related Commands

Command	Description
show crypto ca trustpool policy, on page 166	Display the CA trust pool certificates of the router in a verbose format.
crypto ca trustpool policy, on page 144	Configure CA trust pool policy parameters.

crypto ca trustpool policy

To configure certificate authority (CA) trust pool policy, use the **crypto ca trustpool policy** command in XR Config mode.

```
crypto ca trustpool policy {cabundle url url | crl optional | description line}
```

Syntax Description

cabundle url <i>URL</i>	Configures the URL from which the CA trust pool bundle is downloaded.
crl optional	To specify the certificate revocation list (CRL) query for the CA trust pool, use the <code>crl</code> command in <code>ca-trustpool</code> configuration mode. By default, the router enforces a check of the revocation status of the certificate by querying the certificate revocation list (CRL). Setting this to <code>optional</code> disables revocation checking when the trust pool policy is in use.
description <i>line</i>	Indicates the description for the trust pool policy.

Command Default

The default CA trust pool policy is used.

Command Modes

XR Config mode

Command History

Release	Modification
Release 5.2.0	This command was introduced.

Usage Guidelines

The **crypto ca trustpool policy** command enters `ca-trustpool` configuration mode, where commands can be accessed to configure certificate authority (CA) trustpool policy parameters.

Task ID

Task ID	Operation
crypto	READ, WRITE

Example

This example shows you how to disable certificate revocation checks when the trust pool policy is in use.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:IMC0(config)#crypto ca trustpool policy
RP/0/RSP0/CPU0:IMC0(config-trustpool)#RP/0/RSP0/CPU0:IMC0(config-trustpool)#crl optional
```

Related Commands

Command	Description
crypto ca trustpool import url, on page 142	Allows you to manually update certificates in the trust pool.

Command	Description
show crypto ca trustpool policy, on page 166	Displays the CA trust pool certificates of the router in a verbose format.

crypto key generate dsa

To generate Digital Signature Algorithm (DSA) key pairs, use the **crypto key generate dsa** command in XR EXEC mode.

crypto key generate dsa

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **crypto key generate dsa** command to generate DSA key pairs for your router.

DSA keys are generated in pairs—one public DSA key and one private DSA key.

If your router already has DSA keys when you issue this command, you are warned and prompted to replace the existing keys with new keys.

To remove the DSA key generated, use the **crypto key zeroize dsa** command.

Task ID	Task ID	Operations
	crypto	execute

Examples

The following example shows how to generate a 512-bit DSA key:

```
RP/0/RP0/CPU0:router# crypto key generate dsa
The name for the keys will be: the_default
  Choose the size of your DSA key modulus. Modulus size can be 512, 768, or 1024 bits.
Choosing a key modulus
How many bits in the modulus [1024]: 512
Generating DSA keys...
Done w/ crypto generate keypair
[OK]
```

Related Commands	Command	Description
	crypto key zeroize dsa, on page 148	Deletes a DSA key pair from your router.
	show crypto key mypubkey dsa, on page 166	Displays the DSA public keys for your router.

crypto key generate ecdsa

To generate an Elliptic Curve Digital Signature Algorithm (ECDSA) key pair, use the **crypto key generate ecdsa** command in XR EXEC mode.

```
crypto key generate ecdsa [{nistp256 | nistp384 | nistp521}]
```

Syntax Description	Command	Description
	nistp256	Generates an ECDSA key of curve type nistp256, with key size 256 bits.
	nistp384	Generates an ECDSA key of curve type nistp384, with key size 384 bits.
	nistp521	Generates an ECDSA key of curve type nistp521, with key size 521 bits.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.4.1	This command was introduced.

Usage Guidelines To remove an ECDSA key, use the **crypto key zeroize ecdsa** command.

Task ID	Task ID	Operation
	crypto	execute

The following example shows how to generate a ECDSA key pair:

```
Router# crypto key generate ecdsa nistp384
Wed Mar 28 12:53:57.355 UTC
% You already have keys defined for the_default
Do you really want to replace them? [yes/no]: yes
Generating ECDSA keys ...
Done w/ crypto generate ECDSA keypair
[OK]
```

crypto key generate rsa

To generate a Rivest, Shamir, and Adelman (RSA) key pair, use the **crypto key generate rsa** command in XR EXEC mode.

```
crypto key generate rsa [{usage-keys | general-keys}] [keypair-label]
```

Syntax Description

usage-keys (Optional) Generates separate RSA key pairs for signing and encryption.

general-keys (Optional) Generates a general-purpose RSA key pair for signing and encryption.

keypair-label (Optional) RSA key pair label that names the RSA key pairs.

Command Default

RSA key pairs do not exist. If the **usage-keys** keyword is not used, general-purpose keys are generated. If no RSA label is specified, the key is generated as the default RSA key.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **crypto key generate rsa** command to generate RSA key pairs for your router.

RSA keys are generated in pairs—one public RSA key and one private RSA key.

If your router already has RSA keys when you issue this command, you are warned and prompted to replace the existing keys with new keys. The keys generated by this command are saved in the secure NVRAM (which is not displayed to the user or backed up to another device).

To remove an RSA key, use the **crypto key zeroize rsa** command.

Task ID

Task ID	Operations
crypto	execute

Examples

The following example shows how to generate an RSA key pair:

```
Router# crypto key generate rsa
```

```
The name for the keys will be: the_default
```

```
Choose the size of the key modulus in the range of 360 to 2048 for your
General Purpose Keys. Choosing a key modulus greater than 512 may take
a few minutes.
```

```
How many bits in the modulus[1024]: <return>
```

```
Router(config)#
```

Related Commands	Command	Description
	crypto key zeroize rsa, on page 150	Deletes the RSA key pair for your router.
	show crypto key mypubkey rsa, on page 168	Displays the RSA public keys for your router.

crypto key import authentication rsa

To import a public key using the Rivest, Shamir, and Adelman (RSA) method, use the **crypto key import authentication rsa** command in XR EXEC mode.

crypto key import authentication rsa *path*

Syntax Description *path* (Optional) This denotes the path to the RSA public key file.

Command Default None

Command Modes XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

1. Use ssh-keygen generation mechanism to generate keys using either a LINUX or UNIX client. This creates two keys: one public and one private.
2. Remove the comment and other header tag from the keys, except the base64encoded text.
3. Decode the base64encoded text, and use the for authentication.

Task ID

Task ID	Operations
crypto	execute

Examples The following example displays how to import a public key:

```
RP/0/RP0/CPU0:k2#crypto key import authentication rsa
```

crypto key zeroize dsa

To delete the Digital Signature Algorithm (DSA) key pair from your router, use the **crypto key zeroize dsa** command in XR EXEC mode.

crypto key zeroize dsa

Syntax Description	This command has no keywords or arguments.				
Command Default	None				
Command Modes	XR EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				
Usage Guidelines	Use the crypto key zeroize dsa command to delete the DSA key pair that was previously generated by your router.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>crypto</td> <td>execute</td> </tr> </tbody> </table>	Task ID	Operations	crypto	execute
Task ID	Operations				
crypto	execute				
Examples	<p>The following example shows how to delete DSA keys from your router:</p> <pre>RP/0/RP0/CPU0:router# crypto key zeroize dsa % Keys to be removed are named the_default Do you really want to remove these keys? [yes/no]: yes</pre>				

Related Commands	Command	Description
	crypto key generate dsa, on page 145	Generates DSA key pairs.
	show crypto key mypubkey dsa, on page 166	Displays the DSA public keys for your router.

crypto key zeroize ecdsa

To delete the Elliptic Curve Digital Signature Algorithm (ECDSA) key pair from your router, use the **crypto key zeroize ecdsa** command in XR EXEC mode.

crypto key zeroize ecdsa [**nistp256** | **nistp384** | **nistp521**]

Syntax Description	<p>nistp256 Deletes an ECDSA key of curve type nistp256, with key size 256 bits.</p> <p>nistp384 Deletes an ECDSA key of curve type nistp384, with key size 384 bits.</p> <p>nistp521 Deletes an ECDSA key of curve type nistp521, with key size 521 bits.</p>
Command Default	None
Command Modes	XR EXEC mode

Command History	Release	Modification
	Release 6.4.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	crypto	execute

Example

The following example shows how to delete ECDSA keys from your router:

```
RP/0/RP0/CPU0:router# crypto key zeroize ecdsa nistp384

% Keys to be removed are named the_default
Do you really want to remove these keys ?? [yes/no]: yes
```

crypto key zeroize rsa

To delete all Rivest, Shamir, and Adelman (RSA) keys from the router, use the **crypto key zeroize rsa** command in XR EXEC mode.

crypto key zeroize rsa [*keypair-label*]

Syntax Description *keypair-label* (Optional) Names the RSA key pair to be removed.

Command Default If the key pair label is not specified, the default RSA key pair is removed.

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **crypto key zeroize rsa** command to delete all RSA keys that were previously generated by the router. After issuing this command, you must perform two additional tasks:

- Ask the certification authority (CA) administrator to revoke the certificates for the router at the CA; you must supply the challenge password you created when you originally obtained the router certificates with the [crypto ca enroll, on page 139](#) command CA.
- Manually remove the certificates from the configuration using the **clear crypto ca certificates** command.

Task ID	Task ID	Operations
	crypto	execute

Examples

The following example shows how to delete the general-purpose RSA key pair that was previously generated:

```
RP/0//CPU0:router# crypto key zeroize rsa key1
% Keys to be removed are named key1
Do you really want to remove these keys? [yes/no]: yes
```

Related Commands	Command	Description
	clear crypto ca certificates, on page 134	Clears certificates associated with trustpoints that no longer exist in the configuration file.
	crypto ca enroll, on page 139	Obtains a router certificate from the CA.
	crypto key generate rsa, on page 147	Generates RSA key pairs.
	show crypto key mypubkey rsa, on page 168	Displays the RSA public keys for your router.

description (trustpoint)

To create a description of a trustpoint, use the **description** command in trustpoint configuration mode. To delete a trustpoint description, use the **no** form of this command.

description *string*

Syntax Description *string* Character string describing the trustpoint.

Command Default The default description is blank.

Command Modes Trustpoint configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **description** command in the trustpoint configuration mode to create a description for a trustpoint.

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows how to create a trustpoint description:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint myca
RP/0/RP0/CPU0:router(config-trustp)# description this is the primary trustpoint
```

enrollment retry count

To specify the number of times a router resends a certificate request to a certification authority (CA), use the **enrollment retry count** command in trustpoint configuration mode. To reset the retry count to the default, use the **no** form of this command.

enrollment retry count *number*

Syntax Description

number Number of times the router resends a certificate request when the router does not receive a certificate from the previous request. The range is from 1 to 100.

Command Default

If no retry count is specified, the default value is 10.

Command Modes

Trustpoint configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

After requesting a certificate, the router waits to receive a certificate from the CA. If the router does not receive a certificate within a specified time (the retry period), the router sends another certificate request. The router continues to send requests until it receives a valid certificate, the CA returns an enrollment error, or the configured number of retries (the retry count) is exceeded.

To reset the retry count to the default of 10, use the **no** form of this command. Setting the retry count to 0 indicates an infinite number of retries. The router sends the CA certificate requests until a valid certificate is received (there is no limit to the number of retries).

Task ID

Task ID	Operations
crypto	read, write

Examples

The following example shows how to declare a CA, change the retry period to 10 minutes, and change the retry count to 60 retries. The router resends the certificate request every 10 minutes until receipt of the certificate or approximately 10 hours pass since the original request was sent, whichever occurs first (10 minutes x 60 tries = 600 minutes = 10 hours).

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint myca
```

```
RP/0/RP0/CPU0:router(config-trustp)# enrollment url http://ca_server
RP/0/RP0/CPU0:router(config-trustp)# enrollment retry period 10
RP/0/RP0/CPU0:router(config-trustp)# enrollment retry count 60
```

Related Commands	Command	Description
	crl optional (trustpoint), on page 135	Allows the certificates of other peers to be accepted without trying to obtain the appropriate CRL.
	crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
	enrollment retry period, on page 153	Specifies the wait period between certificate request retries.
	enrollment url, on page 155	Specifies the certification authority (CA) location by naming the CA URL.

enrollment retry period

To specify the wait period between certificate request retries, use the **enrollment retry period** command in trustpoint configuration mode. To reset the retry period to the default of 1 minute, use the **no** form of this command.

enrollment retry period *minutes*

Syntax Description	<i>minutes</i> Period (in minutes) between certificate requests issued to a certification authority (CA) from the router. The range is from 1 to 60 minutes.				
Command Default	<i>minutes: 1</i>				
Command Modes	Trustpoint configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				

Usage Guidelines After requesting a certificate, the router waits to receive a certificate from the CA. If the router does not receive a certificate within a specified time (the retry period), the router sends another certificate request. The router continues to send requests until it receives a valid certificate, the CA returns an enrollment error, or the configured number of retries (the retry count) is exceeded.

The router sends the CA another certificate request every minute until a valid certificate is received. (By default, the router sends ten requests, but you can change the number of permitted retries with the **enrollment retry count** command.)

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows how to declare a CA and change the retry period to 5 minutes:

```
RP/0//CPU0:router# configure
RP/0//CPU0:router(config)# crypto ca trustpoint myca
RP/0//CPU0:router(config-trustp)# enrollment retry period 5
```

Related Commands

Command	Description
crl optional (trustpoint), on page 135	Allows the certificates of other peers to be accepted without trying to obtain the appropriate CRL.
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
enrollment retry count, on page 152	Specifies the number of times a router resends a certificate request.

enrollment terminal

To specify manual cut-and-paste certificate enrollment, use the **enrollment terminal** command in trustpoint configuration mode. To delete a current enrollment request, use the **no** form of this command.

enrollment terminal

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

Trustpoint configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

You can manually cut and paste certificate requests and certificates when you do not have a network connection between the router and certification authority (CA). When the **enrollment terminal** command is enabled, the router displays the certificate request on the console terminal, which allows you to enter the issued certificate on the terminal.

Task ID

Task ID	Operations
crypto	read, write

Examples

The following example shows how to manually specify certificate enrollment through cut-and-paste. In this example, the CA trustpoint is myca.

```
RP/0/RP0/CPU0:router# configure
```

```
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint myca
RP/0/RP0/CPU0:router(config-trustp)# enrollment terminal
```

Related Commands

Command	Description
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.

enrollment url

To specify the certification authority (CA) location by naming the CA URL, use the **enrollment url** command in trustpoint configuration mode. To remove the CA URL from the configuration, use the **no** form of this command.

enrollment url *CA-URL*

Syntax Description

CA-URL URL of the CA server. The URL string must start with `http://CA_name`, where `CA_name` is the host Domain Name System (DNS) name or IP address of the CA (for example, `http://ca-server`).

If the CA cgi-bin script location is not `/cgi-bin/pkiclient.exe` at the CA (the default CA cgi-bin script location), you must also include the nonstandard script location in the URL, in the form of `http://CA-name/script-location`, where `script-location` is the full path to the CA scripts.

Command Default

None

Command Modes

Trustpoint configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **enrollment url** command to specify the CA URL. This command is required when you declare a CA with the **crypto ca trustpoint** command. The URL must include the CA script location if the CA scripts are not loaded into the default cgi-bin script location. The CA administrator should be able to tell you where the CA scripts are located.

This table lists the available enrollment methods.

Table 11: Certificate Enrollment Methods

Enrollment Method	Description
SFTP	Enroll through SFTP: file system
TFTP ¹	Enroll through TFTP: file system

¹ If you are using TFTP for enrollment, the URL must be in the form `tftp://certserver/file_specification`. (The file specification is optional.)

TFTP enrollment sends the enrollment request and retrieves the certificate of the CA and the certificate of the router. If the file specification is included in the URL, the router appends an extension to the file specification.

To change the CA URL, repeat the **enrollment url** command to overwrite the previous URL

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows the absolute minimum configuration required to declare a CA:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)#
    crypto ca trustpoint myca
RP/0/RP0/CPU0:router(config-trustp)#
    enrollment url http://ca.domain.com/certsrv/mscep/mscep.dll
```

Related Commands

Command	Description
crl optional (trustpoint), on page 135	Allows the certificates of other peers to be accepted without trying to obtain the appropriate CRL.
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
ip-address (trustpoint), on page 156	Specifies a dotted IP address that is included as an unstructured address in the certificate request.

ip-address (trustpoint)

To specify a dotted IP address that is included as an unstructured address in the certificate request, use the **ip-address** command in trustpoint configuration mode. To restore the default behavior, use the **no** form of this command.

ip-address *{ip-address | none}*

Syntax Description

ip-address Dotted IP address that is included in the certificate request.

none Specifies that an IP address is not included in the certificate request.

Command Default

You are prompted for the IP address during certificate enrollment.

Command Modes

Trustpoint configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **ip-address** command to include the IP address of the specified interface in the certificate request or to specify that an IP address should not be included in the certificate request.

Task ID**Task Operations ID**

crypto read,
write

Examples

The following example shows how to include the IP address of the Ethernet-0 interface in the certificate request for the trustpoint frog:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint frog
RP/0/RP0/CPU0:router(config-trustp)# enrollment url http://frog.phoobin.com
RP/0/RP0/CPU0:router(config-trustp)# subject-name OU=Spiral Dept., O=tiedye.com
RP/0/RP0/CPU0:router(config-trustp)# ip-address 172.19.72.120
```

The following example shows that an IP address is not to be included in the certificate request:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint myca
RP/0/RP0/CPU0:router(config-trustp)# enrollment url http://10.3.0.7:80
RP/0/RP0/CPU0:router(config-trustp)# subject-name CN=subject1, OU=PKI, O=Cisco Systems, C=US
RP/0/RP0/CPU0:router(config-trustp)# ip-address none
```

Related Commands

Command	Description
crl optional (trustpoint), on page 135	Allows the certificates of other peers to be accepted without trying to obtain the appropriate CRL.
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
enrollment url, on page 155	Specifies the certification authority (CA) location by naming the CA URL.
serial-number (trustpoint), on page 159	Specifies whether the router serial number should be included in the certificate request.
subject-name (trustpoint), on page 162	Specifies the subject name in the certificate request.

query url

To specify Lightweight Directory Access Protocol (LDAP) protocol support, use the **query url** command in trustpoint configuration mode. To remove the query URL from the configuration, use the **no** form of this command.

query url *LDAP-URL*

Syntax Description *LDAP-URL* URL of the LDAP server (for example, ldap://another-server).
This URL must be in the form of ldap://server-name where server-name is the host Domain Name System (DNS) name or IP address of the LDAP server.

Command Default The URL provided in the router certificate's CRLDistributionPoint extension is used.

Command Modes Trustpoint configuration

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines LDAP is a query protocol used when the router retrieves the Certificate Revocation List (CRL). The certification authority (CA) administrator should be able to tell you whether the CA supports LDAP; if the CA supports LDAP, the CA administrator can tell you the LDAP location where certificates and certificate revocation lists should be retrieved.

To change the query URL, repeat the **query url** command to overwrite the previous URL.

Task ID

Task ID	Operations
crypto	read, write

Examples The following example shows the configuration required to declare a CA when the CA supports LDAP:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint myca
RP/0/RP0/CPU0:router(config-trustp)# query url ldap://my-ldap.domain.com
```

Related Commands

Command	Description
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.

rsakeypair

To specify a named Rivest, Shamir, and Adelman (RSA) key pair for this trustpoint, use the **rsakeypair** command in trustpoint configuration mode. To reset the RSA key pair to the default, use the **no** form of this command.

rsakeypair *keypair-label*

Syntax Description *keypair-label* RSA key pair label that names the RSA key pairs.

Command Default If the RSA key pair is not specified, the default RSA key is used for this trustpoint.

Command Modes Trustpoint configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **rsa keypair** command to specify a named RSA key pair generated using the **crypto key generate rsa** command for this trustpoint.

Task ID	Task ID	Operations
	crypto	read, write

Examples The following example shows how to specify the named RSA key pair key1 for the trustpoint myca:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint myca
RP/0/RP0/CPU0:router(config-trustp)# rsa keypair key1
```

Related Commands	Command	Description
	crypto key generate rsa, on page 147	Generates RSA key pairs.

serial-number (trustpoint)

To specify whether the router serial number should be included in the certificate request, use the **serial-number** command in trustpoint configuration mode. To restore the default behavior, use the **no** form of this command.

serial-number [**none**]

Syntax Description **none** (Optional) Specifies that a serial number is not included in the certificate request.

Command Default You are prompted for the serial number during certificate enrollment.

Command Modes Trustpoint configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Before you can use the **serial-number** command, you must enable the **crypto ca trustpoint** command, which declares the certification authority (CA) that your router should use and enters trustpoint configuration mode.

Use this command to specify the router serial number in the certificate request, or use the **none** keyword to specify that a serial number should not be included in the certificate request.

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows how to omit a serial number from the root certificate request:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint root
RP/0/RP0/CPU0:router(config-trustp)# enrollment url http://10.3.0.7:80
RP/0/RP0/CPU0:router(config-trustp)# ip-address none
RP/0/RP0/CPU0:router(config-trustp)# serial-number none
RP/0/RP0/CPU0:router(config-trustp)# subject-name ON=Jack, OU=PKI, O=Cisco Systems, C=US
```

Related Commands

Command	Description
crl optional (trustpoint), on page 135	Allows the certificates of other peers to be accepted without trying to obtain the appropriate CRL.
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
enrollment url, on page 155	Specifies the certification authority (CA) location by naming the CA URL.
ip-address (trustpoint), on page 156	Specifies a dotted IP address that is included as an unstructured address in the certificate request.
subject-name (trustpoint), on page 162	Specifies the subject name in the certificate request.

sftp-password (trustpoint)

To secure the FTP password, use the **sftp-password** command in trustpoint configuration mode. To disable this feature, use the **no** form of this command.

```
sftp-password {clear text | clear text | password encrypted string}
```

Syntax Description

<i>clear text</i>	Clear text password and is encrypted only for display purposes.
password <i>encrypted string</i>	Enters the password in an encrypted form.

Command Default

The *clear text* argument is the default behavior.

Command Modes

Trustpoint configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines

Passwords are stored in encrypted form and not as plain text. The command-line interface (CLI) contains the provisioning (for example, clear and encrypted) to specify the password input.

The username and password are required as part of the SFTP protocol. If you specify the URL that begins with the prefix (sftp://), you must configure the parameters for the **sftp-password** command under the trustpoint. Otherwise, the certificate from the SFTP server, which is used for manual certificate enrollment, cannot be retrieved.

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows how to secure the FTP password in an encrypted form:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint msiox
RP/0/RP0/CPU0:router(config-trustp)# sftp-password password xxxxxx
```

Related Commands	Command	Description
	crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
	sftp-username (trustpoint), on page 161	Secures the FTP username.

sftp-username (trustpoint)

To secure the FTP username, use the **sftp-username** command in trustpoint configuration mode. To disable this feature, use the **no** form of this command.

sftp-username *username*

Syntax Description

username Name of the user.

Command Default None

Command Modes Trustpoint configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

subject-name (trustpoint)**Usage Guidelines**

The **sftp-username** command is used only if the URL has (sftp://) in the prefix. If (sftp://) is not specified in the prefix, the manual certificate enrollment using SFTP fails.

Task ID**Task Operations ID**

crypto read,
write

Examples

The following example shows how to secure the FTP username:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# crypto ca trustpoint msiox
RP/0/RP0/CPU0:router(config-trustp)# sftp-username tmordeko
```

Related Commands

Command	Description
crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
sftp-password (trustpoint), on page 160	Secures the FTP password.

subject-name (trustpoint)

To specify the subject name in the certificate request, use the **subject-name** command in trustpoint configuration mode. To clear any subject name from the configuration, use the **no** form of this command.

subject-name *subject-name*

Syntax Description

subject-name (Optional) Specifies the subject name used in the certificate request.

Command Default

If the *subject-name* argument is not specified, the fully qualified domain name (FQDN), which is the default subject name, is used.

Command Modes

Trustpoint configuration

Command History**Release Modification**

Release 5.0.0 This command was introduced.

Usage Guidelines

Before you can use the **subject-name** command, you must enable the **crypto ca trustpoint** command, which declares the certification authority (CA) that your router should use and enters trustpoint configuration mode.

The **subject-name** command is an attribute that can be set for automatic enrollment; thus, issuing this command prevents you from being prompted for a subject name during enrollment.

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows how to specify the subject name for the frog certificate:

```
Router# configure
Router(config)# crypto ca trustpoint frog
Router(config-trustp)# enrollment url http://frog.phoobin.com
Router(config-trustp)# subject-name OU=Spiral Dept., O=tiedye.com
Router(config-trustp)# ip-address 172.19.72.120
```

Related Commands	Command	Description
	crl optional (trustpoint), on page 135	Allows the certificates of other peers to be accepted without trying to obtain the appropriate CRL.
	crypto ca trustpoint, on page 141	Configures a trusted point with a selected name.
	enrollment url, on page 155	Specifies the certification authority (CA) location by naming the CA URL.
	ip-address (trustpoint), on page 156	Specifies a dotted IP address that is included as an unstructured address in the certificate request.
	serial-number (trustpoint), on page 159	Specifies whether the router serial number should be included in the certificate request.

show crypto ca certificates

To display information about your certificate and the certification authority (CA) certificate, use the **show crypto ca certificates** command in XR EXEC mode.

show crypto ca certificates

Syntax Description	This command has no keywords or arguments.				
Command Default	None				
Command Modes	XR EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				

Usage Guidelines

Use the **show crypto ca certificates** command to display information about the following certificates:

- Your certificate, if you have requested one from the CA (see the **crypto ca enroll** command).
- CA certificate, if you have received the certificate (see the **crypto ca authenticate** command).

Task ID**Task ID Operations**

crypto read

Examples

The following sample output is from the **show crypto ca certificates** command:

```
RP/0/RP0/CPU0:router# show crypto ca certificates
Trustpoint      : msiox
=====
CAa certificate
  Serial Number : 06:A5:1B:E6:4F:5D:F7:83:41:11:D5:F9:22:7F:95:23
  Subject:
    Name: CA2
    CN= CA2
  Issued By      :
    cn=CA2
  Validity Start : 07:51:51 UTC Wed Jul 06 2005
  Validity End   : 08:00:43 UTC Tue Jul 06 2010
  CRL Distribution Point
    http://10.56.8.236/CertEnroll/CA2.crl
Router certificate
  Status          : Available
  Key usage       : Signature
  Serial Number   : 38:6B:C6:B8:00:04:00:00:01:45
  Subject:
    Name: tdlr533.cisco.com
    IP Address: 3.1.53.3
    Serial Number: 8cd96b64
  Issued By      :
    cn=CA2
  Validity Start : 08:30:03 UTC Mon Apr 10 2006
  Validity End   : 08:40:03 UTC Tue Apr 10 2007
  CRL Distribution Point
    http://10.56.8.236/CertEnroll/CA2.crl
Associated Trustpoint: MS-IOX
Router certificate
  Status          : Available
  Key usage       : Encryption
  Serial Number   : 38:6D:2B:A7:00:04:00:00:01:46
  Subject:
    Name: tdlr533.cisco.com
    IP Address: 3.1.53.3
    Serial Number: 8cd96b64
  Issued By      :
    cn=CA2
  Validity Start : 08:31:34 UTC Mon Apr 10 2006
  Validity End   : 08:41:34 UTC Tue Apr 10 2007
  CRL Distribution Point
    http://10.56.8.236/CertEnroll/CA2.crl
Associated Trustpoint: msiox
```

Related Commands	Command	Description
	crypto ca authenticate, on page 136	Authenticates the CA by obtaining the certificate of the CA.
	crypto ca enroll, on page 139	Obtains the certificates of your router from the CA.
	crypto ca import, on page 140	Imports a certification authority (CA) certificate manually through TFTP, SFTP, or cut and paste it at the terminal.
	crypto ca trustpoint, on page 141	Configures a trustpoint with a selected name.

show crypto ca crls

To display information about the local cache Certificate Revocation List (CRL), use the **show crypto ca crls** command in XR EXEC mode.

show crypto ca crls

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	crypto	read

Examples

The following sample output is from the **show crypto ca crls** command:

```
RP/0//CPU0:router# show crypto ca crls
CRL Entry
=====
Issuer : cn=xyz-w2k-root,ou=HFR,o=Cisco System,l=San Jose,st=CA,c=US
Last Update : [UTC] Thu Jan 10 01:01:14 2002
Next Update : [UTC] Thu Jan 17 13:21:14 2002
CRL Distribution Point :
http://xyz-w2k.cisco.com/CertEnroll/xyz-w2k-root.crl
```

Related Commands	Command	Description
	clear crypto ca crl, on page 134	Clears all the CRLs stored on the router.

show crypto ca trustpool policy

To display the CA trust pool certificates of the router in a verbose format use the **show crypto ca trustpool policy** command in XR EXEC mode.

show crypto ca trustpool policy

Syntax Description This command has no keywords or arguments.

Command Default No default behavior or values

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.2.0	This command was introduced.

Usage Guidelines Use the command to display the CA trust pool certificates of the router in a verbose format.

Task ID	Task	Operation
	crypto	read

Example

This example shows you how to run the command to view details of your CA certificate trust pool policy.

```
RP/0/RSP0/CPU0:IMC0#show crypto ca trustpool policy
```

```
Trustpool Policy
```

```
Trustpool CA certificates will expire [UTC] Thu Sep 30 14:01:15 2021
CA Bundle Location: http://cisco.com/security/pki/trs/ios.p7b
```

Related Commands

Command	Description
crypto ca trustpool import url, on page 142	Allows you to manually update certificates in the trust pool.
crypto ca trustpool policy, on page 144	Configures CA trust pool policy parameters.

show crypto key mypubkey dsa

To display the Directory System Agent (DSA) public keys for your router, use the **show crypto key mypubkey dsa** command in XR EXEC mode.

show crypto key mypubkey dsa

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	crypto	read

Examples

The following sample output is from the **show crypto key mypubkey dsa** command:

```
RP/0/RP0/CPU0:router# show crypto key mypubkey dsa

Key label: mykey
Type : RSA General purpose
Size : 1024
Created : 17:33:23 UTC Thu Sep 18 2003
Data :
3081F230 81AA0605 2B0E0302 0C3081A0 02020200 024100C8 A36B6179 56B8D620
1F77595C 32EF3004 577A9F79 0A8ABDA4 89FB969D 35C04E7E 5491ED4E 120C657C
610576E5 841696B6 0948846C C92F56E5 B4921458 70FC4902 1500AB61 5C0D63D3
EB082BB9 F16030C5 AA0B5D1A DFE50240 73F661EA 9F579E77 B413DBC4 9047B4F2
10A1CFBC 14D98B57 3E0BBA97 9B5120AD F52BBDC7 15B63454 8CB54885 92B6C9DF
7DC27768 FD296844 42024945 5E86C81A 03430002 4071B49E F80F9E4B AF2B62E7
AA817460 87EFD503 C668AD8C D606050B 225CC277 7C0A0974 8072D7D7 2ADDDE42
329FE896 AB015ED1 3A414254 6935FDCA 0043BA4F 66
```

Related Commands

Command	Description
crypto key generate dsa, on page 145	Generates DSA key pairs.
crypto key zeroize dsa, on page 148	Deletes all DSA keys from the router.

show crypto key mypubkey ecdsa

To display the Elliptic Curve Digital Signature Algorithm (ECDSA) public keys for your router, use the **show crypto key mypubkey ecdsa** command in XR EXEC mode.

show crypto key mypubkey ecdsa

show crypto key mypubkey rsa

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.4.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	crypto	read

Example

```
RP/0/RSP0/CPU0:Router# show crypto key mypubkey ecdsa
```

```
Key label: the_default
Type      : ECDSA General Curve Nistp256
Degree    : 256
Created   : 19:10:54 IST Mon Aug 21 2017
Data      :
04255331 89B3CC40 BCD5A5A3 3BCCE7FF 522BF88D F3CC300D CEC9D7FD 98796ABB
6A69523F E5FBAB66 804A05BF ECCDABC6 63F73AE8 E89827DD 18EB106A 7735C34A
```

show crypto key mypubkey rsa

To display the Rivest, Shamir, and Adelman (RSA) public keys for your router, use the **show crypto key mypubkey rsa** command in XR EXEC mode.

show crypto key mypubkey rsa

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	crypto	read

Examples

The following is sample output from the **show crypto key mypubkey rsa** command:

```
RP/0//CPU0:router# show crypto key mypubkey rsa

Key label: mykey
Type : RSA General purpose
Size : 1024
Created : 07:46:15 UTC Fri Mar 17 2006
Data :
30819F30 0D06092A 864886F7 0D010101 05000381 8D003081 89028181 00CF8CDF
5BFCA055 DA4D164D F6EDB78B 926B1DDE 0383027F BA71BCC6 9D5592C4 5BA8670E
35CD19B7 1C973A46 62CC5F8C 82BD596C F292410F 8E83B753 4BA71BAC 41AB6B60
F34A2499 EDE11639 F88B4210 B2A0CF5F DD678C36 0D8E7DE1 A2AB5122 9ED947D5
76CF5BCD D9A2039F D02841B0 7F8BFF97 C080B791 10A9ED41 00FB6F40 95020301
0001

Key label: the_default
Type : RSA General purpose
Size : 512
Created : 07:46:15 UTC Fri Mar 17 2006
Data :
305C300D 06092A86 4886F70D 01010105 00034B00 30480241 00C7DE73 7B3EA447
CCE8F3DF DD1327D8 C1C30C45 2EEB4981 B1B48D2B 1AF14665 178058FB 8F6BB6BB
E08C6163 FA0EE356 395C8E5F 2AC59383 0706BDDF EC8E5822 9B020301 0001
```

Related Commands

Command	Description
crypto key generate rsa, on page 147	Generates RSA key pairs.
crypto key zeroize rsa, on page 150	Deletes all RSA keys from the router.

```
show crypto key mypubkey rsa
```



CHAPTER 7

Software Authentication Manager Commands

This module describes the Cisco IOS XR software commands used to configure Software Authentication Manager (SAM).

For detailed information about SAM concepts, configuration tasks, and examples, see the *Configuring Software Authentication Manager* module in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

- [sam add certificate, on page 171](#)
- [sam delete certificate, on page 173](#)
- [sam prompt-interval, on page 174](#)
- [sam verify, on page 176](#)
- [show sam certificate, on page 177](#)
- [show sam crl, on page 181](#)
- [show sam log, on page 183](#)
- [show sam package, on page 184](#)
- [show sam sysinfo, on page 186](#)

sam add certificate

To add a new certificate to the certificate table, use the **sam add certificate** command in XR EXEC mode.

```
sam add certificate filepath location {trust | untrust}
```

Syntax Description

filepath Absolute path to the source location of the certificate.

location Storage site of the certificate. Use one of the following: **root**, **mem**, **disk0**, **disk1**, or **other flash device name on router**.

trust Adds the certificate to the certificate table without validation by the Software Authentication Manager (SAM). To add a root certificate, you must use the **trust** keyword. Adding a root certificate with the **untrust** keyword is not allowed.

untrust Adds the certificate to the certificate table after the SAM has validated it. Adding a root certificate with the **untrust** keyword is not allowed. To add a root certificate, you must use the **trust** keyword.

Command Default

None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines For security reasons, the **sam add certificate** command can be issued only from the console or auxiliary port of the networking device; the command cannot be issued from a Telnet connection to any other interface on the networking device.

The certificate must be copied to the network device before it can be added to the certificate table. If the certificate is already present in the certificate table, the SAM rejects the attempt to add it.

When adding root certificates, follow these guidelines:

- Only the certificate authority (CA) root certificate can be added to the root location.
- To add a root certificate, you must use the **trust** keyword. Adding the root certificate with the **untrust** keyword is not allowed.

Use of the **trust** keyword assumes that you received the new certificate from a source that you trust, and therefore have enough confidence in its authenticity to bypass validation by the SAM. One example of acquiring a certificate from a trusted source is downloading it from a CA server (such as Cisco.com) that requires user authentication. Another example is acquiring the certificate from a person or entity that you can verify, such as by checking the identification badge for a person. If you bypass the validation protection offered by the SAM, you must verify the identity and integrity of the certificate by some other valid process.

Certificates added to the memory (**mem**) location validate software installed in memory. Certificates added to the **disk0** or **disk1** location validate software installed on those devices, respectively.



Note If the **sam add certificate** command fails with a message indicating that the certificate has expired, the networking device clock may have been set incorrectly. Use the **show clock** command to determine if the clock is set correctly.

Task ID	Task ID	Operations
	crypto	execute

Examples

The following example shows how to add the certificate found at **/bootflash/ca.bin** to the certificate table in the root location without first validating the certificate:

```
RP/0/RP0/CPU0:router# sam add certificate /bootflash/ca.bin root trust
SAM: Successful adding certificate /bootflash/ca.bin
```

The following example shows how to add the certificate found at **/bootflash/css.bin** to the certificate table in the memory (**mem**) location after validating the certificate:

```
RP/0/RP0/CPU0:router# sam add certificate /bootflash/css.bin mem untrust
```

SAM: Successful adding certificate /bootflash/css.bin

Related Commands	Command	Description
	sam delete certificate, on page 173	Deletes a certificate from the certificate table.
	show sam certificate, on page 177	Displays records in the certificate table, including the location of the certificates.
	show clock	Displays networking device clock information. <i>System Management Command Reference for Cisco NCS 6000 Series Routers .</i>

sam delete certificate

To delete a certificate from the certificate table, use the **sam delete certificate** command in XR EXEC mode.

sam delete certificate *location certificate-index*

Syntax Description	<i>location</i>
	Storage site of the certificate. Use one of the following: root , mem , disk0 , disk1 , or other flash device name on the router .
	<i>certificate-index</i> Number in the range from 1 to 65000.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines For security reasons, the **sam delete certificate** command can be issued only from the console port of the networking device; the command cannot be issued from a Telnet connection to any other interface on the networking device.

Use the **show sam certificate summary** command to display certificates by their index numbers.

Because the certificate authority (CA) certificate must not be unknowingly deleted, the Software Authentication Manager (SAM) prompts the user for confirmation when an attempt is made to delete the CA certificate.

If a certificate stored on the system is no longer valid (for example, if the certificate has expired), you can use the **sam delete certificate** command to remove the certificate from the list.

Task ID	Task Operations ID
	crypto execute

Examples

The following example shows how to delete the certificate identified by the index number 2 from the memory location:

```
RP/0/RP0/CPU0:router# sam delete certificate mem 2
```

```
SAM: Successful deleting certificate index 2
```

The following example shows how to cancel the deletion of the certificate identified by the index number 1 from the root location:

```
RP/0/RP0/CPU0:router# sam delete certificate root 1
```

```
Do you really want to delete the root CA certificate (Y/N): N
```

```
SAM: Delete certificate (index 1) canceled
```

The following example shows how to delete the certificate identified by the index number 1 from the root location:

```
RP/0/RP0/CPU0:router# sam delete certificate root 1
```

```
Do you really want to delete the root CA certificate (Y/N): Y
```

```
SAM: Successful deleting certificate index 1
```

Related Commands

Command	Description
sam add certificate, on page 171	Adds a new certificate to the certificate table.
show sam certificate, on page 177	Displays records in the certificate table, including the location of the certificates stored.

sam prompt-interval

To set the interval that the Software Authentication Manager (SAM) waits after prompting the user for input when it detects an abnormal condition at boot time and to determine how the SAM responds when it does not receive user input within the specified interval, use the **sam prompt-interval** command in XR Config mode. To reset the prompt interval and response to their default values, use the **no** form of this command.

```
sam prompt-interval time-interval {proceed | terminate}
```

Syntax Description

time-interval Prompt time, in the range from 0 to 300 seconds.

proceed Causes the SAM to respond as if it had received a “yes” when the prompt interval expires.

terminate Causes the SAM to respond as if it had received a “no” when the prompt interval expires.

Command Default

The default response is for the SAM to wait 10 seconds and then terminate the authentication task.

Command Modes

XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **sam prompt-interval** command to control the action taken when the system detects an exception condition, such as an expired certificate during initialization of the SAM at boot time. The following message appears when the software detects the abnormal condition of a certificate authority (CA) certificate expired:

```
SAM detects expired CA certificate. Continue at risk (Y/N):
```

The SAM waits at the prompt until you respond or the time interval controlled by the **sam prompt-interval** command expires, whichever is the earlier event. If you respond “N” to the prompt, the boot process is allowed to complete, but no packages can be installed.

The following message appears when the software detects the abnormal condition of a Code Signing Server (CSS) certificate expired:

```
SAM detects CA certificate (Code Signing Server Certificate Authority) has expired. The
validity period is Oct 17, 2000 01:46:24 UTC - Oct 17, 2015 01:51:47 UTC. Continue at risk?
(Y/N) [Default:N w/in 10]:
```

If you do not respond to the prompt, the SAM waits for the specified interval to expire, and then it takes the action specified in the **sam prompt-interval** command (either the **proceed** or **terminate** keyword).

If you enter the command with the **proceed** keyword, the SAM waits for the specified interval to expire, and then it proceeds as if you had given a “yes” response to the prompt.

If you enter the command with the **terminate** keyword, the SAM waits for the specified interval to expire, and then it proceeds as if you had given a “no” response to the prompt. This use of the command keeps the system from waiting indefinitely when the system console is unattended.



Note After the software has booted up, the *time-interval* argument set using this command has no effect. This value applies at boot time only.

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows how to tell the SAM to wait 30 seconds for a user response to a prompt and then terminate the requested SAM processing task:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# sam prompt-interval 30 terminate
```

Related Commands	Command	Description
	show sam sysinfo, on page 186	Displays the current status information for the SAM.

sam verify

To use the Message Digest 5 (MD5) hash algorithm to verify the integrity of the software component on a flash memory card and ensure that it has not been tampered with during transit, use the **sam verify** command in XR EXEC mode.

```
sam verify {locationfile-system} {MD5 | SHA [digest]}
```

Syntax Description

<i>location</i>	Name of the flash memory card slot, either disk0 or disk1.
<i>file-system</i>	Absolute path to the file to be verified.
MD5	Specifies a one-way hashing algorithm to generate a 128-bit hash (or message digest) of the specified software component.
SHA	Specifies the Secure Hash Algorithm, a hashing algorithm that takes a message of less than 264 bits in length and produces a 160-bit message digest. The large message digest provides security against brute-force collision and inversion attacks.
<i>digest</i>	(Optional) Message digest generated by the hashing algorithm, to be compared in determining the integrity of the software component.

Command Default

None

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **sam verify** command to generate a message digest for a given device. The message digest is useful for determining whether software on a flash memory card has been tampered with during transit. The command generates a hash code that can be used to compare the integrity of the software between the time it was shipped and the time you received it.

For example, if you are given a flash memory card with preinstalled software and a previously generated MD5 message digest, you can verify the integrity of the software using the **sam verify** command:

```
sam verify device MD5 digest
```

The *device* argument specifies the flash device. The *digest* argument specifies the message digest supplied by the originator of the software.

If the message digest matches the message digest generated by the **sam verify** command, the software component is valid.



Note You should calculate the hash code on the contents of the flash memory code at the destination networking device using a different set of files from the one loaded on the flash memory card. It is possible for an unauthorized person to use the same software version to produce the desired (matching) hash code and thereby disguise that someone has tampered with the new software.

Task ID	Task ID	Operations
	crypto	execute

Examples

The example shows a third **sam verify** command, issued with a mismatched message digest, to show the Software Authentication Manager (SAM) response to a mismatch. The following example shows how to use MD5 to generate a message digest on the entire file system on the flash memory card in slot 0 and then use that message digest as input to perform the digest comparison:

```
RP/0/RP0/CPU0:router# sam verify disk0: MD5

Total file count in disk0: = 813
082183cb6e65a44fd7ca95fe8e93def6

RP/0//CPU0:router# sam verify disk0: MD5 082183cb6e65a44fd7ca95fe8e93def6

Total file count in disk0: = 813
Same digest values

RP/0//CPU0:router# sam verify disk0: MD5 3216c9282d97ee7a40b78a4e401158bd

Total file count in disk0: = 813
Different digest values
```

The following example shows how to use MD5 to generate a message digest and then uses that message digest as input to perform the digest comparison:

```
RP/0/RP0/CPU0:router# sam verify disk0: /crl_revoked.bin MD5

38243ffbbe6cdb7a12fa9fa6452956ac

RP/0//CPU0:router# sam verify disk0: /crl_revoked.bin MD5 38243ffbbe6cdb7a12fa9fa6452956ac

Same digest values
```

show sam certificate

To display records in the certificate table, use the **show sam certificate** command in XR EXEC mode.

Syntax Description	detail	Displays all the attributes for the selected table entry (specified by the <i>certificate-index</i> argument).
--------------------	--------	--

show sam certificate

<i>location</i>	Specifies the certificates stored in a specific location. Use one of the following: root , mem , disk0 , disk1 , or other flash device on router .
<i>certificate-index</i>	Index number for the entry, in the range from 1 to 65000.
brief	Displays selected attributes for entries in the table.
all	Displays selected attributes for all the entries in the table.
<i>location</i>	Displays selected attributes for only the certificates stored in a specific location. Use one of the following: root , mem , disk0 , disk1 , or other flash device on router .

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **show sam certificate** command when you want to display all the certificates stored in the system. Attributes are certificate number, certificate flag, serial number, subject name, issued by, version, issuing algorithm, not-before and not-after dates, public key, and signature.

To get the certificate number, use the *certificate-index* argument. When used with the **brief** keyword, the **all** keyword displays selected attributes for all the entries in the table.

Task ID	Task ID	Operations
	none	—

Examples

In the example, the root location has one certificate, and disk0 has one certificate. The following sample output is from the **show sam certificate** command:

```
RP/0/RP0/CPU0:router# show sam certificate

all

----- SUMMARY OF CERTIFICATES -----

Certificate Location   :root
Certificate Index      :1
Certificate Flag       :VALIDATED
  Serial Number       :32:E0:A3:C6:CA:00:39:8C:4E:AC:22:59:1B:61:03:9F
  Subject Name        :
    cn=Code Signing Server Certificate Authority,o=Cisco,c=US
  Issued By           :
    cn=Code Signing Server Certificate Authority,o=Cisco,c=US
  Validity Start      :[UTC] Tue Oct 17 01:46:24 2000
  Validity End        :[UTC] Sat Oct 17 01:51:47 2015
  CRL Distribution Point
```

```
file://\CodeSignServer\CertEnroll\Code%20Signing%20Server%20Certificate
%20Authority.crl
```

```
Certificate Location      :mem
Certificate Index         :1
Certificate Flag          :VALIDATED
  Serial Number          :01:27:FE:79:00:00:00:00:05
  Subject Name           :
                        cn=Engineer code sign certificate
  Issued By              :
                        cn=Code Signing Server Certificate Authority,o=Cisco,c=US
  Validity Start         :[UTC] Tue Oct  9 23:14:28 2001
  Validity End           :[UTC] Wed Apr  9 23:24:28 2003
  CRL Distribution Point
```

```
file://\CodeSignServer\CertEnroll\Code%20Signing%20Server%20Certificate %20Authority.crl
```

This table describes the significant fields shown in the display.

Table 12: show sam certificate summary all Field Descriptions

Field	Description
Certificate Location	Location of the certificate; one of the following: root , mem , disk0 , or disk1 .
Certificate Index	Index number that the Software Authentication Manager automatically assigns to the certificate.
Certificate Flag	One of the following: TRUSTED, VALIDATED, EXPIRED, or REVOKED.
Serial Number	Unique serial number of the certificate, assigned by its issuer.
Subject Name	Name of the entity for which the certificate is issued.
Issued By	Name of the entity that issued the certificate.

The following sample output from the **show sam certificate** command shows how to display particular SAM details:

```
RP/0/RP0/CPU0:router# show sam certificate detail mem 1
-----
Certificate Location      :mem
Certificate Index         :1
Certificate Flag          :VALIDATED

----- CERTIFICATE -----
  Serial Number          :01:27:FE:79:00:00:00:00:05
  Subject Name           :
                        cn=Engineer code sign certificate
  Issued By              :
                        cn=Code Signing Server Certificate Authority,o=Cisco,c=US
  Validity Start         :[UTC] Tue Oct  9 23:14:28 2001
  Validity End           :[UTC] Wed Apr  9 23:24:28 2003
  CRL Distribution Point

file://\CodeSignServer\CertEnroll\Code%20Signing%20Server%20Certificate
%20Authority.crl
  Version 3 certificate
```

show sam certificate

```

Issuing Algorithm:MD5withRSA
Public Key BER (294 bytes):
30 82 01 22 30 0d 06 09 2a 86 48 86 f7 0d 01 01 [0.."0...*.H.....]
01 05 00 03 82 01 0f 00 30 82 01 0a 02 82 01 01 [.....0.....]
00 be 75 eb 9b b3 d9 cb 2e d8 c6 db 68 f3 5a ab [..u.....h.Z.]
0c 17 d3 84 16 22 d8 18 dc 3b 13 99 23 d8 c6 94 [....."....;.#....]
91 15 15 ec 57 ea 68 dc a5 38 68 6a cb 0f 4b c2 [....W.h..8hj..K.]
43 4b 2d f9 92 94 93 04 df ff ca 0b 35 1d 85 12 [CK-.....5....]
99 e9 bd bc e2 98 99 58 fe 6b 45 38 f0 52 b4 cb [.....X.kE8.R..]
a9 47 cd 22 aa ce 70 0e 4c 9b 48 a1 cf 0f 4a db [..G."..p.L.H...J.]
35 f5 1f 20 b7 68 cb 71 2c 27 01 84 d6 bf 4e d1 [5... .h.q,'....N.]
ba e1 b2 50 e7 f1 29 3a b4 85 3e ac d7 cb 3f 36 [...P..):..>...?6]
96 65 30 13 27 48 84 f5 fe 88 03 4a d7 05 ed 72 [..e0.'H.....J...r]
4b aa a5 62 e6 05 ac 3d 20 4b d6 c9 db 92 89 38 [K..b...= K.....8]
b5 14 df 46 a3 8f 6b 05 c3 54 4d a2 83 d4 b7 02 [...F..k..TM.....]
88 2d 58 e7 a4 86 1c 48 77 68 49 66 a1 35 3e c4 [..-X....HwhIf.5>.]
71 20 aa 18 9d 9f 1a 38 52 3c e3 35 b2 19 12 ad [q .....8R<.5....]
99 ad ce 68 8b b0 d0 29 ba 25 fd 1e e0 5d aa 12 [..h...)%...]..]
9c 44 89 63 89 62 e3 cb f3 5d 5f a3 7c b7 b9 ef [..D.c.b...]|...]
01 89 5b 33 35 a8 81 60 38 61 4e d8 4f 6a 53 70 [..[35...`8aN.OjSp]
35 02 03 01 00 01 [5.....]

Certificate signature (256 bytes):
67 f6 12 25 3f d4 d2 dd 6a f7 3e 55 b8 9f 33 53 [g..%?...j.>U...3S]
20 4d d1 17 54 08 8a 70 22 35 92 59 9c 03 9c 0f [ M..T..p"5.Y....]
ce 46 3c 06 74 d0 a9 8e b1 88 a2 35 b3 eb 1b 00 [..F<.t.....5....]
5c 6d bb 1d b5 ad 17 19 f2 c6 96 87 9b e7 15 01 [\m.....]
b2 04 af 7d 92 60 d9 ee ef bc 60 4e 2e af 84 e2 [...}.`.....N....]
42 fe 07 71 7e fc ee ee f5 d1 6d 71 e7 46 f0 97 [B..q~.....mq.F..]
e0 e8 b3 0e f9 07 e0 de 6e 36 5a 56 1e 80 10 05 [.....n6ZV....]
59 d9 88 ba f7 a3 d1 f6 cd 00 12 9f 90 f0 65 83 [Y.....e..]
e9 0f 76 a4 da eb 1b 1b 2d ea bd be a0 8a fb a7 [..v.....-.....]
a5 18 ff 9f 5c e9 99 66 f0 d3 90 ae 49 3f c8 cc [....\..f....I?..]
32 6b db 64 da fd f5 42 ea bc f3 b0 8a 2f 17 d8 [2k.d...B...../..]
cf c0 d8 d4 3a 41 ae 1d cf 7a c6 a6 a1 65 c2 94 [....:A...z...e..]
8a ba ea d3 da 3e 8a 44 9b 47 35 10 ab 61 1b 4f [.....>.D.G5..a.O]
82 dd 59 16 d5 f2 1d f3 c2 08 cc 1c 7f ab be 9c [..Y.....]
be 52 73 ea e0 89 d7 6f 4d d0 d8 aa 3d 50 d6 b0 [..Rs.....oM...=P..]
e1 ea 3b 27 50 42 08 d6 71 eb 66 37 b1 f5 f6 5d [..;'PB..q.f7....]

```

This table describes the significant fields shown in the display.

Table 13: show sam certificate detail mem 1 Field Descriptions

Field	Descriptions
Certificate Location	Location of the certificate; one of the following: root , mem , disk0 , or disk1 .
Certificate Index	Index number that the SAM automatically assigns to the certificate.
Certificate Flag	One of the following: TRUSTED, VALIDATED, EXPIRED, or REVOKED.
Serial Number	Unique serial number of the certificate, assigned by its issuer.
Subject Name	Name of the entity for which the certificate is issued.
Issued By	Name of the entity that issued the certificate.
Version	The X.509 version of the certificate. The version can be 1 (X.509v1), 2 (X.509v2), or 3 (X.509v3).
Issuing Algorithm	Hash and public key algorithm that the issuer uses to sign the certificate.

Field	Descriptions
Public Key	Subject public key for the certificate.
Certificate signature	Encrypted hash value (or signature) of the certificate. The hash value of the certificate is encrypted using the private key of the issuer.

show sam crl

To display the records in the certificate revocation list (CRL) table, use the **show sam crl** command in XR EXEC mode.

```
show sam crl {summary | detail crl-index}
```

Syntax Description

summary Displays selected attributes for all entries in the table.

detail Displays all the attributes for the selected table entry (specified by the *crl-index* argument).

crl-index Index number for the entry, in the range from 1 to 65000.

Command Default

None

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **show sam crl** command when you want to display all the revoked certificates currently stored on the system. Attributes are CRL index number, issuer, and update information.

To get the CRL index number, use the **summary** keyword.

Task ID

Task ID	Operations
crypto	read

Examples

The following sample output is from the **show sam crl** command for the **summary** keyword:

```
RP/0/RP0/CPU0:router# show sam crl summary
----- SUMMARY OF CRLs -----
CRL Index      :1
Issuer:CN = Code Sign Server Certificate Manager, OU = Cisco HFR mc , O =
Cisco,
  L = San Jose, ST = CA, C = US, EA =<16> iosmx-css-cert@cisco.com
```

Including updates of:

Sep 09, 2002 03:50:41 GMT

This table describes the significant fields shown in the display.

Table 14: show sam crl summary Field Descriptions

Field	Description
CRL Index	Index number for the entry, in the range from 1 to 65000. The index is kept in the certificate revocation list table.
Issuer	Certificate authority (CA) that issued this CRL.
Including updates of	Versions of CRLs from this CA that are included in the CRL table.

The following sample output is from the **show sam crl** command for the **detail** keyword:

```
RP/0/RP0/CPU0:router# show sam crl detail 1
-----
CRL Index      :1
-----
----- CERTIFICATE REVOCATION LIST (CRL) -----
Issuer:CN = Code Sign Server Certificate Manager, OU = Cisco HFR mc , O = Cisco,
L = San Jose, ST = CA, C = US, EA =<16> iosmx-css-cert@cisco.com
Including updates of:
                Sep 09, 2002 03:50:41 GMT
Revoked certificates include:

    Serial #:61:2C:5C:83:00:00:00:00:44, revoked on Nov 03, 2002 00:59:02 GMT
    Serial #:21:2C:48:83:00:00:00:00:59, revoked on Nov 06, 2002 19:32:51 GMT
-----
```

This table describes the significant fields shown in the display.

Table 15: show sam crl detail Field Descriptions

Field	Descriptions
CRL Index	Index number for the entry, in the range from 1 to 65000. The index is kept in the certificate revocation list table.
Issuer	CA that issued this CRL.
Including updates of	Versions of CRLs from this CA that are included in the CRL table.
Revoked certificates include	List of certificates that have been revoked, including the certificate serial number and the date and time the certificate was revoked.

show sam log

To display the contents of the Software Authentication Manager (SAM) log file, use the **show sam log** command in XR EXEC mode.

```
show sam log [lines-number]
```

Syntax Description	<i>lines-number</i> (Optional) Number of lines of the SAM log file to display, in the range from 0 to 200, where 0 displays all lines in the log file and 200 displays the most recent 200 lines (or as many lines as there are in the log file if there are fewer than 200 lines).				
Command Default	The show sam log command without a <i>lines-number</i> argument displays all the lines in the log file.				
Command Modes	XR EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				
Usage Guidelines	The SAM log file records changes to the SAM tables, including any expired or revoked certificates, table digest mismatches, and SAM server restarts.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>crypto</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	crypto	read
Task ID	Operations				
crypto	read				

Examples

The following sample output is from the **show sam log** command:

```
RP/0//CPU0:router# show sam log

06/16/02 12:03:44 UTC Added certificate in table root/1 CN = Certificate Manage, 0x01
06/16/02 12:03:45 UTC SAM server restarted through router reboot
06/16/02 12:03:47 UTC Added CRL in table CN = Certificate Manage, updated at Nov 10, 2001
    04:11:42 GMT
06/16/02 12:03:48 UTC Added certificate in table mem:/1 CN = Certificate Manage, 0x1e
06/16/02 12:16:16 UTC SAM server restarted through router reboot
06/16/02 12:25:02 UTC SAM server restarted through router reboot
06/16/02 12:25:04 UTC Added certificate in table mem:/1 CN = Certificate Manage, 0x1e
06/16/02 12:39:30 UTC SAM server restarted through router reboot
06/16/02 12:39:30 UTC SAM server restarted through router reboot
06/16/02 12:40:57 UTC Added certificate in table mem/1 CN = Certificate Manage, 0x1e

33 entries shown
```

Each line of output shows a particular logged event such as a table change, expired or revoked certificates, table digest mismatches, or SAM server restarts.

show sam package

To display information about the certificate used to authenticate the software for a particular package installed on the networking device, use the **show sam package** command in XR EXEC mode.

show sam package *package-name*

Syntax Description	<i>package-name</i> Location of the software package, including the memory device (disk0: , disk1: , mem: , and so on) and the file system path to the file. Use the show install all command to display the Install Manager package name and location information.				
Command Default	None				
Command Modes	XR EXEC mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				
Usage Guidelines	Use the show install all command to display the installed location and name of the software package—for example, <code>mem:ena-base-0.0.0</code> or <code>disk1:crypto-exp-lib-0.4.0</code> —and then use the show sam package command to display information about the certificate used to authenticate that installed package. The show sam package command displays the same information as the show sam certificate command for the detail keyword.				

Task ID	Task	Operations
	crypto	read

Examples

The following sample output is from the **show sam package** command:

```
RP/0//CPU0:router# show sam package mem:12k-rp-1.0.0
-----
Certificate Location      :mem
Certificate Index        :1
Certificate Flag          :VALIDATED
-----
----- CERTIFICATE -----
Serial Number   :01:27:FE:79:00:00:00:00:05
Subject Name    :
                 cn=Engineer code sign certificate
Issued By       :
                 cn=Code Signing Server Certificate Authority,o=Cisco,c=US
Validity Start  :[UTC] Tue Oct  9 23:14:28 2001
Validity End    :[UTC] Wed Apr  9 23:24:28 2002
CRL Distribution Point

file:///\\CodeSignServer\CertEnroll\Code%20Signing%20Server%20Certificate
```

```

%20Authority.crl
  Version 3 certificate
  Issuing Algorithm:MD5withRSA
  Public Key BER (294 bytes):
30 82 01 22 30 0d 06 09 2a 86 48 86 f7 0d 01 01      [0.."0...*.H.....]
01 05 00 03 82 01 0f 00 30 82 01 0a 02 82 01 01      [...0.....]
00 be 75 eb 9b b3 d9 cb 2e d8 c6 db 68 f3 5a ab      [...u.....h.Z.]
0c 17 d3 84 16 22 d8 18 dc 3b 13 99 23 d8 c6 94      [.....";.##...]
91 15 15 ec 57 ea 68 dc a5 38 68 6a cb 0f 4b c2      [...W.h..8hj..K.]
43 4b 2d f9 92 94 93 04 df ff ca 0b 35 1d 85 12      [CK-.....5...]
99 e9 bd bc e2 98 99 58 fe 6b 45 38 f0 52 b4 cb      [...X.ke8.R..]
a9 47 cd 22 aa ce 70 0e 4c 9b 48 a1 cf 0f 4a db      [G..".p.L.H...J.]
35 f5 1f 20 b7 68 cb 71 2c 27 01 84 d6 bf 4e d1      [5.. .h.q,'...N.]
ba e1 b2 50 e7 f1 29 3a b4 85 3e ac d7 cb 3f 36      [...P..):.>.5?6]
96 65 30 13 27 48 84 f5 fe 88 03 4a d7 05 ed 72      [e0.'H.....J...r]
4b aa a5 62 e6 05 ac 3d 20 4b d6 c9 db 92 89 38      [K..b...= K.....8]
b5 14 df 46 a3 8f 6b 05 c3 54 4d a2 83 d4 b7 02      [...F..k..TM.....]
88 2d 58 e7 a4 86 1c 48 77 68 49 66 a1 35 3e c4      [-X....HwhIf.5>.]
71 20 aa 18 9d 9f 1a 38 52 3c e3 35 b2 19 12 ad      [q .....8R<.5....]
99 ad ce 68 8b b0 d0 29 ba 25 fd 1e e0 5d aa 12      [...h...).%...].]
9c 44 89 63 89 62 e3 cb f3 5d 5f a3 7c b7 b9 ef      [D.c.b...].|.].]
01 89 5b 33 35 a8 81 60 38 61 4e d8 4f 6a 53 70      [..[35...`8aN.OjSp]
35 02 03 01 00 01                                     [5.....]
  Certificate signature (256 bytes):
67 f6 12 25 3f d4 d2 dd 6a f7 3e 55 b8 9f 33 53      [g..%?...j.>U..3S]
20 4d d1 17 54 08 8a 70 22 35 92 59 9c 03 9c 0f      [ M..T..p"5.Y....]
ce 46 3c 06 74 d0 a9 8e b1 88 a2 35 b3 eb 1b 00      [F<.t.....5....]
5c 6d bb 1d b5 ad 17 19 f2 c6 96 87 9b e7 15 01      [\m.....]
b2 04 af 7d 92 60 d9 ee ef bc 60 4e 2e af 84 e2      [...}.`.....N....]
42 fe 07 71 7e fc ee ee f5 d1 6d 71 e7 46 f0 97      [B..q~.....mq.F..]
e0 e8 b3 0e f9 07 e0 de 6e 36 5a 56 1e 80 10 05      [...n6ZV....]
59 d9 88 ba f7 a3 d1 f6 cd 00 12 9f 90 f0 65 83      [Y.....e.]
e9 0f 76 a4 da eb 1b 1b 2d ea bd be a0 8a fb a7      [...v.....-.....]
a5 18 ff 9f 5c e9 99 66 f0 d3 90 ae 49 3f c8 cc      [...\...f.....I?..]
32 6b db 64 da fd f5 42 ea bc f3 b0 8a 2f 17 d8      [2k.d...B...../..]
cf c0 d8 d4 3a 41 ae 1d cf 7a c6 a6 a1 65 c2 94      [....:A...z...e..]
8a ba ea d3 da 3e 8a 44 9b 47 35 10 ab 61 1b 4f      [.....>.D.G5...a.O]
82 dd 59 16 d5 f2 1d f3 c2 08 cc 1c 7f ab be 9c      [...Y.....]
be 52 73 ea e0 89 d7 6f 4d d0 d8 aa 3d 50 d6 b0      [Rs.....oM...=P..]

```

This table describes the significant fields shown in the display.

Table 16: show sam package Field Descriptions

Field	Description
Certificate Location	Location of the certificate; one of the following: root , mem , disk0 , or disk1 .
Certificate Index	Index number that the Software Authentication Manager (SAM) automatically assigns to the certificate.
Certificate Flag	One of the following: TRUSTED, VALIDATED, EXPIRED, or REVOKED.
Serial Number	Unique serial number of the certificate, assigned by its issuer.
Subject Name	Name of the entity for which the certificate is issued.
Issued By	Name of the entity that issued the certificate.
Version	X.509 version of the certificate. The version can be 1 (X.509v1), 2 (X.509v2), or 3 (X.509v3).

Field	Description
Issuing Algorithm	Hash and public key algorithm that the issuer uses to sign the certificate.
Public Key	Subject public key for the certificate.
Certificate signature	Encrypted hash value (or signature) of the certificate. The hash value of the certificate is encrypted using the private key of the issuer.

Related Commands

Command	Description
show install	Displays the installed location and name of the software package. You can use the all keyword to display the active packages from all locations. For more information, see <i>System Management Command Reference for Cisco NCS 6000 Series Routers</i> .
show sam certificate, on page 177	Displays records in the SAM certificate table.

show sam sysinfo

To display current configuration settings for the Software Authentication Manager (SAM), use the **show sam sysinfo** command in XR EXEC mode.

show sam sysinfo

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **show sam sysinfo** command to determine the configuration settings of the SAM. The display shows the status of the SAM, current prompt interval setting, and current prompt default response.

Task ID	Task	Operations
	crypto	read

Examples The following sample output is from the **show sam sysinfo** command:

```
RP/0//CPU0:router# show sam sysinfo

Software Authentication Manager System Information
=====
Status                : running
Prompt Interval       : 10 sec
Prompt Default Response : NO
```

This table describes the significant fields shown in the display.

Table 17: show sam sysinfo Field Descriptions

Field	Description
Status	<p>One of the following: running or not running.</p> <p>If the SAM is not running, the System Manager should detect that state and attempt to restart the SAM. If problems prevent the System Manager from restarting the SAM after a predefined number of repeated attempts, the SAM will not be restarted. In such a case, you should contact Cisco Technical Assistance Center (TAC) personnel.</p>
Prompt Interval	<p>Current setting for the prompt interval. The interval can be set in the range from 0 to 300 seconds. The value shown in the sample output (10 seconds) is the default.</p>
Prompt Default Response	<p>Current setting that specifies the action taken by the SAM if the prompt interval expires before the user responds to the prompt. If the user does not respond to the prompt, the SAM waits for the specified interval to expire and then takes the action specified in the sam prompt-interval command (either proceed keyword or terminate keyword).</p> <p>Entering the sam promptinterval command with the proceed keyword causes the show sam sysinfo command to display “Yes,” meaning that the default action taken by the SAM is to wait for the prompt interval to expire and then respond as if it had received a “yes” from the user.</p> <p>Entering the sam promptinterval command with the terminate keyword causes the show sam sysinfo command to display “No,” meaning that the default action taken by the SAM is to wait for the prompt interval to expire and then respond as if it had received a “no” from the user.</p>

Related Commands

Command	Description
sam prompt-interval, on page 174	Sets the interval that the SAM waits after prompting the user for input when it detects an abnormal condition and determines how the SAM responds when it does not receive user input within the specified interval.

■ show sam sysinfo



CHAPTER 8

Secure Shell Commands

This module describes the Cisco IOS XR software commands used to configure Secure Shell (SSH).

For detailed information about SSH concepts, configuration tasks, and examples, see the *Implementing Secure Shell on* module in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

- [clear ssh](#), on page 190
- [netconf-yang agent ssh](#) , on page 191
- [sftp](#), on page 192
- [sftp \(Interactive Mode\)](#), on page 195
- [show ssh](#), on page 198
- [show ssh history](#), on page 201
- [show ssh history details](#), on page 202
- [show ssh rekey](#), on page 203
- [show ssh session details](#), on page 204
- [show tech-support ssh](#), on page 206
- [ssh](#), on page 207
- [ssh algorithms cipher](#), on page 208
- [ssh client enable cipher](#) , on page 209
- [ssh client knownhost](#), on page 210
- [ssh client source-interface](#), on page 211
- [ssh client vrf](#), on page 212
- [ssh server](#), on page 213
- [ssh server algorithms host-key](#), on page 215
- [ssh disable hmac](#), on page 216
- [ssh server enable cipher](#), on page 217
- [ssh server rekey-time](#), on page 217
- [ssh server rekey-volume](#), on page 218
- [ssh server logging](#), on page 219
- [ssh server rate-limit](#), on page 220
- [ssh server session-limit](#), on page 221
- [ssh server v2](#), on page 222
- [ssh server netconf port](#), on page 222
- [ssh timeout](#), on page 223

clear ssh

To terminate an incoming or outgoing Secure Shell (SSH) connection, use the **clear ssh** command in XR EXEC mode.

clear ssh {*session-id* | **outgoing** *session-id*}

Syntax Description	<i>session-id</i>	Session ID number of an incoming connection as displayed in the show ssh command output. Range is from 0 to 1024.
	outgoing <i>session-id</i>	Specifies the session ID number of an outgoing connection as displayed in the show ssh command output. Range is from 1 to 10.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **clear ssh** command to disconnect incoming or outgoing SSH connections. Incoming connections are managed by the SSH server running on the local networking device. Outgoing connections are initiated from the local networking device.

To display the session ID for a connection, use the **show ssh** command.

Task ID	Task ID	Operations
	crypto	execute

Examples

In the following example, the **show ssh** command is used to display all incoming and outgoing connections to the router. The **clear ssh** command is then used to terminate the incoming session with the ID number 0.

```
RP/0/RP0/CPU0:router# show ssh

SSH version: Cisco-2.0
session      pty  location  state      userid    host      ver
-----
Incoming sessions
0           vty0 0/33/1  SESSION_OPEN  cisco    172.19.72.182  v2
1           vty1 0/33/1  SESSION_OPEN  cisco    172.18.0.5     v2
2           vty2 0/33/1  SESSION_OPEN  cisco    172.20.10.3   v1
3           vty3 0/33/1  SESSION_OPEN  cisco    3333:::50     v2

Outgoing sessions
1           0/33/1  SESSION_OPEN  cisco    172.19.72.182  v2
2           0/33/1  SESSION_OPEN  cisco    3333:::50     v2
```

```
RP/0/RP0/CPU0:router# clear ssh 0
```

The following output is applicable for the **clear ssh** command starting IOS-XR 5.3.2 releases and later.

```
RP/0/RP0/CPU0:router# show ssh
SSH version : Cisco-2.0
```

```

id chan pty      location          state          userid  host          ver
authentication connection type
-----
Incoming sessions
0 1 vty0 0/RSP0/CPU0 SESSION_OPEN lab 12.22.57.75 v2
rsa-pubkey Command-Line-Interface
0 2 vty1 0/RSP0/CPU0 SESSION_OPEN lab 12.22.57.75 v2
rsa-pubkey Command-Line-Interface
0 3 0/RSP0/CPU0 SESSION_OPEN cisco 12.22.57.75 v2
rsa-pubkey Sftp-Subsystem
1 vty7 0/RSP0/CPU0 SESSION_OPEN cisco 12.22.22.57 v1 password
Command-Line-Interface
3 1 0/RSP0/CPU0 SESSION_OPEN lab 12.22.57.75 v2 password
Netconf-Subsystem
4 1 vty3 0/RSP0/CPU0 SESSION_OPEN lab 192.168.1.55 v2 password
Command-Line-Interface

Outgoing sessions
1 0/RSP0/CPU0 SESSION_OPEN lab 192.168.1.51 v2 password
```

```
RP/0/RP0/CPU0:router# clear ssh 0
```

Related Commands

Command	Description
show ssh, on page 198	Displays the incoming and outgoing connections to the router.

netconf-yang agent ssh

To enable netconf agent over SSH (Secure Shell) , use the **netconf-yang agent ssh** command in XR Config mode. To disable netconf, use the **no** form of the command.

netconf-yang agent ssh

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.3.0	This command was introduced.

Usage Guidelines SSH is currently the supported transport method for Netconf.

Task ID	Task ID	Operation
	config-services	read, write

Example

This example shows how to use the **netconf-yang agent ssh** command:

```
RP/0/RP0/CPU0:router (config) # netconf-yang agent ssh
```

sftp

To start the secure FTP (SFTP) client, use the **sftp** command in XR EXEC mode.

```
sftp [ username @ host : remote-filename ] source-filename dest-filename [ source-interface type interface-path-id ] [ vrf vrf-name ]
```

Syntax Description	
<i>username</i>	(Optional) Name of the user performing the file transfer. The at symbol (@) following the username is required.
<i>hostname:remote-filename</i>	(Optional) Name of the Secure Shell File Transfer Protocol (SFTP) server. The colon (:) following the hostname is required.
<i>source-filename</i>	SFTP source, including the path.
<i>dest-filename</i>	SFTP destination, including the path.
source-interface	(Optional) Specifies the source IP address of a selected interface for all outgoing SSH connections.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command in EXEC mode to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
vrf <i>vrf-name</i>	Specifies the name of the VRF associated with the source interface.

Command Default If no *username* argument is provided, the login name on the router is used. If no *hostname* argument is provided, the file is considered local.

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines

SFTP provides for the secure (and authenticated) copying of files between a router and a remote host. Like the **copy** command, the **sftp** command can be invoked only in EXEC mode.

If a username is not provided, the login name on the router is used as the default. If a host name is not provided, the file is considered local.

If the source interface is specified in the **sftp** command, the **sftp** interface takes precedence over the interface specified in the **ssh client source-interface** command.

When the file destination is a local path, all of the source files should be on remote hosts, and vice versa.

When multiple source files exist, the destination should be a preexisting directory. Otherwise, the destination can be either a directory name or destination filename. The file source cannot be a directory name.

If you download files from different remote hosts, that is, the source points to different remote hosts, the SFTP client spawns SSH instances for each host, which may result in multiple prompts for user authentication.

Task ID	Task ID	Operations
	crypto	execute
	basic-services	execute

Examples

In the following example, user *abc* is downloading the file *ssh.diff* from the SFTP server *ena-view1* to *disk0*:

```
RP/0/RP0/CPU0:router#sftp abc@ena-view1:ssh.diff disk0
```

In the following example, user *abc* is uploading multiple files from *disk 0:/sam_** to */users/abc/* on a remote SFTP server called *ena-view1*:

```
RP/0/RP0/CPU0:router# sftp disk0:/sam_* abc@ena-view1:/users/abc/
```

In the following example, user *admin* is downloading the file *run* from *disk0a:* to *disk0:/v6copy* on a local SFTP server using an IPv6 address:

```
RP/0/RP0/CPU0:router#sftp admin@[2:2:2::2]:disk0a:/run disk0:/V6copy
Connecting to 2:2:2::2...
Password:
```

```
disk0a:/run
  Transferred 308413 Bytes
  308413 bytes copied in 0 sec (338172)bytes/sec
```

```
RP/0/RP0/CPU0:router#dir disk0:/V6copy
```

```
Directory of disk0:
```

```
70144      -rwx  308413      Sun Oct 16 23:06:52 2011  V6copy
```

```
2102657024 bytes total (1537638400 bytes free)
```

In the following example, user *admin* is uploading the file *v6copy* from *disk0:* to *disk0a:/v6back* on a local SFTP server using an IPv6 address:

```
RP/0/RP0/CPU0:router#sftp disk0:/V6copy admin@[2:2:2::2]:disk0a:/v6back
Connecting to 2:2:2::2...
Password:
```

```
/disk0:/V6copy
  Transferred 308413 Bytes
  308413 bytes copied in 0 sec (421329)bytes/sec
```

```
RP/0/RP0/CPU0:router#dir disk0a:/v6back
```

```
Directory of disk0a:
```

```
66016      -rwx  308413      Sun Oct 16 23:07:28 2011  v6back
```

```
2102788096 bytes total (2098987008 bytes free)
```

In the following example, user *admin* is downloading the file *sampfile* from *disk0:* to *disk0a:/sampfile_v4* on a local SFTP server using an IPv4 address:

```
RP/0/RP0/CPU0:router#sftp admin@2.2.2.2:disk0:/sampfile disk0a:/sampfile_v4
Connecting to 2.2.2.2...
Password:
```

```
disk0:/sampfile
  Transferred 986 Bytes
  986 bytes copied in 0 sec (493000)bytes/sec
```

```
RP/0/RP0/CPU0:router#dir disk0a:/sampfile_v4
```

```
Directory of disk0a:
```

```
131520     -rwx   986      Tue Oct 18 05:37:00 2011  sampfile_v4
```

```
502710272 bytes total (502001664 bytes free)
```

In the following example, user *admin* is uploading the file *sampfile_v4* from *disk0a:* to *disk0:/sampfile_back* on a local SFTP server using an IPv4 address:

```
RP/0/RP0/CPU0:router#sftp disk0a:/sampfile_v4 admin@2.2.2.2:disk0:/sampfile_back
Connecting to 2.2.2.2...
Password:
```

```
disk0a:/sampfile_v4
  Transferred 986 Bytes
  986 bytes copied in 0 sec (564000)bytes/sec
```

```
RP/0/RP0/CPU0:router#dir disk0:/sampfile_back
```

```
Directory of disk0:
```

```
121765     -rwx   986      Tue Oct 18 05:39:00 2011  sampfile_back
```

```
524501272 bytes total (512507614 bytes free)
```

Related Commands	Command	Description
	ssh client source-interface, on page 211	Specifies the source IP address of a selected interface for all outgoing SSH connections.
	ssh client vrf, on page 212	Configures a new VRF for use by the SSH client.

sftp (Interactive Mode)

To enable users to start the secure FTP (SFTP) client, use the **sftp** command in XR EXEC mode.

```
sftp [ username @ host : remote-filename ] [ source-interface type interface-path-id ]
[ vrf vrf-name ]
```

Syntax Description		
<i>username</i>	(Optional) Name of the user performing the file transfer. The at symbol (@) following the username is required.	
<i>hostname:remote-filename</i>	(Optional) Name of the Secure Shell File Transfer Protocol (SFTP) server. The colon (:) following the hostname is required.	
port <i>port-num</i>	Specifies the non-default port number of the server to which the SFTP client on the router attempts a connection. The port number ranges from 1025 - 65535.	
source-interface	(Optional) Specifies the source IP address of a selected interface for all outgoing SSH connections.	
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.	
<i>interface-path-id</i>	Physical interface or virtual interface. Note Use the show interfaces command in EXEC mode to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.	
vrf <i>vrf-name</i>	Specifies the name of the VRF associated with the source interface.	

Command Default If no *username* argument is provided, the login name on the router is used. If no *hostname* argument is provided, the file is considered local.

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines

The SFTP client, in the interactive mode, creates a secure SSH channel where the user can enter any supported command. When a user starts the SFTP client in an interactive mode, the SFTP client process creates a secure SSH channel and opens an editor where user can enter any supported command.

More than one request can be sent to the SFTP server to execute the commands. While there is no limit on the number of 'non-acknowledged' or outstanding requests to the server, the server might buffer or queue these requests for convenience. Therefore, there might be a logical sequence to the order of requests.

The following unix based commands are supported in the interactive mode:

- **bye**
- **cd** *<path>*
- **chmod** *<mode>* *<path>*
- **exit**
- **get** *<remote-path>* [*local-path*]
- **help**
- **ls** [*-alt*] [*path*]
- **mkdir** *<path>*
- **put** *<local-path>* [*remote-path*]
- **pwd**
- **quit**
- **rename** *<old-path>* *<new-path>*
- **rmdir** *<path>*
- **rm** *<path>*

The following commands are not supported:

- **lcd**, **lls**, **lpwd**, **lumask**, **lmkdir**
- **ln**, **symlink**
- **chgrp**, **chown**
- **!**, **!command**
- **?**
- **mget**, **mput**

Task ID	Task ID	Operations
	crypto	execute
	basic-services	execute

Examples

In the following example, user *admin* is downloading and uploading a file from/to an external SFTP server using an IPv6 address:

```
RP/0/RP0/CPU0:router#sftp admin@[2:2:2::2]

Connecting to 2:2:2::2...
Password:
sftp> pwd
Remote working directory: /
sftp> cd /auto/tftp-server1-users5/admin
sftp> get frmRouter /disk0:/frmRouterdownload

/auto/tftp-server1-users5/admin/frmRouter
  Transferred 1578 Bytes
  1578 bytes copied in 0 sec (27684)bytes/sec
sftp> put /disk0:/frmRouterdownload againtoServer

/disk0:/frmRouterdownload
  Transferred 1578 Bytes
  1578 bytes copied in 0 sec (14747)bytes/sec
sftp>
```

In the following example, user *abc* is downloading and uploading a file from/to an external SFTP server using an IPv4 address:

```
RP/0/RP0/CPU0:router#sftp abc@2.2.2.2
Connecting to 2.2.2.2...
Password:
sftp> pwd
Remote working directory: /
sftp> cd /auto/tftp-server1-users5/abc
sftp> get frmRouter /disk0:/frmRouterdownload

/auto/tftp-server1-users5/abc/frmRouter
  Transferred 1578 Bytes
  1578 bytes copied in 0 sec (27684)bytes/sec
sftp> put /disk0:/frmRouterdownload againtoServer

/disk0:/frmRouterdownload
  Transferred 1578 Bytes
  1578 bytes copied in 0 sec (14747)bytes/sec
sftp>
```

Related Commands

Command	Description
ssh client source-interface, on page 211	Specifies the source IP address of a selected interface for all outgoing SSH connections.
ssh client vrf, on page 212	Configures a new VRF for use by the SSH client.

show ssh

To display all incoming and outgoing connections to the router, use the **show ssh** command in XR EXEC mode.

show ssh

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **show ssh** command to display all incoming and outgoing Secure Shell (SSH) Version 1 (SSHv1) and SSH Version 2 (SSHv2) connections.

The connection type field in the command output of **show ssh** command shows as **port-forwarded local** for SSH port-forwarded sessions.

Use the **show ssh server** command to see the details of the SSH server. The **Port Forwarding** column shows as **local** for the port-forwarded session. Whereas, for a regular SSH session, the field displays as **disabled**.

Task ID	Task ID	Operations
	crypto	read

Examples

This is sample output from the **show ssh** command when SSH is enabled:

```
RP/0/RP0/CPU0:router# show ssh

SSH version : Cisco-2.0

id  pty  location  state  userid  host  ver  authentication
-----
Incoming sessions

Outgoing sessions
1   0/3/CPU0  SESSION_OPEN  lab  12.22.57.  v2  password
2   0/3/CPU0  SESSION_OPEN  lab  12.22.57.75  v2  keyboard-interactive
```

The following output is applicable for the **show ssh** command starting IOS-XR 5.3.2 releases and later.

```
RP/0/RP0/CPU0:router# show ssh
SSH version : Cisco-2.0
```

```

id  chan  pty      location      state      userid  host      ver
authentication connection type
-----
Incoming sessions
0  1  vty0    0/RSP0/CPU0  SESSION_OPEN  lab     12.22.57.75  v2
rsa-pubkey  Command-Line-Interface
0  2  vty1    0/RSP0/CPU0  SESSION_OPEN  lab     12.22.57.75  v2
rsa-pubkey  Command-Line-Interface
0  3          0/RSP0/CPU0  SESSION_OPEN  cisco   12.22.57.75  v2
rsa-pubkey  Sftp-Subsystem
1          vty7    0/RSP0/CPU0  SESSION_OPEN  cisco   12.22.22.57  v1 password
          Command-Line-Interface
3  1          0/RSP0/CPU0  SESSION_OPEN  lab     12.22.57.75  v2 password
          Netconf-Subsystem
4  1  vty3    0/RSP0/CPU0  SESSION_OPEN  lab     192.168.1.55  v2 password
          Command-Line-Interface

Outgoing sessions
1          0/RSP0/CPU0  SESSION_OPEN  lab     192.168.1.51  v2 password

```

This table describes significant fields shown in the display.

Table 18: show ssh Field Descriptions

Field	Description
id	Session identifier for the incoming and outgoing SSH connections.
chan	Channel identifier for incoming (v2) SSH connections. NULL for SSH v1 sessions.
pty	pty-id allocated for the incoming session. Null for outgoing SSH connection.
location	Specifies the location of the SSH server for an incoming connection. For an outgoing connection, location specifies from which route processor the SSH session is initiated.
state	The SSH state that the connection is currently in.
userid	Authentication, authorization and accounting (AAA) username used to connect to or from the router.
host	IP address of the remote peer.
ver	Specifies if the connection type is SSHv1 or SSHv2.
authentication	Specifies the type of authentication method chosen by the user.
connection type	Specifies which application is performed over this connection (Command-Line-Interface, Remote-Command, Scp, Sftp-Subsystem, or Netconf-Subsystem)

The following is a sample output of SSH port-forwarded session:

```
Router#show ssh
Wed Oct 14 11:22:05.575 UTC
```

```

SSH version : Cisco-2.0

id chan pty location state userid host ver authentication connection type
-----
Incoming sessions
15 1 XXX 0/RP0/CPU0 SESSION_OPEN admin 192.168.122.1 v2 password
port-forwarded-local

Outgoing sessions

Router#

```

The following is a sample output of **show ssh server** command with SSH port forwarding enabled:

```

Router#show ssh server
Tue Sep 7 17:43:22.483 IST
-----
SSH Server Parameters
-----

Current supported versions := v2
                        SSH port := 22
                        SSH vrfs := vrfname:=default(v4-acl:=, v6-acl:=)
                        Netconf Port := 830
                        Netconf Vrfs := vrfname:=default(v4-acl:=, v6-acl:=)

Algorithms
-----
Hostkey Algorithms :=
x509v3-ssh-rsa,ecdsa-sha2-nistp521,ecdsa-sha2-nistp384,ecdsa-sha2-nistp256,rsa-sha2-512,rsa-sha2-256,ssh-rsa,ssh-dsa,ssh-ed25519

Key-Exchange Algorithms :=
ecdh-sha2-nistp521,ecdh-sha2-nistp384,ecdh-sha2-nistp256,diffie-hellman-group14-sha1

Encryption Algorithms :=
aes128-ctr,aes192-ctr,aes256-ctr,aes128-gcm@openssh.com,aes256-gcm@openssh.com
Mac Algorithms := hmac-sha2-512,hmac-sha2-256,hmac-sha1

Authentication Method Supported
-----
PublicKey := Yes
Password := Yes
Keyboard-Interactive := Yes
Certificate Based := Yes

Others
-----
DSCP := 0
Ratelimit := 600
Sessionlimit := 110
Rekeytime := 30
Server rekeyvolume := 1024
TCP window scale factor := 1
Backup Server := Disabled
Host Trustpoint :=
User Trustpoint := tes,test,x509user
Port Forwarding := local
Max Authentication Limit := 16
Certificate username := Common name(CN) User principle name(UPN)
Router#

```

Related Commands	Command	Description
	show sessions	Displays information about open Telnet or rlogin connections. For more information, see the <i>System Management Command Reference for Cisco NCS 6000 Series Routers</i>
	show ssh session details, on page 204	Displays the details for all the incoming and outgoing SSHv2 connections, to the router.

show ssh history

To display the last hundred SSH connections that were terminated, use the **show ssh history** command in XR EXEC mode.

show ssh history

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History

Release	Modification
Release 6.4.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
crypto	read

Examples

The following is sample output from the **show ssh history** command to display the last hundred SSH sessions that were terminated:

```
RP/0/RP0/CPU0:router# show ssh history

SSH version : Cisco-2.0

id      chan  pty      location      userid      host          ver authentication
connection type
-----
Incoming sessions
1       1      XXXXX   0/RP0/CPU0    root        10.105.227.252  v2 password
Netconf-Subsystem
2       1      XXXXX   0/RP0/CPU0    root        10.105.227.252  v2 password
Netconf-Subsystem
3       1      XXXXX   0/RP0/CPU0    root        10.105.227.252  v2 password
```

show ssh history details

```

Netconf-Subsystem
4      1      XXXXX  0/RP0/CPU0    root      10.105.227.252    v2  password
Netconf-Subsystem
5      1      XXXXX  0/RP0/CPU0    root      10.105.227.252    v2  password
Netconf-Subsystem
6      1      XXXXX  0/RP0/CPU0    root      10.105.227.252    v2  password
Netconf-Subsystem
7      1      XXXXX  0/RP0/CPU0    root      10.105.227.252    v2  password
Netconf-Subsystem
8      1      XXXXX  0/RP0/CPU0    root      10.105.227.252    v2  password
Netconf-Subsystem
9      1      vty0   0/RP0/CPU0    root      10.196.98.106     v2  key-intr
Command-Line-Interface

```

Pty – VTU number used. This is represented as ‘XXXX’ when connection type is SFTP, SCP or Netconf.

show ssh history details

To display the last hundred SSH connections that were terminated, and also the start and end time of the session, use the **show ssh history details** command in XR EXEC mode.

show ssh history details

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.4.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	crypto	read

Examples

The following is sample output from the **show ssh history details** command to display the last hundred SSH sessions that were terminated along with the start and end time of the sessions:

```

RP/0/RP0/CPU0:router# show ssh history details

SSH version : Cisco-2.0

id      key-exchange      pubkey      incipher      outcipher      inmac
outmac      start_time      end_time

```

```

Incoming Session
1      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  14-02-18 14:00:39      14-02-18 14:00:41
2      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  14-02-18 16:21:54      14-02-18 16:21:55
3      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  14-02-18 16:22:18      14-02-18 16:22:19
4      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  15-02-18 12:17:44      15-02-18 12:17:46
5      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  15-02-18 12:18:16      15-02-18 12:18:17
6      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  15-02-18 14:44:08      15-02-18 14:44:09
7      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  15-02-18 14:50:15      15-02-18 14:50:16
8      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  15-02-18 14:50:52      15-02-18 14:50:53
9      ecdh-sha2-nistp256      ssh-rsa      aes128-ctr  aes128-ctr  hmac-sha2-256
hmac-sha2-256  15-02-18 15:31:26      15-02-18 15:31:38

```

This table describes the significant fields shown in the display.

Table 19: Field Descriptions

Field	Description
session	Session identifier for the incoming and outgoing SSH connections.
key-exchange	Key exchange algorithm chosen by both peers to authenticate each other.
pubkey	Public key algorithm chosen for key exchange.
incipher	Encryption cipher chosen for the receiver traffic.
outcipher	Encryption cipher chosen for the transmitter traffic.
inmac	Authentication (message digest) algorithm chosen for the receiver traffic.
outmac	Authentication (message digest) algorithm chosen for the transmitter traffic.
start_time	Start time of the session.
end_time	End time of the session.

show ssh rekey

To display session rekey details such as session id, session rekey count, time to rekey, data to rekey, use the **show ssh rekey** command in XR EXEC mode.

show ssh rekey

Command Default None

Command Modes XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines The ssh rekey data is updated ten times between two consecutive rekeys.

Task ID

Task ID	Operations
crypto	read

Examples

The following sample output is from the **show ssh rekey** command:

```
# show ssh rekey

id      RekeyCount  TimeToRekey (min)  VolumeToRekey (MB)
-----
Incoming Session
0        8            59.5               1024.0
```

This table describes the fields shown in the display.

Table 20: show ssh rekey Field Descriptions

Field	Description
Rekey Count	Number of times the ssh rekey is generated.
TimeToRekey	Time remaining (in minutes) before the ssh rekey is regenerated based on the value set using the ssh server rekey-time command.
VolumeToRekey	Volume remaining (in megabytes) before the ssh rekey is regenerated based on the value set using the ssh server rekey-volume command.

show ssh session details

To display the details for all incoming and outgoing Secure Shell Version 2 (SSHv2) connections, use the **show ssh session details** command in XR EXEC mode.

show ssh session details

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines Use the **show ssh session details** command to display a detailed report of the SSHv2 connections to or from the router, including the cipher chosen for the specific session.

Task ID

Task ID	Operations
crypto	read

Examples

The following is sample output from the **show ssh session details** command to display the details for all the incoming and outgoing SSHv2 connections:

```
RP/0/RP0/CPU0:router# show ssh session details

id key-exchange          pubkey    incipher  outcipher  inmac     outmac
-----
Incoming Session
0  diffie-hellman-group14  ssh-rsa  aes128-ctr  aes128-ctr  hmac-sha1  hmac-sha1
1  ecdh-sha2-nistp521     ssh-rsa  aes256-ctr  aes256-ctr  hmac-sha2-512  hmac-sha2-512
```

This table describes the significant fields shown in the display.

Table 21: show ssh session details Field Descriptions

Field	Description
session	Session identifier for the incoming and outgoing SSH connections.
key-exchange	Key exchange algorithm chosen by both peers to authenticate each other.
pubkey	Public key algorithm chosen for key exchange.
incipher	Encryption cipher chosen for the Rx traffic.
outcipher	Encryption cipher chosen for the Tx traffic.
inmac	Authentication (message digest) algorithm chosen for the Rx traffic.
outmac	Authentication (message digest) algorithm chosen for the Tx traffic.

Related Commands

Command	Description
show sessions	Displays information about open Telnet or rlogin connections.

Command	Description
show ssh, on page 198	Displays all the incoming and outgoing connections to the router.

show tech-support ssh

To automatically run show commands that display system information, use the show tech-support command, use the **show tech-support ssh** command in XR EXEC mode.

show tech-support ssh

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 6.4.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task Operations ID
	crypto read

Examples The following is sample output from the **show tech-support ssh** command:

```
RP/0/RP0/CPU0:router# show tech-support ssh
++ Show tech start time: 2018-Feb-20.123016.IST ++
Tue Feb 20 12:30:27 IST 2018 Waiting for gathering to complete
.....
Tue Feb 20 12:32:35 IST 2018 Compressing show tech output
Show tech output available at 0/RP0/CPU0 :
/harddisk:/showtech/showtech-ssh-2018-Feb-20.123016.IST.tgz
++ Show tech end time: 2018-Feb-20.123236.IST ++
RP/0/RP0/CPU0:turin-sec1#
```

The **show tech-support ssh** command collects the output of these CLI:

Command	Description
show logging	Displays the contents of the logging buffer.
show context location all	

Command	Description
show running-config	Displays the contents of the currently running configuration or a subset of that configuration.
show ip int brief	Displays brief information about each interface.
show ssh	Displays all incoming and outgoing connections to the router.
show ssh session details	Displays the details for all the incoming and outgoing SSHv2 connections, to the router.
show ssh rekey	Displays session rekey details such as session id, session rekey count, time to rekey, data to rekey.
show ssh history	Displays the last hundred SSH connections that were terminated.
show tty trace info all all	
show tty trace error all all	

ssh

To start the Secure Shell (SSH) client connection and enable an outbound connection to an SSH server, use the **ssh** command in XR EXEC mode.

Syntax Description

<i>ipv4-address</i>	IPv4 address in A:B:C:D format.
<i>ipv6-address</i>	IPv6 address in X:X::X format.
<i>hostname</i>	Hostname of the remote node. If the hostname has both IPv4 and IPv6 addresses, the IPv4 address is used.
username <i>user-id</i>	(Optional) Specifies the username to use when logging in on the remote networking device running the SSH server. If no user ID is specified, the default is the current user ID.
cipher	
source interface	(Optional) Specifies the source IP address of a selected interface for all outgoing SSH connections.
<i>type</i>	Interface type. For more information, use the question mark (?)online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.
Note	Use the show interfaces command in XR EXEC mode to see a list of all interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark(?)online help function.

command (Optional) Specifies a remote command. Adding this keyword prompts the SSHv2 server to parse and execute the `ssh command` in non-interactive mode instead of initiating the interactive session.

Command Default None

Command Modes XR EXEC mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the `ssh` command to make an outbound client connection. The SSH client tries to make an SSHv2 connection to the remote peer. If the remote peer supports only the SSHv1 server, it internally spawns an SSHv1 connection to the remote server. The process of the remote peer version detection and spawning the appropriate client connection is transparent to the user.

If is specified in the `ssh` command, the `ssh` interface takes precedence over the interface specified in the `ssh client source-interface ssh client source-interface`, on page 211 command.

Use the `command` keyword to enable the SSHv2 server to parse and execute the `ssh` command in non-interactive mode instead of initiating an interactive session.

Task ID

Task ID	Operations
crypto	execute
basic-services	execute

Examples

The following sample output is from the `ssh` command to enable an outbound SSH client connection:

```
RP/0/RP0/CPU0:router# ssh username userabc

Password:
Remote-host>
```

Related Commands

Command	Description
show ssh, on page 198	Displays all the incoming and outgoing connections to the router.

ssh algorithms cipher

To configure the list of supported SSH algorithms on the client or on the server, use the `ssh client algorithms cipher` command or `ssh server algorithms cipher` command in XR Config mode. To remove the configuration, use the `no` form of this command.

```
ssh {client | server} algorithms cipher {aes256-cbc | aes256-ctr | aes192-ctr | aes192-cbc |
aes128-ctr | aes128-cbc | aes128-gcm@openssh.com | aes256-gcm@openssh.com | 3des-cbc}
```

Syntax Description	client	Configures the list of supported SSH algorithms on the client.
	server	Configures the list of supported SSH algorithms on the server.

Command Default None

Command Modes XR Config mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task Operation ID
	crypto read, write

This example shows how to enable CTR cipher on the client and CBC cipher on the server:

```
Router1#ssh client algorithms cipher aes128-ctr aes192-ctr aes256-ctr
```

```
Router1#ssh server algorithms cipher aes128-cbc aes192-cbc aes256-cbc 3des-cbc
```

Related Commands	Command	Description
	ssh client enable cipher , on page 209	Enables CBC mode ciphers on the SSH client.
	ssh server enable cipher, on page 217	Enables CBC mode ciphers on the SSH server.

ssh client enable cipher

To enable the CBC mode ciphers 3DES-CBC and/or AES-CBC for an SSH client connection, use the **ssh client enable cipher** command in XR Config mode. To disable the ciphers, use the **no** form of this command.

```
ssh client enable cipher {aes-cbc | 3des-cbc}
```

Syntax Description	3des-cbc	Specifies that the 3DES-CBC cipher be enabled for the SSH client connection.
	aes-cbc	Specifies that the AES-CBC cipher be enabled for the SSH client connection.

Command Default CBC mode ciphers are disabled.

Command Modes XR Config mode

Command History	Release	Modification
	Release 6.3.1	This command was introduced.

Usage Guidelines The support for CBC ciphers were disabled by default, from Cisco IOS XR Software Release 6.1.2. Hence, **ssh client enable cipher** and **ssh server enable cipher** commands were introduced to explicitly enable CBC ciphers in required scenarios.

If a client tries to reach the router which acts as a server with CBC cipher, and if the CBC cipher is not explicitly enabled on that router, then the system displays an error message:

```
ssh root@x.x.x. -c aes128-cbc
Unable to negotiate with x.x.x.x port 22: no matching cipher found.
Their offer: aes128-ctr,aes192-ctr,aes256-ctr,aes128-gcm@openssh.com,aes256-gcm@openssh.com
```

You must configure **ssh server enable cipher aes-cbc** command in this case, to connect to the router using the CBC cipher.

Task ID	Task ID	Operation
	crypto read, write	

Examples The following example shows how to enable the 3DES-CBC and AES-CBC ciphers for an SSH client connection:

```
Router# configure
Router(config)# ssh client enable cipher aes-cbc 3des-cbc
Router(config)# commit
```

Related Commands	Command	Description
	ssh server enable cipher, on page 217	Enables CBC mode ciphers on the SSH server.

ssh client knownhost

To authenticate a server public key (pubkey), use the **ssh client knownhost** command in XR Config mode. To disable authentication of a server pubkey, use the **no** form of this command.

ssh client knownhost device: /filename

Syntax Description	device:/filename	Complete path of the filename (for example, slot0:/server_pubkey). The colon (:) and slash (/) are required.

Command Default	None

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines The *server pubkey* is a cryptographic system that uses two keys at the client end—a public key known to everyone and a private, or secret, key known only to the owner of the keys. In the absence of certificates, the server pubkey is transported to the client through an out-of-band secure channel. The client stores this pubkey in its local database and compares this key against the key supplied by the server during the early stage of key negotiation for a session-building handshake. If the key is not matched or no key is found in the local database of the client, users are prompted to either accept or reject the session.

The operative assumption is that the first time the server pubkey is retrieved through an out-of-band secure channel, it is stored in the local database. This process is identical to the current model adapted by Secure Shell (SSH) implementations in the UNIX environment.

Task ID	Task ID	Operations
	crypto	read, write

Examples The following sample output is from the **ssh client knownhost** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh client knownhost disk0:/ssh.knownhost
RP/0/RP0/CPU0:router(config)# commit
RP/0/RP0/CPU0:router# ssh host1 username user1234
Host key not found from the list of known hosts.
Are you sure you want to continue connecting (yes/no)? yes
Password:
RP/0/RP0/CPU0:host1# exit
RP/0/RP0/CPU0:router# ssh host1 username user1234
```

ssh client source-interface

To specify the source IP address of a selected interface for all outgoing Secure Shell (SSH) connections, use the **ssh client source-interface** command in XR Config mode. To disable use of the specified interface IP address, use the **no** form of this command.

ssh client source-interface *type interface-path-id*

Syntax Description	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
--------------------	-------------	---

interface-path-id Physical interface or virtual interface.

Note Use the **show interfaces** command to see a list of all interfaces currently configured on the router.

For more information about the syntax for the router, use the question mark (?) online help function.

Command Default No source interface is used.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **ssh client source-interface** command to set the IP address of the specified interface for all outgoing SSH connections. If this command is not configured, TCP chooses the source IP address when the socket is connected, based on the outgoing interface used—which in turn is based on the route required to reach the server. This command applies to outbound shell over SSH as well as Secure Shell File Transfer Protocol (SFTP) sessions, which use the ssh client as a transport.

The source-interface configuration affects connections only to the remote host in the same address family. The system database (Sysdb) verifies that the interface specified in the command has a corresponding IP address (in the same family) configured.

Task ID	Task ID	Operations
	crypto	read, write

Examples The following example shows how to set the IP address of the Management Ethernet interface for all outgoing SSH connections:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh client source-interface MgmtEth 0//CPU0/0
```

ssh client vrf

To configure a new VRF for use by the SSH client, use the **ssh client vrf** command in XR Config mode. To remove the specified VRF, use the **no** form of this command.

ssh client vrf *vrf-name*

Syntax Description	<i>vrf-name</i>
	Specifies the name of the VRF to be used by the SSH client.

Command Default None

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Command History	Release	Modification
	Release 3.8.0	This command was introduced.

Usage Guidelines An SSH client can have only one VRF.

If a specific VRF is not configured for the SSH client, the default VRF is assumed when applying other SSH client-related commands, such as [ssh client knownhost, on page 210](#) or [ssh client source-interface, on page 211](#).

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows the SSH client being configured to start with the specified VRF:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh client vrf green
```

Related Commands	Command	Description
	ssh client dscp <value from 0 - 63>	SSH Client supports setting DSCP value in the outgoing packets. If not configured, the default DSCP value set in packets is 16 (for both client and server).

ssh server

To bring up the Secure Shell (SSH) server and to configure one or more VRFs for its use, use the **ssh server** command in XR Config mode. To stop the SSH server from receiving any further connections for the specified VRF, use the **no** form of this command. Optionally ACLs for IPv4 and IPv6 can be used to restrict access to the server before the port is opened.

```
ssh server vrf vrf-name [ipv4 access-list ipv4 access list name ] [ipv6 access-list ipv6 access list name ]
ssh server v2
```

Syntax Description	vrf <i>vrf-name</i>	Specifies the name of the VRF to be used by the SSH server. The maximum VRF length is 32 characters. Note If no VRF is specified, the default VRF is assumed.
	ipv4 access-list <i>access list name</i>	Configures an IPv4 access-list for access restrictions to the ssh server.
	ipv6 access-list <i>access list name</i>	Configures an IPv6 access-list for access restrictions to the ssh server
	v2	Forces the SSH server version to be of only version 2.

Command Default The default SSH server version is 2 (SSHv2), which falls back to 1 (SSHv1) if the incoming SSH client connection is set to SSHv1.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines An SSH server must be configured at minimum for one VRF. If you delete all configured VRFs, including the default, the SSH server process stops. If you do not configure a specific VRF for the SSH client when applying other commands, such as **ssh client knownhost** or **ssh client source-interface**, the default VRF is assumed.

The SSH server listens for an incoming client connection on port 22. This server handles both Secure Shell Version 1 (SSHv1) and SSHv2 incoming client connections for both IPv4 and IPv6 address families. To accept only Secure Shell Version 2 connections, use the [ssh server v2, on page 222](#) command.

To verify that the SSH server is up and running, use the **show process sshd** command.

Task ID	Task ID	Operations
	crypto	read, write

Examples In the following example, the SSH server is brought up to receive connections for VRF “green”:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh
```

Examples In the following example, the SSH server is configured to use IPv4 ACLs:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh vrf vrf nameipv4 access-list access list name
```

Related Commands	Command	Description
	show processes	Displays information about the SSH server.
	ssh server v2, on page 222	Forces the SSH server version to be only 2 (SSHv2).
	ssh server dscp <value from 0 - 63>	SSH server supports setting DSCP value in the outgoing packets. If not configured, the default DSCP value set in packets is 16 (for both client and server).

ssh server algorithms host-key

To configure the allowed SSH host-key pair algorithms from the list of auto-generated host-key pairs on the SSH server, use the **ssh server algorithms host-key** command in XR Config mode. To remove the configuration, use the **no** form of this command.

```
ssh server algorithms host-key { dsa | ecdsa-nistp256 | ecdsa-nistp384 | ecdsa-nistp521 |
rsa }
```

Syntax Description	<ul style="list-style-type: none"> • dsa • ecdsa-nistp256 • ecdsa-nistp384 • ecdsa-nistp521 • rsa 	<p>Selects the specified host keys to be offered to the SSH client.</p> <p>While configuring this, you can specify the algorithms in any order.</p>
Command Default	In the absence of this configuration, the SSH server considers that it can send all the available algorithms to the user as host key algorithm, based on the availability of the key or the certificate.	
Command Modes	XR Config mode	
Usage Guidelines	<p>This configuration is optional. If this configuration is not present, it is considered that all the SSH host-key pairs are configured. In that case, the SSH client is allowed to connect to the SSH sever with any of the host-key pairs.</p> <p>You can also use the crypto key zeroize command to remove the SSH host keys that are not required.</p> <p>With the introduction of the automatic generation of SSH host-key pairs, the show crypto key mypubkey command output displays key information of all the keys that are auto-generated. Before its introduction, the output of this command displayed key information of only those host-key pairs that were explicitly configured using the crypto key generate command.</p>	
Task ID	Task ID	Operation
	crypto	read, write

This example shows how to select the **ecdsa** algorithm from the list of auto-generated host-key pairs on the SSH server:

```
Router(config)#ssh server algorithms host-key ecdsa-nistp521
```

ssh disable hmac

To disable HMAC cryptographic algorithm on the SSH server, use the **ssh server disable hmac** command, and to disable HMAC cryptographic algorithm on the SSH client, use the **ssh client disable hmac** command in XR Config mode. To disable this feature, use the **no** form of this command.

```
ssh {client | server} disable hmac {hmac-sha1 | hmac-sha2-512}
```

Syntax Description	
hmac-sha1	Disables the SHA-1 HMAC cryptographic algorithm.
hmac-sha2-512	Disables the SHA-2 HMAC cryptographic algorithm.
Note	This option is available only for the server .

Command Default None

Command Modes XR Config mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	crypto read, write	

This example shows how to disable SHA1 HMAC cryptographic algorithm on the SSH client:

```
Router#ssh client disable hmac hmac-sha1
```

This example shows how to disable SHA-2 HMAC cryptographic algorithm on the SSH server:

```
Router#ssh server disable hmac hmac-sha2-512
```

ssh server enable cipher

To enable CBC mode ciphers 3DES-CBC and/or AES-CBC for an SSH server connection, use the **ssh server enable cipher** command in XR Config mode. To disable the ciphers, use the **no** form of this command.

```
ssh server enable cipher {aes-cbc | 3des-cbc}
```

Syntax Description	3des-cbc Specifies that the 3DES-CBC cipher be enabled for the SSH server connection.				
	aes-cbc Specifies that the AES-CBC cipher be enabled for the SSH server connection.				
Command Default	CBC mode ciphers are disabled.				
Command Modes	XR Config mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.3.1	This command was introduced.
Release	Modification				
Release 6.3.1	This command was introduced.				
Usage Guidelines	The support for CBC ciphers were disabled by default, from Cisco IOS XR Software Release 6.1.2. Hence, ssh client enable cipher and ssh server enable cipher commands were introduced to explicitly enable CBC ciphers in required scenarios.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>crypto</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operation	crypto	read, write
Task ID	Operation				
crypto	read, write				
Examples	<p>The following example shows how to enable the 3DES-CBC and AES-CBC ciphers for an SSH server connection:</p> <pre>Router# configure Router(config)# ssh server enable cipher aes-cbc 3des-cbc Router(config)# commit</pre>				
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ssh client enable cipher , on page 209</td> <td>Enables CBC mode ciphers on the SSH client.</td> </tr> </tbody> </table>	Command	Description	ssh client enable cipher , on page 209	Enables CBC mode ciphers on the SSH client.
Command	Description				
ssh client enable cipher , on page 209	Enables CBC mode ciphers on the SSH client.				

ssh server rekey-time

To configure rekey of the ssh server key based on time, use the **ssh server** command in XR Config mode. Use the **no** form of this command to remove the rekey interval.

ssh server rekey-time *time in minutes*

Syntax Description	rekey-time <i>time in minutes</i>	Specifies the rekey-time interval in minutes. The range is between 30 to 1440 minutes.
	Note	If no time interval is specified, the default interval is considered to be 60 minutes.

Command Default None.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Task ID	Task ID	Operations
	crypto	read, write

Examples

In the following example, the SSH server rekey-interval of 450 minutes is used:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh server rekey-time 450
```

ssh server rekey-volume

To configure a volume-based rekey threshold for an SSH session, use the **ssh server** command in XR Config mode. Use the **no** form of this command to remove the volume-based rekey threshold.

ssh server rekey-volume *data in megabytes*

Syntax Description	rekey-volume <i>data in megabytes</i>	Specifies the volume-based rekey threshold in megabytes. The range is between 1024 to 4095 megabytes.
	Note	If no volume threshold is specified, the default size is considered to be 1024 MB.

Command Default None.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Task ID	Task ID	Operations
	crypto	read, write

Examples

In the following example, the SSH server rekey-volume of 2048 minutes is used:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh
```

ssh server logging

To enable SSH server logging, use the **ssh server logging** command in XR Config mode. To discontinue SSH server logging, use the **no** form of this command.

ssh server logging

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Once you configure the logging, the following messages are displayed:

- Warning: The requested term-type is not supported
- SSH v2 connection from %s succeeded (*user:%s, cipher:%s, mac:%s, pty:%s*)

The warning message appears if you try to connect using an unsupported terminal type. Routers running the Cisco IOS XR software support only the vt100 terminal type.

The second message confirms a successful login.

Task ID	Task ID	Operations
	crypto	read, write

Examples

The following example shows the initiation of an SSH server logging:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# ssh server logging
```

Related Commands

Command	Description
ssh server, on page 213	Initiates the SSH server.

ssh server rate-limit

To limit the number of incoming Secure Shell (SSH) connection requests allowed per minute, use the **ssh server rate-limit** command in XR Config mode. To return to the default value, use the **no** form of this command.

ssh server rate-limit *rate-limit*

Syntax Description

rate-limit Number of incoming SSH connection requests allowed per minute. Range is from 1 to 120. When setting it to 60 attempts per minute, it basically means that we can only allow 1 per second. If you set up 2 sessions at the same time from 2 different consoles, one of them will get rate limited. This is connection attempts to the ssh server, not bound per interface/username or anything like that. So value of 30 means 1 session per 2 seconds and so forth.

Command Default

rate-limit: 60 connection requests per minute

Command Modes

XR Config mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **ssh server rate-limit** command to limit the incoming SSH connection requests to the configured rate. Any connection request beyond the rate limit is rejected by the SSH server. Changing the rate limit does not affect established SSH sessions.

If, for example, the *rate-limit* argument is set to 30, then 30 requests are allowed per minute, or more precisely, a two-second interval between connections is enforced.

Task ID

Task ID	Operations
crypto	read, write

Examples

The following example shows how to set the limit of incoming SSH connection requests to 20 per minute:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh server rate-limit 20
```

ssh server session-limit

To configure the number of allowable concurrent incoming Secure Shell (SSH) sessions, use the **ssh server session-limit** command in XR Config mode. To return to the default value, use the **no** form of this command.

ssh server session-limit *sessions*

Syntax Description

sessions Number of incoming SSH sessions allowed across the router. The range is from 1 to 100.

Note Although CLI output option has 1024, you are recommended to configure session-limit not more than 100. High session count may cause resource exhaustion .

Command Default

sessions: 64 per router

Command Modes

XR Config mode

Command History

Release	Modification
Release 5.0.0	This command was introduced.

Usage Guidelines

Use the **ssh server session-limit** command to configure the limit of allowable concurrent incoming SSH connections. Outgoing connections are not part of the limit.

Task ID

Task ID	Operations
crypto	read, write

Examples

The following example shows how to set the limit of incoming SSH connections to 50:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh server session-limit 50
```

Related Commands

Command	Description
show processes	Displays information about the SSH server.

ssh server v2

To force the SSH server version to be only 2 (SSHv2), use the **ssh server v2** command in XR Config mode. To bring down an SSH server for SSHv2, use the **no** form of this command.

ssh server v2

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Only SSHv2 client connections are allowed.

Task ID	Task ID	Operations
	crypto	read, write

Examples The following example shows how to initiate the SSH server version to be only SSHv2:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)# ssh server v2
```

ssh server netconf port

To configure a port for the netconf SSH server, use the **ssh server netconf port** command in XR Config mode. To return to the default port, use the **no** form of the command.

ssh server netconf port *port number*

Syntax Description **port** *port-number* Port number for the netconf SSH server (default port number is 830).

Command Default The default port number is 830.

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.3.0	This command was introduced.
	Release 6.0	The ssh server netconf command is no longer auto completed to configure the default port. This command is now optional

Usage Guidelines Starting with IOS-XR 6.0.0 it is no longer sufficient to configure a netconf port to enable netconf subsystem support. ssh server netconf needs to be at least configured for one vrf.

Task ID	Task ID	Operations
	crypto	read, write

Examples

This example shows how to use the ssh server netconf port command with port 831:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh
```

Related Commands	Command	Description
	ssh server netconf	Configures the vrf(s), where netconf subsystem requests are to be received.
	netconf-yang agent ssh	Configures the ssh netconf-yang backend for the netconf subsystem (Required to allow the system to service netconf-yang requests). For more information, see the <i>Cisco ASR 9000 Series Aggregation Services Router System Management Command Reference</i> .

ssh timeout

To configure the timeout value for authentication, authorization, and accounting (AAA) user authentication, use the **ssh timeout** command in XR Config mode. To set the timeout value to the default time, use the **no** form of this command.

ssh timeout *seconds*

Syntax Description *seconds* Time period (in seconds) for user authentication. The range is from 5 to 120.

Command Default *seconds: 30*

Command Modes XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines Use the **ssh timeout** command to configure the timeout value for user authentication to AAA. If the user fails to authenticate itself within the configured time to AAA, the connection is terminated. If no value is configured, the default value of 30 seconds is used.

Task ID	Task ID	Operations
	crypto	read, write

Examples In the following example, the timeout value for AAA user authentication is set to 60 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# ssh timeout 60
```



CHAPTER 9

Secure Socket Layer Protocol Commands

This module describes the commands used to configure the Secure Socket Layer (SSL) protocol.

For detailed information about SSL concepts, configuration tasks, and examples, see the *Implementing Secure Socket Layer on* module in the *System Security Configuration Guide for Cisco NCS 6000 Series Routers*.

- [show ssl, on page 225](#)

show ssl

To display active Secure Socket Layer (SSL) sessions, use the **show ssl** command in XR EXEC mode.

```
show ssl [process-id]
```

Syntax Description	<i>process-id</i> (Optional) Process ID (PID) of the SSL application. The range is from 1 to 1000000000.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	XR EXEC mode
----------------------	--------------

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines	To display a specific process, enter the process ID number. To get a specific process ID number, enter run pidin from the command line or from a shell.
-------------------------	--

The absence of any argument produces a display that shows all processes that are running SSL.

Task ID	Task ID	Operations
	crypto	read

Examples	The following sample output is from the show ssl command:
-----------------	--

```
RP/0/RP0/CPU0:router# show ssl
```

```

PID          Method      Type      Peer          Port      Cipher-Suite
=====
1261711      sslv3       Server    172.16.0.5    1296      DES-CBC3-SHA

```

This table describes the fields shown in the display.

Table 22: show ssl Field Descriptions

Field	Description
PID	Process ID of the SSL application.
Method	Protocol version (sslv2, sslv3, sslv23, or tlsv1).
Type	SSL client or server.
Peer	IP address of the SSL peer.
Port	Port number on which the SSL traffic is sent.
Cipher-Suite	Exact cipher suite chosen for the SSL traffic. The first portion indicates the encryption, the second portion the hash or integrity method. In the sample display, the encryption is Triple DES and the Integrity (message digest algorithm) is SHA.

Related Commands

Command	Description
run pidin	Displays the process ID for all processes that are running.



INDEX

A

aaa accounting command [2](#)
aaa accounting system default command [4](#)
aaa accounting update command [5](#)
aaa authentication command [6](#)
aaa authorization command [8](#)
aaa default-taskgroup command [15](#)
aaa group server radius command [16](#)
aaa group server tacacs+ command [17](#)
accept-lifetime command [103](#)
accept-tolerance command [105](#)
accounting (line) command [23](#)
address ipv4 (MPP) command [121](#)
allow command [122](#)
authorization command [24](#)

C

clear crypto ca certificates command [134](#)
clear crypto ca crl command [134](#)
clear crypto ipsec sa command [95](#)
clear ssh command [190](#)
control-plane command [124](#)
crl optional (trustpoint) command [135](#)
crypto ca authenticate command [136](#)
crypto ca cancel-enroll command [138](#)
crypto ca enroll command [139](#)
crypto ca import command [140](#)
crypto ca trustpoint command [141](#)
crypto ca trustpool import url command [142](#)
crypto ca trustpool policy command [144](#)
crypto key generate dsa command [145](#)
crypto key generate rsa command [147](#)
crypto key import authentication rsa command [148](#)
crypto key zeroize dsa command [148](#)
crypto key zeroize rsa command [150](#)

D

description (AAA) command [26](#)
description (IPSec profile) command [96](#)
description (trustpoint) command [151](#)

E

enrollment retry count command [152](#)
enrollment retry period command [153](#)
enrollment terminal command [154](#)
enrollment url command [155](#)

G

group (AAA) command [27](#)

I

inband command [125](#)
inherit taskgroup command [30](#)
inherit usergroup command [31](#)
interface (MPP) command [126](#)
ip-address (trustpoint) command [156](#)

K

key (key chain) command [107](#)
key (TACACS+) command [32](#)
key chain (key chain) command [109](#)
key-string (keychain) command [110–111](#)

L

login authentication command [33](#)

M

management-plane command [127](#)

O

out-of-band command [128](#)

P

password (AAA) command [34](#)

Q

query url command [157](#)

R

radius-server dead-criteria time command [37](#)

radius-server dead-criteria tries command [38](#)

rsakeypair command [158](#)

S

sam add certificate command [171](#)

sam delete certificate command [173](#)

sam prompt-interval command [174](#)

sam verify command [176](#)

secret command [43](#)

send-lifetime command [113](#)

serial-number (trustpoint) command [159](#)

server (RADIUS) command [46](#)

server (TACACS+) command [47](#)

server-private (RADIUS) command [48](#)

sftp (Interactive Mode) command [195](#)

sftp command [192](#)

sftp-password (trustpoint) command [160](#)

sftp-username (trustpoint) command [161](#)

show aaa accounting command [54](#)

show aaa command [49](#)

show aaa user-group [69](#)

show crypto ca certificates command [163](#)

show crypto ca crls command [165](#)

show crypto ca trustpool policy command [166](#)

show crypto ipsec sa command [97](#)

show crypto ipsec summary command [100](#)

show crypto ipsec transform-set command [101](#)

show crypto key mypubkey dsa command [166](#)

show crypto key mypubkey rsa command [168](#)

show key chain command [114](#)

show mgmt-plane command [129](#)

show nacm [12](#)

show radius accounting command [58](#)

show radius authentication command [59](#)

show radius command [56](#)

show radius dead-criteria command [61](#)

show radius server-groups command [62](#)

show sam certificate command [177](#)

show sam crl command [181](#)

show sam log command [183](#)

show sam package command [184](#)

show sam sysinfo command [186](#)

show ssh command [198](#)

show ssh session details command [204](#)

show ssl command [203, 225](#)

show tacacs command [64](#)

show tacacs server-groups command [65](#)

show tech-support aaa [69](#)

show user command [67](#)

single-connection command [70](#)

ssh client knownhost command [210](#)

ssh client source-interface command [211](#)

ssh client vrf command [212](#)

ssh command [207](#)

ssh server command [213, 217–218, 222](#)

ssh server logging command [219](#)

ssh server rate-limit command [220](#)

ssh server session-limit command [221](#)

ssh server v2 command [222](#)

ssh timeout command [223](#)

subject-name (trustpoint) command [162](#)

T

tacacs source-interface command [77](#)

tacacs-server host command [72](#)

tacacs-server key command [75](#)

tacacs-server timeout command [76](#)

task command [78](#)

taskgroup command [80](#)

timeout (TACACS+) command [81](#)

timeout login response command [82](#)

U

usergroup command [83](#)

username command [84](#)

users group command [91](#)

V

vrf (MPP) command [131](#)

vrf (RADIUS) command [92](#)