



DSL IPoE

- [Configure DSL IPoE, on page 1](#)

Configure DSL IPoE

Use one of these methods to configure DSL IPoE:

- [Configuration group](#)
- [Feature template](#)

Configure DSL IPoE using a configuration group

Follow these steps to configure DSL IPoE using a configuration group.

Before you begin

On the **Configuration > Configuration Groups** page, choose **SD-WAN** as the solution type.

Procedure

Step 1 From the Cisco SD-WAN Manager menu, choose **Configuration > Configuration Groups**.

Step 2 Create and configure the DSL IPoE parameters in a Transport and Management Profile.

- Configure basic configuration.

Table 1: Basic Configuration

Parameter Name	Description
Controller Slot*	Enter the slot number of the controller, in the following format: <i>slot/subslot/port</i> (for example, 0/2/0)

Parameter Name	Description
Controller Mode	Select the operating mode of the DSL controller from the drop-down list: <ul style="list-style-type: none"> • ADSL1: Use ITU G.992.1 Annex A full-rate mode, which provides a downstream rate of 1.3 Mbps and an upstream rate of 1.8 Mbps. • ADSL2: Use ITU G.992.3 Annex A, Annex L, and Annex M, which provides a downstream rate of 12 Mbps and an upstream rate of 1.3 Mbps. • ADSL2+: Use ITU G.992.5 Annex A and Annex M, which provides a downstream rate of 24 Mbps and an upstream rate of 3.3 Mbps. • ANSI: Operating in ADSL2/2+ mode, as defined in ITU G.991.1, G.992.3, and G992.5, Annex A and Annex M, and in VDSL2 mode, as defined in ITU-T G993.2. • VDSL2: Operate in VDSL2 mode, as defined in ITU-T G.993.2, which uses frequencies of up to 30 MHz to provide a downstream rate of 200 Mbps and an upstream rate of 100 Mbps.
SRA	Enabled by default. Click No to disable seamless rate adaptation on the interface. SRA adjusts the line rate based on current line conditions.

b. Configure Ethernet.

Table 2: Ethernet

Parameter Name	Description
Ethernet Interface Name *	Enter the name of an ethernet interface. For IOS XE routers, you must spell out the interface names completely (for example, GigabitEthernet0/0/0).
Description	Enter a description for the interface.
VLAN ID	Enter the VLAN identifier of the Ethernet interface.

c. Configure Tunnel.

Table 3: Tunnel

Parameter Name	Description
Tunnel Interface	
Per Tunnel QoS	Enable per tunnel QoS and choose from the following values to configure hub-to-spoke network topologies: <ul style="list-style-type: none"> • Spoke • Hub
Color	Select a color for the TLOC.

Parameter Name	Description
Color Description	Minimum supported release: Cisco Catalyst SD-WAN Manager Release 20.18.1 Enter a description associated to the TLOC color.
Groups	Enter the list of groups in the field.
Exclude Controller Group List	Set the Cisco SD-WAN Controllers that the tunnel interface is not allowed to connect to. Range: 0 through 100
Maximum Control Connections	Specify the maximum number of Cisco SD-WAN Controllers that the WAN tunnel interface can connect to. To have the tunnel establish no control connections, set the number to 0. Range: 0 through 8 Default: 2
Cisco SD-WAN Manager Connection Preference	Set the preference for using a tunnel interface to exchange control traffic with Cisco SD-WAN Manager. Range: 0 through 8 Default: 5
Tunnel TCP MSS	TCP MSS affects any packet that contains an initial TCP header that flows through the router. When configured, TCP MSS is examined against the MSS exchanged in the three-way handshake. The MSS in the header is lowered if the configured TCP MSS setting is lower than the MSS in the header. If the MSS header value is already lower than the TCP MSS, the packets flow through unmodified. The host at the end of the tunnel uses the lower setting of the two hosts. To configure TCP MSS, provide a value that is 40 bytes lower than the minimum path MTU. Specify the MSS of TPC SYN packets passing through the Cisco IOS XE Catalyst SD-WAN. By default, the MSS is dynamically adjusted based on the interface or tunnel MTU such that TCP SYN packets are never fragmented. Range: 552 through 1460 bytes Default: None
Border	From the drop-down list, select Global . Click On to set TLOC as border TLOC.
Validator As Stun Server	Click On to enable Session Traversal Utilities for NAT (STUN) to allow the tunnel interface to discover its public IP address and port number when the router is located behind a NAT.
Full Port Hop	Minimum release: Cisco IOS XE Catalyst SD-WAN Release 17.18.1a Enable full port hopping at the TLOC level to allow devices to establish connections with controllers by switching to the next port if the current port is blocked or non-functional. Default: Disabled
Port Hop	From the drop-down list, select Global . Click Off to allow port hopping on tunnel interface. Default: On , which disallows port hopping on tunnel interface. Starting from Cisco IOS XE Catalyst SD-WAN Release 17.18.1a, this field is deprecated. Instead use the Full Port Hop option. See the Full Port Hop field.

Parameter Name	Description
Low-Bandwidth Link	Click On to set the tunnel interface as a low-bandwidth link. Default: Off
Clear-Dont-Fragment	Configure Clear-Dont-Fragment for packets that arrive at an interface that has Don't Fragment configured. If these packets are larger than what MTU allows, they are dropped. If you clear the Don't Fragment bit, the packets are fragmented and sent. Click On to clear the Dont Fragment bit in the IPv4 packet header for packets being transmitted out of the interface. When the Dont Fragment bit is cleared, the router fragments packets larger than the MTU of the interface before sending the packets. Note Clear-Dont-Fragment clears the Dont Fragment bit and the Dont Fragment bit is set. For packets not requiring fragmentation, the Dont Fragment bit is not affected.
Network Broadcast	From the drop-down list, select Global . Click On to accept and respond to network-prefix-directed broadcasts. Enable this parameter only if the Directed Broadcast is enabled on the LAN interface feature template. Default: Off
Carrier	From the drop-down list, select Global and select the carrier name or private network identifier to associate with the tunnel. Values: carrier1, carrier2, carrier3, carrier4, carrier5, carrier6, carrier7, carrier8, default. Default: default
Bind Loopback Tunnel	Enter the name of a physical interface to bind to a loopback interface. The interface name has the following format: <i>ge slot/port</i>
NAT Refresh Interval	Set the interval between NAT refresh packets sent on a DTLS or TLS WAN transport connection. Range: 1 through 60 seconds Default: 5 seconds
Hello Interval	Enter the interval between Hello packets sent on a DTLS or TLS WAN transport connection. Range: 100 through 10000 milliseconds Default: 1000 milliseconds (1 second)

Parameter Name	Description
Hello Tolerance	<p>Enter the time to wait for a Hello packet on a DTLS or TLS WAN transport connection before declaring that transport tunnel to be down.</p> <p>Range: 12 through 60 seconds. Default: 12 seconds.</p> <p>The default hello interval is 1000 milliseconds, and it can be a time in the range 100 through 600000 milliseconds (10 minutes). The default hello tolerance is 12 seconds, and it can be a time in the range 12 through 600 seconds (10 minutes). To reduce outgoing control packets on a TLOC, it is recommended that on the tunnel interface you set the hello interval to 60000 milliseconds (10 minutes) and the hello tolerance to 600 seconds (10 minutes) and include the no track-transport disable regular checking of the DTLS connection between the edge device and the controller. For a tunnel connection between a edge device and any controller device, the tunnel uses the hello interval and tolerance times configured on the edge device. This choice is made to minimize the traffic sent over the tunnel, to allow for situations where the cost of a link is a function of the amount of traffic traversing the link. The hello interval and tolerance times are chosen separately for each tunnel between a edge device and a controller device. Another step taken to minimize the amount of control plane traffic is to not send or receive OMP control traffic over a cellular interface when other interfaces are available. This behavior is inherent in the software and is not configurable.</p>
Last Resort Circuit	<p>Select to use the tunnel interface as the circuit of last resort.</p> <p>Note It is assumed that an interface configured as a circuit of last resort is unavailable and is skipped while calculating the number of control connections. As a result, the cellular modem becomes dormant, and no traffic is sent over the circuit.</p> <p>When the configurations are activated on the edge device with cellular interfaces, all the interfaces begin the process of establishing control and BFD connections. When one or more of the primary interfaces establishes a BFD connection, the circuit of last resort shuts itself down.</p> <p>If the primary interfaces lose their connections to remote edges, the circuit of last resort activates itself, triggering a BFD TLOC Down alarm and a Control TLOC Down alarm on the edge device. The last resort interfaces are a backup circuit on edge device and are activated when all other transport links BFD sessions fail. In this mode, the radio interface is turned off, and no control or data connections exist over the cellular interface.</p>
Allow Services	Click On or Off for each service to enable or disable the service on the cellular interface.
Encapsulation	

Parameter Name	Description
Encapsulation	<p>Enable atleast one of the following encapsulation methods:</p> <ul style="list-style-type: none"> IPsec: Enter a value to set the preference for directing traffic to the tunnel. A higher value is preferred over a lower value. Range: 0 through 4294967295 Default: 0 IPsec Preference: From the drop-down list, select Global and enter a value to set the preference for directing traffic to the tunnel. A higher value is preferred over a lower value. Range: 0 through 4294967295 Default: 0 IPsec Weight: From the drop-down list, select Global and enter a value to set weight for balancing traffic across multiple TLOCs. A higher value sends more traffic to the tunnel. Range: 1 through 255 Default: 1 GRE: Enter a value to set GRE preference for TLOC. Range: 0 through 4294967295 GRE Preference: From the drop-down list, select Global and enter a value to set the preference for directing traffic to the tunnel. A higher value is preferred over a lower value. Range: 0 through 4294967295 Default: 0 GRE Weight: From the drop-down list, select Global and enter a value to set weight for balancing traffic across multiple TLOCs. A higher value sends more traffic to the tunnel. Range: 1 through 255 Default: 1

d. Configure NAT.

Table 4: NAT

Parameter Name	Description
UDP Timeout (Minutes)	<p>Specify when NAT translations over UDP sessions time out. Range: 1 through 65536 minutes Default: 1 minute</p>

Parameter Name	Description
TCP Timeout (Minutes)	Specify when NAT translations over TCP sessions time out. Range: 1 through 65536 minutes Default: 60 minutes (1 hour)

- e. Configure QoS.

Table 5: QoS

Parameter Name	Description
Adaptive QoS	Enter adaptive QoS parameters. You can leave the additional details at as default or specify your values. <ul style="list-style-type: none"> • Adapt Period (Minutes): Choose Global from the drop-down list, click On, and enter the period in minutes. • Shaping Rate Upstream: Choose Global from the drop-down list, click On, and enter the minimum, maximum, and default upstream bandwidth in Kbps. • Shaping Rate Downstream: Choose Global from the drop-down list, click On, and enter the minimum, maximum, downstream, and upstream bandwidth in Kbps.
Shaping Rate (kbps)	Choose Global from the drop-down list and configure the aggregate traffic transmission rate on the interface to be less than line rate, in kilobits per second (kbps). Range: 8 through 100000000

- f. Configure ACL.

Table 6: ACL

Parameter Name	Description
IPv4 Ingress Access List	Enter the name of an IPv4 access list to packets being received on the interface.
IPv4 Egress Access List	Enter the name of an IPv4 access list to packets being transmitted on the interface.
IPv6 Ingress Access List	Enter the name of an IPv6 access list to packets being received on the interface.
IPv6 Egress Access List	Enter the name of an IPv6 access list to packets being transmitted on the interface.

- g. Configure advanced parameters.

Table 7: Advanced

Parameter Name	Description
Shutdown	Click No to enable the interface.

Parameter Name	Description
Tracker / Tracker Group	Enter the name of a tracker or tracker group to track the status of transport interfaces that connect to the internet.
Service Provider	Specify the details of the service provider.
Bandwidth Upstream (Kbps)	Specify the bandwidth value to generate notifications when the bandwidth of traffic transmitted on a physical interface exceeds the value.
Bandwidth Downstream (Kbps)	Specify the bandwidth value to generate notifications when the bandwidth of traffic transmitted on a physical interface exceeds the value.
IP MTU	Enter the maximum MTU size of packets on the interface. Range: 576 through 1804 Default: 1500
TCP MSS	Enter the maximum segment size (MSS) of TPC SYN packets passing through the router. By default, the MSS is dynamically adjusted based on the interface or tunnel MTU such that TCP SYN packets are never fragmented. Range: 552 through 1460 bytes Default: 1500
TLOC Extension	Enter the name of a physical interface on the same router that connects to the WAN transport. This configuration binds the service-side interface to the WAN transport by enabling a device to access the opposite WAN transport connected to the neighbouring device using a TLOC-extension interface.
IP Directed Broadcast	From the drop-down list, select Global to enable IP Directed Broadcast. An IP directed broadcast is an IP packet whose destination address is a valid broadcast address for some IP subnet but which originates from a node that is not itself part of that destination subnet.

What to do next

Also see *Deploy a configuration group*.

Configure DSL IPoE using templates

Follow these steps to configure DSL IPoE using a feature template.

You configure IPoE on routers with DSL interfaces, to provide support for service provider digital subscriber line (DSL) functionality.

To configure DSL interfaces on Cisco IOS XE Catalyst SD-WAN devices using Cisco SD-WAN Manager templates:

1. Create a VPN Interface DSL IPoE feature template to configure IP-over-Ethernet interface parameters, as described in this article.
2. Create a VPN feature template to configure VPN parameters. See the VPN help topic.

Procedure

Step 1 From the Cisco SD-WAN Manager menu, choose **Configuration > Templates**.

Step 2 Click **Device Templates**, and click **Create Template**.

In Cisco vManage Release 20.7.x and earlier releases, **Device Templates** is titled **Device**.

- a) From the **Create Template** drop-down list, choose **From Feature Template**.
- b) From the **Device Model** drop-down list, select the type of device for which you are creating the template.
- c) Click **Transport & Management VPN** or scroll to the **Transport & Management VPN** section.
- d) Under **Additional VPN 0 Templates**, click **VPN Interface DSL IPoE**.
- e) From the **VPN Interface DSL IPoE** drop-down list, choose **Create Template**. The **VPN Interface DSL IPoE** template form is displayed.

This form contains fields for naming the template, fields for defining the IPoE Interface parameters. 

In **Template Name**, enter a name for the template. The name can be up to 128 characters and can contain only alphanumeric characters.

In **Template Description**, enter a description of the template. The description can be up to 2048 characters and can contain only alphanumeric characters.

Step 3 Configure the basic IPoE functionality.

Table 8:

Parameter Name	Description
Shutdown*	Click No to enable the VDSL controller interface.
Controller VDSL Slot*	Enter the slot number of the controller VDSL interface, in the format <i>slot/subslot/port</i> (for example, 0/2/0).

Parameter Name	Description
Mode*	Select the operating mode of the VDSL controller from the drop-down: <ul style="list-style-type: none"> • Auto—Default mode. • ADSL1—Use ITU G.992.1 Annex A full-rate mode, which provides a downstream rate of 1.3 Mbps and an upstream rate of 1.8 Mbps. • ADSL2—Use ITU G.992.3 Annex A, Annex L, and Annex M, which provides a downstream rate of 12 Mbps and an upstream rate of 1.3 Mbps. • ADSL2+— Use ITU G.992.5 Annex A and Annex M, which provides a downstream rate of 24 Mbps and an upstream rate of 3.3 Mbps. • ANSI—Operating in ADSL2/2+ mode, as defined in ITU G.991.1, G.992.3, and G992.5, Annex A and Annex M, and in VDSL2 mode, as defined in ITU-T G993.2. • VDSL2—Operate in VDSL2 mode, as defined in ITU-T G.993.2, which uses frequencies of up to 30 MHz to provide a downstream rate of 200 Mbps and an upstream rate of 100 Mbps..
VDSL Modem Configuration	Enter a command to send to the DSL modem in the NIM module. If the command is valid, it is executed and the results are returned to the Cisco SD-WAN Manager NMS. If the command is not valid, it is not executed.
SRA	Click Yes to enable seamless rate adaptation on the interface. SRA adjusts the line rate based on current line conditions.

Step 4 Configure an Ethernet interface on the VDSL controller.

Table 9:

Parameter Name	Description
Ethernet Interface Name	Enter a name for the Ethernet interface, in the format <i>subslot/port</i> (for example 2/0). You do not need to enter the slot number, because it must always be 0.
VLAN ID	Enter the VLAN identifier of the Ethernet interface.
Description	Enter a description for the interface.
Dynamic/Static	Assign a dynamic or static IPv4 address to the Ethernet interface.
IPv4 Address	Enter the static IPv4 address of the Ethernet interface.
DHCP Helper	Enter up to eight IP addresses for DHCP servers in the network, separated by commas, to have the interface be a DHCP helper. A DHCP helper interface forwards BOOTP (Broadcast) DHCP requests that it receives from the specified DHCP servers.

Step 5 Configure a tunnel interface for the multilink interface.

Table 10:

Parameter Name	Description
Tunnel Interface	Click On to create a tunnel interface.
Color	Select a color for the TLOC.
Color Description	Minimum supported release: Cisco Catalyst SD-WAN Manager Release 20.18.x Enter a description associated to the TLOC color.
Control Connection	<p>By default, Control Connection is set to On, which establishes a control connection for the TLOC. If the router has multiple TLOCs, click No to have the tunnel not establish control connection for the TLOC.</p> <p>Note We recommend a minimum of 650-700 Kbps bandwidth with default 10 msec hello-interval and 12 sec hello-tolerance parameters configured to avoid any data/packet loss in connection traffic.</p> <p>For each BFD session, an additional average sized BFD packet of 175 Bytes consumes 1.4 Kbps of bandwidth.</p> <p>A sample calculation of the required bandwidth for bidirectional BFD packet flow is given below:</p> <ul style="list-style-type: none"> • 650 – 700 Kbps per device for control connections. • 175 Bytes (or 1.4 Kbps) per BFD session on the device (request) • 175 Bytes (or 1.4 Kbps) per BFD session on the device (response) <p>If the path MTU discovery (PMTUD) is enabled, bandwidth for send/receive BFD packets per tunnel for every 30 secs:</p> <p>A 1500 Bytes BFD request packet is sent per tunnel every 30 secs: $1500 \text{ Bytes} * 8 \text{ bits/1 byte} * 1 \text{ packet} / 30 \text{ secs} = 400 \text{ bps (request)}$</p> <p>A 147 Bytes BFD packet is sent in response: $147 \text{ Bytes} * 8 \text{ bits/1 byte} * 1 \text{ packet} / 30 \text{ secs} = 40 \text{ bps (response)}$</p> <p>Therefore, a device with 775 BFD sessions (for example) requires a bandwidth of: $700k + (1.4k*775) + (400 *775) + (1.4k*775) + (40 *775) = \sim 3,5 \text{ MBps}$</p>
Maximum Control Connections	Specify the maximum number of Cisco SD-WAN Controllers that the WAN tunnel interface can connect to. To have the tunnel establish no control connections, set the number to 0. Range: 0 through 8. Default: 2
Cisco SD-WAN Validator As STUN Server	Click On to enable Session Traversal Utilities for NAT (STUN) to allow the tunnel interface to discover its public IP address and port number when the router is located behind a NAT.

Parameter Name	Description
Exclude Controller Group List	Set the Cisco SD-WAN Controllers that the tunnel interface is not allowed to connect to. Range: 0 through 100
Cisco SD-WAN Manager Connection Preference	Set the preference for using a tunnel interface to exchange control traffic with the Cisco SD-WAN Manager NMS. Range: 0 through 8. Default: 5
Full Port Hop	Minimum release: Cisco Catalyst SD-WAN Manager Release 20.18.x Enable full port hopping at the TLOC level to allow devices to establish connections with controllers by switching to the next port if the current port is blocked or non-functional. Default: Disabled
Port Hop	Click On to enable port hopping, or click Off to disable it. When a router is behind a NAT, port hopping rotates through a pool of preselected OMP port numbers (called base ports) to establish DTLS connections with other routers when a connection attempt is unsuccessful. The default base ports are 12346, 12366, 12386, 12406, and 12426. To modify the base ports, set a port offset value. Default: Enabled Starting from Cisco Catalyst SD-WAN Manager Release 20.18.x, this field is deprecated. Instead use the Full Port Hop option. See the Full Port Hop field.
Low-Bandwidth Link	Select to characterize the tunnel interface as a low-bandwidth link.
TCP MSS	TCP MSS affects any packet that contains an initial TCP header that flows through the router. When configured, TCP MSS is examined against the MSS exchanged in the three-way handshake. The MSS in the header is lowered if the configured TCP MSS setting is lower than the MSS in the header. If the MSS header value is already lower than the TCP MSS, the packets flow through unmodified. The host at the end of the tunnel uses the lower setting of the two hosts. If the TCP MSS is to be configured, it should be set at 40 bytes lower than the minimum path MTU. Specify the MSS of TPC SYN packets passing through the Cisco IOS XE Catalyst SD-WAN device. By default, the MSS is dynamically adjusted based on the interface or tunnel MTU such that TCP SYN packets are never fragmented. Range: 552 to 1460 bytes Default: None

Parameter Name	Description
Clear-Dont-Fragment	<p>Configure Clear-Dont-Fragment for packets that arrive at an interface that has Don't Fragment configured. If these packets are larger than what MTU allows, they are dropped. If you clear the Don't Fragment bit, the packets are fragmented and sent.</p> <p>Click On to clear the Dont Fragment bit in the IPv4 packet header for packets being transmitted out of the interface. When the Dont Fragment bit is cleared, packets larger than the MTU of the interface are fragmented before being sent.</p> <p>Note Clear-Dont-Fragment clears the Dont Fragment bit and the Dont Fragment bit is set. For packets not requiring fragmentation, the Dont Fragment bit is not affected.</p>
Allow Service	Choose On or Off for each service to allow or disallow the service on the interface.

To configure additional tunnel interface parameters, click **Advanced Options** and configure the following parameters:

Table 11:

Parameter Name	Description
GRE	<p>Use GRE encapsulation on the tunnel interface. By default, GRE is disabled.</p> <p>If you select both IPsec and GRE encapsulations, two TLOCs are created for the tunnel interface that have the same IP addresses and colors, but that differ by their encapsulation.</p>
IPsec	<p>Use IPsec encapsulation on the tunnel interface. By default, IPsec is enabled.</p> <p>If you select both IPsec and GRE encapsulations, two TLOCs are created for the tunnel interface that have the same IP addresses and colors, but that differ by their encapsulation.</p>
IPsec Preference	<p>Specify a preference value for directing traffic to the tunnel. A higher value is preferred over a lower value.</p> <p>Range: 0 through 4294967295</p> <p>Default: 0</p>
IPsec Weight	<p>Enter a weight to use to balance traffic across multiple TLOCs. A higher value sends more traffic to the tunnel.</p> <p>Range: 1 through 255</p> <p>Default: 1</p>
Carrier	<p>Select the carrier name or private network identifier to associate with the tunnel.</p> <p>Values: carrier1, carrier2, carrier3, carrier4, carrier5, carrier6, carrier7, carrier8, default</p> <p>Default: default</p>
Bind Loopback Tunnel	Enter the name of a physical interface to bind to a loopback interface.

Parameter Name	Description
Last-Resort Circuit	<p>Select to use the tunnel interface as the circuit of last resort.</p> <p>Note An interface configured as a circuit of last resort is expected to be down and is skipped while calculating the number of control connections, the cellular modem becomes dormant, and no traffic is sent over the circuit.</p> <p>When the configurations are activated on the edge device with cellular interfaces, then all the interfaces begin the process of establishing control and BFD connections. When one or more of the primary interfaces establishes a BFD connection, the circuit of last resort shuts itself down.</p> <p>Only when all the primary interfaces lose their connections to remote edges, then the circuit of last resort activates itself triggering a BFD TLOC Down alarm and a Control TLOC Down alarm on the edge device. The last resort interfaces are used as backup circuit on edge device and are activated when all other transport links BFD sessions fail. In this mode the radio interface is turned off, and no control or data connections exist over the cellular interface.</p>
NAT Refresh Interval	<p>Enter the interval between NAT refresh packets sent on a DTLS or TLS WAN transport connection.</p> <p>Range: 1 through 60 seconds Default: 5 seconds</p>
Hello Interval	<p>Enter the interval between Hello packets sent on a DTLS or TLS WAN transport connection.</p> <p>Range: 100 through 10000 milliseconds Default: 1000 milliseconds (1 second)</p>
Hello Tolerance	<p>Enter the time to wait for a Hello packet on a DTLS or TLS WAN transport connection before declaring that transport tunnel to be down.</p> <p>Range: 12 through 60 seconds Default: 12 seconds</p>

Step 6 Configure an interface to act as a NAT device for applications such as port forwarding.

Table 12:

Parameter Name	Description
NAT	Click On to have the interface act as a NAT device.
Refresh Mode	Select how NAT mappings are refreshed, either outbound or bidirectional (outbound and inbound). Default: Outbound
UDP Timeout	Specify when NAT translations over UDP sessions time out. Range: 1 through 65536 minutes Default: 1 minutes

TCP Timeout	Specify when NAT translations over TCP sessions time out. Range: 1 through 65536 minutes Default: 60 minutes (1 hour)
Block ICMP	Select On to block inbound ICMP error messages. By default, a router acting as a NAT device receives these error messages. Default: Off
Respond to Ping	Select On to have the router respond to ping requests to the NAT interface's IP address that are received from the public side of the connection.

To create a port forwarding rule, click **Add New Port Forwarding Rule** and configure the following parameters. You can define up to 128 port-forwarding rules to allow requests from an external network to reach devices on the internal network.

Table 13:

Parameter Name	Description
Port Start Range	Enter a port number to define the port or first port in the range of interest. Range: 0 through 65535
Port End Range	Enter the same port number to apply port forwarding to a single port, or enter a larger number to apply it to a range of ports. Range: 0 through 65535
Protocol	Select the protocol to which to apply the port-forwarding rule, either TCP or UDP. To match the same ports for both TCP and UDP traffic, configure two rules.
VPN	Specify the private VPN in which the internal server resides. This VPN is one of the VPN identifiers in the overlay network. Range: 0 through 65527
Private IP	Specify the IP address of the internal server to which to direct traffic that matches the port-forwarding rule.

Step 7 Configure ACLs to selectively indicate what traffic will enjoy the benefits of QoS

Table 14:

Parameter Name	Description
Shaping rate	Configure the aggregate traffic transmission rate on the interface to be less than line rate, in kilobits per second (kbps).
QoS map	Specify the name of the QoS map to apply to packets being transmitted out the interface.
Rewrite Rule	Click On , and specify the name of the rewrite rule to apply on the interface.

Parameter Name	Description
Ingress ACL – IPv4	Click On , and specify the name of the access list to apply to IPv4 packets being received on the interface.
Egress ACL – IPv4	Click On , and specify the name of the access list to apply to IPv4 packets being transmitted on the interface.
Ingress ACL – IPv6	Click On , and specify the name of the access list to apply to IPv6 packets being received on the interface.
Egress ACL – IPv6	Click On , and specify the name of the access list to apply to IPv6 packets being transmitted on the interface.
Ingress Policer	Click On , and specify the name of the policer to apply to packets being received on the interface.
Egress Policer	Click On , and specify the name of the policer to apply to packets being transmitted on the interface.

Step 8 Configure other interface properties.

Table 15:

Parameter Name	Description
Bandwidth Upstream	When the bandwidth of traffic transmitted on a physical interface in the WAN transport VPN (VPN 0) exceeds a specific limit by 85 percent (on Cisco IOS XE Catalyst SD-WAN devices and Cisco SD-WAN Manager NMSs only), BW Uptream issues notifications. For transmitted traffic, set the bandwidth above which to generate notifications. Range: 1 through $(2^{32} / 2) - 1$ kbps
Bandwidth Downstream	When the bandwidth of traffic received on a physical interface in the WAN transport VPN (VPN 0) exceeds a specific limit by 85 percent (on Cisco IOS XE Catalyst SD-WAN devices and Cisco SD-WAN Manager NMSs only), BW Downstream issues notifications. For received traffic, set the bandwidth above which to generate notifications. Range: 1 through $(2^{32} / 2) - 1$ kbps
IP MTU	IP MTU affects IP packets. If an IP packet exceeds the IP MTU, then the packet will be fragmented. Specify the maximum MTU size of packets on the interface. Range: 576 through 1804 Default: 1500 bytes

Parameter Name	Description
TCP MSS	<p>In a single TCP/IPv4 datagram, the TCP Maximum Segment Size (MSS) defines the maximum data that a host will accept. This TCP/IPv4 datagram might be fragmented at the IPv4 layer. The MSS value is sent as a TCP header option only in TCP SYN segments.</p> <p>Specify the maximum segment size (MSS) of TPC SYN packets passing through the router. By default, the MSS is dynamically adjusted based on the interface or tunnel MTU such that TCP SYN packets are never fragmented.</p> <p>Range: 552 to 1460 bytes</p> <p>Default: None</p>
TLOC Extension	<p>Use a TLOC Extension to bind an interface and connect another Cisco IOS XE Catalyst SD-WAN device at the same physical site to the local router's WAN transport interface (on Cisco IOS XE Catalyst SD-WAN devices only).</p> <p>Enter the name of the physical interface on the same router that connects to the WAN transport circuit. This configuration then binds this service-side interface to the WAN transport. A second router at the same site that itself has no direct connection to the WAN (generally because the site has only a single WAN connection) and that connects to this service-side interface is then provided with a connection to the WAN.</p>
Tracker	<p>Tracking the interface status is useful when you enable NAT on a transport interface in VPN 0 to allow data traffic from the router to exit directly to the internet rather than having to first go to a router in a data center. In this situation, enabling NAT on the transport interface splits the TLOC between the local router and the data center into two, with one going to the remote router and the other going to the internet.</p> <p>When you enable transport tunnel tracking, the software periodically probes the path to the internet to determine whether it is up. If the software detects that this path is down, it withdraws the route to the internet destination, and traffic destined to the internet is then routed through the data center router. When the software detects that the path to the internet is again functioning, the route to the internet is reinstalled.</p> <p>Enter the name of a tracker to track the status of transport interfaces that connect to the internet.</p>
IP Directed-Broadcast	<p>An IP directed broadcast is an IP packet whose destination address is a valid broadcast address for some IP subnet but which originates from a node that is not itself part of that destination subnet.</p> <p>A device that is not directly connected to its destination subnet forwards an IP directed broadcast in the same way it would forward unicast IP packets destined to a host on that subnet. When a directed broadcast packet reaches a device that is directly connected to its destination subnet, that packet is broadcast on the destination subnet. The destination address in the IP header of the packet is rewritten to the configured IP broadcast address for the subnet, and the packet is sent as a link-layer broadcast.</p> <p>If directed broadcast is enabled for an interface, incoming IP packets whose addresses identify them as directed broadcasts intended for the subnet to which that interface is attached are broadcast on that subnet.</p>

