



FXOS Troubleshooting Commands

This section includes common troubleshooting commands.

- [Chassis Mode Troubleshooting Commands, on page 1](#)
- [Eth-Uplink Mode Troubleshooting Commands, on page 6](#)
- [Fabric Interconnect Mode Troubleshooting Commands, on page 8](#)
- [Connect Local-Mgmt Troubleshooting Commands for the Firepower 2100 in Platform Mode, on page 11](#)
- [Connect Local-Mgmt Troubleshooting Commands for the Secure Firewall 3100, on page 16](#)
- [Connect Local-Mgmt Troubleshooting Commands for the Secure Firewall 4200 in Appliance Mode, on page 28](#)
- [Security Services Mode Troubleshooting Commands, on page 37](#)
- [Packet Capture for Secure Firewall 3100/4200, on page 39](#)

Chassis Mode Troubleshooting Commands

Use the following chassis mode FXOS CLI commands to troubleshoot issues with your system.

show environment

Displays environment information for the chassis.

For example:

```
FPR2100 /chassis # show environment expand detail
Chassis 1:
Overall Status: Power Problem
Operability: Operable
Power State: Ok
Thermal Status: Ok

PSU 1:
Overall Status: Powered Off
Operability: Unknown
Power State: Off
Voltage Status: Unknown

PSU 2:
Overall Status: Operable
Operability: Operable
Power State: On
Voltage Status: Ok

Tray 1 Module 1:
Overall Status: Operable
Operability: Operable
Power State: On
```

```

Fan 1:
    Overall Status: Operable
    Operability: Operable
    Power State: On
Fan 2:
    Overall Status: Operable
    Operability: Operable
    Power State: On
Fan 3:
    Overall Status: Operable
    Operability: Operable
    Power State: On
Fan 4:
    Overall Status: Operable
    Operability: Operable
    Power State: On
Server 1:
    Overall Status: Ok
    Memory Array 1:
        Current Capacity (MB): 32768
        Populated: 2
        DIMMs:
            ID  Overall Status          Capacity (MB)
            ---  -
            1  Operable                16384
            2  Operable                16384
    CPU 1:
        Presence: Equipped
        Cores: 8
        Product Name: Intel(R) Xeon(R) CPU D-1548 @ 2.00GHz
        Vendor: GenuineIntel
        Thermal Status: OK
        Overall Status: Operable
        Operability: Operable

```

scope fan

Enters the fan mode on Firepower 2110, 2120, and Secure Firewall 3100 series devices.

scope fan-module

Enters the fan mode on Firepower 2130, 2140, and Secure Firewall 3100 devices. From this mode, you can display detailed information about the chassis fan.

For example:

```

FPR2100 /chassis # show fan-module expand detail
Fan Module:
    Tray: 1
    Module: 1
    Overall Status: Operable
    Operability: Operable
    Power State: On
    Presence: Equipped
    Product Name: Cisco Firepower 2000 Series Fan Tray
    PID: FPR2K-FAN
    Vendor: Cisco Systems, Inc
    Fan:
        ID: 1
        Overall Status: Operable
        Operability: Operable
        Power State: On
        Presence: Equipped
        ID: 2
        Overall Status: Operable
        Operability: Operable
        Power State: On
        Presence: Equipped

```

show inventory

Displays inventory information such as the chassis number, vendor, and serial number.

Note: This command only applies to Firepower 2130 and 3100 devices.

For example:

```
FPR2100 /chassis # show inventory
Chassis  PID          Vendor          Serial (SN) HW Revision
-----  -
1 FPR-2140      Cisco Systems, In JAD201005FC 0.1
```

show inventory expand

Displays detailed inventory information about FRUable components such as the chassis, PSU, and network modules.

For example:

```
FPR2100 /chassis # show inventory expand detail
Chassis 1:
  Product Name: Cisco Firepower 2000 Appliance
  PID: FPR-2130
  VID: V01
  Vendor: Cisco Systems, Inc
  Model: FPR-2130
  Serial (SN): JAD2012091X
  HW Revision: 0.1
  PSU 1:
    Presence: Equipped
    Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
    PID: FPR2K-PWR-AC-400
    VID: V01
    Vendor: Cisco Systems, Inc
    Serial (SN): LIT2010CAFE
    HW Revision: 0
  PSU 2:
    Presence: Equipped
    Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
    PID: FPR2K-PWR-AC-400
    VID: V01
    Vendor: Cisco Systems, Inc
    Serial (SN): LIT2010CAFE
    HW Revision: 0
  Fan Modules:
    Tray 1 Module 1:
      Presence: Equipped
      Product Name: Cisco Firepower 2000 Series Fan Tray
      PID: FPR2K-FAN
      Vendor: Cisco Systems, Inc
  Fans:
    ID Presence
    --
    1 Equipped
    2 Equipped
    3 Equipped
    4 Equipped
Fabric Card 1:
  Description: Cisco SSP FPR 2130 Base Module
  Number of Ports: 16
  State: Online
  Vendor: Cisco Systems, Inc.
  Model: FPR-2130
  HW Revision: 0
  Serial (SN): JAD2012091X
  Perf: N/A
  Operability: Operable
```

```

Overall Status: Operable
Power State: Online
Presence: Equipped
Thermal Status: N/A
Voltage Status: N/A
Fabric Card 2:
Description: 8-port 10 Gigabit Ethernet Expansion Module
Number of Ports: 8
State: Online
Vendor: Cisco Systems, Inc.
Model: FPR-NM-8X10G
HW Revision: 0
Serial (SN): JAD19510AKD
Perf: N/A
Operability: Operable
Overall Status: Operable
Power State: Online
Presence: Equipped
Thermal Status: N/A
Voltage Status: N/A

```

scope psu

Enters the power supply unit mode. From this mode, you can view detailed information about the power supply unit.

For example:

```

FPR2100 /chassis # show psu expand detail
PSU:
PSU: 1
Overall Status: Powered Off
Operability: Unknown
Power State: Off
Presence: Equipped
Voltage Status: Unknown
Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
PID: FPR2K-PWR-AC-400
VID: V01
Vendor: Cisco Systems, Inc
Serial (SN): LIT2010CAFE
Type: AC
Fan Status: Ok
PSU: 2
Overall Status: Operable
Operability: Operable
Power State: On
Presence: Equipped
Voltage Status: Ok
Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
PID: FPR2K-PWR-AC-400
VID: V01
Vendor: Cisco Systems, Inc
Serial (SN): LIT2010CAFE
Type: AC
Fan Status: Ok

```

scope stats

Enters the stats mode. From this mode, you can view detailed information about the chassis statistics.

For example:

```

FPR2100 /chassis # show stats
Chassis Stats:
Time Collected: 2016-11-14T21:19:46.317
Monitored Object: sys/chassis-1/stats
Suspect: No

```

```
Outlet Temp1 (C): 43.000000
Outlet Temp2 (C): 41.000000
Inlet Temp (C): 30.000000
Internal Temp (C): 34.000000
Thresholded: 0
Fan Stats:
Time Collected: 2016-11-14T21:19:46.317
Monitored Object: sys/chassis-1/fan-module-1-1/fan-1/stats
Suspect: No
Speed (RPM): 17280
Thresholded: 0
Time Collected: 2016-11-14T21:19:46.317
Monitored Object: sys/chassis-1/fan-module-1-1/fan-2/stats
Suspect: No
Speed (RPM): 17340
Thresholded: 0
Time Collected: 2016-11-14T21:19:46.317
Monitored Object: sys/chassis-1/fan-module-1-1/fan-3/stats
Suspect: No
Speed (RPM): 17280
Thresholded: 0
Time Collected: 2016-11-14T21:19:46.317
Monitored Object: sys/chassis-1/fan-module-1-1/fan-4/stats
Suspect: No
Speed (RPM): 17280
Thresholded: 0
Psu Stats:
Time Collected: 2016-11-14T21:19:46.318
Monitored Object: sys/chassis-1/psu-1/stats
Suspect: No
Input Current (A): 0.000000
Input Power (W): 8.000000
Input Voltage (V): 0.000000
Psu Temp1 (C): 32.000000
Psu Temp2 (C): 36.000000
Psu Temp3 (C): 32.000000
Fan Speed (RPM): 0
Thresholded: 0
Time Collected: 2016-11-14T21:19:46.318
Monitored Object: sys/chassis-1/psu-2/stats
Suspect: No
Input Current (A): 0.374000
Input Power (W): 112.000000
Input Voltage (V): 238.503006
Psu Temp1 (C): 36.000000
Psu Temp2 (C): 47.000000
Psu Temp3 (C): 47.000000
Fan Speed (RPM): 2240
Thresholded: 0
CPU Env Stats:
Time Collected: 2016-11-14T21:19:46.317
Monitored Object: sys/chassis-1/blade-1/board/cpu-1/env-stats
Suspect: No
Temperature (C): 46.000000
Thresholded: 0
Time Collected: 2016-11-14T21:19:46.317
Monitored Object: sys/chassis-1/blade-1/npu/cpu-1/env-stats
Suspect: No
Temperature (C): 38.000000
Thresholded: 0
```

Eth-Uplink Mode Troubleshooting Commands

Use the following eth-uplink mode FXOS CLI commands to troubleshoot issues with your system.

show detail

Displays detailed information about your device's Ethernet uplink.

For example:

```
FPR2100 /eth-uplink # show detail
Ethernet Uplink:
  Mode: Security Node
  MAC Table Aging Time (dd:hh:mm:ss): 00:04:01:40
  VLAN Port Count Optimization: Disabled
  Current Task:
```

scope fabric a

Enters the eth-uplink interface mode. From this mode, you can view port channel, statistics, and interface information.

For example:

```
FPR2100 /eth-uplink/fabric # show interface
Interface:
```

| Port Name | Port Type | Admin State | Oper State | State Reason |
|--------------|-----------|-------------|------------|--------------|
| Ethernet1/1 | Data | Enabled | Up | Up |
| Ethernet1/2 | Data | Enabled | Link Down | Down |
| Ethernet1/3 | Data | Disabled | Link Down | Down |
| Ethernet1/4 | Data | Disabled | Link Down | Down |
| Ethernet1/5 | Data | Disabled | Link Down | Down |
| Ethernet1/6 | Data | Disabled | Link Down | Down |
| Ethernet1/7 | Data | Disabled | Link Down | Down |
| Ethernet1/8 | Data | Disabled | Link Down | Down |
| Ethernet1/9 | Data | Disabled | Link Down | Down |
| Ethernet1/10 | Data | Disabled | Link Down | Down |
| Ethernet1/11 | Data | Disabled | Link Down | Down |
| Ethernet1/12 | Data | Disabled | Link Down | Down |
| Ethernet1/13 | Data | Disabled | Link Down | Down |
| Ethernet1/14 | Data | Disabled | Link Down | Down |
| Ethernet1/15 | Data | Disabled | Link Down | Down |
| Ethernet1/16 | Data | Disabled | Link Down | Down |
| Ethernet2/1 | Data | Disabled | Link Down | Down |
| Ethernet2/2 | Data | Disabled | Link Down | Down |
| Ethernet2/3 | Data | Disabled | Link Down | Down |
| Ethernet2/4 | Data | Disabled | Link Down | Down |
| Ethernet2/5 | Data | Disabled | Link Down | Down |
| Ethernet2/6 | Data | Disabled | Link Down | Down |
| Ethernet2/7 | Data | Disabled | Link Down | Down |
| Ethernet2/8 | Data | Disabled | Link Down | Down |

```
FPR2100 /eth-uplink/fabric # show port-channel
```

Port Channel:

| State | Port Channel Id | Name | Port Type | Admin State | Oper State |
|--------------|-----------------|------|-----------|-------------|------------|
| State Reason | | | | | |
| ----- | | | | | |
| 1 | Port-channel1 | Data | Disabled | | |
| Link Down | | Down | | | |

```
FPR2100 /eth-uplink/fabric/port-channel # show stats
Ether Error Stats:
  Time Collected: 2016-11-14T21:27:16.386
  Monitored Object: fabric/lan/A/pc-1/err-stats
  Suspect: No
  Rcv (errors): 0
  Align (errors): 0
  Fcs (errors): 0
  Xmit (errors): 0
  Under Size (errors): 0
  Out Discard (errors): 0
  Deferred Tx (errors): 0
  Int Mac Tx (errors): 0
  Int Mac Rx (errors): 0
  Thresholded: Xmit Delta Min
Ether Loss Stats:
  Time Collected: 2016-11-14T21:27:16.386
  Monitored Object: fabric/lan/A/pc-1/loss-stats
  Suspect: No
  Single Collision (errors): 0
  Multi Collision (errors): 0
  Late Collision (errors): 0
  Excess Collision (errors): 0
  Carrier Sense (errors): 0
  Giants (errors): 0
  Symbol (errors): 0
  SQE Test (errors): 0
  Thresholded: 0
Ether Pause Stats:
  Time Collected: 2016-11-14T21:27:16.386
  Monitored Object: fabric/lan/A/pc-1/pause-stats
  Suspect: No
  Recv Pause (pause): 0
  Xmit Pause (pause): 0
  Resets (resets): 0
  Thresholded: 0
Ether Rx Stats:
  Time Collected: 2016-11-14T21:27:16.386
  Monitored Object: fabric/lan/A/pc-1/rx-stats
  Suspect: No
  Total Packets (packets): 0
  Unicast Packets (packets): 0
  Multicast Packets (packets): 0
  Broadcast Packets (packets): 0
  Total Bytes (bytes): 0
  Jumbo Packets (packets): 0
  Thresholded: 0
Ether Tx Stats:
  Time Collected: 2016-11-14T21:27:16.386
  Monitored Object: fabric/lan/A/pc-1/tx-stats
  Suspect: No
  Total Packets (packets): 0
  Unicast Packets (packets): 0
  Multicast Packets (packets): 0
  Broadcast Packets (packets): 0
  Total Bytes (bytes): 0
  Jumbo Packets (packets): 0
FPR2100 /eth-uplink/fabric/interface # show stats
Ether Error Stats:
  Time Collected: 2016-11-14T21:27:46.395
  Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/err-stats
  Suspect: No
  Rcv (errors): 0
```

```

Align (errors): 0
Fcs (errors): 0
Xmit (errors): 0
Under Size (errors): 0
Out Discard (errors): 0
Deferred Tx (errors): 0
Int Mac Tx (errors): 0
Int Mac Rx (errors): 0
Thresholded: Xmit Delta Min
Ether Loss Stats:
Time Collected: 2016-11-14T21:27:46.395
Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/loss-stats
Suspect: No
Single Collision (errors): 0
Multi Collision (errors): 0
Late Collision (errors): 0
Excess Collision (errors): 0
Carrier Sense (errors): 0
Giants (errors): 7180
Symbol (errors): 0
SQE Test (errors): 0
Thresholded: 0
Ether Pause Stats:
Time Collected: 2016-11-14T21:27:46.395
Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/pause-stats
Suspect: No
Recv Pause (pause): 0
Xmit Pause (pause): 0
Resets (resets): 0
Thresholded: 0
Ether Rx Stats:
Time Collected: 2016-11-14T21:27:46.395
Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/rx-stats
Suspect: No
Total Packets (packets): 604527
Unicast Packets (packets): 142906
Multicast Packets (packets): 339031
Broadcast Packets (packets): 122590
Total Bytes (bytes): 59805045
Jumbo Packets (packets): 0
Thresholded: 0
Ether Tx Stats:
Time Collected: 2016-11-14T21:27:46.395
Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/tx-stats
Suspect: No
Total Packets (packets): 145018
Unicast Packets (packets): 145005
Multicast Packets (packets): 0
Broadcast Packets (packets): 13
Total Bytes (bytes): 13442404
Jumbo Packets (packets): 0
Thresholded: 0

```

Fabric Interconnect Mode Troubleshooting Commands

Use the following fabric-interconnect mode FXOS CLI commands to troubleshoot issues with your system.

show card

Displays information on a fabric card.

For example:


```

FPR2100 /fabric-interconnect # show card detail expand
Fabric Card:
  Id: 1
  Description: Cisco SSP FPR 2130 Base Module
  Number of Ports: 16
  State: Online
  Vendor: Cisco Systems, Inc.
  Model: FPR-2130
  HW Revision: 0
  Serial (SN): JAD2012091X
  Perf: N/A
  Operability: Operable
  Overall Status: Operable
  Power State: Online
  Presence: Equipped
  Thermal Status: N/A
  Voltage Status: N/A

```

show image

Displays all available images.

```

firepower /firmware # show image

```

| Name | Type | Version |
|--------------------------------------|--------------------|--------------|
| cisco-asa-9.10.1.csp | Firepower Cspapp | 9.10.1 |
| cisco-asa-9.9.2.csp | Firepower Cspapp | 9.9.2 |
| fxos-k8-fp2k-firmware.0.4.04.SPA | Firepower Firmware | 0.4.04 |
| fxos-k8-fp2k-lfbff.82.1.1.303i.SSA | Firepower System | 82.1(1.303i) |
| fxos-k8-fp2k-npu.82.1.1.303i.SSA | Firepower Npu | 82.1(1.303i) |
| fxos-k8-fp2k-npu.82.1.1.307i.SSA | Firepower Npu | 82.1(1.307i) |
| fxos-k9-fp2k-manager.82.1.1.303i.SSA | Firepower Manager | 82.1(1.303i) |

show package

Displays all available packages.

```

firepower /firmware # show package

```

| Name | Package-Vers |
|---------------------------|--------------|
| cisco-ftd-fp2k.9.10.1.SSA | 9.10.1 |
| cisco-ftd-fp2k.9.9.2.SSA | 9.9.2 |

show package *package_name* expand

Displays the package details.

```

firepower /firmware # show package cisco-ftd-fp2k.9.10.1.SSA expand
Package cisco-ftd-fp2k.9.10.1.SSA:
  Images:
    cisco-asa.9.10.1.csp
    fxos-k8-fp2k-firmware.0.4.04.SPA
    fxos-k8-fp2k-lfbff.82.1.1.303i.SSA
    fxos-k8-fp2k-npu.82.1.1.303i.SSA
    fxos-k9-fp2k-manager.82.1.1.303i.SSA

```

scope auto-install

Enters the auto-install mode. From this mode, you can view the current FXOS upgrade state.

```

firepower /firmware/auto-install # show
Firmware Auto-Install:

```

| Package-Vers | Oper State | Upgrade State |
|--------------|------------|------------------------|
| 9.10.1 | Scheduled | Installing Application |

scope firmware

Enters the firmware mode. From this mode, you can view download task information.

For example:

```
FPR2100 /firmware # show download-task
Download task:
  File Name
  Userid      State
  -----
  cisco-ftd-fp2k.9.10.1.SSA
0 danp      Downloaded
  cisco-ftd-fp2k.9.9.1.SSA
0 danp      Downloaded
  Protocol Server      Port
  -----
  Scp      172.29.191.78
  Scp      172.29.191.78
```

scope download-task

Enters the download-task mode. From this mode, you can view additional details about each download task and restart the download task.

For example:

```
Download task:
  File Name: test.SSA
  Protocol: Scp
  Server: 172.29.191.78
  Port: 0
  Userid: user
  Path: /tmp
  Downloaded Image Size (KB): 0
  Time stamp: 2016-11-15T19:42:29.854
  State: Failed
  Transfer Rate (KB/s): 0.000000
  Current Task: deleting downloadable test.SSA on
local(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:DeleteLocal)
firepower /firmware/download-task # show fsm status
File Name: test.SSA
FSM 1:
  Remote Result: End Point Failed
  Remote Error Code: ERR MO Illegal Iterator State
  Remote Error Description: End point timed out. Check for IP, port, password,
disk space or network access related issues.#
  Status: Download Fail
  Previous Status: Download Fail
  Timestamp: 2016-11-15T19:42:29.854
  Try: 2
  Progress (%): 0
  Current Task: deleting downloadable test.SSA on
local(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:DeleteLocal)

firepower /firmware/download-task # restart
Password:
```

scope psu

Enters the power supply unit mode. From this mode, you can view detailed information about the power supply unit.

For example:

```
FPR2100 /chassis # show psu expand detail
PSU:
  PSU: 1
  Overall Status: Powered Off
  Operability: Unknown
  Power State: Off
```

```

Presence: Equipped
Voltage Status: Unknown
Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
PID: FPR2K-PWR-AC-400
VID: V01
Vendor: Cisco Systems, Inc
Serial (SN): LIT2010CAFE
Type: AC
Fan Status: Ok
PSU: 2
Overall Status: Operable
Operability: Operable
Power State: On
Presence: Equipped
Voltage Status: Ok
Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
PID: FPR2K-PWR-AC-400
VID: V01
Vendor: Cisco Systems, Inc
Serial (SN): LIT2010CAFE
Type: AC
Fan Status: Ok

```

Connect Local-Mgmt Troubleshooting Commands for the Firepower 2100 in Platform Mode

Use the following connect local-mgmt mode FXOS CLI commands to troubleshoot issues with your Firepower 2100 in Platform mode. To access connect local-mgmt mode, enter:

FPR2100# connect local-mgmt

show lacp

Displays detailed information about EtherChannel LACP.

For example:

```

FPR2100(local-mgmt)# show lacp neighborFlags: S - Device is requesting Slow LACPDUs
F - Device is requesting Fast LACPDUs
A - Device is in Active mode          P - Device is in Passive mode

```

Channel group: 11

Partner (internal) information:

| Port | Partner System ID | Partner Port Number | Age | Partner Flags |
|--------|----------------------|---------------------|------|---------------|
| Eth1/1 | 32768,286f.7fec.5980 | 0x10e | 13 s | FA |

| LACP Partner Port Priority | Partner Oper Key | Partner Port State |
|----------------------------|------------------|--------------------|
| 32768 | 0x16 | 0x3f |

Port State Flags Decode:

| Activity: | Timeout: | Aggregation: | Synchronization: |
|-----------|----------|--------------|------------------|
| Active | Long | Yes | Yes |

| Collecting: | Distributing: | Defaulted: | Expired: |
|-------------|---------------|------------|----------|
| Yes | Yes | No | No |

```

Port      Partner
System ID      Partner
Eth1/2      32768,286f.7fec.5980  0x10f      Age      Partner
                                           5 s      Flags
                                           FA

LACP Partner      Partner      Partner
Port Priority      Oper Key      Port State
32768              0x16              0x3f

Port State Flags Decode:
Activity:  Timeout:  Aggregation:  Synchronization:
Active     Long      Yes          Yes

Collecting:  Distributing:  Defaulted:  Expired:
Yes          Yes          No          No

```

```
FP2100(local-mgmt)# show lacp counters
```

| Port | LACPDUs | | Marker | | Marker Response | | LACPDUs | |
|-------------------|---------|------|--------|------|-----------------|------|---------|-----|
| | Sent | Recv | Sent | Recv | Sent | Recv | Pkts | Err |
| Channel group: 11 | | | | | | | | |
| Eth1/1 | 4435 | 3532 | 0 | 0 | 0 | 0 | 0 | |
| Eth1/2 | 4566 | 3532 | 0 | 0 | 0 | 0 | 0 | |

show portchannel

Displays detailed information about EtherChannels.

For example:

```

FPR2100(local-mgmt)# show portchannel summary
Flags:  D - Down      P - Up in port-channel (members)
I - Individual  H - Hot-standby (LACP only)
s - Suspended   r - Module-removed
S - Switched   R - Routed
U - Up (port-channel)
M - Not in use. Min-links not met

```

| Group | Port-Channel | Type | Protocol | Member Ports |
|-------|--------------|------|----------|---------------------|
| 11 | Po11(U) | Eth | LACP | Eth1/1(P) Eth1/2(P) |

show portmanager

Displays detailed information about physical interfaces.

For example:

```

FPR2100(local-mgmt)# show portmanager counters ethernet 1 1
Good Octets Received      : 105503260
Bad Octets Received       : 0
MAC Transmit Error        : 0
Good Packets Received     : 1376050
Bad Packets Received      : 0
BRDC Packets Received     : 210
MC Packets Received       : 1153664
Size 64                   : 1334830
Size 65 to 127            : 0
Size 128 to 255           : 0
Size 256 to 511           : 41220
Size 512 to 1023          : 0
Size 1024 to Max          : 0

```

| PHY Data: | | | | | | | |
|-----------|------|--------|--------|------|------|--------|--------|
| PAGE | IFC | OFFSET | VALUE | PAGE | IFC | OFFSET | VALUE |
| ---- | ---- | ----- | ----- | ---- | ---- | ----- | ----- |
| 0 | 0 | 0x0000 | 0x1140 | 0 | 0 | 0x0001 | 0x796d |
| 0 | 0 | 0x0002 | 0x0141 | 0 | 0 | 0x0003 | 0x0ee1 |
| 0 | 0 | 0x0004 | 0x03e3 | 0 | 0 | 0x0005 | 0xc1e1 |
| 0 | 0 | 0x0006 | 0x000f | 0 | 0 | 0x0007 | 0x2001 |
| 0 | 0 | 0x0008 | 0x4f08 | 0 | 0 | 0x0009 | 0x0f00 |
| 0 | 0 | 0x000a | 0x3800 | 0 | 0 | 0x000f | 0x3000 |
| 0 | 0 | 0x0010 | 0x3070 | 0 | 0 | 0x0011 | 0xac08 |
| 0 | 0 | 0x0012 | 0x0000 | 0 | 0 | 0x0013 | 0x1c40 |
| 0 | 0 | 0x0014 | 0x8020 | 0 | 0 | 0x0015 | 0x0000 |
| 18 | 0 | 0x001b | 0x0000 | | | | |

| Item | Description |
|-------------------------------|--|
| Good Octets Received | Number of ethernet frames received that are not bad ethernet frames |
| Bad Octets Received | Sum of lengths of all bad ethernet frames received |
| MAC Transmit Error | Number of frames not transmitted correctly or dropped due to internal MAC Tx error |
| Good Packets Received | The number of bad frames received |
| Bad Packets Received | The number of bad frames received |
| BRDC Packets Received | The number of good frames received that have a Broadcast destination MAC address |
| MC Packets Received | The number of good frames received that have a Multicast destination MAC address |
| Good Octets Sent | The sum of lengths of all Ethernet frames sent |
| Good Packets Sent | The number of good frames sent |
| Excessive Collision | The number of collision events seen by the MAC not including those counted in Single, Multiple, Excessive, or Late. This counter is applicable in half-duplex only |
| MC Packets Sent | The number of good frames send that have a Multicast destination MAC address |
| BRDC Packets Sent | The number of good frames send that have a Broadcast destination MAC address |
| Unrecognized MAC Received | Number of received MAC Control frames that are not Flow control frames. |
| FC sent | Number of Flow Control frames sent. |
| Good FC Received | Number of good IEEE 802.3x Flow Control packets received. |
| Drop Events | Number of packets dropped |
| Undersize Packets | Number of undersize packets received |
| Fragments Packets | Number of fragments received. |
| Oversize Packets | Number of oversize packets received |
| Jabber Packets | Number of jabber packets received |
| MAC RX Error Packets Received | Number of Rx Error events seen by the receive side of the MAC |

| Item | Description |
|--------------------------|--|
| Bad CRC | Number of packets received with bad CRC |
| Collisions | Number of late collisions seen by the MAC |
| Late collison | Total number of late collisions seen by the MAC |
| Bad FC Received | Number of bad IEEE 802.3x Flow Control packets received |
| Good UC Packets Received | Number of Ethernet Unicast frames received |
| Good UC Packets Sent | Number of Ethernet Unicast frames sent |
| Multiple Packets Sent | Valid Frame transmitted on half-duplex link that encountered more then one collision. Byte count and cast are valid. |
| Deferred Packets Sent | Valid frame transmitted on half-duplex link with no collisions, but where the frame transmission was delayed due to media being busy. Byte count and cast are valid. |
| Size 1024 to 15180 | The number of received and transmitted, good and bad frames that are 1024 to 1518 bytes in size |
| Size 1519 to Max | The number of received and transmitted, good and bad frames that are more than 1519 bytes in size |
| txqFilterDisc | Number of IN packets that were filtered due to TxQ |
| linkChange | number of link up or link down changes for the port |

```
FPR2100(local-mgmt)# show portmanager switch mac-filters
```

| port | ix | MAC | mask | action | packets | bytes |
|------|-----|-------------------|-------------------|---------|---------|----------|
| 00 | 0ba | 2C:F8:9B:1E:8F:D7 | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 0c9 | 01:80:C2:00:00:02 | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 0cc | 2C:F8:9B:1E:8F:F7 | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 0cf | FF:FF:FF:FF:FF:FF | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | b70 | 00:00:00:00:00:00 | 01:00:00:00:00:00 | DROP | 222201 | 14220864 |
| | bb8 | 01:00:00:00:00:00 | 01:00:00:00:00:00 | DROP | 1153821 | 91334968 |
| 01 | 0bd | 2C:F8:9B:1E:8F:D6 | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 0c0 | 01:80:C2:00:00:02 | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 0c3 | 2C:F8:9B:1E:8F:F6 | FF:FF:FF:FF:FF:FF | FORWARD | | |
| | 0c6 | FF:FF:FF:FF:FF:FF | FF:FF:FF:FF:FF:FF | FORWARD | 210 | 13440 |
| | b73 | 00:00:00:00:00:00 | 01:00:00:00:00:00 | DROP | 222201 | 14220864 |
| | bbb | 01:00:00:00:00:00 | 01:00:00:00:00:00 | DROP | 1153795 | 91281055 |

```
<...>
```

```
FPR2100(local-mgmt)# show portmanager switch status
```

| Dev/Port | Mode | Link | Speed | Duplex | Loopback | Mode |
|----------|-------|-------|-------|--------|----------|-------|
| ----- | ----- | ----- | ----- | ----- | ----- | ----- |

| | | | | | |
|------|--------|------|-----|------|------|
| 0/0 | QSGMII | Up | 1G | Full | None |
| 0/1 | QSGMII | Up | 1G | Full | None |
| 0/2 | QSGMII | Down | 1G | Half | None |
| 0/3 | QSGMII | Down | 1G | Half | None |
| 0/4 | QSGMII | Down | 1G | Half | None |
| 0/5 | QSGMII | Down | 1G | Half | None |
| 0/6 | QSGMII | Up | 1G | Full | None |
| 0/7 | QSGMII | Down | 1G | Half | None |
| 0/48 | QSGMII | Down | 1G | Half | None |
| 0/49 | QSGMII | Down | 1G | Half | None |
| 0/50 | QSGMII | Down | 1G | Half | None |
| 0/51 | QSGMII | Down | 1G | Half | None |
| 0/52 | KR | Up | 40G | Full | None |
| 0/56 | SR_LR | Down | 10G | Full | None |
| 0/57 | SR_LR | Down | 10G | Full | None |
| 0/58 | SR_LR | Down | 10G | Full | None |
| 0/59 | SR_LR | Down | 10G | Full | None |
| 0/64 | SR_LR | Down | 10G | Full | None |
| 0/65 | SR_LR | Down | 10G | Full | None |
| 0/66 | SR_LR | Down | 10G | Full | None |
| 0/67 | SR_LR | Down | 10G | Full | None |
| 0/68 | SR_LR | Down | 10G | Full | None |
| 0/69 | SR_LR | Down | 10G | Full | None |
| 0/70 | SR_LR | Down | 10G | Full | None |
| 0/71 | SR_LR | Down | 10G | Full | None |
| 0/80 | KR | Up | 10G | Full | None |
| 0/81 | KR | Down | 10G | Full | None |
| 0/83 | KR | Up | 10G | Full | None |

Connect Local-Mgmt Troubleshooting Commands for the Secure Firewall 3100

In addition to the existing debugging commands, CLIs specific to Secure Firewall 3100 are explained in this section below.

Use the following connect local-mgmt mode FXOS CLI commands to troubleshoot issues with your Secure Firewall 3100. To access connect local-mgmt mode, enter:

FPR3100# connect local-mgmt

show portmanager

Displays detailed information about switched, packets, SFP-FEC counters, digital optical monitoring, QOS functionality, CPSS AP, and Cyclic log dumps.

For example:

The following CLI displays the FXOS port manager switch hardware TCAM rules dump in vtcam-tti:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
detail
VTCAM_RULE_ID  VLAN  SRC_PORT  PORTCHANNEL_ID  FLAGS  MODE  REF_COUNT
1              21      0         2                0      2      5          3
2             3078      0         0                0      0      0          1
3             3077      0         0                0      0      0          1
4             3076      0         0                0      0      0          1
5             3075      0         0                0      0      0          1
6             3074      0         0                0      0      0          1
7             3073      0         0                0      0      0          1
8              1      0         0                0      0      0          1
```


| | | | | | | | |
|----|----|-----|----|---|----|---|---|
| 9 | 18 | 102 | 0 | 0 | 24 | 8 | 1 |
| 10 | 5 | 157 | 0 | 0 | 24 | 8 | 1 |
| 11 | 31 | 0 | 12 | 0 | 2 | 5 | 3 |
| 12 | 15 | 105 | 0 | 0 | 24 | 8 | 1 |
| 13 | 9 | 111 | 0 | 0 | 24 | 8 | 1 |
| 14 | 13 | 107 | 0 | 0 | 24 | 8 | 1 |
| 15 | 26 | 0 | 7 | 0 | 2 | 5 | 3 |
| 16 | 29 | 0 | 10 | 0 | 2 | 5 | 3 |
| 17 | 23 | 0 | 4 | 0 | 2 | 5 | 3 |
| 18 | 19 | 101 | 0 | 0 | 24 | 8 | 1 |
| 19 | 30 | 0 | 11 | 0 | 2 | 5 | 3 |
| 20 | 28 | 0 | 9 | 0 | 2 | 5 | 3 |
| 21 | 4 | 156 | 0 | 0 | 24 | 8 | 1 |
| 22 | 34 | 0 | 15 | 0 | 2 | 5 | 3 |
| 23 | 6 | 158 | 0 | 0 | 24 | 8 | 1 |
| 24 | 8 | 112 | 0 | 0 | 24 | 8 | 1 |
| 25 | 24 | 0 | 5 | 0 | 2 | 5 | 3 |
| 26 | 14 | 106 | 0 | 0 | 24 | 8 | 1 |
| 27 | 32 | 0 | 13 | 0 | 2 | 5 | 3 |
| 28 | 25 | 0 | 6 | 0 | 2 | 5 | 3 |
| 29 | 12 | 0 | 0 | 9 | 6 | 5 | 2 |
| 30 | 20 | 0 | 1 | 0 | 2 | 5 | 3 |
| 31 | 11 | 109 | 0 | 0 | 24 | 8 | 1 |
| 32 | 27 | 0 | 8 | 0 | 2 | 5 | 3 |
| 33 | 17 | 103 | 0 | 0 | 24 | 8 | 1 |
| 34 | 22 | 0 | 3 | 0 | 2 | 5 | 3 |
| 35 | 16 | 104 | 0 | 0 | 24 | 8 | 1 |
| 36 | 3 | 0 | 19 | 0 | 26 | 8 | 1 |
| 37 | 35 | 0 | 16 | 0 | 2 | 5 | 3 |
| 38 | 33 | 0 | 14 | 0 | 2 | 5 | 3 |
| 39 | 7 | 159 | 0 | 0 | 24 | 8 | 1 |
| 40 | 2 | 0 | 17 | 0 | 26 | 8 | 1 |
| 41 | 10 | 110 | 0 | 0 | 24 | 8 | 1 |

The following CLI displays the FXOS port manager switch VLANs output:

```
firepower-3140(local-mgmt)# show portmanager switch vlans
```

| VLAN | FDB-mode | Ports | Tag | MAC-Learning |
|------|----------|-----------|-----------------------|--------------|
| 1 | FID | 0/17,19 | pop_outer_tag | Control |
| 2 | FID | 0/1-16,18 | outer_tag0_inner_tag1 | Control |
| | | 0/20 | pop_outer_tag | |
| 3 | FID | 0/1-16,18 | outer_tag0_inner_tag1 | Control |
| 4 | FID | 0/1-16,18 | outer_tag0_inner_tag1 | Control |
| 5 | FID | 0/1-16,18 | outer_tag0_inner_tag1 | Control |
| 6 | FID | 0/1-16,18 | outer_tag0_inner_tag1 | Control |
| 7 | FID | 0/1-16,18 | outer_tag0_inner_tag1 | Control |
| 8 | FID | 0/1-16,18 | outer_tag0_inner_tag1 | Control |

The following CLI helps you to to check port-channel interface summary:

```

firepower-3140(local-mgmt)# show por
portchannel portmanager

firepower-3140(local-mgmt)# show portchannel summary
Flags: D - Down          P - Up in port-channel (members)
I - Individual  H - Hot-standby (LACP only)
s - Suspended   r - Module-removed
S - Switched   R - Routed
U - Up (port-channel)
M - Not in use. Min-links not met
-----
Group Port-      Type      Protocol  Member Ports
      Channel
-----
3     Po3 (U)     Eth       LACP      Eth1/3 (P)
2     Po2 (U)     Eth       LACP      Eth1/2 (P)

LACP KeepAlive Timer:
-----
      Channel  PeerKeepAliveTimerFast
-----
3     Po3 (U)      False
2     Po2 (U)      False

Cluster LACP Status:
-----
      Channel  ClusterSpanned  ClusterDetach  ClusterUnitID  ClusterSysID
-----
3     Po3 (U)      False          False          0
2     Po2 (U)      False          False          0
</pre>

```

The following CLI displays the port-channel load-balancing method:

```

firepower-3140(local-mgmt)# show portchannel load-balance
PortChannel Load-Balancing Configuration:
      src-dst ip-l4port
PortChannel Load-Balancing Configuration Used Per-Protocol:
Non-IP: src-dst mac
      IP: src-dst ip-l4port
</pre>

```

The following CLI displays the status of FXOS system processes:

```

firepower-3140(local-mgmt)# show pmon state

```

| SERVICE NAME | STATE | RETRY (MAX) | EXITCODE | SIGNAL | CORE |
|-----------------------|---------|-------------|----------|--------|-------|
| ----- | ----- | ----- | ----- | ----- | ----- |
| svc_sam_dme | running | 0 (4) | 0 | 0 | no |
| svc_sam_dcosAG | running | 0 (4) | 0 | 0 | no |
| svc_sam_portAG | running | 0 (4) | 0 | 0 | no |
| svc_sam_statsAG | running | 0 (4) | 0 | 0 | no |
| httpd.sh | running | 0 (4) | 0 | 0 | no |
| svc_sam_sessionmgrAG | running | 0 (4) | 0 | 0 | no |
| sam_core_mon | running | 0 (4) | 0 | 0 | no |
| svc_sam_svcmonAG | running | 0 (4) | 0 | 0 | no |
| svc_sam_serviceOrchAG | running | 0 (4) | 0 | 0 | no |
| svc_sam_appAG | running | 0 (4) | 0 | 0 | no |
| svc_sam_envAG | running | 0 (4) | 0 | 0 | no |
| svc_sam_npuAG | running | 0 (4) | 0 | 0 | no |
| svc_sam_eventAG | running | 0 (4) | 0 | 0 | no |

The following CLI displays switch hardware TCAM rules dump in vcam-tti stage matching ethernet 1/1 port:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
ethernet 1 1
RULE_ID    VLAN    SRC_PORT  PC_ID    SRC_ID    MODE    PAK_CNT
1          20      0 1       0        101     0       151
```

The following CLI displays switch hardware TCAM rules dump in vtcam-tti stage matching vlan 0:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
vlan 0
RULE_ID    VLAN    SRC_PORT  PC_ID    SRC_ID    MODE    PAK_CNT
1          2       0        17       0        17      0       1709
2          3       0        19       0        19      0       1626
3          4       0        16       0         0      0         0
4          5       0        15       0         0      0         0
5          6       0        14       0         0      0         0
6          7       0        13       0         0      0         0
7          8       0        12       0         0      0         0
8          9       0        11       0         0      0         0
9         10       0        10       0         0      0         0
10         11       0         9       0         0      0         0
11         12       0         8       0         0      0         0
12         13       0         7       0         0      0         0
13         14       0         6       0         0      0         0
14         15       0         5       0         0      0         0
15         16       0         4       0         0      0         0
16         17       0         3       0         0      0         0
17         18       0         2       0         0      0         0
18         19       0         1       0         0      0         0
19         20       0         1       0        101     0        166
20         21       0         2       0        102     0       1597
21         22       0         3       0        103     0         0
22         23       0         4       0        104     0         0
23         24       0         5       0        105     0         0
24         25       0         6       0        106     0         0
25         26       0         7       0        107     0         0
26         27       0         8       0        108     0         0
27         28       0         9       0        109     0         0
28         29       0        10       0        110     0         0
29         30       0        11       0        111     0         0
30         31       0        12       0        112     0         0
31         32       0        13       0        159     0         0
32         33       0        14       0        158     0         0
33         34       0        15       0        157     0         0
34         35       0        16       0        156     0         0
35          1       0        17       0         0      0         0
```

The following CLI displays detailed information about hardware MAC-filter / EM stage rules:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware mac-filter
detail
EM Entry-No : 1

VLAN : 0
SRC_PORT : 17
PC_ID : 0
SRC_ID : 17
DST_PORT : 19
HW_ID : 3072
ACT_CMD : 0
PCL_ID : 1
REDIRECT_CMD : 1
BYPASS_BRG : 1
CND_INDEX : 3074
```

```

PACKET_COUNT      :      1977
DMAC               : 00:00:00:00:00:00

```

```
EM Entry-No      :      2

```

```

VLAN              :      0
SRC_PORT          :      19
PC_ID             :      0
SRC_ID            :      19
DST_PORT          :      17
HW_ID             :     3074
ACT_CMD           :      0
PCL_ID            :      1
REDIRECT_CMD      :      1
BYPASS_BRG        :      1
CND_INDEX         :     3075
PACKET_COUNT      :      1858
DMAC              : 00:00:00:00:00:00

```

The following CLI displays switch hardware TCAM rules dump in mac-filter stage matching ethernet 1/9 port:

```

firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware mac-filter
ethernet 1 9
VLAN    SRC_PORT  PC_ID  SRC_ID  DST_PORT  PKT_CNT  DMAC
1       0         9      0       109      1536     0 1:80:c2:0:0:2

```

The following CLI displays detailed information about software MAC-filter:

```

firepower-3140(local-mgmt)# show portmanager switch forward-rules software mac-filter
detail
VLAN    SRC_PORT  PORTCHANNEL_ID  DST_PORT  FLAGS  MODE  DMAC
1       0         17              0         19     26    8 0:0:0:0:0:0
2       0         9               0         1536    2    5 1:80:c2:0:0:2
3      104         0               0         4      24    8 0:0:0:0:0:0
4       0         7               0         1536    2    5 1:80:c2:0:0:2
5      101         0               0         1      24    8 0:0:0:0:0:0
6       0         1               0         1536    2    5 1:80:c2:0:0:2
7       0         3               0         1536    2    5 1:80:c2:0:0:2
8      106         0               0         6      24    8 0:0:0:0:0:0
9      158         0               0         14     24    8 0:0:0:0:0:0
10      0        13               0         1536    2    5 1:80:c2:0:0:2
11      0        14               0         1536    2    5 1:80:c2:0:0:2
12      0         6               0         1536    2    5 1:80:c2:0:0:2
13      0         8               0         1536    2    5 1:80:c2:0:0:2
14     112         0               0         12     24    8 0:0:0:0:0:0
15     107         0               0         7      24    8 0:0:0:0:0:0
16      0        19               0         17     26    8 0:0:0:0:0:0
17      0        12               0         1536    2    5 1:80:c2:0:0:2
18      0         5               0         1536    2    5 1:80:c2:0:0:2
19     102         0               0         2      24    8 0:0:0:0:0:0
20     156         0               0         16     24    8 0:0:0:0:0:0
21     103         0               0         3      24    8 0:0:0:0:0:0
22      0        11               0         1536    2    5 1:80:c2:0:0:2
23     157         0               0         15     24    8 0:0:0:0:0:0
24     111         0               0         11     24    8 0:0:0:0:0:0
25      0        10               0         1536    2    5 1:80:c2:0:0:2
26     108         0               0         8      24    8 0:0:0:0:0:0
27     159         0               0         13     24    8 0:0:0:0:0:0
28     110         0               0         10     24    8 0:0:0:0:0:0
29     105         0               0         5      24    8 0:0:0:0:0:0

```

```

30      0      2      0      1536      2      5      1:80:c2:0:0:2
31      0      4      0      1536      2      5      1:80:c2:0:0:2
32      0     16      0      1536      2      5      1:80:c2:0:0:2
33     109      0      0          9     24      8      0:0:0:0:0:0
34      0     15      0      1536      2      5      1:80:c2:0:0:2

```

The following CLI displays switch software DB rules in mac-filter stage matching ethernet1/9 port:

```

firepower-3140(local-mgmt)# show portmanager switch forward-rules software mac-filter
ethernet 1 9
VLAN   SRC_PORT   PORTCHANNEL_ID  DST_PORT   FLAGS   MODE   DMAC
1       0           9              0          1536    2      5      1:80:c2:0:0:2

```

The following CLI displays detailed information about switch bridge engine packet drops:

```

firepower-3140(local-mgmt)# show portmanager switch counters bridge
Bridge Ingress Drop Counter: 2148
No Bridge Ingress Drop

```

The following CLI displays details on hardware switch packet counters:

```

firepower-3140(local-mgmt)# show portmanager switch counters packet-trace

```

| Counter | Description |
|------------------------|---|
| goodOctetsRcv | Number of ethernet frames received that are not bad ethernet frames or MAC Control pkts |
| badOctetsRcv | Sum of lengths of all bad ethernet frames received |
| gtBrgInFrames | Number of packets received |
| gtBrgVlanIngFilterDisc | Number of packets discarded due to VLAN Ingress Filtering |
| gtBrgSecFilterDisc | Number of packets discarded due to Security Filtering measures |
| gtBrgLocalPropDisc | Number of packets discarded due to reasons other than VLAN ingress and Security filtering |
| dropCounter | Ingress Drop Counter |
| outUcFrames | Number of unicast packets transmitted |
| outMcFrames | Number of multicast packets transmitted. This includes registered multicasts, unregistered multicasts and unknown unicast packets |
| outBcFrames | Number of broadcast packets transmitted |
| brgEgrFilterDisc | Number of IN packets that were Bridge Egress filtered |
| txqFilterDisc | Number of IN packets that were filtered due to TxQ congestion |
| outCtrlFrames | Number of out control packets (to cpu, from cpu and to analyzer) |
| egrFrwDropFrames | Number of packets dropped due to egress forwarding restrictions |
| goodOctetsSent | Sum of lengths of all good ethernet frames sent from this MAC |

| Counter | Source port- 0/0 | Destination port- 0/0 |
|------------------------|------------------|-----------------------|
| goodOctetsRcv | --- | --- |
| badOctetsRcv | --- | --- |
| Ingress counters | | |
| gtBrgInFrames | 6650 | 6650 |
| gtBrgVlanIngFilterDisc | 0 | 0 |
| gtBrgSecFilterDisc | 0 | 0 |
| gtBrgLocalPropDisc | 0 | 0 |
| dropCounter | 2163 | Only for source-port |
| Egress counters | | |
| outUcFrames | 0 | 0 |
| outMcFrames | 2524 | 2524 |
| outBcFrames | 1949 | 1949 |

```

brgEgrFilterDisc          14          14
txqFilterDisc             0           0
outCtrlFrames             0           0
egrFrwDropFrames         0           0
goodOctetsSent            ---          ---      #

```

The following CLI displays detailed informatin about the switch traffic for CPU:

```
firepower-3140(local-mgmt)# show portmanager switch traffic cpu
```

```

Dev/RX queue  packets    bytes
-----
0/0           0          0
0/1           0          0
0/2           0          0
0/3           0          0
0/4           0          0
0/5           0          0
0/6           0          0
0/7           0          0      #

```

The following CLI displays details on hardware switch port traffic:

```
firepower-3140(local-mgmt)# show portmanager switch traffic port
```

```

max-rate - pps that the port allow with packet size=64
actual-tx-rate - pps that egress the port (+ % from 'max')
actual-rx-rate - pps that ingress the port(+ % from 'max')

```

```

Dev/Port    max-rate    actual-tx-rate    actual-rx-rate
-----
0/1         1488095    (0%)---          (0%)---
0/2         1488095    (0%)---          (0%)---
0/3         14880     (0%)---          (0%)---
0/4         14880     (0%)---          (0%)---
0/5         14880     (0%)---          (0%)---
0/6         14880     (0%)---          (0%)---
0/7         14880     (0%)---          (0%)---
0/8         14880     (0%)---          (0%)---
0/9         14880952   (0%)---          (0%)---
0/10        14880952   (0%)---          (0%)---
0/11        14880952   (0%)---          (0%)---
0/12        14880952   (0%)---          (0%)---
0/13        14880952   (0%)---          (0%)---
0/14        14880952   (0%)---          (0%)---
0/15        1488095    (0%)---          (0%)---
0/16        1488095    (0%)---          (0%)---
0/17        14880952   (0%)---          (0%)---
0/18        74404761   (0%)---          (0%)---
0/19        37202380   (0%)---          (0%)---
0/20        37202380   (0%)---          (0%)---

```

The following CLI displays detailed information about SFP-FEC Counters matching ethernet 1/13 port:

```

firepower-3140(local-mgmt)# show portmanager counters ethernet 1 13
  Good Octets Received      : 2153
  Bad Octets Received      : 0
  MAC Transmit Error       : 0
  Good Packets Received    : 13
  Bad packets Received     : 0

```

```

BRDC Packets Received           : 0
MC Packets Received             : 13
.....
.....
txqFilterDisc                   : 0
linkchange                      : 1
FcFecRxBlocks                   : 217038081
FcFecRxBlocksNoError           : 217038114
FcFecRxBlocksCorrectedError    : 0
FcFecRxBlocksUnCorrectedError  : 0
FcFecRxBlocksCorrectedErrorBits : 0
FcFecRxBlocksCorrectedError0   : 0
FcFecRxBlocksCorrectedError1   : 0
FcFecRxBlocksCorrectedError2   : 0
FcFecRxBlocksCorrectedError3   : 0
FcFecRxBlocksUnCorrectedError0 : 0
FcFecRxBlocksUnCorrectedError1 : 0
FcFecRxBlocksUnCorrectedError2 : 0
FcFecRxBlocksUnCorrectedError3 : 0

```

The following CLI displays detailed information about SFP-FEC Counters matching ethernet 1/14 port:

```

firepower-3140(local-mgmt)# show portmanager counters ethernet 1 14
  Good Octets Received           : 2153
  Bad Octets Received            : 0
  MAC Transmit Error             : 0
  Good Packets Received          : 13
  Bad packets Received           : 0
  BRDC Packets Received          : 0
  MC Packets Received            : 13
  ....
  ....
  txqFilterDisc                  : 0
  linkchange                     : 1
  RsFeccorrectedFecCodeword      : 0
  RsFecuncorrectedFecCodeword    : 10
  RsFecsymbolError0              : 5
  RsFecsymbolError1              : 0
  RsFecsymbolError2              : 0
  RsFecsymbolError3              : 0

```

The following CLI displays detailed information on the Digital Optical Monitoring information matching ethernet 1/5 port:

```

firepower-4245(local-mgmt)# show portmanager port-info ethernet 1 5
  ....
  ....
  DOM info:
  =====:

  Status/Control Register: 0800
    RX_LOS State: 0
    TX_FAULT State: 0
  Alarm Status: 0000
  No active alarms
  Warning Status: 0000
  No active warnings

  THRESHOLDS
                                high alarm   high warning   low warning   low alarm

```

| | | | | | |
|----------------|----|----------|----------|----------|----------|
| Temperature | C | +075.000 | +070.000 | +000.000 | -05.000 |
| Voltage | V | 003.6300 | 003.4650 | 003.1350 | 002.9700 |
| Bias Current | mA | 012.0000 | 011.5000 | 002.0000 | 001.0000 |
| Transmit power | mW | 034.6740 | 017.3780 | 002.5120 | 001.0000 |
| Receive power | mW | 034.6740 | 017.3780 | 001.3490 | 000.5370 |

Environmental Information - raw values

Temperature: 38.84 C

Supply voltage: 33703 in units of 100uVolt

Tx bias: 3499 in units of 2uAmp

Tx power: 0.1 dBm (10251 in units of 0.1 uW)

Rx power: -0.9 dBm (8153 in units of 0.1 uW)

DOM (256 bytes of raw data in hex)

```

=====
0x0000 : 4b 00 fb 00 46 00 00 00 8d cc 74 04 87 5a 7a 76
0x0010 : 17 70 01 f4 16 76 03 e8 87 72 03 e8 43 e2 09 d0
0x0020 : 87 72 02 19 43 e2 05 45 00 00 00 00 00 00 00 00
0x0030 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x0040 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x0050 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 86
0x0060 : 26 54 83 a7 0d ab 28 0b 1f d9 00 00 00 00 08 00
0x0070 : 00 00 03 00 00 00 00 00 08 f3 00 00 00 00 00 01
0x0080 : 49 4e 55 49 41 43 53 45 41 41 31 30 2d 33 33 38
0x0090 : 38 2d 30 31 56 30 31 20 01 00 46 00 00 00 00 e3
0x00a0 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x00b0 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x00c0 : 53 46 50 2d 31 30 2f 32 35 47 2d 43 53 52 2d 53
0x00d0 : 20 20 20 20 30 38 00 00 00 00 00 00 00 00 00 d1
0x00e0 : 1e 20 2a 2a 31 34 29 36 00 00 00 00 00 00 00 00
0x00f0 : 00 00 00 00 00 56 00 00 ff ff ff ff 00 00 00 cf
=====

```

PHY Data:

| PAGE | IFC | OFFSET | VALUE | PAGE | IFC | OFFSET | VALUE |
|------|-----|--------|-------|------|-----|--------|-------|
| ---- | --- | ----- | ----- | ---- | --- | ----- | ----- |

The following CLI displays detailed information about the parameters set for the packet capture:

```

firepower-3140(local-mgmt)# show portmanager switch pktpcap-rules software
Software DB rule:1
Slot= 1
Interface= 12
Breakout-port= 0
Protocol= 6
Ethertype= 0x0000
Filter_key= 0x00000040
Session= 1
Vlan= 0
SrcPort= 0
DstPort= 0
SrcIp= 0.0.0.0
DstIp= 0.0.0.0
SrcIpv6= ::
DestIpv6= ::
SrcMacAddr= 00:00:00:00:00:00
DestMacAddr= 00:00:00:00:00:00

```

The following CLI displays detailed information on the FXOS port manager switch hardware TCAM rules:


```
firepower-3140(local-mgmt)# show portmanager switch pktcap-rules hardware
Hardware DB rule:1
Hw_index= 15372
Rule_id= 10241
Cnc_index= 1
Packet_count= 0
Slot= 1
Interface= 12
Protocol= 6
Ethertype= 0x0000
Vlan= 0
SrcPort= 0
DstPort= 0
SrcIp= 0.0.0.0
DstIp= 0.0.0.0
SrcIpv6= ::
DestIpv6= ::
SrcMacAddr= 00:00:00:00:00:00
DestMacAddr= 00:00:00:00:00:00
```

The following displays detailed information about the QOS functionality:

```
firepower(local-mgmt)# show portmanager switch qos-rule policer counters
Policer_type    green(pass_count)    yellow(pass_count)    red(drop_count)
-----
OSPF
780
Policer_type    green(pass_count)    yellow(pass_count)    red(drop_count)
-----
CCL_CLU
Policer_type    green(pass_count)    yellow(pass_count)    red(drop_count)
-----
BFD
Policer_type    green(pass_count)    yellow(pass_count)    red(drop_count)
-----
HA
Policer_type    green(pass_count)    yellow(pass_count)    red(drop_count)
-----
CCL_CONTROL
```

| Policer_type | green(pass_count) | yellow(pass_count) | red(drop_count) |
|--------------|-------------------|--------------------|-----------------|
| OSPF | 102025351 | 17832 | 590 |
| CCL_CLU | 0 | 0 | 0 |
| BFD | 61343307 | 0 | 0 |
| HA | 0 | 0 | 0 |
| CCL_CONTROL | 0 | 0 | 0 |

The following CLI verifies if the high priority traffic is hitting the TCAM:

```
firepower(local-mgmt)# show portmanager switch qos-rule counters
Rule_no  Rule_id  Rule_type  pass_count
-----
1        9218    SW_QOS_BFD  0
Rule_no  Rule_id  Rule_type  pass_count
-----
2        9216    SW_QOS_OSPF  102633941
Rule_no  Rule_id  Rule_type  pass_count
-----
3        9217    SW_QOS_BFD  61343307
```

The following CLI displays the CPU statistics as per queue per device matching ethernet 1/10 port:

```
firepower(local-mgmt)# show queuing interface ethernet 1 10
Queue    Traffic-type    Scheduler-type    oper-bandwidth    Destination
-----
3        Data            WRR                100                Application
4        CCL-CLU         SP                 0                  Application
```

```

5          BFD          SP          0          Application
6          OSPF         SP          0          Application
7  CCL-CONTROL/HA/LACP_Tx  SP          0          Application
0  packet-capture      N/A          0          CPU
7          LACP_Rx      N/A          0          CPU
Port 1/10 Queue Statistics:
Queue 0:
  Number of packets passed :          0
  Number of packets dropped:          0
Queue 1:
  Number of packets passed :          0
  Number of packets dropped:          0
Queue 2:
  Number of packets passed :          0
  Number of packets dropped:          0
Queue 3:
  Number of packets passed :      466420167
  Number of packets dropped:          0
Queue 4:
  Number of packets passed :          0
  Number of packets dropped:          0
Queue 5:
  Number of packets passed :          0
  Number of packets dropped:          0
Queue 6:
  Number of packets passed :      41536261
  Number of packets dropped:          0
Queue 7:
  Number of packets passed :          912
  Number of packets dropped:          0
CPU Statistics:
Queue 2:
  Number of packets passed :      180223
  Number of packets dropped:          0
Queue 7:
  Number of packets passed :          1572
  Number of packets dropped:          0

```

The following CLI displays the CPU statistics as per queue per device matching internal 1/1 port:

```

firepower(local-mgmt)# show queuing interface internal 1 1
Queue      Traffic-type      Scheduler-type  oper-bandwidth  Destination
-----
3          Data          WRR            100            Application
4          CCL-CLU          SP             0              Application
5          BFD            SP             0              Application
6          OSPF          SP             0              Application
7  CCL-CONTROL/HA/LACP_Tx  SP             0              Application
0  packet-capture      N/A            0              CPU
7          LACP_Rx      N/A            0              CPU
Port 1/18 Queue Statistics:
Queue 0:
  Number of packets passed :          0
  Number of packets dropped:          0
Queue 1:
  Number of packets passed :          0
  Number of packets dropped:          0
Queue 2:
  Number of packets passed :          0
  Number of packets dropped:          0
Queue 3:
  Number of packets passed :          17

```

```

    Number of packets dropped:          0
Queue 4:
    Number of packets passed :          0
    Number of packets dropped:          0
Queue 5:
    Number of packets passed :          0
    Number of packets dropped:          0
Queue 6:
    Number of packets passed :        5151
    Number of packets dropped:          0
Queue 7:
    Number of packets passed :        17345
    Number of packets dropped:          0
CPU Statistics:
Queue 2:
    Number of packets passed :        180223
    Number of packets dropped:          0
Queue 7:
    Number of packets passed :         1572
    Number of packets dropped:          0
Note:The CPU statistics are per Queue per Device

```

The following CLI displays detailed information about dump AP log option :

```

firepower-3110(local-mgmt)# dump portmanager switch ap-log
requested log has been dumped to /opt/cisco/platform/logs/portmgr.out*

firepower-3110(local-mgmt)# dump portmanager switch cyclic-log
requested log has been dumped to /opt/cisco/platform/logs/portmgr.out*

```

The following CLI displays detailed information on enabling or disabling verbose logging for port manager:

```

firepower-3110(local-mgmt)# debug portmanager switch
all  Enable or Disable verbose logging for switch

firepower-3110(local-mgmt)# debug portmanager switch all
firepower-3110(local-mgmt)#

firepower-3110(local-mgmt)# no debug portmanager switch all
firepower-3110(local-mgmt)#

```

The following CLI displays detailed information on port-based packet drops for eight traffic classes/queues:

```

firepower-3110(local-mgmt)# show portmanager switch tail-drop-allocated buffers all
-----

```

| Per Port and Traffic Class | | | | | | | | |
|----------------------------|----------|-----|-----|-----|-----|-----|-----|-----|
| Port | Per port | TC0 | TC1 | TC2 | TC3 | TC4 | TC5 | TC6 |
| 0/1 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |
| 0/2 | 15 | 15 | 15 | 15 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |
| 0/3 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |
| 0/4 | 80 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |

```

|80      |
0/5 |0      |0      |0      |0      |0      |0      |0      |0
|0      |
0/6 |0      |0      |0      |0      |0      |0      |0      |0
|0      |
0/7 |200     |25     |25     |50     |0      |0      |25     |50
|25     |
0/8 |0      |0      |0      |0      |0      |0      |0      |0
|0      |
-----

```

The following CLI displays dropped packet counts due to tti-lookup0:

```
firepower-3110(local-mgmt)# show portmanager switch default-rule-drop-counter tti-lookup0
```

```

Rule_id      cnc_index      packet_count
-----
1            1              4

```

The following CLI displays dropped packet counts due to ipcl-lookup0:

```
firepower-3110(local-mgmt)# show portmanager switch default-rule-drop-counter ipcl-lookup0
```

```

Rule_id      cnc_index      packet_count
-----
4096         0              114

```

Connect Local-Mgmt Troubleshooting Commands for the Secure Firewall 4200 in Appliance Mode

In addition to the existing debugging commands, CLIs specific to Secure Firewall 3100 are explained in this section below.

Use the following connect local-mgmt mode FXOS CLI commands to troubleshoot issues with your Secure Firewall 3100 in Appliance mode. To access connect local-mgmt mode, enter:

FPR 4200# connect local-mgmt

show portmanager

Displays detailed information about switched, packets, SFP-FEC counters, digital optical monitoring, QOS functionality, CPSS AP, and Cyclic log dumps.

For example:

The following CLI displays the FXOS port manager switch hardware TCAM rules dump in vtcam-tti:

```

firepower(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
      RULE_ID  VLAN  NUM_MPLS_LABELS  SRC_PORT  PC_ID  SRC_ID  MODE  PAK_CNT
1         2      0         0         10      0      10      0      1951
2         3      0         0         14      0      14      0         19
3         4      0         0          9      0       9      0      227505
4         5      0         0         13      0      13      0      103587
5         6      0         0          8      0       0      0         0
6         7      0         0          7      0       0      0         0
7         8      0         0          6      0       0      0         0
8         9      0         0          5      0       0      0         0
9        10      0         0          4      0       0      0         0

```

| | | | | | | | | |
|----|------|---|---|----|---|-----|---|------|
| 10 | 11 | 0 | 0 | 3 | 0 | 0 | 0 | 0 |
| 11 | 12 | 0 | 0 | 2 | 0 | 0 | 0 | 0 |
| 12 | 13 | 0 | 0 | 1 | 0 | 0 | 0 | 607 |
| 13 | 14 | 0 | 0 | 44 | 0 | 0 | 0 | 0 |
| 14 | 15 | 0 | 0 | 40 | 0 | 0 | 0 | 0 |
| 15 | 16 | 0 | 0 | 36 | 0 | 0 | 0 | 0 |
| 16 | 17 | 0 | 0 | 32 | 0 | 0 | 0 | 0 |
| 17 | 30 | 0 | 0 | 1 | 0 | 101 | 1 | 2120 |
| 18 | 18 | 0 | 0 | 1 | 0 | 101 | 0 | 306 |
| 19 | 19 | 0 | 0 | 2 | 0 | 102 | 0 | 2429 |
| 20 | 20 | 0 | 0 | 3 | 0 | 103 | 0 | 0 |
| 21 | 21 | 0 | 0 | 4 | 0 | 104 | 0 | 0 |
| 22 | 22 | 0 | 0 | 5 | 0 | 105 | 0 | 0 |
| 23 | 23 | 0 | 0 | 6 | 0 | 106 | 0 | 0 |
| 24 | 24 | 0 | 0 | 7 | 0 | 107 | 0 | 0 |
| 25 | 25 | 0 | 0 | 8 | 0 | 108 | 0 | 0 |
| 26 | 26 | 0 | 0 | 32 | 0 | 117 | 0 | 0 |
| 27 | 27 | 0 | 0 | 36 | 0 | 121 | 0 | 0 |
| 28 | 28 | 0 | 0 | 40 | 0 | 125 | 0 | 0 |
| 29 | 29 | 0 | 0 | 44 | 0 | 129 | 0 | 0 |
| 30 | 1 | 0 | 0 | 9 | 0 | 0 | 0 | 1875 |
| 31 | 8193 | 0 | 1 | 0 | 0 | 0 | 0 | 0 |
| 32 | 8194 | 0 | 2 | 0 | 0 | 0 | 0 | 0 |
| 33 | 8195 | 0 | 3 | 0 | 0 | 0 | 0 | 0 |
| 34 | 8196 | 0 | 4 | 0 | 0 | 0 | 0 | 0 |
| 35 | 8197 | 0 | 5 | 0 | 0 | 0 | 0 | 0 |
| 36 | 8198 | 0 | 6 | 0 | 0 | 0 | 0 | 0 |

The following CLI displays switch hardware TCAM rules dump in vtcam-tti stage matching vlan 0:

```
firepower(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
      RULE_ID  VLAN  NUM_MPLS_LABELS  SRC_PORT  PC_ID  SRC_ID  MODE  PAK_CNT
1         2      0         0         10      0      10      0    1961
2         3      0         0         14      0      14      0      19
3         4      0         0          9      0       9      0   227517
4         5      0         0         13      0      13      0  103683
5         6      0         0          8      0       0      0      0
6         7      0         0          7      0       0      0      0
7         8      0         0          6      0       0      0      0
8         9      0         0          5      0       0      0      0
9        10      0         0          4      0       0      0      0
10        11      0         0          3      0       0      0      0
11        12      0         0          2      0       0      0      0
12        13      0         0          1      0       0      0    617
13        14      0         0         44      0       0      0      0
14        15      0         0         40      0       0      0      0
15        16      0         0         36      0       0      0      0
16        17      0         0         32      0       0      0      0
17        30      0         0          1      0      101      1   2156
18        18      0         0          1      0      101      0    306
19        19      0         0          2      0      102      0   2466
20        20      0         0          3      0      103      0      0
21        21      0         0          4      0      104      0      0
22        22      0         0          5      0      105      0      0
23        23      0         0          6      0      106      0      0
24        24      0         0          7      0      107      0      0
25        25      0         0          8      0      108      0      0
26        26      0         0         32      0      117      0      0
27        27      0         0         36      0      121      0      0
28        28      0         0         40      0      125      0      0
29        29      0         0         44      0      129      0      0
30         1      0         0          9      0       0      0   1875
31       8193      0         1          0      0       0      0      0
```

```

32      8194      0      2      0      0      0      0      0
33      8195      0      3      0      0      0      0      0
34      8196      0      4      0      0      0      0      0
35      8197      0      5      0      0      0      0      0
36      8198      0      6      0      0      0      0      0

```

The following CLI displays switch hardware TCAM rules dump in mac-filter stage matching ethernet 1/9 port:

```

firepower(local-mgmt)# show portmanager switch forward-rules hardware mac-filter
      VLAN      SRC_PORT      PC_ID      SRC_ID      DST_PORT      PKT_CNT      DMAC
1         0         44         0         129         1536         0 1:80:c2:0:0:2
2         0         44         0         129         1536         0 ff:ff:ff:ff:ff:ff
3         0          2         0         102         1536         0 ba:db:ad:f0:2:8f
4         0          4         0         104         1536         0 ff:ff:ff:ff:ff:ff
5         0          4         0         104         1536         0 1:80:c2:0:0:2
6         0          5         0         105         1536         0 1:80:c2:0:0:2
7         0          5         0         105         1536         0 ff:ff:ff:ff:ff:ff
8         0         13         0          13           9      103735 0:0:0:0:0:0
9         0         32         0         117         1536         0 ba:db:ad:f0:2:9e
10        0          7         0         107         1536         0 ff:ff:ff:ff:ff:ff
11        0          7         0         107         1536         0 1:80:c2:0:0:2
12        0          6         0         106         1536         0 1:80:c2:0:0:2
13        0          6         0         106         1536         0 ff:ff:ff:ff:ff:ff
14        0         14         0          14          10          19 0:0:0:0:0:0
15        0         10         0          10          14      1979 0:0:0:0:0:0
16        0         44         0         129         1536         0 ba:db:ad:f0:2:a1
17        0          9         0          9          13     1227537 0:0:0:0:0:0
18        0          8         0         108         1536         0 1:80:c2:0:0:2
19        0          8         0         108         1536         0 ff:ff:ff:ff:ff:ff
20        0          1         0         101         1536         0 ff:ff:ff:ff:ff:ff
21        0          1         0         101         1536         0 1:80:c2:0:0:2
22        0          3         0         103         1536         0 1:80:c2:0:0:2
23        0          1         0         101         1536      2183 1:0:0:0:0:0
24        0          3         0         103         1536         0 ff:ff:ff:ff:ff:ff
25        0          2         0         102         1536      23  ff:ff:ff:ff:ff:ff
26        0          2         0         102         1536         0 1:80:c2:0:0:2
27        0         32         0         117         1536         0 ff:ff:ff:ff:ff:ff
28        0         32         0         117         1536         0 1:80:c2:0:0:2
29        0         40         0         125         1536         0 ff:ff:ff:ff:ff:ff
30        0         40         0         125         1536         0 1:80:c2:0:0:2
31        0          7         0         107         1536         0 ba:db:ad:f0:2:94
32        0          5         0         105         1536         0 ba:db:ad:f0:2:92
33        0         36         0         121         1536         0 1:80:c2:0:0:2
34        0          4         0         104         1536         0 ba:db:ad:f0:2:91
35        0         36         0         121         1536         0 ff:ff:ff:ff:ff:ff
36        0          8         0         108         1536         0 ba:db:ad:f0:2:95
37        0          6         0         106         1536         0 ba:db:ad:f0:2:93
38        0          3         0         103         1536         0 ba:db:ad:f0:2:90
39        0         36         0         121         1536         0 ba:db:ad:f0:2:9f
40        0          1         0         101         1536      32  ba:db:ad:f0:2:8e
41        0         40         0         125         1536         0 ba:db:ad:f0:2:a0

```

The following CLI displays detailed information about software MAC-filter:

```

firepower-4225(local-mgmt)# show portmanager switch forward-rules software mac-filter
      NATIVE_VLAN      VLAN      SRC_PORT      PORTCHANNEL_ID      DST_PORT      FLAGS      MODE      DMAC
1         0         106          6              0         1536         2         5
1:80:c2:0:0:2
2         0         105          5              0         1536         2         5
ff:ff:ff:ff:ff:ff
3         0         105          5              0         1536         2         5

```

| | | | | | | | |
|-------------------|---|-----|----|---|------|----|---|
| 1:80:c2:0:0:2 | | | | | | | |
| 4 | 0 | 121 | 0 | 0 | 36 | 24 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 5 | 0 | 106 | 6 | 0 | 1536 | 2 | 5 |
| ff:ff:ff:ff:ff:ff | | | | | | | |
| 6 | 0 | 121 | 36 | 0 | 1536 | 2 | 5 |
| 1:80:c2:0:0:2 | | | | | | | |
| 7 | 0 | 117 | 32 | 0 | 1536 | 2 | 5 |
| 1:80:c2:0:0:2 | | | | | | | |
| 8 | 0 | 125 | 40 | 0 | 1536 | 2 | 5 |
| ff:ff:ff:ff:ff:ff | | | | | | | |
| 9 | 0 | 129 | 0 | 0 | 44 | 24 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 10 | 0 | 117 | 32 | 0 | 1536 | 2 | 5 |
| ff:ff:ff:ff:ff:ff | | | | | | | |
| 11 | 0 | 103 | 3 | 0 | 1536 | 2 | 5 |
| 1:80:c2:0:0:2 | | | | | | | |
| 12 | 0 | 102 | 2 | 0 | 1536 | 2 | 5 |
| ff:ff:ff:ff:ff:ff | | | | | | | |
| 13 | 0 | 117 | 0 | 0 | 32 | 24 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 14 | 0 | 107 | 0 | 0 | 7 | 24 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 15 | 0 | 101 | 1 | 0 | 1536 | 2 | 5 |
| ba:db:ad:f0:2:8e | | | | | | | |
| 16 | 0 | 107 | 7 | 0 | 1536 | 2 | 5 |
| ff:ff:ff:ff:ff:ff | | | | | | | |
| 17 | 0 | 106 | 6 | 0 | 1536 | 2 | 5 |
| ba:db:ad:f0:2:93 | | | | | | | |
| 18 | 0 | 105 | 0 | 0 | 5 | 24 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 19 | 0 | 102 | 0 | 0 | 2 | 24 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 20 | 0 | 104 | 4 | 0 | 1536 | 2 | 5 |
| ba:db:ad:f0:2:91 | | | | | | | |
| 21 | 0 | 107 | 7 | 0 | 1536 | 2 | 5 |
| ba:db:ad:f0:2:94 | | | | | | | |
| 22 | 0 | 129 | 44 | 0 | 1536 | 2 | 5 |
| 1:80:c2:0:0:2 | | | | | | | |
| 23 | 0 | 102 | 2 | 0 | 1536 | 2 | 5 |
| 1:80:c2:0:0:2 | | | | | | | |
| 24 | 0 | 121 | 36 | 0 | 1536 | 2 | 5 |
| ff:ff:ff:ff:ff:ff | | | | | | | |
| 25 | 0 | 1 | 13 | 0 | 9 | 26 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 26 | 0 | 108 | 8 | 0 | 1536 | 2 | 5 |
| 1:80:c2:0:0:2 | | | | | | | |
| 27 | 0 | 101 | 1 | 0 | 1536 | 2 | 5 |
| ff:ff:ff:ff:ff:ff | | | | | | | |
| 28 | 0 | 2 | 10 | 0 | 14 | 26 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 29 | 0 | 101 | 1 | 0 | 1536 | 2 | 5 |
| 1:80:c2:0:0:2 | | | | | | | |
| 30 | 0 | 1 | 9 | 0 | 13 | 26 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 31 | 0 | 129 | 44 | 0 | 1536 | 2 | 5 |
| ff:ff:ff:ff:ff:ff | | | | | | | |
| 32 | 0 | 125 | 0 | 0 | 40 | 24 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 33 | 0 | 108 | 8 | 0 | 1536 | 2 | 5 |
| ba:db:ad:f0:2:95 | | | | | | | |
| 34 | 0 | 2 | 14 | 0 | 10 | 26 | 8 |
| 0:0:0:0:0:0 | | | | | | | |
| 35 | 0 | 129 | 44 | 0 | 1536 | 2 | 5 |

```

ba:db:ad:f0:2:a1
36      0      103      0      0      3      24      8
0:0:0:0:0:0
37      0      104      0      0      4      24      8
0:0:0:0:0:0
38      0      104      4      0      1536     2      5
ff:ff:ff:ff:ff:ff
39      0      107      7      0      1536     2      5
1:80:c2:0:0:2
40      0      104      4      0      1536     2      5
1:80:c2:0:0:2
41      0      101      1      0      1536    18      8
0:0:0:0:0:0
42      0      101      0      0      1      24      8
0:0:0:0:0:0
43      0      108      8      0      1536     2      5
ff:ff:ff:ff:ff:ff
44      0      121     36      0      1536     2      5
ba:db:ad:f0:2:9f
45      0      117     32      0      1536     2      5
ba:db:ad:f0:2:9e
46      0      105      5      0      1536     2      5
ba:db:ad:f0:2:92
47      0      125     40      0      1536     2      5
ba:db:ad:f0:2:a0
48      0      125     40      0      1536     2      5
1:80:c2:0:0:2
49      0      108      0      0      8      24      8
0:0:0:0:0:0
50      0      106      0      0      6      24      8
0:0:0:0:0:0
51      0      103      3      0      1536     2      5
ba:db:ad:f0:2:90
52      0      102      2      0      1536     2      5
ba:db:ad:f0:2:8f
53      0      103      3      0      1536     2      5
ff:ff:ff:ff:ff:ff

```

The following CLI displays detailed information about switch bridge engine packet drops:

```

firepower-4225(local-mgmt)# show portmanager switch counters bridge
Bridge Ingress Drop Counter: 4688
No Bridge Ingress Drop

```

The following CLI displays details on hardware switch packet counters:

```

how portmanager switch counters packet-trace

firepower-4225(local-mgmt)# show portmanager switch counters packet-trace

```

| Counter | Description |
|------------------------|---|
| goodOctetsRcv | Number of ethernet frames received that are not bad ethernet frames or MAC Control pkts |
| badOctetsRcv | Sum of lengths of all bad ethernet frames received |
| gtBrgInFrames | Number of packets received |
| gtBrgVlanIngFilterDisc | Number of packets discarded due to VLAN Ingress Filtering |
| gtBrgSecFilterDisc | Number of packets discarded due to Security Filtering measures |
| gtBrgLocalPropDisc | Number of packets discarded due to reasons other than VLAN ingress and Security filtering |
| dropCounter | Ingress Drop Counter |
| outUcFrames | Number of unicast packets transmitted |


```

outMcFrames          Number of multicast packets transmitted. This includes
                      registered multicasts, unregistered multicasts
                      and unknown unicast packets
outBcFrames          Number of broadcast packets transmitted
brgEgrFilterDisc     Number of IN packets that were Bridge Egress filtered
txqFilterDisc        Number of IN packets that were filtered
                      due to TxQ congestion
outCtrlFrames        Number of out control packets
                      (to cpu, from cpu and to analyzer)
egrFrwDropFrames     Number of packets dropped due to egress
                      forwarding restrictions
goodOctetsSent       Sum of lengths of all good ethernet
                      frames sent from this MAC

```

| Counter | Source port- 0/0 | Destination port- 0/0 |
|------------------------|------------------|-----------------------|
| goodOctetsRcv | --- | --- |
| badOctetsRcv | --- | --- |
| Ingress counters | | |
| gtBrgInFrames | 1341132 | 1341132 |
| gtBrgVlanIngFilterDisc | 0 | 0 |
| gtBrgSecFilterDisc | 0 | 0 |
| gtBrgLocalPropDisc | 0 | 0 |
| dropCounter | 4699 | Only for source-port |
| Egress counters | | |
| outUcFrames | 1329593 | 1329593 |
| outMcFrames | 4594 | 4594 |
| outBcFrames | 2237 | 2237 |
| brgEgrFilterDisc | 9 | 9 |
| txqFilterDisc | 0 | 0 |
| outCtrlFrames | 0 | 0 |
| egrFrwDropFrames | 0 | 0 |
| mcFifoDropPkts | 0 | 0 |
| mcFilterDropPkts | 0 | 0 |
| goodOctetsSent | --- | --- |

The following CLI displays detailed informatin about the switch traffic for CPU:

```
firepower-4225(local-mgmt)# show portmanager switch traffic cpu
```

| Dev/RX queue | packets | bytes |
|--------------|---------|-------|
| 0/0 | 0 | 0 |
| 0/1 | 0 | 0 |
| 0/2 | 0 | 0 |
| 0/3 | 0 | 0 |
| 0/4 | 0 | 0 |
| 0/5 | 0 | 0 |
| 0/6 | 0 | 0 |
| 0/7 | 0 | 0 |

The following CLI displays details on hardware switch port traffic:

```
firepower-4225(local-mgmt)# show portmanager switch traffic port
```

max-rate - pps that the port allow with packet size=64
 actual-tx-rate - pps that egress the port (+ % from 'max')
 actual-rx-rate - pps that ingress the port(+ % from 'max')

| Dev/Port | max-rate | actual-tx-rate | actual-rx-rate |
|----------|----------|----------------|----------------|
| 0/1 | 1488095 | (0%)--- | (0%)--- |
| 0/2 | 1488095 | (0%)--- | (0%)--- |
| 0/3 | 14880 | (0%)--- | (0%)--- |
| 0/4 | 14880 | (0%)--- | (0%)--- |
| 0/5 | 14880 | (0%)--- | (0%)--- |
| 0/6 | 14880 | (0%)--- | (0%)--- |
| 0/7 | 14880 | (0%)--- | (0%)--- |
| 0/8 | 14880 | (0%)--- | (0%)--- |
| 0/9 | 14880952 | (0%)--- | (0%)--- |
| 0/10 | 14880952 | (0%)--- | (0%)--- |
| 0/11 | 14880952 | (0%)--- | (0%)--- |
| 0/12 | 14880952 | (0%)--- | (0%)--- |
| 0/13 | 14880952 | (0%)--- | (0%)--- |
| 0/14 | 14880952 | (0%)--- | (0%)--- |
| 0/15 | 1488095 | (0%)--- | (0%)--- |
| 0/16 | 1488095 | (0%)--- | (0%)--- |
| 0/17 | 14880952 | (0%)--- | (0%)--- |
| 0/18 | 74404761 | (0%)--- | (0%)--- |
| 0/19 | 37202380 | (0%)--- | (0%)--- |
| 0/20 | 37202380 | (0%)--- | (0%)--- |

The following CLI displays detailed information about SFP-FEC Counters matching ethernet 1/13 port:

```
firepower-4225(local-mgmt)# show portmanager counters ethernet 1 13
  Good Octets Received           : 2153
  Bad Octets Received           : 0
  MAC Transmit Error            : 0
  Good Packets Received         : 13
  Bad packets Received          : 0
  BRDC Packets Received         : 0
  MC Packets Received           : 13
  .....
  .....
  txqFilterDisc                  : 0
  linkchange                     : 1
  FcFecRxBlocks                  : 217038081
  FcFecRxBlocksNoError           : 217038114
  FcFecRxBlocksCorrectedError    : 0
  FcFecRxBlocksUnCorrectedError  : 0
  FcFecRxBlocksCorrectedErrorBits : 0
  FcFecRxBlocksCorrectedError0   : 0
  FcFecRxBlocksCorrectedError1   : 0
  FcFecRxBlocksCorrectedError2   : 0
  FcFecRxBlocksCorrectedError3   : 0
  FcFecRxBlocksUnCorrectedError0 : 0
  FcFecRxBlocksUnCorrectedError1 : 0
  FcFecRxBlocksUnCorrectedError2 : 0
  FcFecRxBlocksUnCorrectedError3 : 0
```

The following CLI displays detailed information about SFP-FEC Counters matching ethernet 1/14 port:

```
firepower-4225(local-mgmt)# show portmanager counters ethernet 1 14
  Good Octets Received           : 2153
  Bad Octets Received           : 0
```

```

MAC Transmit Error           : 0
Good Packets Received       : 13
Bad packets Received        : 0
BRDC Packets Received       : 0
MC Packets Received         : 13
.....
.....
txqFilterDisc               : 0
linkchange                  : 1
RsFeccorrectedFecCodeword   : 0
RsFecuncorrectedFecCodeword : 10
RsFecsymbolError0          : 5
RsFecsymbolError1          : 0
RsFecsymbolError2          : 0
RsFecsymbolError3          : 0

```

The following CLI displays detailed information on the Digital Optical Monitoring information matching ethernet 1/5 port:

```
firepower-4245(local-mgmt)# show portmanager port-info ethernet 1 5
```

```
....
....
```

```
DOM info:
=====:
```

```

Status/Control Register: 0800
    RX_LOS State: 0
    TX_FAULT State: 0
Alarm Status: 0000
No active alarms
Warning Status: 0000
No active warnings

```

THRESHOLDS

| | | high alarm | high warning | low warning | low alarm |
|----------------|----|------------|--------------|-------------|-----------|
| Temperature | C | +075.000 | +070.000 | +000.000 | -05.000 |
| Voltage | V | 003.6300 | 003.4650 | 003.1350 | 002.9700 |
| Bias Current | mA | 012.0000 | 011.5000 | 002.0000 | 001.0000 |
| Transmit power | mW | 034.6740 | 017.3780 | 002.5120 | 001.0000 |
| Receive power | mW | 034.6740 | 017.3780 | 001.3490 | 000.5370 |

Environmental Information - raw values

```

Temperature: 38.84 C
Supply voltage: 33703 in units of 100uVolt
Tx bias: 3499 in units of 2uAmp
Tx power: 0.1 dBm (10251 in units of 0.1 uW)
Rx power: -0.9 dBm (8153 in units of 0.1 uW)
DOM (256 bytes of raw data in hex)

```

```

=====
0x0000 : 4b 00 fb 00 46 00 00 00 8d cc 74 04 87 5a 7a 76
0x0010 : 17 70 01 f4 16 76 03 e8 87 72 03 e8 43 e2 09 d0
0x0020 : 87 72 02 19 43 e2 05 45 00 00 00 00 00 00 00 00
0x0030 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x0040 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0x0050 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 86
0x0060 : 26 54 83 a7 0d ab 28 0b 1f d9 00 00 00 00 08 00
0x0070 : 00 00 03 00 00 00 00 00 08 f3 00 00 00 00 00 01
0x0080 : 49 4e 55 49 41 43 53 45 41 41 31 30 2d 33 33 38

```

The following CLI displays detailed information about the parameters set for the packet capture:

The following CLI displays detailed information on the FXOS port manager switch hardware TCAM rules:

The following CLI displays detailed information on port-based packet drops for eight traffic classes/queues:

| Per Port and Traffic Class | |
|----------------------------|-----|
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 10 | 10 |
| 11 | 11 |
| 12 | 12 |
| 13 | 13 |
| 14 | 14 |
| 15 | 15 |
| 16 | 16 |
| 17 | 17 |
| 18 | 18 |
| 19 | 19 |
| 20 | 20 |
| 21 | 21 |
| 22 | 22 |
| 23 | 23 |
| 24 | 24 |
| 25 | 25 |
| 26 | 26 |
| 27 | 27 |
| 28 | 28 |
| 29 | 29 |
| 30 | 30 |
| 31 | 31 |
| 32 | 32 |
| 33 | 33 |
| 34 | 34 |
| 35 | 35 |
| 36 | 36 |
| 37 | 37 |
| 38 | 38 |
| 39 | 39 |
| 40 | 40 |
| 41 | 41 |
| 42 | 42 |
| 43 | 43 |
| 44 | 44 |
| 45 | 45 |
| 46 | 46 |
| 47 | 47 |
| 48 | 48 |
| 49 | 49 |
| 50 | 50 |
| 51 | 51 |
| 52 | 52 |
| 53 | 53 |
| 54 | 54 |
| 55 | 55 |
| 56 | 56 |
| 57 | 57 |
| 58 | 58 |
| 59 | 59 |
| 60 | 60 |
| 61 | 61 |
| 62 | 62 |
| 63 | 63 |
| 64 | 64 |
| 65 | 65 |
| 66 | 66 |
| 67 | 67 |
| 68 | 68 |
| 69 | 69 |
| 70 | 70 |
| 71 | 71 |
| 72 | 72 |
| 73 | 73 |
| 74 | 74 |
| 75 | 75 |
| 76 | 76 |
| 77 | 77 |
| 78 | 78 |
| 79 | 79 |
| 80 | 80 |
| 81 | 81 |
| 82 | 82 |
| 83 | 83 |
| 84 | 84 |
| 85 | 85 |
| 86 | 86 |
| 87 | 87 |
| 88 | 88 |
| 89 | 89 |
| 90 | 90 |
| 91 | 91 |
| 92 | 92 |
| 93 | 93 |
| 94 | 94 |
| 95 | 95 |
| 96 | 96 |
| 97 | 97 |
| 98 | 98 |
| 99 | 99 |
| 100 | 100 |

| Port | Per port | TC0 | TC1 | TC2 | TC3 | TC4 | TC5 | TC6 |
|------|----------|-----|-----|-----|-----|-----|-----|-----|
| TC7 | | | | | | | | |
| 0/1 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |
| 0/2 | 15 | 15 | 15 | 15 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |
| 0/3 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |
| 0/4 | 180 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| 180 | | | | | | | | |
| 0/5 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |
| 0/6 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |
| 0/7 | 200 | 25 | 25 | 50 | 10 | 10 | 25 | 50 |
| 25 | | | | | | | | |
| 0/8 | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| 10 | | | | | | | | |

The following CLI displays dropped packet counts due to tti-lookup0:

```
firepower-4225(local-mgmt)# show portmanager switch default-rule-drop-counter tti-lookup0
```

| Rule_id | cnc_index | packet_count |
|---------|-----------|--------------|
| 1 | 1 | 4 |

Security Services Mode Troubleshooting Commands

Use the following security services (ssa) mode FXOS CLI commands to troubleshoot issues with your system.

show app

Displays information about the applications attached to your Firepower device.

For example:

```
firepower /ssa # show app
Application:
  Name      Version  Description Author  Deploy Type CSP Type  Is Default
App
-----
  asa      9.10.1   N/A      cisco  Native  Application Yes
  asa      9.9.2    N/A      cisco  Native  Application No
```

showapp-instance

Displays information about the verified app-instance status

```
firepower-2120 /ssa # show app-instance
Application Name  Slot ID  Admin State  Operational State  Running Version  Startup
Version Cluster Oper State
-----
asa              1        Enabled      Online              9.14.2           9.14.2
                  Not Applicable
```

showfault

Displays information about the fault message

```
firepower-2120 /ssa # show fault
Severity  Code      Last Transition Time      ID      Description
-----  -
Cleared   F16589   2021-10-11T21:58:53.200    25140   [FSM:STAGE:RETRY:]: Waiting for chassis
object ready (FSM-STAGE:sam:dme:SmSecSvcAutoDeployCSP:WaitForChassisM
oReady)
```

show failsafe-params

The fail-safe mode for an threat defense application on Firepower 1000/2100 or Secure Firewall 3100 is activated due to continuous boot loop, traceback, etc. The following parameters control the activation of the fail-safe mode:

- Max Restart—maximum number of times that an application should restart in order to activate the fail-safe mode.
- Current Reboot Count—number of times the application continuously restarted.
- Restart Time Interval (secs)—the amount of time in seconds, during which the Max Restart counter should be reached in order to trigger the fail-safe mode. If the application restarts 'Max Restart' or more times within this interval, the fail-safe mode is enabled.

For example:

```
firepower-2120-failed(local-mgmt) # show failsafe-params
Max Restart: 8
Current Reboot Count: 0
Restart Time Interval(secs): 3600
```

When the system is in the fail-safe mode:

- The system name is appended with the "-failed" string:

```
firepower-2120-failed /ssa #
```

- The output of the "show failsafe-params" command in the local-mgmt command shell contains a warning message:

```
firepower-2120-failed(local-mgmt) # show failsafe-params
Max Restart: 1
Current Reboot Count: 1
Restart Time Interval(secs): 3600
WARNING: System in Failsafe mode. Applications are not running!
```

- Operation State of the application is Offline:

```
firepower-2120-failed /ssa # show app-instance
Application Name      Slot ID      Admin State      Operational State      Running Version
Startup Version Cluster Oper State      Cluster Role
-----
asa                   1            Enabled          Offline <=====      9.16.2.3
9.16.2.3              Not Applicable      None
```

Packet Capture for Secure Firewall 3100/4200

The Packet Capture tool is a valuable asset for use in debugging connectivity and configuration issues and for understanding traffic flows through your devices. You can now use the Packet Capture CLIs to log traffic that is going through specific interfaces on your Secure Firewall 3100/4200 devices.

You can create multiple packet capture sessions, and each session can capture traffic on multiple interfaces. For each interface included in a packet capture session, a separate packet capture (PCAP) file will be created.

Guidelines and Limitations for Packet Capture

The Packet Capture tool has the following limitations:

- Packet capture sessions can be created even when there is not enough storage space available to run the packet capture session. You should verify that you have enough storage space available before you start a packet capture session.
- For packet capture sessions on a single-wide 4x100Gbps or 2x100Gbps network module (part numbers FPR-NM-4X100G and FPR-NM-2X100G respectively), if the module `adminstate` is set to `off`, the capture session is automatically disabled with an “Oper State Reason: Unknown Error.” You will have to restart the capture session after the module `adminstate` is set to `on` again.

With all other network modules, packet capture sessions continue across module `adminstate` changes.

- Does not support multiple active packet capturing sessions.
- There is no option to filter based on source or destination IPv6 address.
- Filters are not effective on packets that cannot be understood by the internal switch (for example Security Group Tag and Network Service Header packets).
- You cannot capture packets for an EtherChannel as a whole. However, for an EtherChannel allocated to a logical device, you can capture packets on each member interface of the EtherChannel.
- You cannot copy or export a PCAP file while the capture session is still active.
- When you delete a packet capture session, all packet capture files associated with that session are also deleted.

Creating or Editing a Packet Capture Session

Procedure

-
- | | |
|---------------|--|
| Step 1 | Enter packet capture mode: firepower-4215 # scope packet-capture |
| Step 2 | Create a filter. firepower-4215 /packet-capture/filter* # set <filterprop filterprop_value |

Table 1: Supported Filter Properties

| | |
|-----------|--|
| ivlan | Inner VLAN ID (vlan of packet while ingressing port) |
| ovlan | Outer VLAN ID |
| srcip | Source IP Address (IPv4) |
| destip | Destination IP Address (IPv4) |
| srcport | Source Port Number |
| destport | Destination Port Number |
| protocol | IP Protocol [IANA defined Protocol values in decimal format] |
| ethertype | Ethernet Protocol type [IANA defined Ethernet Protocol type value in decimal format. For eg: IPv4 = 2048, IPv6 = 34525, ARP = 2054, SGT = 35081] |
| srcmac | Source Mac Address |
| destmac | Destination Mac Address |

You can apply filters to any of the interfaces included in a packet capture session.

Step 3 To create or edit a packet capture session:

```
firepower-4215 /packet-capture # enter session session_name
```

Step 4 Specify the length of the packet that you want to capture for this packet capture session:

```
firepower-4215 /packet-capture/session* # set session-pcap-snaplength session_snap_length_in_bytes
```

The specified snap length must be between 64 and 9006 bytes. If you do not configure the session snap length, the default capture length is 1518 bytes.

Step 5 Specify the physical source ports that should be included in this packet capture session.

You can capture from multiple ports and can capture from both physical ports and application ports during the same packet capture session. A separate packet capture file is created for each port included in the session. You cannot capture packets for an EtherChannel as a whole. However, for an EtherChannel allocated to a logical device, you can capture packets on each member interface of the EtherChannel.

Note To remove a port from the packet capture session, use **delete** instead of **create** in the commands listed below.

a) Specify the physical port.

```
firepower-4215 /packet-capture/session* # create {phy-port | phy-aggr-port} port_id
```

Example:

Example:

```
firepower-4215 /packet-capture/session* # create phy-port Ethernet1/1
firepower-4215 /packet-capture/session/phy-port* #
```

b) Capture packets on a subinterface.


```
firepower-4215 /packet-capture/session/phy-port* # set subinterface id
```

You can only capture packets for one subinterface per capture session, even if you have multiple subinterfaces on one or more parents. Subinterfaces for EtherChannels are not supported. If the parent interface is also allocated to the instance, you can either choose the parent interface or a subinterface; you cannot choose both.

Example:

```
firepower-4215 /packet-capture/session/phy-port* # set subinterface 100
firepower-4215 /packet-capture/session/phy-port* #
```

- c) For container instances, specify the container instance name.

```
firepower-4215 /packet-capture/session/phy-port* # set app-identifier instance_name
```

Example:

```
firepower-4215 /packet-capture/session/phy-port* # set app-identifier asa-instance1
firepower-4215 /packet-capture/session/phy-port* #
```

- d) (Optional) For capturing the mac-filter dropped packets from switch, specify the mac-filter drop.

```
firepower-4215 /packet-capture/session/phy-port* # set drop {mac-filter | disable}
```

- **disable**—To disable capture of packets dropped from switch.
- **mac-filter**—To capture switch mac-filter drop

Note The mac-filter option is supported only for the ingress packet capture direction and the default option is always **disable**.

- e) (Optional) Apply the desired filter.

```
firepower-4215 /packet-capture/session/phy-port* # set {source-filter} filtername
```

Note To remove a filter from a port, use **set source-filter ""**.

- f) Repeat the steps above as needed to add all desired ports.

Step 6 Specify the application source ports that should be included in this packet capture session.

You can capture from multiple ports and can capture from both physical ports and application ports during the same packet capture session. A separate packet capture file is created for each port included in the session.

Note To remove a port from the packet capture session, use **delete** instead of **create** in the commands listed below.

- a) Specify the application port.

```
firepower-4215 /packet-capture/session* # create app_port module_slot link_name interface_name
app_name
```

Syntax Description

| | |
|--------------------|--|
| module_slot | Security module in which the application is installed. |
| link_name | Any user descriptive name referring to the interface, for example, link1, inside_port1, etc. |

| | |
|-----------------------|---|
| interface_name | Interface attached to the application where packets need to be captured from, for example, Ethernet1/1, Ethernet2/2 |
| app_name | Application installed on the module - asa |

- b) (Optional) Apply the desired filter.

```
firepower-4215 /packet-capture/session/phy-port* # set {source-filter} filename
```

Syntax Description

| | |
|-----------------|---|
| filename | The filter name from the 'create filter' command under packet-capture scope |
|-----------------|---|

Note To remove a filter from a port, use **set source-filter ""**.

- c) Repeat the steps above as needed to add all desired application ports.

Step 7 If you want to start the packet capture session now:

```
firepower-4215 /packet-capture/session* # enable
```

Newly created packet-capture sessions are disabled by default. Explicit enabling of a session activates the packet capture session when the changes are committed. If another session is already active, enabling a session will generate an error. You must disable the already active packet-capture session before you can enable this session.

Step 8 Commit the transaction to the system configuration:

```
firepower-4215 /packet-capture/session* # commit-buffer
```

If you enabled the packet capture session, the system will begin capturing packets. You will need to stop capturing before you can download the PCAP files from your session.

Example

```
firepower-4215 # scope packet-capture
firepower-4215 /packet-capture # create session asalinside
firepower-4215 /packet-capture* # create filter interfacelvlan100
firepower-4215 /packet-capture/filter* # set ivlan 100
firepower-4215 /packet-capture/filter* # set srcIP 6.6.6.6
firepower-4215 /packet-capture/filter* # set destIP 10.10.10.10
firepower-4215 /packet-capture/filter* # exit
firepower-4215 /packet-capture/session* # create phy-port Ethernet1/1
firepower-4215 /packet-capture/session/phy-port* # set drop mac-filter
firepower-4215 /packet-capture/session/phy-port* # set src-filter interfacelvlan100
firepower-4215 /packet-capture/session/phy-port* # exit
firepower-4215 /packet-capture/session* # enable
firepower-4215 /packet-capture/session* # commit-buffer
firepower-4215 /packet-capture/session #
```

Deleting Packet Capture Sessions

You can delete an individual packet capture session if it is not currently running or you can delete all inactive packet capture sessions.

Procedure

- Step 1** Enter packet capture mode:
firepower-4215 # **scope packet-capture**
- Step 2** To delete a specific packet capture session:
firepower-4215 /packet-capture # **delete session** *session_name*
- Step 3** To delete all inactive packet capture sessions:
firepower-4215/packet-capture # **delete-all-sessions**
- Step 4** Commit the transaction to the system configuration:
firepower-4215 /packet-capture* # **commit-buffer**
-

Example

```
firepower-4215 # scope packet-capture
firepower-4215 packet-capture # delete session asalinside
firepower-4215 packet-capture* # commit-buffer
firepower-4215 packet-capture #
```

