



CHAPTER 20

Configuring the NM CIDS

**Note**

The number of concurrent CLI sessions is limited based on the platform. The IDS 4215 and NM CIDS are limited to three concurrent CLI sessions. All other platforms allow ten concurrent sessions.

**Note**

The NM CIDS does not operate in inline mode, only in promiscuous mode, therefore you cannot configure intrusion prevention.

**Note**

The NM CIDS does not support virtualization. For more information on virtualization, see [Configuring the Virtual Sensor, page 7-3](#).

**Note**

The NM CIDS does not support bridged interfaces. Although Cisco IOS allows you to configure IDS using the NM CIDS on a bridged interface, the NM CIDS is not designed to inspect traffic on bridged interfaces, and the configuration does not work.

This chapter describes the tasks you need to perform to set up the NM CIDS and get it ready to receive traffic. After that you are ready to configure intrusion detection. This chapter contains the following sections:

- [Configuration Sequence, page 20-1](#)
- [Configuring IDS-Sensor Interfaces on the Router, page 20-2](#)
- [Establishing the NM CIDS Sessions, page 20-4](#)
- [Configuring Packet Capture, page 20-5](#)
- [Administrative Tasks, page 20-7](#)
- [Supported Cisco IOS Commands, page 20-8](#)

Configuration Sequence

Perform the following tasks to configure the NM CIDS:

1. Configure the IDS interfaces on the router.
2. Log in to the NM CIDS.

3. Initialize the NM CIDS.
Run the **setup** command to initialize the NM CIDS.
4. Configure the NM CIDS to capture traffic for intrusion detection analysis.
5. Create the service account.
6. Perform the other initial tasks, such as adding users, trusted hosts, and so forth.
7. Configure intrusion detection.
8. Perform administrative tasks to keep your NM CIDS running smoothly.
9. Upgrade the IPS software with new signature updates and service packs.
10. Reimage the boot helper and bootloader when needed.

For More Information

- For the procedure for configuring the IDS interfaces on the router, see [Configuring IDS-Sensor Interfaces on the Router, page 20-2](#).
- For the procedure for logging in to the NM CIDS, see [Establishing the NM CIDS Sessions, page 20-4](#).
- For the procedure for using the setup command to initialize the NM CIDS, see [Initializing NM CIDS, page 3-31](#).
- For the procedure for configuring the NM CIDS to capture traffic for intrusion detection analysis, see [Configuring Packet Capture, page 20-5](#).
- For the procedure for creating service account, see [Creating the Service Account, page 4-13](#).
- For the procedures for setting up the sensor, see [Chapter 4, “Initial Configuration Tasks.”](#)
- For the procedures for configuring intrusion detection, see [Chapter 9, “Configuring Anomaly Detection,”](#) [Chapter 8, “Configuring Event Action Rules,”](#) [Chapter 6, “Defining Signatures,”](#) and [Chapter 13, “Configuring Attack Response Controller for Blocking and Rate Limiting.”](#)
- For the administrative procedures, see [Chapter 16, “Administrative Tasks for the Sensor”](#) and [Administrative Tasks, page 20-7](#).
- For more information on obtaining the latest IPS software, see [Obtaining Cisco IPS Software, page 22-1](#).
- For the procedures for reimaging the boot help and bootloader, see [Installing the NM CIDS System Image, page 21-28](#).

Configuring IDS-Sensor Interfaces on the Router

The NM CIDS does not have an external console port. Console access to the NM CIDS is enabled when you issue the **service-module ids-module slot_number/0 session** command on the router, or when you initiate a Telnet connection in to the router with the port number corresponding to the NM CIDS slot. The lack of an external console port means that the initial bootup configuration is possible only through the router.

When you issue the **service-module ids-sensor slot_number/0 session** command, you create a console session with the NM CIDS, in which you can issue any IPS configuration commands. After completing work in the session and exiting the IPS CLI, you are returned to the Cisco IOS CLI.

The **session** command starts a reverse Telnet connection using the IP address of the ids-sensor interface. The ids-sensor interface is an interface between the NM CIDS and the router. You must assign an IP address to the ids-sensor interface before invoking the **session** command. Assigning a routable IP address can make the ids-sensor interface itself vulnerable to attacks. To counter that vulnerability, a loopback IP address is assigned to the ids-sensor interface.

To configure the NM CIDS interfaces, follow these steps:

Step 1 Enter privileged EXEC mode on the router.

```
router> enable
```

Step 2 Confirm the NM CIDS slot number in your router.

```
router # show interfaces ids-sensor slot_number/0
```



Note You can also use the **show run** command. Look for “IDS-Sensor” and the slot number.



Note Cisco IOS gives the NM CIDS the name “IDS-Sensor.” In this example, 1 is the slot number and 0 is the port number, because there is only one port.

Step 3 Enable the CEF switching path.

```
router# configuration terminal
router(config)# ip cef
router(config)# exit
```

Step 4 Create a loopback interface.

```
router# configure terminal
router(config)# interface loopback 0
```

Step 5 Assign an IP address and netmask to the loopback interface.

```
router(config-if)# ip address 10.99.99.99 255.255.255.255
```



Note You must assign an IP address to the internal interface of the NM CIDS to session in to the NM CIDS. Choose a network that does not overlap with any networks assigned to the other interfaces in the router.

Step 6 Assign an unnumbered loopback interface to the ids-sensor interface. Use slot 1 for this example.

```
router(config)# interface ids-sensor 1/0
router(config-if)# ip unnumbered loopback 0
```

Step 7 Activate the port.

```
router(config-if)# no shutdown
```

Step 8 Exit configuration mode.

```
router(config-if)# end
```

Step 9 Write the configuration to NVRAM.

```
router# write memory
Building configuration
[OK]
```

Establishing the NM CIDS Sessions

This section describes how to establish sessions between the router and the NM CIDS. It contains the following topics:

- [Sessioning to the NM CIDS, page 20-4](#)
- [Telneting to the NM CIDS, page 20-5](#)

Sessioning to the NM CIDS

Use the **session** command to establish a session from the router to the NM CIDS. Press **Ctrl-Shift-6**, then **x**, to return a session prompt to a router prompt, that is, to go from the NM CIDS prompt back to the router prompt. Press **Enter** on a blank line to go back to the session prompt, the NM CIDS prompt. You should only suspend a session to the NM CIDS if you will be returning to the session after executing router commands. If you do not plan on returning to the NM CIDS session, you should close the session rather than suspend it.

When you close a session, you are logged completely out of the NM CIDS CLI and a new session connection requires a username and password to log in. A suspended session leaves you logged in to the CLI. When you connect with the **session** command, you can go back to the same CLI without having to provide your username and password.



Note

Telnet clients vary. In some cases, you may have to press **Ctrl-6 + x**. The control character is specified as **^^**, **Ctrl-^**, or ASCII value 30 (hex 1E).



Caution

If you use the **disconnect** command to leave the session, the session remains running. The open session can be exploited by someone wanting to take advantage of a connection that is still in place.

To open and close sessions to the NM CIDS, follow these steps:

Step 1 Open a session from the router to the NM CIDS.

```
router# service-module ids-sensor 1/0 session
Trying 10.99.99.99, 2033 ... Open
```

Step 2 Exit the NM CIDS session.

```
nm-cids# exit
```



Note If you are in submodes of the IPS CLI, you must exit all submodes. Type **exit** until the sensor login prompt appears.

Failing to close a session properly makes it possible for others to exploit a connection that is still in place. Remember to type **exit** at the `Router#` prompt to close the Cisco IOS session completely.

- Step 3** Suspend and close the session to the NM CIDS by pressing **Ctrl-Shift** and pressing **6**. Release all keys, and then press **x**.



Note When you are finished with a session, you need to return to the router to establish the association between a session (the IPS application) and the router interfaces you want to monitor.

- Step 4** Disconnect from the router.

```
router# disconnect
```

- Step 5** Press **Enter** to confirm the disconnection.

```
router# Closing connection to 10.99.99.99 [confirm] <Enter>
```

Telneting to the NM CIDS

You can also Telnet directly to the router with the port number corresponding to the NM CIDS slot. Use the address you established when configuring the loopback 0 interface.

The port number is determined by the following formula: $2001 + 32 \times \text{slot number}$.

For example, for slot 1, the port number is 2033, for slot 2, it is 2065, and so forth.

To use Telnet to invoke a session to port 2033:

```
router# telnet 10.99.99.99 2033
```

For More Information

For the procedure for configuring the loopback 0 interface, see [Configuring IDS-Sensor Interfaces on the Router, page 20-2](#).

Configuring Packet Capture

You must enable the desired interfaces (including subinterfaces) on the router for packet monitoring. You can select any number of interfaces or subinterfaces to be monitored. The packets sent and received on these interfaces are forwarded to the NM CIDS for inspection. You enable and disable the interfaces through the router CLI (Cisco IOS).



Note If the router is performing encryption, the NM CIDS receives the packets after decryption coming in to the router and before encryption leaving the router.

To configure packet capture on the NM CIDS, follow these steps:

- Step 1** Log in to the router console.

- Step 2** View your interface configuration.

```
router# show run
```

Step 3 Identify the interfaces or subinterfaces that you want to monitor, for example, FastEthernet0/0.



Note You can choose more than one interface or subinterface to monitor, but you can only edit one interface at a time.

Step 4 Enter global configuration mode.

```
router# configure terminal
```

Step 5 Specify the interface or subinterface.

```
router(config)# interface FastEthernet0/0
```



Note The traffic comes from one of the router interfaces.

Step 6 Configure the interface to copy network traffic to the NM CIDS.

```
router(config-if)# ids-service-module monitoring
```



Note Use the **no ids-service-module monitoring** command to turn off monitoring.

Step 7 Exit interface mode.

```
router(config-if)# exit
```

Step 8 Repeat Steps 3 through 6 for each interface or subinterface that you want to monitor.

Step 9 Exit global configuration mode.

```
router(config)# exit
```

Step 10 Verify that the NM CIDS is analyzing network traffic.

- a. Open a Telnet or SSH session to the external interface on the NM CIDS, or establish a router console session.



Note SSH requires allowed hosts.

- b. Log in to the NM CIDS.

- c. View the interface statistics to make sure the monitoring interface is up.

```
nm-cids# show interface clear
nm-cids# show interface
MAC statistics from interface FastEthernet0/1
Media Type = backplane
Missed Packet Percentage = 0
Inline Mode = Unpaired
Pair Status = N/A
Link Status = Up
Link Speed = Auto_100
Link Duplex = Auto_Full
Total Packets Received = 23
Total Bytes Received = 1721
Total Multicast Packets Received = 0
Total Broadcast Packets Received = 0
```

```

Total Jumbo Packets Received = 0
Total Undersize Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 2
Total Bytes Transmitted = 120
Total Multicast Packets Transmitted = 0
Total Broadcast Packets Transmitted = 0
Total Jumbo Packets Transmitted = 0
Total Undersize Packets Transmitted = 0
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0

```

- d. Repeat Step c to see the counters gradually increasing. This indicates that the NM CIDS is receiving network traffic.

If the counters are not increasing, make sure the you executed Steps 3 though 6 properly and that FastEthernet0/1 was added to the virtual sensor when you initialized the NM CIDS with the **setup** command.

For More Information

For the procedure for adding SSH allowed hosts, see [Adding Hosts to the SSH Known Hosts List, page 4-31](#).

Administrative Tasks

The following section describes how to reboot the NM CIDS and how to check the status of the Cisco IPS software. It contains the following topics:

- [Shutting Down, Reloading, and Resetting the NM CIDS, page 20-7](#)
- [Checking the Status of the Cisco IPS Software, page 20-8](#)

Shutting Down, Reloading, and Resetting the NM CIDS

The Cisco IOS provides the following commands to control the NM CIDS: **shutdown**, **reload**, and **reset**:

- **shutdown**—Brings the operating system down gracefully:

```
router# service-module ids-sensor slot_number/0 shutdown
```



Caution

Make sure you execute a **shutdown** command before you remove the NM CIDS from the router. Failing to do so can lead to the loss of data or the corruption of the hard-disk drive.

- **reload**—Performs a graceful halt and reboot of the operating system on the NM CIDS:

```
router# service-module ids-sensor slot_number/0 reload
```

- **reset**—Resets the hardware on the NM CIDS. Typically this command is used to recover from a shutdown.

```
router# service-module ids-sensor slot_number/0 reset
```

The following warning appears:

```
router# service-module ids-sensor 1/0 reset
Use reset only to recover from shutdown or failed state
Warning: May lose data on the hard disc!
Do you want to reset?[confirm]
```



Caution

Hard-disk drive data loss only occurs if you issue the **reset** command without first shutting down the NM CIDS. If the NM CIDS is still running correctly, use the **reload** command rather than the **reset** command. You can use the **reset** command safely in other situations.

Checking the Status of the Cisco IPS Software

Use the **status** command to check the status of the Cisco IPS software running on the router:

```
router# service-module ids-sensor slot_number/0 status
```

Something similar to the following output appears:

```
Router# service-module ids-sensor 1/0 status
Service Module is Cisco IDS-Sensor 1/0
Service Module supports session via TTY line 33
Service Module is in Steady state
Getting status from the Service Module, please wait..
Service Module Version information received,
Major ver = 1, Minor ver= 1
Cisco Systems Intrusion Detection System Network Module
Software version: 5.0(1)S42
Model: NM-CIDS
Memory: 254676 KB
Mgmt IP addr:      xx.xx.xx.xx
Mgmt web ports:   443
Mgmt TLS enabled: true
```

Supported Cisco IOS Commands

The **service-module ids-sensor slot_number/0** Cisco IOS command is new to support the NM CIDS. The slot number can vary, but the port is always 0.

The following options apply:

- Privileged mode EXEC
 - **service-module ids-sensor slot_number/0 reload**
Reloads the operating system on the NM CIDS.
 - **service-module ids-sensor slot_number/0 reset**
Provides a hardware reset to the NM CIDS.
 - **service-module ids-sensor slot_number/0 session**
The **session** command lets you access the IPS console.

- **service-module ids-sensor *slot_number*/0 shutdown**

Shuts down the IPS applications running on the NM CIDS.

**Caution**

Removing the NM CIDS without proper shutdown can result in the hard-disk drive being corrupted. After successful shutdown of the NM CIDS applications, Cisco IOS prints a message indicating that you can now remove the NM CIDS.

- **service-module ids-sensor *slot_number*/0 status**

Provides information on the status of the Cisco IPS software.

- Configure interfaces mode (*config-if*)

- **ids-service-module monitoring**

You can enable IPS monitoring on a specified interface (or subinterface). Both inbound and outbound packets on the specified interface are forwarded for monitoring.

