



## Cisco ISE CLI Commands in EXEC Show Mode

This chapter describes **show** commands in EXEC mode that are used to display the Cisco ISE settings and are among the most useful commands. Each of the commands in this chapter is followed by a brief description of its use, command syntax, usage guidelines, and one or more examples.



**Note** From Cisco ISE Release 3.0 onwards, if there is an escape character required after running certain show commands, press **Ctrl+C** and then press **Q**.

- [show](#), on page 3
- [show application](#), on page 4
- [show backup](#), on page 6
- [show banner](#), on page 8
- [show cdp](#), on page 9
- [show clock](#), on page 11
- [show container](#), on page 12
- [show cpu](#), on page 16
- [show crypto](#), on page 18
- [show disks](#), on page 19
- [show icmp-status](#), on page 21
- [show interface](#), on page 23
- [show inventory](#), on page 25
- [show ip](#), on page 27
- [show ipv6 route](#), on page 28
- [show logging](#), on page 29
- [show logins](#), on page 32
- [show memory](#), on page 33
- [show ntp](#), on page 34
- [show ports](#), on page 35
- [show process](#), on page 37
- [show repository](#), on page 39
- [show restore](#), on page 41
- [show running-config](#), on page 42
- [show snmp engineid](#), on page 44

- [show snmp user](#), on page 45
- [show startup-config](#), on page 46
- [show tech-support](#), on page 48
- [show terminal](#), on page 50
- [show timezone](#), on page 51
- [show timezones](#), on page 52
- [show udi](#), on page 53
- [show uptime](#), on page 54
- [show users](#), on page 55
- [show version](#), on page 56

# show

To show the running system information, use the **show** command in EXEC mode.

**show** *keyword*

---

**Command Default** No default behavior or values.

---

**Command Modes** EXEC

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.

---

---

**Usage Guidelines** All **show** commands require at least one keyword to function.

## Example

```
ise/admin# show application
<name>          <Description>
ise             Cisco Identity Services Engine
ise/admin#
```

# show application

To show installed application packages on the system, use the **show application** command in EXEC mode.

**show application** > *file-name*

**show application** [status {*application\_name*}]

**show application** [version {*application\_name*}]

## Syntax Description

>	Redirects output to a file.
<i>file-name</i>	Name of the file to store the Cisco ISE application information.
<b>status</b>	Displays the status of the installed application.
<b>version</b>	Displays the application version for an installed application (Cisco ISE).
<i>application_name</i>	Name of the installed application.
	Output modifier variables: <ul style="list-style-type: none"> <li>• begin—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• count—Count the number of lines in the output. Add number after the count. <ul style="list-style-type: none"> <li> —Output modifier variables for count.</li> </ul> </li> <li>• end—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• exclude—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• include—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• last—Display last few lines of output. Add number after the word last. Supports up to 80 lines to display. Default 10. <ul style="list-style-type: none"> <li> —Output modifier variables for last.</li> </ul> </li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view the application status and version about installed packages on the system, use the **show application** commands.

**Example 1**

```
ise/admin# show application
<name>          <Description>
ise             Cisco Identity Services Engine
ise/admin#
```

**Example 2**

```
ise/admin# show application version ise
Cisco Identity Services Engine
-----
Version       : 1.3.0.672
Build Date   : Thu Jun 19 19:33:17 2014
Install Date : Thu Jun 19 21:06:34 2014
ise/admin#
```

**Example 2**

```
ise/admin# show application version ise
Cisco Identity Services Engine
-----
Version       : 1.4.0.205
Build Date    : Tue Mar 3 05:37:10 2015
Install Date  : Tue Mar 3 21:06:34 2015
ise/admin#
```

**Example 3**

Cisco ISE includes the status of processes that are optional (persona-based). Processes like pxGrid, Certificate Authority, M&T, and Identity Mapping Services can be in any one of the following states:

- Running—Cisco ISE services are up and running
- Not Running—Cisco ISE services are shut down
- Disabled—Cisco ISE services are disabled

```
ise/admin# show application status ise
ISE PROCESS NAME          STATE          PROCESS ID
-----
Database Listener        running        3688
Database Server          running        41 PROCESSES
Application Server        running        6041
Profiler Database        running        4533
AD Connector             running        6447
M&T Session Database     running        2363
M&T Log Processor        running        6324
Certificate Authority Service running        6263
pxGrid Infrastructure Service disabled
pxGrid Publisher Subscriber Service disabled
pxGrid Connection Manager disabled
pxGrid Controller        disabled
Identity Mapping Service disabled
ise/admin#
```

# show backup

To display the backup history of the system or the status of the backup, use the **show backup** command in EXEC mode.

**show backup** [**history** | **status**]

<b>Syntax Description</b>	<b>history</b>	Displays historical information about backups on the system.
	<b>progress</b>	Displays the backup status on the system.
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view the system backup history and status, use the **show backup** command.

## Example 1

```
ise/admin# Show backup history
Wed Apr 10 02:35:29 EDT 2013: backup mybackup-CFG-130410-0226.tar.gpg to repository
myrepository: success
Wed Apr 10 02:40:07 EDT 2013: backup mybackup1-OPS-130410-0239.tar.gpg to repository
myrepository: success
ise/admin#
```

## Example 2

```
ise/admin# show backup status
%% Configuration backup status
%% -----
%      backup name: mybackup
%      repository: myrepository
%      start date: Wed Apr 10 02:26:04 EDT 2013
%      scheduled: no
%      triggered from: Admin web UI
%      host: ise.cisco.com
%      status: backup mybackup-CFG-130410-0226.tar.gpg to repository myrepository:
success
%% Operation backup status
%% -----
%      backup name: mybackup1
%      repository: myrepository
%      start date: Wed Apr 10 02:39:02 EDT 2013
%      scheduled: no
%      triggered from: Admin web UI
%      host: ise.cisco.com
%      status: backup mybackup1-OPS-130410-0239.tar.gpg to repository myrepository:
```

```
success  
ise/admin#
```

# show banner

To display pre-login and post-login banners, use the **show banner** command in EXEC mode.

**show banner** [**post-login** | **pre-login**]

The banners are configured in the Cisco ISE GUI in the following window:

**Administration > System > Admin Access > Settings > Access**. The **Session** tab contains the fields for configuring the pre-login and post-login banners for Cisco ISE CLI and GUI.

<b>Syntax Description</b>	<b>post-login</b>	Displays the post-login information that is configured in the Cisco ISE server for the current CLI session.
	<b>pre-login</b>	Displays the pre-login information that is configured in the Cisco ISE server for the current CLI session.
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.
<b>Usage Guidelines</b>	Use the <b>show banner</b> command in the active SSH sessions. If the active SSH sessions exceed the Maximum Concurrent Sessions that is configured in the Cisco ISE Admin portal, you get the “WARNING: Maximum active SSH sessions reached” message.	



# show cdp

To display information about all enabled Cisco Discovery Protocol (CDP) interfaces, use the **show cdp** command in EXEC mode.

**show cdp** [**all** | **neighbors**]

Syntax Description	all	Shows all enabled Cisco Discovery Protocol interfaces.
	<b>neighbors</b>	Shows the Cisco Discovery Protocol neighbors.

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view enabled Cisco Discovery Protocol interfaces and CDP neighbors, use the **show cdp** command.



**Note** CDP can be visualized from neighboring IPv4 and IPv6 interfaces

## Example 1

```
ise/admin# show cdp all
CDP protocol is enabled...
    broadcasting interval is every 60 seconds.
    time-to-live of cdp packets is 180 seconds.
    CDP is enabled on port GigabitEthernet0.
ise/admin#
```

## Example 2

```
ise/admin# show cdp neighbors
CDP Neighbor: 000c297840e5
    Local Interface : GigabitEthernet0
    Device Type    : ISE-1141VM-K9
    Port           : eth0
    Address        : 172.23.90.114
    IPv6 Address   : 2001:420:54ff:4::458:1
CDP Neighbor: isexp-esw5
    Local Interface : GigabitEthernet0
    Device Type    : cisco WS-C3560E-24TD
    Port           : GigabitEthernet0/5
    Address        : 172.23.90.45
    IPv6 Address   : 2001:420:54ff:4::458:5
CDP Neighbor: 000c29e29926
    Local Interface : GigabitEthernet0
    Device Type    : ISE-1141VM-K9
```

**show cdp**

```
Port          : eth0
Address       : 172.23.90.115
IPv6 Address  : 2001:420:54ff:4::458:2
CDP Neighbor: 000c290fba98
Local Interface : GigabitEthernet0
Device Type   : ISE-1141VM-K9
Port          : eth0
Address       : 172.23.90.111
IPv6 Address  : 2001:420:54ff:4::458:3
ise/admin#
```

# show clock

To display the day, month, date, time, time zone, and year of the system software clock, use the **show clock** command in EXEC mode.

This command has no keywords and arguments.

**show clock**

---

**Command Default** No default behavior or values.

---

**Command Modes** EXEC

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.

---

---

**Usage Guidelines** The **show clock** output in the following example includes Coordinated Universal Time (UTC) or Greenwich Mean Time (GMT), Great Britain, or Zulu time.

## Example

```
ise/admin# show clock
Fri Aug 6 10:46:39 UTC 2010
ise/admin#
```

## show container

To view information about the Threat-Centric NAC adapters and Wi-Fi setup, use the **show container** command in EXEC mode.

The output of this command provides statistical information about the vulnerability assessment scans, when the adapters were created, how long the adapters were running, and their current statuses. You can further view information about each of the adapters in detail based on the container name or ID.

**show container tc-nac** {**adapters** | **all** | **inspect** {**container-id** *container-id* | **container-name** *container-name*} | **stats** {**container-id** *container-id* | **container-name** *container-name*}} | **wifi setup all**}

### Syntax Description

<b>tc-nac</b>	Displays information about the Threat-Centric NAC adapters.
<b>wifi setup</b>	Displays the Wi-Fi container setup information.
<b>all</b>	When used with TC NAC, lists all the adapters that are available in Cisco ISE, including the container name and ID. When used with Wi-Fi Setup, displays the Wi-Fi container setup information.
<b>adapters</b>	Lists the TC NAC adapters that are configured in Cisco ISE. Lists the container ID and name, the time when the adapter was created and how long the adapter has been running, and the current status of the adapter.
<b>inspect</b> { <b>container-id</b> <i>container-id</i>   <b>container-name</b> <i>container-name</i> }	Lists detailed information about the specific adapter.
<b>stats</b> { <b>container-id</b> <i>container-id</i>   <b>container-name</b> <i>container-name</i> }	Provides statistical information about the specific adapter.
>	Redirects output to a file.
/	Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the word count.  —Output modifier variables for count.</li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word last. Supports up to 80 lines to display. Default 10.  —Output modifier variables for last.</li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.2.0.470	This command was introduced.
	3.1	This command no longer includes Wi-Fi configurations.

**Usage Guidelines** To view information about the Threat-Centric NAC adapters, use the **show container** command.

### Example 1

```
ise/admin# show container tc-nac adapters
```

CONTAINER ID STATUS	IMAGE PORTS	COMMAND	CREATED NAMES
63b8904f41c6 Up 19 hours	irf-adapter-nexpose	"/opt/CSCOcpm/vaservi"	19 hours ago nexpose
8389f7e249cf Up 2 days	irf-adapter-tenable	"/opt/CSCOcpm/vaservi"	2 days ago tenable

```
ise/admin#
```

### Example 2

```
ise/admin# show container tc-nac all
```

CONTAINER ID STATUS	IMAGE PORTS	COMMAND	CREATED NAMES
63b8904f41c6 Up 19 hours	irf-adapter-nexpose	"/opt/CSCOcpm/vaservi"	19 hours ago nexpose
8389f7e249cf Up 2 days	irf-adapter-tenable	"/opt/CSCOcpm/vaservi"	2 days ago tenable
41921c1539bf Up 3 days	irf-core-engine:2.2.6 127.0.0.1:3000->3000/tcp	"/bin/sh -c 'npm star"	3 days ago
irf-core-engine-runtime c4f6ff3cf628 Up 3 days	irf-rabbitmq:2.2.6 4369/tcp, 5671-5672/tcp,	"/docker-entrypoint.s"	3 days ago irf-rabbitmq-runtime
e682a5a5ad69 Up 3 days	irf-mongo:2.2.6 27017/tcp	"/entrypoint.sh mongo"	3 days ago irf-mongo-runtime

```
ise/admin#
```

### Example 3

```
ise/admin# show container tc-nac inspect container-name nexpose
```

```
[
{
  "Id": "63b8904f41c6ce2a58660d38eb3500104038e650e4e3365e21e0a536a1ba3044",
  "Created": "2016-09-22T11:38:03.146141316Z",
  "Path": "/opt/CSCOcpm/vaservice/nexposeadapter/bin/nexposeadaptercontrol.sh",
  "Args": [
    "start",
```

```

        "http://irf-core-engine-runtime:3000/api/adapter/instance/register",
        "07bc6aee-fb9f-4845-86cb-886c7c095188"
    ],
    "State": {
        "Status": "running",
        "Running": true,
        "Paused": false,
        "Restarting": false,
        "OOMKilled": false,
        "Dead": false,
        "Pid": 23433,
        "ExitCode": 0,
        "Error": "",
        "StartedAt": "2016-09-22T11:38:05.609439645Z",
        "FinishedAt": "0001-01-01T00:00:00Z"
    },
    "Image": "06ba3230bd64872b988f4506e7fffddc8c6374c7ece285555ee1cc57743ea7e0",
    "ResolvConfPath":
"/opt/docker/runtime/containers/63b8904f41c6ce2a58660d38eb3500104038e650e4e3365e21e0a536a1ba3044/resolv.conf",

    "HostnamePath":
"/opt/docker/runtime/containers/63b8904f41c6ce2a58660d38eb3500104038e650e4e3365e21e0a536a1ba3044/hostname",

    "HostsPath":
"/opt/docker/runtime/containers/63b8904f41c6ce2a58660d38eb3500104038e650e4e3365e21e0a536a1ba3044/hosts",

    "LogPath":
"/opt/docker/runtime/containers/63b8904f41c6ce2a58660d38eb3500104038e650e4e3365e21e0a536a1ba3044/
        63b8904f41c6ce2a58660d38eb3500104038e650e4e3365e21e0a536a1ba3044-json.log",
    "Name": "/nexpose",
    "RestartCount": 0,
    "Driver": "devicemapper",
    "ExecDriver": "native-0.2",
    "MountLabel": "",
    "ProcessLabel": "",
    "AppArmorProfile": "",
    "ExecIDs": [
        "d76578aa48118167d9d029037fcb2e56aa7dce8672b8991a736617a6d6879750"
    ],
    .
    .
    "NetworkSettings": {
        "Bridge": "",
        "SandboxID": "9873fb92f86e665039a6de15bfe057bc3fd341f7b39acedee57cbd89b3f56ce0",
        "HairpinMode": false,
        "LinkLocalIPv6Address": "",
        "LinkLocalIPv6PrefixLen": 0,
        "Ports": {},
        "SandboxKey": "/var/run/docker/netns/9873fb92f86e",
        "SecondaryIPAddresses": null,
        "SecondaryIPv6Addresses": null,
        "EndpointID": "",
        "Gateway": "",
        "GlobalIPv6Address": "",
        "GlobalIPv6PrefixLen": 0,
        "IPAddress": "",
        "IPPrefixLen": 0,
        "IPv6Gateway": "",
        "MacAddress": "",
        "Networks": {
            "irf-internal-nw": {
                "EndpointID":

```

```
"8999c12319144cfd66a4e99be40f7fbc228779e43f2a7f20c48867b8b3ca7a49",
  "Gateway": "169.254.1.1",
  "IPAddress": "169.254.1.6",
  "IPPrefixLen": 24,
  "IPv6Gateway": "",
  "GlobalIPv6Address": "",
  "GlobalIPv6PrefixLen": 0,
  "MacAddress": "02:42:a9:fe:01:06"
}
}
}
]
```

#### Example 4

```
ise/admin# show container tc-nac stats container-name nexpose
```

CONTAINER	CPU %	MEM USAGE / LIMIT	MEM %	NET I/O
nexpose	0.07%	327.9 MB / 12.43 GB	2.64%	4.501 MB
/ 2.446 MB	106.4 MB / 21.27 MB			

#### Example 5

```
ise/admin# show container wifi setup all
```

CONTAINER ID	IMAGE	COMMAND	CREATED	STATUS
d51711744e7c	wifisetup:0.0.12	"/sbin/tini -- /usr/b"	6 days ago	Up 6
days		wifisetup-container		

# show cpu

To display CPU information, use the **show cpu** command in EXEC mode.

To show a summary of CPU usage per Cisco ISE component, use the **show cpu usage** command in EXEC mode. The output of this command provides a snapshot of CPU usage at the moment the command is run.

**show cpu** > *file-name*

**show cpu statistics**

**show cpu usage**

Syntax Description		
	>	Redirects output to a file.
	<i>file-name</i>	Name of the file to redirect.
	<b>statistics</b>	Displays CPU statistics.
	<b>cpu usage</b>	Displays the CPU usage per component for an installed application (Cisco ISE).
	/	Output modifier variables: <ul style="list-style-type: none"> <li>• begin—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• count—Count the number of lines in the output. Add number after the word count.               <ul style="list-style-type: none"> <li> —Output modifier variables for count.</li> </ul> </li> <li>• end—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• exclude—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• include—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• last—Display last few lines of output. Add number after the word last. Supports up to 80 lines to display. Default 10.               <ul style="list-style-type: none"> <li> —Output modifier variables for last.</li> </ul> </li> </ul>
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.1.0.474	This command was introduced.
<b>Usage Guidelines</b>	To view CPU information and its statistics, use the <b>show cpu</b> command.	



**Example 1**

```
ise/admin# show cpu
processor: 0
model : Intel(R) Xeon(R) CPU           E5320 @ 1.86GHz
speed(MHz): 1861.914
cache size: 4096 KB
ise/admin#
```

**Example 2**

```
ise/admin# show cpu statistics
user time:          265175
kernel time:       166835
idle time:         5356204
i/o wait time:     162676
irq time:          4055
ise/admin#
```

**Example 3**

```
ise/admin# show cpu usage
```

ISE Function	% CPU Usage	CPU Time	Number of threads
Profiler Database	0.01	1:26.27	3
M&T Session Database	0.01	1:23.06	18
Certificate Authority Service	0.04	6:57.38	31
M&T Log Processor	0.09	15:44.23	60
ISE Indexing Engine	0.12	21:34.76	75
Database Listener	0.01	0:53.18	2
Database Server	0.36	62:48.64	64 processes
Admin Webapp	0.04	6:46.68	53
Profiler	0.00	0:02.94	26
NSF Persistence Layer	0.05	8:09.70	46
Guest Services	0.00	0:00.32	5
Syslog Processor	0.00	0:12.79	3
Quartz Scheduler	0.05	9:08.80	29
RMI Services	0.00	0:05.98	10
Message Queue	0.00	0:43.99	4
BYOD Services	0.00	0:00.00	1
Admin Process JVM Threads	0.19	32:50.67	10
Miscellaneous services	0.17	30:30.47	3557
Identity Mapping Service	N/A		
SXP Engine Service	N/A		
Threat Centric NAC Docker Service	N/A		
Threat Centric NAC MongoDB Container	N/A		
Threat Centric NAC RabbitMQ Container	N/A		
Threat Centric NAC Core Engine Container	N/A		
Vulnerability Assessment Database	N/A		
Vulnerability Assessment Service	N/A		

# show crypto

To display information about the public keys and authorized keys for the logged in administrators and users, use the **show crypto** command.

**show crypto authorized\_keys**

**show crypto host-keys**

**show crypto key**

Syntax	Description
<b>authorized_keys</b>	Displays authorized keys information for the user who is logged in currently.
<b>host_keys</b>	Displays host keys for the user who is logged in currently.
<b>key</b>	Displays key information for the user who is logged in currently.

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view authorized keys and keys for currently logged in users, use the **show crypto** command.

## Example 1

```
ise/admin# show crypto authorized_keys
Authorized keys for admin
ise/admin#
```

## Example 2

```
ise/admin# show crypto key
admin public key: ssh-rsa f8:7f:8a:79:44:b8:5d:5f:af:e1:63:b2:be:7a:fd:d4 admin@ise
ise/admin#
```

# show disks

To display the disks file-system information, use the **show disks** command in EXEC mode.

**show disks** > *file-name*

Syntax Description		
	>	Redirects output to a file.
	<i>file-name</i>	Name of the file to redirect.
	/	Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the word.               <ul style="list-style-type: none"> <li> —Output modifier variables for count.</li> </ul> </li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word. Supports up to 80 lines to display. Default 10.               <ul style="list-style-type: none"> <li> —Output modifier variables for last.</li> </ul> </li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.
	3.2	The filename variable is no longer supported.

**Usage Guidelines** Only platforms that have a disk file system support the **show disks** command.

## Example

```
ise/admin# show disks
Internal filesystems:
/ : 5% used ( 24124436 of 540283556)
/storedconfig : 7% used ( 5693 of 93327)
/tmp : 2% used ( 35960 of 1976268)
/boot : 4% used ( 17049 of 489992)
/dev/shm : 0% used ( 0 of 1943756)
```

```
    all internal filesystems have sufficient free space
ise/admin#
```



---

**Note** In Cisco ISE 3.0, the localdisk partition is allocated dynamically.

---

# show icmp-status

To display the Internet Control Message Protocol (ICMP) echo response configuration information, use the **show icmp\_status** command in EXEC mode.

**show icmp\_status** > *file-name*

Syntax Description		
	>	Redirects output to a file.
	<i>file-name</i>	Name of the file to redirect.
	/	Output modifier commands: <ul style="list-style-type: none"> <li>• <i>begin</i>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <i>count</i>—Count the number of lines in the output. Add number after the count.               <ul style="list-style-type: none"> <li>•  —Output modifier commands for count.</li> </ul> </li> <li>• <i>end</i>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <i>exclude</i>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <i>include</i>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <i>last</i>—Display last few lines of output. Add number after the word. Supports up to 80 lines to display. Default 10.               <ul style="list-style-type: none"> <li>•  —Output modifier commands for last.</li> </ul> </li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view the Internet Control Message Protocol (ICMP) echo response configuration information, use the **show icmp\_status** command.

## Example 1

```
ise/admin# show icmp_status
icmp echo response is turned on
ise/admin#
```

**Example 2**

```
ise/admin# show icmp_status  
icmp echo response is turned off  
ise/admin#
```

# show interface

To display the usability status of interfaces configured for IP, use the **show interface** command in EXEC mode.

**show interface** > *file-name*

**show interface GigabitEthernet** {0-3}

Syntax	Description
>	Redirects output to a file.
<i>file-name</i>	Name of the file to redirect interface information.
<b>GigabitEthernet</b>	Shows the specific Gigabit Ethernet interface information.
0-3	Gigabit Ethernet number that may be one of the following: 0, 1, 2, 3.
/	Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the word count.</li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word last. Supports up to 80 lines to display. Default 10.</li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** In the **show interface GigabitEthernet 0** output, you can find that the interface has three IPv6 addresses. The first internet address (starting with 3ffe) is the result of using stateless autoconfiguration. For this to work, you need to have IPv6 route advertisement enabled on that subnet. The next address (starting with fe80) is a link local address that does not have any scope outside the host. You always see a link local address regardless of the IPv6 autoconfiguration or DHCPv6 configuration. The last address (starting with 2001) is the result obtained from a IPv6 DHCP server.

**Example 1**

```

ise/admin# show interface
eth0      Link encap:Ethernet  HWaddr 00:0C:29:6A:88:C4
          inet addr:172.23.90.113  Bcast:172.23.90.255  Mask:255.255.255.0
          inet6 addr: fe80::20c:29ff:fe6a:88c4/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:48536 errors:0 dropped:0 overruns:0 frame:0
          TX packets:14152 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:6507290 (6.2 MiB)  TX bytes:12443568 (11.8 MiB)
          Interrupt:59 Base address:0x2000
lo        Link encap:Local Loopback
          inet addr:127.0.0.1  Mask:255.0.0.0
          inet6 addr: ::1/128 Scope:Host
          UP LOOPBACK RUNNING  MTU:16436  Metric:1
          RX packets:1195025 errors:0 dropped:0 overruns:0 frame:0
          TX packets:1195025 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
          RX bytes:649425800 (619.3 MiB)  TX bytes:649425800 (619.3 MiB)
sit0     Link encap:IPv6-in-IPv4
          NOARP  MTU:1480  Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
          RX bytes:0 (0.0 b)  TX bytes:0 (0.0 b)
ise/admin#

```

**Example 2**

```

ise/admin# show interface GigabitEthernet 0
eth0      Link encap:Ethernet  HWaddr 00:0C:29:AF:DA:05
          inet addr:172.23.90.116  Bcast:172.23.90.255  Mask:255.255.255.0
          inet6 addr: 3ffe:302:11:2:20c:29ff:feaf:da05/64 Scope:Global
          inet6 addr: fe80::20c:29ff:feaf:da05/64 Scope:Link
          inet6 addr: 2001:558:ff10:870:8000:29ff:fe36:200/64 Scope:Global
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:77848 errors:0 dropped:0 overruns:0 frame:0
          TX packets:23131 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:10699801 (10.2 MiB)  TX bytes:3448374 (3.2 MiB)
          Interrupt:59 Base address:0x2000
ise/admin#

```



# show inventory

To display information about the hardware inventory, including the Cisco ISE appliance model and serial number, use the **show inventory** command in EXEC mode.

**show inventory** > *file-name*

Syntax Description		
	>	Redirects output to a file.
	<i>file-name</i>	Name of the file to redirect hardware inventory information.
	/	Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the word.</li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word. Supports up to 80 lines to display. Default 10.</li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view the Cisco ISE appliance information, use the **show inventory** command.

## Example

```
ise/admin# show inventory
NAME: "ISE-VM-K9          chassis", DESCR: "ISE-VM-K9          chassis"
PID: ISE-VM-K9          , VID: V01 , SN: H8JESGOFHGG
Total RAM Memory: 1035164 kB
CPU Core Count: 1
CPU 0: Model Info: Intel(R) Xeon(R) CPU          E5320 @ 1.86GHz
Hard Disk Count(*): 1
Disk 0: Device Name: /dev/sda
Disk 0: Capacity: 64.40 GB
Disk 0: Geometry: 255 heads 63 sectors/track 7832 cylinders
NIC Count: 1
NIC 0: Device Name: eth0
```

## show inventory

```
NIC 0: HW Address: 00:0C:29:6A:88:C4
NIC 0: Driver Descr: eth0: registered as PCnet/PCI II 79C970A
(*) Hard Disk Count may be Logical.
ise/admin#
```

# show ip

To display the IP route information, use the **show ip** command in EXEC mode.

## show ip route

<b>Syntax Description</b>	<b>route</b>	Displays IP route information.
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.

**Usage Guidelines** This command displays the IP routing table.

### Example

```
ise/admin# show ip route
Kernel IP routing table
Destination      Gateway         Genmask         Flags Metric Ref    Use Iface
172.21.79.0     0.0.0.0        255.255.255.0  U        0      0      0 eth0
0.0.0.0         172.21.79.1   0.0.0.0        UG       0      0      0 eth0
ise/admin#
```

# show ipv6 route

To display the IPv6 route information, use the **show ipv6 route** command in EXEC mode.

**show ipv6 route**

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** This command displays the IPv6 routing table.

## Example 1

```
ise/admin# show ipv6 route
Destination          Gateway              Iface
-----
2001:DB8:cc00:1::/64  2001:DB8:cc00:1::1  eth0
ff02::1:2/128        ff02::1:2           eth0
ise/admin#
```

## Example 2

```
ise/admin# show ipv6 route
Destination          Gateway              Iface
-----
2001:db8::/64       ::                  eth0
2015:db8::/64       ::                  eth3
2020:db8::/64       2001:db8::5        eth0
default              2001:db8::5        eth0
ise/admin#
```

# show logging

To display the state of system logging (syslog) and the contents of the standard system logging buffer, use the **show logging** command in EXEC mode.

**show logging** > *file-name*

**show logging application** *application-logfile-name*

**show logging container tc-nac** {**container-id** *container-id* [**log-name** *name-of-log-file* **tail**] | **container-name** *container-name*}

**show logging internal**

**show logging system** *system-logfile-name*

## Syntax Description

>	Redirects output to a file.
<i>file-name</i>	Name of the file to redirect system logging information.
<b>application</b>	Displays application logs.
<i>application-logfile-name</i>	Name of the application log file.
<b>container tc-nac</b>	Displays the Threat Centric-NAC containers.
<b>container-id</b> <i>container-id</i> [ <b>log-name</b> <i>name-of-log-file</i> <b>tail</b> ]	Displays the log files related to the specified container (TC-NAC adapt
<b>container-name</b> <i>container-name</i>	Displays the log files related to the specified container (TC-NAC adapt
<b>internal</b>	Displays the syslog configuration.
<b>system</b>	Displays system syslogs.
<i>system-logfile-name</i>	Name of the system log file.
<i>system-file-name</i>	Name of the system log file name.
	Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the word <b>count</b>.</li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word <b>last</b>. Supports up to 80 lines to display. Default 10.</li> </ul>

## show logging

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.
	2.7	The display environment changed to the Unix less command.

**Usage Guidelines** This command displays the state of syslog error and event logging, including host addresses, and for which, logging destinations (console, monitor, buffer, or host) logging is enabled. When you run this command, the content is opened in the Unix less environment. Typing "H" displays the search and movement commands.

**Example 1**

```
ise/admin# show logging system
      0 Feb 25 2013 15:57:43 tallylog
    1781 Feb 26 2013 02:01:02 maillog
    4690 Feb 26 2013 02:40:01 cron
      0 Feb 25 2013 15:56:54 spooler
      0 Feb 25 2013 16:10:03 boot.log
      0 Feb 25 2013 16:00:03 btmp
   38784 Feb 26 2013 02:19:48 wttmp
   16032 Feb 26 2013 02:19:47 faillog
   32947 Feb 26 2013 00:38:02 dmesg
   63738 Feb 26 2013 02:19:49 messages
  146292 Feb 26 2013 02:19:48 lastlog
   13877 Feb 26 2013 01:48:32 rpmpkgs
  129371 Feb 26 2013 02:40:22 secure
   27521 Feb 25 2013 16:10:02 anaconda.syslog
  345031 Feb 25 2013 16:10:02 anaconda.log
      0 Jul 28 2011 00:56:37 mail/statistics
 1272479 Feb 26 2013 02:42:52 ade/ADE.log
   567306 Feb 26 2013 02:40:22 audit/audit.log
   24928 Feb 26 2013 02:40:01 sa/sa26
      0 Feb 25 2013 16:01:40 pm/suspend.log
ise/admin#
```

**Example 2**

To view application log files on Cisco ISE nodes, use the following command:

```
ise/admin# show logging application
    61 Oct 07 2016 03:02:43 dbalert.log
   4569 Oct 07 2016 03:21:18 ad_agent.log
      0 Oct 07 2016 03:13:18 ise-elasticsearch_index_indexing_slowlog.log
      0 Oct 07 2016 03:02:59 edf.log
    124 Oct 07 2016 03:21:59 diagnostics.log
   8182 Oct 07 2016 03:26:45 caservice.log
    426 Oct 07 2016 03:19:17 redis.log
   1056 Oct 07 2016 03:13:07 caservice_bootstrap.log
  49637 Oct 07 2016 03:27:40 passiveid-mgmt.log
      0 Oct 07 2016 03:02:59 passiveid.log
      0 Oct 07 2016 03:13:18 ise-elasticsearch_index_search_slowlog.log
  14152 Oct 07 2016 03:26:03 collector.log
      0 Oct 07 2016 03:02:59 idc-endpoint.log
    134 Oct 07 2016 03:22:34 ocsp.log
```

```
      0 Oct 07 2016 03:02:59 dbconn.log
      0 Oct 07 2016 03:02:59 idc-kerberos.log
100958 Oct 07 2016 03:24:43 crypto.log
      0 Oct 07 2016 03:02:59 idc-syslog.log
      0 Oct 07 2016 03:02:59 replication.log.2016-10-04.1
10394 Oct 07 2016 03:24:01 guest.log
      0 Oct 07 2016 03:02:59 guest.log.2016-10-07.1
      0 Oct 07 2016 03:02:59 vcs.log.2016-10-04.1
288624 Oct 07 2016 03:27:25 ise-psc.log
ise/admin#
```

# show logins

To display the state of system logins, use the **show logins** command in EXEC mode.

## show logins cli

<b>Syntax Description</b>	<b>cli</b>	Lists the cli login history.
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.
<b>Usage Guidelines</b>	Requires the <b>cli</b> keyword; otherwise, an error occurs.	

## Example

```
ise/admin# show logins cli
admin pts/0 10.77.137.60 Fri Aug 6 09:45 still logged in
admin pts/0 10.77.137.60 Fri Aug 6 08:56 - 09:30 (00:33)
admin pts/0 10.77.137.60 Fri Aug 6 07:17 - 08:43 (01:26)
reboot system boot 2.6.18-164.el5PA Thu Aug 5 18:17 (17:49)
admin tty1 Thu Aug 5 18:15 - down (00:00)
reboot system boot 2.6.18-164.el5PA Thu Aug 5 18:09 (00:06)
setup tty1 Thu Aug 5 17:43 - 18:07 (00:24)
reboot system boot 2.6.18-164.el5PA Thu Aug 5 16:05 (02:02)
wtmp begins Thu Aug 5 16:05:36 2010
ise/admin#
```



# show memory

To display the memory usage of all running processes, use the **show memory** command in EXEC mode.

This command has no keywords and arguments.

**show memory**

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view used memory, use the **show memory** command.

## Example

```
ise/admin# show memory
total memory: 4394380 kB
free memory: 206060 kB
cached: 1111752 kB
swap-cached: 9072 kB
```

```
output of free command:
total used free shared buffers cached
Mem: 4394380 4188576 205804 0 147504 1111748
-/+ buffers/cache: 2929324 1465056
Swap: 8185108 192728 7992380
ise/admin#
```

# show ntp

To show the status of the Network Translation Protocol (NTP) associations, use the **show ntp** command in EXEC mode.

This command has no keywords and arguments.

## show ntp

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view the Network Translation Protocol (NTP) associations, use the **show ntp** command.

## Example

```
ise-az2/iseadmin#show ntp
Configured NTP Servers:
  xx.x.xxx.x
  0.north-america.pool.ntp.org
  1.north-america.pool.ntp.org
Reference ID      : 62BFD502 (mail.example.com)
Stratum          : 2
Ref time (UTC)   : Thu May 19 15:49:40 2022
System time      : 0.000000384 seconds fast of NTP time
Last offset      : -0.000422698 seconds
RMS offset       : 0.000422698 seconds
Frequency        : 7.323 ppm slow
Residual freq    : +2.728 ppm
Skew             : 0.352 ppm
Root delay       : 0.090078361 seconds
Root dispersion  : 0.002209879 seconds
Update interval  : 2.1 seconds
Leap status      : Normal

210 Number of sources = 3
MS Name/IP address      Stratum Poll Reach LastRx Last sample
=====
^? ns-dmz.demo.local    0  7   0   -    +0ns[ +0ns] +/-  0ns
^+ lofn.fancube.com     2  6  17  45  +5381us[+4959us] +/- 67ms
^* mail.intrax.com      1  6  17  44  -3730us[-4153us] +/- 47ms

M indicates the mode of the source.
^ server, = peer, # local reference clock.

S indicates the state of the sources.
* Current time source, + Candidate, x False ticker, ? Connectivity lost, ~ Too much
variability
```

Warning: Output results may conflict during periods of changing synchronization.

# show ports

To display information about all processes listening on active ports, use the **show ports** command in EXEC mode.

**show ports** > *file-name*

Syntax Description		
	>	Redirects output to a file.
	<i>file-name</i>	Name of the file to redirect.
	\	Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the word.               <ul style="list-style-type: none"> <li> —Output modifier variables for count.</li> </ul> </li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word. Default 80 lines to display. Default 10.               <ul style="list-style-type: none"> <li> —Output modifier variables for last.</li> </ul> </li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** When you run the **show ports** command, the port must have an associated active session.

## Example

```
ise/admin# show ports
Process : java (22648)
  tcp: 0.0.0.0:9024, 127.0.0.1:2020, 0.0.0.0:9060, 0.0.0.0:37252, 127.0.0.1:8005, 0.0.0.0:9990, 0.0.0.0:8009, 0.0.0.0:8905, 0.0.0.0:5514, 0.0.0.0:1099, 0.0.0.0:61616, 0.0.0.0:80, 127.0.0.1:8888, 0.0.0.0:9080, 0.0.0.0:62424, 0.0.0.0:8443, 0.0.0.0:443, 0.0.0.0:8444
  udp: 172.21.79.91:1812, 172.21.79.91:1813, 172.21.79.91:1700, 0.0.0.0:48425, 172.21.79.91:8905, 172.21.79.91:3799, 0.0.0.0:54104, 172.21.79.91:57696, 172.21.79.91:1645, 172.21.79.91:1646
Process : timestenrepd (21516)
  tcp: 127.0.0.1:56513, 0.0.0.0:51312
Process : timestensubd (21421)
```

```
    tcp: 127.0.0.1:50598
Process : rpc.statd (3042)
    tcp: 0.0.0.0:680
    udp: 0.0.0.0:674, 0.0.0.0:677
Process : ttcserver (21425)
    tcp: 0.0.0.0:53385, 127.0.0.1:49293
Process : timestensubd (21420)
    tcp: 127.0.0.1:51370
Process : redis-server (21535)
    tcp: 0.0.0.0:6379
Process : portmap (2999)
    tcp: 0.0.0.0:111
    udp: 0.0.0.0:111
Process : Decap_main (22728)
--More--
```

# show process

To display information about active processes, use the **show process** command in EXEC mode.

**show process** > *file-name*

Syntax Description		
	>	Redirects output to a file.
	<i>file-name</i>	Name of the file to redirect.
	/	(Optional). Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the word count.</li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word last. Supports up to 80 lines to display. Default 10.</li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

## Usage Guidelines

**Table 1: Show Process Field Descriptions**

Field	Description
USER	Logged-in user.
PID	Process ID.
TIME	The time the command was last used.
TT	Terminal that controls the process.
COMMAND	Type of process or command used.

**Example**

```

ise/admin# show process
USER      PID      TIME TT      COMMAND
root      1 00:00:02 ?      init
root      2 00:00:00 ?      migration/0
root      3 00:00:00 ?      ksoftirqd/0
root      4 00:00:00 ?      watchdog/0
root      5 00:00:00 ?      events/0
root      6 00:00:00 ?      khelper
root      7 00:00:00 ?      kthread
root      10 00:00:01 ?      kblockd/0
root      11 00:00:00 ?      kacpid
root      170 00:00:00 ?      cqueue/0
root      173 00:00:00 ?      khubd
root      175 00:00:00 ?      kseriod
root      239 00:00:32 ?      kswapd0
root      240 00:00:00 ?      aio/0
root      458 00:00:00 ?      kpsmoused
root      488 00:00:00 ?      mpt_poll_0
root      489 00:00:00 ?      scsi_eh_0
root      492 00:00:00 ?      ata/0
root      493 00:00:00 ?      ata_aux
root      500 00:00:00 ?      kstriped
root      509 00:00:07 ?      kjournald
root      536 00:00:00 ?      kauditd
root      569 00:00:00 ?      udevd
root      1663 00:00:00 ?      kmpathd/0
root      1664 00:00:00 ?      kmpath_handlerd
root      1691 00:00:00 ?      kjournald
root      1693 00:00:00 ?      kjournald
root      1695 00:00:00 ?      kjournald
root      1697 00:00:00 ?      kjournald
root      2284 00:00:00 ?      auditd
root      2286 00:00:00 ?      audispd
root      2318 00:00:10 ?      debugd
rpc      2350 00:00:00 ?      portmap
root      2381 00:00:00 ?      rpciod/0
--More--
ise/admin#

```

# show repository

To display the file contents of the repository, use the **show repository** command in EXEC mode.

**show repository** *repository-name*

<b>Syntax Description</b>	<i>repository-name</i>	Name of the repository whose contents you want to view. Supports up to 64 alphanumeric characters.
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.

**Usage Guidelines** To view the contents of the repository, use the **show repository** command.

## Example

```
ise/admin# show repository myrepository
back1.tar.gpg
back2.tar.gpg
ise/admin#
```



**Note** If you have enabled PKI authentication for an SFTP repository, you must generate the public key for the repository from the ISE CLI in addition to generating it from the ISE GUI. When the SFTP repository is configured from the ISE GUI, the public key on Cisco ISE is generated only for the root user and not for the admin user (user with which all commands can be run from the CLI). Follow these steps to verify and configure the public key from the ISE CLI:

1. Verify whether the crypto key is yet generated or not. If the output for the following command is empty it means that the crypto key is not generated.

```
ise24/admin# show crypto key
```

2. Hence from the CLI EXEC mode generate the key using the command: **crypto key generate rsa passphrase <secretkey>**.

3. From the following we can now confirm that the crypto key is generated successfully:

```
ise24/admin# show crypto key
admin public key: ssh-rsa SHA256:eEziR/ARPyFolWptgI+y5WNjGIrgfPmEpEswVY7Qjb0 admin@ise24
```

4. After this, the admin needs to export the public key for 'admin' user using the command: **crypto key export <sample-name> repository <another-repository-name>**.
5. Now open the file saved to the **<another-repository-name>** and add it to **/home/<username>/.ssh/authorized\_keys** folder in the SFTP server.



# show restore

To display the restore history and the status of restore, use the **show restore** command in EXEC mode.

**show restore** {**history** | **status**}

<b>Syntax Description</b>	<b>history</b>	Displays the restore history on the system.
	<b>status</b>	Displays the status of restore on the system.
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.
<b>Usage Guidelines</b>	<b>Example</b>	

```
ise/admin# show restore history
Wed Apr 10 03:32:24 PDT 2013: restore mybackup-CFG-130410-0228.tar.gpg from repository
myrepository: success
Wed Apr 10 03:45:19 PDT 2013: restore mybackup1-OPS-130410-0302.tar.gpg from repository
myrepository: success
ise/admin#
ise/admin# show restore status
%% Configuration restore status
%% -----
% No data found. Try 'show restore history' or ISE operation audit report
%% Operation restore status
%% -----
% No data found. Try 'show restore history' or ISE operation audit report
ise/admin#
```

# show running-config

To display the contents of the currently running configuration file or the configuration, use the **show running-config** command in EXEC mode.

This command has no keywords and arguments.

## show running-config

### Command Default

None

### Command Modes

EXEC

### Command History

Release	Modification
2.0.0.306	This command was introduced.

### Usage Guidelines

The **show running-config** command displays all of the running configuration information.

### Example

```
ise/admin# show running-config
Generating configuration...
!
hostname ise
!
ip domain-name cisco.com
!
interface GigabitEthernet 0
  ip address 172.23.90.113 255.255.255.0
  ipv6 address autoconfig
!
ip name-server 171.70.168.183
!
ip default-gateway 172.23.90.1
!
clock timezone UTC
!
ntp server time.nist.gov
!
username admin password hash $1$JbbHvKVG$xMZ/XL4tH15Knf.FfcZZr. role admin
!
service sshd
!
password-policy
  lower-case-required
  upper-case-required
  digit-required
  no-username
  disable-cisco-passwords
  min-password-length 6
!
logging localhost
logging loglevel 6
!
cdp timer 60
cdp holdtime 180
```

```
cdp run GigabitEthernet 0
!  
icmp echo on  
!  
ise/admin#
```

# show snmp engineid

To display the default or configured engine ID, use the **show snmp engineid** command in EXEC mode. This command displays the identification of the local SNMP engine and all remote engines that have been configured on the device.

## show snmp engineid

**Command Default** No default behavior or values.

**Command Modes** EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.
	3.1	The command was updated from <b>show snmp engineid</b> to <b>show snmp-server engineid</b> .

## Example

```
ise/admin# show snmp engineid  
Local SNMP EngineID: 0x1234567
```

```
ise/admin#
```

# show snmp user

To display a list of defined snmp users, use the **show snmp user** command in EXEC mode.

**show snmp user**

---

**Command Default** No default behavior or values.

---

**Command Modes** EXEC

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.
	3.1	The command was updated from <b>show snmp user</b> to <b>show snmp-server user</b> .

---

## Example

```
ise/admin# show snmp user
User: snmp3
  EngineID: 80001f88044b4951504a375248374c55
  Auth Protocol: sha
  Priv Protocol: aes-128

ise/admin#
```

## show startup-config

To display the contents of the startup configuration file or the configuration, use the **show startup-config** command in EXEC mode.

This command has no keywords and arguments.

### show startup-config

#### Command Default

None

#### Command History

Release	Modification
2.0.0.306	This command was introduced.

#### Usage Guidelines

The **show startup-config** command displays all of the startup configuration information.

#### Example

```
ise/admin# show startup-config
!
hostname ise
!
ip domain-name cisco.com
!
interface GigabitEthernet 0
 ip address 172.23.90.113 255.255.255.0
 ipv6 address autoconfig
!
ip name-server 171.70.168.183
!
ip default-gateway 172.23.90.1
!
clock timezone UTC
!
ntp server time.nist.gov
!
username admin password hash $1$JbbHvKVG$xMZ/XL4tH15Knf.FfcZZr. role admin
!
service sshd
!
password-policy
 lower-case-required
 upper-case-required
 digit-required
 no-username
 disable-cisco-passwords
 min-password-length 6
!
logging localhost
logging loglevel 6
!
cdp timer 60
cdp holdtime 180
cdp run GigabitEthernet 0
!
icmp echo on
```

```
!  
ise/admin#
```

# show tech-support

To display technical support information, including e-mail, use the **show tech-support** command in EXEC mode.

**show tech-support** > *file-name*

**show tech-support file** *file-name*

<b>Syntax Description</b>	>	Redirects output to a file.
	<b>file</b>	Saves any technical support data as a file in the local disk.
	<i>file-name</i>	Filename to save technical support data. Supports up to 80 alphanumeric characters.
<b>Command Default</b>	Passwords and other security information do not appear in the output.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.

**Usage Guidelines** The **show tech-support** command is useful for collecting a large amount of information about the Cisco ISE server for troubleshooting purposes. You can then provide output to technical support representatives when reporting a problem.

## Example

```
ise/admin# show tech-support
*****
Displaying ISE version ...
*****
Cisco Identity Services Engine
-----
Version       : 1.3.0.862
Build Date    : Tue Oct 14 19:02:08 2014
Install Date  : Wed Oct 15 09:08:53 2014

*****
Displaying Clock ...
*****
Tue Oct 21 11:24:08 IST 2014

*****
Displaying UDI ...
*****
ISE-VM-K9

*****
Displaying ISE application status ...
*****
```



```

ISE PROCESS NAME                STATE                PROCESS ID
--More--
(show Spacebar to continue)
ise/admin#

```

### Example

```

ise/admin# show tech-support
*****
Displaying ISE version ...
*****
Cisco Identity Services Engine
-----
Version      : 1.4.0.205
Build Date   : Tue 03 Mar 2015 05:37:10 AM UTC
Install Date : Tue 03 Mar 2015 08:25:37 PM UTC

*****
Displaying Clock ...
*****
Mon Mar 16 03:51:35 UTC 2015

*****
Displaying UDI ...
*****
ISE-VM-K9

*****
Displaying ISE application status ...
*****
ISE PROCESS NAME                STATE                PROCESS ID
--More--
(show Spacebar to continue)
ise/admin#

```

# show terminal

To obtain information about the terminal configuration parameter settings, use the **show terminal** command in EXEC mode.

This command has no keywords and arguments.

## show terminal

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** The following table describes the fields of the **show terminal** output.

*Table 2: Show Terminal Field Descriptions*

Field	Description
TTY: /dev/pts/0	Displays standard output to type of terminal.
Type: "vt100"	Type of current terminal used.
Length: 27 lines	Length of the terminal display.
Width: 80 columns	Width of the terminal display, in character columns.
Session Timeout: 30 minutes	Length of time, in minutes, for a session, after which the connection closes.

## Example

```
ise/admin# show terminal
TTY: /dev/pts/0 Type: "vt100"
Length: 27 lines, Width: 80 columns
Session Timeout: 30 minutes
ise/admin#
```

# show timezone

To display the time zone as set on the system, use the **show timezone** command in EXEC mode.

This command has no keywords and arguments.

## **show timezone**

This command has no keywords and arguments.

---

**Command Default**

No default behavior or values.

---

**Command Modes**

EXEC

---

**Command History**

<b>Release</b>	<b>Modification</b>
2.0.0.306	This command was introduced.

---

**Usage Guidelines****Example**

```
ise/admin# show timezone
UTC
ise/admin#
```

# show timezones

To obtain a list of time zones from which you can select, use the **show timezones** command in EXEC mode.

This command has no keywords and arguments.

## show timezones

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** See the clock timezone section, for examples of the time zones available for the Cisco ISE server.

## Example

```
ise/admin# show timezones
Africa/Cairo
Africa/Banjul
Africa/Nouakchott
Africa/Gaborone
Africa/Bangui
Africa/Malabo
Africa/Lusaka
Africa/Conakry
Africa/Freetown
Africa/Bamako
--More--
(press Spacebar to continue)
ise/admin#
```

# show udi

To display information about the Unique Device Identifier (UDI) of the Cisco ISE appliance, use the **show udi** command in EXEC mode.

This command has no keywords and arguments.

**show udi**

---

**Command Default** No default behavior or values.

---

**Command Modes** EXEC

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.

---

---

**Usage Guidelines** **Example 1**

```
ise/admin# show udi
SPID: ISE-3415-K9
VPID: V01
Serial: LAB12345678
ise/admin#
```

**Example 2**

The following output appears when you run the **show udi** command on VMware servers.

```
ise/admin# show udi
SPID: ISE-VM-K9
VPID: V01
Serial: 5C79C84ML9H
ise/admin#
```

# show uptime

To display the length of time, the Cisco ISE server has been up since the last reboot, use the **show uptime** command in EXEC mode.

**show uptime** > *file-name*

Syntax Description		
	>	Redirects output to a file.
	<i>file-name</i>	Name of the file to redirect.
	/	Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the count.</li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word last. Supports up to 80 lines to display. Default 10.</li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** Use this **show uptime** to check for how long the Cisco ISE server has been up since the last reboot.

## Example

```
ise/admin# show uptime
3 day(s), 18:55:02
ise/admin#
```

# show users

To display the list of users logged in to the Cisco ISE server, use the **show users** command in EXEC mode.

**show users** > *file-name*

<b>Syntax Description</b>	>	Redirects output to a file.
	<i>file-name</i>	Name of the file to redirect.
	/	Output modifier variables: <ul style="list-style-type: none"> <li>• <b>begin</b>—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• <b>count</b>—Count the number of lines in the output. Add number after the word count.</li> <li>• <b>end</b>—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• <b>exclude</b>—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>include</b>—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• <b>last</b>—Display last few lines of output. Add number after the word last. Supports up to 80 lines to display. Default 10.</li> </ul>
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.0.306	This command was introduced.
<b>Usage Guidelines</b>	Use this <b>show users</b> command to check the list of users logged into the Cisco ISE server.	

## Example

```
ise/admin# show users
USERNAME      ROLE   HOST                TTY   LOGIN DATETIME
admin        Admin  10.77.202.52       pts/0 Tue Feb 26 20:36:41 2013
-----
DETACHED SESSIONS:
-----
USERNAME      ROLE   STARTDATE
% No disconnected user sessions present
ise/admin#
```

# show version

To display information about the software version of the system and software installation information, use the **show version** command in EXEC mode.

**show version** > *file-name*

**show version history**

Syntax Description		
>		Redirects output to a file.
<i>file-name</i>		Name of the file to redirect.
history		Shows software version history information.
/		Output modifier variables: <ul style="list-style-type: none"> <li>• begin—Matched pattern. Supports up to 80 alphanumeric characters.</li> <li>• count—Count the number of lines in the output. Add number after the count.</li> <li>• end—End with line that matches. Supports up to 80 alphanumeric characters.</li> <li>• exclude—Exclude lines that match. Supports up to 80 alphanumeric characters.</li> <li>• include—Include lines that match. Supports up to 80 alphanumeric characters.</li> <li>• last—Display last few lines of output. Add number after the word last. Supports up to 80 lines to display. Default 10.</li> </ul>

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	2.0.0.306	This command was introduced.

**Usage Guidelines** This command displays version information about the Cisco ADE-OS software running in the Cisco ISE server, and also displays the Cisco ISE version.

## Example 1

```
ise/admin# show version
```

```
Cisco Application Deployment Engine OS Release: 3.0
ADE-OS Build Version: 3.0.3.030
ADE-OS System Architecture: x86_64
```

```
Copyright (c) 2005-2014 by Cisco Systems, Inc.
All rights reserved.
```



```
Hostname: docs-ise-23-lnx
```

```
Version information of installed applications
```

```
-----  
Cisco Identity Services Engine
```

```
-----  
Version      : 2.3.0.297  
Build Date   : Mon Jul 24 18:51:29 2017  
Install Date : Wed Jul 26 13:59:41 2017
```

```
ise/admin#
```

## Example 2

```
ise/admin# show version history
```

```
-----  
Install Date: Wed Jul 26 19:02:13 UTC 2017  
Application: ise  
Version: 2.3.0.297  
Install type: Application Install  
Bundle filename: ise.tar.gz  
Repository: SystemDefaultPkgRepos  
ise/admin#
```

show version