



Introduction

Welcome to the *Cisco Secure Malware Analytics Appliance Administration Guide*. This chapter provides a brief description of the appliance, the intended audience and how to access relevant product documentation.

- [About the Secure Malware Analytics Appliance, on page 1](#)
- [What's New In This Release, on page 2](#)
- [Audience, on page 2](#)
- [About This Guide, on page 2](#)
- [User Documentation, on page 3](#)
- [Login Names and Passwords \(Default\), on page 7](#)
- [Resetting the Administrator Password, on page 8](#)

About the Secure Malware Analytics Appliance

The Secure Malware Analytics appliance provides safe and highly secure on-premises advanced malware analysis, with deep threat analytics and content. A Secure Malware Analytics Appliance provides the complete malware analysis platform, installed on a Cisco Secure Malware Analytics M6 Appliance server (v2.19 and later) or M5 Appliance server (v2.7.2 and later). It empowers organizations operating under various compliance and Secure Malware Analytics policy restrictions, to submit malware samples to the appliance.



Note Cisco UCS C220 M4 (TG5400) servers are still supported for Secure Malware Analytics Appliance but the servers are end of life.

Many organizations that handle sensitive data, such as banks and health services, must follow various regulatory rules and guidelines that do not allow certain types of files, such as malware artifacts, to be sent outside of the network for malware analysis. By maintaining a Cisco Secure Malware Analytics Appliance on-premises, organizations are able to send suspicious documents and files to it to be analyzed without leaving the network.

With a Secure Malware Analytics Appliance, security teams can analyze all samples using proprietary and highly secure static and dynamic analysis techniques. The appliance correlates the analysis results with hundreds of millions of previously analyzed malware artifacts, to provide a global view of malware attacks and campaigns, and their distributions. A single sample of observed activity and characteristics can quickly be correlated against millions of other samples to fully understand its behaviors within an historical and global context. This ability helps security teams to effectively defend the organization against threats and attacks from advanced malware.

What's New In This Release

The following changes have been implemented in this guide in Version 2.19:

Table 1: Changes in Version 2.19

Feature or Update	Section
Update firmware	Updating Firmware with FirmwareUp
Enhanced dashboard in the Admin UI	Home
In TGSN, you can now ping via a clean and dirty interface.	-

Audience

This guide is intended to be used by the Secure Malware Analytics Appliance administrator after the appliance has been set up and configured, and an initial test malware sample has been successfully submitted and analyzed. It describes how to manage organizations and users for the malware analysis tool, appliance updates, backups, and other server administration tasks.

This guide also provides information for administrators who are integrating the Secure Malware Analytics Appliance with other Cisco products and services, such as Cisco Email Security Appliance, Cisco Web Security Appliance, and Secure Endpoint Private Cloud devices.



Note For information about Secure Malware Analytics Appliance setup and configuration, see the [Cisco Threat Grid Appliance Getting Started Guide](#).

About This Guide

This guide provides planning information, configuration tasks, and general administrative tasks, and is organized as follows:

Chapter	Description
Introduction	Provides brief description of the appliance, the intended audience, how to access relevant product documentation, log in names and passwords, how to reset the administrator password, and contacting Support.
Planning	Describes the environmental, hardware, and network requirements that should be reviewed prior to setup and configuration.
Network Configuration Using the TGSN Dialog	Provides information about using the Admin TUI to make changes to your initial network configuration, reconnecting to the Admin TUI, and configuring the network in recovery mode.


Chapter	Description
Home	Provides information about using the Home screen of the Admin UI.
Configuration	Provides information about using the Admin UI to make configuration changes to your appliance.
Status	Provides information about viewing system information in the Admin UI, such as installed system packages and their version, detailed logs, and available storage.
Operations	Provides information about activating configuration changes, reloading the Admin UI, managing jobs and power settings, and installing updates.
Support	Provides instructions for starting a live support session and taking support snapshots to aid in resolving issues with the appliance.
Organizations and Users	Provides instructions for creating organizations, managing users, and activating a new device user account.
Inbound and Outbound Connections	Provides information about connecting other Cisco appliances (ESA and WSA), and Secure Endpoint Private Cloud to the Secure Malware Analytics Appliance.
Removing All Data with the Wipe Appliance Boot Option	Describes how to use the Wipe Appliance boot option to remove all data from the Secure Malware Analytics Appliance, including clusters.
Updating Firmware with FirmwareUp	Describes how to update firmware.
CIMC Configuration	Provides information about using the CIMC utility to set up remote server management.

User Documentation

Secure Malware Analytics Appliance User Guides

The latest versions of Cisco Secure Malware Analytics Appliance product documentation can be found on [Cisco.com](https://www.cisco.com).

Figure 1: User Guides on Cisco.com



- [Cisco Secure Malware Analytics Appliance Release Notes](#)
- [Cisco Secure Malware Analytics Appliance Getting Started Guide](#)
- [Cisco Secure Malware Analytics Version Lookup Table](#)
- [Cisco Secure Malware Analytics M6 Hardware Installation Guide](#)



Note The Cisco Secure Malware Analytics M6 Appliance is supported in appliance version 2.19 and later.

- [Cisco Secure Malware Analytics M5 Hardware Installation Guide](#)




Note The Cisco Secure Malware Analytics M5 Appliance is supported in appliance version 2.7.2 and later.

Secure Malware Analytics Portal UI Online Help


Secure Malware Analytics Portal user documentation, including Release Notes, Using Secure Malware Analytics Online Help, API documentation, and other information is available from the ? (**Help**) icon located in the navigation bar in the upper right corner of the Secure Malware Analytics user interface.

Figure 2: Secure Malware Analytics Portal Online Help



Use the online help Search feature located at the top of the left column to find appliance-specific information.


Figure 3: Online Help Search Feature



Secure Malware Analytics Portal UI Administration Guide

A portal online help topic is available for administrators, with instructions on how to manage users and other information. Click the **Administration** tab and choose **Administration Guide**.

Figure 4: Administration Guide for the Secure Malware Analytics Portal UI



Email Security Appliance and Web Security Appliance Documentation

For information on connecting an Email Security Appliance (ESA) or Web Security Appliance (WSA), see [Integrations](#).

See the instructions for Enabling and Configuring File Reputation and Analysis Services in the online help or user guide for your ESA/WSA:

- [Cisco Secure Email Gateway User Guide](#)
- [Cisco Secure Web Appliance User Guide](#)

Login Names and Passwords (Default)

The default login names and passwords are listed in the following table:

User	Login/Password
Admin UI and Shell User	Use the initial Secure Malware Analytics/Admin TUI randomly generated password, and then the new password entered during the first step of the Admin UI configuration workflow. If you lose the password, follow the instructions in Resetting the Administrator Password .
Secure Malware Analytics Web portal UI Administrator	Login: admin Password: Initialize with the first Admin UI password, and then it becomes independent.
CIMC	Login: admin Password: password

Password Criteria

Passwords must include the following:

- Minimum of 8 characters
- At least one number
- At least one special character
- Uppercase and lowercase characters

Resetting the Administrator Password

The default administrator password is only visible in the Admin TUI during the initial appliance setup and configuration. Once the initial configuration is completed, the password is no longer displayed in visible text.



Note LDAP authentication is available for Admin TUI and Admin UI login when you have multiple administrators. If the appliance is configured for LDAP authentication only, resetting the password in recovery mode will reconfigure the authentication mode to allow login with system password as well.

If you lose the administrator password and are unable to log in to the Admin UI, complete the following steps to reset the password.

Procedure


Step 1 Reboot the Secure Malware Analytics Appliance: click the **Operations** tab and choose **Power**, and then click the **Reboot** button. The appliance reboots, and opens the BIOS window.

Figure 5: BIOS Window - Choose Boot Menu <F6> for Recovery Mode



Step 2 In the BIOS window, press **F6** to open the **Boot** menu.

Step 3 Choose **Recovery** and press **Enter**.

Figure 6: Boot Menu

The Secure Malware Analytics Shell opens in Recovery Mode.

Figure 7: Secure Malware Analytics Shell (tgsh) in Recovery Mode

```

any network configuration changes will be applied both to the running recovery
instance and to the real (non-recovery) system, and tgsh will be immediately
restarted.

( 29.363005) configure-from-target(1352): net.ipv4.tcp_sack = 1
( OK ) Started OpenSSH Daemon.
YOU MUST EXIT TGSH BEFORE NETWORK CONFIGURATION CHANGES TAKE EFFECT.

FAILING TO DO SO MAY PREVENT SUPPORT STAFF FROM BEING ABLE TO REACH YOUR SYSTEM.
( 29.454605) configure-from-target(1352): net.ipv4.tcp_window_scaling = 1
( OK ) Reached target ThreatGRID Recovery Mode.
Welcome to the ThreatGrid Shell.
For help, type "help" then enter.
( 29.516710) configure-from-target(1352): net.ipv4.tcp_keepalive_intvl = 30
( 29.566235) configure-from-target(1352): net.ipv4.tcp_tw_reuse = 1
( 29.570452) configure-from-target(1352): net.core.umem_default = 8388608
( 29.590340) configure-from-target(1352): net.core.rmem_default = 8388608
( 29.602073) configure-from-target(1352): net.core.umem_max = 8388608
( 29.613473) configure-from-target(1352): net.core.rmem_max = 8388608
( 29.624361) configure-from-target(1352): net.core.netdev_max_backlog = 10000
( 29.635073) configure-from-target(1352): vm.swappiness = 0
( 29.645657) configure-from-target(1352): kernel.shmmax = 77309411328
( 29.656570) configure-from-target(1352): kernel.shmall = 10874368
( 29.667725) sshd(1493): Server listening on 0.0.0.0 port 22.
( 29.680570) sshd(1493): Server listening on :: port 22.
( 29.692276) su(1495): (to threatgrid) root on console
( 29.702720) su(1495): pam_unix(su-1:session): session opened for user threatgrid by (uid=0)
( 29.713260) systemd(1): Started Initialize From Target.
( 29.723599) systemd(1): Starting Rescue Shell...
( 29.733666) systemd(1): Started Rescue Shell.
( 29.743472) systemd(1): Starting ThreatGRID Support Mode Worker...
( 29.753293) systemd(1): Starting OpenSSH Daemon...
( 29.762993) systemd(1): Started OpenSSH Daemon.
( 29.772456) systemd(1): Starting ThreatGRID Recovery Mode.
( 29.781763) systemd(1): Reached target ThreatGRID Recovery Mode.
( 29.791010) systemd(1): Started ThreatGRID Support Mode Worker.
( 29.800165) systemd(1): Startup finished in 5.581s (kernel) + 23.940s (userspace) = 29.530s.
( 29.809035) configure-from-target(1352): Done with importing configuration from target
( 29.819359) rash-worker(1501): -- rash-worker.go:42: RASH worker "TGH18320319" ready to dial roster.
( 30.827516) rash-worker(1501): -- rash-worker.go:55: connected to router "ThreatGRID" at rash.threatgrid.com:19791

```

Step 4 Run `passwd` to change the password.

Figure 8: Enter New Password

```

>> passwd
( 286.653257) sudo(1511): threatgrid : TTY=ttty1; PWD=/home/threatgrid : USER=root : COMMAND=/usr/bin/passwd threatgrid
Enter new UNIX password: ( 286.663606) sudo(1511): pam_unix(sudo:session): session opened for user root by (uid=0)

```

Note

The command prompt is not always visible in this mode and logging output may be displayed at any point on top of your input. This does not affect input; you can keep typing blindly. Ignore the two lines of logging output.

Step 5 Enter (blindly) the password and press **Enter**.

Step 6 Re-type the password and press **Enter**.

Note

The password will not be displayed.

Step 7 Type **reboot** and press **Enter** to start the appliance in normal mode.

Note

The exit command is no longer required before rebooting for a password reset to take effect (for v2.10 and later).

