



CHAPTER 3

Assigning the Switch IP Address and Default Gateway

This chapter describes how to create the initial switch configuration (for example, assigning the IP address and default gateway information) by using a variety of automatic and manual methods. It also describes how to modify the switch startup configuration.



Note

For complete syntax and usage information for the commands used in this chapter, see the command reference for this release and the *Cisco IOS IP Command Reference, Volume 1 of 3: Addressing and Services* from the Cisco.com page under **Documentation > Cisco IOS Software 12.2 Mainline Command References**

This chapter consists of these sections:

- [Understanding the Bootup Process, page 3-1](#)
[Assigning Switch Information, page 3-2](#)
[Checking and Saving the Running Configuration, page 3-15](#)
[Modifying the Startup Configuration, page 3-17](#)
[Scheduling a Reload of the Software Image, page 3-21](#)



Information in this chapter about configuring IP addresses and DHCP is specific to IP Version 4 (IPv4).

Understanding the Bootup Process

- Performs low-level CPU initialization. It initializes the CPU registers, which control where physical memory is mapped, its quantity, its speed, and so forth.
Performs power-on self-test (POST) for the CPU subsystem. It tests the CPU DRAM and the portion of the flash device that makes up the flash file system.

-
- Loads a default operating system software image into memory and boots the switch.

The bootloader provides access to the flash file system before the operating system is loaded. Normally, the bootloader is used only to load, uncompress, and launch the operating system. After the bootloader gives the operating system control of the CPU, the bootloader is not active until the next system reset or power-on.

The bootloader also provides trap-door access into the system if the operating system has problems serious enough that it cannot be used. The trap-door mechanism provides enough access to the system so that if it is necessary, you can format the flash file system, reinstall the operating system software image by using the Xmodem Protocol, recover from a lost or forgotten password, and finally restart the operating system. For more information, see the [“Recovering from a Software Failure”](#) section on page 41-2 and the [“Recovering from a Lost or Forgotten Password”](#) section on page 41-3.



You can disable password recovery. For more information, see the [“Disabling Password Recovery”](#) section on page 8-5.

Before you can assign switch information, make sure you have connected a PC or terminal to the console port, and configured the PC or terminal-emulation software baud rate and character format to match these of the switch console port:

Baud rate default is 9600.

Data bits default is 8.



If the data bits option is set to 8, set the parity option to none.

Stop bits default is 1.

Parity settings default is none.

Assigning Switch Information

Use the switch setup program if you want to be prompted for specific IP information. With this program, you can also configure a hostname and an enable secret password. It gives you the option of assigning a Telnet password (to provide security during remote management) and configuring your switch as a standalone switch. For more information about the setup program, see the hardware installation guide.

Use a DHCP server for centralized control and automatic assignment of IP information after the server is configured.



Note

If you are using DHCP, do not respond to any of the questions in the setup program until the switch receives the dynamically assigned IP address and reads the configuration file.

If you are an experienced user familiar with the switch configuration steps, manually configure the switch. Otherwise, use the setup program described previously.

-
-
-

Default Switch Information

Table 3-1 Default Switch Information

Feature	Default Setting
	<i>Switch</i>


Understanding DHCP-Based Autoconfiguration

Ethernet interface. This occurs if the Onboard Administrator is connected to a network in which a DHCP server is also connected or if the Onboard Administrator has been configured as a DHCP server. If either of these conditions is true, the fa0 interface obtains an IP address, and you can manage the switch through the fa0 interface. See the HP BladeSystem documentation at <http://www.hp.com/go/ bladesystem/documentation> for more information about the Onboard Administrator.

DHCP Client Request Process

ip address dhcp

Figure 3-1 DHCP Client and Server Message Exchange



In a DHCPREQUEST broadcast message, the client returns a formal request for the offered configuration information to the DHCP server. The formal request is broadcast so that all other DHCP servers that received the DHCPDISCOVER broadcast message from the client can reclaim the IP addresses that they offered to the client.

The DHCP server confirms that the IP address has been allocated to the client by returning a DHCPACK unicast message to the client. With this message, the client and server are bound, and the client uses configuration information received from the server. The amount of information the switch receives depends on how you configure the DHCP server. For more information, see the [“Configuring the TFTP Server”](#) section on page 3-7.

If the configuration parameters sent to the client in the DHCPOFFER unicast message are invalid (a configuration error exists), the client returns a DHCPDECLINE broadcast message to the DHCP server.

The DHCP server sends the client a DHCPNAK denial broadcast message, which means that the offered configuration parameters have not been assigned, that an error has occurred during the negotiation of the parameters, or that the client has been slow in responding to the DHCPOFFER message (the DHCP server assigned the parameters to another client).

A DHCP client might receive offers from multiple DHCP or BOOTP servers and can accept any of the offers; however, the client usually accepts the first offer it receives. The offer from the DHCP server is not a guarantee that the IP address is allocated to the client; however, the server usually reserves the address until the client has had a chance to formally request the address. If the switch accepts replies from a BOOTP server and configures itself, the switch broadcasts, instead of unicasts, TFTP requests to obtain the switch configuration file.

Understanding DHCP-based Autoconfiguration and Image Update

DHCP Autoconfiguration

DHCP Auto-Image Update



Cisco IOS IP Configuration Guide, Release 12.2

Limitations and Restrictions

-
-
-



copy running-configuration startup-configuration **write memory**

Configuring DHCP-Based Autoconfiguration

- [DHCP Server Configuration Guidelines, page 3-6](#)
- [Configuring the TFTP Server, page 3-7](#)
- [Configuring the DNS, page 3-7](#)
- [Configuring the Relay Device, page 3-7](#)
- [Obtaining Configuration Files, page 3-8](#)
- [Example Configuration, page 3-9](#)

If your DHCP server is a Cisco device, for additional information about configuring DHCP, see the “Configuring DHCP” section of the “IP Addressing and Services” section of the [Cisco.com](#) page under [Configuration Guides](#)

DHCP Server Configuration Guidelines

-
-
-
-
-
-
-

Configuring the TFTP Server

switch's current hostname. The TFTP server addresses used include the specified TFTP server address (if any) and the broadcast address (255.255.255.255).

For the switch to successfully download a configuration file, the TFTP server must contain one or more configuration files in its base directory. The files can include these files:

- The configuration file named in the DHCP reply (the actual switch configuration file).
- The network-config or the cisco.net.cfg file (known as the default configuration files).
- The router-config or the ciscotr.cfg file (These files contain commands common to all switches. Normally, if the DHCP and TFTP servers are properly configured, these files are not accessed.)

If you specify the TFTP server name in the DHCP server-lease database, you must also configure the TFTP server name-to-IP-address mapping in the DNS-server database.

If the TFTP server to be used is on a different LAN from the switch, or if it is to be accessed by the switch through the broadcast address (which occurs if the DHCP server response does not contain all the required information described previously), a relay must be configured to forward the TFTP packets to the TFTP server. For more information, see the [“Configuring the Relay Device” section on page 3-7](#). The preferred solution is to configure the DHCP server with all the required information.

Configuring the DNS

Configuring the Relay Device


relay agent

```
router(config-if)# ip helper-address 20.0.0.2
ip helper-address 20.0.0.3
ip helper-address 20.0.0.4
```

```
ip helper-address 10.0.0.1
```



Figure 3-2 Relay Device Used in Autoconfiguration



Obtaining Configuration Files


•

•



Example Configuration

shows a sample network for retrieving IP information by using DHCP-based autoconfiguration.



	Switch A	Switch B	Switch C	Switch D
	10.0.0.3	<i>tftpserver</i> 10.0.0.3	<i>tftpserver</i> 10.0.0.3	<i>tftpserver</i> 10.0.0.3

DNS Server Configuration

tftpserver

TFTP Server Configuration (on UNIX)

switcha-config

switchb-config

```
prompt> cd /tftpserver/work/
ls
network-config
switcha-config
switchb-config
switchc-config
switchd-config
prompt> cat network-config
ip host switcha 10.0.0.21
ip host switchb 10.0.0.22
ip host switchc 10.0.0.23
ip host switchd 10.0.0.24
```

DHCP Client Configuration

Configuration Explanation

Configuring the DHCP Auto Configuration and Image Update Features

Configuring DHCP Autoconfiguration (Only Configuration File)

	Command	Purpose
Step 1		
Step 2		
Step 3	bootfile	
Step 4	network <i>network-number mask</i> <i>prefix-length</i>	
Step 5	<i>address</i>	
Step 6	option 150	
Step 7	exit	
Step 8	tftp-server flash:	
Step 9		
Step 10		
Step 11		
Step 12		
Step 13		

```
Switch# configure terminal
      ip dhcp pool pool1
          network 10.10.10.0 255.255.255.0
          bootfile config-boot.text
          default-router 10.10.10.1
          option 150 10.10.10.1
          exit
      tftp-server flash:config-boot.text
      interface gigabitethernet1/0/4
          no switchport
          ip address 10.10.10.1 255.255.255.0
          end
```



```

Switch(dhcp-config)#
Switch(config)#
Switch(config)# tftp-server flash:c3750m-ip-services-mz.122-44.3.SE.tar
tftp-server flash:boot-config.text
tftp-server flash:autoinstall_dhcp
interface gigabitEthernet1/0/4
  no switchport
  ip address 10.10.10.1 255.255.255.0
end

```

banner config-save ^C	^C
end	
show boot	

```

configure terminal
  boot host dhcp
  boot host retry timeout 300
  banner config-save ^C Caution - Saving Configuration File to NVRAM May Cause
You to No longer Automatically Download Configuration Files at Reboot^C
  vlan 99
Switch(config-vlan)#
Switch(config-if)#
Switch(config-if)#
Switch#
BOOT path-list:
Config file:          flash:/config.text
Private Config file: flash:/private-config.text
Enable Break:        no
Manual Boot:          no
HELPER path-list:
NVRAM/Config file
  buffer size:        32768
Timeout for Config
  Download:           300 seconds
Config Download
  via DHCP:           enabled (next boot: enabled)
Switch#

```



Manually Assigning IP Information



Note

Command	Purpose
Step 1	
Step 2	
Step 3	
Step 4	
Step 5	
	Note
Step 6	
Step 7	
Step 8	
Step 9	

Checking and Saving the Running Configuration

```
Current configuration : 3990 bytes
!
version 12.2
no service pad
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
!
!
!
no aaa new-model
system env temperature threshold yellow 25
ip subnet-zero
!
no ip domain-lookup
!
!
!
no file verify auto
spanning-tree mode pvst
spanning-tree extend system-id
!
vlan internal allocation policy ascending
!
vlan 2-4,20-22,100,200,999
!
!
interface FastEthernet0
 ip address dhcp
 no ip route-cache
 keepalive 1
!
interface GigabitEthernet0/1
 speed 1000
 spanning-tree portfast
!
interface GigabitEthernet0/2
 speed 1000
 spanning-tree portfast
!
interface GigabitEthernet0/3
 speed 1000
 spanning-tree portfast
!
interface GigabitEthernet0/4
 speed 1000
 spanning-tree portfast
!
interface GigabitEthernet0/5
 speed 1000
 spanning-tree portfast
!
interface GigabitEthernet0/6
 speed 1000
 spanning-tree portfast
!
```

```
interface GigabitEthernet0/7
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/8
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/9
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/10
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/11
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/12
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/13
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/14
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/15
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/16
  speed 1000
  spanning-tree portfast
!
interface GigabitEthernet0/17
  switchport access vlan 20
  switchport trunk encapsulation dot1q
  switchport trunk native vlan 20
  switchport mode access
  switchport backup interface Gi0/19
  media-type rj45
!
interface GigabitEthernet0/18
  switchport access vlan 100
  switchport trunk native vlan 2
  switchport mode access
!
interface GigabitEthernet0/19
  switchport access vlan 20
  switchport trunk native vlan 20
  switchport mode access
  media-type rj45
!
interface GigabitEthernet0/20
  switchport access vlan 21
  switchport trunk native vlan 21
  switchport mode access
  switchport backup interface Gi0/22
```



```
!  
interface GigabitEthernet0/21  
  switchport access vlan 22  
  switchport trunk native vlan 2  
  switchport mode access  
  switchport backup interface Gi0/23  
!  
interface GigabitEthernet0/22  
  switchport access vlan 21  
  switchport trunk native vlan 21  
  switchport mode access  
!  
interface GigabitEthernet0/23  
  switchport access vlan 22  
  switchport trunk native vlan 2  
  switchport mode access  
!  
interface GigabitEthernet0/24  
  switchport access vlan 2  
  switchport trunk native vlan 2  
!  
interface Vlan1  
  no ip 2.2.2.122 255.255.255.0  
  no ip route-cache  
!  
ip http server  
snmp-server community public RO  
!  
control-plane  
!
```

```
Switch#  
Destination filename [startup-config]?  
Building configuration...
```

Modifying the Startup Configuration

-
-
-
-
-

Default Bootup Configuration

Feature	Default Setting

Automatically Downloading a Configuration File

Specifying the Filename to Read and Write the System Configuration

	Command	Purpose
Step 1		
Step 2	<code>boot config-file flash:/</code>	
Step 3	<code>end</code>	
Step 4	<code>show boot</code>	<code>boot config-file</code>
Step 5	<code>copy running-config startup-config</code>	

no boot config-file

Booting Up Manually

	Command	Purpose
Step 1	configure terminal	
Step 2	boot manual	
Step 3	end	
Step 4	show boot	<pre> boot manual boot :/ • : flash: • </pre>
Step 5	copy running-config startup-config	

no boot manual

Booting Up a Specific Software Image

■ Modifying the Startup Configuration

	Command	Purpose
Step 1		
Step 2		<ul style="list-style-type: none"> • •
Step 3		
Step 4		
Step 5		

no boot system

Controlling Environment Variables

-
-



Table 3-4 *Environment Variables*

Variable	Bootloader Command	Cisco IOS Global Configuration Command
BOOT	set BOOT :/	boot system <i>ilesystem:/file-url ...</i>
MANUAL_BOOT	set MANUAL_BOOT yes	boot manual boot flash: :/
CONFIG_FILE	set CONFIG_FILE flash:/	boot config-file flash:/

Scheduling a Reload of the Software Image



reload in [:] []

This command schedules a reload of the software to take affect in the specified minutes or hours and minutes. The reload must take place within approximately 24 days. You can specify the reason for the reload in a string up to 255 characters in length.

[|] []

This command schedules a reload of the software to take place at the specified time (using a 24-hour clock). If you specify the month and day, the reload is scheduled to take place at the specified time and date. If you do not specify the month and day, the reload takes place at the specified time on the current day (if the specified time is later than the current time) or on the next day (if the specified time is earlier than the current time). Specifying 00:00 schedules the reload for midnight.



Use the keyword only if the switch system clock has been set (through Network Time Protocol (NTP), the hardware calendar, or manually). The time is relative to the configured time zone on the switch. To schedule reloads across several switches to occur simultaneously, the time on each switch must be synchronized with NTP.

The command halts the system. If the system is not set to manually boot up, it reboots itself. Use the command after you save the switch configuration information to the startup configuration ().

If your switch is configured for manual booting up, do not reload it from a virtual terminal. This restriction prevents the switch from entering the bootloader mode and thereby taking it from the remote user's control.

If you modify your configuration file, the switch prompts you to save the configuration before reloading. During the save operation, the system requests whether you want to proceed with the save if the CONFIG_FILE environment variable points to a startup configuration file that no longer exists. If you proceed in this situation, the system enters setup mode upon reload.

This example shows how to reload the software on the switch on the current day at 7:30 p.m:

```
Reload scheduled for 19:30:00 UTC Wed Jun 5 1996 (in 2 hours and 25 minutes)
Proceed with reload? [confirm]
```

```
Switch# reload at 02:00 jun 20
Reload scheduled for 02:00:00 UTC Thu Jun 20 1996 (in 344 hours and 53 minutes)
Proceed with reload? [confirm]
```

