



Troubleshooting Multipod and Multi-Site Issues

This chapter contains the following sections:

- [Troubleshooting Multipod and Multi-Site, on page 1](#)

Troubleshooting Multipod and Multi-Site

This section describes how to troubleshoot Multipod and Multi-Site.

If you receive the following error:

Error:400 - Invalid Configuration Following Intersite Spines are not configured as Mpod Spines: 1202

You must enable the fabric external connectivity for all the existing spines and if you are trying to add new spines use the Setup Multipod method.

There are two ways to resolve this issue.

- Enable all the spines under the external routed network:
 - In the APIC GUI, on the menu bar, click **Tenant > infra**.
 - In the **Navigation** pane, expand **Networking > External Routed Networks**, right-click on the external routed network and choose **Enable Fabric External Connectivity**.
- Add new spines under the external routed network:
 - In the APIC GUI, on the menu bar, click **Fabric**.
 - In the **Navigation** pane, expand **Quick Start > Node or Pod Setup > Setup Multipod** and complete the Multipod setup.

