



INDEX

Numerics

12-port 4-Gbps Fibre Channel switching modules

description [1-15](#)

figure [1-15](#)

16-Port Storage Services Module [1-21](#)

16-port switching modules

description [1-18](#)

figure [1-18](#)

LEDs (table) [1-17, 1-20](#)

24-port 4-Gbps Fibre Channel switching modules

description [1-14](#)

figure [1-14](#)

32-port Fibre Channel Advanced Services Module. See ASM

32-port Fibre Channel Storage Services Module. See SSM

32-port switching modules

description

[1-17](#)

figure [1-18](#)

LEDs (table) [1-17, 1-20](#)

4 [1-13](#)

4/44-port 8-Gbps Host Optimized Fibre Channel Switching Module [1-13](#)

4/44-Port 8-Gbps Host-Optimized Fibre Channel switching modules

description [1-13](#)

4/44-port 8-Gbps Host-Optimized Fibre Channel switching modules

connectors [1-13](#)

figure [1-13](#)

48-port 4-Gbps Fibre Channel switching modules

connectors [1-13](#)

description [1-13](#)

figure [1-13](#)

LEDs (figure) [1-14](#)

4-port 10-Gbps Fibre Channel switching modules

description [1-16](#)

figure [1-16](#)

69066

2H_Head2

Cisco MDS 16-Port Storage Services Node (SSN-16) [1-21](#)

A

airflow specifications [B-2](#)

alarm

front panel LEDs [1-29](#)

ASM

description [1-30](#)

LEDs (table) [1-32](#)

power and heat specification [B-5](#)

B

batteries, CSM [2-35](#)

binary images

downloading [1-29, 1-31](#)

brackets

C brackets [2-7](#)

front rack-mount [2-6](#)

C

cabinet installation guidelines [2-2](#)

cabinets

Send documentation comments to mdsfeedback-doc@cisco.com

- perforated (requirements) [A-2](#)
 - solid-walled (requirements) [A-3](#)
 - cabling
 - COM1 port [C-3](#)
 - console port [C-2](#)
 - MGMT 10/100/1000 Ethernet port [C-4](#)
 - MGMT 10/100 Ethernet port [C-6](#)
 - requirements [3-1](#)
 - SFP transceivers [3-11, 3-12](#)
 - Caching Services Module. See CSM
 - chassis
 - description [1-3](#)
 - grounding [2-24](#)
 - grounding (figure) [2-25](#)
 - removing from rack (procedure) [2-40](#)
 - Cisco MDS 9200 Series product overview [1-1](#)
 - Cisco MDS 9222i Multiservice Modular Switch [1-1](#)
 - clock modules
 - MTBF [1-9](#)
 - replacing [1-9](#)
 - COM1 port
 - cabling [C-3](#)
 - connecting (figure) [3-4](#)
 - connecting (procedure) [3-4](#)
 - pinouts (table) [C-3](#)
 - connecting
 - console port (figure) [3-2](#)
 - console port (procedure) [3-2](#)
 - Fibre Channel ports [3-6](#)
 - MGMT 10/100 [3-5](#)
 - console port
 - cabling [C-2](#)
 - connecting (figure) [3-2](#)
 - connecting (procedure) [3-3](#)
 - pinouts [C-2](#)
 - contact and site information
 - records [D-3](#)
 - worksheet [D-3](#)
 - CSM
 - batteries [2-35](#)
 - battery specifications (table) [B-3](#)
 - description [1-32](#)
 - figure [1-33](#)
 - installing (procedure) [2-33](#)
 - internal view (figure) [1-33](#)
 - LEDs (table) [1-35](#)
 - maintaining [2-35](#)
 - power and heat specification [B-5](#)
 - removing [2-31](#)
 - CUP [1-23](#)
 - CWDM transceivers
 - description [1-39](#)
 - SFP transceiver specifications [B-18](#)
-
- D**
- downloading software images
 - ASM-SFN image [1-31](#)
 - SSM [1-29](#)
 - DWDM Fibre Channel SFP Transceivers [1-39](#)
-
- E**
- electrostatic discharge (ESD) [2-21](#)
 - encryption [1-24](#)
 - environmental specifications [B-1](#)
 - equipment required, installing [2-4](#)
-
- F**
- fan modules
 - description [1-37](#)
 - figure [2-39](#)
 - installing (procedure) [2-39](#)
 - LEDs [1-37](#)
 - removing (procedure) [2-39](#)
 - Fiber Connectivity [1-23](#)

Send documentation comments to mdsfeedback-doc@cisco.com

fiber optic cables
 maintaining [3-13](#)
 Fibre Channel/Gigabit Ethernet SFP transceivers [1-38](#)
 Fibre Channel ports
 connecting [3-6](#)
 connecting with LC-type cable (figure) [3-12](#)
 Figure 1-8 [1-13](#)

G

Generation 1 modules [1-11](#)
 Generation 2 modules [1-11](#)
 Gigabit Ethernet/Fibre Channel SFP transceiver specifications [B-16](#)
 grounding
 attaching the ESD wrist strap [2-21](#)
 best practices [2-19](#)
 chassis [2-24](#)
 chassis (figure) [2-25](#)
 establishing the system ground [2-23](#)
 tools and equipment [2-23](#)

H

heat dissipation specifications [B-5](#)

I

installing
 equipment required [2-4](#)
 rack-mount (front-facing) [2-6](#)
 rack-mount (rear-facing) [2-16](#)
 rack-mount (rotated brackets) [2-14](#)
 rack-mount front-facing (figure) [2-9](#)
 rack-mount rear-facing (figure) [2-17](#)
 SFP transceiver cables [3-11](#)
 SFP transceivers (note) [3-10](#)
 X2 transceivers [3-8](#)
 interface module

description [1-9](#)

figure [1-9](#)

LEDs (table) [1-10](#)

IPS modules

description [1-26](#)

IPS-4 (figure) [1-27](#)

IPS-8 (figure) [1-27](#)

LEDs (table) [1-28](#)

power and heat specification [B-5](#)

IP Storage Services modules. See IPS modules

IPv6 [1-23](#)

L

LC-type cables

connecting to Fibre Channel ports [3-12](#)

figure [3-12](#)

LEDs

ASM (table) [1-32](#)

CSM (table) [1-35](#)

fan module [1-37](#)

interface module (table) [1-10](#)

IPS modules (table) [1-28](#)

MPS-14/2 (table) [1-26](#)

supervisor module (table) [1-8](#)

switching modules (table) [1-17, 1-20](#)

M

maintaining

fiber optic cables [3-13](#)

SFP transceivers [3-13](#)

maintenance records [D-1](#)

MGMT 10/100/1000 Ethernet port

cabling [C-4](#)

pinouts [C-4](#)

MGMT 10/100 Ethernet port

cabling [C-6](#)

Send documentation comments to mdsfeedback-doc@cisco.com

connecting (figure) [3-5](#)
 connecting (procedure) [3-5](#)
 pinouts [C-6](#)

Module Specifications [B-2](#)

MPS-14/2

figure [1-25](#)
 LEDs (table) [1-26](#)

N

network connections, preparing [3-2](#)
 New and Changed Information [i-ix](#)
 new and changed information (table) [i-ix](#)

O

open racks, standard (requirements) [A-3](#)

P

physical specifications (table) [B-2](#)
 pinouts
 COM 1 port [C-3](#)
 console port [C-2](#)
 MGMT 10/100/1000 Ethernet port [C-4](#)
 MGMT 10/100 Ethernet port [C-6](#)
 plugs supported for power supplies [C-7](#)
 ports
 COM1 [3-4](#)
 console [3-2](#)
 Fibre Channel [3-6](#)
 MGMT 10/100 [3-5](#)
 power cord, jumper [C-11](#)
 power cords, length [C-7](#)
 power-on
 front panel LEDs [1-29](#)
 power supplies
 description [1-36](#)

figure [1-36](#)
 installing (procedure) [2-36](#)
 LED (table) [1-36](#)
 removing (procedure) [2-36](#)
 specifications [B-4](#)
 supported plugs [C-7](#)

Preface [i-xiii](#)

pre-installation

 guidelines [2-2](#)
 options [2-2](#)
 required equipment [2-4](#)
 unpacking the switch [2-4](#)

R

rack-mount installation

 guidelines [A-4](#)
 kit [2-5](#)
 procedures [2-5](#)
 specifications [A-4](#)

ready

 front panel LEDs [1-29](#)

records

 chassis and module information [D-4](#)
 contact and site information [D-3](#)
 site planning and maintenance [D-1](#)

removing

 chassis from rack [2-40](#)
 SFP transceiver cables [3-12](#)
 SFP transceivers [3-10](#)
 X2 transceivers [3-8](#)

S

SAN extension [1-23](#)

self-test passed

 front panel LEDs [1-29](#)

self-test running

Send documentation comments to mdsfeedback-doc@cisco.com

- front panel LEDs [1-29](#)
- services modules
 - ASM [1-30](#)
 - downloading binary image [1-31](#)
 - installing (procedure) [2-33](#)
 - IPS-4 [1-26](#)
 - IPS-8 [1-26](#)
 - MPS-14/2 [1-24](#)
 - removing (procedure) [2-32](#)
 - specifications [B-2](#)
 - SSM [1-28](#)
- SFP transceivers
 - cabling [3-11, 3-12](#)
 - CWDM [1-39, B-18](#)
 - description [1-38, 1-39, 3-8, B-10](#)
 - Fibre Channel [1-38](#)
 - Fibre Channel/Gigabit Ethernet [1-38](#)
 - Fibre Channel/Gigabit Ethernet supported [B-16](#)
 - Fibre Channel specifications [B-10](#)
 - Fibre Channel supported [B-10](#)
 - Gigabit Ethernet [1-39](#)
 - installing [3-9](#)
 - installing a cable [3-11](#)
 - latches supported [3-9](#)
 - maintaining fiber optic cables [3-13](#)
 - maintaining fiber optic cables (procedures) [3-13](#)
 - removing [3-10](#)
 - removing a cable (procedure) [3-12](#)
 - specifications [B-10](#)
 - supported [1-37](#)
- shelf bracket
 - installation (four-post EIA rack) [A-7](#)
 - installation (Telco/IEA) [A-6](#)
 - installing switch [A-8](#)
 - removing kit [A-9](#)
 - Telco/EIA kit (note) [A-4](#)
- site planning, preparation checklist [D-1](#)
- software release requirement [1-2](#)
- specifications
 - airflow [B-2](#)
 - cables [C-1](#)
 - environmental [B-1](#)
 - heat dissipation [B-5](#)
 - modules [B-2](#)
 - physical [B-2](#)
 - pinouts [C-1](#)
 - power [B-4](#)
 - power requirements [B-5](#)
 - SFP transceivers [B-10](#)
- SSM
 - description [1-28](#)
 - figure [1-29](#)
- SSN-16 [1-21](#)
- starting up the switch [2-26](#)
- supervisor modules
 - Cisco MDS 9216A [1-7](#)
 - Cisco MDS 9216i [1-6](#)
 - installing [2-28](#)
 - LEDs (table) [1-8](#)
 - power and heat specification [B-5](#)
 - removing [2-31, 2-32](#)
 - specifications [B-2](#)
- switching modules
 - 12-port 4-Gbps Fibre Channel switching modules [1-15](#)
 - 16-port 2-Gbps Fibre Channel (figure) [1-18](#)
 - 24-port 4-Gbps Fibre Channel switching modules [1-14](#)
 - 32-port 1-Gbps/2-Gbps Fibre Channel (figure) [1-18](#)
 - 4/44-Port 8-Gbps Host-Optimized Fibre Channel switching modules [1-13](#)
 - 48-port 4-Gbps Fibre Channel switching modules [1-13](#)
 - 4-port 10-Gbps Fibre Channel switching modules [1-16](#)
 - description [1-11](#)
 - downloading binary image [1-29](#)
 - features [1-19](#)
 - installing (procedure) [2-33](#)

Send documentation comments to mdsfeedback-doc@cisco.com

LEDs (table) [1-17,1-20](#)
positioning in chassis (figure) [2-30](#)
power and heat specification [B-5](#)
removing [2-31,2-32](#)
removing (procedure) [2-32](#)
specifications [B-2](#)
verifying installation [2-34](#)
switch specifications (table) [B-1](#)
system grounding [2-19](#)

T

T [1-13](#)
Table [B-1](#)
Telco racks (requirements) [A-4](#)
transceivers, supported SFPs. See SFP transceivers

W

weight of modules (table) [B-3](#)

X

X2 transceivers
description [1-38, B-7](#)
figure [3-7](#)
installing [3-8](#)
removing [3-8](#)
supported (table) [B-7](#)