



CHAPTER 4

Configuring IP Services

About IP Services

Cisco MDS 9000 Family switches can route IP traffic between Ethernet and Fibre Channel interfaces. The IP static routing feature is used to route traffic between VSANs. To do so, each VSAN must be in a different IP subnetwork. Each Cisco MDS 9000 Family switch provides the following services for network management systems (NMSs):

- IP forwarding on the out-of-band Ethernet interface (mgmt0) on the front panel of the supervisor modules.
- IP forwarding on in-band Fibre Channel interface using the IP over Fibre Channel (IPFC) function—IPFC specifies how IP frames can be transported over Fibre Channel using encapsulation techniques. IP frames are encapsulated into Fibre Channel frames so NMS information can cross the Fibre Channel network without using an overlay Ethernet network.
- IP routing (default routing and static routing)—If your configuration does not need an external router, you can configure a default route using static routing.

Switches are compliant with RFC 2338 standards for Virtual Router Redundancy Protocol (VRRP) features. VRRP is a restartable application that provides a redundant, alternate path to the gateway switch.



Note

For information about configuring IPv6, see [Chapter 8, “Configuring IPv6 for Gigabit Ethernet Interfaces.”](#)

This chapter includes the following sections:

- [Traffic Management Services, page 4-2](#)
- [Management Interface Configuration, page 4-2](#)
- [Default Gateway, page 4-3](#)
- [IPv4 Default Network Configuration, page 4-6](#)
- [IPFC, page 4-7](#)
- [IPv4 Static Routes, page 4-7](#)
- [Overlay VSANs, page 4-8](#)
- [Configuring Multiple VSANs, page 4-9](#)
- [Virtual Router Redundancy Protocol, page 4-10](#)
- [DNS Server Configuration, page 4-14](#)


Send documentation comments to mdsfeedback-doc@cisco.com

- [Default Settings, page 4-15](#)

Traffic Management Services

In-band options are compliant with and use the RFC 2625 standards. An NMS host running the IP protocol over an Fibre Channel interface can access the switch using the IPFC functionality. If the NMS does not have a Fibre Channel HBA, in-band management can still be performed using one of the switches as an access point to the fabric as shown in [Figure 4-1](#).

Figure 4-1 Management Access to Switches



Management Interface Configuration

The management interface on the switch allows multiple simultaneous Telnet or SNMP sessions. You can remotely configure the switch through the management interface, but first you must configure IP version 4 (IPv4) parameters (IP address, subnet mask) or an IP version 6 (IPv6) address and prefix length so that the switch is reachable. For information on configuring IPv6 addresses, see [Chapter 8, “Configuring IPv6 for Gigabit Ethernet Interfaces.”](#)

On director class switches, a single IP address is used to manage the switch. The active supervisor module's management (mgmt0) interface uses this IP address. The mgmt0 interface on the standby supervisor module remains in an inactive state and cannot be accessed until a switchover happens. After a switchover, the mgmt0 interface on the standby supervisor module becomes active and assumes the same IP address as the previously active supervisor module.



Note

The port on the Ethernet switch to which the MDS management interface is connected should be configured as a host port (also known as access port) instead of a switch port. Spanning tree configuration for that port (on the Ethernet switch) should be disabled. This helps avoid the delay in the MDS management port coming up due to delay from Ethernet spanning tree processing that the Ethernet

Send documentation comments to mdsfeedback-doc@cisco.com

switch would run if enabled. For Cisco Ethernet switches, use either the **switchport host** command in Cisco IOS or the **set port host** command in the Catalyst OS. Refer to the configuration guide for your Ethernet switch.

**Note**

Before you begin to configure the management interface manually, obtain the switch's IP address and IP subnet mask. Also make sure the console cable is connected to the console port.

To configure the mgmt0 Ethernet interface using Device Manager for IPv6, follow these steps:

- Step 1** Select **Interface > Mgmt > Mgmt0**.
- Step 2** Enter the description.
- Step 3** Select the administrative state of the interface.
- Step 4** Check the **CDP** check box to enable CDP.
- Step 5** Enter the IP address mask.
- Step 6** Click **Apply** to apply the changes.

Default Gateway

You can configure a default gateway IPv4 address on your Cisco MDS 9000 Family switch.

This section includes the following topics:

- [About the Default Gateway, page 4-3](#)
- [Configuring the Default Gateway, page 4-3](#)

About the Default Gateway

The default gateway IPv4 address should be configured along with the IPv4 static routing attributes (IP default network, destination prefix, and destination mask, and next hop address). If you configure the static route IP forwarding and the default-network details, these IPv4 addresses will be used regardless of the default-gateway being enabled or disabled.

The default gateway IPv4 address should be configured along with the IPv4 static routing attributes (IP default network, destination prefix, and destination mask, and next hop address).

**Tip**

If you configure the static route IP forwarding and the default-network details, these IPv4 addresses will be used regardless of the default-gateway being enabled or disabled. If these IP addresses are configured but not available, the switch will fall back to using the default gateway IP address, if you have configured it. Be sure to configure IP addresses for all entries in the switch.

Configuring the Default Gateway

To configure an IP route using Fabric Manager, follow these steps:


Send documentation comments to mdsfeedback-doc@cisco.com

Step 1 Select **Switches > Interfaces > Management**, and select **IP** in the Physical Attributes pane.

Step 2 Click the **Route** tab in the information pane.

You see the IP route window showing the switch name, destination, mask, gateway, metric, interface, and active status of each IP route as shown in [Figure 4-2](#).

Figure 4-2 IP Route For Multiple Switches




Switch	Destination, Mask, Gateway	Metric	Interface	Active
sw172-22-46-221	default, 0, 172.22.46.1	1	mgmt0	true
sw172-22-46-182	default, 0, 172.22.46.1	0	mgmt0	true
sw172-22-46-224	default, 0, 172.22.46.1	0	mgmt0	true
sw172-22-47-167	default, 0, 172.22.46.1	0	mgmt0	true
sw172-22-47-132	default, 0, 172.22.46.1	0	mgmt0	true
sw172-22-46-222	default, 0, 172.22.46.1	0	mgmt0	true
sw172-22-46-225	default, 0, 172.22.46.1	0	mgmt0	true
sw172-22-46-223	default, 0, 172.22.46.1	1	mgmt0	true
sw172-22-46-174	default, 0, 172.22.46.1	1	mgmt0	true
sw172-22-47-133	default, 0, 172.22.46.1	0	mgmt0	true
sw172-22-46-233	default, 0, 172.22.46.1	0	mgmt0	true

Step 3 Click the **Create Row** icon to add a new IP route.

You see the dialog box shown in [Figure 4-3](#).

Figure 4-3 User-Defined Command Dialog Box



Switch: sw-dc4-i-151

RouteDest: 10.1.1.0

Mask: 24

Gateway: 10.1.1.2

Metric: 1

Interface: cpp1/1/1

Success.

Create Close

Step 4 Complete the fields in this window.

- Enter the switch name in the Switch field.
- Configure a static route, by entering the destination network ID and subnet mask in the Routedest and Mask fields.
- Configure a default gateway by entering the IP address of the seed switch in the Gateway field.
- Set the Metric and Interface fields.



Note

With Cisco NX-OS Release 4.2(1) and later, CPP interfaces also are available for selection when you create a new IP route.


Step 5 Click the **Create** icon.

To configure an IP route or identify the default gateway using Device Manager, follow these steps:

Send documentation comments to mdsfeedback-doc@cisco.com

- Step 1** Choose **IP > Routes**.
You see the IP Routes window.
- Step 2** Create a new IP route or identify the default gateway on a switch by clicking **Create**.
You see the dialog box shown in [Figure 4-4](#).

Figure 4-4 User-Defined Command Dialog Box



- Step 3** Complete the fields in this window.
- Enter the switch name in the Switch field.
 - Configure a static route, by entering the destination network ID and subnet mask in the Routedest and Mask fields.
 - Configure a default gateway by entering the IP address of the seed switch in the Gateway field.
 - Set the Metric and Interface fields.




Note With Cisco NX-OS Release 4.2(1) and later, CPP interfaces also are available for selection when you create a new IP route.

If you choose the CPP interface, the switch uses the input CPP-assigned IP address and mask to generate the IP route prefix.

- Step 4** Click **Create** to add the IP route.
The new IP route is created as shown in [Figure 4-5](#).

Figure 4-5 IP Route Window



Send documentation comments to mdsfeedback-doc@cisco.com

**Note**

You cannot delete the switch-generated IP route for the CPP interface. If you try to delete the IP route for the CPP interface, SNMP displays this error message:

```
ip: route type not supported.
```

IPv4 Default Network Configuration


If you assign the IPv4 default network address, the switch considers routes to that network as the last resort. If the IPv4 default network address is not available, the switch uses the IPv4 default gateway address. For every network configured with the IPv4 default network address, the switch flags that route as a candidate default route, if the route is available.

**Tip**

If you configure the static route IP forwarding and the default network details, these IPv4 addresses will be used regardless of the default gateway being enabled or disabled. If these IPv4 addresses are configured and not available, the switch will fall back to using the default gateway IPv4 address, if you have configured it. Be sure to configure IPv4 addresses for all entries in the switch if you are using IPv4.

When the Ethernet interface is configured, the switch should point to the gateway router for the IP network. The host accesses the gateway using a gateway switch. This gateway switch is configured as the default gateway. The other switches in the fabric that are connected to the same VSAN as the gateway switch can also be connected through the gateway switch. Every interface connected to this VSAN should be configured with the VSAN IPv4 address of the gateway switch as shown in [Figure 4-6](#).

Figure 4-6 Overlay VSAN Functionality



In [Figure 4-1](#), switch A has the IPv4 address 1.12.11.1, switch B has the IPv4 address 1.12.11.2, switch C has the IPv4 address 1.12.11.3, and switch D has the IPv4 address 1.12.11.4. Switch A is the gateway switch with the Ethernet connection. The NMS uses the IPv4 address 1.1.1.10 to connect to the gateway switch. Frames forwarded to any switch in the overlaid VSAN 1 are routed through the gateway switch.

Send documentation comments to mdsfeedback-doc@cisco.com

Configuring the gateway switch's IPv4 address (1.12.11.1) in the other switches enable the gateway switch to forward the frame to the intended destination. Similarly, if a non-gateway switch in the VSAN forwards a frame to the Ethernet, the frame is routed through the gateway switch.

When forwarding is disabled (default), IP frames are not sent from one interface to another. In these cases, the software performs local IP routing between two switches using the in-band option for Fibre Channel traffic and the mgmt0 option for Ethernet traffic.

When a VSAN is created, a VSAN interface is not created automatically. You need to specifically create the interface.

IPFC

IPFC provides IP forwarding on in-band switch management over a Fibre Channel interface (rather than out-of-band using the Gigabit Ethernet mgmt 0 interface). You can use IPFC to specify that IP frames can be transported over Fibre Channel using encapsulation techniques. IP frames are encapsulated into Fibre Channel frames so NMS information can cross the Fibre Channel network without using an overlay Ethernet network.

Once the VSAN interface is created, you can specify the IP address for that VSAN. You can assign an IPv4 address or an IPv6 address.

**Note**

See the [Chapter 8, “Configuring IPv6 for Gigabit Ethernet Interfaces”](#) for information about configuring IPv6 on the Cisco MDS 9000 Family switches.

IPFC Configuration Guidelines

Follow these guidelines to configure IPFC:

1. Create the VSAN to use for in-band management, if necessary.
2. Configure an IPv4 address and subnet mask for the VSAN interface.
3. Enable IPv4 routing.
4. Verify connectivity.

IPv4 Static Routes

If your network configuration does not need an external router, you can configure IPv4 static routing on your MDS switch.

**Note**

For information about IPv6 static routing, see the [Chapter 8, “Configuring IPv6 for Gigabit Ethernet Interfaces.”](#)

Static routing is a mechanism to configure IPv4 routes on the switch. You can configure more than one static route.

If a VSAN has multiple exit points, configure static routes to direct traffic to the appropriate gateway switch. IPv4 routing is disabled by default on any gateway switch between the out-of-band management interface and the default VSAN, or between directly connected VSANs.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

Overlay VSANs

This section describes overlay VSANs and how to configure them.

This section includes the following topics:

- [About Overlay VSANs, page 4-8](#)
- [Configuring Overlay VSANs, page 4-8](#)

About Overlay VSANs

VSANs enable deployment of larger SANs by overlaying multiple logical SANs, each running its own instance of fabric services, on a single large physical network. This partitioning of fabric services reduces network instability by containing fabric reconfiguration and error conditions within an individual VSAN. VSANs also provide the same isolation between individual VSANs as physically separated SANs. Traffic cannot cross VSAN boundaries and devices may not reside in more than one VSAN. Because each VSAN runs separate instances of fabric services, each VSAN has its own zone server and can be zoned in exactly the same way as SANs without VSAN capability.


Configuring Overlay VSANs

To configure an overlay VSAN, follow these steps:

-
- Step 1** Add the VSAN to the VSAN database on all switches in the fabric.
 - Step 2** Create a VSAN interface for the VSAN on all switches in the fabric. Any VSAN interface belonging to the VSAN has an IP address in the same subnet. Create a route to the IPFC cloud on the IP side.
 - Step 3** Configure a default route on every switch in the Fibre Channel fabric pointing to the switch that provides NMS access.
 - Step 4** Configure the default gateway (route) and the IPv4 address on switches that point to the NMS as shown in [Figure 4-7](#).

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 4-7 Overlay VSAN Configuration Example



Configuring Multiple VSANs


More than one VSAN can be used to segment the management network in multiple subnets. An active interface must be present on the switch for the VSAN interface to be enabled.

To configure multiple VSANs, follow these steps:

- Step 1** Add the VSAN to the VSAN database on any switch in the fabric.
- Step 2** Create a VSAN interface for the appropriate VSAN on any switch in the fabric.
- Step 3** Assign an IP address on every VSAN interface on the same subnet as the corresponding VSAN.
- Step 4** Define the multiple static routes on the Fibre Channel switches and the IP cloud as shown in [Figure 4-8](#).

Send documentation comments to mdsfeedback-doc@cisco.com

Figure 4-8 Multiple VSAN Configuration Example



Virtual Router Redundancy Protocol

Cisco MDS 9000 Family switches are compliant with RFC 2338 standards for Virtual Router Redundancy Protocol (VRRP) features. This section provides details on the VRRP feature.

This section includes the following topics:

- [About VRRP, page 4-11](#)
- [Configuring VRRP, page 4-12](#)

Send documentation comments to mdsfeedback-doc@cisco.com

About VRRP

Cisco MDS 9000 Family switches are compliant with RFC 2338 standards for Virtual Router Redundancy Protocol (VRRP) features. VRRP provides a redundant alternative path to the gateway switch, which has connectivity to the NMS. VRRP has the following characteristics and advantages:


- VRRP is a restartable application.
- When a VRRP master fails, the VRRP backup takes over within three times the advertisement time.
- VRRP over Ethernet, VRRP over VSAN, and Fibre Channel functions are implemented as defined in RFC 2338 and the draft-ietf-vrrp-ipv6 specification.
- A virtual router is mapped to each VSAN and Ethernet interface with its unique virtual router IP, virtual router MAC, and VR ID.
- VR IDs can be reused in multiple VSANs with different virtual router IP mapping.
- Both IPv4 and IPv6 is supported.
- The management interface (mgmt 0) supports only one virtual router group. All other interfaces each support up to seven virtual router groups, including both IPv4 and IPv6 combined. Up to 255 virtual router groups can be assigned in each VSAN.
- VRRP security provides three options, including no authentication, simple text authentication, and MD5 authentication.



Note If you are using IPv6, you must either configure an IPv6 address on the interface or enable IPv6 on the interface. For more information about IPv6, see [Chapter 8, “Configuring IPv6 for Gigabit Ethernet Interfaces.”](#)

In [Figure 4-9](#), switch A is the VRRP master and switch B is the VRRP backup switch. Both switches have an IP address to VRRP mapping configured. The other switches set switch A as the default gateway. If switch A fails, the other switches do not have to change the routing configurations as switch B automatically becomes the master and takes over the function of a gateway.


Figure 4-9 VRRP Functionality



Send documentation comments to mdsfeedback-doc@cisco.com

In [Figure 4-10](#), the fabric example has two virtual router groups (VR1 and VR 2) because a virtual router cannot span across different types of interfaces. In both switch 1 and switch 2, the Ethernet interface is in VR 1 and the FC interface is in VR 2. Each virtual router is uniquely identified by the VSAN interface and the VR ID.

Figure 4-10 Redundant Gateway



Configuring VRRP

This section describes how to configure VRRP and includes the following topics:

- [Adding and Deleting a Virtual Router, page 4-12](#)
- [Virtual Router Initiation, page 4-13](#)
- [Adding Virtual Router IP Addresses, page 4-13](#)
- [Setting the Priority for the Virtual Router, page 4-13](#)
- [Setting the Time Interval for Advertisement Packets, page 4-13](#)
- [Configuring or Enabling Priority Preemption, page 4-13](#)
- [Setting Virtual Router Authentication, page 4-14](#)
- [Tracking the Interface Priority, page 4-14](#)

Adding and Deleting a Virtual Router

All VRRP configurations should be replicated across switches in a fabric that runs VRRP.



Note

The total number of VRRP groups that you can configure on a Gigabit Ethernet port, including main interfaces and subinterfaces, cannot exceed seven. This limitation applies to both IPv4 and IPv6 groups.

Send documentation comments to mdsfeedback-doc@cisco.com

Virtual Router Initiation

By default, a virtual router is always disabled. VRRP can be configured only if this state is enabled. Be sure to configure at least one IP address, either IPv4 or IPv6, before attempting to enable a VR.

Adding Virtual Router IP Addresses

One virtual router IP address can be configured for a virtual router. If the configured IP address is the same as the interface IP address, this switch automatically owns the IP address. You can configure either an IPv4 address or an IPv6 address.

According to the VRRP specification, the master VRRP router drops the packets addressed to the virtual router's IP address because the virtual router is only intended as a next-hop router to forward packets. In MDS switches however, some applications require that packets addressed to virtual router's IP address be accepted and delivered to them. By using the **secondary** option to the virtual router IPv4 address, the VRRP router will accept these packets when it is the master.

To manage IP addresses for virtual routers from Device Manager, follow these steps:

-
- Step 1** Choose **IP > VRRP**. You see the **Operations** tab of the VRRP dialog box.
 - Step 2** Click the **IP Addresses** tab on the VRRP dialog box.
 - Step 3** To create a new VRRP entry, click **Create**. You see the Create VRRP IP Addresses window.
 - Step 4** Complete the fields in this window to create a new VRRP IP address, and click **OK** or **Apply**.
-

Setting the Priority for the Virtual Router

The valid range to assign a virtual router priority is 1 to 254 with 1 being the lowest priority and 254 being the highest priority. The default value is 100 for switches with secondary IP addresses and 255 for switches with the primary IP address.

Setting the Time Interval for Advertisement Packets

The valid time range for an advertisement packet on an interface using IPv4 is between 1 and 255 seconds. The default value is 1 (one) second. If the switch has the primary IP address, this time must be specified.

Configuring or Enabling Priority Preemption

You can enable a higher-priority backup virtual router to preempt the lower-priority master virtual router.

**Note**

If the virtual IP address is also the IP address for the interface, then preemption is implicitly applied.

**Note**

The VRRP preemption is not supported on IP storage Gigabit Ethernet interfaces.

Send documentation comments to mdsfeedback-doc@cisco.com

Setting Virtual Router Authentication

VRRP security provides three options, including simple text authentication, MD5 authentication, and no authentication.

- Simple text authentication uses a unique, 1 to 8 character password that is used by all switches participating in the same virtual router. This password should be different from other security passwords.
- MD5 authentication uses a unique, 16 character key that is shared by all switches participating in the same virtual router. This secret key is shared by all switches in the same virtual router.
- No authentication is the default option.

You can configure the key using the authentication option in the VRRP submode and distribute it using the configuration file. The security parameter index (SPI) settings assigned in this option should be unique for each VSAN.



Note All VRRP configurations must be duplicated.



Note VRRP router authentication does not apply to IPv6.

Tracking the Interface Priority

Interface state tracking changes the priority of the virtual router based on the state of another interface in the switch. When the tracked interface is down, the priority of the virtual router is restored to the interface state tracking value. When the tracked interface is up, the priority reverts to the priority value for the virtual router (see the [“Setting the Priority for the Virtual Router”](#) section on page 4-13). You can track the state of either a specified VSAN interface or the management interface (mgmt 0). The interface state tracking feature is disabled by default.



Note For interface state tracking to function, you must enable preemption on the interface. See the [“Configuring or Enabling Priority Preemption”](#) section on page 4-13.

DNS Server Configuration

The DNS client on the switch communicates with the DNS server to perform the IP address-name server correspondence.

The DNS server may be dropped after two attempts because of one of the following reasons:

- The IP address or the switch name is wrongly configured.
- The DNS server is not reachable because external reasons (reasons beyond our control).



Note When accessing a Telnet host, if the DNS server is not reachable (for any reason) the switch login prompt may take a longer time to appear. If so, verify that the DNS server is accurately configured and reachable.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

Default Settings

Table 4-1 lists the default settings for DNS features.

Table 4-1 *Default DNS Settings*

Parameters	Default
Domain lookup	Disabled
Domain name	Disabled
Domains	None
Domain server	None
Maximum domain servers	6

Table 4-2 lists the default settings for VRRP features.

Table 4-2 *Default VRRP Settings*

Parameters	Default
Virtual router state	Disabled
Maximum groups per VSAN	255
Maximum groups per Gigabit Ethernet port	7
Priority preemption	Disabled
Virtual router priority	100 for switch with secondary IP addresses 255 for switches with the primary IP address
Priority interface state tracking	Disabled
Advertisement interval	1 second for IPv4 100 centiseconds for IPv6

Send documentation comments to mdsfeedback-doc@cisco.com