



P Commands

This chapter describes the Cisco Nexus 1010 commands that begin with the letter P.

packet vlan

To modify the VLAN ID of the Virtual Supervisor Module (VSM) domain packet VLAN, use the **packet vlan** command.

packet vlan *vlanid*

Syntax Description	<i>vlanid</i>	Number that identifies the VSM domain packet VLAN. The range is from 1 to 3967 and 4048 to 4093.
---------------------------	---------------	--

Defaults	None
-----------------	------

Command Modes	SVS domain configuration (config-svs-domain)
----------------------	--

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

Examples This example shows how to modify the VLAN ID of the VSM domain packet VLAN to be 1117:

```
n1010# config t
n1010(config)# svs-domain
n1010(config-svs-domain)# packet vlan 1117
```

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	login virtual-service-blade	Logs you into the Cisco Nexus 1000V CLI for the VSM that you are modifying.
	show svcs-domain	Displays the domain configuration for the VSM.
	control vlan	Modifies the VLAN ID of the VSM domain control VLAN.

Send document comments to nexus1k-docfeedback@cisco.com.

password strength-check

To enable password-strength checking, use the **password strength-check** command. To disable the checking of password strength, use the **no** form of this command.

password strength-check

no password strength-check

Syntax Description This command has no arguments or keywords.

Defaults This feature is enabled by default.

Command Modes Global configuration (config)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

Examples This example shows how to enable the checking of password strength:

```
n1010# config t
n1010(config)# password strength-check
n1010(config)#
```

This example shows how to disable the checking of password strength:

```
n1010# config t
n1010(config)# no password strength-check
n1010(config)#
```

Related Commands	Command	Description
	show password strength-check	Displays the configuration for checking password strength.
	username	Creates a user account.
	role name	Names a user role and places you in role configuration mode for that role.

Send document comments to nexus1k-docfeedback@cisco.com.

ping

To determine the network connectivity to another device using IPv4 addressing, use the **ping** command.

```
ping [dest-ipv4-address | hostname | multicast multicast-group-address interface [ethernet
slot/port | loopback number | mgmt0 | port-channel channel-number | vethernet number]]
[count {number | unlimited}] [df-bit] [interval seconds] [packet-size bytes] [source
src-ipv4-address] [timeout seconds] [vrf vrf-name]
```

Syntax Description

<i>dest-ipv4-address</i>	IPv4 address of destination device. The format is <i>A.B.C.D</i> .
<i>hostname</i>	Hostname of destination device. The hostname is case sensitive.
multicast	(Optional) Specifies a multicast ping.
<i>multicast-group-address</i>	Multicast group address. The format is <i>A.B.C.D</i> .
interface	Specifies the interface to send the multicast packet.
ethernet <i>slot/port</i>	(Optional) Specifies the slot and port number for the Ethernet interface.
loopback <i>number</i>	(Optional) Specifies a virtual interface number from 0 to 1023.
mgmt0	(Optional) Specifies the management interface.
port-channel <i>channel-number</i>	(Optional) Specifies a port-channel interface in the range from 1 to 4096.
vethernet <i>number</i>	(Optional) Specifies a virtual Ethernet interface in the range from 1 to 1048575.
count	(Optional) Specifies the number of transmissions to send.
<i>number</i>	Number of pings. The range is from 1 to 655350. The default is 5.
unlimited	Allows an unlimited number of pings.
df-bit	(Optional) Enables the do-not-fragment bit in the IPv4 header. The default is disabled.
interval <i>seconds</i>	(Optional) Specifies the interval in seconds between transmissions. The range is from 0 to 60. The default is 1 second.
packet-size <i>bytes</i>	(Optional) Specifies the packet size in bytes to transmit. The range is from 1 to 65468. The default is 56 bytes.
source <i>scr-ipv4-address</i>	(Optional) Specifies the source IPv4 address to use. The format is <i>A.B.C.D</i> . The default is the IPv4 address for the management interface of the device.
timeout <i>seconds</i>	(Optional) Specifies the nonresponse timeout interval in seconds. The range is from 1 to 60. The default is 2 seconds.
vrf <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) name. The default is the default VRF.

Defaults

For the default values, see the “Syntax Description” section for this command.

Command Modes

Any

Send document comments to nexus1k-docfeedback@cisco.com.

SupportedUserRoles network-admin

Command History

Release	Modification
4.0(4)SP1(1)	This command was introduced.

Examples

This example shows how to determine connectivity to another device using IPv4 addressing:

```
n1010# ping 172.28.231.246 vrf management
PING 172.28.231.246 (172.28.231.246): 56 data bytes
Request 0 timed out
64 bytes from 172.28.231.246: icmp_seq=1 ttl=63 time=0.799 ms
64 bytes from 172.28.231.246: icmp_seq=2 ttl=63 time=0.597 ms
64 bytes from 172.28.231.246: icmp_seq=3 ttl=63 time=0.711 ms
64 bytes from 172.28.231.246: icmp_seq=4 ttl=63 time=0.67 ms

--- 172.28.231.246 ping statistics ---
5 packets transmitted, 4 packets received, 20.00% packet loss
round-trip min/avg/max = 0.597/0.694/0.799 ms
```

Related Commands

Command	Description
ping6	Determines connectivity to another device using IPv6 addressing.

Send document comments to nexus1k-docfeedback@cisco.com.

port-profile

To create a port profile and enter port-profile configuration mode, use the **port-profile** command. To remove the port profile configuration, use the **no** form of this command.

port-profile *name*

no port-profile *name*

Syntax Description	<i>name</i> Port profile name. The name can be up to 80 characters.				
Defaults	None				
Command Modes	Global configuration (config)				
SupportedUserRoles	network-admin				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(4)SP1(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.0(4)SP1(1)	This command was introduced.
Release	Modification				
4.0(4)SP1(1)	This command was introduced.				
Usage Guidelines	The port profile name must be unique for each port profile on the Cisco Nexus 1000V.				
Examples	<p>This example shows how to create a port profile with the name AccessProf:</p> <pre>n1010# configure terminal n1010(config)# port-profile AccessProf n1010(config-port-prof)</pre> <p>This example shows how to remove the port profile with the name AccessProf:</p> <pre>n1010# configure terminal n1010(config)# no port-profile AccessProf n1010(config)</pre>				
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>show port-profile <i>name</i></td> <td>Displays information about the port profiles.</td> </tr> </tbody> </table>	Command	Description	show port-profile <i>name</i>	Displays information about the port profiles.
Command	Description				
show port-profile <i>name</i>	Displays information about the port profiles.				

Send document comments to nexus1k-docfeedback@cisco.com.

pwd

To view the current directory, use the **pwd** command.

pwd

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any

SupportedUserRoles network-admin
network-operator

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

Examples This example shows how to view the current directory:

```
n1010# pwd
bootflash:
n1010#
```

Related Commands	Command	Description
	cd	Changes the current working directory.
	dir	Displays the directory contents.
	rmdir	Removes a directory.

Send document comments to nexus1k-docfeedback@cisco.com.