DHCP, DAI, and IPSG

This chapter describes how to identify and resolve problems related to the following security features:

- Dynamic Host Configuration Protocol (DHCP) Snooping
- Dynamic ARP Inspection (DAI)
- IP Source Guard (IPSG)

This chapter includes the following sections:

- Information About DHCP Snooping, page 19-1
- Information About Dynamic ARP Inspection, page 19-2
- Information About IP Source Guard, page 19-2
- Guidelines and Limitations for Troubleshooting, page 19-2
- Problems with DHCP Snooping, page 19-3
- Troubleshooting Dropped ARP Responses, page 19-4
- Problems with IP Source Guard, page 19-5
- Collecting and Evaluating Logs, page 19-5
- DHCP, DAI, and IPSG Troubleshooting Commands, page 19-6

Information About DHCP Snooping

DHCP snooping acts like a firewall between untrusted hosts and trusted DHCP servers by doing the following:

- Validates DHCP messages received from untrusted sources and filters out invalid response messages from DHCP servers.
- Builds and maintains the DHCP snooping binding database, which contains information about untrusted hosts with leased IP addresses.
- Uses the DHCP snooping binding database to validate subsequent requests from untrusted hosts.

Dynamic ARP inspection (DAI) and IP Source Guard also use information stored in the DHCP snooping binding database.

For detailed information about configuring DHCP snooping, see the *Cisco Nexus 1000V Security Configuration Guide*.

Information About Dynamic ARP Inspection

DAI is used to validate ARP requests and responses as follows:

- Intercepts all ARP requests and responses on untrusted ports.
- Verifies that a packet has a valid IP-to-MAC address binding before updating the ARP cache or forwarding the packet.
- Drops invalid ARP packets.

DAI can determine the validity of an ARP packet based on valid IP-to-MAC address bindings stored in a Dynamic Host Configuration Protocol (DHCP) snooping binding database. This database is built by DHCP snooping when it is enabled on the VLANs and on the device. It may also contain static entries that you have created.

For detailed information about configuring DAI, see the Cisco Nexus 1000V Security Configuration Guide.

Information About IP Source Guard

IP Source Guard is a per-interface traffic filter that permits IP traffic only when the IP address and MAC address of each packet matches the IP and MAC address bindings of dynamic or static IP source entries in the Dynamic Host Configuration Protocol (DHCP) snooping binding table.

For detailed information about configuring IP Source Guard, see the Cisco Nexus 1000V Security Configuration Guide.

Guidelines and Limitations for Troubleshooting

The following guidelines and limitations apply when troubleshooting DHCP snooping, Dynamic ARP Inspection, or IP Source Guard:

- A maximum of 2000 DHCP entries can be snooped and learned system-wide in the DVS. This is a combined total for both entries learned dynamically and entries configured statically.
- Rate limits on interfaces must be set to high values for trusted interfaces such as VSD SVM ports or vEthernet ports connecting to DHCP servers.

For detailed guidelines and limitations used in configuring these features, see the *Cisco Nexus 1000V Security Configuration Guide*.

Problems with DHCP Snooping

The following are symptoms, possible causes, and solutions for problems with DHCP snooping.

Symptom	Possible Causes	Solution			
With snooping configured, DHCP client is not able to obtain an IP address from the server.	IP address was not added to binding database. Faulty connection between DHCP server and client.	 Verify the connection between the DHCP server(s) and the host connected to the client. vmkping If the connection between DHCP server and the host is broken, do the following: Check the configuration in the upstream switch, for example, verifying that the VLAN is allowed, etc. Make sure the server itself is up and 			
	The interface of the DHCP server(s) connected to the DVS as a VM is not trusted.	 on the VSM, verify that the interface is trusted. show ip dhcp snooping On the VSM, verify the vEthernet interface attached to the server is trusted. module vem mod# execute vemcmd show dhcps interfaces 			
	DHCP requests from the VM are not reaching the server for acknowledgement.	On the DHCP server, log in and use a packet captur utility to verify requests and acknowledgements in packets.			
	DHCP requests and acknowledgements are not reaching the Cisco Nexus 1000V.	 From the client vEthernet interface, SPAN the packets to verify they are reaching the client. On the host connected to the client, enable VEM packet capture to verify incoming requests and acknowledgements in packets. 			
	The Cisco Nexus 1000V is dropping packets.	On the VSM, verify DHCP statistics. show ip dhcp snooping statistics module vem mod# execute vemcmd show dhcps stats			

Troubleshooting Dropped ARP Responses

The following are possible causes, and solutions for dropped ARP responses.

Possible Causes	Solution				
ARP inspection is not configured on the VSM	On the VSM, verify that ARP inspection is configured as expected.				
	show ip arp inspection				
	For detailed information about configuring DAI, see the Cisco Nexus 1000V Security Configuration Guide				
DHCP snooping is not enabled globally on the	On the VSM, verify the DHCP snooping configuration.				
VSM, or is not enabled on the VLAN.	show ip dhcp snooping				
	For detailed information about enabling DHCP, and configuring DAI, see the Cisco Nexus 1000V Security Configuration Guide.				
DHCP snooping is not enabled on the VEM, or	1. From the VSM, verify the VEM DHCP snooping configuration.				
is not enabled on the VLAN.	module vem mod# execute vemcmd show dhcps vlan				
	2. Do one of the following:				
	 Correct any errors in the VSM DHCP configuration. For detailed information, see the Cisco Nexus 1000V Security Configuration Guide. 				
	 If the configuration appears correct on the VSM but fails on the VEM, capture and analyze the error logs from both VSM and the VEM to identify the reason for the failure. 				
If snooping is disabled, the binding entry is not	1. On the VSM, display the binding table.				
statically configured in the binding table.	show ip dhep snooping binding				
	2. Correct any errors in the static binding table.				
	For detailed information about clearing entries from the table, enabling DHCP, and configuring DAI, see the <i>Cisco Nexus 1000V Security Configuration Guide</i> .				
The binding corresponding to the VM sending	1. On the VSM, display the binding table.				
the ARP response is not present in the binding table.	show ip dhep snooping binding				
table.	2. Correct any errors in the static binding table.				
	For detailed information about clearing entries from the table, enabling DHCP, and configuring DAI, see the <i>Cisco Nexus 1000V Security Configuration Guide</i> .				
	3. If all configurations are correct, make sure to turn on DHCP snooping before DAI or IPSG. This is to make sure the Cisco Nexus 1000V has enough time to add the binding in the snooping database.				
	For more information, see the Cisco Nexus 1000V Security Configuration Guide.				

Problems with IP Source Guard

The following are symptoms, possible causes, and solutions for problems with IP Source Guard.

Symptom	Possible Causes	Solution		
Traffic disruptions	ARP inspection is not configured on the VSM.	On the VSM, verify that IP Source Guard is configured as expected.		
		show port-profile name profile_name		
		show running interface if_ID		
		show ip verify source		
		For detailed information about configuring IP Source Guard, see the <i>Cisco Nexus 1000V Security Configuration Guide</i>		
	The IP address corresponding to the vEthernet interface is not in the snooping binding table.	1. On the VSM, display the binding table.		
		show ip dhep snooping binding		
		2. Configure the missing static entry or renew the lease on the VM.		
		3. On the VSM, display the binding table again to verify the entry is added correctly.		
		show ip dhep snooping binding		

Collecting and Evaluating Logs

You can use the commands in this section from the VSM to collect and view logs related to DHCP, DAI, and IP Source Guard.

- VSM Logging, page 19-5
- Host Logging, page 19-6

VSM Logging

You can use the commands in this section from the VSM to collect and view logs related to DHCP, DAI, and IP Source Guard.

VSM Command	Description
debug dhcp all	Enable debug all for dhcp configuration flags
debug dhcp errors Enable debugging of errors	
debug dhcp mts-errors Enable debugging of mts errors	
debug dhcp mts-events	Enable debugging of mts events
debug dhcp pkt-events	Enable debugging of pkt events
debug dhcp pss-errors	Enable debugging of pss errors
debug dhcp pss-events	Enable debugging of pss events

Host Logging

You can use the commands in this section from the ESX host to collect and view logs related to DHCP, DAI, and IP Source Guard.

ESX Host Command	Description		
echo "logfile enable" > /tmp/dpafifo	Enables DPA debug logging.		
	Logs are output to /var/log/vemdpa.log file.		
echo "debug sfdhcpsagent all" > /tmp/dpafifo	Enables DPA DHCP agent debug logging.		
	Logs are output to /var/log/vemdpa.log file.		
vemlog debug sfdhcps all	Enables datapath debug logging, and captures logs for the data packets sent between the client and the server.		
vemlog debug sfdhcps_config all	Enables datapath debug logging, and captures logs for configuration coming from the VSM.		
vemlog debug sfdhcps_binding_table all	Enables datapath debug logging, and captures logs corresponding to binding database changes.		

DHCP, DAI, and IPSG Troubleshooting Commands

You can use the commands in this section to troubleshoot problems related to DHCP snooping, DAI, and IP Source Guard.

Command	Description		
show running-config dhcp	Displays the DHCP snooping, DAI, and IP Source Guard configuration		
	See Example 19-1 on page 19-7.		
show ip dhcp snooping	Displays general information about DHCP snooping.		
	See Example 19-2 on page 19-7.		
show ip dhcp snooping binding	Display the contents of the DHCP snooping binding table.		
	See Example 19-3 on page 19-7.		
show feature	Displays the features available, such as DHCP, and whether they are enabled.		
	See Example 19-4 on page 19-8.		
show ip arp inspection	Displays the status of DAI.		
	See Example 19-5 on page 19-8.		
show ip arp inspection interface vethernet interface-number	Displays the trust state and ARP packet rate for a specific interface.		
	See Example 19-6 on page 19-8.		

Command	Description
show ip arp inspection vlan vlan-ID	Displays the DAI configuration for a specific VLAN.
	See Example 19-7 on page 19-8.
show ip verify source	Displays interfaces where IP source guard is enabled and the IP-MAC address bindings.
	See Example 19-8 on page 19-9.
<pre>show system internal dhcp { event-history mem-stats msgs }</pre>	Debugs any issues in the filter-mode configuration. See Example 19-9 on page 19-9, Example 19-10 on page 19-9, and Example 19-11 on page 19-10.
Debug dhcp all	Enables debug all for dhcp configuration flags on the VSM. See Example 19-12 on page 19-10.

Example 19-1 show running-config dhcp

```
n1000v# show running-config dhcp
!Command: show running-config dhcp
!Time: Wed Feb 16 14:20:36 2011
version 4.2(1)SV1(4)
feature dhcp
no ip dhcp relay
```

Example 19-2 show ip dhcp snooping

n1000v#

```
n1000v# show ip dhcp snooping
DHCP snooping service is enabled
Switch DHCP snooping is enabled
DHCP snooping is configured on the following VLANs:
1,13
DHCP snooping is operational on the following VLANs:

1
Insertion of Option 82 is disabled
Verification of MAC address is enabled
DHCP snooping trust is configured on the following interfaces:
Interface Trusted
------
vEthernet 3 Yes

n1000v#
```

Example 19-3 show ip dhcp snooping binding

n1000v# show ip dhcp snooping binding							
MacAddress	IpAddress	LeaseSec	Type	VLAN	Interface		
Of:00:60:b3:23:33	10.3.2.2	infinite	static	13	vEthernet 6		
Of:00:60:b3:23:35	10.2.2.2	infinite	static	100	vEthernet 10		
n1000v#							

Example 19-4 show feature

n1000v# show feature		
Feature Name	Instance	State
dhcp-snooping	1	enabled
http-server	1	enabled
ippool	1	enabled
lacp	1	enabled
lisp	1	enabled
lisphelper	1	enabled
netflow	1	disabled
port-profile-roles	1	enabled
private-vlan	1	disabled
sshServer	1	enabled
tacacs	1	enabled
telnetServer	1	enabled
n1000v#		

Example 19-5 show ip arp inspection

 ${\tt n1000v\#}$ show ip arp inspection

Source Mac Validation : Disabled Destination Mac Validation : Disabled IP Address Validation : Disabled

Vlan : 1

Configuration : Disabled Operation State : Inactive

Vlan : 5

Configuration : Disabled Operation State : Inactive

Vlan : 100

Configuration : Disabled Operation State : Inactive

Vlan : 101

Configuration : Disabled Operation State : Inactive

n1000v#

Example 19-6 show ip arp inspection interface

 $n1000\mathrm{v}\#$ show ip arp inspection interface vethernet 6

Interface Trust State
---vEthernet 6 Trusted
n1000v#

Example 19-7 show ip arp inspection vlan

n1000v# show ip arp inspection vlan 13

Source Mac Validation : Disabled Destination Mac Validation : Enabled IP Address Validation : Enabled

n1000v#

Example 19-8 show ip verify source

```
n1000v# show ip arp inspection vlan 13
```

IP source guard is enabled on the following interfaces:

Vethernet1

Example 19-9 show system internal dhcp event-history msgs

n1000v# show system internal dhcp event-history msgs

- 1) Event:E_MTS_RX, length:60, at 809122 usecs after Mon Oct 8 20:59:08 2012
 [RSP] Opc:MTS_OPC_PDL32(148511), Id:0X00F132AB, Ret:SUCCESS
 Src:0x00000302/747, Dst:0x00000201/360, Flags:None
 HA_SEQNO:0X00000000, RRtoken:0x00009498, Sync:UNKNOWN, Payloadsize:132
 Payload:
 0x0000: 00 00 00 03 00 00 00 01 00 00 64 00 00 07
- 2) Event:E_MTS_RX, length:60, at 809100 usecs after Mon Oct 8 20:59:08 2012
 [RSP] Opc:MTS_OPC_PDL32(148511), Id:0X00E01555, Ret:SUCCESS
 Src:0x00000502/747, Dst:0x00000201/360, Flags:None
 HA_SEQNO:0X00000000, RRtoken:0x00009497, Sync:UNKNOWN, Payloadsize:132
 Payload:
 0x0000: 00 00 00 03 00 00 00 01 00 00 64 00 00 00 07
- 3) Event:E_MTS_RX, length:60, at 809079 usecs after Mon Oct 8 20:59:08 2012 [RSP] Opc:MTS_OPC_PDL32(148511), Id:0X006BE1FC, Ret:SUCCESS Src:0x00000602/747, Dst:0x00000201/360, Flags:None HA_SEQNO:0X00000000, RRtoken:0x00009496, Sync:UNKNOWN, Payloadsize:132 Payload:
 0x0000: 00 00 00 03 00 00 00 01 00 00 64 00 00 00 07
- 4) Event:E_MTS_RX, length:60, at 809028 usecs after Mon Oct 8 20:59:08 2012
 [RSP] Opc:MTS_OPC_PDL32(148511), Id:0X00F132AA, Ret:SUCCESS
 Src:0x00000302/747, Dst:0x00000201/360, Flags:None
 HA_SEQNO:0X00000000, RRtoken:0x00009474, Sync:UNKNOWN, Payloadsize:132
 Payload:
 0x0000: 00 00 00 03 00 00 01 00 00 064 00 00 07
 contd.

Example 19-10 show system internal dhcp mem-stats detail

VSM-N1k# show system internal dhcp mem-stats detail

Private Mem stats for UUID : Malloc track Library(103) Max types: 5

TYPE NAME	Ī	ALLOCS		BYTES
	CURR	MAX	CURR	MAX
2 MT_MEM_mtrack_hdl	33	34	19236	19384
3 MT_MEM_mtrack_info	588	880	9408	14080
4 MT_MEM_mtrack_lib_name	882	1174	42246	56230

Total bytes: 70890 (69k)

Private Mem stats for UUID : Non mtrack users(0) Max types: 149

TYPE	NAME		ALLOCS		BYTES
		CURR	MAX	CURR	MAX
11	<pre>[r-xp]/isan/plugin/0/isan/lib/libavl.so</pre>	3421	3421	68360	68360
26	<pre>[r-xp]/isan/plugin/0/isan/lib/libddbcom</pre>	116	141	302445	308307
47	<pre>[r-xp]/isan/plugin/0/isan/lib/libindxob</pre>	6	6	456	456
50	<pre>[r-xp]/isan/plugin/0/isan/lib/libip.so.</pre>	1	1	212	212
64	<pre>[r-xp]/isan/plugin/0/isan/lib/libmpmts.</pre>	0	9	0	785
66	<pre>[r-xp]/isan/plugin/0/isan/lib/libmts.so</pre>	10	11	972	984
68	<pre>[r-xp]/isan/plugin/0/isan/lib/libnetsta</pre>	1	2	704	1350
81	<pre>[r-xp]/isan/plugin/0/isan/lib/libpss.so</pre>	158	262	101579	204281
85	<pre>[r-xp]/isan/plugin/0/isan/lib/libsdb.so</pre>	44	44	3914	3914
89	<pre>[r-xp]/isan/plugin/0/isan/lib/libsmm.so</pre>	3	3	216	216
111	<pre>[r-xp]/isan/plugin/0/isan/lib/libutils.</pre>	4	7	69	349
112	<pre>[r-xp]/isan/plugin/0/isan/lib/libvdc_mg</pre>	0	1	0	20
118	<pre>[r-xp]/isan/plugin/2/isan/bin/dhcp_snoo</pre>	0	2	0	64
121	<pre>[r-xp]/isan/plugin/2/isan/lib/libpdlser</pre>	4	29	208	1016
128	[r-xp]/lib/ld-2.3.3.so	33	33	5363	5371
131	<pre>[r-xp]/lib/tls/libc-2.3.3.so</pre>	51	51	1347	1637
134	<pre>[r-xp]/lib/tls/libpthread-2.3.3.so</pre>	1	1	33	33
138	<pre>[r-xp]/usr/lib/libglib-2.0.so.0.600.1</pre>	15	16	10372	10392
145	<pre>[r-xp]/isan/plugin/1/isan/lib/libvem_mg</pre>	0	1	0	1940

Total bytes: 496250 (484k)

contd.

Example 19-11 show system internal dhcp msgs

n1000v# show system internal dhcp msgs

- 1) Event:E_DEBUG, length:75, at 409832 usecs after Mon Oct 8 20:57:48 2012
 [16843009] Session close, handle -767541913, sess-id 0xff0101ba02812d08, state 3
- 2) Event:E_DEBUG, length:62, at 399944 usecs after Mon Oct 8 20:57:48 2012
 [16843009] PPF session open session-id 0xff0101ba02812d08, msg_id 0
- 3) Event: E_DEBUG, length: 30, at 399866 usecs after Mon Oct $\,$ 8 20:57:48 2012 [16843009] PPF goto setting state 1 $\,$
- 4) Event: E_DEBUG, length: 23, at 682346 usecs after Mon Oct $\,$ 8 20:57:11 2012 [16843009] Processed log-mts contd

Example 19-12 debug dhcp all

n1000v# debug dhcp all

#