



Configuring DNS

This chapter contains the following sections:

- [DNS Client Overview, page 1](#)
- [Prerequisites for DNS Clients, page 2](#)
- [Licensing Requirements for DNS Clients, page 2](#)
- [Default Settings, page 2](#)
- [Configuring DNS Clients, page 3](#)

DNS Client Overview

If your network devices require connectivity with devices in networks for which you do not control name assignment, you can assign device names that uniquely identify your devices within the entire internetwork using the domain name server (DNS). DNS uses a hierarchical scheme for establishing host names for network nodes, which allows local control of the segments of the network through a client-server scheme. The DNS system can locate a network device by translating the host name of the device into its associated IP address.

On the Internet, a domain is a portion of the naming hierarchy tree that refers to general groupings of networks based on organization type or geography. Domain names are pieced together with periods (.) as the delimiting characters. For example, Cisco is a commercial organization that the Internet identifies by a com domain, so its domain name is cisco.com. A specific host name in this domain, the File Transfer Protocol (FTP) system, for example, is identified as ftp.cisco.com.

Name Servers

Name servers keep track of domain names and know the parts of the domain tree for which they have complete information. A name server may also store information about other parts of the domain tree. To map domain names to IP addresses in Cisco NX-OS, you must first identify the host names, then specify a name server, and enable the DNS service.

Cisco NX-OS allows you to statically map IP addresses to domain names. You can also configure Cisco NX-OS to use one or more domain name servers to find an IP address for a host name.

DNS Operation

A name server handles client-issued queries to the DNS server for locally defined hosts within a particular zone as follows:

- An authoritative name server responds to DNS user queries for a domain name that is under its zone of authority by using the permanent and cached entries in its own host table. If the query is for a domain name that is under its zone of authority but for which it does not have any configuration information, the authoritative name server simply replies that no such information exists.
- A name server that is not configured as the authoritative name server responds to DNS user queries by using information that it has cached from previously received query responses. If no router is configured as the authoritative name server for a zone, queries to the DNS server for locally defined hosts will receive nonauthoritative responses.

Name servers answer DNS queries (forward incoming DNS queries or resolve internally generated DNS queries) according to the forwarding and lookup parameters configured for the specific domain.

High Availability

Cisco NX-OS supports stateless restarts for the DNS client. After a reboot or supervisor switchover, Cisco NX-OS applies the running configuration.

Prerequisites for DNS Clients

The DNS client has the following prerequisites:

- You must have a DNS name server on your network.

Licensing Requirements for DNS Clients

The following table shows the licensing requirements for this feature:

Product	Licence Requirement
Cisco NX-OS	DNS requires no license. Any feature not included in a license package is bundled with the Cisco NX-OS system images and is provided at no extra charge to you. For a complete explanation of the Cisco NX-OS licensing scheme, see the <i>Cisco NX-OS Licensing Guide</i> .

Default Settings

The following table shows the default settings for DNS client parameters.

Parameter	Default
DNS client	Enabled

Configuring DNS Clients

You can configure the DNS client to use a DNS server on your network.

Before You Begin

- Ensure that you have a domain name server on your network.

SUMMARY STEPS

1. configuration terminal
2. vrf context management
3. ip host *name address1 [address2... address6]*
4. ip domain name *name [use-vrf vrf-name]*
5. ip domain-list *name [use-vrf vrf-name]*
6. ip name-server *server-address1 [server-address2... server-address6] [use-vrf vrf-name]*
7. ip domain-lookup
8. show hosts
9. exit
10. copy running-config startup-config

DETAILED STEPS

	Command or Action	Purpose
Step 1	configuration terminal Example: switch# configuration terminal switch(config)#	Enters the configuration terminal mode.
Step 2	vrf context management Example: switch(config)# vrf context management switch(config)#	Specifies a configurable VRF name.
Step 3	ip host <i>name address1 [address2... address6]</i> Example: switch# ip host cisco-rtp 192.0.2.1 switch(config)#	Defines up to six static host name-to-address mappings in the host name cache.

	Command or Action	Purpose
Step 4	ip domain name <i>name</i> [use-vrf <i>vrf-name</i>] Example: <pre>switch(config)# ip domain-name myserver.com switch(config)#</pre>	(Optional) Defines the default domain name server that Cisco NX-OS uses to complete unqualified host names. You can optionally define a VRF that Cisco NX-OS uses to resolve this domain name server if it cannot be resolved in the VRF that you configured this domain name under. Cisco NX-OS appends the default domain name to any host name that does not contain a complete domain name before starting a domain-name lookup.
Step 5	ip domain-list <i>name</i> [use-vrf <i>vrf-name</i>] Example: <pre>switch(config)# ip domain-list mycompany.com switch(config)#</pre>	(Optional) Defines additional domain name servers that Cisco NX-OS can use to complete unqualified host names. You can optionally define a VRF that Cisco NX-OS uses to resolve this domain name server if it cannot be resolved in the VRF that you configured this domain name under. Cisco NX-OS uses each entry in the domain list to append that domain name to any host name that does not contain a complete domain name before starting a domain-name lookup. Cisco NX-OS continues this for each entry in the domain list until it finds a match.
Step 6	ip name-server <i>server-address1</i> [<i>server-address2... server-address6</i>] [use-vrf <i>vrf-name</i>] Example: <pre>switch(config)# ip name-server 192.0.2.22</pre>	(Optional) Defines up to six name servers. The address can be either an IPv4 address or an IPv6 address. You can optionally define a VRF that Cisco NX-OS uses to reach this name server if it cannot be reached in the VRF that you configured this name server under.
Step 7	ip domain-lookup Example: <pre>switch(config)# ip domain-lookup</pre>	(Optional) Enables DNS-based address translation. Enabled by default.
Step 8	show hosts Example: <pre>switch(config)# show hosts</pre>	(Optional) Displays information about DNS.
Step 9	exit Example: <pre>switch(config)# exit switch#</pre>	Exits configuration mode and returns to EXEC mode.
Step 10	copy running-config startup-config Example: <pre>switch# copy running-config startup-config switch#</pre>	(Optional) Copies the running configuration to the startup configuration.

This example shows how to configure a default domain name and enable DNS lookup:

```
switch# config t
switch(config)# vrf context management
switch(config)# ip domain-name mycompany.com
switch(config)# ip name-server 172.68.0.10
switch(config)# ip domain-lookup
```

