



## M Commands

---

- [m2rib debug ftag](#), on page 6
- [m2rib debug gr-route add nh](#), on page 7
- [m2rib debug log-size event-history](#), on page 9
- [m2rib debug log-size transactions](#), on page 10
- [m2rib debug omf enable](#), on page 11
- [m2rib debug pkt-recv enable](#), on page 12
- [m2rib debug swroute nh](#), on page 13
- [m2rib debug topo](#), on page 14
- [m2rib debug topo loop-flush-timeout](#), on page 15
- [mac-addr](#), on page 16
- [mac-address](#), on page 17
- [mac-address](#), on page 18
- [mac-address](#), on page 19
- [mac-address bpdu source version 2](#), on page 20
- [mac-address destination](#), on page 21
- [mac-address ipv6-extract](#), on page 22
- [mac-learn disable](#), on page 23
- [mac-learn disable](#), on page 24
- [mac-list permit](#), on page 25
- [mac access-list](#), on page 26
- [mac address-table aging-time](#), on page 27
- [mac address-table guard-vpc-peergw-mac](#), on page 28
- [mac address-table limit system](#), on page 29
- [mac address-table loop-detect port-down](#), on page 30
- [mac address-table multicast vlan interface](#), on page 31
- [mac address-table notification mac-move](#), on page 32
- [mac address-table notification threshold](#), on page 33
- [mac address-table static vlan interface](#), on page 34
- [mac address-table static vni](#), on page 35
- [mac address](#), on page 36
- [mac address inherit](#), on page 37
- [mac advert interval](#), on page 38
- [mac packet-classify](#), on page 39

- [mac packet-classify](#), on page 40
- [mac port access-group](#), on page 41
- [managed-config-flag](#), on page 42
- [management](#), on page 43
- [map-notify-group](#), on page 44
- [map-server key](#), on page 45
- [marker-packet-n3500](#), on page 46
- [marker-packet](#), on page 47
- [master ipv4](#), on page 48
- [match-address](#), on page 49
- [match](#), on page 50
- [match](#), on page 52
- [match](#), on page 53
- [match access-group name](#), on page 57
- [match address](#), on page 58
- [match as-number](#), on page 59
- [match as-number as-path-list](#), on page 60
- [match as-path](#), on page 61
- [match class-map](#), on page 62
- [match community](#), on page 63
- [match cos](#), on page 64
- [match cos](#), on page 65
- [match datalink](#), on page 66
- [match datalink](#), on page 67
- [match dscp](#), on page 68
- [match dscp](#), on page 69
- [match exception](#), on page 70
- [match extcommunity](#), on page 71
- [match interface](#), on page 72
- [match ip address](#), on page 73
- [match ip address prefix-list](#), on page 74
- [match ip multicast rp](#), on page 75
- [match ip next-hop prefix-list](#), on page 76
- [match ip protocol](#), on page 77
- [match ip route-source prefix-list](#), on page 78
- [match ipv4 protocol](#), on page 79
- [match ipv4 source address](#), on page 80
- [match ipv4 source address](#), on page 81
- [match ipv4 transport destination](#), on page 82
- [match ipv6](#), on page 83
- [match ipv6](#), on page 84
- [match ipv6 address](#), on page 85
- [match ipv6 address prefix-list](#), on page 86
- [match ipv6 multicast rp](#), on page 87
- [match ipv6 next-hop prefix-list](#), on page 88
- [match ipv6 protocol](#), on page 89

- [match ipv6 route-source prefix-list](#), on page 90
- [match ipv6 transport destination](#), on page 91
- [match metric](#), on page 92
- [match ospf-area](#), on page 93
- [match protocol](#), on page 94
- [match protocol arp](#), on page 95
- [match qos-group](#), on page 96
- [match qos-group2](#), on page 97
- [match qos-group2](#), on page 98
- [match qos-group](#), on page 99
- [match redirect](#), on page 100
- [match route-type](#), on page 101
- [match source-protocol](#), on page 102
- [match tag](#), on page 103
- [match transport destination](#), on page 104
- [max-backoff](#), on page 105
- [max-backoff](#), on page 106
- [max-lsa](#), on page 107
- [max-lsa](#), on page 108
- [max-lsp-lifetime](#), on page 109
- [max-lsp-lifetime](#), on page 110
- [max-lsp-lifetime](#), on page 111
- [max-metric router-lsa](#), on page 112
- [max-metric router-lsa](#), on page 113
- [max-ports](#), on page 114
- [max-ports](#), on page 115
- [maxas-limit](#), on page 116
- [maximum-paths](#), on page 117
- [maximum-paths](#), on page 118
- [maximum-paths](#), on page 119
- [maximum-paths](#), on page 120
- [maximum-paths](#), on page 121
- [maximum-paths](#), on page 122
- [maximum-paths](#), on page 123
- [maximum-paths](#), on page 124
- [maximum-paths eibgp](#), on page 125
- [maximum-paths mixed](#), on page 126
- [maximum-peers](#), on page 127
- [maximum-prefix](#), on page 128
- [maximum-prefix](#), on page 129
- [maximum-prefix](#), on page 130
- [maximum routes](#), on page 131
- [mdix auto](#), on page 132
- [mdt asm-use-shared-tree](#), on page 133
- [mdt data](#), on page 134
- [mdt data bidir-enable](#), on page 135

- mdt default, on page 136
- mdt enforce-bgp-mdt-safi, on page 137
- mdt mtu, on page 138
- mdt pim hello-interval, on page 139
- mdt pim jp-interval, on page 140
- mdt source, on page 141
- media-type auto, on page 142
- media-type rj45, on page 143
- media-type sfp, on page 144
- media, on page 145
- medium, on page 146
- medium broadcast, on page 147
- medium broadcast, on page 148
- medium p2p, on page 149
- medium p2p, on page 150
- member vlan, on page 151
- member vni, on page 152
- member vni, on page 153
- member vni associate-vrf, on page 154
- message-digest-key md5, on page 155
- message-digest-key md5, on page 156
- metric-style transition, on page 157
- metric-type, on page 158
- metric direct 0, on page 159
- metric maximum-hops, on page 160
- metric rib-scale, on page 161
- metric version 64bit, on page 162
- metric weights, on page 163
- mkdir, on page 164
- mode, on page 165
- mode, on page 166
- mode, on page 167
- mode tap-aggregation, on page 168
- module transceiver-frequency, on page 169
- monitor erspan granularity, on page 170
- monitor erspan origin ip-address, on page 171
- monitor erspan switch-id, on page 172
- monitor session, on page 173
- monitor session shut, on page 174
- monitor session type acl-capture, on page 175
- monitor session type erspan-destination, on page 176
- monitor session type erspan-source, on page 177
- monitor session warp, on page 178
- monitor session warp, on page 179
- mount, on page 180
- mount slot0, on page 181

- [move](#), on page 182
- [mst designated priority](#), on page 183
- [mst root priority](#), on page 184
- [mtrace](#), on page 185
- [mtu](#), on page 186
- [mtu1](#), on page 187
- [mtu](#), on page 188
- [mtu](#), on page 189
- [mtu](#), on page 190
- [mtu](#), on page 191
- [mtu](#), on page 192
- [mtu](#), on page 193
- [multi-topology](#), on page 194
- [multicast](#), on page 195
- [multisite border-gateway interface](#), on page 196
- [multisite ingress-replication](#), on page 197
- [mvr-config](#), on page 198
- [mvr-group](#), on page 199
- [mvr-group](#), on page 200
- [mvr-group](#), on page 201
- [mvr-group](#), on page 202
- [mvr-group](#), on page 203
- [mvr-group](#), on page 204
- [mvr-group](#), on page 205
- [mvr-group](#), on page 206
- [mvr-suppress-query vlan](#), on page 207
- [mvr-type receiver](#), on page 208
- [mvr-type source](#), on page 209
- [mvr-vlan](#), on page 210
- [mvr-vlan](#), on page 211

## m2rib debug ftag

```
m2rib debug ftag { add | del | mod } <ftag-id> <topo-id> { [ UCAST ] [ MCAST ] [ ACTIVE ] [ INACTIVE ] } + [ <proto> ] [ vampire-tap ]
```

### Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
ftag	Configure M2RIB's ftag db
add	Add an ftag
mod	Modify an ftag flags
del	Delete an ftag
<i>ftag-id</i>	ftag id
<i>topo-id</i>	topo id
<i>proto</i>	(Optional) Protocol owner id
UCAST	(Optional) Broadcast ftag
MCAST	(Optional) Multicast ftag
ACTIVE	(Optional) Active ftag
INACTIVE	(Optional) Inactive ftag
vampire-tap	(Optional) Send a copy of all M2RIB generated messages to CLI

### Command Mode

- /exec

## m2rib debug gr-route add nh

```
m2rib debug gr-route { add | del } <vlan> { { <v4-source> <v4-group> } | { <v6-source> <v6-group> } } {
nh-if <if-name> | nh-sw <switch-id> } { [ WC_SRC ][ WC_GRP ][ NH_EXCLUDE ][ FLOOD_TO_VLAN
] [ LOCAL ][ REMOTE ][ IGNORE_STAR ] } + [ proto <proto> ] [ route-type <route-type> ] [ vampire-tap
]
```

### Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
gr-route	Perform group route operations on m2rib
add	Add a route next-hop
del	Delete a route next-hop
proto	(Optional) Protocol owning this next-hop
route-type	(Optional) Route type of this next-hop
nh-if	next-hop interface
nh-sw	next-hop switch
vlan	vlan key
v4-source	IPv4 Multicast traffic source
v4-group	IPv4 Multicast Group address
if-name	Specify the next hop interface
switch-id	Specify the next hop switch id
WC_SRC	(Optional) Source is wildcarded
WC_GRP	(Optional) Group is wildcarded
NH_EXCLUDE	(Optional) Next-hop excluded from ltl+1
FLOOD_TO_VLAN	(Optional) Broadcast (flood-to-vlan) special group
LOCAL	(Optional) Local members exist
REMOTE	(Optional) Remote members exist
IGNORE_STAR	(Optional) Do not combine with router-port oif list
proto	(Optional) Protocol owner id
route-type	(Optional) Route type

vampire-tap	(Optional) Send a copy of all M2RIB generated messages to CLI
-------------	---

**Command Mode**

- /exec



## m2rib debug log-size event-history

m2rib debug log-size event-history { <size> | small | medium | large }

### Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
log-size	Set log sizes
event-history	Set event-history size
<i>size</i>	Buffer size in KB
small	Set to default small log size
medium	Set to default medium log size
large	Set to default large log size

### Command Mode

- /exec/configure

## m2rib debug log-size transactions

```
m2rib debug log-size transactions { { received | u2rib | mfdm | pixm | eltm } [ error-log ] | announced } {
<size> | small | medium | large } <size_bytes>
```

### Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
log-size	Set log sizes
transactions	Set transaction log sizes
received	Set received transaction log size
announced	Set announced transaction log size
u2rib	Set U2RIB transaction log size
mfdm	Set MFDM transaction log size
pixm	Set PIXM transaction log size
eltn	Set ELTM transaction log size
error-log	(Optional) errors only log
<i>size</i>	Size in number of transactions
small	Set number of transactions default small log size (0 disables limits)
medium	Set number of transactions default medium log size
large	Set number of transactions default large log size
<i>size_bytes</i>	Max log size in number of bytes

### Command Mode

- /exec/configure

## m2rib debug omf enable

m2rib debug omf { enable | disable } <from-vlan> <to-vlan> [ vampire-tap ]

### Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
omf	Enable or disable Optimized Multicast Flood (OMF)
enable	Enable OMF
disable	Disable OMF
<i>from-vlan</i>	from vlan
<i>to-vlan</i>	to vlan
vampire-tap	(Optional) Send a copy of all M2RIB generated messages to CLI

### Command Mode

- /exec

## m2rib debug pkt-recv enable

m2rib debug pkt-recv { enable | disable } <from-vlan> <to-vlan> <proto> [ vampire-tap ]

### Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
pkt-recv	Enable or disable protocol packet reception
enable	Enable packet receive
disable	Disable packet receive
<i>from-vlan</i>	from vlan
<i>to-vlan</i>	to vlan
<i>proto</i>	Protocol id
vampire-tap	(Optional) Send a copy of all M2RIB generated messages to CLI

### Command Mode

- /exec

## m2rib debug swroute nh

```
m2rib debug swroute { add | mod | del } <ftag> <switch-id> nh <if-name> [ proto <proto> ] [ route-type
<route-type> ] [ vampire-tap ]
```

### Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
swroute	Perform route operations on m2rib
add	Add a route next-hop
mod	Modify a route's next-hop
del	Delete a route next-hop
nh	next-hop
proto	(Optional) Protocol owning this next-hop
route-type	(Optional) Route type of this next-hop
<i>ftag</i>	ftag key
<i>switch-id</i>	switch id
<i>if-name</i>	Specify the next hop interface
<i>proto</i>	(Optional) Protocol owner id
<i>route-type</i>	(Optional) Route type
vampire-tap	(Optional) Send a copy of all M2RIB generated messages to CLI

### Command Mode

- /exec

## m2rib debug topo

m2rib debug topo { create | del | add-vlans | del-vlans } <topo-id> <from-vlan> <to-vlan> [ <proto> ] [ vampire-tap ]

### Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
topo	Configure M2RIB's topo db
create	Create a topo in m2rib
del	Delete a topo in m2rib
add-vlans	Add vlans to an existing topo
del-vlans	Delete vlans from an existing topo
<i>topo-id</i>	topo id
<i>from-vlan</i>	from vlan
<i>to-vlan</i>	to vlan
<i>proto</i>	(Optional) Protocol owner id
vampire-tap	(Optional) Send a copy of all M2RIB generated messages to CLI

### Command Mode

- /exec

# m2rib debug topo loop-flush-timeout

m2rib debug topo [ <topo-id> ] loop-flush-timeout <timeout>

## Syntax Description

m2rib	Configure m2rib
debug	Configure m2rib debug
topo	configure M2RIB's topology db
<i>topo-id</i>	(Optional) topo id
loop-flush-timeout	configure the loop flush timer value
<i>timeout</i>	Loop flush timeout value in ms

## Command Mode

- /exec/configure

# mac-addr

```
{ mac-addr <dstmac> <smac> [ dot1q <dot1q-id> ] }
```

## Syntax Description

mac-addr	Mac
<i>dstmac</i>	Destination mac address
<i>smac</i>	Source mac address
dot1q	(Optional) Encapsulation dot1q/bd
<i>dot1q-id</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt

## Command Mode

- /exec/configure/configngoamccpayload



# mac-address

mac-address <mac\_address\_val> | no mac-address [ <mac\_address\_val> ]

## Syntax Description

no	Negate a command or set its defaults
mac-address	Configure interface mac address (1)
<i>mac_address_val</i>	Static Router MAC address (1)

## Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-ether-sub /exec/configure/if-eth-non-member /exec/configure/if-remote-ethernet-sub /exec/configure/if-port-channel /exec/configure/if-port-channel-sub /exec/configure/if-ether-sub-p2p /exec/configure/if-ethernet-p2p

# mac-address

mac-address <macaddress> | no mac-address [ <macaddress> ]

## Syntax Description

no	Negate a command or set its defaults
mac-address	Virtual MAC address
<i>macaddress</i>	MAC address(FORMAT:xxxx.xxxx.xxxx)

## Command Mode

- /exec/configure/if-eth-any/hsrp\_ipv4 /exec/configure/if-eth-any/hsrp\_ipv6

# mac-address

mac-address <mac-addr> | no mac-address

## Syntax Description

no	Negate a command or set its defaults
mac-address	Manually set interface MAC address
<i>mac-addr</i>	MAC address

## Command Mode

- /exec/configure/if-vlan-common

## mac-address bpdu source version 2

[no] mac-address bpdu source version 2

### Syntax Description

no	(Optional) Negate a command or set its defaults
mac-address	change vpc mac address
bpdu	bpdu
source	source
version	version
2	use version 2 bpdu source mac-address

### Command Mode

- /exec/configure/vpc-domain

# mac-address destination

{ mac-address { destination | source } <addr> } | { no mac-address { destination | source } }

## Syntax Description

no	Negate a command or set its defaults
mac-address	specify flow mac address
source	specify flow source mac address
destination	specify flow destination mac address
<i>addr</i>	mac address

## Command Mode

- /exec/configure/configngoamprofileflow

# mac-address ipv6-extract

mac-address ipv6-extract | no mac-address ipv6-extract

## Syntax Description

no	Negate a command or set its defaults
mac-address	Configure interface mac address (3)
ipv6-extract	Extract mac-address (3) from the IPv6 address configured on the interface

## Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-ether-sub /exec/configure/if-eth-non-member /exec/configure/if-remote-ethernet-sub /exec/configure/if-port-channel-sub /exec/configure/if-port-channel

# mac-learn disable

mac-learn disable | no mac-learn disable

## Syntax Description

no	Negate a command or set its defaults
mac-learn	Mac Learning disable/enable
disable	Mac Learning disable to use switch as a HUB. Do a clear mac address-table dynamic after disabling mac learning

## Command Mode

- /exec/configure

# mac-learn disable

mac-learn disable | no mac-learn disable

## Syntax Description

no	Negate a command or set its defaults
mac-learn	Mac Learning disable/enable on vlan
disable	Mac Learning disable on vlan

## Command Mode

- /exec/configure/vlan-config



# mac-list permit

```
{ mac-list <name> [ seq <seq> ] { permit | deny } <mac-addr> [ <mac-mask> ] } | { no mac-list <name> [ seq <seq> ] [ { permit | deny } <mac-addr> [ <mac-mask> ] ] }
```

## Syntax Description

no	Negate a command or set its defaults
mac-list	Build a mac list
<i>name</i>	Name of prefix list
seq	(Optional) Sequence number of an entry
<i>seq</i>	(Optional) Sequence number
permit	Specify routes to forward
deny	Specify routes to reject
<i>mac-addr</i>	MAC address
<i>mac-mask</i>	(Optional) MAC Mask. Default Mask is ffff.ffff.ffff

## Command Mode

- /exec/configure

## mac access-list

[no] mac access-list <name> [ client <clienttype> <clientID> ]

### Syntax Description

no	(Optional) Negate a command or set its defaults
mac	MAC configuration commands
access-list	Configure access list
<i>name</i>	List name
client	(Optional) set client type
<i>clienttype</i>	(Optional) CLI/ONEP
<i>clientID</i>	(Optional) client appID

### Command Mode

- /exec/configure

## mac address-table aging-time

```
mac address-table aging-time { 0 | <seconds> } [ { vlan <vlan-id> } ] [ __readonly__ <info_str> ] | no mac
address-table aging-time [ [ 0 | <seconds> ] ]
```

### Syntax Description

no	Negate a command or set its defaults
mac	MAC configuration commands
address-table	MAC Address Table
aging-time	Aging time
0	0 disables aging
<i>seconds</i>	Aging time in seconds.
vlan	(Optional) VLAN
<i>vlan-id</i>	(Optional) VLAN ID
__readonly__	(Optional)
<i>info_str</i>	(Optional) Information

### Command Mode

- /exec/configure

## mac address-table guard-vpc-peergw-mac

[no] mac address-table guard-vpc-peergw-mac

### Syntax Description

no	(Optional) Negate a command or set its defaults
mac	MAC configuration commands
address-table	MAC Address Table
guard-vpc-peergw-mac	Prevent vPC Peer gateway MAC Spoofing

### Command Mode

- /exec/configure

## mac address-table limit system

```
mac address-table limit { system | vlan <id> } [ <limitcount> ] [ actiondrop ] [ __readonly__ <info_str> ] |
no mac address-table limit { system | vlan <id> } [ <limitcount> ] [ actiondrop ]
```

### Syntax Description

no	Negate a command or set its defaults
mac	MAC configuration commands
address-table	MAC Address Table
limit	Restrict number of Mac addresses learnt
system	System-wide
vlan	VLAN
<i>id</i>	List of VLAN ids
<i>limitcount</i>	(Optional) Mac address limit count
actiondrop	(Optional) Drop packets instead of flooding
__readonly__	(Optional)
<i>info_str</i>	(Optional) Information

### Command Mode

- /exec/configure

# mac address-table loop-detect port-down

mac address-table loop-detect port-down | no mac address-table loop-detect port-down

## Syntax Description

no	Negate a command or set its defaults
mac	MAC configuration commands
address-table	MAC Address Table
loop-detect	Action for Mac loop detection
port-down	Take port-down action for mac loop detection

## Command Mode

- /exec/configure

## mac address-table multicast vlan interface

[no] mac address-table multicast <mac-address> { vlan <vlan> | bridge-domain <bdid> } interface [ vsi ] <interface>

### Syntax Description

no	(Optional) Negate a command or set its defaults
mac	MAC configuration commands
address-table	MAC Address Table
multicast	mcast mac OIF Static Entry
<i>mac-address</i>	mcast MAC Address, not in Unicast IP Range
vlan	VLAN
<i>vlan</i>	VLAN
bridge-domain	BD
<i>bdid</i>	BD
interface	Interface
vsi	(Optional) Specify if this interface is a VSI
<i>interface</i>	Interface name

### Command Mode

- /exec/configure

# mac address-table notification mac-move

mac address-table notification mac-move | no mac address-table notification mac-move

## Syntax Description

no	Negate a command
mac	MAC configuration commands
address-table	MAC Address Table
notification	Notify of mac-move
mac-move	MAC move notification on syslog

## Command Mode

- /exec/configure



# mac address-table notification threshold

mac address-table notification threshold [ limit <percentage> interval <seconds> ] | no mac address-table notification threshold

## Syntax Description

no	Negate a command
mac	MAC configuration commands
address-table	MAC Address Table
notification	Notify of mac-move
threshold	MAC Address Table threshold notification
limit	(Optional) Specify the percentage limit beyond which notifications are enabled
<i>percentage</i>	(Optional) Percentage of MAC Table Consumption
interval	(Optional) Minimum time in seconds between two notifications
<i>seconds</i>	(Optional) Interval time in seconds

## Command Mode

- /exec/configure

## mac address-table static vlan interface

```
mac address-table static <mac-address> vlan <vlan-id> { interface <interface-name> | drop } [ auto-learn ] [
__readonly__ <info_str> ] | no mac address-table static <mac-address> vlan <vlan-id>
```

### Syntax Description

no	Negate a command or set its defaults
mac	MAC configuration commands
address-table	MAC Address Table
static	Static Entry
<i>mac-address</i>	MAC Address
vlan	VLAN
<i>vlan-id</i>	VLAN ID
interface	Interface
<i>interface-name</i>	Interface name
drop	Drop all traffic
auto-learn	(Optional) Allow moving this MAC address
__readonly__	(Optional)
<i>info_str</i>	(Optional) Information

### Command Mode

- /exec/configure

# mac address-table static vni

mac address-table static <mac-address> vni <vni-id>

## Syntax Description

mac	MAC configuration commands
address-table	MAC Address Table
static	Static Entry
<i>mac-address</i>	MAC Address
vni	Virtual Network Identifier
<i>vni-id</i>	VNI ID

## Command Mode

- /exec/configure

# mac address

[no] mac address { <macaddr> }

## Syntax Description

no	(Optional) Negate a command or set its defaults
mac	Configure vMAC address options for Pathway
address	Pathway will use a specified vMAC address
<i>macaddr</i>	48-bit MAC address in HEX

## Command Mode

- /exec/configure/if-eth-any/vrrs

# mac address inherit

mac address inherit

## Syntax Description

mac	Configure vMAC address options for Pathway
address	Pathway will use a specified vMAC address
inherit	Pathway will inherit vMAC

## Command Mode

- /exec/configure/if-eth-any/vrrs

# mac advert interval

[no] mac advert interval | mac advert interval <macint>

## Syntax Description

no	Negate a command or set its defaults
mac	Configure vMAC address options for Pathway
advert	Specify vMAC unsolicited advertisements
interval	Specify interval between vMAC unsolicited advertisements
<i>macint</i>	Advertisement Interval in seconds

## Command Mode

- /exec/configure/if-eth-any/vrrs

# mac packet-classify

[no] mac packet-classify

## Syntax Description

no	(Optional) Negate a command or set its defaults
mac	MAC
packet-classify	Force mac classification of packets

## Command Mode

- /exec/configure/vlan

# mac packet-classify

[no] mac packet-classify

## Syntax Description

no	(Optional) Negate a command or set its defaults
mac	MAC configuration commands
packet-classify	Force mac classification of packets

## Command Mode

- /exec/configure/if-ethernet-switch /exec/configure/if-remote-ethernet-switch  
/exec/configure/if-eth-port-channel-switch /exec/configure/if-ethernet-all



# mac port access-group

[no] mac port access-group <name>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mac	MAC configuration commands
port	Port policy
access-group	Specify access control for packets
<i>name</i>	List name

## Command Mode

- /exec/configure/if-set-acl-l2

# managed-config-flag

[no] managed-config-flag <state>

## Syntax Description

no	(Optional) Negate a command or set its defaults
<i>state</i>	

## Command Mode

- /exec/configure/config-ra-guard

# management

[no] management

## Syntax Description

no	(Optional) Negate a command or set its defaults
management	Allow in-band management access to VLAN Interface IP address

## Command Mode

- /exec/configure/if-vlan-common

# map-notify-group

```
{ [ no ] map-notify-group { <addr> | <addr6> } }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
map-notify-group	Group address to send and receive site specific Map-Notify messages
<i>addr</i>	IPv4 group address

## Command Mode

- /exec/configure/lisp-dynamic-eid /exec/configure/vrf/lisp-dynamic-eid

# map-server key

```
{ { [ no ] map-server { <ms> | <ms6> } [ key-type { sha1 | sha2 } ] key <key> } | { [ no ] map-server { <ms> | <ms6> } proxy-reply } }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
map-server	To interact with Map-Server
<i>ms</i>	Address of IPv4 map-server
key-type	(Optional) Authentication key type, either sha1 or sha2
sha1	(Optional) Use sha1 authentication in Map-Register messages
sha2	(Optional) Use sha2 authentication in Map-Register messages
key	Authentication key used with Map-Server
<i>key</i>	SHA-1 password key
proxy-reply	Request Map-Server to send Map-Replies on behalf of dynamic-EID

## Command Mode

- /exec/configure/lisp-dynamic-eid /exec/configure/vrf/lisp-dynamic-eid

# marker-packet-n3500

[no] marker-packet-n3500 [ <interval> | seconds <interval1> | milliseconds <interval2> ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
marker-packet-n3500	Enable/Disable send marker packet
<i>interval</i>	(Optional) range between <1-4> second
seconds	(Optional) Configure interval in secs
<i>interval1</i>	(Optional) range between <1-4> second
milliseconds	(Optional) Interval in milli second.
<i>interval2</i>	(Optional) range between <100-900> msec, increments in multiples of 100

## Command Mode

- /exec/configure/config-monitor-erspan-src

# marker-packet

[no] marker-packet [ <interval> ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
marker-packet	Enable/Disable send marker packet
<i>interval</i>	(Optional)

## Command Mode

- /exec/configure/config-monitor-erspan-src

# master ipv4

[no] master ipv4 <ip>

## Syntax Description

no	(Optional) Negate a command or set its defaults
master	master
ipv4	ipv4
<i>ip</i>	IPv4 address (A.B.C.D) of slave

## Command Mode

- /exec/configure/ptp-ucast-slave



# match-address

[no] match-address

## Syntax Description

no	(Optional) Negate a command or set its defaults
match-address	Match addresses in advertisement packets

## Command Mode

- /exec/configure/if-eth-any/vrrpv3

# match

```
[no] match { { access-group name <acl-name> } | [ not ] { dscp { <dscp-list> | { <dscp-enum> } + } | { {
packet length <len-list> | ip rtp <port-list> } [ replace ] } | { cos <cos-list> } | { qos-group <qos-group-list>
} | { precedence { <precedence-list> | { <prec-enum> } + } } | { protocol <protocol-enum> } | { mpls
experimental topmost <exp-list> } | { ip roce <port-list> } } }
```

## Syntax Description

<i>dscp-list</i>	<dscp-enum>
<i>cos-list</i>	
<i>precedence-list</i>	<prec-enum>
no	(Optional) Negate a command or set its defaults
replace	(Optional) Replace current ip rtp / packet length configuration
match	Classification criteria
not	(Optional) Negate this match result
access-group	Access group
name	Named Access List
<i>acl-name</i>	Access List name
dscp	DSCP in IP(v4) and IPv6 packets
<i>dscp-enum</i>	
cos	IEEE 802.1Q Class of Service
qos-group	Qos-group
<i>qos-group-list</i>	List of qos-group values
precedence	Precedence in IP(v4) and IPv6 packets
<i>prec-enum</i>	
protocol	Protocol
<i>protocol-enum</i>	
packet	Packet
length	Length of IP datagram
<i>len-list</i>	List of IP packet length
ip	IP

rtp	Real Time Protocol
<i>port-list</i>	UDP port list that are using RTP
mpls	Match on MPLS label
experimental	Match on MPLS Experimental label
topmost	Match on topmost MPLS label
ip	IP
roce	Roce protocol. port to be used 3804
<i>port-list</i>	UDP port list that are using RoCE
<i>exp-list</i>	List of MPLS exp values

**Command Mode**

- /exec/configure/class-map

# match

```
[no] match { [ not ] { { discard-class <discard-class-list> } | { class-map <cmmap-name> } } }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
not	(Optional) Negate this match result
discard-class	Discard class
<i>discard-class-list</i>	List of discard-class values
class-map	Class map
<i>cmmap-name</i>	Match class-map name

## Command Mode

- /exec/configure/class-map

# match

```
[no] match { { access-group name <acl-name> } | [ not ] { { cos <cos-value> } | any | { eth-src <mac_src>
<mac_src_wild> } | { eth-dest <mac_dest> <mac_dest_wild> } | { eth-type <eth-value> } | { vlan
<vlan-number> } | { ip-tos <tos-value> <tos-mask> } | { ip-protocol <ip-protocol-value> } | { ip-src-addr
<ip-s-addr> <ip-s-mask> } | { ip-dst-addr <ip-d-addr> <ip-d-mask> } | { tcp-src-port <tcp-src-port-addr> } |
{ tcp-dst-port <tcp-dest-port-addr> } | { udp-src-port <udp-src-port-addr> } | { udp-dst-port
<udp-dest-port-addr> } | { input-interface <ifnum> } | { ipv6-src-addr <ipv6-s-addr> <ipv6-s-mask> } | {
ipv6-dst-addr <ipv6-d-addr> <ipv6-d-mask> } | { ipv6-protocol <ipv6-protocol-value> } | { ipv6-flowlabel
<ipv6-flowlabel-value> } | { icmpv6-type <icmpv6-type-value> } | { icmpv6-code <icmpv6-code-value> } |
{ ipv4-dscp <ipv4-dscp-list> } | { ipv6-dscp <ipv6-dscp-list> } | { dscp { <dscp-list> | <dscp-enum> } + } |
{ precedence { <precedence-list> | <prec-enum> } + } | { discard-class <discard-class-list> } | { qos-group
<qos-group-list> } | { class-map <cmap-name-plc> } | { protocol <protocol-enum> } | { packet length <len-list>
} | { ip rtp <port-list> } | { mpls experimental topmost <exp-list> } } }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
not	(Optional) Negate this match result
access-group	Access group
name	Named Access List
<i>acl-name</i>	Access List name
cos	IEEE 802.1Q class of service
dscp	DSCP in IP(v4) and IPv6 packets
<i>dscp-list</i>	List of DSCP values
<i>dscp-enum</i>	
precedence	Precedence in IP(v4) and IPv6 packets
<i>precedence-list</i>	List of precedence values
<i>prec-enum</i>	
discard-class	Discard class
<i>discard-class-list</i>	List of discard-class values
qos-group	Qos-group
<i>qos-group-list</i>	List of qos-group values
class-map	Class map
<i>cmap-name-plc</i>	Match class-map name

protocol	Protocol
<i>protocol-enum</i>	
packet	Packet
length	Length of IP datagram
<i>len-list</i>	list of IP packet length
ip	IP
rtsp	Real Time Protocol
<i>port-list</i>	UDP port list that are using RTP
mpls	Match on MPLS label
experimental	Match on MPLS Experimental label
topmost	Match on topmost MPLS label
<i>exp-list</i>	List of MPLS exp values
any	Match on Any Filter
eth-dest	Match on Layer 2 destination MAC address
eth-src	Match on Layer 2 source MAC address
eth-type	Match on Ether type
vlan	Match on 802.1Q vlan
ip-tos	Match on IPv4 TOS
ip-protocol	Match on IP protocol
ip-src-addr	Match on IPv4 source address
ip-dst-addr	Match on IPv4 destination address
ipv6-src-addr	Match on IPv6 source address
ipv6-dst-addr	Match on IPv6 destination address
tcp-src-port	Match on TCP source port
tcp-dst-port	Match on TCP source port
udp-src-port	Match on UDP source port
udp-dst-port	Match on UDP source port
input-interface	Match on physical input interface
ipv6-protocol	Match on IPv6 Protocol Value

<i>ipv6-flowlabel</i>	Match on IPv6 Flowlabel
<i>icmpv6-type</i>	Match on ICMPv6 Message Type
<i>icmpv6-code</i>	Match on ICMPv6 Message Code
<i>ipv4-dscp</i>	Match on DSCP for IPV4 Packets
<i>ipv6-dscp</i>	Match on DSCP for IPV6 Packets
<i>cos-value</i>	class of service Value
<i>mac_src</i>	Source MAC address
<i>mac_src_wild</i>	Source MAC mask
<i>mac_dest</i>	Destination MAC address
<i>mac_dest_wild</i>	Destination MAC mask
<i>eth-value</i>	Ethernet type
<i>vlan-number</i>	Vlan number
<i>tos-value</i>	IPv4 TOS
<i>tos-mask</i>	IPV4 TOS Mask for DSCP
<i>ip-protocol-value</i>	IPV4 protocol
<i>ip-s-addr</i>	IPV4 address in format a.b.c.d
<i>ip-d-addr</i>	IPV4 address in format a.b.c.d
<i>ip-s-mask</i>	IPV4 address Mask in format a.b.c.d
<i>ip-d-mask</i>	IPV4 address Mask in format a.b.c.d
<i>tcp-src-port-addr</i>	Transport layer port number
<i>tcp-dest-port-addr</i>	Transport layer port number
<i>udp-src-port-addr</i>	Transport layer port number
<i>udp-dest-port-addr</i>	Transport layer port number
<i>ifnum</i>	Physical interface Name and Number
<i>ipv6-protocol-value</i>	IPv6 Protocol Value
<i>ipv6-flowlabel-value</i>	IPv6 Flowlabel
<i>icmpv6-type-value</i>	ICMPv6 Message Type
<i>icmpv6-code-value</i>	ICMPv6 Message Code
<i>ipv4-dscp-list</i>	List of IPV4 DSCP values

<i>ipv6-dscp-list</i>	List of IPV6 DSCP values
-----------------------	--------------------------

**Command Mode**

- /exec/configure/class-map/type/plc



## match access-group name

[no] match access-group name <acs-grp-name>

### Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
access-group	Match with given access group
name	Name of the access group
<i>acs-grp-name</i>	Match parameter for class-map

### Command Mode

- /exec/configure/cmap

## match address

[no] match <ip\_ipv6\_mac> address <name>

### Syntax Description

no	(Optional) Negate a command or set its defaults
match	Specify the match clause
<i>ip_ipv6_mac</i>	IP/IPv6/MAC
address	Match an access list
<i>name</i>	List name

### Command Mode

- /exec/configure/vacl

# match as-number

[no] match as-number [ { <asnum> | <asnum\_range> } + ] { <asnum\_trail> | <asnum\_range\_trail> }

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
as-number	Match BGP peer AS number
<i>asnum</i>	(Optional) <AA4> ,
<i>asnum_range</i>	(Optional) <AA4>-<AA4> ,
<i>asnum_trail</i>	<AA4> ,
<i>asnum_range_trail</i>	<AA4>-<AA4> ,

## Command Mode

- /exec/configure/route-map

## match as-number as-path-list

match as-number as-path-list <aspl-name> + | no match as-number as-path-list { <aspl-name> | <aspl-name> } +

### Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
as-number	Match BGP peer AS number
as-path-list	AS-path access-list
<i>aspl-name</i>	AS path access list name
<i>aspl-name</i>	AS path access list name
<i>aspl-name</i>	Known as-path access-list name

### Command Mode

- /exec/configure/route-map

# match as-path

match as-path <aspl-name> + | no match as-path { <aspl-name> | <aspl-name> } +

## Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
as-path	Match BGP AS path list
<i>aspl-name</i>	AS path access list name
<i>aspl-name</i>	AS path access list name
<i>aspl-name</i>	Known as-path access-list name

## Command Mode

- /exec/configure/route-map

# match class-map

[no] match class-map < cmap-name >

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
class-map	Class map
<i>cmap-name</i>	class map name

## Command Mode

- /exec/configure/class-map/type/queuing

# match community

[no] match community <name> + [ exact-match ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
community	Match BGP community list
<i>name</i>	Community list name
exact-match	(Optional) Do exact matching of communities

## Command Mode

- /exec/configure/route-map

# match cos

[no] match cos <cos-list>

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
cos	IEEE 802.1Q class of service
<i>cos-list</i>	List of class-of-service values

## Command Mode

- /exec/configure/class-map/type/uf



# match cos

[no] match cos <cos-list>

## Syntax Description

<i>cos-list</i>	
no	(Optional) Negate a command or set its defaults
match	Classification criteria
cos	IEEE 802.1Q Class of Service

## Command Mode

- /exec/configure/class-map/type/queuing

# match datalink

[no] match datalink { mac source-address | mac destination-address | ethertype | vlan }

## Syntax Description

match	Specify a key field
datalink	datalink (Layer 2) attributes
mac	MAC Address
source-address	Source MAC Address
destination-address	Destination MAC Address
ethertype	Ethertype
vlan	VLAN ID

## Command Mode

- /exec/configure/nfm-record

# match datalink

[no] match datalink { mac source-address | mac destination-address | ethertype }

## Syntax Description

match	Specify a key field
datalink	datalink (Layer 2) attributes
mac	MAC Address
source-address	Source MAC Address
destination-address	Destination MAC Address
ethertype	Ethertype

## Command Mode

- /exec/configure/config-fte-record

# match dscp

[no] match dscp { <dscp-list> | <dscp-enum> } +

## Syntax Description

<i>dscp-list</i>	<dscp-enum>
no	(Optional) Negate a command or set its defaults
match	Classification criteria
dscp	DSCP in IP(v4) and IPv6 packets
<i>dscp-enum</i>	

## Command Mode

- /exec/configure/color-cmap

# match dscp

[no] match dscp { <dscp-list> } +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
dscp	DSCP in IP(v4) packets
<i>dscp-list</i>	List of DSCP values

## Command Mode

- /exec/configure/class-map/type/queuing

## match exception

```
[no] match exception { { ip | ipv6 } { option | { icmp { redirect | unreachable } } | multicast } } | ttl-failure
| glean | mtu-failure | nat-flow | sflow | { multicast { rpf-failure | sg-rpf-failure | dest-miss | ipv6-rpf-failure |
ipv6-sg-rpf-failure | ipv6-dest-miss } } }
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
exception	Match exception packets
ip	ipv4 match criteria
ipv6	ipv6 match criteria
option	Match ip/ipv6 option exception packets
icmp	Icmp redirect packets
redirect	Send redirected packets back to sender
unreachable	Send unreachable packets back to sender
municast	IP unicast packets with multicast MAC
ttl-failure	Failed in ttl
mtu-failure	mtu-failure
glean	Glean packets
multicast	multicast packets
rpf-failure	multicast rpf check failure
sg-rpf-failure	multicast sg rpf check failure
dest-miss	L3 multicast destination lookup failure
ipv6-rpf-failure	IPv6 multicast rpf check failure
ipv6-sg-rpf-failure	IPv6 multicast sg rpf check failure
ipv6-dest-miss	IPv6 L3 multicast destination lookup failure
nat-flow	ipv4 software nat flow packets
sflow	sflow packets

### Command Mode

- /exec/configure/cmap

# match extcommunity

[no] match extcommunity <name> + [ exact-match ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
extcommunity	Match BGP community list
<i>name</i>	Extended Community list name
exact-match	(Optional) Do exact matching of extended communities

## Command Mode

- /exec/configure/route-map

# match interface

[no] match interface <name> +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
interface	Match first hop interface of route
<i>name</i>	Interface name

## Command Mode

- /exec/configure/route-map



# match ip address

[no] match ip address <name> +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
ip	Configure IP features
address	Match address of route or match packet
<i>name</i>	IP access-list name (for use in route-maps for PBR only)

## Command Mode

- /exec/configure/route-map

## match ip address prefix-list

match ip address prefix-list <ipv4-pfl-name> + | no match ip address prefix-list { <ipv4-pfl-name> | <ipv4-pfl-name> } +

### Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
ip	Configure IP features
address	Match address of route or match packet
prefix-list	Match entries of prefix-lists
<i>ipv4-pfl-name</i>	Name of prefix-list
<i>ipv4-pfl-name</i>	Name of prefix-list
<i>ipv4-pfl-name</i>	Known prefix-list name

### Command Mode

- /exec/configure/route-map

# match ip multicast rp

```
{ match ip multicast { { rp <i>iprp</i> [ rp-type <i>iprptype</i> ] } | { group <i>gprefix</i> } | { source <i>ipsrc</i> } } + } |
{ match ip multicast { { rp <i>iprp</i> [ rp-type <i>iprptype</i> ] } | { group-range <i>gaddr_start</i> to <i>gaddr_end</i> }
| { source <i>ipsrc</i> } } + } | { no match ip multicast }
```

## Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
ip	Configure IP features
multicast	Match multicast attributes
rp	Rendezvous point
<i>iprp</i>	IPv4 rendezvous prefix
rp-type	(Optional) Multicast rendezvous point type
<i>iprptype</i>	(Optional) IPv4 rendezvous point type
group	Multicast Group prefix
<i>gprefix</i>	IPv4 group prefix
group-range	Multicast Group address range
<i>gaddr_start</i>	First Group address
to	Range
<i>gaddr_end</i>	Last Group address
source	Multicast source address
<i>ipsrc</i>	IPv4 source prefix

## Command Mode

- /exec/configure/route-map

# match ip next-hop prefix-list

match ip next-hop prefix-list <ipv4-pfl-name> + | no match ip next-hop prefix-list { <ipv4-pfl-name> | <ipv4-pfl-name> } +

## Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
ip	Configure IP features
next-hop	Match next-hop address of route
prefix-list	Match entries of prefix-lists
<i>ipv4-pfl-name</i>	Name of prefix-list
<i>ipv4-pfl-name</i>	Name of prefix-list
<i>ipv4-pfl-name</i>	Known prefix-list name

## Command Mode

- /exec/configure/route-map

# match ip protocol

[no] match ip { protocol | tos }

## Syntax Description

match	Specify a key field
ip	IP attributes
protocol	Protocol
tos	TOS

## Command Mode

- /exec/configure/nfm-record

## match ip route-source prefix-list

match ip route-source prefix-list <ipv4-pfl-name> + | no match ip route-source prefix-list { <ipv4-pfl-name> | <ipv4-pfl-name> } +

### Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
ip	Configure IP features
route-source	Match advertising source address of route
prefix-list	Match entries of prefix-lists
<i>ipv4-pfl-name</i>	Name of prefix-list
<i>ipv4-pfl-name</i>	Name of prefix-list
<i>ipv4-pfl-name</i>	Known prefix-list name

### Command Mode

- /exec/configure/route-map

# match ipv4 protocol

[no] match ipv4 { protocol | tos }

## Syntax Description

match	Specify a key field
ipv4	IPv4 attributes
protocol	Protocol
tos	TOS

## Command Mode

- /exec/configure/config-fte-record

## match ipv4 source address

[no] match ipv4 { source | destination } address

### Syntax Description

match	Specify a key field
ipv4	IPv4 attributes
source	Source Address
destination	Destination Address
address	Address

### Command Mode

- /exec/configure/config-fte-record



# match ipv4 source address

[no] match ipv4 { source | destination } address

## Syntax Description

match	Specify a key field
ipv4	IPv4 attributes
source	Source Address
destination	Destination Address
address	Address

## Command Mode

- /exec/configure/nfm-record

# match ipv4 transport destination

[no] match ipv4 transport { destination-port | source-port }

## Syntax Description

match	Specify a key field
ipv4	IPv4 attributes
transport	Transport layer fields
destination-port	Transport destination port
source-port	Transport source port

## Command Mode

- /exec/configure/config-fte-record

# match ipv6

```
[no] match ipv6 { { { source | destination } address } | { flow-label | options } }
```

## Syntax Description

match	Specify a key field
ipv6	IPv6 attributes
source	Source Address
destination	Destination Address
address	Address
flow-label	Flow label
options	Options

## Command Mode

- /exec/configure/nfm-record

# match ipv6

```
[no] match ipv6 { { { source | destination } address } | { flow-label } }
```

## Syntax Description

match	Specify a key field
ipv6	IPv6 attributes
source	Source Address
destination	Destination Address
address	Address
flow-label	Flow label

## Command Mode

- /exec/configure/config-fte-record

# match ipv6 address

[no] match ipv6 address <name>

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
ipv6	Configure IPv6 features
address	Match address of route or match packet
<i>name</i>	IPv6 access-list name (for use in route-maps for PBR only)

## Command Mode

- /exec/configure/route-map

# match ipv6 address prefix-list

match ipv6 address prefix-list <ipv6-pfl-name> + | no match ipv6 address prefix-list { <ipv6-pfl-name> | <ipv6-pfl-name> } +

## Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
ipv6	Configure IPv6 features
address	Match address of route or match packet
prefix-list	Match entries of prefix-lists
<i>ipv6-pfl-name</i>	Name of prefix-list
<i>ipv6-pfl-name</i>	Name of prefix-list
<i>ipv6-pfl-name</i>	Known prefix-list name

## Command Mode

- /exec/configure/route-map

## match ipv6 multicast rp

```
{ match ipv6 multicast { { rp <ipv6rp> [ rp-type <ipv6rptype> ] } | { group <gprefix> } | { source <ipv6src> } } + } | { match ipv6 multicast { { rp <ipv6rp> [ rp-type <ipv6rptype> ] } | { group-range <gaddr_start> to <gaddr_end> } | { source <ipv6src> } } + } | { no match ipv6 multicast }
```

### Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
ipv6	Configure IPv6 features
multicast	Match multicast attributes
rp	Rendezvous point
rp-type	(Optional) Multicast rendezvous point type
<i>ipv6rptype</i>	(Optional) IPv6 rendezvous point type
group	Multicast group address
group-range	Multicast Group address range
to	Range
source	Multicast source address

### Command Mode

- /exec/configure/route-map

## match ipv6 next-hop prefix-list

```
match ipv6 next-hop prefix-list <ipv6-pfl-name> + | no match ipv6 next-hop prefix-list { <ipv6-pfl-name> |
<ipv6-pfl-name> } +
```

### Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
ipv6	Configure IPv6 features
next-hop	Match next-hop address of route
prefix-list	Match entries of prefix-lists
<i>ipv6-pfl-name</i>	Name of prefix-list
<i>ipv6-pfl-name</i>	Name of prefix-list
<i>ipv6-pfl-name</i>	Known prefix-list name

### Command Mode

- /exec/configure/route-map



# match ipv6 protocol

[no] match ipv6 { protocol | tos }

## Syntax Description

match	Specify a key field
ipv6	IPv6 attributes
protocol	Protocol
tos	TOS

## Command Mode

- /exec/configure/config-fte-record

## match ipv6 route-source prefix-list

```
match ipv6 route-source prefix-list <ipv6-pfl-name> + | no match ipv6 route-source prefix-list {
<ipv6-pfl-name> | <ipv6-pfl-name> } +
```

### Syntax Description

no	Negate a command or set its defaults
match	Match values from routing table
ipv6	Configure IPv6 features
route-source	Match advertising source address of route
prefix-list	Match entries of prefix-lists
<i>ipv6-pfl-name</i>	Name of prefix-list
<i>ipv6-pfl-name</i>	Name of prefix-list
<i>ipv6-pfl-name</i>	Known prefix-list name

### Command Mode

- /exec/configure/route-map

# match ipv6 transport destination

[no] match ipv6 transport { destination-port | source-port }

## Syntax Description

match	Specify a key field
ipv6	IPv6 attributes
transport	Transport layer fields
destination-port	Transport destination port
source-port	Transport source port

## Command Mode

- /exec/configure/config-fte-record

# match metric

[no] match metric { <measure> [ <plus-minus> <deviation> ] } +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
metric	Match metric of route
<i>plus-minus</i>	(Optional) +-
<i>measure</i>	Metric value
<i>deviation</i>	(Optional) Deviation value

## Command Mode

- /exec/configure/route-map

# match ospf-area

[no] match ospf-area <area> +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
ospf-area	Match ospf area
<i>area</i>	area id

## Command Mode

- /exec/configure/route-map

# match protocol

[no] match protocol { fcoe | iscsi | tcp }

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
protocol	Protocol
fcoe	FCoE
iscsi	ISCSI
tcp	TCP

## Command Mode

- /exec/configure/class-map/type/uf

# match protocol arp

```
[no] match protocol { arp | mpls [ router-alert | exp <exp_value> ] }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
protocol	Protocol
arp	IP ARP
mpls	Multi-protocol Label Switching
router-alert	(Optional) Match packets with router-alert label set to 1 for OTV Overlay frames
exp	(Optional) Match packets on MPLS exp bits
<i>exp_value</i>	(Optional) Exp bits value

## Command Mode

- /exec/configure/cmap

# match qos-group

[no] match qos-group { <qos-group-list> } +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
qos-group	QoS Group
<i>qos-group-list</i>	List of qos-group values

## Command Mode

- /exec/configure/class-map/type/queuing



# match qos-group2

[no] match qos-group2 { <qos-group-list> }

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
qos-group2	QoS Group
<i>qos-group-list</i>	

## Command Mode

- /exec/configure/class-map/type/queuing

# match qos-group2

[no] match qos-group2 <qos-group-list>

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
qos-group2	QoS Group
<i>qos-group-list</i>	

## Command Mode

- /exec/configure/class-map/type/uf

# match qos-group

[no] match qos-group <qos-group-list>

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
qos-group	QoS Group
<i>qos-group-list</i>	List of qos-group values

## Command Mode

- /exec/configure/class-map/type/uf

# match redirect

[no] match redirect <opt\_match\_redirect>

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Classification criteria
redirect	Match redirected packets
<i>opt_match_redirect</i>	Match criteria for redirected packets

## Command Mode

- /exec/configure/cmap

# match route-type

[no] match route-type { external | internal | level-1 | level-2 | local | nssa-external | type-1 | type-2 | inter-area | intra-area } +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
route-type	Match route-type of route
external	external route (BGP, EIGRP and OSPF type 1/2)
internal	internal route (including OSPF intra/inter area)
level-1	IS-IS level-1 route
level-2	IS-IS level-2 route
local	locally generated route
nssa-external	nssa-external route (OSPF type 1/2)
type-1	OSPF external type 1 route
type-2	OSPF external type 2 route
inter-area	OSPF inter area route
intra-area	OSPF intra area route

## Command Mode

- /exec/configure/route-map

# match source-protocol

[no] match source-protocol <src\_prot> +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
source-protocol	Match source protocol
<i>src_prot</i>	Protocol instance name

## Command Mode

- /exec/configure/route-map

# match tag

[no] match tag <tagid> +

## Syntax Description

no	(Optional) Negate a command or set its defaults
match	Match values from routing table
tag	Match tag of route
<i>tagid</i>	Tag value

## Command Mode

- /exec/configure/route-map

# match transport destination

[no] match transport { destination-port | source-port }

## Syntax Description

match	Specify a key field
transport	Transport layer fields
destination-port	Transport destination port
source-port	Transport source port

## Command Mode

- /exec/configure/nfm-record



# max-backoff

max-backoff <maxbackoff-val> | no max-backoff

## Syntax Description

no	Negate a command or set its defaults
max-backoff	OpenFlow controller maximum backoff timer (default is 8 seconds)
<i>maxbackoff-val</i>	max backoff timer value in secs

## Command Mode

- /exec/configure/openflow/switch

# max-backoff

max-backoff <maxbackoff-val> | no max-backoff

## Syntax Description

no	Negate a command or set its defaults
max-backoff	OpenFlow controller maximum backoff timer (default is 8 seconds)
<i>maxbackoff-val</i>	max backoff timer value in secs

## Command Mode

- /exec/configure/openflow/switch/sub-switch

# max-lsa

[no] max-lsa <maximum-number> [ <threshold> ] [ warning-only | [ ignore-time <ignore-time-minutes> ] [ ignore-count <ignore-count-number> ] [ reset-time <reset-time-minutes> ] ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
max-lsa	Feature to limit the number of non-self-originated LSAs
<i>maximum-number</i>	Set maximum number of non self-generated LSAs
<i>threshold</i>	(Optional) Threshold value (%) at which to generate a warning message
warning-only	(Optional) Log a warning message when limit is exceeded
ignore-time	(Optional) Set time during which all adjacencies are suppressed
<i>ignore-time-minutes</i>	(Optional) ignore-time in minutes
ignore-count	(Optional) Set count on how many times adjacencies can be suppressed
<i>ignore-count-number</i>	(Optional) ignore-count
reset-time	(Optional) Set number of minutes after which ignore-count is reset to zero
<i>reset-time-minutes</i>	(Optional) reset-time in minutes

## Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

# max-lsa

[no] max-lsa <maximum-number> [ <threshold> ] [ warning-only | [ ignore-time <ignore-time-minutes> ] [ ignore-count <ignore-count-number> ] [ reset-time <reset-time-minutes> ] ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
max-lsa	Feature to limit the number of non-self-originated LSAs
<i>maximum-number</i>	Set maximum number of non self-generated LSAs
<i>threshold</i>	(Optional) Threshold value (%) at which to generate a warning message
warning-only	(Optional) Log a warning message when limit is exceeded
ignore-time	(Optional) Set time during which all adjacencies are suppressed
<i>ignore-time-minutes</i>	(Optional) ignore-time in minutes
ignore-count	(Optional) Set count on how many times adjacencies can be suppressed
<i>ignore-count-number</i>	(Optional) ignore-count
reset-time	(Optional) Set number of minutes after which ignore-count is reset to zero
<i>reset-time-minutes</i>	(Optional) reset-time in minutes

## Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

# max-lsp-lifetime

max-lsp-lifetime <lifetime> | no max-lsp-lifetime [ <lifetime> ]

## Syntax Description

no	Negate a command or set its defaults
max-lsp-lifetime	Set maximum LSP lifetime
<i>lifetime</i>	Maximum LSP lifetime in seconds

## Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

# max-lsp-lifetime

max-lsp-lifetime <lifetime> | no max-lsp-lifetime [ <lifetime> ]

## Syntax Description

no	Negate a command or set its defaults
max-lsp-lifetime	Set maximum LSP lifetime
<i>lifetime</i>	Maximum LSP lifetime in seconds

## Command Mode

- /exec/configure/otv-isis/otv-isis-vrf-common

# max-lsp-lifetime

max-lsp-lifetime <lifetime> | no max-lsp-lifetime [ <lifetime> ]

## Syntax Description

no	Negate a command or set its defaults
max-lsp-lifetime	Set maximum LSP lifetime
<i>lifetime</i>	Maximum LSP lifetime in seconds

## Command Mode

- /exec/configure/l2mp-isis/l2mp-isis-vrf-common

## max-metric router-lsa

```
[no] max-metric router-lsa [ external-lsa [ <max-metric-extlsa> ] ] [ stub-prefix-lsa ] [ on-startup [ <timeout> ] ] [ wait-for bgp <as> ] ] [ inter-area-prefix-lsa [ <max-metric-sumlsa> ] ]
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
max-metric	Maximize the cost metric
router-lsa	Router LSA
external-lsa	(Optional) External LSAs
<i>max-metric-extlsa</i>	(Optional) Max metric value for external LSAs
stub-prefix-lsa	(Optional) Advertise Max metric for Stub links as well
on-startup	(Optional) Effective only at startup
<i>timeout</i>	(Optional) Wait period in seconds after startup
wait-for	(Optional) Wait for an event to advertise normal metric
bgp	(Optional) BGP Convergence
<i>as</i>	(Optional) ASN of BGP to wait for
inter-area-prefix-lsa	(Optional) Inter-area-prefix LSAs
<i>max-metric-sumlsa</i>	(Optional) Max metric value for summary LSAs

### Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf



## max-metric router-lsa

```
[no] max-metric router-lsa [ external-lsa [ <max-metric-extlsa> ] ] [ include-stub ] [ on-startup [ <timeout> ]
[ wait-for bgp <as> ] ] [ summary-lsa [ <max-metric-sumlsa> ] ]
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
max-metric	Maximize the cost metric
router-lsa	Router LSA
external-lsa	(Optional) External LSAs
<i>max-metric-extlsa</i>	(Optional) Max metric value for external LSAs
include-stub	(Optional) Advertise Max metric for Stub links as well
on-startup	(Optional) Effective only at startup
<i>timeout</i>	(Optional) Wait period in seconds after startup
wait-for	(Optional) Wait for an event to advertise normal metric
bgp	(Optional) BGP Convergence
<i>as</i>	(Optional) ASN of BGP to wait for
summary-lsa	(Optional) Summary LSAs
<i>max-metric-sumlsa</i>	(Optional) Max metric value for summary LSAs

### Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

# max-ports

[no] [ vmware ] max-ports

## Syntax Description

no	Negate a command or set its defaults
vmware	(Optional) VMware configuration
max-ports	Max ports on which this profile can be inherited

## Command Mode

- /exec/configure/port-profile

# max-ports

[ vmware ] max-ports <i0>

## Syntax Description

vmware	(Optional) VMware configuration
max-ports	Max ports on which this profile can be inherited
<i>i0</i>	Enter the max-number of ports

## Command Mode

- /exec/configure/port-profile

# maxas-limit

maxas-limit <as-limit> | no maxas-limit [ <as-limit> ]

## Syntax Description

no	Negate a command or set its defaults
maxas-limit	Allow AS-PATH attribute from EBGP neighbor imposing a limit on number of ASes
<i>as-limit</i>	Number of ASes in the AS-PATH attribute

## Command Mode

- /exec/configure/router-bgp/vrf-cmds

# maximum-paths

maximum-paths <max-paths> | no maximum-paths [ <max-paths> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Maximum paths per destination
<i>max-paths</i>	Maximum paths per destination

## Command Mode

- /exec/configure/router-ospf

# maximum-paths

maximum-paths <max-paths> | no maximum-paths [ <max-paths> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	RIP set maximum paths per route
<i>max-paths</i>	Maximum paths per prefix

## Command Mode

- /exec/configure/router-rip/router-rip-af-common /exec/configure/router-rip/router-rip-vrf-af-common

# maximum-paths

maximum-paths <max-paths> | no maximum-paths [ <max-paths> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Set maximum paths per destination
<i>max-paths</i>	Maximum paths per destination

## Command Mode

- /exec/configure/router-isis/router-isis-af-ipv4

# maximum-paths

maximum-paths <max-paths> | no maximum-paths [ <max-paths> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Set maximum paths per destination
<i>max-paths</i>	Maximum paths per destination

## Command Mode

- /exec/configure/router-isis/router-isis-vrf-common



# maximum-paths

maximum-paths <max-paths> | no maximum-paths [ <max-paths> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Maximum paths per destination
<i>max-paths</i>	Maximum paths per destination

## Command Mode

- /exec/configure/router-ospf3/router-ospf3-af-ipv6 /exec/configure/router-ospf3/vrf/router-ospf3-af-ipv6

# maximum-paths

{ { maximum-paths <num-paths> } | { no maximum-paths [ <num-paths> ] } }

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Forward packets over multiple paths
<i>num-paths</i>	Number of paths

## Command Mode

- /exec/configure/router-egrp/router-egrp-vrf-common /exec/configure/router-egrp/router-egrp-af-common

# maximum-paths

maximum-paths [ ibgp ] <mpath-count> | no maximum-paths [ ibgp ] [ <mpath-count> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Forward packets over multipath paths
ibgp	(Optional) Configure multipath for IBGP paths
<i>mpath-count</i>	Number of parallel paths

## Command Mode

- /exec/configure/router-bgp/router-bgp-af /exec/configure/router-bgp/router-bgp-af-l2vpn-evpn

# maximum-paths

maximum-paths <max-paths> | no maximum-paths [ <max-paths> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Set maximum paths per destination
<i>max-paths</i>	Maximum paths per destination

## Command Mode

- /exec/configure/l2mp-isis/l2mp-isis-vrf-common /exec/configure/l2mp-isis/l2mp-isis-l2-topo

# maximum-paths eibgp

maximum-paths eibgp <mpath-count> | no maximum-paths eibgp [ <mpath-count> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Forward packets over multipath paths
eibgp	Configure multipath for both EBGP and IBGP paths
<i>mpath-count</i>	Number of parallel paths

## Command Mode

- /exec/configure/router-bgp/router-bgp-vrf-af-ipv4 /exec/configure/router-bgp/router-bgp-vrf-af-ipv6  
/exec/configure/router-bgp/router-bgp-af-vpn4 /exec/configure/router-bgp/router-bgp-af-vpn6

# maximum-paths mixed

maximum-paths mixed <mpath-count> | no maximum-paths mixed [ <mpath-count> ]

## Syntax Description

no	Negate a command or set its defaults
maximum-paths	Forward packets over multipath paths
mixed	Configure multipath for local and remote paths
<i>mpath-count</i>	Number of parallel paths

## Command Mode

- /exec/configure/router-bgp/router-bgp-vrf-af-ipv4 /exec/configure/router-bgp/router-bgp-vrf-af-ipv6  
/exec/configure/router-bgp/router-bgp-af-vpn4 /exec/configure/router-bgp/router-bgp-af-vpn6  
/exec/configure/router-bgp/router-bgp-af-l2vpn-evpn

# maximum-peers

{ maximum-peers <limit> | no maximum-peers [ <limit> ] }

## Syntax Description

no	Negate a command or set its defaults
maximum-peers	Maximum number of peers for this prefix
<i>limit</i>	Max. peers limit

## Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor-prefix

# maximum-prefix

```
{ { maximum-prefix <value> [ <threshold> ] [ warning-only ] [ restart <time1> ] [ restart-count <count> ] [
reset-time <time2> ] [ dampened ] } | { no maximum-prefix [ <value> [ <threshold> ] [ warning-only ] [ restart
<time1> ] [ restart-count <count> ] [ reset-time <time2> ] [ dampened ] } }
```

## Syntax Description

no	Negate a command or set its defaults
maximum-prefix	Maximum number of IP prefixes acceptable in aggregate
<i>value</i>	Number of IP prefixes for maximum-prefix limit
<i>threshold</i>	(Optional) Threshold value (%) at which to generate a warning message
warning-only	(Optional) Only give warning message when limit is exceeded
restart	(Optional) Duration for which a prefix source is ignored
<i>time1</i>	(Optional) Restart interval in minutes
restart-count	(Optional) Number of times sessions are auto-restarted
<i>count</i>	(Optional) Number of times
reset-time	(Optional) Duration after which restart history is cleared
<i>time2</i>	(Optional) Reset time in minutes
dampened	(Optional) Exponentially increase restart time interval

## Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common



## maximum-prefix

```
maximum-prefix <limit> [ <percent> ] [ restart <restart-time> | warning-only ] | { no | default } maximum-prefix
[ <limit> [ <percent> ] [ restart <restart-time> | warning-only ] ]
```

### Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
maximum-prefix	Maximum number of prefixes from this neighbor
<i>limit</i>	Max. prefix limit
<i>percent</i>	(Optional) Threshold percentage at which to generate a warning
restart	(Optional) Restart bgp connection after limit is exceeded
<i>restart-time</i>	(Optional) Restart interval in minutes
warning-only	(Optional) Only give a warning message when limit is exceeded

### Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-evpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv4
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv6
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-link-state
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-label
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-label

# maximum-prefix

maximum-prefix <limit> [ <percent> ] [ restart <restart-time> | warning-only ] | { no | default } maximum-prefix [ <limit> [ <percent> ] [ restart <restart-time> | warning-only ] ]

## Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
maximum-prefix	Maximum number of prefixes from this neighbor
<i>limit</i>	Max. prefix limit
<i>percent</i>	(Optional) Threshold percentage at which to generate a warning
restart	(Optional) Restart bgp connection after limit is exceeded
<i>restart-time</i>	(Optional) Restart interval in minutes
warning-only	(Optional) Only give a warning message when limit is exceeded

## Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mdt  
/exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-vpls

## maximum routes

[no] maximum routes <limit> [ { <warnlevel> [ reinstall <threshold> ] } | warning-only ]

### Syntax Description

no	(Optional) Negate a command or set its defaults
maximum	Set a limit
routes	Maximum number of routes allowed in this routing table
<i>limit</i>	Maximum number of routes allowed
<i>warnlevel</i>	(Optional) Threshold value (%) at which to generate a warning msg
reinstall	(Optional) Reinstall previous rejected route due to over maximum route limit
<i>threshold</i>	(Optional) Threshold value (%) at which to reinstall routes back to VRF
warning-only	(Optional) Only give a warning message if limit is exceeded

### Command Mode

- /exec/configure/vrf-af-ipv4 /exec/configure/vrf-af-ipv6

# mdix auto

{ mdix auto | no mdix [ auto ] }

## Syntax Description

no	Negate a command or set its defaults
mdix	Enable auto mdix mode
auto	Enable auto mdix mode

## Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

# mdt asm-use-shared-tree

[no] mdt asm-use-shared-tree

## Syntax Description

no	(Optional) Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
asm-use-shared-tree	Use (*,G) only state, no remote source state is created

## Command Mode

- /exec/configure/vrf

## mdt data

[no] mdt data <prefix> [ threshold <value> | immediate-switch ] [ route-map <policy-name> ]

### Syntax Description

no	(Optional) Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
data	Configure settings for Data MDT
<i>prefix</i>	List of group range prefixes
threshold	(Optional) Data MDT switching threshold
immediate-switch	(Optional) Move to data mdt immediately if remote receiver exists
<i>value</i>	(Optional) Threshold in kilobits per sec
route-map	(Optional) Specify policy for creating Data MDTs
<i>policy-name</i>	(Optional) A route-map name

### Command Mode

- /exec/configure/vrf

# mdt data bidir-enable

[no] mdt data bidir-enable

## Syntax Description

no	(Optional) Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
data	Configure settings for Data MDT
bidir-enable	Allow creation of data mdts for bidir customers

## Command Mode

- /exec/configure/vrf

# mdt default

mdt default <mdt-default> | no mdt default [ <mdt-default> ]

## Syntax Description

no	Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
default	The default group
<i>mdt-default</i>	IP multicast group address

## Command Mode

- /exec/configure/vrf



# mdt enforce-bgp-mdt-safi

[no] mdt enforce-bgp-mdt-safi

## Syntax Description

no	(Optional) Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
enforce-bgp-mdt-safi	Depend on BGP MDT SAFI for auto-discovery

## Command Mode

- /exec/configure/vrf

# mdt mtu

[no] mdt mtu <mtu-value>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
mtu	The MTU
<i>mtu-value</i>	MTU value

## Command Mode

- /exec/configure/vrf

# mdt pim hello-interval

[no] mdt pim hello-interval <interval>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
pim	PIM protocol related parameters
hello-interval	Hello interval used between peers
<i>interval</i>	Interval in milliseconds

## Command Mode

- /exec/configure/vrf

# mdt pim jp-interval

[no] mdt pim jp-interval <interval>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
pim	PIM protocol related parameters
jp-interval	Join-Prune interval used between peers
<i>interval</i>	Interval in seconds

## Command Mode

- /exec/configure/vrf

# mdt source

[no] mdt source <interface>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mdt	Backbone Multicast Distribution Tree
source	Source interface to be used in the backbone network
<i>interface</i>	Use IP address of this interface

## Command Mode

- /exec/configure/vrf

# media-type auto

media-type auto

## Syntax Description

media-type	Select the media-type link
auto	Select mgmt port as auto

## Command Mode

- /exec/configure/if-mgmt-ether

# media-type rj45

media-type rj45

## Syntax Description

media-type	Select the media-type link
rj45	Select mgmt port rj45

## Command Mode

- /exec/configure/if-mgmt-ether

# media-type sfp

media-type sfp

## Syntax Description

media-type	Select the media-type link
sfp	Select mgmt port sfp

## Command Mode

- /exec/configure/if-mgmt-ether



# media

media <vlanshowinfo-media-type> | no media

## Syntax Description

no	Negate a command or set its defaults
media	Media type of the VLAN
<i>vlanshowinfo-media-type</i>	Select media type

## Command Mode

- /exec/configure/vlan

# medium

medium <medium-type> | no medium <medium-type>

## Syntax Description

no	Negate a command or set its defaults
medium	Configure Interface medium mode
<i>medium-type</i>	

## Command Mode

- /exec/configure/if-vlan-common

# medium broadcast

{ medium broadcast | no medium broadcast }

## Syntax Description

no	Negate a command or set its defaults
medium	Configure Interface medium mode
broadcast	Broadcast medium

## Command Mode

- /exec/configure/if-ethernet-p2p-switch /exec/configure/if-ethernet-p2p /exec/configure/if-ethernet-all /exec/configure/if-eth-l3-non-member /exec/configure/if-port-channel /exec/configure/if-remote-ethernet-sub /exec/configure/if-eth-port-channel-p2p /exec/configure/if-ethernet-p2p-m

# medium broadcast

{ medium broadcast | no medium broadcast }

## Syntax Description

no	Negate a command or set its defaults
medium	Configure Interface medium mode
broadcast	Broadcast medium

## Command Mode

- /exec/configure/ppm-ethernet-switch /exec/configure/if-ether-sub /exec/configure/if-ether-sub-p2p /exec/configure/if-ethernet-all

# medium p2p

{ medium p2p | no medium p2p }

## Syntax Description

no	Negate a command or set its defaults
medium	Configure Interface medium mode
p2p	Point-to-Point medium

## Command Mode

- /exec/configure/if-ethernet-p2p-switch /exec/configure/if-ethernet-p2p /exec/configure/if-ethernet-all /exec/configure/if-eth-l3-non-member /exec/configure/if-port-channel /exec/configure/if-remote-ethernet-sub /exec/configure/if-eth-port-channel-p2p /exec/configure/if-ethernet-p2p-m

# medium p2p

{ medium p2p | no medium p2p }

## Syntax Description

no	Negate a command or set its defaults
medium	Configure Interface medium mode
p2p	Point-to-Point medium

## Command Mode

- /exec/configure/ppm-ethernet-switch /exec/configure/if-ether-sub /exec/configure/if-ether-sub-p2p /exec/configure/if-port-channel-sub /exec/configure/if-ethernet-all

# member vlan

{ member vlan <vlan-range> } | { no member vlan [ <vlan-range> ] }

## Syntax Description

no	Negate a command or set its defaults
member	Set fabricpath topology VLAN membership
vlan	Configure VLANs for Fabricpath Topology
<i>vlan-range</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19

## Command Mode

- /exec/configure/fp-topology

# member vni

{ member vni <vni-range> } | { no member vni [ <vni-range> ] }

## Syntax Description

no	Negate a command or set its defaults
member	Set fabricpath topology VNI membership
vni	Configure VNIs for L2MP Topology
<i>vni-range</i>	vni range, Example: 4096, 4099-5013, 5019

## Command Mode

- /exec/configure/fp-topology



# member vni

[no] member vni <vni-range>

## Syntax Description

no	(Optional) Negate a command or set its defaults
member	NVE VN-Segment Membership
vni	Virtual Network Identifier
<i>vni-range</i>	vni range, Example: 5000 or 5001-5008

## Command Mode

- /exec/configure/if-nve

## member vni associate-vrf

[no] member vni <vni-range> associate-vrf

### Syntax Description

no	(Optional) Negate a command or set its defaults
member	NVE VN-Segment Membership
vni	Virtual Network Identifier
<i>vni-range</i>	vni range, Example: 5000 or 5001-5008
associate-vrf	Associate vni with a vrf

### Command Mode

- /exec/configure/if-nve

## message-digest-key md5

```
{ { message-digest-key <keyid> md5 <key> } | { no message-digest-key [ <keyid> md5 <key> ] } }
```

### Syntax Description

no	Negate a command or set its defaults
message-digest-key	Message digest authentication password (key)
<i>keyid</i>	Key ID
md5	Use MD5 algorithm
<i>key</i>	The OSPF password (key)

### Command Mode

- /exec/configure/router-ospf/router-ospf-vlink /exec/configure/router-ospf/vrf/router-ospf-vlink

## message-digest-key md5

```
{ { message-digest-key <keyid> md5 <key> } | { no message-digest-key [ <keyid> md5 <key> ] } }
```

### Syntax Description

no	Negate a command or set its defaults
message-digest-key	Message digest authentication password (key)
<i>keyid</i>	Key ID
md5	Use MD5 algorithm
<i>key</i>	OSPF password (key)

### Command Mode

- /exec/configure/router-ospf/vrf/router-ospf-slink

# metric-style transition

[no] metric-style { transition }

## Syntax Description

no	(Optional) Negate a command or set its defaults
metric-style	Configure metric style used in advertised LSPs
transition	Use both narrow and wide metric style

## Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

# metric-type

[no] metric-type <metric-type>

## Syntax Description

no	(Optional) Negate a command or set its defaults
metric-type	Identifying name of metric with max 128 characters
<i>metric-type</i>	Supported metric-types te,igp

## Command Mode

- /exec/configure/sr/te/color

# metric direct 0

[no] metric direct 0

## Syntax Description

no	(Optional) Negate a command or set its defaults
metric	Cost of direct routes
direct	Cost of direct routes
0	direct route cost is zero to be compatible with IOS

## Command Mode

- /exec/configure/router-rip

## metric maximum-hops

{ { metric maximum-hops <hops> } | { no metric maximum-hops [ <hops> ] } }

### Syntax Description

no	Negate a command or set its defaults
metric	Modify EIGRP routing metrics and parameters
maximum-hops	Advertise EIGRP routes greater than <hops> as unreachable
<i>hops</i>	Hop count

### Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common



# metric rib-scale

{ { metric rib-scale <rib-scale> } | { no metric rib-scale [ <rib-scale> ] } }

## Syntax Description

no	Negate a command or set its defaults
metric	Modify EIGRP routing metrics and parameters
rib-scale	Defines RIB scaling value
<i>rib-scale</i>	Rib scale

## Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

## metric version 64bit

{ { metric version 64bit } | { no metric version [ 64bit ] } }

### Syntax Description

no	Negate a command or set its defaults
metric	Modify EIGRP routing metrics and parameters
version	Modify EIGRP metric version
64bit	64 bit metric version

### Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

# metric weights

```
{ { metric weights <tos> <k1> <k2> <k3> <k4> <k5> [ <k6> ] } | { no metric weights [ <tos> <k1> <k2> <k3> <k4> <k5> [ <k6> ] ] } }
```

## Syntax Description

no	Negate a command or set its defaults
metric	Modify EIGRP routing metrics and parameters
weights	Modify EIGRP metric coefficients
<i>tos</i>	Type Of Service (Only TOS 0 supported)
<i>k1</i>	K1
<i>k2</i>	K2
<i>k3</i>	K3
<i>k4</i>	K4
<i>k5</i>	K5
<i>k6</i>	(Optional) K6

## Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

# mkdir

mkdir <uri0>

## Syntax Description

mkdir	Create new directory
<i>uri0</i>	Directory name

## Command Mode

- /exec

# mode

[no] mode <mode-id>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mode	Hot-standby mode
<i>mode-id</i>	Node Mode

## Command Mode

- /exec/configure/itd-dg-node

# mode

[no] mode <vmode>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mode	Operational mode of the VLAN
<i>vmode</i>	

## Command Mode

- /exec/configure/vlan

# mode

[no] mode <mode-id>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mode	Configure Hot-standby mode for a node
<i>mode-id</i>	Mode of node

## Command Mode

- /exec/configure/plb-dg-node

## mode tap-aggregation

[no] mode tap-aggregation [ { vlan <vlan\_id> } ]

### Syntax Description

no	(Optional) Negate a command or set its defaults
mode	Configure the interface operational mode
tap-aggregation	Disable/Enable tap aggregation on the interface
vlan	(Optional) vlan that is to be tagged in outgoing packets
<i>vlan_id</i>	(Optional) Vlan ID

### Command Mode

- /exec/configure/if-switching



# module transceiver-frequency

[no] module <module> transceiver-frequency { <xcvr\_frequency> }

## Syntax Description

no	(Optional) Negate a command or set its defaults
module	Configure for module
<i>module</i>	Enter module number
transceiver-frequency	Configure X2 transceiver frequency type
<i>xcvr_frequency</i>	Enter transceiver frequency type

## Command Mode

- /exec/configure

# monitor erspan granularity

[no] monitor erspan granularity { 100\_us | 100\_ns | 1588 | ns }

## Syntax Description

no	(Optional) Negate a command or set its defaults
monitor	Configure Ethernet SPAN sessions
erspan	Configure Ethernet ERSPAN sessions
granularity	Configure granularity for ERSPAN Type III sessions
100_us	100 microseconds
100_ns	100 nanoseconds
1588	1588 in seconds/nanoseconds
ns	nanoseconds

## Command Mode

- /exec/configure

# monitor erspan origin ip-address

[no] monitor erspan origin ip-address <ip> [ global ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
monitor	Configure Ethernet SPAN sessions
erspan	Configure Ethernet ERSPAN sessions
origin	Configure the erspan origin ip address
ip-address	Configure global origin IP address
<i>ip</i>	
global	(Optional) Configure in default VDC across all VDCs

## Command Mode

- /exec/configure

# monitor erspan switch-id

[no] monitor erspan switch-id <switch\_id>

## Syntax Description

no	(Optional) Negate a command or set its defaults
monitor	Configure Ethernet SPAN sessions
erspan	Configure Ethernet ERSPAN sessions
switch-id	Configure the erspan switch-id
<i>switch_id</i>	erspan-switch-id

## Command Mode

- /exec/configure

# monitor session

monitor session <session\_number> [ type local ]

## Syntax Description

monitor	Configure Ethernet SPAN sessions
session	Configure session preferences
<i>session_number</i>	
type	(Optional) Specify a session type
local	(Optional) Create a local session

## Command Mode

- /exec/configure

## monitor session shut

[no] monitor session { all | <session\_range> } [ shut ] | monitor session { all | <session\_range> } shut

### Syntax Description

no	Negate a command or set its defaults
monitor	Configure Ethernet SPAN sessions
session	Configure session preferences
all	All sessions
<i>session_range</i>	
shut	(Optional) Shut the selected session

### Command Mode

- /exec/configure

# monitor session type acl-capture

monitor session <session\_number> type acl-capture

## Syntax Description

monitor	Configure Ethernet SPAN sessions
session	Configure session preferences
<i>session_number</i>	
type	Specify a session type
acl-capture	Create an acl-capture session

## Command Mode

- /exec/configure

# monitor session type erspan-destination

monitor session <session\_number> type erspan-destination

## Syntax Description

monitor	Configure Ethernet SPAN sessions
session	Configure session preferences
<i>session_number</i>	
type	Specify a session type
erspan-destination	Create an erspan destination session

## Command Mode

- /exec/configure



## monitor session type erspan-source

monitor session <session\_number> type erspan-source

### Syntax Description

monitor	Configure Ethernet SPAN sessions
session	Configure session preferences
<i>session_number</i>	
type	Specify a session type
erspan-source	Create an erspan source session

### Command Mode

- /exec/configure

# monitor session warp

[no] monitor session warp

## Syntax Description

no	Negate a command or set its defaults
monitor	Configure Ethernet SPAN sessions
session	Configure session preferences
warp	Configure Warp span mode

## Command Mode

- /exec/configure

# monitor session warp

monitor session warp [ type local ]

## Syntax Description

monitor	Configure Ethernet SPAN sessions
session	Configure session preferences
warp	Create warp session
type	(Optional) Specify a session type
local	(Optional) Create a local session

## Command Mode

- /exec/configure

# mount

mount { usb1: | usb2: }

## Syntax Description

mount	mount expansion flash or USB storage
usb1:	mount USB drive in port 1
usb2:	mount USB drive in port 2

## Command Mode

- /exec

# mount slot0

mount slot0:

## Syntax Description

mount	mount expansion flash or USB storage
slot0:	mount expansion flash

## Command Mode

- /exec

# move

move <uri0> <uri1>

## Syntax Description

move	Move files
<i>uri0</i>	Source file path
<i>uri1</i>	Destination file path

## Command Mode

- /exec

## mst designated priority

mst <mst-id> designated priority <prio> | no mst <mst-id> designated priority [ <prio> ]

### Syntax Description

no	Negate a command or set its defaults
mst	Multiple spanning tree configuration
<i>mst-id</i>	MST instance range, example: 0-3,5,7-9
designated	Set the designated bridge priority for the spanning tree
priority	Set the bridge priority for the spanning tree
<i>prio</i>	bridge priority in increments of 4096

### Command Mode

- /exec/configure/spanning-tree/pseudo

## mst root priority

mst <mst-id> root priority <prio> | no mst <mst-id> root priority [ <prio> ]

### Syntax Description

no	Negate a command or set its defaults
mst	Multiple spanning tree configuration
<i>mst-id</i>	MST instance range, example: 0-3,5,7-9
root	Set the root bridge priority for the spanning tree
priority	Set the bridge priority for the spanning tree
<i>prio</i>	bridge priority in increments of 4096

### Command Mode

- /exec/configure/spanning-tree/pseudo



# mtrace

```
mtrace <source> [ <receiver> ] [ <group> ] [ vrf <vrf-known-name> ]
```

## Syntax Description

mtrace	Trace
<i>source</i>	IP
<i>receiver</i>	(Optional) IP
<i>group</i>	(Optional) IP
vrf	(Optional) VRF
<i>vrf-known-name</i>	(Optional) Known VRF name

## Command Mode

- /exec

# mtu

mtu <mtu\_val> | no mtu [ <mtu\_val> ]

## Syntax Description

no	Negate a command or set its defaults
mtu	Configure mtu for the port
<i>mtu_val</i>	

## Command Mode

- /exec/configure/if-ether-sub /exec/configure/if-ether-sub-p2p /exec/configure/if-port-channel-sub /exec/configure/if-sub /exec/configure/if-ethernet-all /exec/configure/if-eth-non-member /exec/configure/if-port-channel

# mtu1

[no] mtu1 <value>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mtu1	MTU for the CoS
<i>value</i>	MTU value

## Command Mode

- /exec/configure/policy-map/type/uf/class

# mtu

mtu <mtu\_value> | no mtu

## Syntax Description

no	Negate a command or set its defaults
mtu	Set the MTU size for SPAN packets
<i>mtu_value</i>	

## Command Mode

- /exec/configure/monitor-local-src

# mtu

mtu <mtu\_value> | no mtu

## Syntax Description

no	Negate a command or set its defaults
mtu	Set the MTU size for ERSPAN packets
<i>mtu_value</i>	

## Command Mode

- /exec/configure/monitor-erspan-src

# mtu

mtu <mtu-val> | no mtu [ <mtu-val> ]

## Syntax Description

no	Negate a command or set its defaults
mtu	Configure MTU
<i>mtu-val</i>	Bytes

## Command Mode

- /exec/configure/if-any-tunnel

# mtu

[no] mtu <value>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mtu	MTU for the CoS
<i>value</i>	MTU value

## Command Mode

- /exec/configure/policy-map/type/uf/class

# mtu

[no] mtu <mtu>

## Syntax Description

mtu	MTU
<i>mtu</i>	MTU port to be configured

## Command Mode

- /exec/configure/config-ssx-exporter



# mtu

mtu <mtu\_val> | no mtu

## Syntax Description

no	Negate a command or set its defaults
mtu	Set the interface Maximum Transmission Unit (MTU)
<i>mtu_val</i>	MTU size in bytes

## Command Mode

- /exec/configure/if-vlan-common

# multi-topology

[no] multi-topology [ transition ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
multi-topology	Enable multitopology for IPV6
transition	(Optional) Configure multitopology transition mode

## Command Mode

- /exec/configure/router-isis/router-isis-af-ipv6

# multicast

[no] multicast <mode\_enum>

## Syntax Description

no	(Optional) Negate a command or set its defaults
multicast	Enable multicast best-effort
<i>mode_enum</i>	

## Command Mode

- /exec/configure/monitor-local-src /exec/configure/config-monitor  
/exec/configure/config-monitor-erspan-src

# multisite border-gateway interface

[no] multisite border-gateway interface <interface>

## Syntax Description

no	(Optional) Negate a command or set its defaults
multisite	VxLAN Multisite
border-gateway	VxLAN Multisite Border-gateway
interface	NVE Multisite Border-gateway Interface
<i>interface</i>	

## Command Mode

- /exec/configure/if-nve

# multisite ingress-replication

[no] multisite ingress-replication

## Syntax Description

no	(Optional) Negate a command or set its defaults
multisite	multisite ingress replication
ingress-replication	Configure ingress replication

## Command Mode

- /exec/configure/if-nve/vni

# mvr-config

[no] mvr-config

## Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-config	Enable IGMP MVR

## Command Mode

- /exec/configure

# mvr-group

```
[no] mvr-group { { <ip-addr> <ip-mask> } [ { vlan <vlan-id> } ] }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-group	MVR interface config
<i>ip-addr</i>	Group IP Address
<i>ip-mask</i>	IP network mask in format m.m.m.m
vlan	(Optional) Global default MVR vlan
<i>vlan-id</i>	(Optional) Enter MVR Vlan

## Command Mode

- /exec/configure/if-ethernet-switch /exec/configure/if-ethernet-all /exec/configure/if-eth-port-channel-switch /exec/configure/if-ethernet-p2p-switch /exec/configure/if-remote-ethernet-switch

## mvr-group

```
[no] mvr-group { { <ip-addr> } [ { vlan <vlan-id> } ] }
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-group	MVR Group
<i>ip-addr</i>	Group IP Address
vlan	(Optional) Global default MVR vlan
<i>vlan-id</i>	(Optional) Enter MVR Vlan

### Command Mode

- /exec/configure/igmp-mvr-global



# mvr-group

```
[no] mvr-group { { <ip-addr> count <count> } [ { vlan <vlan-id> } ] }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-group	MVR Group
<i>ip-addr</i>	Group IP Address
count	Number of contiguous groups
<i>count</i>	Number of contiguous groups
vlan	(Optional) Global default MVR vlan
<i>vlan-id</i>	(Optional) Enter MVR Vlan

## Command Mode

- /exec/configure/igmp-mvr-global

## mvr-group

```
[no] mvr-group { { <ip-addr> <ip-mask> } [ { vlan <vlan-id> } ] }
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-group	MVR Group
<i>ip-addr</i>	Group IP Address
<i>ip-mask</i>	IP network mask in format m.m.m.m
vlan	(Optional) Global default MVR vlan
<i>vlan-id</i>	(Optional) Enter MVR Vlan

### Command Mode

- /exec/configure/igmp-mvr-global

# mvr-group

```
[no] mvr-group { { <ip-prefix> } [ { vlan <vlan-id> } ] }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-group	MVR Group
<i>ip-prefix</i>	IP prefix and network mask length in format x.x.x.x/m
vlan	(Optional) Global default MVR vlan
<i>vlan-id</i>	(Optional) Enter MVR Vlan

## Command Mode

- /exec/configure/igmp-mvr-global

## mvr-group

```
[no] mvr-group { { <ip-addr> } [ { vlan <vlan-id> } ] }
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-group	MVR interface config
<i>ip-addr</i>	Group IP Address
vlan	(Optional) Global default MVR vlan
<i>vlan-id</i>	(Optional) Enter MVR Vlan

### Command Mode

- /exec/configure/if-ethernet-switch /exec/configure/if-ethernet-all /exec/configure/if-eth-port-channel-switch /exec/configure/if-ethernet-p2p-switch /exec/configure/if-remote-ethernet-switch

# mvr-group

```
[no] mvr-group { { <ip-addr> count <count> } [ { vlan <vlan-id> } ] }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-group	MVR interface config
<i>ip-addr</i>	Group IP Address
count	Number of contiguous groups
<i>count</i>	Number of contiguous groups
vlan	(Optional) Global default MVR vlan
<i>vlan-id</i>	(Optional) Enter MVR Vlan

## Command Mode

- /exec/configure/if-ethernet-switch /exec/configure/if-ethernet-all /exec/configure/if-eth-port-channel-switch /exec/configure/if-ethernet-p2p-switch /exec/configure/if-remote-ethernet-switch

## mvr-group

```
[no] mvr-group { { <ip-prefix> } [ { vlan <vlan-id> } ] }
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-group	MVR interface config
<i>ip-prefix</i>	IP prefix and network mask length in format x.x.x.x/m
vlan	(Optional) Global default MVR vlan
<i>vlan-id</i>	(Optional) Enter MVR Vlan

### Command Mode

- /exec/configure/if-ethernet-switch /exec/configure/if-ethernet-all /exec/configure/if-eth-port-channel-switch /exec/configure/if-ethernet-p2p-switch /exec/configure/if-remote-ethernet-switch

## mvr-suppress-query vlan

{ { mvr-suppress-query vlan <vlan-range> } | { no mvr-suppress-query } }

### Syntax Description

no	Negate a command or set its defaults
mvr-suppress-query	Suppress IGMP General query forwarding from vlans
vlan	MVR Vlan Id or ranges
<i>vlan-range</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19

### Command Mode

- /exec/configure/igmp-mvr-global

# mvr-type receiver

[no] mvr-type receiver

## Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-type	MVR interface config
receiver	Mvr receiver port

## Command Mode

- /exec/configure/if-ethernet-switch /exec/configure/if-ethernet-all /exec/configure/if-eth-port-channel-switch /exec/configure/if-ethernet-p2p-switch /exec/configure/if-remote-ethernet-switch



## mvr-type source

[no] mvr-type source

### Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-type	MVR interface config
source	Mvr source port

### Command Mode

- /exec/configure/if-ethernet-switch /exec/configure/if-ethernet-all /exec/configure/if-eth-port-channel-switch /exec/configure/if-ethernet-p2p-switch /exec/configure/if-remote-ethernet-switch

# mvr-vlan

[no] mvr-vlan <vlan-id>

## Syntax Description

no	(Optional) Negate a command or set its defaults
mvr-vlan	Global default MVR vlan
<i>vlan-id</i>	Enter MVR Vlan

## Command Mode

- /exec/configure/igmp-mvr-global

# mvr-vlan

{ { no mvr-vlan <vlan-id> } | { mvr-vlan <vlan-id> } }

## Syntax Description

no	Negate a command or set its defaults
mvr-vlan	Interface MVR Config
<i>vlan-id</i>	Enter MVR Vlan

## Command Mode

- /exec/configure/if-ethernet-switch /exec/configure/if-ethernet-all /exec/configure/if-eth-port-channel-switch /exec/configure/if-ethernet-p2p-switch /exec/configure/if-remote-ethernet-switch

