

Send comments to nexus5k-docfeedback@cisco.com



S Commands

This chapter describes the Cisco NX-OS interface commands that begin with S.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

shutdown

To shut down the local traffic on an interface, use the **shutdown** command. To return the interface to its default operational state, use the **no** form of this command.

shutdown

no shutdown

Syntax Description This command has no arguments or keywords.

Command Default Not shut down

Command Modes Interface configuration mode
Subinterface configuration mode
Virtual Ethernet interface configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	5.0(3)N1(1)	Support for Layer 3 interfaces and subinterfaces was added.
	5.1(3)N1(1)	Support for virtual Ethernet interface was added.

Usage Guidelines You can use this command on the following interfaces:

- Layer 2 interface (Ethernet interface, EtherChannel interface, subinterface)
- Layer 3 interface



Note Use the **no switchport** command to configure an interface as a Layer 3 interface.

- Layer 3 subinterface
- Management interface
- Virtual Ethernet interface

Examples This example shows how to shut down, or disable, a Layer 2 interface:

```
switch(config)# interface ethernet 1/10
switch(config-if)# shutdown
switch(config-if)#
```

This example shows how to shut down a Layer 3 Ethernet subinterface:

```
switch(config)# interface ethernet 1/5.1
switch(config-subif)# shutdown
```

Send comments to nexus5k-docfeedback@cisco.com

```
switch(config-subif)#
```

This example shows how to shut down a virtual Ethernet interface:

```
switch(config)# interface vethernet 10  
switch(config-if)# shutdown  
switch(config-if)#
```

Related Commands

Command	Description
no switchport	Converts an interface to a Layer 3 routed interface.
show interface ethernet	Displays the Ethernet interface configuration information.
show interface port-channel	Displays information on traffic about the specified EtherChannel interface.
show interface vethernet	Displays the virtual Ethernet interface configuration information.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

speed (interface)

To configure the transmit and receive speed for an interface, use the **speed** command. To reset to the default speed, use the **no** form of this command.

speed { **10** | **100** | **1000** | **10000** | **auto** }

no speed

Syntax Description		
10	Sets the interface speed to 10 Mbps.	This speed is not supported on Cisco Nexus 5500 Series switches.
100	Sets the interface speed to 100 Mbps.	This speed is not supported on a management interface, Cisco Nexus 5500 Series switches, or the CU-96 CEM card.
1000	Sets the interface speed to 1 Gbps.	For the Cisco Nexus 5596T switch, the base board ports support 1 Gbps.
10000	Sets the interface speed to 10 Gbps. This is the default speed.	This speed is not supported on a management interface. For the Cisco Nexus 5596T switch, the base board ports support 10 Gbps.
auto	Specifies that the speed of the interface is auto negotiated.	For the Cisco Nexus 5596T switch, you can choose auto negotiation on the 10GBase-T ports.

Command Default The default speed is 10000 (10-Gigabit).

Command Modes Interface configuration mode

Command History	Release	Modification
	4.0(1a)N1(1)	This command was introduced.
	5.1(3)N1(1)	Interface speed of 100 Mbps and the auto keyword was introduced.

Usage Guidelines The first 8 ports of a Cisco Nexus 5010 switch and the first 16 ports of a Cisco Nexus 5020 switch are switchable 1-Gigabit and 10-Gigabit ports. The default interface speed is 10-Gigabit. To configure these ports for 1-Gigabit Ethernet, insert a 1-Gigabit Ethernet SFP transceiver into the applicable port and then set its speed with the speed command.

The first 32 ports of a Cisco Nexus 5596T switch are switchable 1-Gigabit and 10-Gigabit ports. You can also configure them to auto-negotiate to either 1-Gigabit or 10-Gigabit. The last ports 33-48 are SFP+ ports and do not support auto negotiation.

Send comments to nexus5k-docfeedback@cisco.com**Examples**

This example shows how to set the speed for a 1-Gigabit Ethernet port:

```
switch# configure terminal
switch(config)# interface ethernet 2/1
switch(config-if)# speed 1000
```

This example shows how to set the an interface port to automatically negotiate the speed:

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config-if)# speed auto
switch(config-if)#
```

Related Commands

Command	Description
show interface	Displays the interface configuration information.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

system default switchport shutdown

To configure all Layer 2 switchports to be Layer 3 routed ports, use the **system default switchport shutdown** command. To reset to the default of all Layer 2 switchports, use the **no** form of this command.

system default switchport shutdown

no system default switchport shutdown

Syntax Description This command has no arguments or keywords.

Command Default The default is all ports configured as Layer 2 switchports.

Command Modes Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines When the **system default switchport shutdown** command is issued, any switchports (including FEX HIFs) that are not configured with **no shutdown** command are shut down. To avoid the shutdown, configure the switchports with **no shutdown** command.

Examples This example shows how to set all ports as Layer 3 routed ports:

```
switch# configure terminal
switch(config)# system default switchport shutdown
switch(config)#
```

This example shows how to reset all ports back to Layer 2 switchports:

```
switch# configure terminal
switch(config)# system default switchport shutdown
switch(config)#
```

Related Commands	Command	Description
	show interface	Displays the interface configuration information.