



# I Commands

---

- [install certificate](#), on page 2
- [install feature-set virtualization](#), on page 3
- [instance vlan](#), on page 4
- [interface ethernet](#), on page 5
- [interface ethernet \(Layer 3\)](#), on page 7
- [interface loopback](#), on page 10
- [interface mgmt](#), on page 11
- [interface port-channel](#), on page 12
- [interface vethernet](#), on page 14
- [interface vlan](#), on page 16
- [ip igmp snooping \(EXEC\)](#), on page 17
- [ip igmp snooping \(VLAN\)](#), on page 18

# install certificate

To install a certificate that is used to connect to a vCenter Server, use the **install certificate** command. To remove a certificate, use the **no** form of this command.

```
install certificate {bootflash:[// server /]|default}
no install certificate
```

## Syntax Description

<b>bootflash</b> :[// <i>server</i> /]	Specifies the source or destination URL for boot flash memory to install the certificate. The <i>server</i> argument value is <b>module-1</b> , <b>sup-1</b> , <b>sup-active</b> , or <b>sup-local</b> .
<b>default</b>	Specifies the default path.

## Command Default

None

## Command Modes

SVS connection configuration mode

## Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

## Usage Guidelines

This command does not require a license.

## Examples

This example shows how to install a certificate to the boot flash memory:

```
switch# configure terminal
switch(config)# svs connection SVSConn
switch(config-svs-conn)# install certificate bootflash:///
switch(config-svs-conn)#
```

This example shows how to remove a certificate:

```
switch# configure terminal
switch(config)# svs connection SVSConn
switch(config-svs-conn)# no install certificate
switch(config-svs-conn)#
```

## Related Commands

Command	Description
<b>show svs connections</b>	Displays SVS connection information.
<b>svs connection</b>	Enables an SVS connection.

# install feature-set virtualization

Does this need to be removed for the 6000?

To install the Cisco virtual machine feature set on the switch, use the **install feature-set virtualization** command. To remove the Cisco virtual machine feature set, use the **no** form of this command.

**install feature-set virtualization**  
**no install feature-set virtualization**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Disabled

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

## Usage Guidelines



**Note** The Cisco virtual machine feature is supported only on the Cisco Nexus 5500 Series switches.

This command requires an Enhanced Layer 2 license.

## Examples

This example shows how to install the Cisco virtual machine feature set on the switch:

```
switch# configure terminal
switch(config)# install feature-set virtualization
switch(config)#
```

## Related Commands

Command	Description
<b>feature vmfex</b>	Enables or disables Cisco Virtual Machine Fabric Extender (VM-FEX) on the switch.
<b>feature-set virtualization</b>	Enables the Cisco virtual machine feature set on the switch.
<b>show feature-set</b>	Displays the status of the virtualization feature set.
<b>show running-config</b>	Displays the running system configuration information.

# instance vlan

To map a VLAN or a set of VLANs to a Multiple Spanning Tree instance (MSTI), use the **instance vlan** command. To delete the instance and return the VLANs to the default instance (Common and Internal Spanning Tree [CIST]), use the **no** form of this command.

**instance** *instance-id* **vlan** *vlan-id*  
**no instance** *instance-id* [**vlan** *vlan-id*]

Syntax Description	
<i>instance-id</i>	Instances to which the specified VLANs are mapped. The range is from 0 to 4094.
<b>vlan</b> <i>vlan-id</i>	Specifies the number of the VLANs that you are mapping to the specified MSTI. The VLAN ID range is from 1 to 4094.

**Command Default** No VLANs are mapped to any MST instance (all VLANs are mapped to the CIST instance).

**Command Modes** MST configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

**Usage Guidelines** The VLAN identifier is entered as a single value or a range.  
 The mapping is incremental, not absolute. When you enter a range of VLANs, this range is added to or removed from the existing instances.  
 Any unmapped VLAN is mapped to the CIST instance.



**Caution** When you change the VLAN-to-MSTI mapping, the system restarts MST.

**Examples** This example shows how to map a range of VLANs to MSTI 4:

```
switch(config)#
spanning-tree mst configuration
switch(config-mst)# instance 4 vlan 100-200
```

Related Commands	Command	Description
	<b>show spanning-tree mst configuration</b>	Displays information about the MST protocol.
	<b>spanning-tree mst configuration</b>	Enters MST configuration mode.

# interface ethernet

To enter interface configuration mode for an Ethernet IEEE 802.3 interface, use the **interface ethernet** command.

**interface ethernet** [*chassis\_ID* /] *slot* /[*QSFP-module* /] *port*

Syntax Description	
<i>chassis_ID</i>	(Optional) Specifies the Fabric Extender chassis ID. The chassis ID is from 100 to 199. <b>Note</b> This argument is not optional when addressing the host interfaces of a Cisco Nexus 2000 Series Fabric Extender.
<i>slot</i>	Slot from 1 to 4. The following list defines the slots available: <ul style="list-style-type: none"> <li>• Slot 1 is the fixed ports.</li> <li>• Slot 2 to 4 are hot-swappable LEMs.</li> </ul>
<i>QSFP-module</i>	The QSFP-module number is 1 to 4. <b>Note</b> The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).
<i>port</i>	Port number within a particular slot. The port number is from 1 to 128.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	6.0(2)N1(1)	Support for the QSFP+ GEM was added.
	5.2(1)N1(1)	This command was introduced.

## Examples

This example shows how to enter configuration mode for Ethernet interface 1/4:

```
switch(config)#
interface ethernet 1/4
```

```
switch(config-if)#
```

This example shows how to enter configuration mode for a host interface on a Fabric Extender:

```
switch(config)#
interface ethernet 101/1/1
```

```
switch(config-if)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>interface vethernet</b>	Configures a virtual Ethernet interface.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show interface ethernet</b>	Displays various parameters of an Ethernet IEEE 802.3 interface.
<b>speed</b>	Sets the speed on the interface.
<b>vtp (interface)</b>	Enables VLAN Trunking Protocol (VTP) on an interface.

## interface ethernet (Layer 3)

To configure a Layer 3 Ethernet IEEE 802.3 routed interface, use the **interface ethernet** command.

**interface ethernet** [*chassis\_ID* /] *slot* / [*QSFP-module* /] *port* [.*subintf-port-no*]

Syntax Description	
<i>chassis_ID</i>	(Optional) Specifies the Fabric Extender chassis ID. The chassis ID is from 100 to 199. <b>Note</b> This argument is not optional when addressing the host interfaces of a Cisco Nexus 2000 Series Fabric Extender.
<i>slot</i>	Slots from 1 to 4. The following list defines the slots available: <ul style="list-style-type: none"> <li>• Slot 1 are the fixed ports.</li> <li>• Slots 2 to 4 are expansion modules.</li> </ul>
<i>QSFP-module</i>	The <i>QSFP-module</i> numbers are from 1 to 4. <b>Note</b> The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).
<i>port</i>	Port number within a particular slot. The port number is from 1 to 128.
.	(Optional) Specifies the subinterface separator.
<i>subintf-port-no</i>	(Optional) Port number for the subinterface. The range is from 1 to 48.

**Command Default** None

**Command Modes** Global configuration mode  
Interface configuration mode

Command History	Release	Modification
	6.0(2)N1(1)	Support for the QSFP+ GEM was added.
	5.2(1)N1(1)	This command was introduced.

**Usage Guidelines** You must use the **no switchport** command in the interface configuration mode to configure the interface as a Layer 3 routed interface. When you configure the interface as a Layer 3 interface, all Layer 2 specific configurations on this interface are deleted.

Use the **switchport** command to convert a Layer 3 interface into a Layer 2 interface. When you configure the interface as a Layer 2 interface, all Layer 3 specific configurations on this interface are deleted.

### Examples

This example shows how to enter configuration mode for a Layer 3 Ethernet interface 1/5:

```
switch(config)#
interface ethernet 1/5

switch(config-if)#
```

```

no switchport

switch(config-if)#
ip address 10.1.1.1/24

switch(config-if)#

```

This example shows how to configure a Layer 3 subinterface for Ethernet interface 1/5 in the global configuration mode:

```

switch(config)#
interface ethernet 1/5.2

switch(config-if)#
no switchport

switch(config-subif)#
ip address 10.1.1.1/24

switch(config-subif)#

```

This example shows how to configure a Layer 3 subinterface in interface configuration mode:

```

switch(config)#
interface ethernet 1/5

switch(config-if)#
no switchport

switch(config-if)#
interface ethernet 1/5.1

switch(config-subif)#
ip address 10.1.1.1/24

switch(config-subif)#

```

This example shows how to convert a Layer 3 interface to a Layer 2 interface:

```

switch(config)#
interface ethernet 1/5

switch(config-if)#
no switchport

switch(config-if)#
ip address 10.1.1.1/24

switch(config-if)#
switchport
switch(config-if)#

```

#### Related Commands

Command	Description
<b>bandwidth</b>	Sets the bandwidth parameters for an interface.
<b>delay</b>	Configures the interface throughput delay value.
<b>encapsulation</b>	Sets the encapsulation type for an interface.



<b>Command</b>	<b>Description</b>
<b>ip address</b>	Sets a primary or secondary IP address for an interface.
<b>inherit</b>	Assigns a port profile to an interface.
<b>interface vethernet</b>	Configures a virtual Ethernet interface.
<b>no switchport</b>	Configures an interface as a Layer 3 interface.
<b>service-policy</b>	Configures a service policy for an interface.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show interface ethernet</b>	Displays various parameters of an Ethernet IEEE 802.3 interface.

# interface loopback

To create a loopback interface and enter interface configuration mode, use the **interface loopback** command. To remove a loopback interface, use the **no** form of this command.

**interface loopback** *number*  
**no interface loopback** *number*

## Syntax Description

<i>number</i>	Interface number; valid values are from 0 to 1023.
---------------	----------------------------------------------------

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

## Usage Guidelines

Use the **interface loopback** command to create or modify loopback interfaces.

From the loopback interface configuration mode, the following parameters are available:

- **description**—Provides a description of the purpose of the interface.
- **ip**—Configures IP features, such as the IP address for the interface, Address Resolution Protocol (ARP) attributes, load balancing, Unicast Reverse Path Forwarding (RPF) or IP Source Guard.
- **logging**—Configure logging of events.
- **shutdown**—Shut down traffic on the interface.

This command does not require a license.

## Examples

This example shows how to create a loopback interface:

```
switch(config)# interface loopback 50

switch(config-if)# ip address 10.1.1.1/24
switch(config-if)#
```

## Related Commands

Command	Description
<b>show interface loopback</b>	Displays information about the traffic on the specified loopback interface.

# interface mgmt

To enter the management interface configuration mode, use the **interface mgmt** command.

```
interface mgmt mgmt-intf-num
```

<b>Syntax Description</b>	<i>mgmt-intf-num</i>	Management interface number. The interface number is 0.
---------------------------	----------------------	---------------------------------------------------------

**Command Default** None

**Command Modes** Global configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.2(1)N1(1)	This command was introduced.

## Examples

This example shows how to enter the management interface configuration mode:

```
switch# configure terminal
switch(config)# interface mgmt 0
switch(config-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show interface mgmt</b>	Displays information about the management interface.
	<b>cdp enable</b>	Enables the Cisco Discovery Protocol (CDP) on an interface.
	<b>description (interface)</b>	Adds a description to an interface configuration.
	<b>duplex</b>	Configures the duplex mode for an interface.
	<b>lldp (interface)</b>	Enables the reception or transmission of Link Layer Discovery Protocol (LLDP) packets on an interface.
	<b>rate-limit cpu direction</b>	Configures the packet per second (PPS) rate limit for an interface.
	<b>snmp trap link-status</b>	Enables Simple Network Management Protocol (SNMP) link trap generation on an interface.
	<b>speed</b>	Configures the transmit and receive speed for an interface.
	<b>vrf member</b>	Adds an interface to a virtual routing and forwarding (VRF) instance.

# interface port-channel

To create an EtherChannel interface and enter interface configuration mode, use the **interface port-channel** command. To remove an EtherChannel interface, use the **no** form of this command.

```
interface port-channel channel-number [. subintf-channel-no]
no interface port-channel channel-number [. subintf-channel-no]
```

## Syntax Description

<i>channel-number</i>	Channel number that is assigned to this EtherChannel logical interface. The range is from 1 to 4096.
.	(Optional) Specifies the subinterface separator. <b>Note</b> Applies to Layer 3 interfaces.
<i>subintf-channel-no</i>	(Optional) Port number of the EtherChannel subinterface. The range is from 1 to 4093. <b>Note</b> Applies to Layer 3 interfaces.

## Command Default

None

## Command Modes

Global configuration mode  
Interface configuration mode

## Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

## Usage Guidelines

A port can belong to only one channel group.

When you use the **interface port-channel** command for Layer 2 interfaces, follow these guidelines:

- If you are using CDP, you must configure it only on the physical interface and not on the EtherChannel interface.
- If you do not assign a static MAC address on the EtherChannel interface, a MAC address is automatically assigned. If you assign a static MAC address and then later remove it, the MAC address is automatically assigned.
- The MAC address of the EtherChannel is the address of the first operational port added to the channel group. If this first-added port is removed from the channel, the MAC address comes from the next operational port added, if there is one.

You must use the **no switchport** command in the interface configuration mode to configure the EtherChannel interface as a Layer 3 interface. When you configure the interface as a Layer 3 interface, all Layer 2 specific configurations on this interface are deleted.

Use the **switchport** command to convert a Layer 3 EtherChannel interface into a Layer 2 interface. When you configure the interface as a Layer 2 interface, all Layer 3 specific configurations on this interface are deleted.

You can configure one or more subinterfaces on a port channel made from routed interfaces.

## Examples

This example shows how to create an EtherChannel group interface with channel-group number 50:

```
switch(config)# interface port-channel 50
switch(config-if)#
```

This example shows how to create a Layer 3 EtherChannel group interface with channel-group number 10:

```
switch(config)# interface port-channel 10
switch(config-if)# no switchport
switch(config-if)# ip address 192.0.2.1/24
switch(config-if)#
```

This example shows how to configure a Layer 3 EtherChannel subinterface with channel-group number 1 in interface configuration mode:

```
switch(config)# interface port-channel 10
switch(config-if)# no switchport
switch(config-if)# interface port-channel 10.1
switch(config-subif)# ip address 192.0.2.2/24
switch(config-subif)#
```

This example shows how to configure a Layer 3 EtherChannel subinterface with channel-group number 20.1 in global configuration mode:

```
switch(config)# interface port-channel 20.1
switch(config-subif)# ip address 192.0.2.3/24
switch(config-subif)#
```

## Related Commands

Command	Description
<b>encapsulation</b>	(Layer 3 interfaces) Sets the encapsulation type for an interface.
<b>ip address</b>	(Layer 3 interfaces) Sets a primary or secondary IP address for an interface.
<b>no switchport</b>	(Layer 3 interfaces) Configures an interface as a Layer 3 interface.
<b>show interface</b>	Displays configuration information about interfaces.
<b>show lacp</b>	Displays LACP information.
<b>show port-channel summary</b>	Displays information on the EtherChannels.
<b>vtp (interface)</b>	Enables VLAN Trunking Protocol (VTP) on an interface.

# interface vethernet

To enter interface configuration mode for a virtual Ethernet (vEth) interface, use the **interface vethernet** command. To remove a virtual Ethernet interface, use the **no** form of this command.

```
interface vethernet veth-id [vethernet veth-id,...]
no interface vethernet veth-id [vethernet veth-id,...]
```

## Syntax Description

<i>veth-id</i>	Virtual Ethernet interface number. The range is from 1 to 1,048,575. You can specify more than one virtual Ethernet interface. Make sure you use the comma (,) separator.
----------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

## Usage Guidelines

Before you use a virtual Ethernet interface, you must enable the Cisco Virtual Machine Fabric Extender (VM-FEX) on the switch by using the **feature vmfex** command.

Before you use this command, you must enable the Adapter Fabric Extender (Adapter-FEX) on the switch by using the **feature adapter-fex** command.

You must configure a virtual Ethernet interface on each switch. The configuration in the secondary switch must be identical to that of the primary switch.

Does the following apply to the 6000?

You can create a maximum of 1000 virtual Ethernet interfaces on a Cisco Nexus 5548 switch. Before you disable Adapter-FEX on the switch, make sure that you delete these interfaces. After you delete a virtual Ethernet interface, make sure that you save the running configuration of the switch to the startup configuration file.

## Examples

This example shows how to enter configuration mode for virtual Ethernet interface 10:

```
switch# configure terminal
switch(config)# interface vethernet 10
switch(config-if)#
```

This example shows how to enter configuration mode for multiple virtual Ethernet interfaces:

```
switch# configure terminal
switch(config)# interface vethernet 10, vethernet 2
switch(config-if-range)#
```

This example shows how to bind an interface, configure a vEthernet access interface, assign the access VLAN for that interface, and then assign a port profile named ppVEth, and a class of service (CoS) value 3 to a virtual Ethernet interface:

```

switch# configure terminal
switch(config)# port-profile type vethernet ppVEth
switch(config-port-prof)# switchport mode access
switch(config-port-prof)# service-policy type qos input my_policy1
switch(config-port-prof)# exit
switch(config)# interface vethernet 10
switch(config-if)# bind interface ethernet 1/5 channel 10
switch(config-if)# inherit port-profile ppVEth
switch(config-if)# untagged cos 3
switch(config-if)#

```

This example shows how to remove a virtual Ethernet interface:

```

switch# configure terminal
switch(config)# no interface vethernet 2
switch(config)#

```

### Related Commands

Command	Description
<b>bind</b>	Binds an interface to a virtual Ethernet interface.
<b>feature adapter-fex</b>	Enables Adapter-FEX on the switch.
<b>feature vmfex</b>	enables VM-FEX on the switch.
<b>port-profile</b>	Configures a port profile.
<b>show interface ethernet</b>	Displays information about Ethernet interfaces.
<b>show interface vethernet</b>	Displays various parameters of a virtual Ethernet interface.
<b>show running-config interface</b>	Displays the running configuration of an interface.
<b>vethernet auto-create</b>	Sets the default policy to enable auto creation of virtual Ethernet interfaces.

# interface vlan

To create a VLAN interface and enter interface configuration mode, use the **interface vlan** command. To remove a VLAN interface, use the **no** form of this command.

```
interface vlan vlan-id
no interface vlan vlan-id
```

## Syntax Description

<i>vlan-id</i>	VLAN to set when the interface is in access mode; valid values are from 1 to 4094, except for the VLANs reserved for the internal switch use.
----------------	-----------------------------------------------------------------------------------------------------------------------------------------------

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

## Usage Guidelines

Before you use this command, enable the interface-vlan feature by using the **feature interface-vlan** command.

Use the **interface vlan** command to create or modify VLAN interfaces.

The VLAN interface is created the first time that you enter the **interface vlan** command for a particular VLAN. The *vlan-id* argument corresponds to the VLAN tag that is associated with the data frames on an IEEE 802.1Q-encapsulated trunk, or the VLAN ID that is configured for an access port.

This command does not require a license.

## Examples

This example shows how to create a VLAN interface for VLAN 50:

```
switch(config)# interface vlan 50
switch(config-if)#
```

## Related Commands

Command	Description
<b>feature interface-vlan</b>	Enables the ability to create VLAN interfaces.
<b>show interface vlan</b>	Displays information about the traffic on the specified VLAN interface.



## ip igmp snooping (EXEC)

To enable Internet Group Management Protocol (IGMP), use the **ip igmp snooping** command. To disable IGMP snooping, use the **no** form of this command.

**ip igmp snooping**  
**no ip igmp snooping**

**Syntax Description** This command has no arguments or keywords.

**Command Default** IGMP snooping is enabled.



**Note** If the global setting is disabled, then all VLANs are treated as disabled, whether they are enabled or not.

**Command Modes** EXEC mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

**Examples** This example shows how to enable IGMP snooping:

```
switch# ip igmp snooping
```

Related Commands	Command	Description
	<b>show ip igmp snooping</b>	Displays IGMP snooping information and configuration.

## ip igmp snooping (VLAN)

To configure Internet Group Management Protocol (IGMP) on a VLAN, use the **ip igmp snooping** command. To negate the command or return to the default settings, use the **no** form of this command

**ip igmp snooping** *parameter*

**no ip igmp snooping** *parameter*

### Syntax Description

<i>parameter</i>	Parameter to configure. See the “Usage Guidelines” section for additional information.
------------------	----------------------------------------------------------------------------------------

### Command Default

The default settings are as follows:

- **explicit-tracking**—enabled
- **fast-leave**—disabled for all VLANs
- **last-member-query-interval** *seconds* —1
- **querier** *IP-address* —disabled
- **report-suppression**—enabled

### Command Modes

VLAN configuration mode

### Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

### Usage Guidelines

The following table lists the valid values for *parameter*.

*Table 1: IGMP Snooping Parameters*

Keyword and Argument	Description
<b>explicit-tracking</b>	Enables tracking IGMPv3 membership reports for each port on a per-VLAN basis. The default is enabled on all VLANs.
<b>fast-leave</b>	Enables IGMPv3 snooping fast-leave processing. The default is disabled for all VLANs.
<b>last-member-query-interval</b> <i>seconds</i>	Removes the group if no hosts respond to an IGMP query message. Valid value is from 1 to 25 seconds. The default is 1 second.
<b>mrouter interface</b> <i>interface</i>	Configures a static connection to a multicast router. The specified interface is Ethernet or EtherChannel.
<b>querier</b> <i>IP-address</i>	Configures a snooping querier. The IP address is used as the source in messages. The default is disabled.
<b>report-suppression</b>	Limits the membership report traffic sent to multicast-capable routers. When you disable report suppression, all IGMP reports are sent as is to multicast-capable routers. The default is enabled.

Keyword and Argument	Description
<b>static-group</b> <i>group-ip-addr</i> [ <b>source</b> <i>source-ip-addr</i> ] <b>interface</b> <i>interface</i>	Configures an interface belonging to a VLAN as a static member of a multicast group. The specified interface is Ethernet or EtherChannel, or virtual Ethernet.

### Examples

This example shows how to configure IGMP snooping parameters for VLAN 5:

```
switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)# ip igmp snooping last-member-query-interval 3
switch(config-vlan)# ip igmp snooping querier 192.168.2.106
switch(config-vlan)# ip igmp snooping explicit-tracking
switch(config-vlan)# ip igmp snooping fast-leave
switch(config-vlan)# ip igmp snooping report-suppression
switch(config-vlan)# ip igmp snooping mrouter interface ethernet 1/10
switch(config-vlan)# ip igmp snooping static-group 192.0.2.1 interface ethernet 1/10
switch(config-vlan)# ip igmp snooping static-group 192.0.2.12 interface vethernet 4/1
switch(config-vlan)#
```

### Related Commands

Command	Description
<b>show ip igmp snooping</b>	Displays the IGMP snooping information and configuration.

