



R Commands

- [radius-server deadtime](#), on page 6
- [radius-server directed-request](#), on page 7
- [radius-server host key 0 6 7](#), on page 8
- [radius-server host test](#), on page 10
- [radius-server key 0 6 7](#), on page 11
- [radius-server pss-clean](#), on page 12
- [radius-server retransmit](#), on page 13
- [radius-server test](#), on page 14
- [radius-server timeout](#), on page 15
- [random-detect](#), on page 16
- [random-detect2 minimum-threshold2 maximum-threshold2](#), on page 18
- [random-detect](#), on page 19
- [random-detect cos-based](#), on page 21
- [rate-limit](#), on page 23
- [rate-limit cpu direction pps action log](#), on page 24
- [rate-limit cpu direction pps action log](#), on page 25
- [rate-mode](#), on page 26
- [rate-mode](#), on page 27
- [rd auto](#), on page 28
- [rd auto](#), on page 29
- [reconnect-interval](#), on page 30
- [record-route](#), on page 31
- [record-route](#), on page 32
- [record](#), on page 33
- [record netflow-original](#), on page 34
- [record netflow](#), on page 35
- [record netflow](#), on page 36
- [record netflow](#), on page 37
- [record netflow protocol-port](#), on page 38
- [redistribute bgp](#), on page 39
- [redistribute bgp eigrp isis ospf rip static direct amt lisp route-map](#), on page 40
- [redistribute filter route-map](#), on page 41
- [redistribute filter route-map](#), on page 42

- redistribute maximum-prefix, on page 43
- redistribute maximum-prefix, on page 44
- redistribute maximum-prefix, on page 45
- redistribute maximum-prefix, on page 46
- redistribute maximum-prefix, on page 47
- redistribute route-map, on page 48
- redistribute route-map, on page 49
- redistribute route-map, on page 50
- redistribute route-map, on page 51
- redistribute route-map, on page 52
- redistribute route-map, on page 53
- redistribute route-map, on page 54
- redistribute route-map, on page 55
- redistribute static route-map, on page 56
- redistribute static route-map, on page 57
- redundancy-group, on page 58
- reference-bandwidth, on page 59
- reference-bandwidth, on page 60
- register-database-mapping, on page 61
- register-route-notifications, on page 62
- reload, on page 63
- reload ascii, on page 64
- reload fex, on page 65
- reload force, on page 66
- reload kexec, on page 67
- reload kexec, on page 68
- reload module, on page 69
- reload module force-dnld, on page 70
- reload module hard, on page 71
- reload non-interruptive, on page 72
- reload power-cycle, on page 73
- reload restore, on page 74
- reload sync-adjacency, on page 75
- reload sync-adjacency, on page 76
- reload vdc, on page 77
- reload vdc, on page 78
- remark, on page 79
- remote-as, on page 80
- remote-span, on page 81
- remote, on page 82
- remove-private-as, on page 83
- remove-routes vni, on page 84
- reoptimize events link-up, on page 85
- replay-protection, on page 86
- replication-server, on page 87
- report, on page 88

- report, on page 89
- report, on page 90
- report, on page 91
- report, on page 92
- report, on page 93
- report, on page 94
- request-data-size, on page 95
- request-data-size, on page 96
- request-data-size, on page 97
- resequence access, on page 98
- reset, on page 99
- reset, on page 100
- reset, on page 101
- reset, on page 102
- reset, on page 103
- reset, on page 104
- reset, on page 105
- restart amt, on page 106
- restart bgp, on page 107
- restart eigrp, on page 108
- restart fabricpath domain, on page 109
- restart igmp, on page 110
- restart isis, on page 111
- restart l3vm, on page 112
- restart lisp, on page 113
- restart msdp, on page 114
- restart orib, on page 115
- restart ospf, on page 116
- restart ospfv3, on page 117
- restart otv-isis, on page 118
- restart otv, on page 119
- restart pim, on page 120
- restart pim6, on page 121
- restart pim stateless, on page 122
- restart rip, on page 123
- restart rpm, on page 124
- restart rsvp, on page 125
- resync-database, on page 126
- retain route-target all, on page 127
- retransmit-interval, on page 128
- retransmit-interval, on page 129
- retransmit-interval, on page 130
- revision, on page 131
- revocation-check crl, on page 132
- rfc1583compatibility, on page 133
- rip shutdown, on page 134

- [rmdir](#), on page 135
- [rmon alarm absolute rising-threshold falling-threshold](#), on page 136
- [rmon event](#), on page 137
- [rmon hcalarm absolute startupalarm rising-threshold falling-threshold owner](#), on page 138
- [roaming-eid-prefix](#), on page 139
- [role feature-group name](#), on page 140
- [role name](#), on page 141
- [role priority](#), on page 142
- [rollback progress stats](#), on page 143
- [rollback running-config checkpoint](#), on page 144
- [root-priority](#), on page 145
- [route-map](#), on page 146
- [route-map](#), on page 147
- [route-map](#), on page 148
- [route-map](#), on page 149
- [route-map out](#), on page 150
- [route-map out](#), on page 151
- [route-map pbr-statistics](#), on page 152
- [route-reflector-client](#), on page 153
- [route-reflector-client](#), on page 154
- [route-target both auto](#), on page 155
- [route-target both auto](#), on page 156
- [route-target export](#), on page 157
- [route-target export auto](#), on page 158
- [route-target import](#), on page 159
- [route-target import auto](#), on page 160
- [route delete dampen interval](#), on page 161
- [router-id](#), on page 162
- [router-id](#), on page 163
- [router-id](#), on page 164
- [router-id](#), on page 165
- [router-id](#), on page 166
- [router bgp](#), on page 167
- [router eigrp](#), on page 168
- [router isis](#), on page 169
- [router ospf](#), on page 170
- [router ospfv3](#), on page 171
- [router rip](#), on page 172
- [routing-context vrf](#), on page 173
- [routing ipv4 unicast nexthop-sorting](#), on page 174
- [routing ipv6 unicast nexthop-sorting](#), on page 175
- [rsakeypair](#), on page 176
- [rtr etr eid](#), on page 177
- [rule](#), on page 178
- [rule oid](#), on page 179
- [run-script](#), on page 180

- [run-show-tech-script](#), on page 181
- [run2 guestshell](#), on page 182
- [run bash](#), on page 183

radius-server deadtime

[no] radius-server deadtime <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
deadtime	duration for which non-reachable server is skipped
<i>i0</i>	Length of time, in minutes

Command Mode

- /exec/configure

radius-server directed-request

[no] radius-server directed-request

Syntax Description

no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
directed-request	enable direct authentication requests to server

Command Mode

- /exec/configure

radius-server host key 0 6 7

radius-server host key 0 6 7

```
{ { [ no ] radius-server host <hostipname> { { key { 0 <s0> | 6 <s6> | 7 <s1> | <s2> } [ pac ] [ auth-port <i0> [ acct-port <i1> ] ] } | { [ auth-port1 <i2> ] [ acct-port1 <i3> ] } } [ { authentication [ accounting [ timeout <i4> ] [ retransmit <i5> ] ] } | { [ accounting1 ] [ timeout1 <i6> ] [ retransmit1 <i7> ] ] } ] } | { no radius-server host <hostipname> key } }
```

Syntax Description

<i>key</i>	0
no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
host	RADIUS server's DNS name or its IP address
<i>hostipname</i>	IPV4/IPV6 address or DNS name
key	RADIUS shared secret
pac	(Optional) Secure Radius Enable
0	RADIUS shared secret(clear text)
<i>s0</i>	RADIUS shared secret(clear text)
accounting	(Optional) Use for accounting
retransmit	(Optional) RADIUS server retransmit count
<i>i5</i>	(Optional) RADIUS server retransmit count
timeout	(Optional) RADIUS server timeout period in seconds
<i>i4</i>	(Optional) RADIUS server timeout period in seconds
retransmit1	(Optional) RADIUS server retransmit count
<i>i7</i>	(Optional) RADIUS server retransmit count
auth-port	(Optional) RADIUS server's port for authentication
<i>i0</i>	(Optional) port number
timeout1	(Optional) RADIUS server timeout period in seconds
<i>i6</i>	(Optional) RADIUS server timeout period in seconds
acct-port	(Optional) RADIUS server's port for accounting
<i>i1</i>	(Optional) port number
accounting1	(Optional) Use for accounting

authentication	(Optional) Use for authentication
6	Radius shared secret(type-6 encrypted)
s6	Tadius shared secret(encrypted)
7	RADIUS shared secret(encrypted)
s1	RADIUS shared secret(encrypted)
auth-port1	(Optional) RADIUS server's port for authentication
i2	(Optional) port number
s2	RADIUS shared secret(clear text)
acct-port1	(Optional) RADIUS server's port for accounting
i3	(Optional) port number

Command Mode

- /exec/configure

radius-server host test

radius-server host test

[no] radius-server host { <hostipname> } test { { username <s0> { [password <s1> [idle-time <i1>]] | [idle-time <i1>] } } | { password <s1> [idle-time <i1>] } | { idle-time <i1> } }

Syntax Description

<i>username</i>	<s0>
no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
host	RADIUS server's DNS name or its IP address
<i>hostipname</i>	IPV4/IPV6 address or DNS name
test	Parameters to send test packets
<i>s0</i>	user name
password	(Optional) user password in test packets
<i>s1</i>	(Optional) user password
idle-time	(Optional) time interval for monitoring the server
<i>i1</i>	(Optional) time period in minutes

Command Mode

- /exec/configure

radius-server key 0 6 7

```
{ { [ no ] radius-server key { 0 <s0> | 6 <s6> | 7 <s1> | <s2> } } | { no radius-server key } }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
key	Global RADIUS server shared secret
0	default RADIUS shared secret(clear text)
s0	default RADIUS shared secret(clear text)
6	default RADIUS shared secret(type-6 encrypted)
s6	default RADIUS shared secret(type-6 encrypted)
7	default RADIUS shared secret(encrypted)
s1	default RADIUS shared secret(encrypted)
s2	default RADIUS shared secret(clear text)

Command Mode

- /exec/configure

radius-server pss-clean

radius-server pss-clean

[no] radius-server pss-clean

Syntax Description

no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
pss-clean	Erase PSS

Command Mode

- /exec/configure

radius-server retransmit

[no] radius-server retransmit <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
retransmit	Global RADIUS server retransmit count
<i>i0</i>	Global RADIUS server retransmit count

Command Mode

- /exec/configure

radius-server test

[no] radius-server test { { username <s0> { [password <s1> [idle-time <i1>]] | [idle-time <i1>] } } | { password <s1> [idle-time <i1>] } | { idle-time <i1> } }

Syntax Description

<i>username</i>	<s0>
no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
test	Parameters to send test packets
<i>s0</i>	user name
<i>password</i>	(Optional) user password in test packets
<i>s1</i>	(Optional) user password
<i>idle-time</i>	(Optional) time interval for monitoring the server
<i>i1</i>	(Optional) time period in minutes

Command Mode

- /exec/configure

radius-server timeout

[no] radius-server timeout <i0>

Syntax Description

no	(Optional) Negate a command or set its defaults
radius-server	Configure RADIUS related parameters
timeout	Global RADIUS server timeout period in seconds
<i>i0</i>	RADIUS server timeout period in seconds

Command Mode

- /exec/configure

random-detect

[no] random-detect [{ minimum-threshold <min-thresh> { packets | bytes | kbytes | mbytes } maximum-threshold <max-thresh> { packets1 | bytes1 | kbytes1 | mbytes1 } drop-probability <drop-prob> weight <weight> [cap-average] } | threshold { burst-optimized | mesh-optimized }] [ecn]

Syntax Description

no	(Optional) Negate a command or set its defaults
random-detect	Configure WRED parameters
threshold	(Optional) Threshold
burst-optimized	(Optional) Threshold optimized for bursty traffic
mesh-optimized	(Optional) Threshold optimized for mesh traffic
minimum-threshold	(Optional) Specify minimum threshold for WRED
maximum-threshold	(Optional) Specify maximum threshold for WRED
<i>min-thresh</i>	(Optional) Minimum threshold value
<i>max-thresh</i>	(Optional) Maximum threshold value
packets	(Optional) Packets
bytes	(Optional) Bytes
kbytes	(Optional) Kilo bytes
mbytes	(Optional) Mega bytes
packets1	(Optional) Packets
bytes1	(Optional) Bytes
kbytes1	(Optional) Kilo Bytes
mbytes1	(Optional) Mega Bytes
drop-probability	(Optional) Drop Probability at Maximum Threshold
<i>drop-prob</i>	(Optional) Drop Probability Value
weight	(Optional) Queue length weight
<i>weight</i>	(Optional) Queue length weight
cap-average	(Optional) If average queue length is more, replace average queue length with current queue length
ecn	(Optional) ECN

Command Mode

- /exec/configure/policy-map/type/queuing/class

random-detect2 minimum-threshold2 maximum-threshold2

random-detect2 minimum-threshold2 maximum-threshold2

[no] random-detect2 minimum-threshold2 <min-thresh2> { packets2 | bytes2 | kbytes2 | mbytes2 } maximum-threshold2 <max-thresh2> { packets3 | bytes3 | kbytes3 | mbytes3 } [drop-probability2 <drop-prob2> weight2 <weight2> [cap-average2]]

Syntax Description

no	(Optional) Negate a command or set its defaults
random-detect2	Configure WRED parameters
minimum-threshold2	Specify minimum threshold for WRED
maximum-threshold2	Specify maximum threshold for WRED
packets2	Packets
bytes2	Bytes
kbytes2	Kilo Bytes
mbytes2	Mega Bytes
packets3	Packets
bytes3	Bytes
kbytes3	Kilo Bytes
mbytes3	Mega Bytes
drop-probability2	(Optional) Drop Probability at Maximum Threshold
<i>drop-prob2</i>	(Optional) Drop Probability Value
weight2	(Optional) Queue length weight
<i>weight2</i>	(Optional) Queue length weight
cap-average2	(Optional) If average queue length is more, replace average queue length with current queue length

Command Mode

- /exec/configure/policy-map/type/queuing/class

random-detect

[no] random-detect { cos <cos-list> [minimum-threshold] { <min-thresh> [packets | bytes | kbytes | mbytes | ms | us] | percent <min-percent-of-qsize> } [maximum-threshold] { <max-thresh> [packets1 | bytes1 | kbytes1 | mbytes1 | ms1 | us1] | percent1 <max-percent-of-qsize> } }

Syntax Description

no	(Optional) Negate a command or set its defaults
random-detect	Configure WRED parameters
cos	Parameters for each cos value
<i>cos-list</i>	List of class-of-service values
minimum-threshold	(Optional) Specify minimum threshold for WRED
maximum-threshold	(Optional) Specify maximum threshold for WRED
<i>min-thresh</i>	Minimum threshold value
<i>max-thresh</i>	Maximum threshold value
percent	Specify thresholds in percent
percent1	Specify thresholds in percent
<i>min-percent-of-qsize</i>	Minimum threshold percent of queue size
<i>max-percent-of-qsize</i>	Maximum threshold percent of queue size
packets	(Optional) Packets
bytes	(Optional) Bytes
kbytes	(Optional) Kilo bytes
mbytes	(Optional) Mega bytes
ms	(Optional) Milli second(s)
us	(Optional) Micro second(s)
packets1	(Optional) Packets
bytes1	(Optional) Bytes
kbytes1	(Optional) Kilo Bytes
mbytes1	(Optional) Mega Bytes
ms1	(Optional) Milli second(s)
us1	(Optional) Micro second(s)

Command Mode

- /exec/configure/policy-map/type/queuing/class

random-detect cos-based

[no] random-detect cos-based [aggregate [minimum-threshold] { <min-thresh> [packets | bytes | kbytes | mbytes | ms | us] | percent <min-percent-of-qsize> } [maximum-threshold] { <max-thresh> [packets1 | bytes1 | kbytes1 | mbytes1 | ms1 | us1] | percent1 <max-percent-of-qsize> }]

Syntax Description

no	(Optional) Negate a command or set its defaults
random-detect	Configure WRED parameters
cos-based	Configure WRED parameters for cos-based mode
aggregate	(Optional) Configure WRED parameters to same value for all sub-classes
minimum-threshold	(Optional) Specify minimum threshold for WRED
maximum-threshold	(Optional) Specify maximum threshold for WRED
<i>min-thresh</i>	(Optional) Minimum threshold value
<i>max-thresh</i>	(Optional) Maximum threshold value
percent	(Optional) Specify thresholds in percent
percent1	(Optional) Specify thresholds in percent
<i>min-percent-of-qsize</i>	(Optional) Minimum threshold percent of queue size
<i>max-percent-of-qsize</i>	(Optional) Maximum threshold percent of queue size
packets	(Optional) Packets
bytes	(Optional) Bytes
kbytes	(Optional) Kilo bytes
mbytes	(Optional) Mega bytes
ms	(Optional) Milli second(s)
us	(Optional) Micro second(s)
packets1	(Optional) Packets
bytes1	(Optional) Bytes
kbytes1	(Optional) Kilo Bytes
mbytes1	(Optional) Mega Bytes
ms1	(Optional) Milli second(s)
us1	(Optional) Micro second(s)

random-detect cos-based

Command Mode

- /exec/configure/policy-map/type/queuing/class

rate-limit

rate-limit { auto | <rate_value> } | no rate-limit

Syntax Description

no	Negate a command or set its defaults
rate-limit	Set the Rate limit for SPAN packets
auto	Set the Rate limit using auto value
<i>rate_value</i>	Enter the percentage of the maximum rate for SPAN packets

Command Mode

- /exec/configure/monitor-local-src /exec/configure/config-monitor
/exec/configure/config-monitor-erspan-src

rate-limit cpu direction pps action log

rate-limit cpu direction pps action log

[no] rate-limit cpu direction { input | output | both } pps <pps-val> action log

Syntax Description

no	(Optional) Negate a command or set its defaults
rate-limit	set packet per second rate limit
cpu	Supervisor CPU limits
direction	input/output direction
input	set max input packet rate
output	set max output packet rate
both	set max input and output packet rate
pps	packet per second
<i>pps-val</i>	pps value
action	log action
log	write a syslog message if PPS hits rate-limit

Command Mode

- /exec/configure

rate-limit cpu direction pps action log

[no] rate-limit cpu direction { input | output | both } pps <pps-val> action log

Syntax Description

no	(Optional) Negate a command or set its defaults
rate-limit	set packet per second rate limit
cpu	Supervisor CPU limits
direction	input/output direction
input	set max input packet rate
output	set max output packet rate
both	set max input and output packet rate
pps	packet per second
<i>pps-val</i>	pps value
action	log action
log	write a syslog message if PPS hits rate-limit

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-eth-any /exec/configure/if-mgmt-config

rate-mode

[no] rate-mode { bandwidth-fairness module <module> | oversubscription-limit module1 <module> }

Syntax Description

no	(Optional) Negate a command or set its defaults
rate-mode	Configure rate mode oversubscription limit
bandwidth-fairness	configure rate mode bandwidth fairness
module	Configure rate mode bandwidth fairness for a module
<i>module</i>	Enter module number
oversubscription-limit	configure rate mode oversubscription limit
module1	Configure rate mode oversubscription limit for a module
<i>module</i>	Enter module number

Command Mode

- /exec/configure

rate-mode

rate-mode <ratemode> [force] | no rate-mode [<ratemode>] [force]

Syntax Description

no	Negate a command or set its defaults
rate-mode	Enter the rate mode
force	(Optional) This option will shutdown all ports in port-group momentarily
<i>ratemode</i>	Interface port speed

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

rd auto

rd auto

```
{ rd { auto | <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } } | { no rd [ { auto | <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] }
```

Syntax Description

no	Negate a command or set its defaults
rd	VPN Route Distinguisher
auto	Generate RD automatically
<i>ext-comm-rd-aa4nn2</i>	VPN route distinguisher in aa4:nn or ip:nn format
<i>ext-comm-rd-aa2nn4</i>	VPN route distinguisher in aa:nn format

Command Mode

- /exec/configure/vrf

rd auto

```
{ rd { auto | <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } } | { no rd [ { auto | <ext-comm-rd-aa2nn4> | <ext-comm-rd-aa4nn2> } ] }
```

Syntax Description

no	Negate a command or set its defaults
rd	VPN Route Distinguisher
auto	Generate RD automatically
<i>ext-comm-rd-aa2nn4</i>	VPN route distinguisher in aa:nn format
<i>ext-comm-rd-aa4nn2</i>	VPN route distinguisher in aa4:nn or ip:nn format

Command Mode

- /exec/configure/evpn/evi

reconnect-interval

reconnect-interval <interval> | no reconnect-interval [<interval>]

Syntax Description

no	Negate a command or set its defaults
reconnect-interval	Configure connection reconnect interval
<i>interval</i>	Interval in seconds

Command Mode

- /exec/configure/router-bgp/vrf-cmds

record-route

[no] record-route

Syntax Description

no	(Optional) Negate a command or set its defaults
record-route	Record the route used by the LSP

Command Mode

- /exec/configure/te/lsp-attr

record-route

[no] record-route

Syntax Description

no	(Optional) Negate a command or set its defaults
record-route	record the route used by the tunnel

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

record

[no] record <recordname>

Syntax Description

record	Specify Flow Record to use
<i>recordname</i>	Name of record

Command Mode

- /exec/configure/nfm-monitor

record netflow-original

[no] record netflow-original

Syntax Description

record	Specify Flow Record to use
netflow-original	Traditional IPv4 input NetFlow with origin ASs

Command Mode

- /exec/configure/nfm-monitor

record netflow

[no] record netflow { ipv4 { original-input | original-output } }

Syntax Description

record	Specify Flow Record to use
netflow	Traditional NetFlow collection schemes
ipv4	Traditional IPv4 NetFlow collection schemes
original-input	Traditional IPv4 input NetFlow
original-output	Traditional IPv4 output NetFlow

Command Mode

- /exec/configure/nfm-monitor

record netflow

record netflow

[no] record netflow { ipv6 { original-input | original-output } }

Syntax Description

record	Specify Flow Record to use
netflow	Traditional NetFlow collection schemes
ipv6	IPv6 collection schemes
original-input	Input NetFlow
original-output	Output NetFlow

Command Mode

- /exec/configure/nfm-monitor

record netflow

[no] record netflow { layer2-switched { input } }

Syntax Description

record	Specify Flow Record to use
netflow	Traditional NetFlow collection schemes
layer2-switched	Traditional L2 NetFlow collection schemes
input	Input NetFlow

Command Mode

- /exec/configure/nfm-monitor

record netflow protocol-port

record netflow protocol-port

[no] record netflow protocol-port

Syntax Description

record	Specify Flow Record to use
netflow	Traditional NetFlow collection schemes
protocol-port	Protocol and Ports aggregation scheme

Command Mode

- /exec/configure/nfm-monitor

redistribute bgp

```
{ redistribute { { bgp <as>} | { eigrp | isis | ospfv3 | rip } <tag> | static | direct | amt | lisp } route-map { <policy-name> | <rtr_pol_name> } } | { no redistribute { { bgp <as>} | { eigrp | isis | ospfv3 | rip } <tag> | static | direct | amt | lisp } [ route-map { <policy-name> | <rtr_pol_name> } ] }
```

Syntax Description

no	Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
bgp	Border Gateway Protocol (BGP)
as	Autonomous system number
eigrp	Enhanced Interior Gateway Protocol (EIGRP)
isis	ISO Intermediate-to-Intermediate (IS-IS)
ospfv3	Open Shortest Path First (OSPFv3)
rip	Routing Information Protocol (RIP)
tag	Process Tag
static	Static
direct	Directly connected
amt	AMT anycast prefix
lisp	LISP EID-prefixes
route-map	Policy to constrain redistribution
<i>policy-name</i>	Route-map name
<i>rtr_pol_name</i>	An existing routing-rules policy

Command Mode

- /exec/configure/router-ospf3/router-ospf3-af-ipv6 /exec/configure/router-ospf3/vrf/router-ospf3-af-ipv6

```
■ redistribute bgp eigrp isis ospf rip static direct amt lisp route-map
```

redistribute bgp eigrp isis ospf rip static direct amt lisp route-map

{ redistribute { bgp <as> | { eigrp | isis | ospf | rip } <tag> | static | direct | amt | lisp } route-map { <policy-name> | <rtr_pol_name> } } | { no redistribute { bgp <as> | { eigrp | isis | ospf | rip } <tag> | static | direct | amt | lisp } [route-map { <policy-name> | <rtr_pol_name> }] }

Syntax Description

no	Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
bgp	Border Gateway Protocol (BGP)
as	Autonomous system number
isis	ISO Intermediate-to-Intermediate (IS-IS)
ospf	Open Shortest Path First (OSPFv2)
eigrp	Enhanced Interior Gateway Protocol (EIGRP)
rip	Routing Information Protocol (RIP)
tag	Protocol Tag
static	Static
direct	Directly connected
amt	AMT anycast prefix
lisp	LISP EID-prefixes
route-map	Policy to constrain redistribution
policy-name	Route-map name
rtr_pol_name	An existing routing-rules policy

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

redistribute filter route-map

[no] redistribute filter route-map { <map-name> | <rtr_pol_name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
filter	Filter redistributed routes
route-map	Route-map to constrain redistribution
<i>map-name</i>	A 'routing-rules' route-map name
<i>rtr_pol_name</i>	An existing routing-rules policy

Command Mode

- /exec/configure/otv-isis/otv-isis-vrf-common

redistribute filter route-map

[no] redistribute filter route-map { <map-name> | <rtr_pol_name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
filter	Filter redistributed routes
route-map	Route-map to constrain redistribution
<i>map-name</i>	A 'routing-rules' route-map name
<i>rtr_pol_name</i>	An existing routing-rules policy

Command Mode

- /exec/configure/l2mp-isis/l2mp-isis-vrf-common

redistribute maximum-prefix

```
{ redistribute maximum-prefix <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] } | { no redistribute maximum-prefix <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] }
```

Syntax Description

no	Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
maximum-prefix	Maximum number of prefixes redistributed to protocol
<i>maximum</i>	Maximum number of IP prefixes redistributed
<i>threshold</i>	(Optional) Threshold value (%) at which to generate a warning message
<i>warning-only</i>	(Optional) Log a warning message when limit is exceeded
<i>withdraw</i>	(Optional) Withdraw all redistributed routes
<i>retries</i>	(Optional) Number of times to retry to get the redistributed routes again
<i>timeout</i>	(Optional) Timeout between each retries

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

redistribute maximum-prefix

```
redistribute maximum-prefix <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] | no redistribute maximum-prefix [ <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] ]
```

Syntax Description

no	Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
maximum-prefix	Max number of prefixes redistributed
<i>maximum</i>	max number
<i>threshold</i>	(Optional) Threshold in %, at which message is generated
warning-only	(Optional) Warning msg is logged when max is reached
withdraw	(Optional) Withdraw all redistributed routes
<i>retries</i>	(Optional) No of times to retry to get redist routes again
<i>timeout</i>	(Optional) Time between the retries

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common /exec/configure/router-isis/router-isis-af-ipv4

redistribute maximum-prefix

```
redistribute maximum-prefix <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] | no redistribute maximum-prefix [ <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] ]
```

Syntax Description

no	Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
maximum-prefix	Max number of prefixes redistributed
<i>maximum</i>	max number
<i>threshold</i>	(Optional) Threshold in %, at which message is generated
warning-only	(Optional) Warning msg is logged when max is reached
withdraw	(Optional) Withdraw all redistributed routes
<i>retries</i>	(Optional) No of times to retry to get redist routes again
<i>timeout</i>	(Optional) Time between the retries

Command Mode

- /exec/configure/router-isis/router-isis-af-ipv6

redistribute maximum-prefix

redistribute maximum-prefix

```
{ redistribute maximum-prefix <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] } | { no redistribute maximum-prefix }
```

Syntax Description

no	Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
maximum-prefix	Maximum number of prefixes redistributed to protocol
<i>maximum</i>	Maximum number of IP prefixes redistributed
<i>threshold</i>	(Optional) Threshold value (%) at which to generate a warning message
<i>warning-only</i>	(Optional) Log a warning message when limit is exceeded
<i>withdraw</i>	(Optional) Withdraw all redistributed routes
<i>retries</i>	(Optional) Number of times to retry to get the redistributed routes again
<i>timeout</i>	(Optional) Timeout between each retries

Command Mode

- /exec/configure/router-ospf3/router-ospf3-af-ipv6 /exec/configure/router-ospf3/vrf/router-ospf3-af-ipv6

redistribute maximum-prefix

```
redistribute maximum-prefix <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] | no redistribute maximum-prefix [ <maximum> [ <threshold> ] [ warning-only | withdraw [ <retries> <timeout> ] ] ]
```

Syntax Description

no	Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
maximum-prefix	Max number of prefixes redistributed
<i>maximum</i>	max number
<i>threshold</i>	(Optional) Threshold in %, at which message is generated
warning-only	(Optional) Warning msg is logged when threshold is reached
withdraw	(Optional) Withdraw all redistributed routes
<i>retries</i>	(Optional) Number of attempts to receive redistributed routes after max is reached
<i>timeout</i>	(Optional) Retry interval

Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

redistribute route-map

redistribute route-map

[no] redistribute { bgp <as> | { eigrp | isis | ospfv3 | rip } <tag> | static | direct | amt | lisp } route-map <map-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	RIP redistribute routes from other routing protocol
bgp	Border Gateway Protocol (BGP)
as	Autonomous system number
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
isis	Intermediate-to-intermediate (ISIS)
rip	Routing Information Protocol (RIP)
ospfv3	Open Shortest Path First (OSPFv3)
tag	Process tag
static	Static routes
direct	Directly connected routes
amt	AMT anycast prefix
lisp	LISP EID-prefixes
route-map	Policy to constrain redistribution
map-name	Route-map name

Command Mode

- /exec/configure/router-rip/router-rip-af-ipv6 /exec/configure/router-rip/router-rip-vrf-af-ipv6

redistribute route-map

[no] redistribute { bgp <as> | { eigrp | isis | ospf | rip } <tag> | static | direct | amt | lisp } route-map <map-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	RIP redistribute routes from other routing protocol
bgp	Border Gateway Protocol (BGP)
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
<i>as</i>	Autonomous system number
isis	Intermediate-to-intermediate (ISIS)
rip	Routing Information Protocol (RIP)
ospf	Open Shortest Path First (OSPFv2)
<i>tag</i>	Process tag
static	Static routes
direct	Directly connected routes
amt	AMT anycast prefix
lisp	LISP EID-prefixes
route-map	Policy to constrain redistribution
<i>map-name</i>	Route-map name

Command Mode

- /exec/configure/router-rip/router-rip-af-ipv4 /exec/configure/router-rip/router-rip-vrf-af-ipv4

redistribute route-map

redistribute route-map

[no] redistribute { { { eigrp | isis | ospf | rip } <tag> } | amt | lisp | hmm } route-map <rmap-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Configure redistribution
isis	ISO IS-IS
ospf	Open Shortest Path First (OSPF)
rip	Routing Information Protocol (RIP)
eigrp	Enhanced Interior Gateway Protocol
amt	AMT anycast prefix
lisp	LISP EID-prefixes in the non-default VRF
hmm	HMM prefix
route-map	Route-map applied to redistributed routes
<i>rmap-name</i>	Route-map name
tag	Source protocol tag

Command Mode

- /exec/configure/router-bgp/router-bgp-af-ipv4 /exec/configure/router-bgp/router-bgp-vrf-af-ipv4

redistribute route-map

[no] redistribute { { { eigrp | isis | ospfv3 | rip } <tag> } | amt | lisp | hmm } route-map <rmap-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Configure redistribution
isis	ISO IS-IS
ospfv3	Open Shortest Path First, version 3 (OSPFv3)
rip	Routing Information Protocol (RIP)
eigrp	Enhanced Interior Gateway Protocol
amt	AMT anycast prefix
lisp	LISP EID-prefixes in the non-default VRF
hmm	HMM prefix
route-map	Route-map applied to redistributed routes
<i>rmap-name</i>	Route-map name
<i>tag</i>	Source protocol tag

Command Mode

- /exec/configure/router-bgp/router-bgp-af-ipv6 /exec/configure/router-bgp/router-bgp-vrf-af-ipv6

redistribute route-map

redistribute route-map

[no] redistribute { bgp <as> | { eigrp | isis | ospf | rip } <tag> | static | direct | amt | lisp } route-map { <map-name> | <rtr_pol_name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
bgp	Border Gateway Protocol (BGP)
as	Autonomous system number
isis	IS-IS Routing for IPv4
ospf	Open Shortest Path First (OSPF)
eigrp	Enhanced Interior Gateway Protocol
rip	RIP for IPv4
tag	Process tag
static	Static routes
direct	Directly connected
amt	AMT anycast prefix
lisp	LISP EID-prefixes
route-map	Route-map to constrain redistribution
map-name	A 'routing-rules' route-map name
rtr_pol_name	An existing routing-rules policy

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common /exec/configure/router-isis/router-isis-af-ipv4

redistribute route-map

[no] redistribute { bgp <as> | { eigrp | isis | ospfv3 | rip } <tag> | static | direct | amt | lisp } route-map { <map-name> | <rtr_pol_name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
bgp	Border Gateway Protocol (BGP)
as	Autonomous system number
isis	IS-IS Routing for IPv6
ospfv3	Open Shortest Path First (OSPF) V3
eigrp	Enhanced Interior Gateway Protocol
rip	RIP for IPv6 (RIPNG)
tag	Process tag
static	Static routes
direct	Directly connected
amt	AMT anycast prefix
lisp	LISP EID-prefixes
route-map	Route-map to constrain redistribution
map-name	A 'routing-rules' route-map name
rtr_pol_name	An existing routing-rules policy

Command Mode

- /exec/configure/router-isis/router-isis-af-ipv6

redistribute route-map

redistribute route-map

[no] redistribute { bgp <as> | { eigrp | isis | ospf | rip } <tag> | static | direct | amt | lisp } route-map { <map-name> | <rtr_pol_name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
bgp	Border Gateway Protocol (BGP)
as	Autonomous system number
isis	IS-IS Routing for IPv4
ospf	Open Shortest Path First (OSPF)
rip	Routing Information Protocol (RIP)
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
tag	Process tag
static	Static routes
direct	Directly connected
lisp	LISP EID-prefixes
amt	AMT Anycast prefix
route-map	Route-map to constrain redistribution
map-name	Route-map name
rtr_pol_name	An existing routing-rules policy

Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-ipv4

redistribute route-map

[no] redistribute { bgp <as> | { eigrp | isis | ospfv3 | rip } <tag> | static | direct | amt | lisp } route-map { <map-name> | <rtr_pol_name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Redistribute information from another routing protocol
bgp	Border Gateway Protocol (BGP)
as	Autonomous system number
isis	IS-IS Routing for IPv4
ospfv3	Open Shortest Path First (OSPF) V3
rip	Routing Information Protocol (RIP)
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
tag	Process tag
static	Static routes
direct	Directly connected
amt	AMT Anycast prefix
lisp	LISP EID-prefixes
route-map	Route-map to constrain redistribution
map-name	Route-map name
rtr_pol_name	An existing routing-rules policy

Command Mode

- /exec/configure/router-eigrp/router-eigrp-af-ipv6

redistribute static route-map

redistribute static route-map

[no] redistribute { static | direct } route-map <rmap-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Configure redistribution
static	Static routes
direct	Directly connected
route-map	Route-map applied to redistributed routes
<i>rmap-name</i>	Route-map name

Command Mode

- /exec/configure/router-bgp/router-bgp-af-ipv4 /exec/configure/router-bgp/router-bgp-vrf-af-ipv4

redistribute static route-map

[no] redistribute { static | direct } route-map <rmap-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
redistribute	Configure redistribution
static	Static routes
direct	Directly connected
route-map	Route-map applied to redistributed routes
<i>rmap-name</i>	Route-map name

Command Mode

- /exec/configure/router-bgp/router-bgp-af-ipv6 /exec/configure/router-bgp/router-bgp-vrf-af-ipv6

redundancy-group

redundancy-group

[no] redundancy-group

Syntax Description

no	(Optional) Negate a command or set its defaults
redundancy-group	Configure a redundancy-group node

Command Mode

- /exec/configure/if-nve

reference-bandwidth

[no] reference-bandwidth { <ref-bw-mbps> [Mbps] | <ref-bw-gbps> Gbps }

Syntax Description

no	(Optional) Negate a command or set its defaults
reference-bandwidth	Change reference bandwidth used for setting interface metric
<i>ref-bw-mbps</i>	Bandwidth in Mbps (Default)
Mbps	(Optional) Specify in Mbps
<i>ref-bw-gbps</i>	Bandwidth in Gbps
Gbps	Specify in Gbps

Command Mode

- /exec/configure/l2mp-isis/l2mp-isis-vrf-common /exec/configure/l2mp-isis/l2mp-isis-l2-topo

reference-bandwidth

[no] reference-bandwidth { <ref-bw-mbps> [Mbps] | <ref-bw-gbps> Gbps }

Syntax Description

no	(Optional) Negate a command or set its defaults
reference-bandwidth	Change reference bandwidth used for setting interface metric
<i>ref-bw-mbps</i>	Bandwidth in Mbps (Default)
Mbps	(Optional) Specify in Mbps
<i>ref-bw-gbps</i>	Bandwidth in Gbps
Gbps	Specify in Gbps

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

register-database-mapping

{ [no] register-database-mapping }

Syntax Description

no	(Optional) Negate a command or set its defaults
register-database-mapping	Register database-mapping EID-prefix to Map-Server

Command Mode

- /exec/configure/lisp-dynamic-eid /exec/configure/vrf/lisp-dynamic-eid

register-route-notifications

{ [no] register-route-notifications }

Syntax Description

no	(Optional) Negate a command or set its defaults
register-route-notifications	Register more-specific routes of the database-mapping EID-prefix to Map-Server

Command Mode

- /exec/configure/lisp-dynamic-eid /exec/configure/vrf/lisp-dynamic-eid

reload

reload

Syntax Description

reload	reboot the entire box
--------	-----------------------

Command Mode

- /exec

reload ascii

reload ascii

```
reload ascii [ vdc-all ]
```

Syntax Description

reload	Power cycle
ascii	Reload with ASCII startup-configuration
vdc-all	(Optional) Perform for all vdcs

Command Mode

- /exec

reload fex

```
reload fex { all | <i> }
```

Syntax Description

reload	reboot the entire box
fex	Reload Fex
all	Reload all Fex Modules
<i>i</i>	Enter FEX identifier

Command Mode

- /exec

reload force

reload force

reload force

Syntax Description

reload	reboot the entire box
force	reload without prompting

Command Mode

- /exec

reload kexec

reload kexec

Syntax Description

reload	reboot the entire box
kexec	reboot using kexec

Command Mode

- /exec

reload kexec

reload kexec

reload kexec <s0> <s1>

Syntax Description

reload	reboot the entire box
kexec	reboot using kexec
<i>s0</i>	please enter the boot image name
<i>s1</i>	please enter the isan image name

Command Mode

- /exec

reload module

reload module <module>

Syntax Description

reload	reboot the entire box
module	reboot a specific module
<i>module</i>	please enter the module number

Command Mode

- /exec

reload module force-dnld

reload module <module> force-dnld

Syntax Description

reload	reboot the entire box
module	reboot a specific module
<i>module</i>	please enter the module number
force-dnld	reboot a specific module to force NetBoot and image download

Command Mode

- /exec

reload module hard

reload module <module> hard

Syntax Description

reload	reboot the entire box
module	reboot a specific module
<i>module</i>	please enter the module number
hard	hard reboot a specific module

Command Mode

- /exec

reload non-interruptive

reload non-interruptive

reload non-interruptive

Syntax Description

reload	reboot the entire box
non-interruptive	Reboot without interruption

Command Mode

- /exec

reload power-cycle

reload power-cycle

Syntax Description

reload	reboot the entire box
power-cycle	Power cycle ADM

Command Mode

- /exec

reload restore

reload restore

```
reload restore [ delay <time-out> ] | no reload restore
```

Syntax Description

no	Negate a command or set its defaults
reload	Settings for vpc action on reload with vpc configs
restore	restore vpcs assuming peer is not functional
delay	(Optional) Duration to wait before assuming peer dead and restoring vpcs
<i>time-out</i>	(Optional) Time-out for restoring vPC links (in seconds)

Command Mode

- /exec/configure/vpc-domain

reload sync-adjacency

reload sync-adjacency

Syntax Description

reload	reboot the entire box
sync-adjacency	Reload with sync adjacency

Command Mode

- /exec

reload sync-adjacency

reload sync-adjacency

reload sync-adjacency

Syntax Description

reload	reload with sync adjacency
sync-adjacency	Reload with ARP/ND sync adjacency

Command Mode

- /exec

reload vdc

reload vdc <d-vdc>

Syntax Description

vdc	Restart the current vdc
reload	Power cycle
<i>d-vdc</i>	Enter Virtual Device Context <vdc-id>

Command Mode

- /exec

reload vdc

reload vdc

reload vdc

Syntax Description

vdc	Restart the current vdc
reload	Power cycle

Command Mode

- /exec

remark

```
{ [ <seqno> ] | no } remark <comment>
```

Syntax Description

no	Negate a command or set its defaults
<i>seqno</i>	(Optional) Sequence number
remark	Access list entry comment
<i>comment</i>	Comment, up to 100 characters

Command Mode

- /exec/configure/ipacl /exec/configure/ipv6acl /exec/configure/macacl /exec/configure/arpacl
/exec/configure/timerange

remote-as

{ remote-as <asn> } | { { no | default } remote-as [<asn>] }

Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
remote-as	Specify Autonomous System Number of the neighbor
<i>asn</i>	Autonomous System Number

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor-sess

remote-span

[no] remote-span

Syntax Description

no	(Optional) Negate a command or set its defaults
remote-span	Enable remote span VLAN

Command Mode

- /exec/configure/vlan

remote

```
remote { { ip address { <ipaddress> } | hostname <host_name> } [ port <port_no> ] [ vrf { <vrf-name> | <vrf-known-name> } ] | port <port_no> | vrf { <vrf-name> | <vrf-known-name> } } | no remote { ip address | hostname | port }
```

Syntax Description

no	Negate a command or set its defaults
remote	Configure remote machine information
ip	Configure IP features
address	Configure IP address
<i>ipaddress</i>	Enter ipv4 address information
hostname	Configure remote host name
<i>host_name</i>	Enter name of the remote host
port	(Optional) Configure remote host tcp port
<i>port_no</i>	(Optional) Configure the host tcp port number
vrf	(Optional) vrf via which the vCenter Server is reachable
<i>vrf-name</i>	(Optional) Specify the vrf-name
<i>vrf-known-name</i>	(Optional) Known VRF name

Command Mode

- /exec/configure/vmt-conn

remove-private-as

[no | default] remove-private-as [all | replace-as]

Syntax Description

no	(Optional) Negate a command or set its defaults
default	(Optional) Inherit values from a peer template
remove-private-as	Remove private AS number from outbound updates
all	(Optional) All
replace-as	(Optional) Replace

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor-sess

remove-routes vni

remove-routes vni

remove-routes vni <vni-id>

Syntax Description

remove-routes	NVE Peer
vni	Virtual Network Identifier
<i>vni-id</i>	VNI

Command Mode

- /exec/configure/if-nve

reoptimize events link-up

[no] reoptimize events link-up | no reoptimize timers { delay { cleanup | installation } | frequency } | reoptimize timers { delay { cleanup <clean_sec> | installation <inst_sec> } | frequency <freq_sec> }

Syntax Description

no	(Optional) Negate a command or set its defaults
reoptimize	Reoptimization parameters
events	Reoptimization triggers
link-up	Reoptimize tunnels on link up events
timers	Reoptimization timers
delay	Delay reoptimization action
cleanup	Delay cleanup of reoptimized LSP
<i>clean_sec</i>	seconds to delay cleanup of replaced tunnel LSP
installation	Delay replacement of current LSP by reoptimized LSP
<i>inst_sec</i>	seconds to delay replacement of tunnel LSP
frequency	Interval between reoptimization scans
<i>freq_sec</i>	seconds between reoptimizations (0 disables reoptimization)

Command Mode

- /exec/configure/te

replay-protection

[no] replay-protection

Syntax Description

replay-protection	Enable replay-protection (the default use the no form to disable)
-------------------	---

Command Mode

- /exec/configure/cts-dot1x /exec/configure/cts-manual

replication-server

[no] replication-server <addr>

Syntax Description

no	(Optional) Negate a command or set its defaults
replication-server	Configure a replication server
<i>addr</i>	Replication Server IP Address

Command Mode

- /exec/configure/if-nve

report

report

Syntax Description

report	Show trigger report
--------	---------------------

Command Mode

- /exec/elamns/sel3

report

report

Syntax Description

report	Show trigger report
--------	---------------------

Command Mode

- /exec/elamnssel4

report

report

Syntax Description

report	Show trigger report
--------	---------------------

Command Mode

- /exec/elamns/sel5

report

report

Syntax Description

report	Show trigger report
--------	---------------------

Command Mode

- /exec/elamns/sel6

report

report

Syntax Description

report	Show trigger report
--------	---------------------

Command Mode

- /exec/elamns/se17

report

report

Syntax Description

report	Show trigger report
--------	---------------------

Command Mode

- /exec/elamns/outsel0

report

report

Syntax Description

report	Show trigger report
--------	---------------------

Command Mode

- /exec/elamns/outsel5

request-data-size

```
{ { no | default } request-data-size | request-data-size <bytes-in-payload> }
```

Syntax Description

no	
default	Set a command to its defaults
request-data-size	Request data size
<i>bytes-in-payload</i>	Number of bytes in payload

Command Mode

- /exec/configure/ip-sla/udp

request-data-size

```
{ { no | default } request-data-size | request-data-size <bytes-in-payload> }
```

Syntax Description

no	
default	Set a command to its defaults
request-data-size	Request data size
<i>bytes-in-payload</i>	Number of bytes in payload

Command Mode

- /exec/configure/ip-sla/icmpEcho

request-data-size

```
{ { no | default } request-data-size | request-data-size <bytes-in-payload> }
```

Syntax Description

no	
default	Set a command to its defaults
request-data-size	Request data size
<i>bytes-in-payload</i>	Number of bytes in payload

Command Mode

- /exec/configure/ip-sla/jitter

resequence access

resequence { {<ip_ipv6_mac_arp>} access-list } | time-range } <name> <number> <increment>

Syntax Description

resequence	Resequence a list with sequence numbers
<i>ip_ipv6_mac_arp</i>	IP/IPv6/MAC/ARP
access-list	Resequence an access list
time-range	Resequence a time-range
<i>name</i>	List name
<i>number</i>	Starting sequence number
<i>increment</i>	Step to increment the sequence number

Command Mode

- /exec/configure

reset

reset

Syntax Description

reset	Reset Trigger conditions
-------	--------------------------

Command Mode

- /exec/elamns/sel3

reset

Syntax Description

reset	Reset Trigger conditions
-------	--------------------------

Command Mode

- /exec/elamns/sel4

reset

reset

Syntax Description

reset	Reset Trigger conditions
-------	--------------------------

Command Mode

- /exec/elamns/sel5

reset

Syntax Description

reset	Reset Trigger conditions
-------	--------------------------

Command Mode

- /exec/elamns/sel6

reset

reset

Syntax Description

reset	Reset Trigger conditions
-------	--------------------------

Command Mode

- /exec/elamns/sel7

reset

Syntax Description

reset	Reset Trigger conditions
-------	--------------------------

Command Mode

- /exec/elamns/outsel0

reset

reset

Syntax Description

reset	Reset Trigger conditions
-------	--------------------------

Command Mode

- /exec/elamns/outsel5

restart amt

restart amt

Syntax Description

restart	Manually restart a component
amt	Restart the AMT multicast routing protocol

Command Mode

- /exec

restart bgp

restart bgp <as>

Syntax Description

restart	Manually restart a component
bgp	Border Gateway Protocol (BGP)
<i>as</i>	Autonomous

Command Mode

- /exec

restart eigrp

restart eigrp

```
restart eigrp <eigrp-ptag>
```

Syntax Description

restart	Manually restart a component
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
<i>eigrp-ptag</i>	Process tag

Command Mode

- /exec

restart fabricpath domain

restart fabricpath domain

Syntax Description

restart	Manually restart a component
fabricpath	Data Center Intermediate System to Intermediate System (L2MP-IS-IS)
domain	Fabricpath IS-IS domain

Command Mode

- /exec

restart igmp**restart igmp****Syntax Description**

restart	Manually restart a component
igmp	Restart the IGMP multicast routing protocol

Command Mode

- /exec

restart isis

restart isis <tag>

Syntax Description

restart	Manually restart a component
isis	Intermediate System to Intermediate System (IS-IS)
<i>tag</i>	Routing process tag

Command Mode

- /exec

restart l3vm

restart l3vm

Syntax Description

restart	Manually restart a component
l3vm	Display VRF information

Command Mode

- /exec

restart lisp

restart lisp

Syntax Description

restart	Manually restart a component
lisp	Restart the LISP Locator/ID Separation Protocol

Command Mode

- /exec

restart msdp

restart msdp

```
restart msdp
```

Syntax Description

restart	Manually restart a component
msdp	Restart the MSDP multicast routing protocol

Command Mode

- /exec

restart orib

restart orib

Syntax Description

restart	Manually restart a component
orib	OTV RIB (ORIB)

Command Mode

- /exec

restart ospf

restart ospf

restart ospf <tag>

Syntax Description

restart	Manually restart a component
ospf	Open Shortest Path First (OSPF)
<i>tag</i>	Process tag

Command Mode

- /exec

restart ospfv3

restart ospfv3 <tag>

Syntax Description

restart	Manually restart a component
ospfv3	Open Shortest Path First (OSPF) (Version 3)
<i>tag</i>	Process tag

Command Mode

- /exec

restart otv-isis**restart otv-isis <tag>****Syntax Description**

restart	Manually restart a component
otv-isis	Intermediate System to Intermediate System (IS-IS)
<i>tag</i>	Routing process tag

Command Mode

- /exec

restart otv

restart otv

Syntax Description

restart	Manually restart a component
otv	Overlay Transport Virtualization (OTV)

Command Mode

- /exec

restart pim

restart pim

Syntax Description

restart	Manually restart a component
pim	Restart the PIM multicast routing protocol

Command Mode

- /exec

restart pim6

restart pim6

Syntax Description

restart	Manually restart a component
pim6	Restart the PIM6 multicast routing protocol

Command Mode

- /exec

restart pim stateless

restart pim stateless

restart pim stateless

Syntax Description

restart	Manually restart a component
pim	Restart the PIM multicast routing protocol
stateless	Restart PIM in stateless mode

Command Mode

- /exec

restart rip

restart rip <tag>

Syntax Description

restart	Manually restart a component
rip	Routing Information Protocol (RIP)
<i>tag</i>	Process ID

Command Mode

- /exec

restart rpm

restart rpm

restart rpm

Syntax Description

restart	Manually restart a component
rpm	Route Policy Manager (RPM)

Command Mode

- /exec

restart rsvp

restart rsvp

Syntax Description

restart	Manually restart a process
rsvp	RSVP process

Command Mode

- /exec

resync-database

resync-database

Syntax Description

resync-database	Re-synchronize switch-profile database
-----------------	--

Command Mode

- /exec/configure

retain route-target all

[no] retain route-target { all | route-map <rmap-name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
retain	Retain the routes based on Target VPN Extended Communities
route-target	Specify Target VPN Extended Communities
all	All the routes regardless of Target-VPN community
route-map	Apply route-map to filter routes
<i>rmap-name</i>	Route-map name

Command Mode

- /exec/configure/router-bgp/router-bgp-af-vpnv4 /exec/configure/router-bgp/router-bgp-af-vpnv6
/exec/configure/router-bgp/router-bgp-af-link-state /exec/configure/router-bgp/router-bgp-af-l2vpn-vpls
/exec/configure/router-bgp/router-bgp-af-l2vpn-evpn

retransmit-interval

retransmit-interval

{ { retransmit-interval <interval> } | { no retransmit-interval [<interval>] } }

Syntax Description

no	Negate a command or set its defaults
retransmit-interval	Packet retransmission interval
<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf/router-ospf-vlink /exec/configure/router-ospf/vrf/router-ospf-vlink

retransmit-interval

{ { retransmit-interval <interval> } | { no retransmit-interval [<interval>] } }

Syntax Description

no	Negate a command or set its defaults
retransmit-interval	Packet retransmission interval
<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf/vrf/router-ospf-slink

retransmit-interval

retransmit-interval

{ { retransmit-interval <interval> } | { no retransmit-interval [<interval>] } }

Syntax Description

no	Negate a command or set its defaults
retransmit-interval	Packet retransmission interval
<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf3/router-ospf3-vlink /exec/configure/router-ospf3/vrf/router-ospf3-vlink

revision

revision <rev-id> | no revision [<rev-id>]

Syntax Description

no	Negate a command or set its defaults
revision	Set configuration revision number
<i>rev-id</i>	Configuration revision number

Command Mode

- /exec/configure/spanning-tree/mst/configuration

revocation-check crl

revocation-check crl

[no] revocation-check { crl [none] | none }

Syntax Description

no	(Optional) Negate a command or set its defaults
revocation-check	Configure trustpoint revocation check methods
crl	Configure revocation check using crl
none	(Optional) Configure revocation check using none
none	Configure revocation check using none

Command Mode

- /exec/configure/trustpoint

rfc1583compatibility

[no] rfc1583compatibility

Syntax Description

no	(Optional) Negate a command or set its defaults
rfc1583compatibility	Configure 1583 compatibility for external path preferences

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

rip shutdown

[no] rip shutdown

Syntax Description

no	(Optional) Negate a command or set its defaults
rip	RIP configuration commands
shutdown	Shutdown RIP on this interface

Command Mode

- /exec/configure/if-igp

rmdir

```
rmdir { <uri0> | <uri1> }
```

Syntax Description

rmdir	Delete a directory
<i>uri0</i>	Delete a directory
<i>uri1</i>	Delete a directory on expansion flash

Command Mode

- /exec

rmon alarm absolute rising-threshold falling-threshold

rmon alarm <i0> <s0> <i1> { absolute | delta } rising-threshold <i2> [<i3>] falling-threshold <i4> [<i5>] [owner <s1>] | no rmon alarm <i0>

Syntax Description

no	Negate a command or set its defaults
rmon	Remote Monitoring
alarm	Configure an RMON alarm
<i>i0</i>	Alarm number
<i>s0</i>	MIB object to monitor
<i>i1</i>	Sample interval
absolute	Test each sample directly
delta	Test delta between samples
rising-threshold	Configure the rising threshold
<i>i2</i>	Rising threshold value
<i>i3</i>	(Optional) Event to fire on rising threshold crossing
falling-threshold	Configure the falling threshold
<i>i4</i>	Falling threshold value
<i>i5</i>	(Optional) Event to fire on falling threshold crossing
owner	(Optional) Specify an owner for the alarm
<i>s1</i>	(Optional) Alarm owner

Command Mode

- /exec/configure

rmon event

rmon event <i0> [log] [trap <s0>] [description <s1>] [owner <s2>] | no rmon event <i0>

Syntax Description

no	Negate a command or set its defaults
rmon	Remote Monitoring
event	Configure an RMON event
<i>i0</i>	Event number
log	(Optional) Generate RMON log when the event fires
trap	(Optional) Generate SNMP trap when event fires
<i>s0</i>	(Optional) SNMP community string
description	(Optional) Specify a description of the event
<i>s1</i>	(Optional) Event description
owner	(Optional) Specify an owner for the event
<i>s2</i>	(Optional) Event owner

Command Mode

- /exec/configure

```
rmon hcalarm absolute startupalarm rising-threshold falling-threshold owner
```

rmon hcalarm absolute startupalarm rising-threshold falling-threshold owner

```
rmon hcalarm <i0> <s0> <i1> { absolute | delta } startupalarm <i2> rising-threshold <i3> <i4> falling-threshold <i5> <i6> owner <s1> | no rmon hcalarm <i0>
```

Syntax Description

no	Negate a command or set its defaults
rmon	Remote Monitoring
hcalarm	Configure an High Capacity RMON alarm
<i>i0</i>	Alarm number
<i>s0</i>	MIB object to monitor
<i>i1</i>	Sample interval
absolute	Test each sample directly
delta	Test delta between samples
startupalarm	Configure alarm type
<i>i2</i>	Startup alarm type, rising(1) falling(2) risingorfalling(3)
rising-threshold	Configure the rising threshold
<i>i3</i>	Rising threshold value in bytes
<i>i4</i>	Event to fire on rising threshold crossing
falling-threshold	Configure the falling threshold
<i>i5</i>	Falling threshold value in bytes
<i>i6</i>	Event to fire on falling threshold crossing
owner	Specify an owner for the alarm
<i>s1</i>	Alarm owner

Command Mode

- /exec/configure

roaming-eid-prefix

```
{ [ no ] roaming-eid-prefix { <eid-prefix> | <eid-prefix6> } }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
roaming-eid-prefix	Configures what EID-prefixes allowed to roam
<i>eid-prefix</i>	IPv4 roaming EID-prefix

Command Mode

- /exec/configure/lisp-dynamic-eid /exec/configure/vrf/lisp-dynamic-eid

role feature-group name

role feature-group name

[no] role feature-group name <arg6>

Syntax Description

no	(Optional) Negate a command or set its defaults
role	Configure roles
feature-group	Configure role feature-group
name	Feature-group name
<i>arg6</i>	Enter feature-group name

Command Mode

- /exec/configure

role name

[no] role name <arg2>

Syntax Description

no	(Optional) Negate a command or set its defaults
role	Configure roles
name	Enter the role name
<i>arg2</i>	Enter the role name

Command Mode

- /exec/configure

role priority

role priority <priority_value> | no role priority

Syntax Description

no	Negate a command or set its defaults
role	Role related configuration
priority	Configure priority to be used during vPC role (primary/secondary) election
<i>priority_value</i>	specify priority value

Command Mode

- /exec/configure/vpc-domain

rollback progress stats

[no] rollback progress stats

Syntax Description

no	(Optional) negate the command
rollback	Rollback configuration
progress	Rollback progress
stats	Enable rollback progress stats

Command Mode

- /exec

rollback running-config checkpoint

rollback running-config checkpoint

rollback running-config { checkpoint <chkpoint_name> | file <file_uri> } [best-effort | stop-at-first-failure | atomic] [verbose]

Syntax Description

rollback	Rollback configuration
running-config	Rollback running configuration
checkpoint	Rollback running configuration to checkpoint
<i>chkpoint_name</i>	Checkpoint name
file	Rollback running configuration to configuration file
<i>file_uri</i>	Checkpoint file path
best-effort	(Optional) Skip errors and proceed with rollback
stop-at-first-failure	(Optional) Stop rollback at the first error
atomic	(Optional) Stop rollback and revert to original configuration (default)
verbose	(Optional) Show the execution log

Command Mode

- /exec

root-priority

[no] root-priority <root-pri>

Syntax Description

no	(Optional) Negate a command or set its defaults
root-priority	Set priority with which nodes becomes root
<i>root-pri</i>	Root priority value per topology

Command Mode

- /exec/configure/l2mp-isis/l2mp-isis-vrf-common /exec/configure/l2mp-isis/l2mp-isis-l2-topo

route-map

route-map <rtmap-name> [permit | deny]

Syntax Description

route-map	Create route-map or enter route-map command mode
<i>rtmap-name</i>	Route-map name
permit	(Optional) Route map permits set operations
deny	(Optional) Route map denies set operations

Command Mode

- /exec/configure

route-map

```
route-map <rtmap-name> [ permit | deny ] <seq>
```

Syntax Description

route-map	Create route-map or enter route-map command mode
<i>rtmap-name</i>	Route-map name
permit	(Optional) Route map permits set operations
deny	(Optional) Route map denies set operations
<i>seq</i>	Sequence to insert to/delete from existing route-map entry

Command Mode

- /exec/configure

route-map

[no] route-map { <rtmap-name> | <rtmap-name> } [permit | deny]

Syntax Description

no	Negate a command or set its defaults
route-map	Create route-map or enter route-map command mode
<i>rtmap-name</i>	Route-map name
<i>rtmap-name</i>	Known route-map name
permit	(Optional) Route map permits set operations
deny	(Optional) Route map denies set operations

Command Mode

- /exec/configure

route-map

[no] route-map { <rtmap-name> | <rtmap-name> } [permit | deny] <seq>

Syntax Description

no	Negate a command or set its defaults
route-map	Create route-map or enter route-map command mode
<i>rtmap-name</i>	Route-map name
<i>rtmap-name</i>	Known route-map name
permit	(Optional) Route map permits set operations
deny	(Optional) Route map denies set operations
<i>seq</i>	Sequence to insert to/delete from existing route-map entry

Command Mode

- /exec/configure

route-map out

route-map out

[no | default] route-map <rmap-name> { out | in }

Syntax Description

no	(Optional) Negate a command or set its defaults
default	(Optional) Inherit values from a peer template
route-map	Apply route-map to neighbor
<i>rmap-name</i>	Route-map name
out	Apply policy to outgoing routes
in	Apply policy to incoming routes

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af

route-map out

[no | default] route-map <rmap-name> { out | in }

Syntax Description

no	(Optional) Negate a command or set its defaults
default	(Optional) Inherit values from a peer template
route-map	Apply route-map to neighbor
<i>rmap-name</i>	Route-map name
out	Apply policy to outgoing routes
in	Apply policy to incoming routes

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv4
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mdt
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv6
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-vpls
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-evpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-label
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-label

route-map pbr-statistics

route-map pbr-statistics

route-map <route-map-name> pbr-statistics | no route-map { <route-map-name> | <route-map-name> } pbr-statistics

Syntax Description

no	Negate a command or set its defaults
route-map	Create route-map or enter route-map command mode
<i>route-map-name</i>	Route-map name
<i>route-map-name</i>	Route-map name
<i>route-map-name</i>	Known route-map name
pbr-statistics	Statistics for policy based routing

Command Mode

- /exec/configure

route-reflector-client

[no | default] route-reflector-client

Syntax Description

no	(Optional) Negate a command or set its defaults
default	(Optional) Inherit values from a peer template
route-reflector-client	Configure a neighbor as Route reflector client

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af

route-reflector-client

[no | default] route-reflector-client

Syntax Description

no	(Optional) Negate a command or set its defaults
default	(Optional) Inherit values from a peer template
route-reflector-client	Configure a neighbor as Route reflector client

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv4
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mdt
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv6
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-link-state
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-vpls
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-evpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-label
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-label

route-target both auto

```
{ route-target both { auto | <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } [ evpn ] } | { no route-target both [ auto | <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> ] [ evpn ] }
```

Syntax Description

no	Negate a command or set its defaults
route-target	Specify Target VPN Extended Communities
both	Export And Import Target-VPN community
auto	Generate route target automatically
evpn	(Optional) Specify Target for EVPN routes
<i>ext-comm-rt-aa2nn4</i>	RT extcommunity in aa:nn format
<i>ext-comm-rt-aa4nn2</i>	RT extcommunity in aa4:nn or ip:nn format

Command Mode

- /exec/configure/vrf-af-ipv4 /exec/configure/vrf-af-ipv6

route-target both auto

route-target both auto

```
{ route-target both { auto | <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } } | { no route-target both { auto | <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } }
```

Syntax Description

no	Negate a command or set its defaults
route-target	Specify Target VPN Extended Communities
auto	Generate RT automatically
both	Export and Import Target-VPN community
<i>ext-comm-rt-aa2nn4</i>	RT extcommunity in aa:nn format
<i>ext-comm-rt-aa4nn2</i>	RT extcommunity in aa4:nn or ip:nn format

Command Mode

- /exec/configure/evpn/evi

route-target export

```
{ route-target export { <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } [ evpn ] } | { no route-target export  
{ <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } [ evpn ] }
```

Syntax Description

no	Negate a command or set its defaults
route-target	Specify Target VPN Extended Communities
export	Export Target-VPN community
evpn	(Optional) Specify Target for EVPN routes
<i>ext-comm-rt-aa4nn2</i>	RT extcommunity in aa4:nn or ip:nn format
<i>ext-comm-rt-aa2nn4</i>	RT extcommunity in aa:nn format

Command Mode

- /exec/configure/vrf-af-ipv4 /exec/configure/vrf-af-ipv6

route-target export auto

route-target export auto

```
{ route-target export { auto | <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } } | { no route-target export { auto | <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } }
```

Syntax Description

no	Negate a command or set its defaults
route-target	Specify Target VPN Extended Communities
auto	Generate RT automatically
export	Export Target-VPN community
<i>ext-comm-rt-aa2nn4</i>	RT extcommunity in aa:nn format
<i>ext-comm-rt-aa4nn2</i>	RT extcommunity in aa4:nn or ip:nn format

Command Mode

- /exec/configure/evpn/evi

route-target import

```
{ route-target import { <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } [ evpn ] } | { no route-target import { <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } [ evpn ] }
```

Syntax Description

no	Negate a command or set its defaults
route-target	Specify Target VPN Extended Communities
import	Import Target-VPN community
evpn	(Optional) Specify Target for EVPN routes
<i>ext-comm-rt-aa4nn2</i>	RT extcommunity in aa4:nn or ip:nn format
<i>ext-comm-rt-aa2nn4</i>	RT extcommunity in aa:nn format

Command Mode

- /exec/configure/vrf-af-ipv4 /exec/configure/vrf-af-ipv6

route-target import auto

route-target import auto

```
{ route-target import { auto | <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } } | { no route-target import
{ auto | <ext-comm-rt-aa2nn4> | <ext-comm-rt-aa4nn2> } }
```

Syntax Description

no	Negate a command or set its defaults
route-target	Specify Target VPN Extended Communities
import	Import Target-VPN community
auto	Generate RT automatically
<i>ext-comm-rt-aa2nn4</i>	RT extcommunity in aa:nn format
<i>ext-comm-rt-aa4nn2</i>	RT extcommunity in aa4:nn or ip:nn format

Command Mode

- /exec/configure/evpn/evi

route delete dampen interval

[no] route delete dampen interval <time>

Syntax Description

no	(Optional) Negate a command or set its defaults
route	Display routing information
delete	Dampen route delete update to hardware
dampen	Dampen update to hardware
interval	Dampen interval
<i>time</i>	Dampen interval in seconds

Command Mode

- /exec/configure

router-id

[no] router-id <router-id>

Syntax Description

no	(Optional) Negate a command or set its defaults
router-id	Specify the IP address to use as router-id
<i>router-id</i>	Manually configured router identifier

Command Mode

- /exec/configure/router-bgp/vrf-cmds

router-id

{ { router-id <id> } | { no router-id [<id>] } }

Syntax Description

no	Negate a command or set its defaults
router-id	Set OSPF process router-id
<i>id</i>	Router ID Value

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

router-id

router-id [vrf { <vrf-name> | <vrf-known-name> }] <interface> [force] | no router-id [{ vrf { <vrf-name> | <vrf-known-name> } } <interface> [force]]

Syntax Description

no	Negate a command or set its defaults
router-id	Select interface to prefer for LDP identifier address
vrf	(Optional) VRF Routing/Forwarding instance information
<i>vrf-name</i>	(Optional) VPN Routing/Forwarding instance name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>interface</i>	
force	(Optional) Forcibly change the LDP router id

Command Mode

- /exec/configure/ldp

router-id

{ { router-id <id> } | { no router-id [<id>] } }

Syntax Description

no	Negate a command or set its defaults
router-id	Set OSPFv3 process router-id
<i>id</i>	Router ID Value

Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

router-id

{ { [eigrp] router-id <id> } | { no [eigrp] router-id [<id>] } }

Syntax Description

no	Negate a command or set its defaults
eigrp	(Optional) EIGRP router configuration commands
router-id	router-id for this EIGRP process
<i>id</i>	EIGRP Router-ID in IP address format

Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

router bgp

[no] router bgp <as>

Syntax Description

no	(Optional) Negate a command or set its defaults
router	Enable a routing process
bgp	Border Gateway Protocol (BGP)
as	Autonomous

Command Mode

- /exec/configure

router eigrp

router eigrp

[no] router eigrp <eigrp-ptag>

Syntax Description

no	(Optional) Negate a command or set its defaults
router	Enable a routing process
eigrp	Enhanced Interior Gateway Routing Protocol (EIGRP)
<i>eigrp-ptag</i>	Process tag

Command Mode

- /exec/configure

router isis

[no] router isis <tag>

Syntax Description

no	(Optional) Negate a command or set its defaults
router	Enable a routing process
isis	Intermediate System to Intermediate System (IS-IS)
tag	Routing process tag

Command Mode

- /exec/configure

router ospf

router ospf

[no] router ospf <tag>

Syntax Description

no	(Optional) Negate a command or set its defaults
router	Enable a routing process
ospf	Open Shortest Path First (OSPF)
<i>tag</i>	Process tag

Command Mode

- /exec/configure

router ospfv3

[no] router ospfv3 <tag>

Syntax Description

no	(Optional) Negate a command or set its defaults
router	Enable a routing process
ospfv3	Open Shortest Path First (OSPF) (Version 3)
<i>tag</i>	Process tag

Command Mode

- /exec/configure

router rip

[no] router rip <tag>

Syntax Description

no	(Optional) Negate a command or set its defaults
router	Enable a routing process
rip	Routing Information Protocol (RIP)
<i>tag</i>	Process ID

Command Mode

- /exec/configure

routing-context vrf

routing-context vrf <vrf-known-name>

Syntax Description

routing-context	Set the routing context
vrf	The new routing-context VRF
<i>vrf-known-name</i>	Known VRF name

Command Mode

- /exec

```
routing ipv4 unicast nexthop-sorting
```

routing ipv4 unicast nexthop-sorting

[no] routing ipv4 unicast nexthop-sorting

Syntax Description

no	(Optional) Negate a command or set its defaults
routing	Routing events
ipv4	IP events
unicast	unicast
nexthop-sorting	Sort nhs while storing

Command Mode

- /exec/configure

routing ipv6 unicast nexthop-sorting

[no] routing ipv6 unicast nexthop-sorting

Syntax Description

no	(Optional) Negate a command or set its defaults
routing	Routing events
ipv6	Configure IPv6 features
unicast	unicast
nexthop-sorting	Sort nhs while storing

Command Mode

- /exec/configure

rsakeypair

[no] rsakeypair <s0> [<i0>]

Syntax Description

no	(Optional) Negate a command or set its defaults
rsakeypair	Configure trustpoint rsa key-pair details
s0	key-pair label
i0	(Optional) key-pair size

Command Mode

- /exec/configure/trustpoint

rtr etr eid

[no] { rtr | etr | eid } { <locator> | <locator6> } [strict | probe] + <seq>

Syntax Description

no	(Optional) Negate a command or set its defaults
rtr	Configure RTR in ELP ordered list
etr	Configure ETR in ELP ordered list
eid	Configure EID in ELP ordered list
<i>locator</i>	IPv4 locator for RTR/ETR or EID
strict	(Optional) ELP hop must be used in Explicit Locator Path
probe	(Optional) RLOC-probe next-hop in ELP
<i>seq</i>	Sequence to insert or delete RTR/ETR/EID ELP entry

Command Mode

- /exec/configure/lisp-elp /exec/configure/vrf/lisp-elp

rule

rule <number> { <action> } { { <permission> [<featuretype> <name>] } | { command <cmd_line> } } | no rule <number>

Syntax Description

no	Negate a command or set its defaults
rule	Enter the rule number
<i>number</i>	Enter the rule number
<i>action</i>	Action
<i>permission</i>	Permission
<i>command</i>	Command line
<i>cmd_line</i>	Enter the command (use space+'' for command separator) e.g. config t role *
<i>featuretype</i>	(Optional) Feature type
<i>name</i>	(Optional) Enter the access entity name

Command Mode

- /exec/configure/role

rule oid

rule <number> <action> <permission> oid <snmp_oid> | no rule <number>

Syntax Description

no	Negate a command or set its defaults
rule	Enter the rule number
<i>number</i>	Enter the rule number
<i>action</i>	Action
<i>permission</i>	Permission
oid	SNMP oid (up to 32 elements)
<i>snmp_oid</i>	Enter snmp oid instance name

Command Mode

- /exec/configure/role

run-script

run-script <uri0>

Syntax Description

run-script	Run shell scripts
<i>uri0</i>	Enter script file name

Command Mode

- /exec

run-show-tech-script

run-show-tech-script <s0>

Syntax Description

run-show-tech-script	Run show tech script
s0	fname

Command Mode

- /exec

run2 guestshell

run2 guestshell [{ <cmd_args> }]

Syntax Description

run2	execute/run program!!!
guestshell	The guest shell Linux-bash
<i>cmd_args</i>	(Optional) The command to execute

Command Mode

- /exec

run bash

run bash [<cmd>]

Syntax Description

run	execute/run program
bash	linux-bash
<i>cmd</i>	(Optional) the command to execute

Command Mode

- /exec

run bash