



H Commands

- [ha-policy single](#), on page 4
- [ha-stateful](#), on page 5
- [hardware access-list lou resource threshold](#), on page 6
- [hardware access-list match inner-header](#), on page 7
- [hardware access-list module](#), on page 8
- [hardware access-list tcam region](#), on page 9
- [hardware access-list tcam region double-wide](#), on page 10
- [hardware access-list tcam region double-wide](#), on page 11
- [hardware access-list tcam region qualify udf](#), on page 12
- [hardware ecmp hash-offset](#), on page 13
- [hardware ecmp hash-polynomial](#), on page 14
- [hardware ejector enable](#), on page 15
- [hardware fan-zone raise-speed](#), on page 16
- [hardware forwarding funcstats clear](#), on page 17
- [hardware forwarding funcstats disable](#), on page 18
- [hardware forwarding funcstats enable](#), on page 19
- [hardware forwarding l3 resource route non-deterministic](#), on page 20
- [hardware forwarding unicast trace](#), on page 21
- [hardware ip glean throttle](#), on page 22
- [hardware ip glean throttle maximum](#), on page 23
- [hardware ip glean throttle syslog](#), on page 24
- [hardware ip glean throttle timeout](#), on page 25
- [hardware ipv6 glean throttle](#), on page 26
- [hardware ipv6 glean throttle maximum](#), on page 27
- [hardware ipv6 glean throttle syslog](#), on page 28
- [hardware ipv6 glean throttle timeout](#), on page 29
- [hardware module boot-order reverse](#), on page 30
- [hardware profile buffer info poll-interval timer](#), on page 31
- [hardware profile buffer info port-threshold threshold](#), on page 32
- [hardware profile ecmp auto-recovery threshold](#), on page 33
- [hardware profile ecmp resilient](#), on page 34
- [hardware profile front portmode](#), on page 35
- [hardware profile ipv6 alpm carve-value](#), on page 36

- hardware profile ipv6 lpm-entries maximum, on page 37
- hardware profile multicast max-limit, on page 38
- hardware profile multicast max-limit lpm-entries, on page 39
- hardware profile multicast prefer-source-tree, on page 40
- hardware profile multicast syslog-threshold, on page 41
- hardware profile openflow, on page 42
- hardware profile pfc mmu buffer-reservation, on page 43
- hardware profile portmode, on page 44
- hardware profile tcam ipv6-sup-tcam match-inner, on page 45
- hardware profile tcam region, on page 46
- hardware profile tcam region span qualify udf, on page 47
- hardware profile tcam resource service-template, on page 48
- hardware profile tcam resource template, on page 49
- hardware profile ucast6 lpm-65-to-127-max-limit, on page 50
- hardware profile ucast6 max-limit, on page 51
- hardware profile unicast enable-host-ecmp, on page 52
- hardware profile unicast syslog-threshold, on page 53
- hardware sample-redirect module redirect-interface, on page 54
- head, on page 55
- hello-interval, on page 56
- hello-interval, on page 57
- hello-interval, on page 58
- hex, on page 59
- history, on page 60
- history, on page 61
- history, on page 62
- history, on page 63
- history, on page 64
- history, on page 65
- history buffer, on page 66
- history syslog, on page 67
- hold adjacency, on page 68
- hold ip route, on page 69
- hold ipv6 route, on page 70
- hold timeout, on page 71
- holdtime, on page 72
- hop, on page 73
- host-reachability protocol, on page 74
- host-reachability protocol controller, on page 75
- hostname, on page 76
- hostname dynamic, on page 77
- hostname dynamic, on page 78
- hsrp, on page 79
- hsrp anycast, on page 80
- hsrp bfd, on page 81
- hsrp bfd all-interfaces, on page 82

- [hsrp delay minimum](#), on page 83
- [hsrp force state vlan](#), on page 84
- [hsrp internal](#), on page 85
- [hsrp internal](#), on page 86
- [hsrp ipv6](#), on page 87
- [hsrp mac-refresh](#), on page 88
- [hsrp timers extended-hold](#), on page 89
- [hsrp use-bia](#), on page 90
- [hsrp version 1](#), on page 91
- [human](#), on page 92
- [human](#), on page 93
- [hw-module logging onboard](#), on page 94
- [hw-module logging onboard](#), on page 95

ha-policy single

ha-policy { single-sup <hap-change> | dual-sup <sw-change> } +

Syntax Description

Syntax Description

ha-policy Change HA policy for this VDC

hap-change Change HA policy for this VDC

single-sup Change HA policy for this VDC for single-sup situations

dual-sup Change HA policy for this VDC for dual-sup situations

sw-change Set hap policy

Command Mode

- /exec/configure/vdc

ha-stateful

[no] ha-stateful

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
ha-stateful	Enable stateful OSPF HA

Command Mode

- /exec/configure/router-ospf

hardware access-list lou resource threshold

[no] hardware access-list lou resource threshold <threshold>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
access-list	Access Control List
lou	LOU
resource	hardware resource
threshold	port expansion threshold
<i>threshold</i>	value of threshold

Command Mode

- /exec/configure

hardware access-list match inner-header

[no] hardware access-list match inner-header

Syntax Description

Syntax Description	no	(Optional) Negate the command or set its defaults
	hardware	Change hardware usage settings
	access-list	Access Control List
	match	Match criteria in ACL
	inner-header	Match inner header fields in IPinIP/GRE packets

Command Mode

- /exec/configure

hardware access-list module

[no] hardware access-list { resource-pooling | resource pooling } module <module-number>

Syntax Description

Syntax Description		
no	(Optional) Negate a command or set its defaults	
hardware	Show hardware information	
access-list	Access Control List	
resource-pooling	Enable ACL programming across TCAM banks	
resource	hardware resource	
pooling	Enable ACL programming across TCAM banks	
module	module number	
<i>module-number</i>	specify module number	

Command Mode

- /exec/configure

hardware access-list tcam region

[no] hardware access-list tcam region <type> <tcam_size>

Syntax Description

Syntax	Description
no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
access-list	Access Control List
tcam	Configure tcam parameters
region	Configure tcam region
<i>type</i>	Region type
<i>tcam_size</i>	Enter tcam size

Command Mode

- /exec/configure

hardware access-list tcam region double-wide

[no] hardware access-list tcam region <double-wide-region> <tcam_size> double-wide

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hardware		Hardware Internal Information
access-list		Access Control List
tcam		Configure tcam parameters
region		Configure tcam region
<i>double-wide-region</i>		Region type
<i>tcam_size</i>		Enter tcam size
double-wide		Double Width

Command Mode

- /exec/configure

hardware access-list tcam region double-wide

[no] hardware access-list tcam region <arp-ether> <arpether_tcam_size> double-wide

Syntax Description

Syntax Description		
no	(Optional) Negate a command or set its defaults	
hardware	Hardware Internal Information	
access-list	Access Control List	
tcam	Configure tcam parameters	
region	Configure tcam region	
<i>arp-ether</i>	Region type	
<i>arpether_tcam_size</i>	Enter tcam size	
double-wide	Double Width	

Command Mode

- /exec/configure

hardware access-list tcam region qualify udf

[no] hardware access-list tcam region <udf_tcam_type> qualify udf { <udf_name> } +

Syntax Description

Syntax Description		
no	(Optional) Negate the command	
hardware	Change hardware usage settings	
access-list	Access Control List	
tcam	Configure tcam parameters	
region	Configure tcam region	
<i>udf_tcam_type</i>	Region type	
qualify	Configure UDFs to be qualified for span region	
udf	Configure UDF names	
<i>udf_name</i>	UDF name	

Command Mode

- /exec/configure

hardware ecmp hash-offset

[no] hardware ecmp hash-offset <value> [concatenation]

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hardware		Change hardware usage settings
ecmp		ECMP configuration
hash-offset		Configure hash offset
<i>value</i>		Hash offset 0-15 non-concatenate mode, 0-63 concatenate mode
concatenation	(Optional)	Configure hash concatenation

Command Mode

- /exec/configure

hardware ecmp hash-polynomial

hardware ecmp hash-polynomial <poly-type> | no hardware ecmp hash-polynomial

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hardware		Change hardware usage settings
ecmp		ECMP configuration
hash-polynomial		Configure hash polynomial
<i>poly-type</i>		Polynomial type

Command Mode

- /exec/configure

hardware ejector enable

[no] hardware ejector enable

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	hardware	Hardware Internal Information
	ejector	Card ejector functionality
	enable	enabled means when both ejectors are open, card is powered down

Command Mode

- /exec/configure

hardware fan-zone raise-speed

[no] hardware fan-zone <fan_zone_id> raise-speed <speed-to-raise>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hardware	Hardware	Internal Information
fan-zone	Fan Zone	supported in the switch
<i>fan_zone_id</i>	please enter fan zone id	whose speed needs to be increased
raise-speed	Speed to be added for current fan zone	speed
<i>speed-to-raise</i>	please enter additional fan	speed

Command Mode

- /exec/configure

hardware forwarding funcstats clear

hardware forwarding funcstats clear

Syntax Description

Syntax Description	hardware	Change hardware usage settings
	forwarding	Change forwarding related settings
	funcstats	Enable/disable funcstats
	clear	Clear funcstats information

Command Mode

- /exec

hardware forwarding funcstats disable

hardware forwarding funcstats disable

Syntax Description

Syntax Description	hardware	Change hardware usage settings
	forwarding	Change forwarding related settings
	funcstats	Enable/disable funcstats
	disable	Disable funcstats recording and output

Command Mode

- /exec

hardware forwarding funcstats enable

hardware forwarding funcstats enable

Syntax Description

Syntax Description	hardware	Change hardware usage settings
	forwarding	Change forwarding related settings
	funcstats	Enable/disable funcstats
	enable	Enable funcstats recording and output

Command Mode

- /exec

hardware forwarding l3 resource route non-deterministic

[no] hardware forwarding l3 resource route non-deterministic

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hardware		hardware information
forwarding		forwarding information
l3		Layer-3
resource		hardware resources
route		TCAM capacity to hold prefixes
non-deterministic		extend upto 1M

Command Mode

- /exec/configure

hardware forwarding unicast trace

[no] hardware forwarding unicast trace

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
forwarding	Hardware forwarding
unicast	Hardware Unicast forwarding
trace	Debug traces

Command Mode

- /exec/configure

hardware ip glean throttle

[no] hardware ip glean throttle

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	hardware	Hardware information
	ip	IP
	glean	Glean
	throttle	Throttle

Command Mode

- /exec/configure

hardware ip glean throttle maximum

{ hardware ip glean throttle maximum <count> } | { no hardware ip glean throttle maximum }

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hardware		Hardware information
ip		IP
glean		Glean
throttle		Throttle
maximum		Maximum number of entries
<i>count</i>		Count

Command Mode

- /exec/configure

hardware ip glean throttle syslog

{ hardware ip glean throttle syslog <pkt-count> } | { no hardware ip glean throttle syslog }

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hardware		Hardware information
ip		IP
glean		Glean
throttle		Throttle
syslog		Threshold for syslog for number of packets hitting the entry
<i>pkt-count</i>		Packet count

Command Mode

- /exec/configure

hardware ip glean throttle timeout

```
{ hardware ip glean throttle timeout <timeout-in-sec> } | { no hardware ip glean throttle timeout }
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
hardware	Hardware information
ip	IP
glean	Glean
throttle	Throttle
timeout	Timeout
<i>timeout-in-sec</i>	Timeout value in seconds (should be multiple of 30, else will be rounded off to nearest boundary)

Command Mode

- /exec/configure

hardware ipv6 glean throttle

[no] hardware ipv6 glean throttle

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	hardware	Hardware information
	ipv6	IPv6
	glean	Glean
	throttle	Throttle

Command Mode

- /exec/configure

hardware ipv6 glean throttle maximum

```
{ hardware ipv6 glean throttle maximum <count> } | { no hardware ipv6 glean throttle maximum }
```

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	hardware	Hardware information
	ipv6	IPv6
	glean	Glean
	throttle	Throttle
	maximum	Maximum number of entries
	<i>count</i>	Count

Command Mode

- /exec/configure

hardware ipv6 glean throttle syslog

```
{ hardware ipv6 glean throttle syslog <pkt-count> } | { no hardware ipv6 glean throttle syslog }
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hardware		Hardware information
ipv6		IPv6
glean		Glean
throttle		Throttle
syslog		Threshold for syslog for number of packets hitting the entry
<i>pkt-count</i>		Packet count

Command Mode

- /exec/configure

hardware ipv6 glean throttle timeout

{ hardware ipv6 glean throttle timeout <timeout-in-sec> } | { no hardware ipv6 glean throttle timeout }

Syntax Description

Syntax Description

no	Negate a command or set its defaults
hardware	Hardware information
ipv6	IPv6
glean	Glean
throttle	Throttle
timeout	Timeout
<i>timeout-in-sec</i>	Timeout value in seconds (should be multiple of 30, else will be rounded off to nearest boundary)

Command Mode

- /exec/configure

hardware module boot-order reverse

[no] hardware module boot-order reverse

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	hardware	Hardware Internal Information
	module	applies on all the modules
	boot-order	Configure order of module power-up
	reverse	reverse order of module power-up

Command Mode

- /exec/configure

hardware profile buffer info poll-interval timer

[no] hardware profile buffer info poll-interval [module <module>] timer <msec>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hardware		Change hardware usage settings
profile		profile settings
buffer		System buffer
info		Information
poll-interval		System buffer status polling interval
module	(Optional)	Slot/module
<i>module</i>	(Optional)	Slot/module number
timer		Polling timer
<i>msec</i>		Polling timer value in msec

Command Mode

- /exec/configure

hardware profile buffer info port-threshold threshold

[no] hardware profile buffer info port-threshold [module <module>] threshold <value>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hardware		Change hardware usage settings
profile		profile settings
buffer		System buffer
info		Information
port-threshold		Set port egress buffer usage threshold
module	(Optional)	Slot/module
<i>module</i>	(Optional)	Slot/module number
threshold		threshold value
<i>value</i>		percentage of maximum usage

Command Mode

- /exec/configure

hardware profile ecmp auto-recovery threshold

hardware profile ecmp auto-recovery threshold <percentage> | no hardware profile ecmp auto-recovery threshold

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hardware		Change hardware usage settings
profile		profile settings
ecmp		ECMP settings
auto-recovery		ECMP auto-recovery settings
threshold		ECMP table free percentage threshold for auto-recovery
<i>percentage</i>		Percentage

Command Mode

- /exec/configure

hardware profile ecmp resilient

[no] hardware profile ecmp resilient

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
ecmp	ECMP settings
resilient	Configure ECMP resilient mode

Command Mode

- /exec/configure

hardware profile front portmode

hardware profile front portmode <port-mode> | no hardware profile front portmode

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hardware		Change hardware usage settings
profile		profile settings
front		port 1 QSFP/SFP+ settings
portmode		QSFP or SFP+
<i>port-mode</i>		Configure QSFP/sfp+ port mode

Command Mode

- /exec/configure

hardware profile ipv6 alpm carve-value

[no] hardware profile ipv6 alpm carve-value <ipv6_alpm_carve_value>

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
hardware		Change hardware usage settings
profile		profile settings
ipv6		ipv6
alpm		alpm mode
carve-value		carve value
<i>ipv6_alpm_carve_value</i>		maximum entries

Command Mode

- /exec/configure

hardware profile ipv6 lpm-entries maximum

[no] hardware profile ipv6 lpm-entries maximum <ipv6_lpm_max_entry>

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
hardware		Change hardware usage settings
profile		profile settings
ipv6		ipv6
lpm-entries		lpm(non-host) entries
maximum		maximum limit
<i>ipv6_lpm_max_entry</i>		maximum entries

Command Mode

- /exec/configure

hardware profile multicast max-limit

{ hardware profile multicast max-limit <mcast-ent> } | { no hardware profile multicast max-limit }

Syntax Description

Syntax Description		
no		Negate the command
hardware		Change hardware usage settings
profile		profile settings
multicast		Multicast settings
max-limit		maximum limit for multicast entries
<i>mcast-ent</i>		Mcast Table Entries

Command Mode

- /exec/configure

hardware profile multicast max-limit lpm-entries

[no] hardware profile multicast max-limit lpm-entries <ipv4_mcast_lpm_max_entry>

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
hardware		Change hardware usage settings
profile		profile settings
multicast		Multicast settings
max-limit		maximum limit for multicast entries
lpm-entries		lpm(non-host) entries
<i>ipv4_mcast_lpm_max_entry</i>		maximum entries

Command Mode

- /exec/configure

hardware profile multicast prefer-source-tree

[no] hardware profile multicast prefer-source-tree [eternity [limit <max-limit>]]

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
hardware		Change hardware usage settings
profile		profile settings
multicast		Multicast settings
prefer-source-tree		prefer the source tree
eternity	(Optional)	prefer source tree for eternity and not for just 2 minutes
limit	(Optional)	Configure a limit for the number of hardware entries used
<i>max-limit</i>	(Optional)	Number of (S,G) for which source tree is preferred

Command Mode

- /exec/configure

hardware profile multicast syslog-threshold

[no] hardware profile multicast syslog-threshold <percentage>

Syntax Description

Syntax Description		
no	(Optional) Negate the command	
hardware	Change hardware usage settings	
profile	profile settings	
multicast	Multicast settings	
syslog-threshold	MROUTE table syslog threshold	
<i>percentage</i>	Percentage (Default is 90)	

Command Mode

- /exec/configure

hardware profile openflow

```
[no] hardware profile { openflow [ agent default { drop | normal } ] | { tap-aggregation [ l2drop ] } }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
hardware		Hardware Internal Information
profile		Profile
openflow		Openflow
tap-aggregation		Tap Aggregation
l2drop	(Optional)	Drop non IP traffic ingress on mode tap interfaces
agent	(Optional)	Act as Openflow Agent
default	(Optional)	Specify default action for frames which don't match any flow
drop	(Optional)	Drop all frames that miss MAC
normal	(Optional)	[default]Flood unknown traffic

Command Mode

- /exec/configure

hardware profile pfc mmu buffer-reservation

[no] hardware profile pfc mmu buffer-reservation <percentage>

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
hardware		Hardware Internal Information
profile		profile settings
pfc		System level priority-flow-control settings
mmu		Hardware memory management unit configuration
buffer-reservation		Shared pool buffer reservation
<i>percentage</i>		Percentage of shared pool buffers to be reserved

Command Mode

- /exec/configure

hardware profile portmode

{ hardware profile portmode <port-mode> [2-tuple] } | no hardware profile portmode

Syntax Description

Syntax Description	Description
no	Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
portmode	QSFP port mode setting
<i>port-mode</i>	Configure QSFP port mode
2-tuple	(Optional) Display QSFP portnames in 2-tuple mode even in 10G mode

Command Mode

- /exec/configure

hardware profile tcam ipv6-sup-tcam match-inner

```
{ hardware profile tcam ipv6-sup-tcam match-inner } | { no hardware profile tcam ipv6-sup-tcam match-inner }
}
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hardware		Change hardware usage settings
profile		Profile settings
tcam		Configure tcam parameters
ipv6-sup-tcam		IPv6 SUP TCAM parameters
match-inner		match inner payload for tunnel packets

Command Mode

- /exec/configure

hardware profile tcam region

```
[no] hardware profile tcam region { <tcam_compat_type> <tcam_compat_size> | ifacl <tcam_compat_size>
[ double-wide ] }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hardware		Hardware Internal Information
profile		profile
tcam		Configure tcam parameters
region		Configure tcam region
ifacl		IPV4 PAACL size
double-wide	(Optional)	Configure tcam as double wide
<i>tcam_compat_type</i>		
<i>tcam_compat_size</i>		Enter tcam size

Command Mode

- /exec/configure

hardware profile tcam region span qualify udf

[no] hardware profile tcam region span qualify udf { <udf_name> } +

Syntax Description

Syntax Description	
no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	Profile settings
tcam	Configure tcam parameters
region	Configure tcam region
span	Configure for span region
qualify	Configure UDFs to be qualified for span region
udf	Configure UDF names
<i>udf_name</i>	UDF name

Command Mode

- /exec/configure

hardware profile tcam resource service-template

[no] hardware profile tcam resource service-template { <name> } [module { <lc> | <fm> }]

Syntax Description

Syntax Description		
no	(Optional) Negate a command or set its defaults	
hardware	Change hardware usage settings	
profile	Profile settings	
tcam	Configure tcam parameters	
resource	Configure tcam hardware resources	
service-template	Commit template	
<i>name</i>	Select name of template	
module	(Optional) Specify a module number	
<i>lc</i>	(Optional) line card number	
<i>fm</i>	(Optional) fabric module number	

Command Mode

- /exec/configure handle auto 424

hardware profile tcam resource template

```
[no] hardware profile tcam resource template { <name> { ref-template <temp-nontahoe> | ref-template-tahoe
<temp-tahoe> } }
```

Syntax Description

Syntax Description		
no	(Optional) Negate a command or set its defaults	
hardware	Change hardware usage settings	
profile	Profile settings	
tcam	Configure tcam parameters	
resource	Configure tcam hardware resources	
template	Configure template based tcam carving parameters	
ref-template	Select a default template as reference	
<i>temp-nontahoe</i>		
ref-template-tahoe	Select a default template as reference	
<i>temp-tahoe</i>		
<i>name</i>	Create/Select name of custom template	

Command Mode

- /exec/configure

hardware profile ucast6 lpm-65-to-127-max-limit

{ hardware profile ucast6 lpm-65-to-127-max-limit <unicast-ent> } | { no hardware profile ucast6 lpm-65-to-127-max-limit }

Syntax Description

Syntax Description		
no		Negate the command
hardware		Change hardware usage settings
profile		profile settings
ucast6		unicast ipv6 settings
lpm-65-to-127-max-limit		maximum limit for unicast ipv6 lpm-65-to-127 entries, default is 256
<i>unicast-ent</i>		Unicast ipv6 lpm-65-to-127 Table Entries

Command Mode

- /exec/configure

hardware profile ucast6 max-limit

{ hardware profile ucast6 max-limit <unicast-ent> } | { no hardware profile ucast6 max-limit }

Syntax Description

Syntax Description		
no		Negate the command
hardware		Change hardware usage settings
profile		profile settings
ucast6		unicast ipv6 settings
max-limit		maximum limit for unicast ipv6 entries
<i>unicast-ent</i>		Unicast ipv6 Table Entries

Command Mode

- /exec/configure

hardware profile unicast enable-host-ecmp

[no] hardware profile unicast enable-host-ecmp [arp-nd | [ipv4 [arp]] | [ipv6 [nd]]]

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
hardware		Change hardware usage settings
profile		profile settings
unicast		Unicast settings
enable-host-ecmp		Enable ECMP support for /32 (IPv4) and /128 (IPv6) routes
ipv4	(Optional)	Enable ECMP support for /32 (IPv4 Only) Routes
ipv6	(Optional)	Enable ECMP support for /128 (IPv6 Only) Routes
arp-nd	(Optional)	Retain ARP (IPv4) and ND (IPv6) Routes in Host-Table
arp	(Optional)	Retain ARP Entries in Host-Table
nd	(Optional)	Retain ND Entries in Host-Table

Command Mode

- /exec/configure

hardware profile unicast syslog-threshold

```
{ hardware profile unicast syslog-threshold <percentage> } | { no hardware profile unicast syslog-threshold }
}
```

Syntax Description

Syntax Description		
no		Negate the command
hardware		Change hardware usage settings
profile		profile settings
unicast		Unicast settings
syslog-threshold		Unicast Route table syslog threshold
<i>percentage</i>		Percentage

Command Mode

- /exec/configure

hardware sample-redirect module redirect-interface

hardware sample-redirect module <num> redirect-interface <interface>

Syntax Description

Syntax Description		
hardware	Change hardware usage settings	
sample-redirect	Redirect netflow sampled data	
module	Line card module	
<i>num</i>	slot number	
redirect-interface	Interface for redirecting the traffic	
<i>interface</i>	Interface Name	

Command Mode

- /exec

head

| head [-n <lines>]

Syntax Description

Syntax Description

| Pipe command output to filter

head Display first lines

-n (Optional) modify number of lines (default 10)

lines (Optional) number of lines to print

Command Mode

- /output

hello-interval

```
{ { hello-interval <interval> } | { no hello-interval [ <interval> ] } }
```

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	hello-interval	Hello interval
	<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf/router-ospf-vlink /exec/configure/router-ospf/vrf/router-ospf-vlink

hello-interval

```
{ { hello-interval <interval> } | { no hello-interval [ <interval> ] } }
```

Syntax Description

Syntax Description	<code>no</code>	Negate a command or set its defaults
	<code>hello-interval</code>	Hello interval
	<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf/vrf/router-ospf-slink

hello-interval

{ { hello-interval <interval> } | { no hello-interval [<interval>] } }

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	hello-interval	Hello interval
	<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf3/router-ospf3-vlink /exec/configure/router-ospf3/vrf/router-ospf3-vlink

hex

hex <expr>

Syntax Description

Syntax Description

hex calculator with results in decimal format

expr the expression to compute (integer arithmetics)

Command Mode

- /exec

history

```
{ no | default } history { { buckets-kept } | { distributions-of-statistics-kept } | { enhanced [ interval [
<interval-seconds> [ buckets [ <num-buckets> ] ] ] ] } | { filter } | { hours-of-statistics-kept } | { lives-kept }
| { statistics-distribution-interval } }
```

Syntax Description

Syntax Description

no	
<i>interval</i>	(Optional) buckets
default	Set a command to its defaults
history	History and Distribution Data
buckets-kept	Maximum number of history buckets to collect
distributions-of-statistics-kept	Maximum number of statistics distribution buckets to capture
enhanced	Enable enhanced history collection
<i>interval-seconds</i>	(Optional) Interval in seconds
buckets	(Optional) Number of buckets to collect data
<i>num-buckets</i>	(Optional) Number of buckets
filter	Add operation to History when...
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
lives-kept	Maximum number of history lives to collect
statistics-distribution-interval	Statistics distribution interval size

Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/tcp /exec/configure/ip-sla/icmpEcho

history

```
history { { buckets-kept <num-buckets-kept> } | { distributions-of-statistics-kept <num-dist-stats> } | {
enhanced [ interval [ <interval-seconds> [ buckets [ <num-buckets> ] ] ] ] | { filter { all | failures | none |
overThreshold } } | { hours-of-statistics-kept <num-hours-of-stats> } | { lives-kept <life-size-value> } | {
statistics-distribution-interval <dist-interval> } }
```

Syntax Description

Syntax Description		
<i>interval</i>	(Optional) buckets	
<i>interval-seconds</i>	(Optional) <num-buckets>	
<i>life-size-value</i>	<dist-interval>	
history	History and Distribution Data	
buckets-kept	Maximum number of history buckets to collect	
<i>num-buckets-kept</i>	Bucket size value (default 15)	
distributions-of-statistics-kept	Maximum number of statistics distribution buckets to capture	
<i>num-dist-stats</i>	Distribution bucket size value (default 1)	
enhanced	Enable enhanced history collection	
buckets	(Optional) Number of buckets to collect data	
<i>num-buckets</i>	(Optional) Number of buckets	
filter	Add operation to History when...	
all	Collect every operation in History	
failures	Collect operations that fail in History	
none	Shutoff History collection	
overThreshold	Collect operations that are over threshold in History	
hours-of-statistics-kept	Maximum number of statistics hour groups to capture	
<i>num-hours-of-stats</i>	Hour groups size value (default 2)	
lives-kept	Maximum number of history lives to collect	
statistics-distribution-interval	Statistics distribution interval size	
<i>dist-interval</i>	Distribution interval value in msec (default 20)	

Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/tcp /exec/configure/ip-sla/icmpEcho

history

```
{ no | default } history { { buckets-kept } | { distributions-of-statistics-kept } | { filter } | {
hours-of-statistics-kept } | { lives-kept } | { statistics-distribution-interval } }
```

Syntax Description

Syntax Description

no	
default	Set a command to its defaults
history	History and Distribution Data
buckets-kept	Maximum number of history buckets to collect
distributions-of-statistics-kept	Maximum number of statistics distribution buckets to capture
filter	Add operation to History when...
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
lives-kept	Maximum number of history lives to collect
statistics-distribution-interval	Statistics distribution interval size

Command Mode

- /exec/configure/ip-sla/dns /exec/configure/ip-sla/fabricPathEcho

history

```
history { { buckets-kept <num-buckets-kept> } | { distributions-of-statistics-kept <num-dist-stats> } | { filter
{ all | failures | none | overThreshold } } | { hours-of-statistics-kept <num-hours-of-stats> } | { lives-kept
<life-size-value> } | { statistics-distribution-interval <dist-interval> } }
```

Syntax Description

Syntax Description	
<i>dist-interval</i>	<num-buckets-kept>
<i>num-hours-of-stats</i>	<life-size-value>
<i>distributions-of-statistics-kept</i>	hours-of-statistics-kept
<i>statistics-distribution-interval</i>	
history	History and Distribution Data
buckets-kept	Maximum number of history buckets to collect
<i>num-buckets-kept</i>	Bucket size value (default 15)
<i>num-dist-stats</i>	Distribution bucket size value (default 1)
filter	Add operation to History when...
all	Collect every operation in History
failures	Collect operations that fail in History
none	Shutoff History collection
overThreshold	Collect operations that are over threshold in History
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
lives-kept	Maximum number of history lives to collect
<i>life-size-value</i>	Life size value (default 0)

Command Mode

- /exec/configure/ip-sla/dns /exec/configure/ip-sla/fabricPathEcho

history

```
{ no | default } history { { distributions-of-statistics-kept } | { enhanced [ interval [ <interval-seconds> [ buckets [ <num-buckets> ] ] ] ] } | { hours-of-statistics-kept } | { statistics-distribution-interval } }
```

Syntax Description

Syntax Description

no	
<i>interval</i>	(Optional) buckets
<i>distributions-of-statistics-kept</i>	hours-of-statistics-kept
<i>statistics-distribution-interval</i>	
default	Set a command to its defaults
history	History and Distribution Data
enhanced	Enable enhanced history collection
<i>interval-seconds</i>	(Optional) Interval in seconds
buckets	(Optional) Number of buckets to collect data
<i>num-buckets</i>	(Optional) Number of buckets
hours-of-statistics-kept	Maximum number of statistics hour groups to capture

Command Mode

- /exec/configure/ip-sla/jitter

history

```
history { { distributions-of-statistics-kept <num-dist-stats> } | { enhanced [ interval [ <interval-seconds> [
buckets [ <num-buckets> ] ] ] ] } | { hours-of-statistics-kept <num-hours-of-stats> } | {
statistics-distribution-interval <dist-interval> } }
```

Syntax Description

Syntax Description

<i>interval</i>	(Optional) buckets
<i>num-buckets</i>	(Optional) <num-hours-of-stats>
<i>enhanced</i>	hours-of-statistics-kept
history	History and Distribution Data
distributions-of-statistics-kept	Maximum number of statistics distribution buckets to capture
<i>num-dist-stats</i>	Distribution bucket size value (default 1)
<i>interval-seconds</i>	(Optional) Interval in seconds
buckets	(Optional) Number of buckets to collect data
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
<i>num-hours-of-stats</i>	Hour groups size value (default 2)
statistics-distribution-interval	Statistics distribution interval size
<i>dist-interval</i>	Distribution interval value in msec (default 20)

Command Mode

- /exec/configure/ip-sla/jitter

history buffer

```
[no] history buffer [ { size [ <onep-historysize> [ purge <historypurge> ] ] } | { purge <historypurge> [ size <onep-historysize> ] } | { session [ <appname-str> ] } ]
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
history		One Platform history trails
buffer		In memory buffering of API history trails
session	(Optional)	Session history filter
<i>appname-str</i>	(Optional)	Full or partial session name
size	(Optional)	History buffer size in bytes
<i>onep-historysize</i>	(Optional)	Bytes (default: 32768)
purge	(Optional)	Purge the oldest or newest session history
<i>historypurge</i>	(Optional)	Purge session history

Command Mode

- /exec/configure/onep

history syslog

[no] history syslog

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
history	One Platform history trails
syslog	Enable the API history trails to syslog

Command Mode

- /exec/configure/onep

hold adjacency

hold adjacency <all>

Syntax Description

Syntax Description	hold	Hold
	adjacency	Display adjacency table
	all	Hold all adjcencies

Command Mode

- /exec

hold ip route

```
hold ip { route | rnh } [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] <all>
```

Syntax Description

Syntax Description	hold	Hold
	ip	IPv4
	route	Hold routing information
	rnh	Hold only RNH information
	vrf	(Optional) VRF
	<i>vrf-name</i>	(Optional) VRF name
	<i>vrf-known-name</i>	(Optional) Known VRF name
	vrf-all	(Optional) Display information for all VRFs
	all	Hold all routes

Command Mode

- /exec

hold ipv6 route

```
hold ipv6 route [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] <all>
```

Syntax Description

Syntax Description	hold	Hold
	ipv6	IPv6
	route	Hold routing information
	vrf	(Optional) VRF
	<i>vrf-name</i>	(Optional) VRF name
	<i>vrf-known-name</i>	(Optional) Known VRF name
	vrf-all	(Optional) Display information for all VRFs
	all	Hold all routes

Command Mode

- /exec

hold timeout

hold timeout <timeout_val>

Syntax Description

Syntax Description		
hold		Hold timer
timeout	timer	timeout
<i>timeout_val</i>		timeout duration in seconds

Command Mode

- /exec/configure/vpc-domain

holdtime

holdtime { infinite | <secs> } | no holdtime

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	holdtime	LDP session holdtime
	infinite	Ignore LDP session holdtime
	secs	Holdtime in seconds

Command Mode

- /exec/configure/ldp

hop

{ hop <val> } | { no hop }

Syntax Description

Syntax Description

no Negate a command or set its defaults

hop Configure ngoam hop count

val Configure ngoam service hop count value

Command Mode

- /exec/configure/configngoamprofile

host-reachability protocol

[no] host-reachability protocol [bgp | openflow | openflow-ir]

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
host-reachability		Configure host reachability advertisement
protocol		Control protocol to use
bgp	(Optional)	Border Gateway Protocol
openflow	(Optional)	OpenFlow
openflow-ir	(Optional)	OpenFlow-IR

Command Mode

- /exec/configure/if-nve

host-reachability protocol controller

[no] host-reachability protocol controller <controller-id>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
host-reachability	Configure host reachability advertisement
protocol	Control protocol to use
controller	Controller
<i>controller-id</i>	Controller id value

Command Mode

- /exec/configure/if-nve

hostname

{ hostname | switchname } <name> | no { hostname | switchname }

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	hostname	Configure system's host name
	switchname	Configure system's host name
	<i>name</i>	Enter switchname

Command Mode

- /exec/configure

hostname dynamic

[no] hostname dynamic

Syntax Description

Syntax Description	no (Optional) Negate a command or set its defaults
	hostname Set dynamic hostname for IS-IS
	dynamic Dynamic hostname

Command Mode

- /exec/configure/otv-isis/otv-isis-vrf-common

hostname dynamic

[no] hostname dynamic

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	hostname	Set dynamic hostname for IS-IS
	dynamic	Dynamic hostname

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

hsrp

[no] hsrp <group-id> [ipv4]

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	hsrp	HSRP interface configuration commands
	<i>group-id</i>	Group number (0-255 for HSRPv1)
	ipv4	(Optional) Configure IP Version 4 group

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp anycast

```
[no] hsrp anycast <id> { ipv4 | ipv6 | both }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hsrp	HSRP configuration commands
anycast	Anycast related commands
<i>id</i>	Bundle number
ipv4	Associate IP Version 4 for the bundle
ipv6	Associate IP Version 6 for the bundle
both	Associate IP Version 4 and 6 for the bundle

Command Mode

- /exec/configure

hsrp bfd

[no] hsrp bfd

Syntax Description

Syntax Description

no (Optional) Negate a command or set its defaults

hsrp HSRP interface configuration commands

bfd BFD protocol

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp bfd all-interfaces

[no] hsrp bfd all-interfaces

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
bfd	BFD protocol
all-interfaces	On all interfaces

Command Mode

- /exec/configure

hsrp delay minimum

hsrp delay { minimum <min-delay> | reload <reload-delay> } + | no hsrp delay [minimum | reload]

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hsrp		HSRP interface configuration commands
delay		HSRP initialisation delay
minimum		Minimum delay
reload		Delay after reload
<i>min-delay</i>	<0-10000>	Delay in seconds
<i>reload-delay</i>	<0-10000>	Delay in seconds
<i>minimum</i>		(Optional) reload

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp force state vlan

```
hsrp force state vlan { <vlans> | all }
```

Syntax Description

Syntax Description

hsrp Hot Standby Router Protocol (HSRP) information

force Move the HSRP state

state HSRP state

vlan HSRP state changes for these vlans

all Include all HSRP configured VLANs

vlans VLAN IDs of the VLAN for which state change will affect

Command Mode

- /exec

hsrp internal

[no] hsrp internal [debug-level <level>]

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hsrp	HSRP commands
internal	HSRP internal information
debug-level	(Optional) enable debug level
level	(Optional) trace level

Command Mode

- /exec

hsrp internal

[no] hsrp internal [sequence-number] [[command <id>]] [<data1>] [<data2>] [<data3>]

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hsrp		HSRP commands
internal		enable HSRP internals
sequence-number	(Optional)	enable the sequence number transmit in Hellos
command	(Optional)	Internal command specified through number
<i>id</i>	(Optional)	Internal command value
<i>data1</i>	(Optional)	Internal data 1
<i>data2</i>	(Optional)	Internal data 2
<i>data3</i>	(Optional)	Internal data 3

Command Mode

- /exec

hsrp ipv6

[no] hsrp <group-id> ipv6

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
<i>group-id</i>	Group number
ipv6	Configure IP Version 6 group

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp mac-refresh

hsrp mac-refresh [<time>] | no hsrp mac-refresh

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
hsrp		HSRP interface configuration commands
mac-refresh		Interface mac-refresh time
<i>time</i>		(Optional) Timeout value (0-10000) in sec

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp timers extended-hold

[no] hsrp timers extended-hold [<extended-hold>]

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	hsrp	HSRP interface configuration commands
	timers	Global Timers
	extended-hold	Extended Hold
	<i>extended-hold</i>	(Optional) Time in seconds

Command Mode

- /exec/configure

hsrp use-bia

[no] hsrp use-bia [scope interface]

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
use-bia	HSRP uses interface's burned in address
scope	(Optional) Specify the scope of use-bia
interface	(Optional) Use-bia applies to all groups on this interface or sub-interface

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp version 1

hsrp version { 1 | 2 } | no hsrp version

Syntax Description

Syntax Description	
no	Negate a command or set its defaults
hsrp	HSRP interface configuration commands
version	HSRP version
1	Version 1
2	Version 2

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

human

| human

Syntax Description

Syntax Description

| Pipe command output to
filter

human output in human format

Command Mode

- /output

human

| human

Syntax Description

Syntax Description

| Pipe command output to filter

human output in human format

Command Mode

- /output

hw-module logging onboard

[no] hw-module logging onboard [{ counter-stats | module <module> [{ counter-stats }] }]

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
hw-module	Enable/Disable OBFL information
logging	Enable/Disable OBFL information
onboard	Enable/Disable OBFL information
counter-stats	(Optional) Enable/Disable OBFL counter statistics
module	(Optional) Enable/Disable OBFL information for Module
<i>module</i>	(Optional) Enter module number

Command Mode

- /exec/configure

hw-module logging onboard

```
[no] hw-module logging onboard [ { environmental-history | error-stats | interrupt-stats | module <module>
[ { environmental-history | error-stats | interrupt-stats | obfl-logs | cpuhog } ] | obfl-logs | cpuhog } ]
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
hw-module		Enable/Disable OBFL information
logging		Enable/Disable OBFL information
onboard		Enable/Disable OBFL information
environmental-history	(Optional)	Enable/Disable OBFL environmental history
error-stats	(Optional)	Enable/Disable OBFL error statistics
interrupt-stats	(Optional)	Enable/Disable OBFL interrupt statistics
cpuhog	(Optional)	Enable/Disable OBFL cpu hog events
module	(Optional)	Enable/Disable OBFL information for Module
<i>module</i>	(Optional)	Enter module number
obfl-logs	(Optional)	Enable/Disable OBFL (boot-uptime/device-version/obfl-history)

Command Mode

- /exec/configure

