



P Commands

- [packet](#), on page 7
- [param-list param-list](#), on page 8
- [parity](#), on page 9
- [parity](#), on page 10
- [passive-interface default](#), on page 11
- [passive-interface default](#), on page 12
- [passive-interface default](#), on page 13
- [passive-interface default](#), on page 14
- [password](#), on page 15
- [password](#), on page 16
- [password](#), on page 17
- [password prompt username](#), on page 18
- [password secure-mode](#), on page 19
- [password strength-check](#), on page 20
- [path-option dynamic explicit identifier](#), on page 21
- [path-selection metric igp](#), on page 22
- [path-selection metric igp](#), on page 23
- [path-selection overload allow](#), on page 24
- [path](#), on page 25
- [path next-hop out-label-stack](#), on page 26
- [pathtrace nve](#), on page 27
- [pause](#), on page 29
- [pause](#), on page 30
- [pause buffer-size2 pause-threshold2 resume-threshold2](#), on page 31
- [pause priority](#), on page 32
- [payload test pattern-type pad](#), on page 33
- [peer-gateway](#), on page 34
- [peer-ip](#), on page 35
- [peer-keepalive destination](#), on page 36
- [peer-switch](#), on page 38
- [peer-type fabric](#), on page 39
- [peer-vtep](#), on page 40
- [peer ip](#), on page 41

- peer ip, on page 42
- peer ip, on page 43
- peer local service, on page 44
- peer local service, on page 45
- peer vdc service, on page 46
- peer vdc service, on page 47
- peer vpc, on page 48
- perf, on page 49
- periodic-inventory notification, on page 50
- periodic-inventory notification interval, on page 51
- periodic to, on page 52
- periodic to, on page 53
- permit interface, on page 54
- permit vlan, on page 55
- permit vrf, on page 56
- permit vsan, on page 57
- personality, on page 58
- personality backup, on page 59
- personality restore, on page 60
- phone-contact, on page 61
- ping, on page 62
- ping6, on page 64
- ping mpls, on page 65
- ping nve, on page 68
- pktmgr cache disable, on page 70
- pktmgr discard, on page 71
- pktmgr internal event-history size, on page 72
- pktmgr internal mts-queue, on page 73
- pktmgr internal span-drop enable, on page 74
- pktmgr internal span-drop enable, on page 75
- platform access-list capture, on page 76
- platform access-list fp_dnl, on page 77
- platform access-list update, on page 78
- platform fabricpath mac-learning module, on page 79
- platform forwarding interface statistics mode mpls, on page 80
- platform forwarding layer-2 fl exclude supervisor, on page 81
- platform ip verify, on page 82
- platform ipv6 verify, on page 84
- platform qos, on page 85
- platform qos, on page 86
- platform qos, on page 87
- platform qos, on page 88
- platform qos, on page 89
- platform qos, on page 90
- platform qos, on page 91
- platform qos, on page 92

- platform qos, on page 93
- platform qos, on page 94
- platform qos, on page 95
- platform qos, on page 96
- platform qos buffer peak monitor counter0 class, on page 97
- platform qos buffer peak monitor counter1 class, on page 98
- platform qos classify ns-only, on page 99
- platform qos eq, on page 100
- platform qos include ipg, on page 101
- platform qos ing, on page 102
- platform qos ing, on page 103
- platform qos mac ipg, on page 104
- platform qos ns, on page 105
- platform qos q-noise percent, on page 106
- platform rate-limiter, on page 107
- platform rate-limiter, on page 109
- platform rate-limiter access-list-log, on page 111
- platform rate-limiter span-egress, on page 112
- plb, on page 113
- plb l3-device-group, on page 114
- plb session l3-device-group, on page 115
- plb statistics, on page 116
- plugin-test load, on page 117
- plugin-test unload, on page 118
- police, on page 119
- police, on page 121
- police, on page 123
- police, on page 127
- police police pps, on page 131
- police police pps, on page 133
- policy-map, on page 135
- policy-map type control-plane, on page 136
- policy-map type network-qos, on page 137
- policy-map type psp, on page 138
- policy-map type queuing, on page 139
- policy, on page 140
- policy, on page 141
- pop, on page 142
- port-channel limit, on page 143
- port-channel load-balance, on page 144
- port-channel load-balance1 ethernet, on page 145
- port-channel load-balance2 resilient, on page 146
- port-channel load-balance ethernet, on page 147
- port-channel load-balance hash-modulo-f2, on page 148
- port-channel load-balance hash enable, on page 149
- port-channel load-balance internal, on page 150

- port-channel load-balance internal dynamic-pin, on page 151
- port-channel load-balance internal rtag7, on page 152
- port-group, on page 153
- port-group, on page 154
- port-profile, on page 155
- port-profile dump, on page 156
- port-profile no-redirect, on page 157
- port, on page 158
- port control, on page 159
- port control, on page 160
- port control, on page 161
- port destination, on page 162
- power efficient-ethernet auto, on page 163
- power efficient-ethernet sleep threshold aggressive, on page 164
- power redundancy-mode combined, on page 165
- power redundancy-mode combined force, on page 166
- power redundancy-mode insrc-redundant, on page 167
- power redundancy-mode ps-redundant, on page 168
- power reserve, on page 169
- poweroff, on page 170
- pps, on page 171
- pps, on page 172
- precision milliseconds, on page 173
- preempt, on page 174
- preempt, on page 175
- preempt, on page 176
- preempt delay minimum, on page 177
- preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt, on page 178
- prefix out, on page 180
- priority-flow-control auto-restore multiplier, on page 181
- priority-flow-control fixed-restore multiplier, on page 182
- priority-flow-control mode, on page 183
- priority-flow-control override-interface mode off, on page 184
- priority-flow-control recover interface, on page 185
- priority-flow-control tah-recover interface, on page 186
- priority-flow-control watch-dog-interval on, on page 187
- priority-flow-control watch-dog-interval on, on page 188
- priority-flow-control watch-dog internal-interface-multiplier, on page 189
- priority-flow-control watch-dog interval, on page 190
- priority-flow-control watch-dog shutdown-multiplier, on page 191
- priority, on page 192
- priority2, on page 193

- priority, on page 194
- priority, on page 195
- priority, on page 196
- priority, on page 197
- priority, on page 198
- priority, on page 199
- priority, on page 200
- private-vlan, on page 201
- private-vlan association, on page 202
- private-vlan mapping, on page 203
- private-vlan release resource, on page 204
- private-vlan synchronize, on page 205
- probe-interval, on page 206
- probe-interval, on page 207
- probe, on page 208
- probe, on page 209
- probe, on page 210
- probe, on page 211
- probe, on page 212
- probe, on page 213
- probe, on page 214
- probe, on page 215
- probe, on page 216
- probe, on page 217
- probe get, on page 218
- probe get, on page 219
- probe get, on page 220
- probe get, on page 221
- probe get, on page 222
- probe get, on page 223
- probe host, on page 224
- probe host, on page 225
- probe host, on page 226
- probe host, on page 227
- probe host, on page 228
- probe host, on page 229
- probe host, on page 230
- probe host, on page 231
- probe host, on page 232
- probe port, on page 233
- probe port, on page 234
- probe port, on page 235
- probe port, on page 236
- probe port, on page 237
- probe port, on page 238
- probe port, on page 239

- probe port, on page 240
- probe port, on page 241
- promiscuous-mode off, on page 242
- propagate-sgt, on page 243
- protection, on page 244
- protocol-version, on page 245
- protocol-version, on page 246
- protocol, on page 247
- protocol shutdown, on page 248
- protocol shutdown, on page 249
- ptp, on page 250
- ptp announce interval, on page 251
- ptp announce timeout, on page 252
- ptp delay-request minimum interval, on page 253
- ptp domain, on page 254
- ptp offload, on page 255
- ptp priority1, on page 256
- ptp priority2, on page 257
- ptp source, on page 258
- ptp sync interval, on page 259
- ptp time-sync, on page 260
- ptp transport ipv4 ucast master, on page 261
- ptp transport ipv4 ucast slave, on page 262
- ptp ucast-source, on page 263
- ptp vlan, on page 264
- publish-event sub-system type, on page 265
- purge ip route, on page 266
- purge ipv6 route, on page 267
- purge module running-config, on page 268
- push, on page 269
- pwd, on page 270
- python, on page 271
- python execute virtual-service command, on page 272
- python instance, on page 273

packet

{ packet <hex-string> } | { no packet }

Syntax Description

Syntax Description

no Negate a command or set its defaults

packet Provide flow details starting with ethernet header in hex-string format: 0A1B
 ..

hex-string Specify flow and payload in hex string format: 0A1B..

Command Mode

- /exec/configure/configngoamprofileflow

param-list param-list

[no] param-list <plistname> [cross-check] | param-list <plistname>

Syntax Description

Syntax Description

no (Optional) Negate a command or set its defaults

param-list Configure a parameter list

plistname Enter the name of the parameter list

cross-check (Optional) Explicitly search for referencing config profile

Command Mode

- /exec/configure

parity

[no] parity { even | none | odd }

Syntax Description

Syntax Description	no (Optional) Negate a command or set its defaults
	parity Set terminal parity
	even Even parity
	none No parity
	odd Odd parity

Command Mode

- /exec/configure/com1

parity

[no] parity { even | none | odd }

Syntax Description

Syntax Description	no (Optional) Negate a command or set its defaults
	parity Set terminal parity
	even Even parity
	none No parity
	odd Odd parity

Command Mode

- /exec/configure/console

passive-interface default

[no] passive-interface default

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

passive-interface default

[no] passive-interface default <level>

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	passive-interface	Suppress IS-IS PDU
	default	Undo a command
	<i>level</i>	IS-IS level

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

passive-interface default

[no] passive-interface default

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

passive-interface default

[no] passive-interface default

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

password

password <password-string> | { no | default } password [<password-string>]

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
default		Inherit values from a peer template
password		Configure a password for neighbor
<i>password-string</i>		Neighbor password

Command Mode

- /exec/configure/router-bgp/router-bgp-template-neighbor
- /exec/configure/router-bgp/router-bgp-neighbor-stmp /exec/configure/router-bgp/router-bgp-neighbor
- /exec/configure/router-bgp/router-bgp-vrf-neighbor /exec/configure/router-bgp/router-bgp-prefixneighbor
- /exec/configure/router-bgp/router-bgp-vrf-prefixneighbor

password

```
password [ vrf { <vrf-name> | <vrf-known-name> } ] { required [ req-for <req-pfx-list> ] | { fallback | option
<seq-num> opt-for <opt-pfx-list> } { key-chain <name> } } | no password [ vrf { <vrf-name> |
<vrf-known-name> } ] { required | fallback | option <seq-num> }
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
password	Configure LDP password
vrf	(Optional) VRF Routing/Forwarding instance information
<i>vrf-name</i>	(Optional) VPN Routing/Forwarding instance name
<i>vrf-known-name</i>	(Optional) Known VRF name
required	Password is required for the peer
req-for	(Optional) Prefix list specifying control on LDP peers
<i>req-pfx-list</i>	(Optional) Prefix list for LDP peers
fallback	Specifies a fallback password will follow
option	LDP password option
<i>seq-num</i>	Sequence number of the LDP password option
opt-for	Prefix list specifying control on LDP peers
<i>opt-pfx-list</i>	Prefix list for LDP peers
key-chain	Specifies a key-chain name will follow
<i>name</i>	Key-chain name

Command Mode

- /exec/configure/ldp

password

{ [no] password <passwd> }

Syntax Description

Syntax Description

password password

passwd password

Command Mode

- /exec/configure/dot1x-cred

password prompt username

[no] password prompt username

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	password	Password for the user
	prompt	Enable prompt for password
	username	Enable prompt for password on username command

Command Mode

- /exec/configure

password secure-mode

[no] password secure-mode

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	password	Password for the user
	secure-mode	Enable secure mode for changing password

Command Mode

- /exec/configure

password strength-check

[no] password strength-check

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
password	Password for the user
strength-check	Strength check of password

Command Mode

- /exec/configure

path-option dynamic explicit identifier

```
[no] path-option [ protect ] <pref> | path-option <pref> dynamic [ attributes <attr-name> | { bandwidth <kbps> | lockdown } + ] | path-option [ protect ] <pref> explicit { identifier <id-num> | name <name> } [ { attributes <attr-name> [ verbatim ] | { bandwidth <kbps> | lockdown | verbatim } + } ]
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
path-option	a primary or fallback path setup option
protect	(Optional) a path protection setup option
<i>pref</i>	preference for this path option
dynamic	setup based on dynamically calculated path
explicit	setup based on preconfigured path
identifier	Specify an IP explicit path by number
<i>id-num</i>	Number of ip explicit path
name	Specify an IP explicit path by name
<i>name</i>	Name of ip explicit path
attributes	(Optional) Specify an LSP attribute list
<i>attr-name</i>	(Optional) Name of LSP attribute list
verbatim	(Optional) send out path as is, with no checking
bandwidth	(Optional) override the bandwidth configured on the tunnel
<i>kbps</i>	(Optional) bandwidth requirement in kbps
lockdown	(Optional) not a candidate for reoptimization
<i>kbps</i>	(Optional) bandwidth requirement in kbps
lockdown	(Optional) not a candidate for reoptimization

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

path-selection metric igp

path-selection metric { igp | te } | no path-selection metric

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	path-selection	Path Selection Configuration
	metric	Metric Type Configuration
	igp	Use IGP metric
	te	Use TE metric (*Default)

Command Mode

- /exec/configure/te

path-selection metric igp

[no] path-selection metric | path-selection metric { igp | te }

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
path-selection		Path Selection Configuration
metric		Metric type for path calculation
igp		Use IGP Metric
te		Use TE Metric

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

path-selection overload allow

[no] path-selection overload allow | path-selection overload allow { head [middle] [tail] | middle [tail] | tail }

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
path-selection		Path Selection Configuration
overload		Overload Node Configuration
allow		Allow overloaded nodes in CSPFs
head		Allow overloaded head node in TE CSPF
middle		(Optional) Allow overloaded middle node in TE CSPF
tail		(Optional) Allow overloaded tail node in TE CSPF

Command Mode

- /exec/configure/te

path

path <dn> [depth { 0 | 1 | unbounded }] [filter-condition <filter>] | no path <dn>

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
path		Create a sensor path
depth		(Optional) Specify a retrieval depth
filter-condition		(Optional) Specify a filter condition
<i>dn</i>		Distinguished Name
0		(Optional) Retrieval depth (0)
1		(Optional) Retrieval depth (1)
unbounded		(Optional) Retrieve entire tree
<i>filter</i>		(Optional) Filter Condition

Command Mode

- /exec/configure/telemetry/sensor-group

path next-hop out-label-stack

```
{ no path <path-num> | path <path-num> next-hop <next-hop> out-label-stack { <static-outlabel> + |
implicit-null } }
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
path		Configure an outgoing path for the LSP
<i>path-num</i>		Path identifier
next-hop		Nexthop
<i>next-hop</i>		Destination IPv4 next hop
out-label-stack		Series of output labels
<i>static-outlabel</i>		Label Value
implicit-null		IETF MPLS implicit null label (3)

Command Mode

- /exec/configure/mpls_static/ipv4/lsp/inlabel/forw

pathtrace nve

```
pathtrace nve { { { ip { <numeric10> | unknown } } [ vrf { <vrf-name> | <vrf-known-name> } ] { <dot1qid1>
} } } | mac <dmac> <dot1qid> <intfid> } [ profile <pid> ] [ payload { [ mac-addr <dstmac> <smac> ] [ dot1q
<dot1q-id> ] [ ip <dstip> <srcip> | ipv6 <dstip6> <srcip6> ] [ port <sport> <dport> ] [ proto <proto-id> ]
[ src-intf <src_if> ] } payload-end ] [ copy-to <copy-to-ip> [ ext-id <ext_id> ] ] [
```

Syntax Description

Syntax Description

pathtrace	Test
nve	network virtualization edge
<i>numeric10</i>	Peer vtep ip address
unknown	Peer vtep ip is unknown, will be derived from payload
<i>intfid</i>	Name of the interface for ngoam pathtrace on which dot1q is configured
payload	(Optional) Enter customer payload
mac-addr	(Optional) Mac
<i>dstmac</i>	(Optional) Destination mac address
<i>smac</i>	(Optional) Source mac address
dot1q	(Optional) Encapsulation dot1q/bd
<i>dot1q-id</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
ip	ip address
<i>dstip</i>	(Optional) Destination ipv4 address
<i>srcip</i>	(Optional) source ipv4 address
ipv6	(Optional) ipv6 address
port	(Optional) L4 port info
<i>sport</i>	(Optional) Source port
<i>dport</i>	(Optional) Destination port
proto	(Optional) Protocol
<i>proto-id</i>	(Optional) IANA Protocol id
src-intf	(Optional) Interface on which the host with src ip of the payload is connected
<i>src_if</i>	(Optional) Interface
payload-end	(Optional) End payload info input

<i>profile</i>	(Optional) NGOAM profile to use
<i>pid</i>	(Optional) NGOAM profile id
<i>mac</i>	Mac
<i>dmac</i>	Destination mac address
<i>dot1qid</i>	Encapsulation dot1q/bd on which the mac is learnt
<i>dot1qid1</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
<i>vrf</i>	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>copy-to</i>	(Optional) Send responses to this IP over mgmt vrf instead
<i>copy-to-ip</i>	(Optional) IPv4 addr to send responses to
<i>ext-id</i>	(Optional) Identifier passed from caller
<i>ext_id</i>	(Optional) 32-bit identifier

Command Mode

- /exec

pause

[no] pause { buffer-size <size-in-bytes> pause-threshold <xoff-bytes> resume-threshold <xon-bytes> }

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
pause		PAUSE characteristics (CBFC)
buffer-size		Ingress buffer size in bytes
pause-threshold		Buffer limit for pausing in bytes
resume-threshold		Buffer limit at which to resume in bytes

Command Mode

- /exec/configure/policy-map/type/queuing/class

pause

```
[no] pause { no-drop | { delayed-drop <timeout> } | { [ buffer-size <size-in-bytes> pause-threshold <xoff-bytes>
resume-threshold <xon-bytes> ] pfc-cos <pfc-cos-list> } }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
pause		PAUSE charecteristics (CBFC)
no-drop		NO-DROP
delayed-drop		Enable delayed-drop for the CoS
<i>timeout</i>		Timer value for delayed drop
buffer-size	(Optional)	Ingress buffer size in bytes
pause-threshold	(Optional)	Buffer limit for pausing in bytes
resume-threshold	(Optional)	Buffer limit at which to resume in bytes
pfc-cos		CoS values to assert PFC on
<i>pfc-cos-list</i>		List of class-of-service values

Command Mode

- /exec/configure/policy-map/type/uf/class

pause buffer-size2 pause-threshold2 resume-threshold2

[no] pause buffer-size2 <size-in-bytes> pause-threshold2 <xoff-bytes> resume-threshold2 <xon-bytes>

Syntax Description

Syntax Description		
no	(Optional) Negate a command or set its defaults	
pause	PAUSE characteristics (CBFC)	
buffer-size2	Ingress buffer size in bytes	
pause-threshold2	Buffer limit for pausing in bytes	
resume-threshold2	Buffer limit at which to resume in bytes	

Command Mode

- /exec/configure/policy-map/type/queuing/class

pause priority

[no] pause { priority-group <priority-group-number> }

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
pause		PAUSE characteristics (CBFC)
priority-group	ingress	priority-group to which the traffic is mapped and pause limits are applied
<i>priority-group-number</i>		Priority group value

Command Mode

- /exec/configure/policy-map/type/queuing/class

payload test pattern-type pad

{ payload { test pattern-type <test-id> | pad <pad-val> } } | { no payload { test pattern-type | pad } }

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
payload		Configure ngoam payload
test		Configure ngoam payload test
pattern-type		Configure ngoam payload test pattern
<i>test-id</i>		Configure ngoam payload test pattern id
pad		Configure ngoam payload test pattern pad
<i>pad-val</i>		Configure ngoam payload test pad value

Command Mode

- /exec/configure/configngoamprofile

peer-gateway

peer-gateway [exclude-vlan <vlan-list>] | no peer-gateway

Syntax Description

Syntax Description	
no	Negate a command or set its defaults
peer-gateway	Enable L3 forwarding for packets destined to peer's gateway mac-address
exclude-vlan	(Optional) Specify VLANs to be excluded from peer-gateway functionality
<i>vlan-list</i>	(Optional) Specify the list of vlans

Command Mode

- /exec/configure/vpc-domain

peer-ip

[no] peer-ip <addr>

Syntax Description

Syntax Description	<i>no</i> (Optional) Negate a command or set its defaults
	<i>peer-ip</i> Static IP Address Configuration
	<i>addr</i> Remote Peer IP Address

Command Mode

- /exec/configure/if-nve/vni/ingr-rep

peer-keepalive destination

```
peer-keepalive destination <dst-ip> [ [ source <src-ip> | udp-port <udp-port-num> | vrf { <vrf-name> |
<vrf-known-name> } | { interval <interval-ms> timeout <time-out> } | tos-byte <tos-byte-value> | hold-timeout
<hold-time-out> ] + | [ source <src-ip> | udp-port <udp-port-num> | vrf { <vrf-name> | <vrf-known-name>
} | { interval <interval-ms> timeout <time-out> } | tos { <tos-value> | min-delay | max-throughput |
max-reliability | min-monetary-cost | normal } | hold-timeout <hold-time-out> ] + | [ source <src-ip> | udp-port
<udp-port-num> | vrf { <vrf-name> | <vrf-known-name> } | { interval <interval-ms> timeout <time-out> } |
precedence { <prec-vlaue> | network | internet | critical | flash-override | flash | immediate | priority | routine
} | hold-timeout <hold-time-out> ] + ]
```

Syntax Description

Syntax Description

peer-keepalive	Keepalive>Hello with peer switch
destination	specify destination ip address of peer switch
<i>dst-ip</i>	IPv4 address (A.B.C.D) of destination
source	(Optional) source interface for hello
<i>src-ip</i>	(Optional) IPv4 address (A.B.C.D) of source
udp-port	(Optional) enter UDP port number used for hello
<i>udp-port-num</i>	(Optional) udp port number for hellos
vrf	(Optional) vrf to be used for hello messages
<i>vrf-name</i>	(Optional) vrf to be used for hellos
<i>vrf-known-name</i>	(Optional) Known VRF name
interval	(Optional) enter interval in milleseconds
<i>interval-ms</i>	(Optional) Enter interval in milleseconds
timeout	(Optional) enter timeout in seconds
<i>time-out</i>	(Optional) enter timeout in seconds
precedence	(Optional) Precedence
<i>prec-vlaue</i>	(Optional) Precedence value
network	(Optional) network (7)
internet	(Optional) internet (6)
critical	(Optional) critical (5)
flash-override	(Optional) flash-override (4)
flash	(Optional) flash (3)

immediate	(Optional) immediate (2)
priority	(Optional) priority (1)
routine	(Optional) routine (0)
tos	(Optional) Type of Service
<i>tos-value</i>	(Optional) Enter 4-bit TOS value
min-delay	(Optional) min-delay (8)
max-throughput	(Optional) max-throughput (4)
max-reliability	(Optional) max-reliability (2)
min-monetary-cost	(Optional) min-monetary-cost (1)
normal	(Optional) normal (0)
tos-byte	(Optional) Type of Service Byte
<i>tos-byte-value</i>	(Optional) Enter 8-bit TOS value
hold-timeout	(Optional) hold timeout to ignore stale peer alive messages
<i>hold-time-out</i>	(Optional) Enter hold-timeout in seconds

Command Mode

- /exec/configure/vpc-domain

peer-switch

[no] peer-switch

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	peer-switch	Enable peer switch on vPC pair switches

Command Mode

- /exec/configure/vpc-domain

peer-type fabric

peer-type { fabric-external | fabric-border-leaf } | { no | default } peer-type

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
default		Inherit values from a peer template
peer-type		Neighbor facing
fabric-external		Fabric external
fabric-border-leaf		Fabric Border Leaf

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor-sess

peer-vtep

[no] peer-vtep <addr>

Syntax Description

Syntax Description	<i>no</i>	(Optional) Negate a command or set its defaults
	<i>peer-vtep</i>	Configure tunnel End Point
	<i>addr</i>	Remote VTEP IP Address

Command Mode

- /exec/configure/if-nve/vni

peer ip

[no] peer ip <ip-addr>

Syntax Description

Syntax Description

no (Optional) Negate a command or set its defaults

peer ITD peer

ip ITD peer ip

ip-addr NICE node IP prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-inout

peer ip

[no] peer ip <ip-addr>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
peer	ITD peer
ip	ITD peer ip
<i>ip-addr</i>	NICE node IP prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-inout

peer ip

[no] peer ip <ip-addr>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
peer	PLB peer
ip	PLB peer ip
<i>ip-addr</i>	NICE node IP prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-inout

peer local service

[no] peer local service <service-name>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
peer		Peer cli for sandwich mode failure notification
local		Peer involved in sandwich mode
service		Peer service involved in sandwich mode
<i>service-name</i>		Peer service name string

Command Mode

- /exec/configure/itd

peer local service

[no] peer local service <service-name>

Syntax Description

Syntax Description		
	no	(Optional) Negate a command or set its defaults
	peer	Peer cli for sandwich mode failure notification
	local	Peer involved in sandwich mode
	service	Peer service involved in sandwich mode
	<i>service-name</i>	Peer service name string

Command Mode

- /exec/configure/plb

peer vdc service

[no] peer vdc <vdc-id> service <service-name>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
peer		Peer cli for sandwich mode failure notification
vdc		Peer VDC involved in sandwich mode
service		Peer service involved in sandwich mode
<i>vdc-id</i>		VDC name of peer VDC
<i>service-name</i>		Peer service name string

Command Mode

- /exec/configure/itd

peer vdc service

[no] peer vdc <vdc-id> service <service-name>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
peer		Peer cli for sandwich mode failure notification
vdc		Peer VDC involved in sandwich mode
service		Peer service involved in sandwich mode
<i>vdc-id</i>		VDC name of peer VDC
<i>service-name</i>		Peer service name string

Command Mode

- /exec/configure/itd

peer vpc

[no] peer <svc-name> vpc <num>

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	peer	smart channel peer
	vpc	vpc
	<i>svc-name</i>	peer smart channel name
	<i>num</i>	VPC number to assign to smart-channel

Command Mode

- /exec/configure/smartc

perf

```
perf [ { record { context-switch | profile } { system | process <i0> } [ <s1> ] } | { stop { all | <s0> } } | { list
} | { create-archive <s2> } | { remove { all | <s3> } } ]
```

Syntax Description

Syntax Description

perf	Run perf tool to collect or process event data
record	(Optional) Record events to a file for later analysis
stop	(Optional) Stop a perf record.
list	(Optional) List recorded datasets
create-archive	(Optional) Create an archive of dataset for download
remove	(Optional) Remove recorded dataset(s)
all	(Optional) Act on all recorded datasets
context-switch	(Optional) Record context-switch events
profile	(Optional) Record periodic runtime samples
system	(Optional) Record events for all processes on all CPUS
process	(Optional) Record events for a specific process with the given pid
<i>i0</i>	(Optional) pid of process to record events
<i>s0</i>	(Optional) id of perf record session to stop
<i>s1</i>	(Optional) id to use for perf record session
<i>s2</i>	(Optional) id of perf dataset to create an archive
<i>s3</i>	(Optional) id of perf dataset to remove

Command Mode

- /exec

periodic-inventory notification

[no] periodic-inventory notification

Syntax Description

Syntax Description

no (Optional) Negate a command or set its defaults

periodic-inventory Configure periodic software inventory message dispatch

notification Enable periodic software inventory message dispatch

Command Mode

- /exec/configure/callhome

periodic-inventory notification interval

```
periodic-inventory notification { interval <i0> | timeofday <s0> }
```

Syntax Description

Syntax Description

periodic-inventory	Configure periodic software inventory message dispatch
notification	Enable periodic software inventory message dispatch
interval	Configure the time period for periodic inventory
<i>i0</i>	Time period in days (default is 7 days)
timeofday	Configure the timeofday for periodic inventory in HH:MM format
<i>s0</i>	Time period in HH:MM format

Command Mode

- /exec/configure/callhome

periodic to

{ [<seqno>] | no } periodic { { Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday } +
| daily | weekdays | weekend } <stime> to <etime>

Syntax Description

Syntax Description		
<i>seqno</i>	(Optional) Sequence number	
no	Negate a command or set its defaults	
periodic	Periodic time and date	
Monday	Monday	
Tuesday	Tuesday	
Wednesday	Wednesday	
Thursday	Thursday	
Friday	Friday	
Saturday	Saturday	
Sunday	Sunday	
daily	Every day of the week	
weekdays	Monday thru Friday	
weekend	Saturday and Sunday	
<i>stime</i>	Starting time	
to	Ending day and time	
<i>etime</i>	Ending time	

Command Mode

- /exec/configure/timerange

periodic to

```
{ [ <seqno> ] | no } periodic { Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday }
<stime> to { <eday> } <etime>
```

Syntax Description

Syntax Description		
<i>seqno</i>	(Optional) Sequence number	
<i>no</i>	Negate a command or set its defaults	
<i>periodic</i>	Periodic time and date	
<i>Monday</i>	Monday	
<i>Tuesday</i>	Tuesday	
<i>Wednesday</i>	Wednesday	
<i>Thursday</i>	Thursday	
<i>Friday</i>	Friday	
<i>Saturday</i>	Saturday	
<i>Sunday</i>	Sunday	
<i>eday</i>	Day of the week	
<i>stime</i>	Starting time	
<i>to</i>	Ending day and time	
<i>etime</i>	Ending time	

Command Mode

- /exec/configure/timerange

permit interface

[no] permit interface <if0>

Syntax Description

Syntax Description

no (Optional) Negate a command or set its defaults

permit Permit access to interfaces (applicable if interface policy is 'deny')

interface Enter the range of interfaces accessible the role

if0 Enter the interface range

Command Mode

- /exec/configure/role/interface

permit vlan

[no] permit vlan <vlan-mrange>

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to vlans (applicable if vlan policy is 'deny')
vlan	Enter the range of vlans accessible the role
<i>vlan-mrange</i>	Enter the vlan range

Command Mode

- /exec/configure/role/vlan

permit vrf

[no] permit vrf <vrf-name>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
permit	Permit access to vrf (applicable if vrf policy is 'deny')
vrf	Enter the range of vrf accessible the role
<i>vrf-name</i>	Enter the vrf name

Command Mode

- /exec/configure/role/vrf

permit vsan

[no] permit vsan <vsan-mrange>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
permit	Permit access to vsans (applicable if vsan policy is 'deny')
vsan	Enter the range of vsans accessible the role
<i>vsan-mrange</i>	Enter the vsan range

Command Mode

- /exec/configure/role/vsan

personality

[no] personality

Syntax Description

Syntax Description	no	(Optional) Negate a mode
---------------------------	----	--------------------------

personality	Config Personality
-------------	--------------------

Command Mode

- /exec/configure

personality backup

```
personality backup { <uri_local> | <uri_remote> [ password <password> ] [ vrf <vrf-known-name> ] }
```

Syntax Description

Syntax Description		
personality	personality	
backup	backup personality	
password	(Optional) The password for personality backups	
vrf	(Optional) The VRF for personality backups	
<i>uri_local</i>	Personality backup local destination	
<i>uri_remote</i>	Personality backup remote destination	
<i>password</i>	(Optional) Password for SCP username	
<i>vrf-known-name</i>	(Optional) VRF name	

Command Mode

- /exec

personality restore

```
personality restore <uri> [ user-name <user> ] [ password <password> ] [ hostname <hostname> ] [ vrf
<vrf_name> ]
```

Syntax Description

Syntax Description

<i>personality</i>	Personality
<i>restore</i>	Restore the personality file
<i>uri</i>	Personality file
<i>user-name</i>	(Optional) The username for downloads
<i>user</i>	(Optional) The username
<i>password</i>	(Optional) The password for downloads
<i>password</i>	(Optional) The password
<i>hostname</i>	(Optional) The hostname for downloads
<i>hostname</i>	(Optional) The hostname
<i>vrf</i>	(Optional) The VRF for downloads
<i>vrf_name</i>	(Optional) The VRF name

Command Mode

- /exec

phone-contact

{ phone-contact <s0> | no phone-contact }

Syntax Description

Syntax Description

no Negate a command or set its defaults

phone-contact Contact person's phone number

s0 Phone number in international format(such as +1-800-123-4567)

Command Mode

- /exec/configure/callhome

ping

```
ping [ { { <alpha> | <numeric> [ loopback interface <interface> ] } | { multicast <group> interface <interface>
[ loopback ] } } [ [ source-interface <src-intf> | vrf { <vrf-name> | <vrf-known-name> } ] [ count { <count>
| unlimited } | packet-size <packetsize> | vrf { <vrf-name> | <vrf-known-name> } | interval <interval> | source
{ <alpha> | <numeric1> } | df-bit | timeout <timeout> } + [ count { <count> | unlimited } | packet-size
<packetsize> | source-interface <src-intf> | interval <interval> | df-bit | timeout <timeout> } + ] ]
```

Syntax Description

Syntax Description

ping	Test
count	(Optional) Number
unlimited	(Optional) Unlimited
<i>count</i>	(Optional) Number
packet-size	(Optional) Packet
<i>packetsize</i>	(Optional) Size
source-interface	(Optional) Select source interface
<i>src-intf</i>	(Optional) Specify interface
interval	(Optional) Wait
<i>interval</i>	(Optional) Interval
<i>numeric</i>	(Optional) IP address of remote system
<i>numeric1</i>	(Optional) IP
<i>alpha</i>	(Optional) Enter
multicast	(Optional) Multicast
<i>group</i>	(Optional) Multicast
interface	(Optional) Interface
<i>interface</i>	(Optional) Interface
loopback	(Optional) Receive
source	(Optional) Source
df-bit	(Optional) Enable
timeout	(Optional) Specify
<i>timeout</i>	(Optional) Timeout

<code>vrf</code>	(Optional) Display per-VRF information
<code>vrf-name</code>	(Optional) VRF name
<code>vrf-known-name</code>	(Optional) Known VRF name

Command Mode

- /exec

ping6

```
ping6 { { <host> | <hostname> } | { multicast <group> } } [ [ { count { <count> | unlimited } } | { packet-size
<packetsize> } | [ source { <host1> | <hostname> } ] | vrf { <vrf-name> | <vrf-known-name> } | timeout
<timeout> | { interval <interval> } ] + [ [ { count { <count> | unlimited } } | { packet-size <packetsize> } | {
source-interface <src-intf> } | timeout <timeout> | { interval <interval> } ] + ]
```

Syntax Description

Syntax Description

ping6	Test
count	(Optional) Number
<i>count</i>	(Optional) Number
unlimited	(Optional) unlimited
packet-size	(Optional) Packet
<i>packetsize</i>	(Optional) Size
source-interface	(Optional) Select source interface
<i>src-intf</i>	(Optional) Specify interface
interval	(Optional) Wait
<i>interval</i>	(Optional) Interval
<i>hostname</i>	Enter
multicast	Multicast
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
source	(Optional) Source
timeout	(Optional) Specify
<i>timeout</i>	(Optional) Timeout

Command Mode

- /exec

ping mpls

```
ping mpls { nil-fec labels <comma-separated-labels> } { output { ointerface <tx-interface> } nexthop
<nexthop-ip-addr> } [ { repeat <count> } | { size <size> } | { sweep <min-size> <max-size> <increment>
} } | { timeout <seconds> } | { interval <milliseconds> } | { destination <addr-start> [ <addr-end> [
<addr-incr-mask> | <addr-incr> ] ] } | { source <addr> } | { exp <exp-value> } | { pad <pattern> } | { ttl <ttl>
} | { verbose } | { reply { { mode { <reply-mode-ipv4> | router-alert | control-channel | no-reply } } | { dscp
{ <dscp-bits> | af11 | af12 | af13 | af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4
| cs5 | cs6 | cs7 | default | ef } } | { pad-tlv } } } + | { force-explicit-null } | { dsmap [ hashkey { none |
hash-ipv4 { bitmap <bitmap-size> } } } ] } | { flags { fec } } ] +
```

Syntax Description

Syntax Description

ping	need
mpls	Test
nil-fec	Target
labels	A
<i>comma-separated-labels</i>	A
repeat	(Optional) Repeat
<i>count</i>	(Optional) Repeat
size	(Optional) Packet
<i>size</i>	(Optional) Datagram
sweep	(Optional) Sweep
<i>min-size</i>	(Optional)
<i>max-size</i>	(Optional)
<i>increment</i>	(Optional) Sweep
timeout	(Optional) Timeout
<i>seconds</i>	(Optional) Timeout
interval	(Optional) Send
<i>milliseconds</i>	(Optional) Send
destination	(Optional) Destination
<i>addr-start</i>	(Optional) Destination
<i>addr-end</i>	(Optional) Destination
<i>addr-incr-mask</i>	(Optional) Destination

<i>addr-incr</i>	(Optional) Destination
source	(Optional) Source
<i>addr</i>	(Optional) Source
exp	(Optional) EXP
<i>exp-value</i>	(Optional) EXP
pad	(Optional) Pad
<i>pattern</i>	(Optional) Pad
ttl	(Optional) Time
<i>ttl</i>	(Optional) TTL
verbose	(Optional) verbose
reply	(Optional) Reply
mode	(Optional) Reply
reply-mode-ipv4	(Optional) Send
router-alert	(Optional) Send
control-channel	(Optional) Send
no-reply	(Optional) Send
dscp	(Optional) DSCP
<i>dscp-bits</i>	(Optional) Differentiated
af11	(Optional) Match
af12	(Optional) Match
af13	(Optional) Match
af21	(Optional) Match
af22	(Optional) Match
af23	(Optional) Match
af31	(Optional) Match
af32	(Optional) Match
af33	(Optional) Match
af41	(Optional) Match

af42	(Optional) Match
af43	(Optional) Match
cs1	(Optional) Match
cs2	(Optional) Match
cs3	(Optional) Match
cs4	(Optional) Match
cs5	(Optional) Match
cs6	(Optional) Match
cs7	(Optional) Match
default	(Optional) Match
ef	(Optional) Match
pad-tlv	(Optional) Reply
force-explicit-null	(Optional) Force
output	Output
ointerface	Echo
<i>tx-interface</i>	Echo
nexthop	Next
<i>nexthop-ip-addr</i>	Next
dsmap	(Optional) Request
hashkey	(Optional) Downstream
none	(Optional) Hash
hash-ipv4	(Optional) IPv4
bitmap	(Optional) Hash
<i>bitmap-size</i>	(Optional) Multipath
flags	(Optional) Flag
fec	(Optional) Request

Command Mode

- /exec

ping nve

```
ping nve { { { { ip { <numeric10> | <numeric11> | unknown } } [ vrf { <vrf-name> | <vrf-known-name>
} | { <dot1qid1> } ] } | mac <dmac> <dot1qid> <intfid> } [ profile <pid> ] } [ payload { [ mac-addr <dstmac>
<smac> ] [ dot1q <dot1q-id> ] [ ip <dstip> <srcip> | ipv6 <dstipv6> <srcipv6> ] [ port <sport> <dport> ] [
proto <proto-id> ] [ src-intf <src_if> ] } payload-end ] [ source { <numeric1> | <numeric2> } |
```

Syntax Description

Syntax Description	
{	<count>
ping	Test
nve	network virtualization edge
<i>numeric10</i>	Ipv4 address of remote host / VTEP
unknown	Peer vtep ip is unknown, Applicable only for channel Nv03
<i>dot1qid</i>	Encapsulation dot1q/bd on which the mac is learnt
<i>intfid</i>	Name of the interface for ngoam ping on which dot1q is configured
payload	(Optional) Enter customer payload
port	(Optional) L4 port info
<i>sport</i>	(Optional) Source port
<i>dport</i>	(Optional) Destination port
proto	(Optional) Protocol
<i>proto-id</i>	(Optional) IANA Protocol id
src-intf	(Optional) Interface on which the host with src ip of the payload is connected
<i>src_if</i>	(Optional) Interface
payload-end	(Optional) End of payload info
profile	(Optional) NGOAM profile to use
<i>pid</i>	(Optional) NGOAM profile id
mac	Mac
mac-addr	(Optional) Mac
ip	ip address
<i>dstip</i>	(Optional) Destination ipv4 address
<i>srcip</i>	(Optional) source ipv4 address

<i>ipv6</i>	(Optional) ipv6 address
<i>dmac</i>	Destination mac address
<i>dstmac</i>	(Optional) Destination mac address
<i>smac</i>	(Optional) Source mac address
<i>dot1q</i>	(Optional) Encapsulation dot1q/bd
<i>dot1q-id</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
<i>dot1qid1</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
<i>vrf</i>	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>source</i>	(Optional) Source
<i>numeric1</i>	(Optional) IP

Command Mode

- /exec

pktmgr cache disable

{ [no] pktmgr cache disable }

Syntax Description

Syntax Description	no (Optional) Negate a command or set its defaults
	pktmgr packet manager
	cache Disable cache
	disable Disable cache

Command Mode

- /exec/configure

pktmgr discard

```
{ [ no ] pktmgr discard [ type <type> ] [ direction <direction> ] [ detail ] }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
pktmgr	packet manager
discard	discard CPI-bound output packets
detail	(Optional) detailed discard info
direction	(Optional) pm debug-filter direction
<i>direction</i>	(Optional) pm direction
type	(Optional) Driver type
<i>type</i>	(Optional) Driver type

Command Mode

- /exec

pktmgr internal event-history size

```
[no] pktmgr internal event-history { errors | control | log | ha | pkt-errors | pkt-buffer } size { <size_in_text>
| <size_in_Kbytes> }
```

Syntax Description

Syntax Description		
no	(Optional) Negate a command or set its defaults	
internal	Commands for internal use	
pktmgr	Display Packet Manager information	
event-history	various event logs of Pktmgr	
errors	error logs of Pktmgr	
control	control message of Pktmgr	
log	syslog message of Pktmgr	
ha	ha debug message of Pktmgr	
pkt-errors	pkt error message of Pktmgr	
pkt-buffer	pkt buffers message of Pktmgr	
size	Configure the size of the event-hist buffer	
<i>size_in_text</i>	Buffer size	
<i>size_in_Kbytes</i>	Size of the file in kbytes	

Command Mode

- /exec

pktmgr internal mts-queue

{ pktmgr internal mts-queue <size> } | { no pktmgr internal mts-queue }

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	pktmgr	Display Packet Manager information
	internal	Commands for internal use
	mts-queue	mts-queue
	size	Size for pktmgr data sap qlimit

Command Mode

- /exec/configure

pktmgr internal span-drop enable

[no] pktmgr internal span-drop { enable | disable }

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
pktmgr	Display Packet Manager information
internal	Commands for internal use
span-drop	Enable/Disable span to sup packet drops
enable	Enable span to sup packet drops
disable	Dsiable span to sup packet drops

Command Mode

- /exec

pktmgr internal span-drop enable

[no] pktmgr internal span-drop { enable | disable }

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	pktmgr	Display Packet Manager information
	internal	Commands for internal use
	span-drop	Enable/Disable span to sup packet drops
	enable	Enable span to sup packet drops
	disable	Dsiable span to sup packet drops

Command Mode

- /exec

platform access-list capture

[no] { platform | hardware } access-list capture

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	platform	Platform configuration commands
	hardware	Hardware Internal Information
	access-list	Access Control List
	capture	Configure ACL capture

Command Mode

- /exec/configure

platform access-list fp_dnl

[no] { platform | hardware } access-list fp_dnl

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	platform	Platform configuration commands
	hardware	Hardware Internal Information
	access-list	Access control list
	fp_dnl	Fabric path - do not learn mac from broadcast

Command Mode

- /exec/configure

platform access-list update

```
[no] { platform | hardware } access-list update { { atomic [ strict ] } | { default-result permit } }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
access-list	Access Control List
update	Configure atomic/non-atomic update and default-result
atomic	Enable atomic update of access-list in hardware
strict	(Optional) Strict check on TCAM size for using mutiple features
default-result	Default access-list result during non-atomic hardware update
permit	Permit all packets during non-atomic update

Command Mode

- /exec/configure

platform fabricpath mac-learning module

[no] { platform | hardware } fabricpath mac-learning module <module> [port-group { 1-4 | 5-8 | 9-12 | 13-16 | 17-20 | 21-24 | 25-28 | 29-32 | 33-36 | 37-40 | 41-44 | 45-48 } +]

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
fabricpath		Fabric Path
mac-learning		MAC Learning
module		Specify a module number
<i>module</i>		Specify a module number
port-group	(Optional)	Port Group

Command Mode

- /exec/configure

platform forwarding interface statistics mode mpls

```
[no] { platform | hardware } forwarding interface statistics mode { mpls | default } [ module <module-num> ]
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
forwarding		Hardware forwarding
interface		Interface
statistics		Statistics
mode		Statistics mode
mpls		Mpls mode
default		Default mode
module	(Optional)	Specify a module number
<i>module-num</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform forwarding layer-2 f1 exclude supervisor

[no] { platform | hardware } forwarding layer-2 f1 exclude supervisor

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
forwarding	Forwarding information
layer-2	L2 only mode
f1	N7K-F132XP-15 module
exclude	Exclude supervisor from getting copies of ARP and multicast packets
supervisor	Supervisor module

Command Mode

- /exec/configure

platform ip verify

```
[no] { platform | hardware } ip verify { address { source { broadcast | multicast } | class-e | destination { zero
} | identical | reserved } | checksum | protocol | fragment | length { minimum | consistent | maximum { max-frag
| udp | max-tcp } } | tcp { tiny-frag } | version | syslog }
```

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
ip	IP
verify	Enable IPv4 and some IPv6 packet validation checks in hardware
address	IPv4 Source and destination address validation
source	Check source address
broadcast	Source address is 255.255.255.255
multicast	Source address is 224.x.x.x
destination	Check destination address
zero	Destination address is 0.0.0.0
class-e	Class E IDS check
identical	Same IP SA and DA
reserved	Source address is 127.x.x.x
checksum	Verify IPv4 and IPv6 packet checksum
protocol	Verify IP protocol
fragment	Check IPv4 and IPv6 fragment with non-zero offset and DF bit active
length	Validate IPv4 packet header and payload length
minimum	Minimum IPv4 header length
consistent	Actual frame size is equal to or more than IPv4 length plus ethernet header
maximum	Check max fragment offset and payload length
max-frag	Fragment offset field value
udp	Maximum UDP length has to be less than IPv4 payload length
max-tcp	Maximum TCP length has to be less than IPv4 payload length

tcp	Validate TCP packet header
tiny-frag	Check TCP tiny fragment
version	Must be 4 for an ethertype of IPv4 (0x0800)
syslog	Syslog Messages logging configuration for IDS check drops

Command Mode

- /exec/configure

platform ipv6 verify

```
[no] { platform | hardware } ipv6 verify { length { consistent | maximum { max-frag | udp | max-tcp } } | tcp
{ tiny-frag } | version }
```

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
ipv6	IPv6
verify	Enable IPv6 packet validation checks in hardware
length	Validate IPv6 packet header and payload length
consistent	Actual frame size is equal to or more than IPv6 length plus ethernet header
maximum	Check max fragment offset and payload length
max-frag	Fragment offset field value
udp	Maximum UDP length has to be less than IPv6 payload length
max-tcp	Maximum TCP length has to be less than IPv6 payload length
tcp	Validate TCP packet header
tiny-frag	Check TCP tiny fragment
version	Must be 6 for an ethertype of IPv6 (0x86DD)

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { afd profile <prof-opts> [ module <module> ] }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
afd	Approximate Fair Dropping
profile	AFD profiles
<i>prof-opts</i>	
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

[no] { platform | hardware } qos { min-buffer qos-group <buff-prof-opts> [module <module>] }

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure qos related configuration
min-buffer		minimum/reserved buffer selection
qos-group		Qos Group
<i>buff-prof-opts</i>		
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { ns-mcq3-alias qos-group <qos-grp-val> [ module <module> ] }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure QoS related configuration
ns-mcq3-alias	Select qos-group to which to divert qos-group-3	Multicast traffic
qos-group		Qos Group
<i>qos-grp-val</i>		QoS group value
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { ing-pg-hdrm-reserve percent <percent-val> [ module <module> ] }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure qos related configuration
ing-pg-hdrm-reserve		Set Ingress PG Headroom reservation
percent		PG Headroom reservation percent
<i>percent-val</i>		percent of PG Headroom to reserve
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos

[no] { platform | hardware } qos { burst-detect max-records <val> }

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
burst-detect	Set OOBST burst monitor configs
max-records	Set OOBST burst monitor max records
val	maximum number of records to monitor

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { oq-drops type <sel> [ module <module> ] }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
oq-drops	per output queue drops
type	type of drops - occ/wred/both
<i>sel</i>	
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { dynamic-packet-prioritization age-period <period> usec [ module <module> ] }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure qos related configuration
dynamic-packet-prioritization		Dynamic Packet Prioritization
age-period		Aging Period
<i>period</i>		Aging Period
usec		micro seconds
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { dynamic-packet-prioritization max-num-pkts <pkts> [ module <module> ] }
```

Syntax Description

Syntax Description		
	no	(Optional) Negate a command or set its defaults
	platform	Platform configuration commands
	hardware	Hardware Internal Information
	qos	Configure qos related configuration
	dynamic-packet-prioritization	Dynamic Packet Prioritization
	max-num-pkts	Maximum number of packets prioritized
	<i>pkts</i>	Number of packets
	module	(Optional) Specify a module number
	<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { etrap age-period <period> usec [ module <module> ] }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
etrap	Elephant Trap
age-period	Aging Period
<i>period</i>	Aging Period
usec	micro seconds
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { etrap byte-count <count> [ module <module> ] }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
etrap	Elephant Trap
byte-count	Number of bytes to become elephant flow
<i>count</i>	Number of bytes
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos

[no] { platform | hardware } qos { etrap bandwidth-threshold <bw> bytes [module <module>] }

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure qos related configuration
etrap		Elephant Trap
bandwidth-threshold		Bandwidth threshold for elephant flow
<i>bw</i>		Number of bytes
bytes		Bytes
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos

```
[no] { platform | hardware } qos { buffer input peak <sel> [ module <module> ] }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
buffer	buffer config
input	input buffer
peak	peak counter type
<i>sel</i>	
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos buffer peak monitor counter0 class

[no] { platform | hardware } qos buffer peak monitor counter0 class <classes>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
buffer	buffer config
peak	Configure peak control
monitor	monitor peak
counter0	selecting counter 0 for assigning classes
class	class(es) to monitor
classes	qos-group

Command Mode

- /exec/configure

platform qos buffer peak monitor counter1 class

[no] { platform | hardware } qos buffer peak monitor counter1 class { <classes> | none }

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
buffer	buffer config
peak	Configure peak control
monitor	monitor peak
counter1	selecting counter 1 for assigning classes
class	class(es) to monitor
<i>classes</i>	qos-group
none	none

Command Mode

- /exec/configure

platform qos classify ns-only

[no] { platform | hardware } qos classify ns-only

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	platform	Platform configuration commands
	hardware	Hardware Internal Information
	qos	Quality Of Service
	classify	Configure qos classification
	ns-only	Enable qos classification on NS only in hardware

Command Mode

- /exec/configure

platform qos eoq

```
[no] { platform | hardware } qos eoq { stats-class qos-group { all | <qos-grp-val> } [ module <module> ] }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure QoS related configuration
eoq		Extended Output Queue(EOQ) related configuration
stats-class		Select class for which to report the statistics
qos-group		Qos Group
<i>qos-grp-val</i>		QoS group value
all		all Qos Groups
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos include ipg

```
[no] { platform | hardware } qos include { ipg [ module <module> ] }
```

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
include	include specific configuration param
ipg	Select whether to include IPG in Shaping/Policing
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number

Command Mode

- /exec/configure

platform qos ing

```
[no] { platform | hardware } qos { ing-pg-share [ module <module> ] }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure qos related configuration
ing-pg-share		Select Ingress PG Shared Buffer Usage
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos ing

```
[no] { platform | hardware } qos { ing-pg-no-min [ pgmin <pgmin> ] [ module <module> ] }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure qos related configuration
ing-pg-no-min		Enable PG Min
pgmin	(Optional)	Set PG Min Value
<i>pgmin</i>	(Optional)	PG Min Value
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos mac ipg

{ platform | hardware } qos mac ipg <val> | no { platform | hardware } qos mac ipg [<val>]

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure qos related configuration
mac		MAC
ipg		Mac IPG Value
<i>val</i>		new Mac IPG value in byte

Command Mode

- /exec/configure

platform qos ns

```
[no] { platform | hardware } qos { ns-buffer-profile <buff-prof-opts> [ module <module> ] }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
qos		Configure qos related configuration
ns-buffer-profile		NorthStar buffer absorption profiles
<i>buff-prof-opts</i>		
module	(Optional)	Specify a module number
<i>module</i>	(Optional)	Specify a module number

Command Mode

- /exec/configure

platform qos q-noise percent

[no] { platform | hardware } qos q-noise percent <noise>

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
qos	Configure qos related configuration
q-noise	Configure noise thresholds
percent	Noise threshold in percentage of dynamic/static queue_max
noise	Noise percent

Command Mode

- /exec/configure

platform rate-limiter

```
{ platform | hardware } rate-limiter { layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2 { <l2-opts> } | <opts> | fl <fl-opts> } { <pps> [ burst <burst> ] | disable } [ module <module> [ port <start> <end> ] ] | no { platform | hardware } rate-limiter { layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2 { <l2-opts> } | <opts> | fl <fl-opts> } [ disable ] [ <pps> ] [ burst <burst> ] [ module <module> [ port <start> <end> ] ]
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
rate-limiter	Configure Rate-Limiter for packets forwarded
layer-3	Layer-3 control and Routed packets
<i>l3-opts</i>	
multicast	Multicast data packets
<i>mcast-opts</i>	
layer-2	Layer-2 control and Bridged packets
<i>l2-opts</i>	
<i>opts</i>	
<i>pps</i>	value in packets per sec
fl	Control packets from F1 modules to supervisor
<i>fl-opts</i>	
disable	Disable the rate-limiter
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
port	(Optional) Port range
<i>start</i>	(Optional) Port start index
<i>end</i>	(Optional) Port end index
burst	(Optional) Modify burst parameter
<i>burst</i>	(Optional) value of burst size

Command Mode

- /exec/configure

platform rate-limiter

```
{ platform | hardware } rate-limiter { layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2 { <l2-opts> } | <opts> | fl <fl-opts> } { <pps> [ burst <burst> ] | disable } [ module <module> [ port <start> <end> ] ] | no { platform | hardware } rate-limiter { layer-3 { <l3-opts> | multicast <mcast-opts> } | layer-2 { <l2-opts> } | <opts> | fl <fl-opts> } [ disable ] [ <pps> ] [ burst <burst> ] [ module <module> [ port <start> <end> ] ]
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
rate-limiter	Configure Rate-Limiter for packets forwarded
layer-3	Layer-3 control and Routed packets
<i>l3-opts</i>	
multicast	Multicast data packets
<i>mcast-opts</i>	
layer-2	Layer-2 control and Bridged packets
<i>l2-opts</i>	
<i>opts</i>	
<i>pps</i>	value in kbits per sec
fl	Control packets from F1 modules to supervisor
<i>fl-opts</i>	
disable	Disable the rate-limiter
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
port	(Optional) Port range
<i>start</i>	(Optional) Port start index
<i>end</i>	(Optional) Port end index
burst	(Optional) Modify burst parameter
<i>burst</i>	(Optional) value of burst size

Command Mode

- /exec/configure

platform rate-limiter access-list-log

```
{ platform | hardware } rate-limiter access-list-log { <pps> [ burst <burst> ] | disable } [ module <module> [
port <start> <end> ] ] | no { platform | hardware } rate-limiter access-list-log [ disable ] [ <pps> ] [ burst
<burst> ] [ module <module> [ port <start> <end> ] ]
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
rate-limiter	Configure Rate-Limiter for packets forwarded
access-list-log	Packets copied to supervisor for access-list logging
<i>pps</i>	value in packets per sec
disable	Disable the rate-limiter
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
port	(Optional) Port range
<i>start</i>	(Optional) Port start index
<i>end</i>	(Optional) Port end index
burst	(Optional) Modify burst parameter
<i>burst</i>	(Optional) value of burst size

Command Mode

- /exec/configure

platform rate-limiter span-egress

```
{ platform | hardware } rate-limiter span-egress <rate> [ module <module> ] | no { platform | hardware }
rate-limiter span-egress [ <rate> ] [ module <module> ]
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
platform		Platform configuration commands
hardware		Hardware Internal Information
rate-limiter		Configure Rate-Limiter for packets forwarded
span-egress		SPAN/ERSPAN egress packets
<i>rate</i>		value in kbit per sec
module		(Optional) Specify a module number
<i>module</i>		(Optional) Specify a module number

Command Mode

- /exec/configure

plb

{ plb <service-name> } | { no plb <service-name> }

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
plb		PLB service
<i>service-name</i>		PLB service-name

Command Mode

- /exec/configure

plb l3-device-group

```
{ plb l3-device-group <svc-name> } | { no plb l3-device-group <svc-name> }
```

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	plb	PLB service
	l3-device-group	PLB L3 device group
	<i>svc-name</i>	service-name

Command Mode

- /exec/configure

plb session l3-device-group

```
{ plb session l3-device-group <svc-name> } | { no plb session l3-device-group <svc-name> }
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
plb		PLB service
session		PLB session
l3-device-group		PLB L3 device group
<i>svc-name</i>		service-name

Command Mode

- /exec/configure

plb statistics

```
{ plb statistics <service-name> } | { no plb statistics <service-name> }
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
plb		PLB service
statistics		PLB statistics
<i>service-name</i>		PLB service-name

Command Mode

- /exec/configure

plugin-test load

plugin-test load <uri0> [[<uri1>] [<uri2>]]

Syntax Description

Syntax Description	
plugin-test	PLUGIN test
load	PLUGIN test load
<i>uri0</i>	Enter image name
<i>uri1</i>	(Optional) Enter image name
<i>uri2</i>	(Optional) Enter image name

Command Mode

- /exec

plugin-test unload

```
plugin-test unload <s0> [ [ <s1> ] [ <s2> ] ]
```

Syntax Description

Syntax Description	
plugin-test	PLUGIN test
unload	plugin test unload
<i>s0</i>	Enter swid
<i>s1</i>	(Optional) Enter swid
<i>s2</i>	(Optional) Enter swid

Command Mode

- /exec

police

```
[no] police [ { [ cir ] { <cir-val> [ <opt_kbps_mbps_gbps_pps_cir> ] | percent <cir-perc> } } { [ [ bc ]
<bc-val> [ <opt_kbytes_mbytes_gbytes_bc> ] ] } } { [ [ pir ] { <pir> [ <opt_kbps_mbps_gbps_pps_pir> ] |
percent1 <pir-perc> } } [ [ [ be ] <be-val> [ <opt_kbytes_mbytes_gbytes_be> ] ] ] } { [ { conform {
<opt_drop_transmit_conform> | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit { <set-dscp-val> |
<opt_set_dscp> } } | { set-prec-transmit { <set-prec-val> | <opt_set_prec> } } } } ] [ { exceed {
<opt_drop_transmit_exceed> | { set dscp1 dscp2 table cir-markdown-map } } } ] [ { violate {
<opt_drop_transmit_violate> | { set1 dscp3 dscp4 table1 pir-markdown-map } } } ] ] ] }
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
police	Police
cir	(Optional) Specify committed information rate
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
percent	(Optional) Specify rate as percentage of interface data-rate
pir	(Optional) Specify peak information rate
<i>opt_kbps_mbps_gbps_pps_pir</i>	(Optional) Units
percent1	(Optional) Specify rate as percentage of interface data-rate
be	(Optional) Specify extended burst
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
bc	(Optional) Specify committed burst
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
conform	(Optional) Specify a conform action
<i>opt_drop_transmit_conform</i>	(Optional) Set the action
set-cos-transmit	(Optional) Set conform action cos val
<i>set-cos-val</i>	(Optional) 802.1Q Class of Service value
set-dscp-transmit	(Optional) Set conform action dscp val
<i>set-dscp-val</i>	(Optional) DSCP value
<i>opt_set_dscp</i>	(Optional)
set-prec-transmit	(Optional) Set conform action precedence val
<i>set-prec-val</i>	(Optional) IP Precedence value

<i>opt_set_prec</i>	(Optional)
exceed	(Optional) Specify a exceed action
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional) Set exceed action to cir-markdown-map
dscp1	(Optional) Exceed from field
dscp2	(Optional) Exceed to field
table	(Optional) To specify table name
cir-markdown-map	(Optional) Well known markdown map
violate	(Optional) Specify a violate action
<i>opt_drop_transmit_violate</i>	(Optional) Set the action
set1	(Optional) Set violate action to pir-markdown-map
dscp3	(Optional) Violate from field
dscp4	(Optional) Violate to field
table1	(Optional) To specify table name
pir-markdown-map	(Optional) Well known markdown map

Command Mode

- /exec/configure/pmap/class

police

```
[no] police [ { [ cir ] { <cir-val> [ <opt_kbps_mbps_gbps_pps_cir> ] | percent <cir-perc> } } { [ [ bc ]
<bc-val> [ <opt_kbytes_mbytes_gbytes_bc> ] ] } } { [ [ pir ] { <pir> [ <opt_kbps_mbps_gbps_pps_pir> ] |
percent1 <pir-perc> } } [ [ be ] <be-val> [ <opt_kbytes_mbytes_gbytes_be> ] ] ] } { [ { conform {
<opt_drop_transmit_conform> | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit { <set-dscp-val> |
<opt_set_dscp> } } | { set-prec-transmit { <set-prec-val> | <opt_set_prec> } } } ] [ { exceed {
<opt_drop_transmit_exceed> | { set dscp1 dscp2 table cir-markdown-map } } ] [ { violate {
<opt_drop_transmit_violate> | { set1 dscp3 dscp4 table1 pir-markdown-map } } } ] ] ] }
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
police	Police
cir	(Optional) Specify committed information rate
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
percent	(Optional) Specify rate as percentage of interface data-rate
pir	(Optional) Specify peak information rate
<i>opt_kbps_mbps_gbps_pps_pir</i>	(Optional) Units
percent1	(Optional) Specify rate as percentage of interface data-rate
be	(Optional) Specify extended burst
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
bc	(Optional) Specify committed burst
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
conform	(Optional) Specify a conform action
<i>opt_drop_transmit_conform</i>	(Optional) Set the action
set-cos-transmit	(Optional) Set conform action cos val
<i>set-cos-val</i>	(Optional) 802.1Q Class of Service value
set-dscp-transmit	(Optional) Set conform action dscp val
<i>set-dscp-val</i>	(Optional) DSCP value
<i>opt_set_dscp</i>	(Optional)
set-prec-transmit	(Optional) Set conform action precedence val
<i>set-prec-val</i>	(Optional) IP Precedence value

<i>opt_set_prec</i>	(Optional)
exceed	(Optional) Specify a exceed action
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional) Set exceed action to cir-markdown-map
dscp1	(Optional) Exceed from field
dscp2	(Optional) Exceed to field
table	(Optional) To specify table name
cir-markdown-map	(Optional) Well known markdown map
violate	(Optional) Specify a violate action
<i>opt_drop_transmit_violate</i>	(Optional) Set the action
set1	(Optional) Set violate action to pir-markdown-map
dscp3	(Optional) Violate from field
dscp4	(Optional) Violate to field
table1	(Optional) To specify table name
pir-markdown-map	(Optional) Well known markdown map

Command Mode

- /exec/configure/pmap/class

police

```
[no] police { { [ cir ] { <cir-val> [ bps | kbps | mbps | gbps | pps ] | percent <cir-perc> } [ [ bc ] {
<committed-burst> [ bytes | kbytes | mbytes | ms | us | packets ] } ] [ pir { <pir-val> [ bps2 | kbps2 | mbps2 |
gbps2 | pps2 ] | percent <pir-perc> } [ [ be ] { <extended-burst> [ bytes2 | kbytes2 | mbytes2 | ms2 | us2 |
packets2 ] } ] ] [ conform { transmit | set-prec-transmit { <prec-val> | <prec-enum> } | set-dscp-transmit {
<dscp-val> | <dscp-enum> } | set-cos-transmit <cos-val> | set-discard-class-transmit <disc-class-val> |
set-qos-transmit <qos-grp-val> | set-mpls-exp-imposition-transmit <exp-value-imp> |
set-mpls-exp-topmost-transmit <exp-value-top> } [ exceed { transmit1 | drop1 | set <exc-frm-field>
<exc-to-field> table cir-markdown-map | set-prec-transmit1 { <prec-val1> | <prec-enum1> } | set-dscp-transmit1
{ <dscp-val1> | <dscp-enum1> } | set-cos-transmit1 <cos-val1> | set-discard-class-transmit1 <disc-class-val1>
| set-qos-transmit1 <qos-grp-val1> | set-mpls-exp-imposition-transmit1 <exp-value-imp1> |
set-mpls-exp-topmost-transmit1 <exp-value-top1> } ] [ violate { drop2 | set <vio-frm-field> <vio-to-field>
table2 pir-markdown-map | set-prec-transmit2 { <prec-val2> | <prec-enum2> } | set-dscp-transmit2 {
<dscp-val2> | <dscp-enum2> } | set-cos-transmit2 <cos-val2> | set-discard-class-transmit2 <disc-class-val2>
| set-qos-transmit2 <qos-grp-val2> | set-mpls-exp-imposition-transmit2 <exp-value-imp2> |
set-mpls-exp-topmost-transmit2 <exp-value-top2> } ] ] } | aggregate <policer-name> }
```

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
police	police
cir	(Optional) Specify committed information rate
bc	(Optional) Specify committed burst
percent	Specify rate as percentage of interface data-rate
<i>cir-perc</i>	Percentage
<i>pir-perc</i>	(Optional) Percentage
pir	(Optional) Specify peak information rate
be	(Optional) Specify extended burst (for 1R3C meter)
bps	(Optional) Bits per second
kbps	(Optional) Kilo bits per second
mbps	(Optional) Mega bits per second
gbps	(Optional) Giga bits per second
pps	(Optional) Packets per second
bps2	(Optional) Bits per second
kbps2	(Optional) Kilo Bits per second
mbps2	(Optional) Mega Bits per second

gbps2	(Optional) Giga Bits per second
pps2	(Optional) Packets per second
bytes	(Optional) Bytes
kbytes	(Optional) Kilo bytes
mbytes	(Optional) Mega bytes
us	(Optional) Micro second(s)
ms	(Optional) Milli second(s)
packets	(Optional) Packets
bytes2	(Optional) Bytes
kbytes2	(Optional) Kilo Bytes
mbytes2	(Optional) Mega Bytes
ms2	(Optional) Milli seconds
us2	(Optional) Micro seconds
packets2	(Optional) Packets
conform	(Optional) Specify a conform action
exceed	(Optional) Specify a exceed action
violate	(Optional) Specify a violate action
transmit	(Optional) Transmit packet
transmit1	(Optional) Transmit packet
drop1	(Optional) Drop packet
drop2	(Optional) Drop packet
set-prec-transmit	(Optional) Set precedence and send it
set-prec-transmit1	(Optional) Set precedence and send it
set-prec-transmit2	(Optional) Set precedence and send it
<i>prec-val</i>	(Optional) Precedence value
<i>prec-val1</i>	(Optional) Precedence value
<i>prec-val2</i>	(Optional) Precedence value
<i>prec-enum</i>	(Optional)
<i>prec-enum1</i>	(Optional)

<i>prec-enum2</i>	(Optional)
set-dscp-transmit	(Optional) Set dscp and send it
set-dscp-transmit1	(Optional) Set dscp and send it
set-dscp-transmit2	(Optional) Set dscp and send it
<i>dscp-val</i>	(Optional) DSCP value
<i>dscp-val1</i>	(Optional) DSCP value
<i>dscp-val2</i>	(Optional) DSCP value
<i>dscp-enum</i>	(Optional)
<i>dscp-enum1</i>	(Optional)
<i>dscp-enum2</i>	(Optional)
set-cos-transmit	(Optional) Set cos and send it
set-cos-transmit1	(Optional) Set cos and send it
set-cos-transmit2	(Optional) Set cos and send it
<i>cos-val</i>	(Optional) new cos value
<i>cos-val1</i>	(Optional) new cos value
<i>cos-val2</i>	(Optional) new cos value
set-discard-class-transmit	(Optional) Set discard class and send it
set-discard-class-transmit1	(Optional) Set discard class and send it
set-discard-class-transmit2	(Optional) Set discard class and send it
<i>disc-class-val</i>	(Optional) new discard-class value
<i>disc-class-val1</i>	(Optional) new discard-class value
<i>disc-class-val2</i>	(Optional) new discard-class value
set-qos-transmit	(Optional) Set qos-group and send it
set-qos-transmit1	(Optional) Set qos-group and send it
set-qos-transmit2	(Optional) Set qos-group and send it
<i>qos-grp-val</i>	(Optional) QoS group value
<i>qos-grp-val1</i>	(Optional) QoS group value
<i>qos-grp-val2</i>	(Optional) QoS group value
set-mpls-exp-imposition-transmit	(Optional) set-mpls-exp-imposition-transmit

<i>set-mpls-exp-imposition-transmit1</i>	(Optional) set-mpls-exp-imposition-transmit
<i>set-mpls-exp-imposition-transmit2</i>	(Optional) set-mpls-exp-imposition-transmit
<i>exp-value-imp</i>	(Optional) MPLS imposition value
<i>exp-value-imp1</i>	(Optional) MPLS imposition value
<i>exp-value-imp2</i>	(Optional) MPLS imposition value
<i>set-mpls-exp-topmost-transmit</i>	(Optional) Set MPLS topmost label
<i>set-mpls-exp-topmost-transmit1</i>	(Optional) Set MPLS topmost label
<i>set-mpls-exp-topmost-transmit2</i>	(Optional) Set MPLS topmost label
<i>exp-value-top</i>	(Optional) MPLS topmost value
<i>exp-value-top1</i>	(Optional) MPLS topmost value
<i>exp-value-top2</i>	(Optional) MPLS topmost value
<i>set</i>	(Optional) Set a particular value using table or markdown map
<i>exc-frm-field</i>	(Optional)
<i>exc-to-field</i>	(Optional)
<i>vio-frm-field</i>	(Optional)
<i>vio-to-field</i>	(Optional)
<i>table</i>	(Optional) Set using the table-map
<i>table2</i>	(Optional) Set using the table-map
<i>cir-markdown-map</i>	(Optional) Markdown map table name for exceed action
<i>pir-markdown-map</i>	(Optional) Markdown map table name for violate action
<i>aggregate</i>	Choose aggregate policer for current class
<i>policer-name</i>	Enter aggregate-policer name

Command Mode

- /exec/configure/policy-map/class

police

```
[no] police { { [ cir ] { <cir-val> [ bps | kbps | mbps | gbps ] | percent <cir-perc> } [ [ bc ] { <committed-burst>
[ bytes | kbytes | mbytes | ms | us ] } ] [ pir { <pir-val> [ bps2 | kbps2 | mbps2 | gbps2 | pps2 ] | percent <pir-perc>
} [ [ be ] { <extended-burst> [ bytes2 | kbytes2 | mbytes2 | ms2 | us2 | packets2 ] } ] ] [ conform { transmit |
set-prec-transmit { <prec-val> | <prec-enum> } | set-dscp-transmit { <dscp-val> | <dscp-enum> } |
set-cos-transmit <cos-val> | set-discard-class-transmit <disc-class-val> | set-qos-transmit <qos-grp-val> |
set-mpls-exp-imposition-transmit <exp-value-imp> | set-mpls-exp-topmost-transmit <exp-value-top> } [
exceed { drop1 | set <exc-frm-field> <exc-to-field> table cir-markdown-map | set-prec-transmit1 { <prec-val1>
| <prec-enum1> } | set-dscp-transmit1 { <dscp-val1> | <dscp-enum1> } | set-cos-transmit1 <cos-val1> |
set-discard-class-transmit1 <disc-class-val1> | set-qos-transmit1 <qos-grp-val1> |
set-mpls-exp-imposition-transmit1 <exp-value-imp1> | set-mpls-exp-topmost-transmit1 <exp-value-top1> }
] [ violate { drop2 | set <vio-frm-field> <vio-to-field> table2 pir-markdown-map | set-prec-transmit2 {
<prec-val2> | <prec-enum2> } | set-dscp-transmit2 { <dscp-val2> | <dscp-enum2> } | set-cos-transmit2
<cos-val2> | set-discard-class-transmit2 <disc-class-val2> | set-qos-transmit2 <qos-grp-val2> |
set-mpls-exp-imposition-transmit2 <exp-value-imp2> | set-mpls-exp-topmost-transmit2 <exp-value-top2> }
] ] } | aggregate <policer-name> }
```

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
police	police
cir	(Optional) Specify committed information rate
bc	(Optional) Specify committed burst
percent	Specify rate as percentage of interface data-rate
<i>cir-perc</i>	Percentage
<i>pir-perc</i>	(Optional) Percentage
pir	(Optional) Specify peak information rate
be	(Optional) Specify extended burst (for 1R3C meter)
bps	(Optional) Bits per second
kbps	(Optional) Kilo bits per second
mbps	(Optional) Mega bits per second
gbps	(Optional) Giga bits per second
bps2	(Optional) Bits per second
kbps2	(Optional) Kilo Bits per second
mbps2	(Optional) Mega Bits per second
gbps2	(Optional) Giga Bits per second

pps2	(Optional) Packets per second
bytes	(Optional) Bytes
kbytes	(Optional) Kilo bytes
mbytes	(Optional) Mega bytes
us	(Optional) Micro second(s)
ms	(Optional) Milli second(s)
bytes2	(Optional) Bytes
kbytes2	(Optional) Kilo Bytes
mbytes2	(Optional) Mega Bytes
ms2	(Optional) Milli seconds
us2	(Optional) Micro seconds
packets2	(Optional) Packets
conform	(Optional) Specify a conform action
exceed	(Optional) Specify a exceed action
violate	(Optional) Specify a violate action
transmit	(Optional) Transmit packet
drop1	(Optional) Drop packet
drop2	(Optional) Drop packet
set-prec-transmit	(Optional) Set precedence and send it
set-prec-transmit1	(Optional) Set precedence and send it
set-prec-transmit2	(Optional) Set precedence and send it
<i>prec-val</i>	(Optional) Precedence value
<i>prec-val1</i>	(Optional) Precedence value
<i>prec-val2</i>	(Optional) Precedence value
<i>prec-enum</i>	(Optional)
<i>prec-enum1</i>	(Optional)
<i>prec-enum2</i>	(Optional)
set-dscp-transmit	(Optional) Set dscp and send it
set-dscp-transmit1	(Optional) Set dscp and send it

<i>set-dscp-transmit2</i>	(Optional) Set dscp and send it
<i>dscp-val</i>	(Optional) DSCP value
<i>dscp-val1</i>	(Optional) DSCP value
<i>dscp-val2</i>	(Optional) DSCP value
<i>dscp-enum</i>	(Optional)
<i>dscp-enum1</i>	(Optional)
<i>dscp-enum2</i>	(Optional)
<i>set-cos-transmit</i>	(Optional) Set cos and send it
<i>set-cos-transmit1</i>	(Optional) Set cos and send it
<i>set-cos-transmit2</i>	(Optional) Set cos and send it
<i>cos-val</i>	(Optional) new cos value
<i>cos-val1</i>	(Optional) new cos value
<i>cos-val2</i>	(Optional) new cos value
<i>set-discard-class-transmit</i>	(Optional) Set discard class and send it
<i>set-discard-class-transmit1</i>	(Optional) Set discard class and send it
<i>set-discard-class-transmit2</i>	(Optional) Set discard class and send it
<i>disc-class-val</i>	(Optional) new discard-class value
<i>disc-class-val1</i>	(Optional) new discard-class value
<i>disc-class-val2</i>	(Optional) new discard-class value
<i>set-qos-transmit</i>	(Optional) Set qos-group and send it
<i>set-qos-transmit1</i>	(Optional) Set qos-group and send it
<i>set-qos-transmit2</i>	(Optional) Set qos-group and send it
<i>qos-grp-val</i>	(Optional) QoS group value
<i>qos-grp-val1</i>	(Optional) QoS group value
<i>qos-grp-val2</i>	(Optional) QoS group value
<i>set-mpls-exp-imposition-transmit</i>	(Optional) set-mpls-exp-imposition-transmit
<i>set-mpls-exp-imposition-transmit1</i>	(Optional) set-mpls-exp-imposition-transmit
<i>set-mpls-exp-imposition-transmit2</i>	(Optional) set-mpls-exp-imposition-transmit
<i>exp-value-imp</i>	(Optional) MPLS imposition value

<i>exp-value-imp1</i>	(Optional) MPLS imposition value
<i>exp-value-imp2</i>	(Optional) MPLS imposition value
set-mpls-exp-topmost-transmit	(Optional) Set MPLS topmost label
set-mpls-exp-topmost-transmit1	(Optional) Set MPLS topmost label
set-mpls-exp-topmost-transmit2	(Optional) Set MPLS topmost label
<i>exp-value-top</i>	(Optional) MPLS topmost value
<i>exp-value-top1</i>	(Optional) MPLS topmost value
<i>exp-value-top2</i>	(Optional) MPLS topmost value
set	(Optional) Set a particular value using table or markdown map
<i>exc-frm-field</i>	(Optional)
<i>exc-to-field</i>	(Optional)
<i>vio-frm-field</i>	(Optional)
<i>vio-to-field</i>	(Optional)
table	(Optional) Set using the table-map
table2	(Optional) Set using the table-map
cir-markdown-map	(Optional) Markdown map table name for exceed action
pir-markdown-map	(Optional) Markdown map table name for violate action
aggregate	Choose aggregate policer for current class
<i>policer-name</i>	Enter aggregate-policer name

Command Mode

- /exec/configure/policy-map/class

police police pps

```

police { [ cir ] { <cir-val> [ <opt_kbps_mbps_gbps_pps_cir> ] | percent <cir-perc> } } [ { [ bc ] <bc-val>
[ <opt_kbytes_mbytes_gbytes_bc> ] } ] } [ { { pir { <pir> [ <opt_kbps_mbps_gbps_pps_pir> ] | percent1
<pir-perc> } } [ [ be ] <be-val> [ <opt_kbytes_mbytes_gbytes_be> ] ] } ] } [ { conform {
<opt_drop_transmit_conform> | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit { <set-dscp-val> |
<opt_set_dscp> } } | { set-prec-transmit { <set-prec-val> | <opt_set_prec> } } } ] [ { exceed {
<opt_drop_transmit_exceed> | { set dscp1 dscp2 table cir-markdown-map } } } ] [ { violate {
<opt_drop_transmit_violate> | { set1 dscp3 dscp4 table1 pir-markdown-map } } } ] } ] | police { pps {
<pps-val> } }

```

Syntax Description

Syntax Description

police	Police
cir	(Optional) Specify committed information rate
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
percent	Specify rate as percentage of interface data-rate
pir	(Optional) Specify peak information rate
<i>opt_kbps_mbps_gbps_pps_pir</i>	(Optional) Units
percent1	(Optional) Specify rate as percentage of interface data-rate
be	(Optional) Specify extended burst
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
bc	(Optional) Specify committed burst
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
conform	(Optional) Specify a conform action
<i>opt_drop_transmit_conform</i>	(Optional) Set the action
set-cos-transmit	(Optional) Set conform action cos val
<i>set-cos-val</i>	(Optional) 802.1Q Class of Service value
set-dscp-transmit	(Optional) Set conform action dscp val
<i>set-dscp-val</i>	(Optional) DSCP value
<i>opt_set_dscp</i>	(Optional)
set-prec-transmit	(Optional) Set conform action precedence val
<i>set-prec-val</i>	(Optional) IP Precedence value
<i>opt_set_prec</i>	(Optional)

exceed	(Optional) Specify a exceed action
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional) Set exceed action to cir-markdown-map
dscp1	(Optional) Exceed from field
dscp2	(Optional) Exceed to field
table	(Optional) To specify table name
cir-markdown-map	(Optional) Well known markdown map
violate	(Optional) Specify a violate action
<i>opt_drop_transmit_violate</i>	(Optional) Set the action
set1	(Optional) Set violate action to pir-markdown-map
dscp3	(Optional) Violate from field
dscp4	(Optional) Violate to field
table1	(Optional) To specify table name
pir-markdown-map	(Optional) Well known markdown map
pps	Specify PPS rate limit

Command Mode

- /exec/configure/pmap/class

police police pps

```

police { [ cir ] { <cir-val> [ <opt_kbps_mbps_gbps_pps_cir> ] | percent <cir-perc> } } [ { [ bc ] <bc-val>
[ <opt_kbytes_mbytes_gbytes_bc> ] } ] } [ { [ pir ] { <pir> [ <opt_kbps_mbps_gbps_pps_pir> ] | percent1
<pir-perc> } } [ { [ be ] <be-val> [ <opt_kbytes_mbytes_gbytes_be> ] } ] } ] [ { conform {
<opt_drop_transmit_conform> | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit { <set-dscp-val> |
<opt_set_dscp> } } | { set-prec-transmit { <set-prec-val> | <opt_set_prec> } } } ] [ { exceed {
<opt_drop_transmit_exceed> | { set dscp1 dscp2 table cir-markdown-map } } } ] [ { violate {
<opt_drop_transmit_violate> | { set1 dscp3 dscp4 table1 pir-markdown-map } } } ] } ] | police { pps {
<pps-val> } }

```

Syntax Description

Syntax Description

police	Police
cir	(Optional) Specify committed information rate
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
percent	Specify rate as percentage of interface data-rate
pir	(Optional) Specify peak information rate
<i>opt_kbps_mbps_gbps_pps_pir</i>	(Optional) Units
percent1	(Optional) Specify rate as percentage of interface data-rate
be	(Optional) Specify extended burst
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
bc	(Optional) Specify committed burst
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
conform	(Optional) Specify a conform action
<i>opt_drop_transmit_conform</i>	(Optional) Set the action
set-cos-transmit	(Optional) Set conform action cos val
<i>set-cos-val</i>	(Optional) 802.1Q Class of Service value
set-dscp-transmit	(Optional) Set conform action dscp val
<i>set-dscp-val</i>	(Optional) DSCP value
<i>opt_set_dscp</i>	(Optional)
set-prec-transmit	(Optional) Set conform action precedence val
<i>set-prec-val</i>	(Optional) IP Precedence value
<i>opt_set_prec</i>	(Optional)

exceed	(Optional) Specify a exceed action
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
set	(Optional) Set exceed action to cir-markdown-map
dscp1	(Optional) Exceed from field
dscp2	(Optional) Exceed to field
table	(Optional) To specify table name
cir-markdown-map	(Optional) Well known markdown map
violate	(Optional) Specify a violate action
<i>opt_drop_transmit_violate</i>	(Optional) Set the action
set1	(Optional) Set violate action to pir-markdown-map
dscp3	(Optional) Violate from field
dscp4	(Optional) Violate to field
table1	(Optional) To specify table name
pir-markdown-map	(Optional) Well known markdown map
pps	Specify PPS rate limit

Command Mode

- /exec/configure/pmap/class

policy-map

[no] policy-map [type qos] [match-first] <pmap-name-qos>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
policy-map		Configure a policy map
type	(Optional)	Specify the type of this policy-map
qos	(Optional)	Qos policy
match-first	(Optional)	Take the action for the first class that matches
<i>pmap-name-qos</i>		Policy-map name (alphanumeric)

Command Mode

- /exec/configure

policy-map type control-plane

[no] policy-map type control-plane <pmap-name>

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	policy-map	Configure a policy map
	type	Specify the type of this policy-map
	control-plane	Control-Plane
	<i>pmap-name</i>	Policy-map name (alphanumeric)

Command Mode

- /exec/configure

policy-map type network-qos

[no] policy-map type network-qos <pmap-name-nq>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	Specify the type of this policy-map
network-qos	Network QoS policy
<i>pmap-name-nq</i>	Policy-map name

Command Mode

- /exec/configure

policy-map type psp

```
[no] policy-map type psp { <pmap-name-plc> | { handle <ppf_id> } } [ table <table_type> ] [ client <clienttype>
<clientID> ]
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
policy-map		Configure a policy map
type		Specify the type of this policy-map
psp		PSP policy
<i>pmap-name-plc</i>		Policy-map name (alphanumeric)
handle		Handle
<i>ppf_id</i>		PPF ID
table	(Optional)	table
<i>table_type</i>	(Optional)	Table Type
client	(Optional)	set client type
<i>clienttype</i>	(Optional)	cli/onep
<i>clientID</i>	(Optional)	client appID

Command Mode

- /exec/configure

policy-map type queuing

[no] policy-map type queuing [match-first] <pmap-name-que>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
policy-map		Configure a policy map
type		Specify the type of this policy-map
queuing		Queuing policy
match-first	(Optional)	Take the action for the first class that matches
<i>pmap-name-que</i>		Policy-map name (alphanumeric)

Command Mode

- /exec/configure

policy

policy { { dynamic identity <device-id> } | { static sgt <sgt> [trusted] } } | no policy static | no policy dynamic

Syntax Description

Syntax Description

policy	Enable and define policy to be applied
dynamic	apply to authorization server for policy
identity	specify identity of peer for authorization request
<i>device-id</i>	peer's device-id
static	configure static policy
sgt	SGT tag for pkts from this device
<i>sgt</i>	sgt value
trusted	(Optional) specify trust state of the link

Command Mode

- /exec/configure/cts-manual

policy

[no] policy <name>

Syntax Description

Syntax Description	no (Optional) Negate a command or set its defaults
	policy NBM Flow policy
	<i>name</i> Policy name

Command Mode

- /exec/configure/nbm-flow

pop

pop [<name>]

Syntax Description

Syntax Description

pop pop mode from stack or restore from name

name (Optional) name

Command Mode

- /global

port-channel limit

port-channel limit | no port-channel limit

Syntax Description

Syntax Description	
no	Negate a command or set its defaults
port-channel	Configure the maximum number of supported vPCs
limit	limit to 244 vPCs

Command Mode

- /exec/configure/vpc-domain

port-channel load-balance

```
port-channel load-balance <bndl_hash> <bndl_sel> [ rotate <po-lb-rotate-range> ] [ concatenation ] [ module
<module> | fex all ] [ symmetric ] | no port-channel load-balance [ <bndl_hash> <bndl_sel> [ rotate
<po-lb-rotate-range> ] [ concatenation ] [ module <module> | fex all ] [ symmetric ] ]
```

Syntax Description

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance	Configure port-channel load balance
<i>bndl_hash</i>	bundle hash
<i>bndl_sel</i>	bundle select
rotate	(Optional) offset the hash-input
<i>po-lb-rotate-range</i>	(Optional) offset the hash-input
concatenation	(Optional) enable/disable concatenation
module	(Optional) Specify a module number
<i>module</i>	(Optional) Specify a module number
fex	(Optional) FEX devices
all	(Optional) Permit all FEX to configure port-channel LB
symmetric	(Optional) symmetric load balancing

Command Mode

- /exec/configure

port-channel load-balance1 ethernet

port-channel load-balance1 ethernet <algorithm> [symmetric] | no port-channel load-balance1 ethernet [<algorithm> [symmetric]]

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
port-channel		Configure port channel parameters
load-balance1		Configure port-channel load balance
ethernet		Ethernet port-channel
<i>algorithm</i>		Configure port-channel load balance
symmetric		(Optional) symmetric load balancing

Command Mode

- /exec/configure

port-channel load-balance2 resilient

port-channel load-balance2 resilient | no port-channel load-balance2 resilient

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
port-channel		Configure port channel parameters
load-balance2		Configure port-channel load balance
resilient		Configure port-channel load balance resilient mode

Command Mode

- /exec/configure

port-channel load-balance ethernet

port-channel load-balance ethernet <algorithm> [module <module>] | no port-channel load-balance ethernet [<algorithm> [module <module>]]

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
port-channel		Configure port channel parameters
load-balance		Configure port-channel load balance
ethernet		Ethernet port-channel
module		(Optional) Specify a module number
<i>module</i>		(Optional) Specify a module number
<i>algorithm</i>		Configure port-channel load balance

Command Mode

- /exec/configure

port-channel load-balance hash-modulo-f2

[no] port-channel load-balance hash-modulo-f2

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance	Configure port-channel load balance
hash-modulo-f2	Enable/disable modulo hash for N7K-F248XP cards

Command Mode

- /exec/configure

port-channel load-balance hash enable

[no] port-channel load-balance hash enable

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	port-channel	Configure port channel parameters
	load-balance	Configure port-channel load balance
	hash	hash enhancement
	enable	enable

Command Mode

- /exec/configure

port-channel load-balance internal

port-channel load-balance internal <algorithm> | no port-channel load-balance internal <algorithm>

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
port-channel		Configure port channel parameters
load-balance		Configure port-channel load balance
internal		Configure port-channel load balance internal commands
<i>algorithm</i>		Configure port-channel load balance internal mode

Command Mode

- /exec/configure

port-channel load-balance internal dynamic-pin

port-channel load-balance internal dynamic-pin | no port-channel load-balance internal dynamic-pin

Syntax Description

Syntax Description	
no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance	Configure port-channel load balance
internal	Configure port-channel load balance internal commands
dynamic-pin	Configure port-channel load balance internal commands

Command Mode

- /exec/configure

port-channel load-balance internal rtag7

port-channel load-balance internal rtag7 <algorithm> | no port-channel load-balance internal rtag7 <algorithm>

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
port-channel		Configure port channel parameters
load-balance		Configure port-channel load balance
internal		Configure port-channel load balance internal commands
rtag7		Configure port-channel load balance internal commands
<i>algorithm</i>		Configure port-channel load balance internal mode

Command Mode

- /exec/configure

port-group

```
{ port-group <name> } | { no port-group <name> }
```

Syntax Description

Syntax Description	<code>no</code>	Negate a command or set its defaults
	<code>port-group</code>	<code>catena port group</code>
	<i>name</i>	<code>catena port group name</code>

Command Mode

- /exec/configure/catena

port-group

{ port-group <name> } | { no port-group <name> }

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	port-group	smart channel port group
	<i>name</i>	smart channel port group name

Command Mode

- /exec/configure/smartc

port-profile

```
[no] port-profile [ type <typeval> ] { <profilename> | <s0> }
```

Syntax Description

Syntax Description	
<code>no</code>	(Optional) Negate a command or set its defaults
<code>port-profile</code>	Configure a port-profile
<i>profilename</i>	Enter the name of the profile
<i>s0</i>	Enter the name of the profile
<code>type</code>	(Optional) configure type of the profile
<i>typeval</i>	(Optional)

Command Mode

- /exec/configure

port-profile dump

[no] port-profile dump

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
----	---

port-profile	Dump port-profile
--------------	-------------------

dump	Dump all additional information from database
------	---

Command Mode

- /exec

port-profile no-redirectation

[no] port-profile no-redirectation

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	port-profile	Show port-profile information
	no-redirectation	Disable port-profile redirection

Command Mode

- /exec

port

```
{ port <tportnum> } | { no port [ <tportnum-ignore> ] }
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
port		Port number
<i>tportnum</i>		Port number, default: 15002
<i>tportnum-ignore</i>	(Optional)	Port number, default: 15002

Command Mode

- /exe/configure/onep/tls

port control

[no] port control <port-control-name>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
port		ITD port
control		control
<i>port-control-name</i>		Port control name

Command Mode

- /exec/configure/itd-inout

port control

[no] port control <port-control-name>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
port		ITD port
control		control
<i>port-control-name</i>		Port control name

Command Mode

- /exec/configure/itd-inout

port control

[no] port control <port-control-name>

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
port		PLB port
control		control
<i>port-control-name</i>		Port control name

Command Mode

- /exec/configure/plb-inout

port destination

```
{ port { destination | source } <port> } | { no port { destination | source } }
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
port		specify flow port address
source		specify flow source port address
destination		specify flow destination port address
<i>port</i>		port number

Command Mode

- /exec/configure/configngoamprofileflow

power efficient-ethernet auto

[no] power efficient-ethernet auto

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
power		Configure EEE for the port
efficient-ethernet		Configure Energy Efficient Ethernet (EEE)
auto		Auto negotiate EEE

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

power efficient-ethernet sleep threshold aggressive

[no] power efficient-ethernet sleep threshold aggressive

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
power		Configure EEE for the port
efficient-ethernet		Configure Energy Efficient Ethernet (EEE)
sleep		EEE LPI sleep configuration
threshold		EEE LPI sleep threshold
aggressive		Enable/ Disable EEE LPI aggressive sleep mode

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

power redundancy-mode combined

[no] power redundancy-mode combined

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
power		Configure power supply
redundancy-mode		Configure power supply redundancy mode
combined		Configure power supply redundancy mode as combined

Command Mode

- /exec/configure

power redundancy-mode combined force

[no] power redundancy-mode combined force

Syntax Description

Syntax Description		
	no	(Optional) Negate a command or set its defaults
	power	Configure power supply
	redundancy-mode	Configure power supply redundancy mode
	combined	Configure power supply redundancy mode as combined
	force	Force combined mode without prompting

Command Mode

- /exec/configure

power redundancy-mode insrc-redundant

[no] power redundancy-mode insrc-redundant

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
power	Configure power supply
redundancy-mode	Configure power supply redundancy mode
insrc-redundant	Configure power supply redundancy mode as grid/AC input source redundant

Command Mode

- /exec/configure

power redundancy-mode ps-redundant

[no] power redundancy-mode ps-redundant

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
power		Configure power supply
redundancy-mode		Configure power supply redundancy mode
ps-redundant		Configure power supply redundancy mode as PS redundant

Command Mode

- /exec/configure

power reserve

[no] power reserve <percentage>

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
power	Configure power supply
reserve	Override default power reservation
<i>percentage</i>	please enter a percentage

Command Mode

- /exec/configure

poweroff

```
[no] poweroff { module <module> | <s0> <santa-cruz-range> }
```

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
poweroff		Power off a module in the switch
module		enter a module number
<i>module</i>		please enter the module number
<i>s0</i>		Power off a specific xbar
<i>santa-cruz-range</i>		please enter the xbar number

Command Mode

- /exec/configure

pps

pps <pps> <burst> | no pps [<pps>] [<burst>]

Syntax Description

Syntax Description	<i>no</i>	Negate a command or set its defaults
	<i>pps</i>	OSPF packets per second
	<i>pps</i>	Packets per second value
	<i>burst</i>	Burst value

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

pps

pps <pps> <burst> | no pps [<pps>] [<burst>]

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	pps	OSPFv3 packets per second
	<i>pps</i>	Packets per second value
	<i>burst</i>	Burst value

Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

precision milliseconds

{ { no | default } precision | precision { milliseconds | microseconds } }

Syntax Description

Syntax Description	
no	
<i>precision</i>	milliseconds
default	Set a command to its defaults
precision	Set precision of measurement
microseconds	Precision microseconds
milliseconds	Precision milliseconds

Command Mode

- /exec/configure/ip-sla/jitter

preempt

[no] preempt [delay { minimum <min-delay> }]

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
preempt		Overthrow lower priority designated routers
delay	(Optional)	Wait before preempting
minimum	(Optional)	Delay atleast this long
<i>min-delay</i>	(Optional)	Number of seconds for minimum delay

Command Mode

- /exec/configure/if-eth-any/glbp

preempt

[no] preempt | preempt

Syntax Description

Syntax Description

no Negate a command or set its defaults

preempt Enable preemption of lower priority Master

Command Mode

- /exec/configure/if-eth-any/vrrpv3

preempt

[no] preempt

Syntax Description

Syntax Description

no (Optional) Negate a command or set its defaults

preempt Enable preemption of lower priority master

Command Mode

- /exec/configure/if-eth-any/vrrp

preempt delay minimum

[no] preempt delay | preempt delay minimum <secs>

Syntax Description

Syntax Description	
no	Negate a command or set its defaults
preempt	Enable preemption of lower priority Master
delay	Wait before preempting
minimum	Delay at least this long
secs	Seconds to delay

Command Mode

- /exec/configure/if-eth-any/vrrpv3

```
preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt
delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt
delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt
```

preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt

```
preempt delay minimum <min-delay> reload <rel-delay> sync <sync-delay> | preempt delay reload <rel-delay>
minimum <min-delay> sync <sync-delay> | preempt delay sync <sync-delay> minimum <min-delay> reload
<rel-delay> | preempt delay reload <rel-delay> sync <sync-delay> minimum <min-delay> | preempt delay
sync <sync-delay> reload <rel-delay> minimum <min-delay> | preempt delay minimum <min-delay> sync
<sync-delay> reload <rel-delay> | preempt delay reload <rel-delay> sync <sync-delay> | preempt delay sync
<sync-delay> reload <rel-delay> | preempt delay minimum <min-delay> sync <sync-delay> | preempt delay
sync <sync-delay> minimum <min-delay> | preempt delay minimum <min-delay> reload <rel-delay> | preempt
delay reload <rel-delay> | preempt delay sync <sync-delay> | preempt | no preempt | no preempt delay [ { minimum
[ <min-delay> ] [ [ reload [ <rel-delay> ] ] [ sync [ <sync-delay> ] ] [ sync [ <sync-delay> ] ] [ reload [
<rel-delay> ] ] ] | reload [ <rel-delay> ] [ [ minimum [ <min-delay> ] ] [ sync [ <sync-delay> ] ] [ sync [
<sync-delay> ] ] [ minimum [ <min-delay> ] ] ] | sync [ <sync-delay> ] [ [ reload [ <rel-delay> ] ] [ minimum
[ <min-delay> ] ] ] [ minimum [ <min-delay> ] ] [ reload [ <rel-delay> ] ] ] } ]
```

Syntax Description

Syntax Description	Description
no	Negate a command or set its defaults
preempt	Overthrow lower priority Active routers
delay	Wait before preempting
minimum	Delay at least this long
<i>min-delay</i>	Number of seconds for minimum delay
reload	Delay after reload
<i>rel-delay</i>	Number of seconds for reload delay
sync	Wait for IP redundancy clients
<i>sync-delay</i>	Number of seconds for sync delay
<i>minimum</i>	reload

preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt
delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt
delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt

Command Mode

- /exec/configure/if-eth-any/hsrp_ipv4 /exec/configure/if-eth-any/hsrp_ipv6

prefix out

[no | default] { prefix-list <prfxlist-name> } { out | in }

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
default	(Optional)	Inherit values from a peer template
prefix-list		Apply prefix-list
<i>prfxlist-name</i>		Name of prefix-list
out		Apply policy to outgoing routes
in		Apply policy to incoming routes

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv4
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mdt
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv6
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-link-state
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-vpls
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-evpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-label
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-label

priority-flow-control auto-restore multiplier

[no] priority-flow-control auto-restore multiplier { <val> }

Syntax Description

Syntax Description	no	(Optional) Negate the command
	priority-flow-control	pfc related commands
	auto-restore	auto restore
	multiplier	Auto restore multiplier
	val	Auto multiplier value

Command Mode

- /exec/configure

priority-flow-control fixed-restore multiplier

[no] priority-flow-control fixed-restore multiplier { <val> }

Syntax Description

Syntax Description		
no		(Optional) Negate the command
priority-flow-control	pfc	related commands
fixed-restore	fixed	restore
multiplier		Fixed restore multiplier
val		Fixed multiplier value

Command Mode

- /exec/configure

priority-flow-control mode

[no] priority-flow-control mode { auto | on | off } [force]

Syntax Description

Syntax Description		
no	(Optional) Negate a command or set its defaults	
priority-flow-control	Enable/Disable PFC	
mode	PFC Mode	
auto	Set Auto Mode	
on	Force PFC to On	
off	Force PFC to Off	
force	(Optional) Force apply PFC config	

Command Mode

- /exec/configure/if-switching /exec/configure/if-routing /exec/configure/if-port-channel /exec/configure/if-port-channel-sub

priority-flow-control override-interface mode off

[no] priority-flow-control override-interface mode off

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
priority-flow-control		Global priority-flow-control settings
override-interface		Overrides interface priority-flow-control mode
mode		Priority-flow-control mode
off		Off

Command Mode

- /exec/configure

priority-flow-control recover interface

```
priority-flow-control recover interface <if_list> [ qos-group <qgrp-num> ] [ module <module_idx> ] [ instance <inst> ]
```

Syntax Description

Syntax Description

priority-flow-control	Change PFC settings
recover	Recover PFC queue from stuck state
interface	Interface
<i>if_list</i>	List of interfaces
qos-group	(Optional) No-drop class to be recovered
<i>qgrp-num</i>	(Optional) qos-group number of the no-drop class
module	(Optional) Slot/module
<i>module_idx</i>	(Optional) Slot/module number
instance	(Optional) ASIC Instance Number
<i>inst</i>	(Optional) ASIC Instance Number in Decimal

Command Mode

- /exec

priority-flow-control tah-recover interface

```
priority-flow-control tah-recover interface <if_list> [ qos-group <qos> ] [ module <module> ]
```

Syntax Description

Syntax Description	
priority-flow-control	Change PFC settings
tah-recover	Recover PFC queue from stuck state
interface	Interface
<i>if_list</i>	List of interfaces
qos-group	(Optional) No-drop class to be recovered
<i>qos</i>	(Optional) qos-group number of the no-drop class
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number

Command Mode

- /exec

priority-flow-control watch-dog-interval on

[no] priority-flow-control watch-dog-interval { on | off }

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	priority-flow-control	Enable/Disable PFC
	watch-dog-interval	Watch dog interval
	on	PFC watch-dog interval to On
	off	PFC watch-dog interval to Off

Command Mode

- /exec/configure/if-switching /exec/configure/if-routing /exec/configure/if-port-channel /exec/configure/if-port-channel-sub

priority-flow-control watch-dog-interval on

[no] priority-flow-control watch-dog-interval { on | off }

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
priority-flow-control	Enable/Disable	PFC
watch-dog-interval	Watch dog	interval
on	Enable PFC	watch-dog interval globally
off	Disable PFC	watch-dog interval globally

Command Mode

- /exec/configure

priority-flow-control watch-dog internal-interface-multiplier

[no] priority-flow-control watch-dog internal-interface-multiplier { <val> }

Syntax Description

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
watch-dog	watch dog interval
internal-interface-multiplier	Internal Interface Multiplier
<i>val</i>	Multiplier value for internal interfaces, 0 to disable the feature on internal interfaces

Command Mode

- /exec/configure

priority-flow-control watch-dog interval

[no] priority-flow-control watch-dog interval <interval-val>

Syntax Description

Syntax Description		
no	(Optional)	Negate the command
priority-flow-control	pfc	related commands
watch-dog	watch dog	interval
interval	Poll	interval
<i>interval-val</i>	Watch dog	interval value in ms

Command Mode

- /exec/configure

priority-flow-control watch-dog shutdown-multiplier

[no] priority-flow-control watch-dog shutdown-multiplier { <val> }

Syntax Description

Syntax Description	no	(Optional) Negate the command
	priority-flow-control	pfc related commands
	watch-dog	watch dog interval
	shutdown-multiplier	Shutdown multiplier
	val	Shutdown multiplier

Command Mode

- /exec/configure

priority

priority <priority> [forwarding-threshold lower <lower-value> upper <upper-value>] | no priority [forwarding-threshold]

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
priority		Priority level
<i>priority</i>		Priority value
forwarding-threshold	(Optional)	Set forwarding threshold
lower	(Optional)	Set lower threshold value
<i>lower-value</i>	(Optional)	Lower threshold value
upper	(Optional)	Set upper threshold value
<i>upper-value</i>	(Optional)	Upper threshold value

Command Mode

- /exec/configure/if-eth-any/hsrp_ipv4 /exec/configure/if-eth-any/hsrp_ipv6

priority2

[no] priority2 [level2 <value>]

Syntax Description

Syntax Description

no (Optional) Negate a command or set its defaults

priority2 Configure traffic class priority

level2 (Optional) Specify level of priority

value (Optional) Strict-priority level (1=hi 2=med 3=lo)

Command Mode

- /exec/configure/policy-map/type/queuing/class

priority

priority <value> | no priority

Syntax Description

Syntax Description

no Negate a command or set its defaults

priority Configure Bundle priority

value Priority value

Command Mode

- /exec/configure/anycast

priority

[no] priority [level <value>]

Syntax Description

Syntax Description

no (Optional) Negate a command or set its defaults

priority Configure traffic class priority

level (Optional) Specify level of priority

value (Optional) Value of level, lower the number higher the priority

Command Mode

- /exec/configure/policy-map/type/queuing/class

priority

{ priority <pri-value> } | { no priority }

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	priority	Priority level
	<i>pri-value</i>	Priority Value

Command Mode

- /exec/configure/if-eth-any/glbp

priority

[no] priority | priority <val>

Syntax Description

Syntax Description	<i>no</i>	Negate a command or set its defaults
	<i>priority</i>	Priority of this VRRP group
	<i>val</i>	Priority level

Command Mode

- /exec/configure/if-eth-any/vrrpv3

priority

```
{ priority <priority_value> [ forwarding-threshold lower <lower-value> upper <upper-value> ] | no priority
[ forwarding-threshold ] }
```

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
priority		Configure the vr priority
<i>priority_value</i>		Configure the vr priority
forwarding-threshold	(Optional)	Set forwarding threshold
lower	(Optional)	Set lower threshold value
<i>lower-value</i>	(Optional)	Lower threshold value
upper	(Optional)	Set upper threshold value
<i>upper-value</i>	(Optional)	Upper threshold value

Command Mode

- /exec/configure/if-eth-any/vrrp

priority

[no] priority | priority <setup_prio> [<hold_prio>]

Syntax Description

Syntax Description	
no	Negate a command or set its defaults
priority	Specify LSP priority
<i>setup_prio</i>	setup priority
<i>hold_prio</i>	(Optional) hold priority

Command Mode

- /exec/configure/te/lsp-attr

priority

[no] priority | priority <setup_pri> [<hold_pri>]

Syntax Description

Syntax Description	no	Negate a command or set its defaults
	priority	tunnel priority
	<i>setup_pri</i>	setup priority
	<i>hold_pri</i>	(Optional) hold priority

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

private-vlan

[no] private-vlan <pvlan-type>

Syntax Description

Syntax Description	no	(Optional) Negate a command or set its defaults
	private-vlan	Configure a private VLAN
	<i>pvlan-type</i>	PVLAN Type

Command Mode

- /exec/configure/vlan

private-vlan association

```
{ private-vlan association [ { add | remove } ] <secondary_vlans> } | { no private-vlan association [ <secondary_vlans> ] }
```

Syntax Description

Syntax Description		
private-vlan		Configure a private VLAN
association		Add association between private VLANs
add	(Optional)	Add a VLAN to private VLAN list
remove	(Optional)	Remove a VLAN from private VLAN list
no		Negate a command or set its defaults
<i>secondary_vlans</i>		VLAN IDs of the private VLANs to be configured

Command Mode

- /exec/configure/vlan

private-vlan mapping

```
{ private-vlan mapping [ { add | remove } ] <secondary_vlans> } | { no private-vlan mapping [ <secondary_vlans> ] }
```

Syntax Description

Syntax Description		
private-vlan		Configure a private VLAN
mapping		Set the private VLAN interface mapping
add	(Optional)	Add a VLAN to private VLAN list
remove	(Optional)	Remove a VLAN from private VLAN list
no		Negate a command or set its defaults
<i>secondary_vlans</i>		Secondary VLAN IDs of the private VLAN interface mapping

Command Mode

- /exec/configure/if-vlan

private-vlan release resource

```
private-vlan release resource { [ vlan <vlan-id> ] | global }
```

Syntax Description

Syntax Description

private-vlan	Show information about private VLAN
release	release
resource	resource
vlan	(Optional) VLAN status
global	global rid
<i>vlan-id</i>	(Optional) VLAN IDs of the private VLANs to be configured

Command Mode

- /exec

private-vlan synchronize

private-vlan synchronize

Syntax Description

Syntax Description	private-vlan Set private-vlan synchronization
	synchronize Synchronize vlans

Command Mode

- /exec/configure/spanning-tree/mst/configuration

probe-interval

probe-interval <probeinterval-val> | no probe-interval

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
probe-interval		OpenFlow controller probe interval timer (default is 180 seconds)
<i>probeinterval-val</i>		probe interval timer value in secs

Command Mode

- /exec/configure/openflow/switch

probe-interval

probe-interval <probeinterval-val> | no probe-interval

Syntax Description

Syntax Description	
no	Negate a command or set its defaults
probe-interval	OpenFlow controller probe interval timer (default is 180 seconds)
<i>probeinterval-val</i>	probe interval timer value in secs

Command Mode

- /exec/configure/openflow/switch/sub-switch

probe

[no] probe <probe-id> [control <status>] [host <host-name>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>]

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		Catena device-group node probe
<i>probe-id</i>		Probe mode
control	(Optional)	control protocol
<i>status</i>	(Optional)	control protocol status
host	(Optional)	Host name/Target address
<i>host-name</i>	(Optional)	DNS Target IP Address or Hostname
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/catena-device-grp

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/itd-dg-node

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> |
 retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/itd-device-group

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> |
retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/itd-device-group

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		PLB probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		PLB probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		PLB probe
<i>probe-id-icmp</i>		Service mode
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/plb-device-group

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-http</i>	Service mode
get	Host name/Target address
<i>url-name</i>	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional) Use cache
frequency	(Optional) Frequency
<i>freq-num</i>	(Optional) Frequency
timeout	(Optional) Timeout
<i>timeout</i>	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-http</i>		Service mode
get		Host name/Target address
<i>url-name</i>	(Optional)	Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional)	Use cache
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-http</i>	Service mode
get	Host name/Target address
<i>url-name</i>	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional) Use cache
frequency	(Optional) Frequency
<i>freq-num</i>	(Optional) Frequency
timeout	(Optional) Timeout
<i>timeout</i>	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe get

[no] probe <probe-id-http> get <url-name> [cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-http</i>	Service mode
get	Host name/Target address
<i>url-name</i>	Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional) Use cache
frequency	(Optional) Frequency
<i>freq-num</i>	(Optional) Frequency
timeout	(Optional) Timeout
<i>timeout</i>	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe get

[no] probe <probe-id-http> get <url-name> [cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id-http</i>	Service mode
get	Host name/Target address
<i>url-name</i>	Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional) Use cache
frequency	(Optional) Frequency
<i>freq-num</i>	(Optional) Frequency
timeout	(Optional) Timeout
<i>timeout</i>	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe get

[no] probe <probe-id-http> get <url-name> [cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-http</i>		Service mode
get		Host name/Target address
<i>url-name</i>		Specify only the user input text/filename. http://<node-ip>/<user input>
cache	(Optional)	Use cache
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/itd-device-group

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/itd-device-group

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/itd-device-group

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		PLB probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		PLB probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		PLB probe
<i>probe-id-dns</i>		Service mode
host		Host name/Target address
<i>host-name</i>		DNS Target IP Address or Hostname
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/plb-device-group

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id</i>		Service mode
port		Port
<i>port-num</i>		Port number
control	(Optional)	control protocol
<i>status</i>	(Optional)	control protocol status
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id</i>		Service mode
port		Port
<i>port-num</i>		Port number
control	(Optional)	control protocol
<i>status</i>	(Optional)	control protocol status
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id</i>		Service mode
port		Port
<i>port-num</i>		Port number
control	(Optional)	control protocol
<i>status</i>	(Optional)	control protocol status
frequency	(Optional)	Frequency
<i>freq-num</i>	(Optional)	Frequency
timeout	(Optional)	Timeout
<i>timeout</i>	(Optional)	Timeout
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/itd-device-group

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
<i>probe-id</i>	Service mode
port	Port
<i>port-num</i>	Port number
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id</i>		Service mode
port		Port
<i>port-num</i>		Port number
control	(Optional)	control protocol
<i>status</i>	(Optional)	control protocol status
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		ITD probe
<i>probe-id</i>		Service mode
port		Port
<i>port-num</i>		Port number
control	(Optional)	control protocol
<i>status</i>	(Optional)	control protocol status
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/itd-device-group

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		PLB probe
<i>probe-id</i>		Service mode
port		Port
<i>port-num</i>		Port number
control	(Optional)	control protocol
<i>status</i>	(Optional)	control protocol status
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count
ip	(Optional)	ip address for probe
<i>ip-addr</i>	(Optional)	IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	PLB probe
<i>probe-id</i>	Service mode
port	Port
<i>port-num</i>	Port number
control	(Optional) control protocol
<i>status</i>	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
<i>freq-num</i>	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
<i>timeout</i>	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
<i>count</i>	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
<i>up-count</i>	(Optional) Count
ip	(Optional) ip address for probe
<i>ip-addr</i>	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
probe		PLB probe
<i>probe-id</i>		Service mode
port		Port
<i>port-num</i>		Port number
control	(Optional)	control protocol
<i>status</i>	(Optional)	control protocol status
frequency	(Optional)	Frequency in seconds
<i>freq-num</i>	(Optional)	Frequency in seconds
timeout	(Optional)	Timeout in seconds
<i>timeout</i>	(Optional)	Timeout in seconds
retry-down-count	(Optional)	Retry-count when node goes down
<i>count</i>	(Optional)	Count
retry-up-count	(Optional)	Retry-count when node comes back up
<i>up-count</i>	(Optional)	Count

Command Mode

- /exec/configure/plb-device-group

promiscuous-mode off

promiscuous-mode { off | on } | no promiscuous-mode [{ off | on }]

Syntax Description

Syntax Description

no	Negate a command or set its defaults
promiscuous-mode	Configure promiscuous mode for the port
off	Disable promiscuous mode
on	Enable promiscuous mode

Command Mode

- /exec/configure/if-port-channel /exec/configure/if-ethernet-all /exec/configure/if-eth-base

propagate-sgt

[no] propagate-sgt

Syntax Description

Syntax Description

propagate-sgt Enable SGT propagation from this port (the default use the no form to disable)

Command Mode

- /exec/configure/cts-dot1x /exec/configure/cts-manual

protection

[no] protection | protection [fast-reroute [bw-protect]]

Syntax Description

Syntax Description

no Negate a command or set its defaults

protection Enable failure protection

fast-reroute (Optional) Enable fast-reroute failure protection

bw-protect (Optional) Enable BW protection

Command Mode

- /exec/configure/te/lsp-attr

protocol-version

protocol-version { <10> | <13> | negotiate } | no protocol-version

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
protocol-version		Set OpenFlow protocol version
10		Use only OF 1.0 protocol to connect to controller
13		Use only OF 1.3 protocol to connect to controller
negotiate		Negotiate protocol with controller

Command Mode

- /exec/configure/openflow/switch

protocol-version

protocol-version { <10> | <13> | negotiate } | no protocol-version

Syntax Description

Syntax Description		
no		Negate a command or set its defaults
protocol-version		Set OpenFlow protocol version
10		Use only OF 1.0 protocol to connect to controller
13		Use only OF 1.3 protocol to connect to controller
negotiate		Negotiate protocol with controller

Command Mode

- /exec/configure/openflow/switch/sub-switch

protocol

{ protocol <num> } | { no protocol }

Syntax Description

Syntax Description

no Negate a command or set its defaults

protocol specify flow protocol number

num flow protocol number

Command Mode

- /exec/configure/configngoamprofileflow

protocol shutdown

[no] protocol shutdown

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
protocol	OSPF protocol
shutdown	Shutdown the OSPF protocol instance

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

protocol shutdown

[no] protocol shutdown

Syntax Description

Syntax Description	no (Optional) Negate a command or set its defaults
	protocol OSPF protocol
	shutdown shutdown the OSPF protocol instance

Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

ptp

[no] ptp

Syntax Description

Syntax Description	no (Optional) Negate a command or set its defaults
	ptp Precision Time Protocol (IEEE 1588) Subsystem

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp announce interval

```
[no] ptp announce interval { <log-seconds> | smpte-2059-2 <smpte-log-seconds> | aes67 <aes-log-seconds>
}
```

Syntax Description

Syntax Description		
ptp		Precision Time Protocol (IEEE 1588) Subsystem
announce		announce
interval		interval
<i>log-seconds</i>		log seconds
smpte-2059-2		SMPTE-2059-2
<i>smpte-log-seconds</i>		SMPTE-2059-2 log seconds
aes67		AES67-2015
<i>aes-log-seconds</i>		AES67-2015 log seconds

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp announce timeout

[no] ptp announce timeout { <val> | smpte-2059-2 <smpte-val> | aes67 <aes-val> }

Syntax Description

Syntax Description		
ptp		Precision Time Protocol (IEEE 1588) Subsystem
announce	announce	
timeout	timeout	
smpte-2059-2		SMPTE-2059-2
aes67		AES67-2015
<i>val</i>	<i>val</i>	
<i>smpte-val</i>		SMPTE-2059-2 <i>val</i>
<i>aes-val</i>		AES67-2015 <i>val</i>

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp delay-request minimum interval

[no] ptp delay-request minimum interval { <log-seconds> | smpte-2059-2 <smpte-log-seconds> | aes67 <aes-log-seconds> }

Syntax Description

Syntax Description		
ptp		Precision Time Protocol (IEEE 1588) Subsystem
delay-request		delay-request
minimum		minimum
interval		interval
smpte-2059-2		SMPTE-2059-2
aes67		AES67-2015
<i>log-seconds</i>		log seconds
<i>smpte-log-seconds</i>		SMPTE-2059-2 log seconds
<i>aes-log-seconds</i>		AES67-2015 log seconds

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp domain

[no] ptp domain <domain-val>

Syntax Description

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
-----	---

domain	ptp clock domain
--------	------------------

<i>domain-val</i>	Enter domain value
-------------------	--------------------

Command Mode

- /exec/configure

ptp offload

[no] ptp offload

Syntax Description

Syntax Description

ptp Precision Time Protocol (IEEE 1588) Subsystem

offload Allows increasing number of PTP sessions per system by offloading some timers to linecard

Command Mode

- /exec/configure

ptp priority1

[no] ptp priority1 <val>

Syntax Description

Syntax Description	<code>ptp</code>	Precision Time Protocol (IEEE 1588) Subsystem
	<code>priority1</code>	<code>priority1</code>
	<code>val</code>	<code>priority1</code>

Command Mode

- /exec/configure

ptp priority2

[no] ptp priority2 <val>

Syntax Description

Syntax Description	<i>ptp</i>	Precision Time Protocol (IEEE 1588) Subsystem
	<i>priority2</i>	<i>priority1</i>
	<i>val</i>	<i>priority2</i>

Command Mode

- /exec/configure

ptp source

```
[no] ptp source <src-ip> [ vrf { <vrf-name> | <vrf-cfg-name> } ]
```

Syntax Description

Syntax Description		
ptp		Precision Time Protocol (IEEE 1588) Subsystem
source		source IP address
<i>src-ip</i>		IPv4 address (A.B.C.D) of source
vrf		(Optional) vrf to be used for hello messages
<i>vrf-name</i>		(Optional) vrf to be used for hellos
<i>vrf-cfg-name</i>		(Optional) Configurable VRF name

Command Mode

- /exec/configure

ptp sync interval

[no] ptp sync interval { <log-seconds> | smpte-2059-2 <smpte-log-seconds> | aes67 <aes-log-seconds> }

Syntax Description

Syntax Description		
ptp		Precision Time Protocol (IEEE 1588) Subsystem
sync		sync
interval		interval
smpte-2059-2		SMPTE-2059-2
aes67		AES67-2015
<i>log-seconds</i>		log seconds
<i>smpte-log-seconds</i>		SMPTE-2059-2 log seconds
<i>aes-log-seconds</i>		AES67-2015 log seconds

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp time-sync

[no] ptp time-sync <value>

Syntax Description

Syntax Description	<i>ptp</i>	Precision Time Protocol (IEEE 1588) Subsystem
	<i>time-sync</i>	ptp time sync register
	<i>value</i>	default reg value 0x40000000

Command Mode

- /exec/configure

ptp transport ipv4 ucast master

[no] ptp transport ipv4 ucast master

Syntax Description

Syntax Description	
no	(Optional) Negate a command or set its defaults
ptp	Precision Time Protocol (IEEE 1588) Subsystem
transport	unicast support
ipv4	ipv4
ucast	ipv4 unicast
master	master mode

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp transport ipv4 ucast slave

[no] ptp transport ipv4 ucast slave

Syntax Description

Syntax Description		
no	(Optional)	Negate a command or set its defaults
ptp		Precision Time Protocol (IEEE 1588) Subsystem
transport	unicast	support
ipv4	ipv4	
ucast	ipv4	unicast
slave	slave	mode

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp ucast-source

```
[no] ptp ucast-source <src-ip> [ vrf { <vrf-name> | <vrf-cfg-name> } ]
```

Syntax Description

Syntax Description	ptp	Precision Time Protocol (IEEE 1588) Subsystem
	ucast-source	source IP address for ucast messages
	<i>src-ip</i>	IPv4 address (A.B.C.D) of source
	vrf	(Optional) vrf to be used for hello messages
	<i>vrf-name</i>	(Optional) vrf to be used for hellos
	<i>vrf-cfg-name</i>	(Optional) Configurable VRF name

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp vlan

[no] ptp vlan <vlan>

Syntax Description

Syntax Description

ptp Precision Time Protocol (IEEE 1588) Subsystem

vlan vlan

vlan vlan

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

publish-event sub-system type

```
publish-event sub-system <sub-system-id> type <event-type> { [ arg1 <data1> ] [ arg2 <data2> ] [ arg3
<data3> ] [ arg4 <data4> ] }
```

Syntax Description

Syntax Description

publish-event	Publish an application specific event
sub-system	Sub-system ID to which the application event belongs
<i>sub-system-id</i>	Sub-system ID value
type	Event type value
<i>event-type</i>	Event type value
arg1	(Optional) User specified data to be passed when the event is published
<i>data1</i>	(Optional) User specified data value
arg2	(Optional) User specified data to be passed when the event is published
<i>data2</i>	(Optional) User specified data value
arg3	(Optional) User specified data to be passed when the event is published
<i>data3</i>	(Optional) User specified data value
arg4	(Optional) User specified data to be passed when the event is published
<i>data4</i>	(Optional) User specified data value

Command Mode

- /exec

purge ip route

```
purge ip route [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] <all>
```

Syntax Description

Syntax Description		
purge		Purge
ip		IPv4
route		Purge routing information
vrf		(Optional) VRF
<i>vrf-name</i>		(Optional) VRF name
<i>vrf-known-name</i>		(Optional) Known VRF name
vrf-all		(Optional) Display information for all VRFs
all		Purge all routes

Command Mode

- /exec

purge ipv6 route

```
purge ipv6 route [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] <all>
```

Syntax Description

Syntax Description		
purge		Purge
ipv6		IPv6
route		Purge routing information
vrf		(Optional) VRF
<i>vrf-name</i>		(Optional) VRF name
<i>vrf-known-name</i>		(Optional) Known VRF name
vrf-all		(Optional) Display information for all VRFs
all		Purge all routes

Command Mode

- /exec

purge module running-config

purge module <module> running-config

Syntax Description

Syntax Description

purge	Deletes unused data
module	Purge configuration for non-existent modules
<i>module</i>	Enter module number
running-config	purge running configuration for non-existent modules

Command Mode

- /exec

push

push [<name>]

Syntax Description

Syntax Description

push push current mode to stack or save it under name

name (Optional) name

Command Mode

- /global

pwd

pwd

Syntax Description

Syntax Description

pwd View current directory

Command Mode

- /exec

python

python [<uri> [<pyargs>] +]

Syntax Description

Syntax Description

`python` run a python command/script, or enter python mode (if no arg)

uri (Optional) path to a python file

pyargs (Optional) python command line arguments (maximum 32)

Command Mode

- /exec

python execute virtual-service command

python execute virtual-service <service> command [<pyargs>] +

Syntax Description

Syntax Description

python	run a python command/script, or enter python mode (if no arg)
execute	execute a virtual service command
virtual-service	virtual service to execute the command
command	command to execute
<i>service</i>	name of existing virtual service
<i>pyargs</i>	(Optional) command and args (maximum 32)

Command Mode

- /exec

python instance

[no] python instance <inst> [<uri> [<pyargs>] +] | python instance <inst> <uri> [<pyargs>] +

Syntax Description

Syntax Description

<i>no</i>	Negate a command or set its defaults
<i>python</i>	run a python command/script, or enter python mode (if no arg)
<i>instance</i>	label with an instance number
<i>inst</i>	instance number
<i>uri</i>	(Optional) path to a python file
<i>pyargs</i>	(Optional) python command line arguments (maximum 32)

Command Mode

- /exec/configure

