



W Commands

- [wait-igp-convergence](#), on page 2
- [watch](#), on page 3
- [watch service action apply-acl](#), on page 4
- [wc](#), on page 5
- [wedge bmc ip-addr](#), on page 6
- [weight](#), on page 7
- [weight](#), on page 8
- [weight](#), on page 9
- [weight](#), on page 10
- [weighting](#), on page 11
- [where](#), on page 12
- [where detail](#), on page 13
- [which](#), on page 14
- [wide-metric-only](#), on page 15
- [window-size](#), on page 16
- [wred-queue qos-group-map queue-only](#), on page 17
- [write erase](#), on page 18
- [write erase boot](#), on page 19
- [write erase debug](#), on page 20
- [wrr-queue qos-group-map](#), on page 21
- [wrr unicast-bandwidth](#), on page 22

wait-igp-convergence

[no] wait-igp-convergence

Syntax Description

no	(Optional) Negate a command or set its defaults
wait-igp-convergence	Delay initial bestpath until redistributed IGP's have converged

Command Mode

- /exec/configure/router-bgp/router-bgp-af-ipv4 /exec/configure/router-bgp/router-bgp-vrf-af-ipv4
/exec/configure/router-bgp/router-bgp-af-ipv6 /exec/configure/router-bgp/router-bgp-vrf-af-ipv6

watch

watch [differences] [interval <time>] <watch_cmd>

Syntax Description

watch	execute a program periodically
differences	(Optional) highlight the differences
interval	(Optional) watch interval
<i>time</i>	(Optional) interval in seconds
<i>watch_cmd</i>	enter the command you want to watch

Command Mode

- /exec

watch service action apply-acl

[no] watch service <service-name> action apply-acl <acl-name> | no watch service

Syntax Description

no	(Optional) Negate a command or set its defaults
watch	Watch a pod/service
service	The pod or service to watch
<i>service-name</i>	Name of the service/pod to watch
action	Action to be applied
apply-acl	Change ACL config
<i>acl-name</i>	Name of the acl to apply

Command Mode

- /exec/configure/kubernetes

WC

| wc [-c | -l | -w]

Syntax Description

	Pipe command output to filter
wc	Count words, lines, characters
-c	(Optional) Output character count
-l	(Optional) Output line count
-w	(Optional) Output word count

Command Mode

- /output

wedge bmc ip-addr

[no] wedge bmc ip-addr <ip>

Syntax Description

no	(Optional) Negate a command or set its defaults
wedge	Configure wedge Board Management controller ip address
bmc	Board Management Controller ip address
ip-addr	BMC ip address
<i>ip</i>	ip address

Command Mode

- /exec/configure

weight

{ weight <weight> } | { { no | default } weight [<weight>] }

Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
weight	Set default weight for routes from this neighbor
<i>weight</i>	Default weight

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af
/exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv4
/exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv6
/exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-label
/exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-label

weight

{ weight <weight> } | { { no | default } weight [<weight>] }

Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
weight	Set default weight for routes from this neighbor
<i>weight</i>	Default weight

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mdt

weight

[no] weight <weight-value>

Syntax Description

no	(Optional) Negate a command or set its defaults
weight	weight for traffic distribution
<i>weight-value</i>	weight value

Command Mode

- /exec/configure/itd-dg-node

weight

weight <weight-value> | no weight

Syntax Description

no	Negate a command or set its defaults
weight	Configure weight of node for traffic distribution
<i>weight-value</i>	weight value

Command Mode

- /exec/configure/plb-dg-node

weighting

weighting { <weight-max-val> [lower <low-thresh> [upper <upper-thresh>] | upper <upper-thresh>] | track <track-obj> [decrement <dec-val>] } | no weighting [{ <weight-max-val> [lower <low-thresh> [upper <upper-thresh>] | upper <upper-thresh>] | track <track-obj> [decrement <dec-val>] }]

Syntax Description

no	Negate a command or set its defaults
weighting	Gateway weighting and tracking
<i>weight-max-val</i>	Weighting maximum value
lower	(Optional) Weighting lower threshold
<i>low-thresh</i>	(Optional) Weighting lower threshold value
upper	(Optional) Weighting upper threshold
<i>upper-thresh</i>	(Optional) Weighting upper threshold value
track	Interface tracking
<i>track-obj</i>	Tracked object
decrement	(Optional) Weighting decrement
<i>dec-val</i>	(Optional) Decrement value 1 255

Command Mode

- /exec/configure/if-eth-any/glbp

where

where

Syntax Description

where	shows the cli context you are in
-------	----------------------------------

Command Mode

- /global

where detail

where detail

Syntax Description

where	shows the cli context you are in
detail	shows each entry on separate line

Command Mode

- /global

which

which

Syntax Description

which	shows which cli commands are available in current mode (see also 'show cli syntax' which has more options)
-------	--

Command Mode

- /global

wide-metric-only

[no] wide-metric-only

Syntax Description

no	(Optional) Negate a command or set its defaults
wide-metric-only	Advertise only wide metric

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

window-size

[no] window-size <size>

Syntax Description

window-size	Configure Window size
<i>size</i>	window size value

Command Mode

- /exec/configure/macsec-policy

wred-queue qos-group-map queue-only

[no] wred-queue qos-group-map queue-only { <qid> }

Syntax Description

no	(Optional) Negate the command
wred-queue	Enable queue based ECN marking for specific qos-group
queue-only	Enable queue based ECN marking
qos-group-map	Qid value
<i>qid</i>	Provide qos-group value

Command Mode

- /exec/configure

write erase

write erase

Syntax Description

write	Write current configuration
erase	Destroys the configuration on persistent media

Command Mode

- /exec

Usage Guidelines

You can erase the configuration on your device to return to the configuration defaults. In this context, **configuration** refers to the startup configuration as displayed by the **show startup** command. No other internal application or process states are cleared. To remove all application persistency files such as patch rpms, third party rpms, and application configuration in the /etc directory other than configuration, use the **install reset** command.

write erase boot

write erase boot

Syntax Description

write	Write current configuration
erase	Destroys the configuration on persistent media
boot	Destroys boot configuration on persistent media

Command Mode

- /exec

write erase debug

write erase debug

Syntax Description

write	Write current configuration
erase	Destroys the configuration on persistent media
debug	Destroys debug configuration on persistent media

Command Mode

- /exec

wrr-queue qos-group-map

[no] wrr-queue qos-group-map <qid> { <cos> } +

Syntax Description

no	(Optional) Negate the command
wrr-queue	Map traffic priority (QG) values to L3 Multicast Queues
qos-group-map	Qid value
<i>qid</i>	Provide qid value
<i>cos</i>	Provide qos-group-map value

Command Mode

- /exec/configure

wrr unicast-bandwidth

[no] wrr unicast-bandwidth <bw>

Syntax Description

no	(Optional) Negate the command
wrr	Configure Unicast Traffic Bandwidth Percentage
unicast-bandwidth	Specify rate as percentage of interface data-rate
<i>bw</i>	Value in percentage (Default is set to 50)

Command Mode

- /exec/configure